


Product: 1986 Cummins C Series Engine 6C8.3/6CT8.3/6CTA8.3 Service Repair Workshop Manual
Full Download: <https://www.arepairmanual.com/downloads/1986-cummins-c-series-engine-6c8-3-6ct8-3-6cta8-3-service-repair-workshop-manual>


This manual provides instructions for complete rebuild of the "C" Series Engine. This version of the manual was written for Models 6C8.3, 6CT8.3 and 6CTA8.3.



The content of this manual is based on the most current information at the time of publication approval and is subject to change without notice.

Product: 1986 Cummins C Series Engine 6C8.3/6CT8.3/6CTA8.3 Service Repair Workshop Manual
Full Download: <https://www.arepairmanual.com/downloads/1986-cummins-c-series-engine-6c8-3-6ct8-3-6cta8-3-service-repair-workshop-manual/>

Cummins Small Engine C Series



Sample of manual. Download All 257 pages at:
<https://www.arepairmanual.com/downloads/1986-cummins-c-series-engine-6c8-3-6ct8-3-6cta8-3-service-repair-w>

Shop Manual

Table of Contents

	Page
Introduction	i-5
Group 0 - Engine Disassembly and Assembly	0-1
Group 1 - Cylinder Block	1-1
Group 2 - Cylinder Head	2-1
Group 3 - Rocker Levers	3-1
Group 4 - Tappets and Push Rods.....	4-1
Group 5 - Fuel System	5-1
Group 6 - Injectors and Fuel Lines	6-1
Group 7 - Lubricating System	7-1
Group 8 - Cooling System.....	8-1
Group 9 - Drive Units	9-1
Group 10 - Air Intake System	10-1
Group 11 - Exhaust System.....	11-1
Group 12 - Air Equipment	12-1
Group 13 - Electrical Equipment.....	13-1
Group 14 - Engine Testing	14-1
Group 16 - Mounting Adaptations	16-1

Introduction

Table of Contents

	Page
Abbreviations Used in this Manual	i-25
About the Manual	i-6
Capscrew Markings and Torque Values - Metric	i-19
C Series Lubricants	i-24
C Series Sealants	i-23
C Series Torque Specifications.....	i-20
Engine Data Plate	i-15
External Engine Components.....	i-17
Fuel Pump Data Plate (Name Plate)	i-16
General Cleaning Instructions	i-26
• Solvent and Acid	
• Steam	
General Rebuild Instructions.....	i-7
General Safety Instructions	i-8
General Torque Specifications.....	i-19
Generic Symbols	i-10
How to Identify Your Engine	i-15
Illustrations	i-14
Tools Required to Rebuild the C Series Engine.....	i-27

About the Manual

The procedures in this manual were developed for a shop environment with engine disassembly and assembly being performed on a rollover stand. A Group System has been used to subdivide the instructions by major components and systems. Refer to the Table of Contents (page i-3) for the various groups. The information is presented in very basic terms to make sure the instructions are easily understood. Wrench sizes and shop tooling are identified in the procedure when needed.

Each group contains the following in sequence:

- An Alphabetical Table of Contents (Index).
- Exploded view(s) of all the components in the group.
- General Information Section(s) containing the basic service, maintenance, and design information necessary to assist in the rebuild of the engine or a component.
- Procedural instructions for the disassembly, inspection, repair, and assembly that can be required to rebuild an engine. Additional repairs that are not essential during every rebuild, but can be necessary, are included. These repairs depend on the length of time an engine has been in service and the condition of the parts.

General Rebuild Instructions

The C Series Engine incorporates the latest diesel technology, yet it is designed to be rebuilt using existing repair practices performed to quality standards.

Observe all of the safety precautions noted in the procedures.

Provide a clean environment and follow the cleaning instructions specified in the procedures.

Cleanliness is an important consideration during repair of a diesel engine. Built-in contamination can reduce the life of an engine.

Perform the inspections specified in the procedures.

Replacement of worn and damaged parts is also necessary for a successful rebuild - the engine cannot be better than its components.

The dimensions given for a part such as a cylinder bore include the minimum dimension of a new part and the maximum dimension of a part that can be reused. The dimensions of a part such as a crankshaft include the maximum dimension of a new part and the minimum dimension of a part that can be reused. Replace or recondition the parts worn beyond the limits given.

Use genuine Cummins new or ReCon® service parts and assemblies.

The assembly instructions have been written for reusing as many parts and assemblies as is practical. When it is necessary to replace a part or assembly, the procedure is based on the use of new or ReCon® parts. However, some of the major components such as the cylinder block and head can be restored to usable condition by machining. Refer to the Alternative Repair Manual or contact your nearest Cummins Distributor for the correct procedures. All of the rebuild service described in this manual is available from all Cummins Distributors and many Dealer locations.

Follow the specified disassembly and assembly procedures to avoid damaging the parts and to ensure the components are properly assembled and tightened.

In-chassis repair instructions are available in the Troubleshooting and Repair Manual Bulletin Number 3810261, which can be ordered or purchased from a local Cummins Distributor.

The contents of this manual are based on information in effect at the time of publications approval and are subject to change without notice.

Comply with the manufacturer's recommendations for cleaning solvents and other substances used in connection with the rebuild of the engine. Also, observe good safety practices regarding the use of tools and machines.

General Safety Instructions

Important Safety Notice

Read and understand all safety precautions and warnings before performing repairs.



This symbol appears in the manual when a potential safety hazard exists that can cause personal injury or death. These hazards are not always apparent to a trained mechanic.

It is not possible for Cummins Engine Co., Inc. to anticipate every possible circumstance that can involve a potential hazard.



Warning: Cummins Engine Company, Inc. does not recommend or authorize any modifications or repairs to engines or components except for those detailed in **CUMMINS SERVICE INFORMATION**.

In particular, unauthorized repair to safety-related components can cause personal injury. Below is a partial listing of components classified as safety-related:

- Air Compressor
- Air Controls
- Air Shutoff Assemblies
- Balance Weights
- Cooling Fan
- Fan Hub Assembly
- Fan Mounting Bracket(s)
- Fan Mounting Capscrews
- Fan Hub Spindle
- Flywheel
- Flywheel Crankshaft Adapter
- Flywheel Mounting Capscrews
- Fuel Shutoff Assemblies
- Fuel Supply Tubes
- Lifting Brackets
- Throttle Controls
- Turbocharger Compressor Casing
- Turbocharger Oil Drain Line(s)
- Turbocharger Oil Supply Line(s)
- Turbocharger Turbine Casing
- Vibration Damper Mounting Capscrews

Read and understand all of the safety precautions and warnings before performing any repair. This list contains the general safety precautions that must be followed to provide personal safety. Special safety precautions are included in the procedures when they apply.



Be sure the work area surrounding the product is safe. Be aware of hazardous conditions that can exist.



Always wear protective glasses and protective shoes when working.



Do not wear loose-fitting or torn clothing. Remove all jewelry such as rings, watches, etc., when working.



Disconnect the battery and discharge any capacitors before beginning any repair work. Disconnect the air starter if equipped to prevent accidental engine starting. Put a "Do Not Operate" tag in the operator's compartment or on the controls.

General Safety Instructions

Important Safety Notice



Use **ONLY** the proper engine barring techniques for manually rotating the engine. Do not attempt to rotate the engine by pulling or prying on the fan. This practice can cause serious personal injury, property damage, or damage to the fan blade(s) causing premature fan failure.



If an engine has been operating and the coolant is hot, allow the engine to cool before you slowly loosen the filler cap and relieve the pressure from the cooling system.



Do not work on anything that is supported **ONLY** by lift jacks or a hoist. Always use blocks or proper stands to support the product before performing any service work.



Relieve all pressure in the air, oil, and the cooling systems before any lines, fittings, or related items are removed or disconnected. Be alert for possible pressure when disconnecting any device from a system that utilizes pressure. Do not check for pressure leaks with your hand. High pressure oil or fuel can cause personal injury.



To prevent suffocation and frostbite, wear protective clothing and **ONLY** disconnect liquid refrigerant (freon) lines in a well ventilated area.



To avoid personal injury, use a hoist or get assistance when lifting components that weigh 23 kg [50 lbs] or more. Be sure all chains, hooks, slings, etc., are in good condition and are of the correct capacity. Be sure hooks are positioned correctly. Always use a spreader bar when necessary. The lifting hooks must not be side-loaded.



Corrosion inhibitor contains alkali. Do not get the substance in your eyes. Avoid prolonged or repeated contact with skin. Do not swallow internally. In case of contact, immediately wash skin with soap and water. In case of eye contact, immediately flood eyes with large amounts of water for a minimum of 15 minutes. **IMMEDIATELY CALL A PHYSICIAN. KEEP OUT OF REACH OF CHILDREN .**



Naptha and Methyl Ethyl Ketone (MEK) are flammable materials and must be used with caution. Follow the manufacturer's instructions to provide complete safety when using these materials. **KEEP OUT OF REACH OF CHILDREN.**



To avoid burns, be alert for hot parts on products that have just been turned **OFF**, and hot fluids in lines, tubes, and compartments.



Always use tools that are in good condition. Be sure you understand how to use them before performing any service work. Use **ONLY** genuine Cummins or Cummins Recon® replacement parts.



Always use the same fastener part number (or equivalent) when replacing fasteners. Do not use a fastener of less quality if replacements are necessary.

Generic Symbols

The following group of symbols have been used in this manual to help communicate the intent of the instructions. When one of the symbols appears, it conveys the meaning defined below.



WARNING - Serious personal injury or extensive property damage can result if the warning instructions are not followed.



CAUTION - Minor personal injury can result or a part, an assembly or the engine can be damaged if the caution instructions are not followed.



Indicates a **REMOVAL** or **DISASSEMBLY** step.



Indicates an **INSTALLATION** or **ASSEMBLY** step.



INSPECTION is required.



CLEAN the part or assembly.



PERFORM a mechanical or time **MEASUREMENT**.



LUBRICATE the part or assembly.



Indicates that a **WRENCH** or **TOOL SIZE** will be given.



TIGHTEN to a specific torque.



PERFORM an electrical **MEASUREMENT**.



Refer to another location in this manual or another publication for additional information.



The component weighs 23 kg [50 lb] or more. To avoid personal injury, use a hoist or get assistance to lift the component.




Illustrations

The illustrations used in this manual are intended to give an example of a problem, show what to look for and where to look for the problem. Most of the illustrations are generic and might not look exactly like the engine or parts used in your application. Some illustrations contain symbols to indicate an action required and an acceptable or unacceptable condition.

Unacceptable




Acceptable



**Direction of Movement
(Action)**

Engine Dataplate


The engine dataplate shows specific information about your engine. The engine serial number (1) and Control Parts List (CPL) (2) provide information for ordering parts and service needs.




Cummins Engine Company, Inc. Box 3005 Columbus, Indiana 47202-3005	Engine	C.I.D./L.	Series	CPL	Engine Series No. 44005816	
	Cert. I.D.	305/8.3	C	0602	Injector P/N. 3907669	
Timing-TDC		22/BTDC		Cust. Spec. 50030		
Valve lash cold		.010 in. Int. .020 in. Exh.		Rated HP 204 at 2200 RPM		
Firing Order		153624		Fuel rate at rated HP 100 mm ³ /stroke		
Low Idle RPM		750	E.C.S.	NONE		Model Name 6CT8.3
Date of Mfg.		3/20/85		Made in U.S.A.		

How to Identify Your Engine


The model name provides the following engine data:





Fuel Pump Dataplate (Nameplate)

The fuel pump dataplate is located on the side of the fuel pump. It provides information for fuel pump calibration.




The Cummins part number for the fuel pump-governor combination is located on the governor dataplate.


External Engine Components

The pictures which follow show the locations of the major external engine components, the filters, and other service and maintenance points. Some external components will be at different locations for different engine models.



NOTE: The pictures are only a reference to show a typical engine.



Fuel Pump Side View



Rear View




General Torque Specification

The C series engine uses parts that are of metric dimensions.

Always use caution to be sure that capscrews from the engine are put back in their proper locations.

When replacing capscrews, always use a capscrew of the same measurement and strength as the capscrew being replaced. Incorrect capscrews can result in engine damage.

Metric Capscrew Nomenclature



Capscrew Markings and Torque Values - Metric

Metric capscrews are identified by the grade number stamped on the head of the capscrew or on the surface of metric nuts. The higher the number, the greater the strength of the capscrew.

Commercial Steel Class			
Thread Diameter	Torque	Torque	Torque
mm	N•m [ft-lb]	N•m [ft-lb]	N•m [ft-lb]
5	6 [5]	8 [6]	8 [6]
6	10 [5]	15 [10]	15 [10]
8	24 [18]	34 [25]	38 [28]
10	43 [32]	64 [47]	88 [57]
12	77 [57]	112 [83]	137 [101]
14	127 [94]	180 [133]	216 [159]
16	195 [144]	266 [196]	319 [235]

Notes:

1. Do not use these values when the torque values are specified in another section of the manual.
2. These values are based on clean, dry threads. Reduce the value by 10% when a lubricant is used. Reduce the value by 20% if new plated capscrews are used.

When the correct capscrew length is not known, apply the following general rule:

$$\text{Capscrew Length} = \text{Thread Engagement} + \text{Mounting Flange Width} + \text{Washer (Lock and Plain) Width.}$$

- The minimum Thread Engagement depends on the material the threads are machined in.
 - If the material is **cast iron or steel**, multiply the thread diameter by 1.5.
 - If the material is **aluminum**, multiply the thread diameter by 2.

C Series Torque Specifications

Socket Or Wrench Size mm (Inch)	Fastener	Torque ± N•m	(Ft-Lb)
10	Aftercooler Mounting	24 ± 3	(18)
8	Aftercooler Water Hose Clamp	5 ± 1	(4)
(15/16)	Air Compressor Gear Nut	125 ± 3	(93)
18	Air Compressor Mounting Nut	77 ± 7	(57)
19 & (9/16)	Air Compressor to Brace	43 ± 4	(32)
24	Air Compressor Water Line	35 ± 10	(25)
(15/16)	Alternator Pulley Nut	80 ± 8	(59)
8 Allen	(Alternator Shaft)		
13	Alternator Link (Delco 10 SI)	24 ± 3	(18)
16	Alternator Link (Delco 15 SI)	43 ± 4	(32)
19	Alternator Link (Delco 20-27 SI)	43 ± 4	(32)
13	Alternator Mounting Bolt (10-15 SI)	43 ± 4	(32)
15	Alternator Mounting Bolt (20-27 SI)	77 ± 7	(57)
10	Alternator Mounting Bracket	24 ± 3	(18)
13	Belt Tensioner to Bracket	43 ± 4	(32)
5 Allen	Belt Tensioner Bracket to Block	24 ± 3	(18)
13	Camshaft Thrust Plate	24 ± 3	(18)
12	Connecting Rod	40 ± 5	(30)
 Step 2	80 ± 5	(60)
 Step 3	120 ± 5	(88)
18	Crankshaft Damper	200 ± 12	(148)
8	Crossover Clamp	5 ± 1	(4)
15	Exhaust Manifold	43 ± 4	(32)
16	Exhaust Outlet Pipe Mounting	43 ± 4	(32)
11	Exhaust Outlet Pipe, "V" Band Clamp	5 ± 1	(4)
10	Fan Bracket Mounting	24 ± 3	(18)
13	Fan Hub (50mm Bolt Circle)	24 ± 3	(18)
16	Fan Hub (60 mm Bolt Circle)	43 ± 4	(32)
24	Flame Start Aid	40 ± 4	(30)
19	Flywheel	137 ± 7	(101)
18	Flywheel Housing	60 ± 6	(45)
10	Flywheel Housing Cover	24 ± 3	(18)
(1/2)	Flywheel Housing Drain Plug	43 ± 4	(32)
—	Front Cover Cap	—Hand Tighten—	
15	Front Engine Support Mounting	112 ± 10	(82)
	Front Engine Mounting Without Support	77 ± 7	(57)
17	Fuel Banjo Screw (In Filter Head)	32 ± 3	(24)
Slot	Fuel Vent Screw in Banjo	8 ± 1	(6)
75-80	Fuel Filter	3/4 Turn After Contact	
19	Fuel Low Pressure Supply at Pump	24 ± 3	(18)

C Series Torque Specifications

Socket Or Wrench Size mm (Inch)	Fastener	Torque \pm Nom	(Ft-Lb)
19	Fuel Low Pressure Return at Pump.....	24 \pm 2	(18)
24	Fuel Filter Adapter Nut.....	32 \pm 3	(24)
17	Fuel Line Fitting (High Pressure).....	24 \pm 3	(18)
22	Fuel Pump Drive Gear (A).....	93 \pm 7	(68)
27	Fuel Pump Drive Gear (MW).....	105 \pm 5	(77)
24	Fuel Pump Lock.....	15 \pm 3	(11)
15	Fuel Pump Mounting Nut.....	43 \pm 4	(32)
15	Fuel Solenoid Bracket.....	43 \pm 4	(32)
10	Fuel Solenoid Mounting.....	10 \pm 2	(7)
10	Gear Cover.....	24 \pm 3	(18)
10	Gear Housing-to-Block.....	24 \pm 3	(18)
(7/16)	Gear Housing Pipe Plugs.....	5 \pm 1	(4)
18	Cylinder Head Mounting..... Step 1	50	(37)
 Step 2	150	(110)
 Step 3	200	(148)
10	Injector Fuel Drain Manifold.....	8 \pm 1	(6)
10	Injector Retaining Capscrew.....	24 \pm 3	(18)
10	Intake Manifold Cover.....	24 \pm 3	(18)
10	Lift Pump Mounting/Cover Plate.....	24 \pm 3	(18)
18	Lifting Bracket.....	77 \pm 6	(57)
23	Main Bearing Cap..... Step 1	50	(37)
 Step 2	95	(70)
 Step 3	150	(110)
118-131	Oil Filter.....	3/4 Turn After Contact	
10	Oil Cooler Cover.....	24 \pm 3	(18)
17	Oil Pan Drain Plug.....	80 \pm 4	(60)
17	Oil Pan Heater Plug.....	80 \pm 4	(60)
10	Oil Pan Mounting.....	24 \pm 3	(18)
22	Oil Pressure Regulator Valve.....	80 \pm 4	(60)
10	Oil Pump Mounting.....	24 \pm 3	(18)
10	Oil Suction Tube (Flange).....	9 \pm 1	(7)
10	Oil Suction Tube Brace.....	9 \pm 1	(7)
15	PTO Adapter.....	77 \pm 7	(57)
13	PTO Adapter Cover Plate A Drive.....	43 \pm 4	(32)
15	PTO Adapter Cover Plate B Drive.....	77 \pm 7	(57)
(3/4)	PTO Gear Nut A Drive.....	100 \pm 10	(74)
(15/16)	PTO Gear Nut B Drive.....	134 \pm 13	(100)
(11/16)	PTO Flange Companion.....	85 \pm 8	(63)
10	Rocker Support.....	55 \pm 3	(40.5)

C Series Torque Specifications

Socket Or Wrench Size mm (Inch)	Fastener	Torque \pm N•m	(Ft-Lb)
14	Rocker Lever Nut	24 \pm 3	(18)
15	Starter Mounting (12 Point).....	77 \pm 4	(57)
10	Tach Drive Retainer	3 \pm .5	(2)
10	Thermostat Housing	24 \pm 3	(18)
T-25 Torx	Timing Pin Flange Mounting.....	5 \pm 1	(4)
(1/2)	Turbine Housing.....	11 \pm 2	(8)
10	Turbocharger Compressor.....	8 \pm 1	(6)
15	Turbocharger Mounting Nut.....	32 \pm 3	(24)
10	Turbocharger Drain Tube	24 \pm 3	(18)
16	Turbocharger Oil Supply (Both Ends)	15 \pm 2	(11)
8	Water Hose Clamps	5	(4)
(3/8)	Water Inlet Plugs.....	34 \pm 3	(25)
10	Water Pump Mounting.....	24 \pm 3	(18)
15	Valve Cover.....	24 \pm 3	(18)
—	Valve Cover Oil Fill.....	Hand Tighten	
13	WABCO Air Compressor Gear.....	24 \pm 3	(18)
27	WABCO Gear Hub Mounting Nut	180 \pm 18	(133)

C Series Sealants

Use the sealants listed below or sealants containing equivalent properties.

Description	Sealing Method
1. Pipe Plugs	Precoated teflon or pipe sealer.
2. Gaskets	
a. Oil Pan	K&W Copper Coat [™] - Both Sides Apply Permatex [™] No. 2 to the four "T" joints and smear into the joints with finger until full.
b. Gear Cover	K&W Copper Coat [™] - Both Sides.
c. All Other Gaskets	No sealant required.
3. Cup Plugs	Loctite [™] 277 or Cummins Sealant 3375068.
4. O-rings	No sealant required.
5. Rear Camshaft Expansion Plug	Loctite [™] 277 or Cummins Sealant 3375068.
6. Fuel Pump Studs	Loctite [™] 609.
7. Turbocharger Drain (in block)	Loctite [™] 277 or Cummins Sealant 3375068.
8. Dipstick Tube (in block)	Loctite [™] 277 or Cummins Sealant 3375068.
9. Wet Flywheel Housing to Block	K&W Copper Coat [™] .
10. Front Seal (in gear cover)	Loctite [™] 277 or Cummins Sealant 3375068.
11. Rear Seal (in rear cover)	No sealant.
12. Timing Pin Housing Capscrews	Loctite [™] 59,241 liquid teflon.
13. Side Oil Fill	Loctite [™] 277 or Cummins Sealant 3375068.

C Series Lubricants

Use the lubricants listed below or lubricants containing equivalent properties.

Parts	Lubricant Required
Rod Bearings	Lubriplate™ 105
Main Bearings	Lubriplate™ 105
Cam Lobes and Journals	Lubriplate™ 105
Tappets	Lubriplate™ 105
Pistons	15W40 Engine Oil
Piston Rings	15W40 Engine Oil
Piston Pin	15W40 Engine Oil
Rocker Assemblies	15W40 Engine Oil
Push Tubes	Lubriplate™ 105 in cup
Liner O-Ring	15W40 Engine Oil
Capscrews - under head and on threads, as follows:	
● Main Bearing Capscrews	15W40 Engine Oil
● Cylinder Head Capscrews	15W40 Engine Oil
● Connecting Rod Capscrews	15W40 Engine Oil
● Flywheel Mounting Capscrews	15W40 Engine Oil
● Damper Mounting Capscrews	15W40 Engine Oil
● All Other Capscrews	Preservative Oil or 15W40 Engine Oil
Valve Stems (Cylinder Head Assembly)	90W or 140W Oil
Valve Stems (Engine Assembly)	Lubriplate™ 105
Front and Rear Seals to Crankshaft	Dry (use no lubricants)
Rear Seal	Soapy water to install seal in housing
Lube Oil Pressure Regulator	15W40 Engine

Abbreviations Used in This Manual

API	- American Petroleum Institute	in-lb	- Inch Pound
ASTM	- American Society of Testing and Materials	kg	- Kilograms
°C	- Degrees Centigrade	km	- Kilometers
C.I.D.	- Cubic Inch Displacement	kPa	- Kilopascal
CPL	- Control Parts List	m	- metre
cSt	- Centistokes	mm	- Millimetre
DCA	- Diesel Coolant Additive	MPa	- Megapascal
E.C.S.	- Emission Control System	MPQ	- Miles Per Quart
EPA	- Environmental Protection Agency	N•m	- Newton-metre
°F	- Degrees Fahrenheit	OEM	- Original Equipment Manufacturer
ft-lb	- Foot Pound	ppm	- Parts Per Million
GVW	- Gross Vehicle Weight	psi	- Pounds Per Square Inch
Hg-	- Mercury	RPM	- Revolutions Per Minute
HP	- Horsepower	S.A.E.	- Society of Automotive Engineers
H ₂ O	- Water	S.O.	- Shop Order

General Cleaning Instructions

Solvent and Acid Cleaning



Several solvent and acid type cleaners can be used to clean the engine parts. **Cummins Engine Co., Inc. does not recommend any specific cleaners.** Always follow the cleaner manufacturer's instructions.

Experience has shown that the best results can be obtained using a cleaner that can be heated to 90 to 95 degrees Celsius [180 to 200 degrees Fahrenheit]. A cleaning tank that provides a constant mixing and filtering of the cleaning solution will give the best results.

Remove all the gasket material, o-rings, and the deposits of sludge, carbon, etc., with a wire brush or scraper before putting the parts in a cleaning tank. Be careful not to damage any gasket surfaces. When possible, steam clean the parts before putting them in the cleaning tank.



Warning: The use of acid can be extremely dangerous to personnel and can damage the machinery. Always provide a tank of strong soda water as a neutralizing agent.

Rinse all of the parts in hot water after cleaning. Dry completely with compressed air. blow the rinse water from all of the capscrew holes and the oil drillings.

If the parts are **not** to be used immediately after cleaning, dip them in a suitable rustproofing compound. The rustproofing compound **must** be removed from the parts before installation on the engine.

Steam Cleaning



Steam cleaning can be used to remove all types of dirt that can contaminate the cleaning tank. It is a good way to clean the oil drillings.



Warning: Wear protective clothing to prevent personal injury from the high pressure and extreme heat.

Do **not** steam clean the following parts.

1. Electrical Components
2. Wiring
3. Injectors
4. Fuel Pump
5. Belts and Hoses
6. Bearings

Tools Required to Rebuild the C Series Engine

In the text, a symbol followed by the wrench size or tool description is used to identify the tooling required to perform each step. A list of wrench sizes and descriptions indicates more than one tool is needed.

Sockets	Wrenches	Other
10mm	8mm	Allen Wrench (8mm)
12mm	3/8 inch	Allen Wrench (5mm)
13mm	10mm	Breaker Bar (1/2 inch Square Drive)
15mm	7/16 inch	Ratchet (1/2 inch Square Drive)
17mm	1/2 inch	Ratchet (3/8 inch Square Drive)
18mm	13mm	Flat Blade Screwdriver
19mm	9/16 inch	Filter Wrenches (75 to 80mm, 90 to 95mm)
22mm	15mm	and 118 to 131mm)
27mm	5/8 inch	T-Bar Puller (75mm)
	17mm	Torque Wrenches (1/2 and 3/8 inch Square Drive)
	19mm	Pliers
	22mm	Engine Rebuild Stand 3375194
	24mm	Adapter Plate 3822607
		Piston Ring Expander
		Gear Splitter
		Protrusion Gauge ST-545
		Liner Clamp 3376944
		Plastic Hammer
		Dial Indicator
		Feeler Guages
		Liner Puller 3376015
		Liner Driver ST-1229
		Camshaft Bushing Driver
		Slide Hammer 3376617
		Intake Valve Seat Extractor 3377396
		Exhaust Valve Seat Extractor ST-1276-1
		Intake Valve Seat Driver
		Exhaust Valve Seat Driver
		Valve Guide Arbor
		Valve Guide Removal Driver
		Valve Guide Installation Driver
		Valve Guide Reamer
		Engine Barring Tool 3377371
		Injector Puller 3822482
		Blowby Tool (.302 Orifice) 3375788

Engine Disassembly and Assembly - Group 0

Table of Contents

	Page
Engine Assembly	0-33
Engine Disassembly	0-7
Engine Disassembly Check List.....	0-6
General Information.....	0-4
Index	0-2

Engine Disassembly and Assembly - Group 0

Index

	Page No.		Page No.
Assembly and Disassembly			
Air Crossover Tube		Exhaust Manifold	
● Installation.....	0-86	● Installation.....	0-84
● Removal.....	0-10	● Removal.....	0-13
Air Intake Manifold Cover or Aftercooler		Exhaust Outlet Connection	
● Installation.....	0-82	● Installation.....	0-87
● Removal.....	0-10	● Removal.....	0-13
Alternator		Fan Hub	
● Installation.....	0-89	● Installation.....	0-91
● Removal.....	0-14	● Removal.....	0-17
Alternator Bracket		Flywheel Housing	
● Installation.....	0-89	● Dry Clutch Housing Installation.....	0-64
● Removal.....	0-15	● Wet Clutch Housing Installation.....	0-68
Alternator Link		● Removal.....	0-21
● Installation.....	0-89	Flywheel	
● Removal.....	0-14	● Installation.....	0-67
Belt		● Removal.....	0-21
● Installation.....	0-92	Front Gear Cover	
● Removal.....	0-13	● Installation.....	0-72
Belt Tensioner		● Removal.....	0-19
● Installation.....	0-90	Front Seal Installation.....	0-73
● Removal.....	0-14	Front Engine Mount	
Block Heater		● Installation.....	0-92
● Installation.....	0-68	● Removal.....	0-25
● Removal.....	0-21	Fuel Drain Manifold	
Camshaft		● Installation.....	0-81
● Installation.....	0-53	● Removal.....	0-10
● Removal.....	0-22	Fuel Filter Head	
Camshaft End Play.....	0-55	● Installation.....	0-83
Coolant Vent Tube		● Removal.....	0-8
● Installation.....	0-88	Fuel Filter	
● Removal.....	0-15	● Installation.....	0-84
Crankshaft		● Removal.....	0-8
● Installation.....	0-36	Fuel Pump Injector	
● Removal.....	0-28	● Installation.....	0-60
Crankshaft Main Bearing		● Removal.....	0-19
● Installation.....	0-37	Fuel Shutoff Solenoid	
Cylinder Head		● Installation.....	0-93
● Installation.....	0-74	● Removal.....	0-9
● Removal.....	0-16	Gear Housing	
Cylinder Liner		● Installation.....	0-50
● Installation.....	0-33	● Removal.....	0-25
● Removal.....	0-30	High Pressure Fuel Lines	
Engine Accessories		● Installation.....	0-82
● Installation.....	0-64	● Removal.....	0-9
● Removal.....	0-20	Injector	
		● Installation.....	0-80
		● Removal.....	0-10

Engine Disassembly and Assembly - Group 0

Index

	Page No.		Page No.
Assembly and Disassembly (Cont'd.)			
Lift Pump		Tappet	
● Installation.....	0-93	● Installation.....	0-35
● Removal.....	0-8	● Removal.....	0-24
Low Pressure Fuel Lines		Thermostat/Thermostat Housing	
● Installation.....	0-93	● Installation.....	0-88
● Removal.....	0-8	● Removal.....	0-15
Lubricating Oil Pump		Timing Pin Assembly Installation.....	0-57
● Installation.....	0-51	● Locating TDC.....	0-57
● Removal.....	0-24	Turbocharger	
Oil Cooler Assembly		● Installation.....	0-85
● Installation.....	0-70	● Removal.....	0-13
● Removal.....	0-17	Valve Adjustment.....	0-78
Oil Pan		Valve Cover	
● Installation.....	0-56	● Installation.....	0-79
● Removal.....	0-21	● Removal.....	0-11
Oil Transfer Tube		Vibration Damper	
● Installation.....	0-76	● Installation.....	0-91
● Removal.....	0-12	● Removal.....	0-18
Piston and Rod Assemblies		Water Filter Assembly	
● Installation.....	0-43	● Installation.....	0-71
● Connecting Rod Cap Torque Value.....	0-49	● Removal.....	0-17
● Connecting Rod Side Clearance.....	0-50	Water Outlet	
● Piston - Rod Orientation.....	0-48	● Installation.....	0-89
● Piston Ring Installations.....	0-44	● Removal.....	0-15
● Ring Gap Measurement.....	0-44	Water Pump	
● Removal.....	0-26	● Installation.....	0-89
Piston Cooling Nozzles		● Removal.....	0-17
● Installation.....	0-36		
● Removal.....	0-29		
Push Rods			
● Installation.....	0-76		
● Removal.....	0-12		
Rear Seal Housing/Seal			
● Installation.....	0-41		
● Removal.....	0-22		
Removing Engine from Rollover Stand.....	0-92		
● Installation.....	0-9		
Rocker Lever Assemblies			
● Installation.....	0-77		
● Removal.....	0-12		
Oil Suction Tube			
● Installation.....	0-55		
● Removal.....	0-22		
Starter			
● Installation (Dry Housing).....	0-65		
● Installation (Wet Housing).....	0-68		
● Removal.....	0-20		

Engine Disassembly and Assembly - Group 0

General Information

These procedures apply to all C Series engines. The differences between engine models due to the application, the optional equipment on an engine, and the year an engine was built are included in the instructions. Omit the steps that do not apply to the engine being rebuilt.

 A **Warning** statement is included for any component or assembly that weighs more than 23 kg [50 lb]. To avoid personal injury, use a hoist or get assistance when removing or installing these parts.

 All fasteners are given in metric measurements. All fasteners have **right-hand** threads unless a **Caution** states that a fastener has **left-hand** threads.

Disassembly

The instructions in this procedure are organized in a logical sequence to **disassemble** an engine. This is not the **only** sequence to **disassemble** an engine. Certain parts must be removed in the sequence indicated. Use this sequence until you become familiar with the engine.

Discard all gaskets, seals, hoses, filters, and o-rings. Keep these parts if they are needed for a failure analysis.

Label, tag, or mark the parts for location as the parts are removed. This will help identify the parts that can be involved in a failure and will simplify the assembly procedure.

Label, tag, mark, or photograph all special equipment prior to the removal from an engine. This engine assembly procedure does not include the installation of special optional equipment.

Use a mallet when force is required to remove certain parts. Make sure all of the fasteners are removed before using force.

Avoid as much dirt as possible during disassembly. The accumulation of additional dirt will make it more difficult to clean the components.

Assembly

This procedure assumes that all of the components and assemblies have been cleaned, replaced, or rebuilt and are ready to be installed on the engine.

Torque values are listed in each step. If a torque value is not specified, use the chart listed in the Introduction, (Page i-20), to determine the correct torque value.

Many of the gaskets and o-rings are manufactured from a material designed to absorb oil. These gaskets will enlarge and provide a tight seal after coming in contact with oil. Use **ONLY** a recommended contact adhesive or a vegetable based oil to install these parts.

Engine Disassembly Check List

The following is a checklist of recommended measurement to be made during disassembly to aid in determining the reuse of certain parts.


- | | |
|---|---------------------------------------|
| 1. Injection pump drive gear backlash
(refer to page 0-19) | 0.152 to 0.254mm [0.006 to 0.010 in.] |
| 2. Camshaft gear backlash
(refer to page 0-23) | 0.152 to 0.254mm [0.006 to 0.010 in.] |
| 3. Lube pump gear backlash
(refer to page 0-24) | 0.08 to 0.33mm [0.003 to 0.013 in.] |
| 4. Lube pump idler gear backlash
(refer to page 0-25) | 0.08 to 0.33mm [0.003 to 0.013 in.] |
| 5. Cylinder liner maximum inside diameter
(refer to page 0-30) | 114.117mm [4.4928 in.] |
| Maximum out of round | 0.04mm [0.0016 in.] |
| Maximum Taper | 0.04mm [0.0016 in.] |

Engine Disassembly

Prepare the Engine to Be Mounted on the Engine Rebuild Stand

Caution: Cover all engine openings and electrical components. This will prevent water damage.

Steam clean the heavy dirt from the exterior of the engine.




17mm

Note: The maximum oil capacity including the oil filter is 22.4 liters [23.7 U.S. quarts].

Remove the drain plug and discard the copper washer.


Drain the oil.

Torque Value: 80 N•m [60 ft-lb]




90-95mm Filter Wrench


Remove and discard the water filter.



118 to 131mm Filter Wrench


Remove and discard the oil filter if not needed for a failure analysis.






75-80mm Filter Wrench 90-95mm Filter Wrench

Remove and discard the fuel filters and the sealing rings.



24mm

Remove the fuel filter head and discard the o-rings.



20, 19, 17 and 14mm

Disconnect the low pressure fuel lines.

NOTE: To avoid damage to the lift pump, use two wrenches when loosening the low pressure line.

Discard all copper washers.



10mm

Remove the lift pump.