

Product: John Deere 3325 and 3365 Professional Turf Mower Service Repair Technical Manual
Full Download: <https://www.arepairmanual.com/downloads/john-deere-3325-and-3365-professional-turf-mower-service-repair-technical-manual>

/

3325 and 3365 Professional Turf Mower

For complete service information also see:

Yanmar Engine Repair CTM3

John Deere Horizon Works
Sample of manual. Download All 696 pages at:

<https://www.arepairmanual.com/downloads/john-deere-3325-and-3365-professional-turf-mower-service-repair-technical-manual>

TM1427 (COMAR93)

LITHO IN U.S.A.
ENGLISH

Introduction

Product: John Deere 3325 and 3365 Professional Turf Mower Service Repair Technical Manual

Full Download: [https://www.arepairmanual.com/downloads/john-deere-3325-and-](https://www.arepairmanual.com/downloads/john-deere-3325-and-3365-professional-turf-mower-service-repair-technical-manual)

[3365-professional-turf-mower-service-repair-technical-manual](https://www.arepairmanual.com/downloads/john-deere-3325-and-3365-professional-turf-mower-service-repair-technical-manual)

FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

N This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

Sample of manual. Download All 986 pages at:

TM,1427A1,IFC -19-30MAR93

<https://www.arepairmanual.com/downloads/john-deere-3325-and-3365-professional-turf-mower-service-repair-technical-manual>

Contents

SECTION 10—GENERAL INFORMATION

- Group 05—Safety
- Group 10—General Specifications
- Group 15—Repair Information
- Group 20—Fuel and Lubricants
- Group 25—Serial Numbers

SECTION 20—ENGINE REPAIR

- Group 05—Engine Removal and Installation
- Group 10—Muffler
- Group 15—Cooling System

SECTION 30—FUEL AND AIR REPAIR

- Group 05—Fuel System
- Group 10—Air System

SECTION 40—ELECTRICAL REPAIR

- Group 05—Batteries and Cables
- Group 10—Electrical System Components
- Group 15—Wiring Harness

SECTION 50—POWER TRAIN REPAIR

- Group 05—Hydrostatic Transmission
- Group 10—Transaxle
- Group 15—Final Drives
- Group 20—Control Linkage

SECTION 60—STEERING AND BRAKE REPAIR

- Group 05—Steering System Repair
- Group 10—Brake Repair
- Group 15—Rear Axle

SECTION 70—HYDRAULIC REPAIR

- Group 05—Hydraulic Pumps
- Group 10—Hydraulic Control Valves
- Group 15—Weight Transfer System
- Group 20—Hydraulic Cylinders
- Group 25—Rockshaft Assembly
- Group 30—Hydraulic System

SECTION 80—MISCELLANEOUS REPAIR

- Group 05—Cutting Units
- Group 10—Operator Seat Assembly

SECTION 210—OPERATIONAL CHECKOUT PROCEDURE

- Group 05—Test and Adjustment Specifications
- Group 10—Operational Checkout Procedures

SECTION 220—Engine Operation, Tests and Adjustments

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests, & Adjustments

SECTION 230—FUEL/AIR OPERATION, TESTS AND ADJUSTMENTS

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests & Adjustments

SECTION 240—ELECTRICAL OPERATION, TESTS AND ADJUSTMENTS

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis Tests and Adjustments
- Group 20—Wiring Schematics

SECTION 250—POWER TRAIN OPERATION, TESTS AND ADJUSTMENTS

- Group 05—Component Locations
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests, & Adjustments
- Group 20—Hydraulic/Hydrostatic Schematic

SECTION 260—STEERING/BRAKES OPERATION, TESTS, & ADJUSTMENTS

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests & Adjustments
- Group 20—Steering Schematic

SECTION 270—HYDRAULIC SYSTEM OPERATION, TESTS AND ADJUSTMENTS

- Group 05—Component Location
- Group 10—Theory of Operation

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

TM1427-19-30MAR93

COPYRIGHT© 1993
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION™ Manual
Previous Editions
Copyright 1991 Deere & Company

Group 15—Diagnosis, Tests & Adjustments
Group 20—Hydraulic Schematics

Index

10

20

30

40

50

60

70

80

210

220

230

240

250

260

270

INDX

230

240

250

260

270

INDEX

Section 10 GENERAL INFORMATION

Contents

Page

Group 05—Safety 10-05-1

Group 10—General Specifications

3325 and 3365 Specifications 10-10-1

Group 15—Repair Information 10-15-1

Group 20—Fuel and Lubricants

Fuel

Specifications 10-20-1

Storage 10-20-2

Engine

Oil 10-20-3

Coolant 10-20-4

Transmission and Hydraulic Oil 10-20-5

Grease 10-20-6

Alternative and Synthetic Lubricants 10-20-6

Lubricant Storage 10-20-6

Group 25—Serial Numbers

Serial Numbers 10-25-1

Product Identification Number 10-25-1

Engine Serial Number 10-25-1

Transaxle Serial Number 10-25-1

Transmission Serial Number 10-25-2

Transaxle Pump Serial Number 10-25-2

Dual Hydraulic Pump Serial Number 10-25-2

HANDLE FLUIDS SAFELY—AVOID FIRES

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.



DX,FLAME -19-04JUN90

10-05-1
-UN-23AUG88
TS227

PREVENT BATTERY EXPLOSIONS

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



DX,SPARKS -19-03MAR93


-UN-23AUG88
TS204

PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



DX,FIRE2 -19-03MAR93

-UN-23AUG88
TS291

PREVENT ACID BURNS

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 10—15 minutes. Get medical attention immediately.

If acid is swallowed:

1. Drink large amounts of water or milk.
2. Then drink milk of magnesia, beaten eggs, or vegetable oil.
3. Get medical attention immediately.



TS203 -UN-23AUG88

DX,POISON -19-04JUN90


AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



DX,FLUID -19-03MAR93

X9811 -UN-23AUG88

33510

AVOID INJURY FROM ROTATING BLADES

Keep hands and feet away while machine is running. Shut off power to service, lubricate or unlatch cutting units.




2E6,1005G,1C -19-25MAY90

E30096 -UN-21SEP88

PARK MACHINE SAFELY

Before working on the machine:

- Lower all equipment to the ground.
- Stop the engine and remove the key.
- Disconnect the battery ground strap.
- Hang a "DO NOT OPERATE" tag in operator station.



DX,PARK -19-04JUN90


TS230 -UN-24MAY89

10
05
4

SUPPORT MACHINE PROPERLY

Always lower the attachment or implement to the ground before you work on the machine. If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.



DX,LOWER -19-04JUN90

TS229 -UN-23AUG88


WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.




DX,WEAR -19-10SEP90

TS206 -UN-23AUG88

WORK IN CLEAN AREA

Before starting a job:

- Clean work area and machine.
- Make sure you have all necessary tools to do your job.
- Have the right parts on hand.
- Read all instructions thoroughly; do not attempt shortcuts.




DX,CLEAN -19-04JUN90

T6642EJ -UN-18OCT88

SERVICE MACHINES SAFELY

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.




DX, LOOSE -19-04JUN90

510
-UN-23AUG88
TS228

WORK IN VENTILATED AREA

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.




DX, AIR -19-04JUN90

-UN-23AUG88
TS220

ILLUMINATE WORK AREA SAFELY

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.



DX, LIGHT -19-04JUN90

-UN-23AUG88
TS223

REPLACE SAFETY SIGNS

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.



DX, SIGNS1 -19-04JUN90


-UN-23AUG88
TS201

10
05
6

USE PROPER LIFTING EQUIPMENT

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components in the manual.



DX,LIFT -19-04JUN90

TS226 -UN-23AUG88

REMOVE PAINT BEFORE WELDING OR HEATING


Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Do all work outside or in a well ventilated area. Dispose of paint and solvent properly.

Remove paint before welding or heating:

- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.



DX,PAINT -19-03MAR93

TS220 -UN-23AUG88

AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.




DX,TORCH -19-03MAR93

TS953 -UN-15MAY90

KEEP ROPS INSTALLED PROPERLY

Make certain all parts are reinstalled correctly if the roll-over protective structure (ROPS) is loosened or removed for any reason. Tighten mounting bolts to proper torque.

The protection offered by ROPS will be impaired if ROPS is subjected to structural damage, is involved in an overturn incident, or is in any way altered by welding, bending, drilling, or cutting. A damaged ROPS should be replaced, not reused.



DX,ROPS3 -19-03MAR93

TS212 -UN-23AUG88

SERVICE TIRES SAFELY

Explosive separation of a tire and rim parts can cause serious injury or death.

Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job.

Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Never weld or heat a wheel and tire assembly. The heat can cause an increase in air pressure resulting in a tire explosion. Welding can structurally weaken or deform the wheel.

When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side and NOT in front of or over the tire assembly. Use a safety cage if available.

Check wheels for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.



DX,TIRECP -19-24AUG90

TS952 -UN-12APR90

PRACTICE SAFE MAINTENANCE

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

Disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.



DX,SERV -19-03MAR93

TS218 -UN-23AUG88

USE PROPER TOOLS

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards.

Use power tools only to loosen threaded parts and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only service parts meeting John Deere specifications.



DX,REPAIR -19-04JUN90

TS779 -UN-08NOV89

DISPOSE OF WASTE PROPERLY


Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.



DX,DRAIN -19-03MAR93

9510
-UN-26NOV90
TS1133

LIVE WITH SAFETY

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.



DX,LIVE -19-25SEP92

-19-07OCT88
TS231

10
05
10

3325 AND 3365 SPECIFICATIONS

ENGINE

Make	Yanmar
Type	Diesel
Model	4TN82—RJE
Horsepower at 2700 rpm	28 kW (38 hp)
Number of Cylinders	4
Displacement	1.8 L (110.2 cu in.)
Bore and Stroke	82 x 86 mm (3.23 x 3.39)
Fast Idle	2800 rpm
Slow Idle	1000 rpm
Start Aid	Air Heater
Cooling System	Liquid Cooled
Air Cleaner	Replaceable Dry Type w/Safety Element
Engine Shutoff	Key Switch

FUEL SYSTEM

Type	Direct Injection
Fuel Delivery	Electric Fuel Pump

ELECTRICAL SYSTEM

Type	12 Volt
Battery Size	BCI Group 24 F 550 Cold Cranking Amps
Alternator	40 Amps
System Polarity	Negative Ground
Starter	12 Volt Electric w/Solenoid
Instrumentation	Hour Meter, Fuel Gauge & 11 Function Indicators (Stop Engine, Service Alert, Engine Oil Pressure, Engine Coolant Temperature, Water in Fuel, Hydraulic Oil Temperature, Hydrostatic Oil Temperature, Engine Air Heater, Parking Brake, Engine Alternator Volts, Engine Air Restriction)

MX,1010HV,A1 -19-30NOV92

10
10
1

SPECIFICATIONS—CONTINUED

POWER TRAIN

Type	25 Series Sundstrand w/Kansaki Transaxle
Control (Foot)	2 Pedal
Travel Speeds:	
Forward (Transport)	0—18.7 km/h (0—11.7 mph)
Reverse	0—9.7 km/h (0—6 mph)
Mowing	0—10.8 km/h (0—7.2 mph)

STEERING/BRAKES

Steering	Hydrostatic Power
Brakes	Mechanical Wet Disk

HYDRAULIC SYSTEM

Dual Hydraulic Pump Flow at 2800 rpm	37.8 L/min (10 gpm) per section
Reel Relief Valve	20684 kPa (207 bar) (3000 psi)
Wing Lift and Rockshaft Relief Valves	14617 kPa (146 bar) (2120 psi)
Filter Bypass Relief Valve	138—207 kPa (1.4—2.1 bar) (20—30 psi)

HYDROSTATIC SYSTEM

Charge Pump Flow at 2800 rpm	12.1 L/min (3.2 gpm) minimum
Charge Pump Relief Valve	965—1379 kPa (9.6—13.8 bar) (140—200 psi)
Main Relief Valve	41369—44816 kPa (414—448 bar) (6000—6500 psi)
Filter Bypass Relief Valve	138—207 kPa (1.4—2.1 bar) (20—30 psi)
Cooler Bypass Relief Valve	552—896 kPa (5.5—9.0 bar) (80—130 psi)
Transaxle Pump Flow at 2800 rpm	31.8 L/min (8.4 gpm)
Steering Relief Valve	10497 + 500—0 kPa (105 + 5 - 0 bar) (1522.5 + 72.5 - 0 psi)

CAPACITIES

Fuel Tank	75 L (20 gal)
Engine Crankcase	5.7 L (6.0 qt) with Filter
Engine Cooling System	6.6 L (7 qt)
Hydraulic System	26.5 L (7 gal)
Hydrostatic Transaxle System	18.9 L (5 gal)
Cutting Unit Gear Case	0.4 L (0.8 pt)

MX,1010HV,A2 -19-30NOV92

SPECIFICATIONS—CONTINUED

TIRES

Size:

Front 33 x 12.5—15
 Rear 23 x 10.5—12

Maximum Inflation:

Front (Mowers Up) 68 kPa (0.7 bar) (9.9 psi)
 Front (Mowers Down) 67 kPa (0.67 bar) (9.7 psi)
 Rear 62 kPa (0.6 bar) (9.0 psi)

OVERALL DIMENSIONS:

Wheelbase 162.5 cm (64 in.)
 Tread Width 142 cm (56 in.)
 Machine Width (Mowers down) 368 cm (145 in.)
 Machine Width (Mowers up) 226 cm (89 in.)
 Turning Radius 152 cm (60 in.)
 Working Weight 1619 kg (3570 lb)

MOWER

Mower Lift Single Lift Lever w/Auxiliary Switches for Wing Mowers
 Number of Reels 5
 Overall Cutting Width 3.5 m (138 in.)

Reel Speed (3325) 1300 rpm
 Bed Knife Adjustment Reel to Bed Knife
 Height of Cut Range 10 to 76 mm (0.375 to 3.0 in.)
 Number of Blades 6 standard; 8 or 10 optional

CUTTING RATIOS

Ground Speed:		7 km/h (4.5 mph)	8 km/h (5.0 mph)	9 km/h (5.5 mph)	10 km/h (6.0 mph)	11 km/h (6.5 mph)	11.6 km/h (7.2 mph)
NO. of BLADES	MODEL						
6 Blades	3325	17.4 mm (0.71 in.)	19.8 mm (0.79 in.)	22.3 mm (0.86 in.)	24.8 mm (0.94 in.)	27.3 mm (1.02 in.)	28.8 mm (1.13 in.)
	3365	16.0 mm (0.63 in.)	18.0 mm (0.71 in.)	20.0 mm (0.78 in.)	22.0 mm (0.85 in.)	23.0 mm (0.92 in.)	26.0 mm (1.02 in.)
8 Blades	3325	13.0 mm (0.53 in.)	14.9 mm (0.59 in.)	16.7 mm (0.65 in.)	18.6 mm (0.71 in.)	20.5 mm (0.77 in.)	21.6 mm (0.85 in.)
	3365	12.0 mm (0.47 in.)	13.0 mm (0.51 in.)	15.0 mm (0.59 in.)	16.0 mm (0.63 in.)	18.0 mm (0.71 in.)	19.0 mm (0.75 in.)
10 Blades	3325	10.4 mm (0.42 in.)	11.9 mm (0.47 in.)	13.4 mm (0.52 in.)	14.9 mm (0.57 in.)	16.4 mm (0.61 in.)	17.3 mm (0.68 in.)
	3365	10.0 mm (.38 in.)	11.0 mm (0.42 in.)	12.0 mm (0.47 in.)	13.0 mm (0.51 in.)	14.0 mm (0.55 in.)	15.0 mm (0.59 in.)

10
10
3

10
10
4

REPAIR SPECIFICATIONS

NOTE: For repair specification of the engine, use CTM3, 3TN and 4TN Series Yanmar Diesel Engines.

For repair specification of reel mower cutting units, use TM1528, Reel Mower Cutting Units.

Item	Measurement	Specification
SECTION 20—ENGINE REPAIR		
ENGINE:		
Mounting Bracket-to-Frame	Torque	44—54 N·m (33—40 lb-ft)
Cap Screws and Nuts		
Mounting Bracket-to-Engine	Torque	90 N·m (66 lb-ft)
Cap Screws (16 used)		
COOLING SYSTEM:		
Coolant Level Below Bottom of	Distance	13—25 mm (0.5—1.0 in.)
Filler Neck		
Radiator-to-Frame Cap Screws	Torque	31—37 N·m (270—330 lb-in.)
SECTION 30—FUEL AND AIR REPAIR		
For all injection pump, nozzle and governor repair—Use CTM3.		
SECTION 40—ELECTRICAL SYSTEM		
For starter and alternator repair—use CTM3.		
SECTION 50—POWER TRAIN REPAIR		
DRIVE SHAFT:		
Drive Shaft-to-Isolator	Torque	49 N·m (36 lb-ft)
Cap Screws and Nuts		
Isolator-to-Flywheel Cap Screws	Torque	49 N·m (36 lb-ft)
Engine Mount-to-Frame Cap Screws	Torque	44—54 N·m (33—40 lb-ft)
Drive Shaft Coupler Cap Screws	Torque	60 N·m (45 lb-ft)
CHARGE PUMP:		
Seal	Depth Below Surface	1.5—2.5 mm (0.056—0.096 in.)
Charge Pump-to-Transmission Cap Screws	Torque	37—50 N·m (27—37 lb-ft)

MX,1015HV,A2 -19-30NOV92

REPAIR SPECIFICATIONS—CONTINUED

10
15
2

Item	Measurement	Specification
SECTION 50—POWER TRAIN REPAIR—CONTINUED		
HYDROSTATIC TRANSMISSION:		
Swash Plate End Covers Cap Screws	Torque	8—9 N·m (72—84 lb-in.)
Center Section Needle Bearings	Depth above surface of housing	3 mm (7/64 in.)
Center Section-to-Housing Cap Screws	Torque	44—55 N·m (33—41 lb-ft)
Gear to Output Shaft Cap Screw	Torque	54 N·m (40 lb-ft)
Transmission-to-Transaxle Cap Screws	Torque	142 N·m (105 lb-ft)
Neutral Centering Spring		
S.N. —840000	Approx Length	133 mm (5.25 in.)
S.N. 840001—	Approx Length	203 mm (8.00 in.)
HYDROSTATIC OIL COOLER:		
Oil Cooler Fittings	Torque	34 N·m (25 lb-ft)
TRANSAXLE:		
PTO Clutch		
Separator Plate-to-Cylinder	Maximum distance	4.7 mm (0.185 in.)
Top Plate	Minimum thickness	2.9 mm (0.114 in.)
Clutch Disk	Minimum thickness	1.9 mm (0.075 in.)
Separator Plate	Minimum thickness	1.0 mm (0.039 in.)
Piston Return Spring	Minimum free length Minimum working load	29 mm (1.14 in.) 17.5 mm at 540 N (0.689 in. at 121 lb)
Differential		
Bearing Retainer Cap Screws	Torque	26 N·m (19 lb-ft)
Rear Cover Assembly		
M12 Cap Screws	Torque	90 N·m (66 lb-ft)
M10 Cap Screws	Torque	50 N·m (37 lb-ft)
M8 Cap Screws	Torque	26 N·m (19 lb-ft)
Differential Ring Gear	Backlash	0.15—0.21 mm (0.006—0.008 in.)
Differential Carrier-to-Case	Torque	26 N·m (19 lb-ft)
Cap Screws		
Front Cover Cap Screws		
M12 Cap Screw	Torque	90 N·m (66 lb-ft)
M10 Cap Screw	Torque	50 N·m (37 lb-ft)
PTO Valve Cover Cap Screws	Torque	26 N·m (19 lb-ft)
Support-to-Transaxle Cap Screws	Torque	80 N·m (59 lb-ft)
ROPS-to-Frame Cap Screws and Nuts	Torque	130 N·m (96 lb-ft)
Frame-to-Transaxle Cap Screws	Torque	175 N·m (129 lb-ft)
Cross Brace-to-Frame Cap Screws	Torque	175 N·m (129 lb-ft)
and Nuts (3365)		

REPAIR SPECIFICATIONS—CONTINUED

Item	Measurement	Specification
SECTION 50—POWER TRAIN REPAIR—CONTINUED		
Front Wheel Lug Bolts	Torque	115 N·m (85 lb-ft)
Oil Cooler-to-Transmission	Torque	49 N·m (36 lb-ft)
Hose Connections		
Wing Lift-to-Flow Control Valve	Torque	49 N·m (36 lb-ft)
Hose Connection		
Steering Valve-to-Flow Control Valve	Torque	49 N·m (36 lb-ft)
Hose Connection		
Steering Valve-to-PTO Valve Hose Connection	Torque	49 N·m (36 lb-ft)
Hydraulic Pump-to-Transaxle Cap Screws	Torque	54 N·m (40 lb-ft)
Cutting Unit Supply Line-to-Hydraulic	Torque	102 N·m (75 lb-ft)
Pump Connections		
Suction Tube-to-Hydraulic Pump Flange	Torque	37 N·m (27 lb-ft)
Cap Screws		
Lift Link-to-Rockshaft Arm Cap Screws	Torque	163 N·m (120 lb-ft)
and Nuts		
FINAL DRIVES:		
Seal Housing-to-Axle Housing	Torque	25 N·m (18 lb-ft)
Cap Screws (Axle S.N. —000755)		
Ring Gear Cap Screws	Torque	26 N·m (230 lb-in.)
Final Drive-to-Differential Housing	Torque	52 N·m (38 lb-ft)
Cap Screws		
CONTROL LINKAGE:		
Neutral Centering Lever Bushing	Minimum diameter	19.088 ± 0.025 mm (0.7515 ± 0.001 in.)
(S.N. 840001—)		

MX,1015HV,A4 -19-30NOV92

REPAIR SPECIFICATIONS—CONTINUED

Item	Measurement	Specification
SECTION 60—STEERING AND BRAKE REPAIR		
STEERING VALVE:		
Rotor to Stator Clearance	Maximum clearance	0.08 mm (0.003 in.)
Top of Steering Tube to Bushing	Dimension	2.5 mm (0.1 in.)
Metering Assembly Screws	Torque	1.4 ± 0.1 N·m (12 ± 1 lb-in.)
Commutator Ring and Drive Plate TIR	Maximum allowable TIR	0.13 mm (0.005 in.)
Port Cover Nuts	Torque	30 N·m (266 lb-in.)
Check Ball Plug	Torque	14 N·m (124 lb-in.)
Steering Wheel Nut	Torque	15 N·m (11 lb-ft)
Relief Valve	Pressure	10497 + 500 - 0 kPa (1522.5 + 72.5 - 0 psi)
BRAKES:		
Brake Disk	Thickness (new)	4.6—4.8 mm (0.181—0.189 in.)
	Minimum thickness	4.4 mm (0.173 in.)
Brake Disk Spline-to-Shaft	Backlash (new)	0.13—0.31 mm (.005—.012 in.)
	Maximum backlash	1.2 mm (0.047 in.)
Brake Linkage Rod	Approximate length	557 mm (21.9 in.) (includes clevis)
Brake Plate	Thickness (new)	2.5—2.7 mm (0.098—0.106 in.)
	Minimum thickness	2.3 mm (0.090 in.)
	Warpage (new)	0.15 mm (0.006 in.)
	Maximum warpage	0.3 mm (0.012 in.)
STEERING AXLE:		
Steering Cylinder-to-Spindle Nut	Torque	75 N·m (55 lb-ft)
Tie Rod-to-Spindle Nut	Torque	53 N·m (39 lb-ft)
Toe-in Adjustment	Length less at front than at rear of rear tires	6 mm (1/4 in.)
Tie Rod Nut	Torque	118 N·m (87 lb-ft)
Pivot Pin Nut	Torque	509 N·m (375 lb-ft)
Axle Pivot End Play	Approximate clearance	1 mm (0.040 in.)

MX,1015HV,A5 -19-30NOV92

REPAIR SPECIFICATIONS—CONTINUED

Item	Measurement	Specification
SECTION 70—HYDRAULIC REPAIR		
HYDRAULIC PUMPS:		
Transaxle Pump-to-Differential	Torque	47 N·m (35 lb-ft)
Housing Cap Screws		
Lift Link-to-Rockshaft Arm Cap Screw	Torque	163 N·m (120 lb-ft)
Transaxle Pump Cover	Torque	47 N·m (35 lb-ft)
Socket Head Screws		
Hydraulic Pump	Torque	47 N·m (35 lb-ft)
Socket Head Screws		
Hydraulic Pump Mounting Cap Screws	Torque	54 N·m (40 lb-ft)
Hydraulic Pump Tube Nuts	Torque	102 N·m (75 lb-ft)
REEL CONTROL VALVE:		
Tie Rod Nuts	Torque	18.6 N·m (165 lb-in.)
WING LIFT VALVE:		
Tie Rod Nuts	Torque	13 N·m (115 lb-in.)
FLOW CONTROL VALVE:		
Priority Flow Divider Spool Plug	Torque	98 N·m (72 lb-ft)
Proportional Flow Divider Spool Plug	Torque	44 N·m (33 lb-ft)
Relief Spools Seat Retainers	Torque	29 N·m (22 lb-ft)
Relief Spools Plugs	Torque	98 N·m (72 lb-ft)
Socket Head Mounting Screws	Torque	17 N·m (150 lb-in.)
WEIGHT TRANSFER:		
Solenoid Nut	Torque	5.5—8 N·m (48—72 lb-in.)
Cylinder Piston	Torque	47 N·m (35 lb-ft)
ROCKSHAFT ASSEMBLY:		
Rockshaft Valve		
Control Valve Spool Bolt Torque	Torque	10 N·m (88 lb-in.)
Control Valve-to-Rockshaft Cap Screw	Torque	24 N·m (18 lb-ft)
Control Valve Cover-to-Rockshaft	Torque	27 N·m (20 lb-ft)
Cap Screws		
Rockshaft Upper Lever Tension	Force	11.3—13.6 Kg (25—30 lb)
Rockshaft Piston Cover		
Piston Cover-to-Rockshaft	Torque	88 N·m (65 lb-ft)
Check Relief Valve Spring	Free length	27.7 mm (1.09 in.)
	Compressed length	18 mm at 10N (0.71 in. at 2 lb)
Check Relief Valve Plug	Torque	34 N·m (25 lb-ft)
Stop Valve Spring	Free length	36 mm (1.4 in.)
	Compressed length	14 mm at 59N (0.55 in. at 13 lb)
Stop Bolt Assembly-to-Piston	Torque	25 N·m (18 lb-ft)
Cover Socket Head Screws		
Overload Relief Valve Spring	Free length	44 mm (1.73 in.)
	Compressed length	38 mm at 170 N (1.50 in. at 38 lb)


MX,1015HV,A6 -19-30MAR93

REPAIR SPECIFICATIONS—CONTINUED

Item	Measurement	Specification
SECTION 70—HYDRAULIC REPAIR—CONTINUED		
Rockshaft Piston Cover—Continued		
Safety Relief Valve Retainer	Torque	27 N·m (20 lb-ft)
Safety Relief Valve Plug	Torque	78 N·m (58 lb-ft)
Rockshaft Piston		
Rockshaft Cylinder	ID	60.00—60.046 mm (2.362—2.364 in.)
Rockshaft Piston	OD	59.94—59.97 mm (2.360—2.361 in.)
Piston-to-Cylinder Wear Clearance	Maximum clearance	0.3 mm (0.012 in.)
Rockshaft Housing		
Rockshaft Sleeve	OD	44.950—44.975 mm (1.769—1.770 in.)
Sleeve-to-Bushing Clearance	Maximum clearance	0.4 mm (0.016 in.)
Rockshaft Bushing	ID	45.000—45.039 mm (1.771—1.773 in.)
Lift Arm-to-Rockshaft Bolts	Torque	52 N·m (38 lb-ft)
Rockshaft-to-Transmission Cap Screws	Torque	52 N·m (38 lb-ft)
Lift Linkage-to-Lift Arms	Torque	163 N·m (120 lb-ft)
Cap Screws and Nuts		
CUTTING UNIT MOTOR:		
3325 Reel Motor-to-Cutting	Torque	16 N·m (142 lb-in.)
Unit Cap Screws		
Motor Cap Screws	Torque	47 N·m (35 lb-ft)
Motor Gear Nut	Torque	54 N·m (40 lb-ft)
SECTION 80—MISCELLANEOUS REPAIR		
3325 Reel Motor-to-Cutting Unit	Torque	16 N·m (142 lb-in.)
Cap Screws		

MX,1015HV,A7 -19-30MAR93

METRIC BOLT AND CAP SCREW TORQUE VALUES



Size	Class 4.8				Class 8.8 or 9.8				Class 10.9				Class 12.9			
	Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a	
	N-m	lb-ft	N-m	lb-ft												
M6	4.8	3.5	6	4.5	9	6.5	11	8.5	13	9.5	17	12	15	11.5	19	14.5
M8	12	8.5	15	11	22	16	28	20	32	24	40	30	37	28	47	35
M10	23	17	29	21	43	32	55	40	63	47	80	60	75	55	95	70
M12	40	29	50	37	75	55	95	70	110	80	140	105	130	95	165	120
M14	63	47	80	60	120	88	150	110	175	130	225	165	205	150	260	190
M16	100	73	125	92	190	140	240	175	275	200	350	225	320	240	400	300
M18	135	100	175	125	260	195	330	250	375	275	475	350	440	325	560	410
M20	190	140	240	180	375	275	475	350	530	400	675	500	625	460	800	580
M22	260	190	330	250	510	375	650	475	725	540	925	675	850	625	1075	800
M24	330	250	425	310	650	475	825	600	925	675	1150	850	1075	800	1350	1000
M27	490	360	625	450	950	700	1200	875	1350	1000	1700	1250	1600	1150	2000	1500
M30	675	490	850	625	1300	950	1650	1200	1850	1350	2300	1700	2150	1600	2700	2000
M33	900	675	1150	850	1750	1300	2200	1650	2500	1850	3150	2350	2900	2150	3700	2750
M36	1150	850	1450	1075	2250	1650	2850	2100	3200	2350	4050	3000	3750	2750	4750	3500

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class.

Fasteners should be replaced with the same or higher property class. If higher property class fasteners are used, these should only be tightened to the strength of the original.



^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication.

Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

UNIFIED INCH BOLT AND CAP SCREW TORQUE VALUES

10-15-8

SAE Grade and Head Markings	NO MARK	1 or 2 ^b 	5 	5.1 	5.2 	8 	8.2 
	NO MARK	2 	5 		8 		

TS1162 -19-04MAR91

Size	Grade 1				Grade 2 ^b				Grade 5, 5.1, or 5.2				Grade 8 or 8.2			
	Lubricated ^a		Dry ^a													
	N-m	lb-ft	N-m	lb-ft												
1/4	3.7	2.8	4.7	3.5	6	4.5	7.5	5.5	9.5	7	12	9	13.5	10	17	12.5
5/16	7.7	5.5	10	7	12	9	15	11	20	15	25	18	28	21	35	26
3/8	14	10	17	13	22	16	27	20	35	26	44	33	50	36	63	46
7/16	22	16	28	20	35	26	44	32	55	41	70	52	80	58	100	75
1/2	33	25	42	31	53	39	67	50	85	63	110	80	120	90	150	115
9/16	48	36	60	45	75	56	95	70	125	90	155	115	175	130	225	160
5/8	67	50	85	62	105	78	135	100	170	125	215	160	215	160	300	225
3/4	120	87	150	110	190	140	240	175	300	225	375	280	425	310	550	400
7/8	190	140	240	175	190	140	240	175	490	360	625	450	700	500	875	650
1	290	210	360	270	290	210	360	270	725	540	925	675	1050	750	1300	975
1-1/8	470	300	510	375	470	300	510	375	900	675	1150	850	1450	1075	1850	1350
1-1/4	570	425	725	530	570	425	725	530	1300	950	1650	1200	2050	1500	2600	1950
1-3/8	750	550	950	700	750	550	950	700	1700	1250	2150	1550	2700	2000	3400	2550
1-1/2	1000	725	1250	925	990	725	1250	930	2250	1650	2850	2100	3600	2650	4550	3350

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication.

^b Grade 2 applies for hex cap screws (not hex bolts) up to 152 mm (6-in.) long. Grade 1 applies for hex cap screws over 152 mm (6-in.) long, and for all other types of bolts and screws of any length.