

Product: John Deere 322/330/332/430 Lawn and Garden Tractors Service Repair Technical Manual

Full Download: <https://www.arepairmanual.com/downloads/john-deere-322330332>

430-lawn-and-garden-tractors-service-repair-technical-manual

/ **322, 330,  
332 and 430  
Lawn and Garden  
Tractors**

For complete service information also see:

Yanmar Gasoline Engines. . . . . CTM12

John Deere Series 220 Diesel Engines . . . CTM3

John Deere Horizon Works

Sample of manual. Download All 360 pages at:

<https://www.arepairmanual.com/downloads/john-deere-322330332430-lawn-and-garden-tractors-service-repair-technical-manual>

TM1501 (15JUL95)

LITHO IN U.S.A.  
ENGLISH

# Introduction

Product: John Deere 322/330/332/430 Lawn and Garden Tractors Service Repair Technical Manual

Full Download: <https://www.arepairmanual.com/downloads/john-deere-322330332>

430 lawn and garden tractors service repair technical manual

## FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

**N** This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and diagnostics. Repair sections tell how to repair the components. Diagnostic sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, other materials needed to do the job and service parts kits.

Section 10, Group 15—Repair Specifications, consist of all applicable specifications, near tolerances and specific torque values for various components on each individual machine.

Section 10, Group 20—Test and Adjustment Specifications, consist of all applicable test and adjustment specifications for various systems for each individual machine.

Binders, binder labels, and tab sets can be ordered by John Deere dealers direct from the John Deere Distribution Service Center.

This manual is part of a total product support program.

## FOS MANUALS—REFERENCE

### TECHNICAL MANUALS—MACHINE SERVICE

### COMPONENT MANUALS—COMPONENT SERVICE

Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

Technical Manuals are concise guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Component Technical Manuals are concise service guides for specific components. Component technical manuals are written as stand-alone manuals covering multiple machine applications.

Sample of manual. Download All 566 pages at:

<https://www.arepairmanual.com/downloads/john-deere-322330332430-lawn-and-garden-430-lawn-and-garden-tractors-service-repair-technical-manual>

MX,1590,IFC -19-09DEC94

030895

# Contents

## SECTION 10—GENERAL INFORMATION

- Group 05—Safety
- Group 10—General Specifications
- Group 15—Repair Specifications
- Group 20—Test and Adjustment Specifications
- Group 25—Fuels and Lubricants
- Group 30—Serial Number Locations

- Group 10—Diagnosis, Tests and Adjustments—322
- Group 11—Diagnosis, Tests and Adjustments—330, 332 and 430

10

## SECTION 20—ENGINE REPAIR

- Group 05—Engine—322
- Group 06—Engine—330, 332 and 430

20

## SECTION 40—ELECTRICAL REPAIR

- Group 05—Front PTO Clutch

40

## SECTION 50—POWER TRAIN REPAIR

- Group 05—Transmission
- Group 10—Transmission Control Linkage
- Group 15—Differential
- Group 20—Rear Axles
- Group 25—Drive Shaft—322, 330 and 332
- Group 26—Drive Shaft—430

## SECTION 240—ELECTRICAL SYSTEM CHECKOUT, OPERATION AND DIAGNOSIS

- Group 05—Electrical System Checkout
- Group 10—Electrical Schematics
- Group 15—Component Location and Operation
- Group 20—Electrical System Diagnosis
- Group 25—Electrical System Component Tests and Adjustments

50

## SECTION 60—STEERING AND BRAKE REPAIR

- Group 05—Steering—330
- Group 06—Steering—322, 332 and 430
- Group 10—Brakes

60

## SECTION 250—POWER TRAIN CHECKOUT, OPERATION AND DIAGNOSIS

- Group 05—Power Train Checkout
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests and Adjustments

70

## SECTION 70—HYDRAULIC REPAIR

- Group 05—Hydraulic Control Valve

80

## SECTION 80—MISCELLANEOUS REPAIR

- Group 05—Front Axle
- Group 10—Mower Spindle and Jack Sheave Repair
- Group 15—Mower Gear Case Repair

## SECTION 260—STEERING AND BRAKES CHECKOUT, OPERATION AND DIAGNOSIS

- Group 05—Steering And Brakes System Checkout
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests and Adjustments

220

## SECTION 220—ENGINE, FUEL AND AIR SYSTEM CHECKOUT AND DIAGNOSIS

- Group 05—Engine, Fuel and Air System Checkout

240

## SECTION 270—HYDRAULIC SYSTEM CHECKOUT, OPERATION AND DIAGNOSIS

- Group 05—Hydraulic System Checkout
- Group 10—Hydraulic Schematics
- Group 15—Theory of Operation
- Group 20—Diagnosis, Tests and Adjustments

250

## SECTION 299—DEALER FABRICATED TOOLS

- Group 00—Dealer Fabricated Tools

## Index

*All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

TM1591-19-15JUL95

COPYRIGHT© 1995

DEERE &amp; COMPANY

Moline, Illinois

All rights reserved

A John Deere ILLUSTRATION™ Manual

10

20

40

50

60

70

80

220

240

250

260

270

299

INDX

260

270

299

INDX

# Dealer Presentation Sheet

## JOHN DEERE DEALERS

**IMPORTANT: Please remove this page and route through your service department.**

This is a complete revision for models 322, 330, 332 and 430 found in TM1277, TM1309 and TM1345. The complete revision of remaining machines (316, 318 and 420) can be found in TM1590. AFTER receiving both TM1590 and TM1591, please discard old TM1277 dated December 1987, TM1309 dated July 1985 and TM1345 dated June 1986.

*NOTE: There are several "versions" of each model tractor. All versions were not available at time of latest printing. Some versions may not be covered.*

*Dealer Presentation Sheet*

# Section 10

# GENERAL INFORMATION

## Contents

### Page

**Group 05—Safety** ..... 10-05-1

**Group 10—General Specifications**

Machine Specifications

322 and 330 ..... 10-10-1  
332 and 430 ..... 10-10-4

**Group 15—Repair Specifications**

Repair Specifications ..... 10-15-1  
Metric Series Torque Chart ..... 10-15-4  
Inch Series Torque Chart ..... 10-15-5  
Metric Torque Values—Grade 7 ..... 10-15-6  
Set Screw Torque Chart ..... 10-15-6  
Service Recommendations  
Flat Face O-Ring Seal Fittings ..... 10-15-8  
Tube and Hose Fitting, 37° Flare and  
30° Cone Seat Connectors ..... 10-15-9

**Group 20—Test and Adjustment  
Specifications** ..... 10-20-1

**Group 25—Fuels and Lubricants**

Fuel—322 ..... 10-25-1  
Diesel Fuel—330, 332 and 430 ..... 10-25-2  
Storing Fuel ..... 10-25-3  
Do Not Use Galvanized Containers ..... 10-25-3  
Engine Oil—322 ..... 10-25-4  
Diesel Engine Oil—330, 332 and 430 ..... 10-25-5  
Engine Coolant ..... 10-25-6  
Liquid Coolant Conditioner ..... 10-25-6  
Transmission and Hydraulic Oil ..... 10-25-7  
Grease ..... 10-25-8  
Mower Deck Gear Case Oil ..... 10-25-8  
Alternative and Synthetic Lubricants ..... 10-25-9  
Lubricant Storage ..... 10-25-9  
Mixing of Lubricants ..... 10-25-9

**Group 30—Serial Number Locations**

Serial Numbers

Product Identification ..... 10-30-1  
Engine ..... 10-30-1  
Transmission ..... 10-30-1  
Differential ..... 10-30-2  
Control Valve ..... 10-30-2



## RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT

-19-03MAR93

10  
05  
1

-UN-07DEC88  
T81389

## UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.

**DANGER**

**WARNING**

**CAUTION**

DX,SIGNAL

-19-03MAR93

-19-30SEP88  
TS187

## FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.



-UN-23AUG88  
TS201

DX,READ -19-03MAR93

10  
05  
2**HANDLE FLUIDS SAFELY—AVOID FIRES**

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.

TS227  
-UN-23AUG88

DX,FLAME -19-04JUN90

**PREVENT BATTERY EXPLOSIONS**

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).

TS204  
-UN-23AUG88


DX,SPARKS -19-03MAR93

**PREPARE FOR EMERGENCIES**

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.

TS291  
-UN-23AUG88

DX,FIRE2 -19-03MAR93

## PREVENT ACID BURNS

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 15—30 minutes. Get medical attention immediately.

If acid is swallowed:

1. Do not induce vomiting.
2. Drink large amounts of water or milk, but do not exceed 2 L (2 quarts).
3. Get medical attention immediately.



-UN-23AUG88

TS203

DX,POISON -19-21APR93

## SERVICE COOLING SYSTEM SAFELY

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.



-UN-23AUG88

TS281

DX,RCAP -19-04JUN90

10  
05  
4


## HANDLE CHEMICAL PRODUCTS SAFELY

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.

Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

(See your John Deere dealer for MSDS's on chemical products used with John Deere equipment.)



TS1132 -UN-26NOV90

DX,MSDS,NA -19-03MAR93


## AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.




X9811 -UN-23AUG88

DX,FLUID -19-03MAR93

## PREPARE MACHINE FOR REPAIR

1. Move hydrostatic control lever to STOP position.
2. Disengage PTO's
3. Lower all equipment to the ground.
4. Engage park brake.
5. Stop the engine and remove the key.
6. Operate all hydraulic control levers to release hydraulic pressure in the system.

Before you leave the operator's seat, wait for engine and attachment parts to stop moving.

10  
05  
5

-UN-24APR89


M34228

MX,1005R,8 -19-01APR86

## SUPPORT MACHINE PROPERLY

Always lower the attachment or implement to the ground before you work on the machine. If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.



-UN-23AUG88

TS229

DX,LOWER -19-04JUN90


10  
05  
6**WEAR PROTECTIVE CLOTHING**

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.


TS206  
-UN-23AUG88

DX,WEAR -19-10SEP90

**WORK IN CLEAN AREA**

Before starting a job:

- Clean work area and machine.
- Make sure you have all necessary tools to do your job.
- Have the right parts on hand.
- Read all instructions thoroughly; do not attempt shortcuts.


T6642EJ  
-UN-18OCT88

DX,CLEAN -19-04JUN90

**SERVICE MACHINES SAFELY**

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.


TS228  
-UN-23AUG88

DX,LOOSE -19-04JUN90

## WORK IN VENTILATED AREA

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.



DX,AIR

-19-04JUN90


-UN-23AUG88

TS220

10  
05  
7

## ILLUMINATE WORK AREA SAFELY

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.



DX,LIGHT

-19-04JUN90

-UN-23AUG88

TS223

## REPLACE SAFETY SIGNS

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.



DX,SIGNS1

-19-04JUN90


-UN-23AUG88

TS201

## USE PROPER LIFTING EQUIPMENT

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components in the manual.



DX,LIFT

-19-04JUN90

-UN-23AUG88

TS226

10  
05  
8

## REMOVE PAINT BEFORE WELDING OR HEATING


Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Do all work outside or in a well ventilated area. Dispose of paint and solvent properly.

Remove paint before welding or heating:

- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

-UN-23AUG88  
TS220

DX,PAINT -19-03MAR93

## AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.

-UN-15MAY90  
TS953

DX,TORCH -19-03MAR93

## SERVICE TIRES SAFELY

Explosive separation of a tire and rim parts can cause serious injury or death.

Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job.

Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Never weld or heat a wheel and tire assembly. The heat can cause an increase in air pressure resulting in a tire explosion. Welding can structurally weaken or deform the wheel.

When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side and NOT in front of or over the tire assembly. Use a safety cage if available.

Check wheels for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.

10  
05  
9-UN-12APR90  
TS952

DX,TIRECP -19-24AUG90


## AVOID HARMFUL ASBESTOS DUST

Avoid breathing dust that may be generated when handling components containing asbestos fibers. Inhaled asbestos fibers may cause lung cancer.

Components in products that may contain asbestos fibers are brake pads, brake band and lining assemblies, clutch plates, and some gaskets. The asbestos used in these components is usually found in a resin or sealed in some way. Normal handling is not hazardous as long as airborne dust containing asbestos is not generated.

Avoid creating dust. Never use compressed air for cleaning. Avoid brushing or grinding material containing asbestos. When servicing, wear an approved respirator. A special vacuum cleaner is recommended to clean asbestos. If not available, apply a mist of oil or water on the material containing asbestos.

Keep bystanders away from the area.



-UN-23AUG88

TS220

DX,DUST -19-15MAR91

## PRACTICE SAFE MAINTENANCE

10  
05  
10  
Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

Disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.



-UN-23AUG88

TS218

DX,SERV

-19-03MAR93

## USE PROPER TOOLS

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards.

Use power tools only to loosen threaded parts and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only service parts meeting John Deere specifications.



-UN-08NOV89

TS779

DX,REPAIR -19-04JUN90

## DISPOSE OF WASTE PROPERLY


Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.

10  
05  
11

-UN-26NOV90

TS1133

DX,DRAIN -19-03MAR93

## LIVE WITH SAFETY

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.



-19-07OCT88

TS231

DX,LIVE -19-25SEP92

10  
05  
12

**MACHINE SPECIFICATIONS—322 AND 330**

	322	330
<b>ENGINE</b>		
Manufacturer	Yanmar	Yanmar
Model Number	3TG66UJ	3TN66UJ
Horsepower (SAEJ1349)	13.4 kW (18 hp)	12 kW (16 hp)
Torque	4.2 kg m (30.3 ft lbs)	4.2 kg m (30.3 ft lbs)
Engine Rated Speeds		
Fast Idle (No Load)	3500 rpm	3450 rpm
Low Idle (No Load)	1300 rpm	1300 rpm
Number of Cylinders	3	3
Crankshaft Alignment	Horizontal	Horizontal
Stroke/Cycle	4 Cycle	4 Cycle
Bore	66 mm (2.6 in.)	66 mm (2.6 in.)
Stroke	64.2 mm (2.5 in.)	64.2 mm (2.5 in.)
Displacement	658 cm <sup>3</sup> (40.1 cu in.)	658 cm <sup>3</sup> (40.1 cu in.)
Compression Ratio	8.7:1	22.4:1
Cooling	Liquid	Liquid
Coolant Capacity	2.8 L (3 U.S. qt)	2.8 L (3 U.S. qt)
Air Filter Type	Dry with Primary and Secondary Elements	Dry with Primary and Secondary Elements
Lubrication System	Full Pressure w/Filter	Full Pressure w/Filter
Crankcase Capacity (w/o Filter)	2.5 L (2.6 U.S. qt)	2.5 L (2.6 U.S. qt)
Oil Filter	Replaceable	Replaceable
Spark Plugs	NGK BPR4BS	N/A
	Champion RN11YC	

**FUEL SYSTEM**

Fuel Tank Location	Rear	Rear
Fuel Gauge	Standard	Standard
Fuel Tank Capacity	17 L (4.5 U.S. gal)	17 L (4.5 U.S. gal)
Fuel	85 Octane Unleaded	No.1 or No.2 Diesel
Fuel Pump Location	Frame	Frame
Fuel Pump Type	Electric	Electric
Fuel Delivery	Fixed Jet Carburetor	Indirect Injection
Injection Pump Type	N/A	In-Line Multi-Plunger
Fuel Shutoff	Electric Solenoid	Manual

**ELECTRICAL SYSTEM**

Ignition	Electronic	N/A
Type of Starter	12 Volts, Solenoid	12 Volts, Solenoid
Charging System	Remote Alt. 20 amp	Remote Alt. 20 amp
Battery Type	BCI Group, U1	BCI Group, U1
Battery Voltage	12V	12V
Battery Reserve Capacity @25 amp	44 minutes	44 minutes
Battery		
Cold Cranking amp @0°F	342 amp	342 amp
Headlights	Standard	Standard
Reflector/Tail Lights	Standard	Standard
Dash Indicator Lights	Standard	Standard
Operator Presence System	Standard	Standard
Hourmeter	Standard	Standard

*Continued on next page.*

MX,15911010,1 -19-13JUL95

10  
10  
1

	322	330
<b>POWER TRAIN</b>		
Transmission Type	Hydrostatic	Hydrostatic
Number of Speeds	Infinite	Infinite
<b>Travel Speeds</b>		
Forward	0—12.38 km/h (0—7.69 mph)	0—12.38 km/h (0—7.69 mph)
Reverse	0—6.19 km/h (0—3.85 mph)	0—6.19 km/h (0—3.85 mph)
Transmission Capacity (w/Filter)	6.1 L (13 U.S. pt)	6.1 L (13 U.S. pt)
Trans. Oil Cooler	Optional	N/A
Trans. Oil Filter	Standard	Standard
Differential Lock	N/A	N/A
<b>STEERING</b>		
Type	Power, Hydrostatic	Manual
<b>BRAKES</b>		
Location	Rear Wheels	Rear Wheels
Individual Control	Standard	N/A
Type	Shoe and Drum	Shoe and Drum
Return-to-Neutral Braking	Standard	Standard
Parking	Yes	Yes
<b>HYRAULIC SYSTEM</b>		
Type	Two-Function (One w/Float)	Single-Function
Hydraulic Couplers	Two Sets	One Set
<b>PTO</b>		
Front	Standard	Standard
Rear	Optional	Optional
Type	Electric Clutch	Electric Clutch
Control	Elec. Switch on Dash	Elec. Switch on Dash
<b>PTO rpm (No Load)</b>		
Front	3500	3450
Rear	2000	2000
<b>MOWER ATTACHMENT</b>		
Compatibility	38, 46 and 50 Inch	38, 46 and 50 Inch
Lift System	Hydraulic	Hydraulic
<b>WHEEL TREAD</b>		
Front	813 mm (32 in.)	813 mm (32 in.)
Rear		
Narrow	775 mm (30.5 in.)	775 mm (30.5 in.)
Wide	834 mm (32.8 in.)	834 mm (32.8 in.)

Continued on next page.

MX,15911010,2 -19-13JUL95

322

330

## TIRES

## Standard Tires

Front Turf . . . . .	16 x 6.50-8, 2 PR . . . . .	16 x 6.50-8, 2 PR
Rear Turf or Bar . . . . .	23 x 10.50-12, 2 PR . . . . .	23 x 10.50-12, 2 PR

## Optional Tires

Front (Turf) . . . . .	16 x 6.50-8, 4 PR . . . . .	16 x 6.50-8, 4 PR
Rear (Turf or Bar) . . . . .	23 x 8.50-12, 2 PR . . . . .	23 x 8.50-12, 2 PR

## Inflation Pressure

Front . . . . .	41—110 kPa (6—16 psi) . . . . .	41—110 kPa (6—16 psi)
Rear . . . . .	34—69 kPa (5—10 psi) . . . . .	34—69 kPa (5—10 psi)

## SEAT

Style . . . . .	High-Back . . . . .	High-Back
Suspension . . . . .	2 Spring . . . . .	2 Spring
Adjustment . . . . .	Slide Rail . . . . .	Slide Rail

## DIMENSIONS

Wheel Base . . . . .	1.2 m (46 in.) . . . . .	1.2 m (46 in.)
----------------------	--------------------------	----------------

Overall Length . . . . .	1.8 m (69.5 in.) . . . . .	1.8 m (69.5 in.)
--------------------------	----------------------------	------------------

Overall Height . . . . .	1.1 m (44.5 in.) . . . . .	1.1 m (44.5 in.)
--------------------------	----------------------------	------------------

Overall Width (max.) . . . . .	1.1 m (43.3 in.) . . . . .	1.1 m (43.3 in.)
--------------------------------	----------------------------	------------------

Overall Width (min.) . . . . .	1.04 m (41 in.) . . . . .	1.04 m (41 in.)
--------------------------------	---------------------------	-----------------

## Turning Radius

Inside Rear Wheel . . . . .	0.66 m (26 in.) . . . . .	0.66 m (26 in.)
-----------------------------	---------------------------	-----------------

Outside Front Wheel . . . . .	2.0 m (80 in.) . . . . .	2.0 m (80 in.)
-------------------------------	--------------------------	----------------

NET WEIGHT (No Fuel) . . . . .	408 kg (900 lbs) . . . . .	408 kg (900 lbs)
--------------------------------	----------------------------	------------------

SHIPPING WEIGHT . . . . .	445 kg (980 lbs) . . . . .	445 kg (980 lbs)
---------------------------	----------------------------	------------------

(Specifications and design subject to change without notice.)

MX,15911010,3 -19-13JUL95

**MACHINE SPECIFICATIONS—332 AND 430**

332

430

**ENGINE**

Manufacturer	Yanmar	Yanmar
Model Number	3TN66UJ	3TNA72UJ
Horsepower (SAEJ1349)	12 kW (16 hp)	15 kW (20 hp)
Torque	4.2 kg m (30.3 ft lbs)	5.1 kg m (36.8 ft lbs)
Engine Rated Speeds		
Fast Idle (No Load)	3425 rpm	3400 rpm
Low Idle (No Load)	1400 rpm	1300 rpm
Number of Cylinders	3	3
Crankshaft Alignment	Horizontal	Horizontal
Stroke/Cycle	4 Cycle	4 Cycle
Bore	66 mm (2.6 in.)	72 mm (2.84 in.)
Stroke	64.2 mm (2.5 in.)	72 mm (2.84 in.)
Displacement	658 cm <sup>3</sup> (40.1 cu in.)	879 cm <sup>3</sup> (53.6 cu in.)
Compression Ratio	22.4:1	21.6:1
Cooling	Liquid	Liquid
Coolant Capacity	2.8 L (3 U.S. qt)	3.8 L (1 U.S. gal)
Air Filter Type	Dry with Primary and Secondary Elements	Dry with Primary and Secondary Elements
Lubrication System	Full Pressure w/Filter	Full Pressure w/Filter
Crankcase Capacity (w/o Filter)	2.5 L (2.6 U.S. qt)	2.9 L (3.1 U.S. qt)
Oil Filter	Replaceable	Replaceable

**FUEL SYSTEM**

Fuel Tank Location	Rear	Rear
Fuel Gauge	Standard	Standard
Fuel Tank Capacity	17 L (4.5 U.S. gal)	24.6 L (6.5 U.S. gal)
Fuel	No.1 or No.2 Diesel	No.1 or No.2 Diesel
Fuel Pump Location	Frame	Frame
Fuel Pump Type	Electric	Electric
Fuel Delivery	Indirect Injection	Indirect Injection
Injection Pump Type	In-Line Multi-Plunger	In-Line Multi-Plunger
Fuel Shutoff	Electric Solenoid	Electric Solenoid

**ELECTRICAL SYSTEM**

Ignition	N/A	N/A
Type of Starter	12 Volts, Solenoid	12 Volts, Solenoid
Charging System		
Early Machines	Remote Alt. 20 amp	Remote Alt. 35 amp
Later Machines	Remote Alt. 20 amp	Remote Alt. 40 amp
Battery Type	BCI Group, U1	BCI Group, 22F
Battery Voltage	12V	12V
Battery Reserve Capacity @25 amp	44 minutes	102 minutes
Battery		
Cold Cranking amp @0°F	342 amp	491 amp
Headlights	Standard	Standard
Reflector/Tail Lights	Standard	Standard
Dash Indicator Lights	Standard	Standard
Operator Presence System	Standard	Standard
Hourmeter	Standard	Standard

Continued on next page.

MX.15911010.4 -19-13JUL95

	332	430	10 10 5
<b>POWER TRAIN</b>			
Transmission Type	Hydrostatic	Hydrostatic, 2 Ranges	
Number of Speeds	Infinite	Infinite	
<b>Travel Speeds</b>			
Forward	0—12.38 km/h (0—7.69 mph)	N/A	
Reverse	0—6.19 km/h (0—3.85 mph)	N/A	
Forward, High	N/A	0—16.09 km/h (0—10 mph)	
Forward, Low	N/A	0—9.35 km/h (0—5.80 mph)	
Reverse, High	N/A	0—6.44 km/h (0—4 mph)	
Reverse, Low	N/A	0—4.66 km/h (0—2.90 mph)	
Transmission Capacity (w/Filter)	6.1 L (13 U.S. pt)	7.1 L (15 U.S. pt)	
Trans. Oil Cooler	Optional	Standard	
Trans. Oil Filter	Standard	Standard	
Differential Lock	N/A	Standard	
<b>STEERING</b>			
Type	Power, Hydrostatic	Power, Hydrostatic	
<b>BRAKES</b>			
Location	Rear Wheels	Rear Wheels	
Individual Control	Standard	Standard	
Type	Shoe and Drum	Shoe and Drum	
Return-to-Neutral Braking	Standard	Standard	
Parking	Yes	Yes	
<b>HYRAULIC SYSTEM</b>			
Type	Two-Function (One w/Float)	Three-Function (One w/Float)	
Hydraulic Couplers	Two Sets	Two Sets	
<b>PTO</b>			
Front	Standard	Standard	
Rear	Optional	Optional	
Type	Electric Clutch	Electric Clutch	
Control	Elec. Switch on Dash	Elec. Switch on Dash	
<b>PTO rpm (No Load)</b>			
Front	3425	3400	
Rear	2000	2000	
<b>MOWER ATTACHMENT</b>			
Compatibility	38, 46 and 50 Inch	50 and 60 Inch, 260 Rotary	
Lift System	Hydraulic	Hydraulic	

Continued on next page.

MX,15911010,5 -19-13JUL95

	332	430
<b>WHEEL TREAD</b>		
Front	813 mm (32 in.)	914 mm (36 in.)
Rear		
Narrow	775 mm (30.5 in.)	818 mm (32 in.)
Wide	834 mm (32.8 in.)	980 mm (38.6 in.)
<b>TIRES</b>		
Standard Tires		
Front Turf	16 x 6.50-8, 2 PR	18 x 8.50-8, 4 PR
Rear Turf or Bar	23 x 10.50-12, 2 PR	26 x 12.00-12, 2 PR
Optional Tires		
Front (Turf)	16 x 6.50-8, 4 PR	N/A
Rear (Turf or Bar)	23 x 8.50-12, 2 PR	N/A
Inflation Pressure		
Front	41—110 kPa (6—16 psi)	41—152 kPa (6—22 psi)
Rear	34—69 kPa (5—10 psi)	34—69 kPa (5—10 psi)
<b>SEAT</b>		
Style	High-Back/Tilt	High-Back/Tilt
Suspension	2 Spring	Deluxe Seat Suspension
Adjustment	Slide Rail	Slide Rail
<b>DIMENSIONS</b>		
Wheel Base	1.2 m (46 in.)	1.3 m (52 in.)
Overall Length	1.8 m (69.5 in.)	2.13 m (84 in.)
Overall Height	1.1 m (44.5 in.)	1.22 m (48.5 in.)
Overall Width (max.)	1.1 m (43.3 in.)	1.31 m (51.5 in.)
Overall Width (min.)	1.04 m (41 in.)	1.14 m (45 in.)
Turning Radius		
Inside Rear Wheel	0.66 m (26 in.)	0.66 m (26 in.)
Outside Front Wheel	2.0 m (80 in.)	2.2 m (86 in.)
<b>NET WEIGHT (No Fuel)</b>	408 kg (900 lbs)	533 kg (1116 lbs)
<b>SHIPPING WEIGHT</b>	445 kg (980 lbs)	567 kg (1219 lbs)

(Specifications and design subject to change without notice.)

MX,15911010,6 -19-13JUL95

## REPAIR SPECIFICATIONS

Item	Specifications	10 15 1
<b>ENGINE</b>		
For all repair specifications—Use CTM12 (322) and CTM3 (330, 332 and 430)		
Engine Mounting Cap Screw/Nut Torque . . . . .	49 N·m (36 lb·ft)	
Drive Shaft to Engine Cap Screw Torque		
330 and 430 . . . . .	27 N·m (20 lb·ft)	
322 and 332 . . . . .	37 N·m (27 lb·ft)	
Drive Shaft Universal Joint Cap Screw Torque . . . . .	60 N·m (45 lb·ft)	
PTO Belt Tension Spring Length (430) . . . . .	35 mm (1.38 in.)	
Fuel/Water Separator Cap Screw Torque (430) . . . . .	20 N·m (180 lb·in.)	
<b>ELECTRICAL</b>		
Front PTO Clutch-to-Crankshaft Cap Screw Torque . . . . .	47 N·m (35 lb·ft)	
PTO Clutch Armature to Rotor Clearance . . . . .	0.46 mm (0.018 in.)	
PTO Belt Tension Spring Length (430) . . . . .	35 mm (1.380 in.)	
<b>POWER TRAIN</b>		
Transmission		
Charge Pump-to-Transmission Cap Screw Torque . . . . .	70 N·m (52 lb·ft)	
Transmission Cover Bearing Installation Height . . . . .	3 mm (0.118 in.) above housing surface	
Center Section-to-Housing Cap Screw Torque . . . . .	35 N·m (26 lb·ft)	
Transmission-to-Differential Cap Screw Torque . . . . .	45 N·m (33 lb·ft)	
Axe Housing-to-Frame Cap Screw Torque . . . . .	100 N·m (75 lb·ft)	
Brake Rod Spring Length . . . . .	42 mm (1.650 in.)	
Differential-to-Frame Support Cap Screw Torque . . . . .	61 N·m (45 lb·ft)	
Swashplate Control Arm-to-Control Shaft Nut Torque . . . . .	60 N·m (44 lb·ft)	
Drive Shaft Clamping Yoke-to-Transmission Pump Shaft Cap Screw Torque . . . . .	60 N·m (44 lb·ft)	
Differential		
Case and Cover Oil Groove Depth (Minimum) . . . . .	0.25 mm (0.010 in.)	
Carrier Cap Screw Torque . . . . .	53 N·m (39 lb·ft)	
Cover-to-Case Cap Screw Torque . . . . .	23 N·m (204 lb·in.)	
Axe Housing		
Differential Seal Depth . . . . .	3 mm (0.118 in.) below differential surface	
Axe Housing-to-Differential Cap Screw Torque . . . . .	81 N·m (60 lb·ft)	
Brake Plate-to-Axe Housing Cap Screw Torque . . . . .	68 N·m (50 lb·ft)	
Axe Housing-to-Frame Cap Screw Torque . . . . .	100 N·m (75 lb·ft)	
Brake Rod Spring Length . . . . .	42 mm (1.650 in.)	
Brake Drum Nut Torque . . . . .	88 N·m (65 lb·ft)	
Rear Wheel Cap Screw Torque . . . . .	70 N·m (52 lb·ft)	
Drive Shaft—322 and 332		
Isolator-to-Engine Cap Screw Torque . . . . .	37 N·m (27 lb·ft)	
Drive Shaft Cap Screws and Lock Nut Torque		
Flange-to-Isolator . . . . .	27 N·m (20 lb·ft)	
Clamping Yoke-to-Transmission Pump Shaft . . . . .	60 N·m (44 lb·ft)	
Drive Shaft—330		
Isolator-to-Engine Cap Screw Torque . . . . .	27 N·m (20 lb·ft)	
Drive Shaft Cap Screws and Lock Nut Torque		
Flange-to-Isolator . . . . .	27 N·m (20 lb·ft)	
Clamping Yoke-to-Transmission Pump Shaft . . . . .	60 N·m (44 lb·ft)	

Continued on next page.

MX,15911015,1 -19-13JUL95

## 430-lawn-and-garden-tractors-service-repair-technical-manual

## Specifications

Item /	Specifications
10 POWER TRAIN, continued	
15 Drive Shaft—430	
2 Flange-to-Engine Cap Screw Torque . . . . .	27 N·m (20 lb·ft)
Clamping Yoke-to-Transmission Pump Shaft Cap Screw Torque . . . . .	60 N·m (44 lb·ft)
Tube Yoke Shaft-to-Bushing Yoke Tube Lock Nut Torque . . . . .	3 N·m (25 lb·in.)
<b>STEERING AND BRAKES</b>	
Steering—330	
Gearbox Mounting Cap Screw Torque . . . . .	95 N·m (70 lb·ft)
Steering Wheel-to-Shaft Nut Torque . . . . .	15 N·m (133 lb·in.)
Pitman Arm Nut Torque . . . . .	224 N·m (165 lb·ft)
Preload Adjuster Maximum End Clearance . . . . .	0.05 mm (0.002 in.)
Side Cover-to-Gearbox Housing Cap Screw Torque . . . . .	40 N·m (30 lb·ft)
Worm Bearing Preload Rolling Torque . . . . .	0.60—1.0 N·m (5—8 lb·in.)
Over-Center Preload Rolling Torque . . . . .	0.50—1.20 N·m (4—10 lb·in.)
Preload Adjuster Lock Nut Torque . . . . .	34 N·m (25 lb·ft)
Steering Shaft Universal Joint-to-Worm Shaft Cap Screw Torque . . . . .	24 N·m (212 lb·in.)
Steering—322, 332 and 430	
Steering Wheel-to-Shaft Nut Torque . . . . .	15 N·m (133 lb·in.)
Rotor-to-Stator Maximum Allowable Clearance . . . . .	0.08 mm (0.003 in.)
Steering Tube Bushing Depth . . . . .	2.5 mm (0.100 in.) below top of tube
Commutator Cover-to-Commutator Screw Torque . . . . .	1.4 N·m (12 lb·in.)
Port Cover Nut Torque . . . . .	30 N·m (22 lb·ft)
Check Ball Plug Torque (Early Version) . . . . .	14 N·m (124 lb·in.)
Steering Cylinder Mounting Nut Torque . . . . .	163 N·m (120 lb·ft)
Brakes	
Brake Plate-to-Axle Housing Cap Screw Torque . . . . .	68 N·m (50 lb·ft)
Axle Housing-to-Frame Cap Screw Torque . . . . .	100 N·m (75 lb·ft)
Brake Rod Spring Length . . . . .	42 mm (1.650 in.)
Brake Drum-to-Axle Nut Torque . . . . .	88 N·m (65 lb·ft)
Rear Wheel Cap Screw Torque . . . . .	70 N·m (52 lb·ft)
<b>HYDRAULICS</b>	
Single-Spool Valve	
Spool Screw Torque . . . . .	4 N·m (35 lb·in.)
Spool Cap-to-Body Screw Torque . . . . .	4 N·m (35 lb·in.)
Check Valve Plug Torque . . . . .	31 N·m (23 lb·ft)
Two-Spool Valve	
Versions One and Two	
Spool Cap-to-Body Screw Torque . . . . .	31 N·m (23 lb·ft)
Versions Three and Four	
Spool Screw and Detent Torque . . . . .	4 N·m (35 lb·in.)
Spool Cap-to-Body Screw Torque . . . . .	4 N·m (35 lb·in.)
Check Valve Plug Torque . . . . .	31 N·m (23 lb·ft)
Three-Spool Valve	
Spool Screws and Detent Torque . . . . .	4 N·m (35 lb·in.)
Spool Cap-to-Body Screw Torque . . . . .	4 N·m (35 lb·in.)
Check Valve Plug Torque . . . . .	31 N·m (23 lb·ft)

Continued on next page. Download All 566 pages at:

MX.15911015.2 -19-13JUL95

<https://www.arepairmanual.com/downloads/john-deere-322330332430-lawn-and-garden-tractors-service-repair-technical-manual>

10-15-2

030895