



Series 500 6619 Diesel Engines



JOHN DEERE

COMPONENT TECHNICAL MANUAL Series 500 6619 Diesel Engines

CTM9 (25JAN96) English

Deere Power Systems Group
CTM9 (25JAN96)

LITHO IN U.S.A.
ENGLISH



Introduction

FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Use this component technical manual in conjunction with the machine technical manual. An application listing in the introduction identifies product-model/component type-model relationship. See the machine technical manual for information on component removal and installation, and gaining access to the components.

This manual is divided in two parts: repair and operation and tests. Repair sections contain

necessary instructions to repair the component. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Component Technical Manuals are concise service guides for specific components. Component technical manuals are written as stand-alone manuals covering multiple machine applications.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

JOHN DEERE DEALERS

IMPORTANT: The changes listed below make your current CTM obsolete. Discard CTM9, dated (2-87). Please copy this page and route through your service department.


- All safety information has been updated in Group 00. All persons using this manual should read and understand this information.
- Essential and Special Tools listings have been updated throughout the manual.
- Specifications listed at the beginning of each group have been updated.
- Basic engine specifications have been deleted from Group 01. Specifications are covered in detail in their respective groups. All specifications lists have been updated.
- Engine break-in oil information has been added. Engine coolant requirements and recommendations have been updated. (Group 02.)
- Methods for properly lifting of engines have been updated. (Group 03.)
- Information on recommended sealants, thread lock compounds, anti-seize compounds, gasket materials and adhesives has been updated. Generic material recommendations have been updated to provide more specific information. Also, Sealant Applications Guidelines that provide ordering information for these materials as well as helpful "where used" information. (Group 04.)
- Valve clearance checking and adjustment procedure updated to show that these procedures **MUST BE** done with engine **COLD**. Cylinder head removal, inspection, and installation procedures have been updated. (Group 05.)
- Cylinder head cap screw and tightening information have been updated. (Group 05.)
- Crankshaft gear removal and installation procedures, crankshaft grinding guidelines and specifications chart have been updated. (Group 15.)
- Procedures for the removal, repair and installation of the fuel injection pumps have been updated. (Group 35.)
- Engine break-in procedures have been updated. (Group 100.)
- Most component identification illustrations and general system descriptions have been moved to Group 105, Engine System Operation and Tests.
- Dealer Fabricated Tools have been removed from the individual groups and consolidated in Group 199.

ABOUT THIS MANUAL


This component Technical Manual (CTM-9) covers the recommended repair procedure for all 10.1 L (619 cu. in.) Engines produced in Waterloo, Iowa. Before beginning repair of an engine, clean engine and mount in a safety approved repair stand. (See Group 03.)

This manual contains SI Metric units of measure, followed immediately by the U.S. customary units of measure.

Some components of this engine may be serviced without removing the engine from the machine. Refer to the specific machine technical manuals for information on components that can be serviced without removing the engine from the machine and for engine removal/installation procedures.



RG5207 -UN-19JAN90



RG5208 -UN-19JAN90

S11.2000,EK -19-25JAN96

Contents

	Page		Page
Group 00—Safety			
Group 01—General Information			
Engine Model Designation	01-3	Specifications	05-4
Engine Serial Number Information	01-5	Torques	05-6
Option Code Label	01-7	Check and Adjust Valve Clearance	05-7
Engine Application Chart	01-7	Check Valve Lift	05-9
		Remove Cylinder Head	05-10
		Check Valve Height In Relation to Head Surface	05-13
		Rocker Arm and Shaft Assembly, Disassemble and Inspect	05-13
		Assemble Rocker Arm Shaft Assembly	05-15
Group 02—Fuels, Lubricants, And Coolant			
Diesel Fuel	02-1	Preliminary Cylinder Head and Valve Checks	05-16
Lubricity of Diesel Fuels	02-1	Remove Valve Assembly	05-17
Diesel Engine Oil	02-2	Inspect Valve Springs	05-18
Engine Break-In Oil	02-3	Inspect Spring Caps, Wear Caps, and Valve Rotators	05-18
Oilscan® and Coolscan™	02-3	Clean Valves	05-19
Grease	02-4	Inspect and Measure Valves	05-20
Engine Coolant Requirements	02-5	Grind Valves	05-21
Engine Coolant Recommendations	02-7	Inspect and Clean Cylinder Head	05-22
Engine Coolant Specifications	02-8	Check Cylinder Head Flatness	05-23
Engine Coolant Additives	02-10	Measure Cylinder Head Thickness	05-23
Testing Engine Coolant	02-11	Resurface Cylinder Head	05-24
Disposing of Coolant	02-11	Clean Valve Guides	05-24
		Measure Valve Guides	05-25
		Knurl Valve Guides	05-25
Group 03—Engine Mounting			
Engine Repair Stand	03-1	Replace Valve Guides	05-26
Safety Precautions	03-2	Clean and Inspect Valve Seats	05-26
Install 6619 Engine Adapters on Repair Stand	03-2	Measure Valve Seats	05-27
Engine Lifting Procedure	03-3	Grind Valve Seats	05-28
Clean Engine	03-3	Measure Valve Seat Bores in Cylinder Head	05-30
Mount Engine on Repair Stand	03-4	Install Valve Seat Inserts (Standard or Oversize)	05-31
		Clean and Inspect Cylinder Head Nozzle Bore	05-31
		Clean and Inspect Nozzle Seating Surface	05-32
Group 04—Engine Rebuild Guide			
Disassembly Sequence	04-1		
Sealant Application Guidelines	04-2		
Assembly Sequence	04-4		
Group 05—Cylinder Head And Valves			
Essential Tools	05-1		
Service Equipment and Tools	05-3		
Other Materials	05-3		

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

CTM9-19-25JAN96

COPYRIGHT© 1996
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION® Manual
Previous Editions
Copyright 1987 Deere & Company

Contents

		Page		Page
00	Clean and Inspect Top Deck of Cylinder Block	05-33	Complete Disassembly of Cylinder Block	10-34
01	Clean and Inspect Crankcase Ventilation Assembly	05-33	Inspect and Clean Cylinder Block	10-34
	Inspect and Clean Exhaust Manifold	05-34	Clean Cylinder Liner O-Ring Bores in Block	10-37
	Install Valve Assembly	05-35	Remove and Clean Piston Cooling Orifices	10-37
02	Install Cylinder Head	05-36	Measure Cylinder Block	10-38
	Tighten Cylinder Head Cap Screws	05-38	Recheck Cylinder Liner Standout	10-39
	Torque-Turn Cylinder Head Cap Screws	05-39	Measure Liner Flange Thickness	10-40
	Install Push Rods	05-40	Install Liner Shims	10-40
03	Install Rocker Arm Assembly	05-40	Install Liner O-Rings and Packings	10-41
	Complete Final Assembly on Injection Pump Side	05-41	Cylinder Liner Manufacturing Date Codes	10-42
04	Complete Final Assembly on Exhaust Manifold Side—6619A Engines	05-42	Install Cylinder Liners	10-43
	Complete Final Assembly on Exhaust Manifold Side—6619T Engines	05-44	Install Pistons and Connecting Rods	10-44
05			TORQUE-TURN Connecting Rod Cap Screws	10-47
	Group 10—Cylinder Block, Liners, Pistons and Rods		Check Engine Rotation for Excessive Tightness	10-47
10	Essential tools	10-1	Measure Piston Protusion	10-48
	Service Equipment and Tools	10-3	Complete Final Assembly of Cylinder Block	10-49
	Other Materials	10-4		
	Specifications	10-5	Group 15—Crankshaft Main Bearings and Flywheel	
15	Preliminary Liner, Piston and Rod Checks	10-8	Essential Tools	15-1
	Remove Pistons and Connecting Rods	10-9	Service Equipment and Tools	15-5
	Measure Cylinder Liner Standout (Height)	10-13	Other Materials	15-5
16	Remove Cylinder Liners	10-14	Specifications	15-6
	Remove Piston Rings	10-15	Crankshaft and Bearings Failure Analysis	15-8
	Clean Pistons	10-16	Replace Crankshaft Rear Oil Seal and Sleeve (Seal Housing Installed)	15-9
	Inspect Pistons	10-17	Inspect Vibration Damper	15-11
20	Clean Cylinder Liners	10-17	Remove Vibration Damper and Pulley	15-12
	Inspect Cylinder Liners	10-18	Remove Crankshaft Front Oil Seal (Timing Cover Installed)	15-13
	Piston and Liner Identification Markings	10-19	Remove Front Wear Sleeve (Timing Cover Installed)	15-15
25	Check Piston Ring Groove Wear	10-20	Install Front Wear Sleeve (Timing Cover Installed)	15-16
	Measure Oil Control Ring Groove	10-21	Install Front Oil Seal (Timing Cover Installed)	15-17
	Inspect Piston Pin Bore In Piston	10-21	Check Crankshaft End Play	15-20
	Measure Piston OD	10-22	Remove Front Wear Sleeve (Timing Cover Removed)	15-20
30	Measure Cylinder Liners	10-23	Remove Front Oil Seal (Timing Cover Removed)	15-21
	Determine Piston-to-Liner Clearance	10-24	Service Clutch Shaft Pilot Bushing	15-21
	Deglaze Cylinder Liners	10-25	Check Flywheel Housing Face Runout	15-22
35	Inspect and Measure Connecting Rod Bearings	10-26	Check Flywheel Face Flatness	15-23
	Inspect Connecting Rod and Cap	10-27		
	Inspect Piston Pins and Bushings	10-29		
100	Remove 6° Taper Piston Pin Bushing	10-30		
	Remove 19° Taper Piston Pin Bushing	10-31		
	Clean and Inspect Piston Pin Bushing Bore In Connecting Rod	10-31		
105	Install 6° Taper Piston Pin Bushing	10-32		
	Install 19° Taper Piston Pin bushing	10-33		

Continued on next page

Contents

	Page		Page
Remove Flywheel and Flywheel Housing . . .	15-23	Measure Camshaft Drive	
Inspect and Repair Flywheel	15-24	Gear-to-Crankshaft Gear Backlash	16-13
Replace Flywheel Ring Gear	15-24	Remove Tachometer Drive Assembly	16-14
Remove Rear Oil Seal Housing	15-25	Remove Camshaft	16-14
Remove Crankshaft Rear Seal and Sleeve (Seal Housing Removed)	15-25	Remove Camshaft Gear	16-16
Remove Main Bearings	15-26	Measure Thrust Plate and Spacer	16-16
Check Main Bearing Clearance	15-27	Inspect and Measure Camshaft	16-17
Remove Crankshaft	15-28	Inspect Camshaft Followers	16-19
Inspect Crankshaft	15-29	Replace Camshaft Bushings	16-21
Measure Assembled ID of Bearings and OD of Crankshaft Journals	15-31	Install Timing Gear Cover	16-24
Measure Assembled ID of Main Bearing Caps (Without Bearings)	15-33	Install Crankshaft Front Wear Sleeve	16-25
Crankshaft Grinding Guidelines	15-34	Install Crankshaft Front Oil Seal	16-26
Crankshaft Grinding Specifications	15-36	Service and Inspect Tachometer Drive Assy—Camshaft Driven Oil Pump	16-27
Thrust Bearing New Part Specifications	15-36	Service and Inspect Tachometer Drive Assy—Crankshaft Driven Oil Pump	16-28
Replace Crankshaft Drive Gear	15-37	Install Tachometer Drive Assembly	16-29
Replace Crankshaft Oil Pump Drive Gear	15-38	Complete Final Assembly	16-29
Inspect Thrust Bearings	15-39		
Remove and Clean Piston Cooling Orifices	15-39	Group 20—Lubrication System	
Install Main Bearing Inserts in Block	15-40	Essential Tools	20-1
Install Crankshaft	15-41	Other Materials	20-1
Install Oil Pump and Check Drive Gear-to-Crankshaft Clearance	15-42	Specifications	20-2
Install Rear Oil Seal Housing	15-43	Diagnosing Malfunctions	20-4
Check Oil Seal Housing Runout	15-44	Remove Oil Pan	20-5
Crankshaft Rear Oil Seal and Wear Sleeve Handling Precautions	15-45	Remove Oil Pressure Regulating Housing and Oil Cooler Assembly	20-5
Install Crankshaft Rear Oil Seal and Wear Sleeve Assembly	15-45	Oil Pressure Regulating Valve Housing and Oil Cooler Assembly	20-6
Install Crankshaft Front Wear Sleeve	15-47	Remove Cooler Bypass, Filter Bypass and Pressure Regulating Valves	20-7
Install Timing Gear Cover	15-47	Install Cooler Bypass, Filter Bypass and Pressure Regulating Valves	20-8
Install Crankshaft Front Oil Seal (Cover On)	15-48	Install Oil Pressure Regulating and Oil Cooler Housing Assembly	20-9
Install Vibration Damper and Pulley	15-49	Crankshaft Driven Oil Pump	20-10
Install Flywheel Housing and Flywheel	15-52	Check Crankshaft Gear-to-Oil Pump Drive Gear Backlash	20-11
Complete Final Assembly	15-52	Remove Crankshaft Driven Oil Pump	20-11
		Inspect and Clean Crankshaft Driven Oil Pump	20-12
Group 16—Camshaft and Timing Gear Train		Check Drive Shaft End Play—Crankshaft Driven Oil Pump	20-12
Essential Tools	16-1	Check Drive Shaft Side Movement—Crankshaft Driven Oil Pump	20-13
Other Materials	16-4	Check Pumping Gear Backlash—Crankshaft Driven Oil Pump	20-13
Specifications	16-5	Inspect Oil Pump Drive Gear—Crankshaft Driven Oil Pump	20-14
Check Valve Lift	16-7		
Check Backlash, Oil Pump Drive Gear	16-8		
Check Backlash, Oil Pump Driven Gear	16-9		
Remove Vibration Damper and Pulley	16-10		
Remove Front Wear Sleeve (Timing Gear Cover Removed)	16-12		
Check Camshaft End Play	16-13		

Continued on next page

110

115

199

INDX

Contents

	Page		Page
Adjust Oil Pump Set Screw—Crankshaft Driven Oil Pumkp	20-14	Install Coolant Filter Conditioner—Water Manifold Mounted	25-28
Install Crankshaft Driven Oil Pump (Agricultural and OEM Applications)	20-14	Install Coolant Filter Conditioner—Intake Manifold Mounted	25-29
Install Crankshaft Driven Oil Pump (Industrial Applications)	20-15	Complete Final Assembly	25-29
Check Camshaft Gear-to-Oil Pump Drive Gear Backlash	20-18	Check and Adjust V-Belt Tension	25-30
Check Camshaft Gear-to-Oil Pump Driven Gear Backlash	20-19	Group 30—Air Intake and Exhaust System	
Remove and Inspect Camshaft Driven Oil Pump	20-20	Other Material	30-1
Remove Camshaft Driven Oil Pump Gears	20-21	Specifications	30-1
Install Camshaft Driven Oil Pump Gears	20-22	Extending Turbocharger Life	30-2
Install Camshaft Driven Oil Pump	20-23	Remove Turbocharger	30-4
Install Oil Pan	20-23	Diagnosing Turbocharger Malfunctions	30-6
Remove Bypass Oil Filter Assembly	20-25	Turbocharger Seven-Step Inspection	30-9
Inspect and Clean Bypass Oil Filter Assembly	20-25	Radial Bearing Clearance Test	30-14
Install Bypass Oil Filter Assembly	20-26	Axial End Play Bearing Test	30-15
Group 25—Cooling System		Repair Turbocharger	30-15
Essential Tools	25-1	Disassemble and Inspect Turbocharger	30-16
Service Equipment and Tools	25-2	Replace Turbocharger Center Housing	30-18
Other Material	25-2	Prelube Turbocharger	30-19
Specifications	25-3	Install Turbocharger	30-19
Diagnosing Malfunctions	25-4	Remove Aftercooler and Intake Manifold (6619A Engines)	30-22
General Information	25-5	Inspect and Repair Aftercooler (6619A Engines)	30-23
Remove Water Pump	25-5	Inspect and Repair Intake Manifold (6619A Engines)	30-24
Disassemble Standard-Duty Water Pump	25-6	Install Intake Manifold and Aftercooler (6619A Engines)	30-25
Inspect Standard-Duty Water Pump Parts	25-9	Remove, Inspect, Install Intake Manifold (6619T Engines)	30-27
Assemble Standard-Duty Water Pump	25-10	Remove, Inspect, Install Exhaust Manifold Assembly	30-28
Disassemble Heavy-Duty Water Pump	25-12	Group 35—Fuel System	
Inspect Heavy-Duty Water Pump Parts	25-16	Essential Tools	35-1
Assemble Heavy-Duty Water Pump	25-17	Other Material	35-3
Install Water Pump	25-21	Specifications	35-4
Remove Water Manifold	25-22	Relieve System Pressure	35-5
Inspect and Clean Water Manifold	25-23	Remove Fuel Filters	35-6
Install Water Manifold	25-24	Remove Fuel Check Valve Assembly	35-6
Remove Thermostats	25-24	Inspect Check Valve	35-7
Install Thermostats	25-25	Remove Inspect and Clean Fuel Filter Body	35-8
Coolant Filter Conditioner General Information	25-25	Install Fuel Check Valve Assembly	35-9
Remove Coolant Filter Conditioner—Water Manifold Mounted	25-26	Install New Fuel Filters	35-9
Remove Coolant Filter Conditioner—Intake Manifold Mounted	25-27	Service Fuel Inlet Final Filter	35-10
Inspect Coolant Filter Conditioner Components	25-27	Remove Fuel Supply Pump	35-11
		Test Fuel Supply Pump For Leaks	35-12
		Disassemble Fuel Supply Pump	35-13
		Inspect and Repair Fuel Supply Pump	35-16

Continued on next page

Contents

	Page		Page
Assemble Fuel Supply Pump	35-17	Engine General Description	105-5
Install Fuel Supply Pump	35-19	How the Lubrication System Works	105-6
General Information for Aneroid	35-19	How the Cooling System Works	105-8
Repair Aneroid	35-20	Head Gasket Joint Construction and Operation	105-10
Remove Hydraulic Aneroid Activator	35-20	Diagnosing Head Gasket Joint Failures	105-12
Disassemble and Clean Hydraulic Aneroid Activator	35-21	Head Gasket Inspection and Repair	105-15
Assemble and Install Hydraulic Aneroid Activator	35-21	Diagnosing Engine Malfunctions	105-17
Service Overflow Valve	35-22	Test Engine Compression Pressure	105-19
Remove Fuel Injection Pump	35-23	Check Engine Oil Pressure	105-20
Install Fuel Injection Pump	35-27	Check Crankshaft End Play (Damper Installed)	105-21
Remove Fuel Injection Nozzles	35-30	Measure Crankcase Pressure (Blow-By)	105-22
Test Fuel Injection Nozzles	35-33	Pressure Test Cooling System and Radiator Cap	105-23
Nozzle Opening Pressure Test	35-34	Inspect Thermostat and Test Opening Temperature	105-24
Test Nozzle Leakage	35-36		
Test Nozzle Chatter and Spray Pattern	35-37		
Disassemble Fuel Injection Nozzle	35-38		
Clean and Inspect Fuel Injection Nozzle Assembly	35-40	Group 110—Air Intake System Operation and Tests	
Perform Nozzle Slide Test	35-41	Special or Essential Tools	110-1
Clean Nozzle Spray Orifices	35-41	Specifications	110-1
Inspect Nozzle Holder	35-42	Diagnosing Malfunctions	110-2
Inspect Nozzle Gland Nut	35-43	How the Air Intake and Exhaust System Work	110-3
Assemble Fuel Injection Nozzle	35-44	Air Cleaner Operation	110-4
Inspect and Clean Cylinder Head Nozzle Bore	35-47	Diagnosing Turbocharger Malfunctions	110-5
Inspect and Clean Nozzle Seating Surface	35-48	How the Turbocharger Works	110-6
Install Fuel Injection Nozzle	35-48	How the Turbocharger is Lubricated	110-6
Install Fuel Lines (Engine Serial No. —050290)	35-51	How the Aftercooler Works—6619A Engines	110-7
Install Fuel Lines (Engine Serial No. 050291—)	35-52	Check Intake Manifold Pressure—6619AF Engines	110-8
Complete Final Assembly	35-53		
Group 100—Tune-Up		Group 115—Fuel System Operation and Tests	
Altitude Compensation Guideline	100-1	Essential Tools	115-1
Preliminary Engine Testing	100-2	Fuel System Test Specifications	115-2
General Tune-Up Recommendations	100-3	Fuel System Operation	115-3
Dynamometer Test	100-4	Diagnose Fuel System Malfunctions	115-4
Check Crankcase Ventilation System	100-7	Supply Pump Operation	115-8
Check Air Intake System	100-7	Diagnose Fuel Supply Pump Malfunctions	115-10
Check Exhaust System	100-7	Check Supply Pump Operation	115-11
Check and Service Cooling System	100-8	Service Supply Pump	115-14
		Fuel Filter Operation	115-14
		Bleed Fuel System	115-15
		Diagnose Fuel Injection Pump Malfunctions	115-17
		How the Fuel Injection Pump Works	115-18
Group 105—Engine System Operation and Tests			
Special or Essential Tools	105-1		
Engine Test Specifications	105-2		
Engine Sectional View	105-4		

Continued on next page

Contents

	Page
Check and Adjust Injection Pump Timing . . .	115-18
Check Fast Idle Speed	115-21
Check and Adjust Slow Idle Speed	115-22
How the Aneroid Works	115-24
Diagnose Aneroid Malfunctions	115-25
How the Hydraulic Aneroid Activator Works	115-26
Diagnose Malfunctions—Hydraulic Aneroid Activator	115-27
Fuel Injection Nozzles General Information	115-27
Fuel Injection Nozzle Operation	115-29
Diagnose Malfunctions—Fuel Injection Nozzle	115-30
Test Fuel Injection Nozzle (Engine Running)	115-31
Fuel Drain Back Test Procedure	115-31
 Group 199—Fabricated Tools	
Fabricated Tools	199-1
Cylinder Liner Holding Fixture	199-1

Index

HANDLE FLUIDS SAFELY—AVOID FIRES

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.



DX,FLAME -19-04JUN90

00
-UN-23AUG88
TS227

PREVENT BATTERY EXPLOSIONS

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



DX,SPARKS -19-03MAR93


-UN-23AUG88
TS204

PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



DX,FIRE2 -19-03MAR93

-UN-23AUG88
TS291

PREVENT ACID BURNS

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 15—30 minutes. Get medical attention immediately.

If acid is swallowed:

1. Do not induce vomiting.
2. Drink large amounts of water or milk, but do not exceed 2 L (2 quarts).
3. Get medical attention immediately.



TS203 -UN-23AUG88

DX,POISON -19-21APR93


AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



DX,FLUID -19-03MAR93

-JUN-23AUG88

X9811

00
3


WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



DX,WEAR -19-10SEP90


-JUN-23AUG88

TS206

WORK IN CLEAN AREA

Before starting a job:

- Clean work area and machine.
- Make sure you have all necessary tools to do your job.
- Have the right parts on hand.
- Read all instructions thoroughly; do not attempt shortcuts.




DX,CLEAN -19-04JUN90

T6642EJ -UN-18OCT88

SERVICE MACHINES SAFELY

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.




DX,LOOSE -19-04JUN90

TS228 -UN-23AUG88

WORK IN VENTILATED AREA

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.



DX,AIR -19-04JUN90

TS220 -UN-23AUG88

ILLUMINATE WORK AREA SAFELY

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.




DX,LIGHT -19-04JUN90

TS223 -UN-23AUG88

USE PROPER LIFTING EQUIPMENT

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components in the manual.



DX,LIFT -19-04JUN90

TS226 -UN-23AUG88

AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.



DX,TORCH -19-03MAR93

TS953 -UN-15MAY90

REMOVE PAINT BEFORE WELDING OR HEATING

Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Do all work outside or in a well ventilated area. Dispose of paint and solvent properly.

Remove paint before welding or heating:

- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.



DX,PAINT -19-03MAR93

TS220 -UN-23AUG88

USE PROPER TOOLS

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards.

Use power tools only to loosen threaded parts and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only service parts meeting John Deere specifications.



TS779 -UN-08NOV89

DX,REPAIR -19-04JUN90

DISPOSE OF WASTE PROPERLY


Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.



TS1133 -UN-26NOV90

DX,DRAIN -19-03MAR93

LIVE WITH SAFETY

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.











DX,LIVE

-19-25SEP92

TS231 -19-07OCT88

00
7

UNIFIED INCH BOLT AND CAP SCREW TORQUE VALUES

SAE Grade and Head Markings	NO MARK	1 or 2 ^b 	5 5.1 5.2 	8 8.2 
SAE Grade and Nut Markings	NO MARK	2 	5  	8  

01
-19-04MARG1
TS1162

Size	Grade 1				Grade 2 ^b				Grade 5, 5.1, or 5.2				Grade 8 or 8.2			
	Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a	
	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft
1/4	3.7	2.8	4.7	3.5	6	4.5	7.5	5.5	9.5	7	12	9	13.5	10	17	12.5
5/16	7.7	5.5	10	7	12	9	15	11	20	15	25	18	28	21	35	26
3/8	14	10	17	13	22	16	27	20	35	26	44	33	50	36	63	46
7/16	22	16	28	20	35	26	44	32	55	41	70	52	80	58	100	75
1/2	33	25	42	31	53	39	67	50	85	63	110	80	120	90	150	115
9/16	48	36	60	45	75	56	95	70	125	90	155	115	175	130	225	160
5/8	67	50	85	62	105	78	135	100	170	125	215	160	240	175	300	225
3/4	120	87	150	110	190	140	240	175	300	225	375	280	425	310	550	400
7/8	190	140	240	175	190	140	240	175	490	360	625	450	700	500	875	650
1	290	210	360	270	290	210	360	270	725	540	925	675	1050	750	1300	975
1-1/8	400	300	510	375	400	300	510	375	900	675	1150	850	1450	1075	1850	1350
1-1/4	570	425	725	530	570	425	725	530	1300	950	1650	1200	2050	1500	2600	1950
1-3/8	750	550	950	700	750	550	950	700	1700	1250	2150	1550	2700	2000	3400	2550
1-1/2	1000	725	1250	925	990	725	1250	930	2250	1650	2850	2100	3600	2650	4550	3350

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.


Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication.

^b Grade 2 applies for hex cap screws (not hex bolts) up to 152 mm (6-in.) long. Grade 1 applies for hex cap screws over 152 mm (6-in.) long, and for all other types of bolts and screws of any length.

METRIC BOLT AND CAP SCREW TORQUE VALUES



Size	Class 4.8				Class 8.8 or 9.8				Class 10.9				Class 12.9			
	Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a	
	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft
M6	4.8	3.5	6	4.5	9	6.5	11	8.5	13	9.5	17	12	15	11.5	19	14.5
M8	12	8.5	15	11	22	16	28	20	32	24	40	30	37	28	47	35
M10	23	17	29	21	43	32	55	40	63	47	80	60	75	55	95	70
M12	40	29	50	37	75	55	95	70	110	80	140	105	130	95	165	120
M14	63	47	80	60	120	88	150	110	175	130	225	165	205	150	260	190
M16	100	73	125	92	190	140	240	175	275	200	350	255	320	240	400	300
M18	135	100	175	125	260	195	330	250	375	275	475	350	440	325	560	410
M20	190	140	240	180	375	275	475	350	530	400	675	500	625	460	800	580
M22	260	190	330	250	510	375	650	475	725	540	925	675	850	625	1075	800
M24	330	250	425	310	650	475	825	600	925	675	1150	850	1075	800	1350	1000
M27	490	360	625	450	950	700	1200	875	1350	1000	1700	1250	1600	1150	2000	1500
M30	675	490	850	625	1300	950	1650	1200	1850	1350	2300	1700	2150	1600	2700	2000
M33	900	675	1150	850	1750	1300	2200	1650	2500	1850	3150	2350	2900	2150	3700	2750
M36	1150	850	1450	1075	2250	1650	2850	2100	3200	2350	4050	3000	3750	2750	4750	3500

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class.

Fasteners should be replaced with the same or higher property class. If higher property class fasteners are used, these should only be tightened to the strength of the original.

^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication.

Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

ENGINE MODEL DESIGNATION

1. JOHN DEERE ENGINE MODEL - 6619 ENGINE

Engine model designation includes number of cylinders, displacement in cubic inches, aspiration, and application code. For example:

6619AF-00 ENGINE

6 Number of cylinders
619 Cu. in. displacement
A Aspiration code
F User factory code
-00 Application

ASPIRATION CODE

T Turbocharged
A Turbocharged and aftercooled

JD FACTORY/OEM USER FACTORY CODE

T Dubuque
E Ottumwa
R Tractor
F OEM

APPLICATION CODE

-00, -01 Code for specific application

S11,0000,AF -19-25JAN96

01
3

2. DETROIT DIESEL ALLISON (DDA) ENGINE MODEL

DDA engine model designation cross-reference with the John Deere engine model. It includes the series, number of cylinders, application type, direction of rotation, aspiration, and application code. For example, the model 6619AF001 engine just previously discussed, becomes DDA model H0639600:

H0639600 Model Designation

H Engine series
 06 Number of cylinders
 3 Application type
 9 Direction of rotation
 6 Aspiration
 00 Application code

Application Type

2 Marine
 3 Industrial
 4 Power Base
 5 Generator Set
 7 Automotive
 8 Special

Direction of Rotation

9 Right-Hand or clockwise (as viewed from FRONT of engine)
 0 Left-Hand or counterclockwise rotation

Aspiration

3 Turbocharged
 6 Turbocharged and aftercooled

Application Code

00, 01, etc. Code for each specific application

S11,0000,AG -19-27MAY87

01
4

ENGINE SERIAL NUMBER PLATE INFORMATION

IMPORTANT: The engine serial number plate can be easily destroyed. Remove the plate, or record the information elsewhere, before “hot tank” cleaning the block.

1. ENGINE SERIAL NUMBER

Each engine has a 13-digit John Deere serial number (A) identifying the producing factory, engine model designation, and a 6-digit sequential number. The following is an example:

RG6619A000000

RG Factory code producing engine
 6619A Engine model designation
 000000 Sequential number

Factory Code Producing Engine

RG Waterloo

Engine Model Designation

6619A Definition explained previously
 (See Engine Model Designation)

Sequential Number

000000 6-digit sequential number


2. ENGINE APPLICATION DATA

The second line of information on the nameplate (B) identifies the engine/machine or OEM relationship (See ENGINE APPLICATION CHART in this group).

NOTE: Current (later) engines will have a bar coded serial number plate (A, lower illustration) with the same information as detailed above.



John Deere Embossed Nameplate



John Deere Bar Coded Nameplate

-UN-19JAN90
5101
RG4934

-UN-25OCT91
RG5978

RG,0000,AH -19-25JAN96

3. Unit Number

Engines marketed by Detroit Diesel Allison (DDA) have a third line of information on the nameplate. The unit number (A) is the DDA applied serial number and must be utilized for DDA service and customer reference purposes.


A typical unit number converts the 13-digit engine serial number into one that is 10-digits. It includes the number of cylinders, manufacturing factory location, and DDA model designation.

Example:


JD Engine Serial No.	DDA Unit No.
RG6619A000000	06HE000000
6	06
RG	H
RG6619A	**E
000000	000000

JD/DDA	Model Codes	
	Deere Engine Model	DDA Model Code ** (4th position of Unit No.)
RG/H	6619T	D
RG/H	6619A	E

NOTE: Some nameplates (B) are used which do not have the John Deere name printed.




DDA Unit Number Plate



Generic Engine Nameplate

RG.0000,AJ -19-19MAY95

NOTE: Prior to Engine Serial No. (-047325), a one line engine name plate was used on production engines.



S11,0000,AT -19-27MAY87

01
6

-UN-19JAN90

RG4935


-UN-19JAN90

RG4936

-UN-06APR89

RG5059

OPTION CODE LABEL



An option code label is affixed to the rocker arm cover on all OEM engines. (Label is not installed on engines for John Deere machines.)

The label identifies only the factory-installed options on each engine. Distributor/Dealer installed kits would not be shown.

A four-digit number is used to identify a particular option. For example, Code 1403 indicates that the engine is equipped with an SAE No. 3 flywheel housing.

Always provide option code information when ordering repair parts. A listing of option codes is given in the Operator's Manual.

S11,000,AK1 -19-26MAR87

ENGINE APPLICATION CHART

John Deere Agricultural Equipment Applications

Machine Model No.	Engine Model
Forage Harvesters	
5460	6619AE-01
5720	6619AE-02
5820	6619AE-02, 03
5830	6619AE-03
Tractors	
8630	6619AR-01, 10
8630 Export	6619AR-06, 13
8640	6619AR-08
8640 Export	6619AR-09
8650	6619AR-11, 14
8650 Export	6619AR-12

S11,000,AL -19-27MAY87

General Information/Engine Application Chart

John Deere Industrial Equipment Applications

Machine Model No.	Engine Model
Crawlers	
JD850, 850	6619TT-02
JD855, 855	6619AT-02
Excavator	
JD890,890	6619AT-03
890A	6619AT-05
992D	6619AT-07
Scraper	
JD762, 762	6619TT-01
JD860B	6619AT-01
JD862, 862	6619AT-04
862B	6619AT-04

RG,0000,AM -19-31JAN96

OEM Applications

Machine Model No.	Engine Model
OEM	6619AF-00
Repower	6619TF-01
Stationary Engines	6619AR-04

S11,0000,AN -19-27MAY87

01
8

DIESEL FUEL

Consult your local fuel distributor for properties of the diesel fuel available in your area.

In general, diesel fuels are blended to satisfy the low temperature requirements of the geographical area in which they are marketed.

Diesel fuels specified to EN 590 or ASTM D975 are recommended.

In all cases, the fuel must meet the following properties:

- **Cetane Number 40 minimum.** Cetane number greater than 50 is preferred, especially for temperatures below -20° C (-4° F) or elevations above 1500 m (5000 ft).
- **Cold Filter Plugging Point (CFPP)** below the expected low temperature OR **Cloud Point** at least 5° C (9° F) below the expected low temperature.

- **Sulfur Content**

- Sulfur content should not exceed 0.5%. Sulfur content less than 0.05% is preferred.
- If diesel fuel with sulfur content greater than 0.5% is used, reduce the service interval for engine oil and filter changes by 50%.
- DO NOT use diesel fuel with sulfur content greater than 1.0%.

Bio-diesel fuels meeting DIN 51606 or equivalent specification may be used.

RG,FUEL1 -19-25JAN96

LUBRICITY OF DIESEL FUELS

Diesel fuel must have adequate lubricity to ensure proper operation and durability of fuel injection system components.

Diesel fuels for highway use in the United States now require sulfur content less than 0.05%. Diesel fuel in the European Union will require sulfur content less than 0.05% by 1 October 1996.

Experience shows that some low sulfur diesel fuels may have inadequate lubricity and their use may reduce performance in fuel injection systems due to inadequate lubrication of injector components. The lower concentration of aromatic compounds in these fuels also adversely affects injection pump seals and may result in leaks.

Use of low lubricity diesel fuels may also cause accelerated wear, injection nozzle erosion or corrosion, engine speed instability, hard starting, low power, and engine smoke.

Fuel lubricity should pass a minimum of 3300 gram load level as measured by the BOCLE scuffing test.

ASTM D975 and EN 590 specifications do not require fuels to pass a fuel lubricity test. Diesel fuels meeting U.S. Military Specification VV—F—800E pass a fuel lubricity test.

If fuel of low or unknown lubricity is used, add John Deere PREMIUM DIESEL FUEL CONDITIONER or equivalent at the specified concentration. John Deere Premium Diesel Fuel Conditioner is available in winter and summer formulas. Consult your John Deere engine distributor or servicing dealer for more information.

RG,FUEL5 -19-25JAN96

DIESEL ENGINE OIL

Use oil viscosity based on the expected air temperature range during the period between oil changes.

The following oil is preferred.

- **John Deere PLUS-50®**

If John Deere PLUS-50 engine oil and a John Deere oil filter are used, the service interval for oil and filter changes may be extended by 50 hours.

The following oil is also recommended:


- **John Deere TORQ-GARD SUPREME®**

Other oils may be used if they meet one or more of the following:

- John Deere UNI-GARD™
- API Service Classification CG-4
- API Service Classification CF-4
- API Service Classification CE
- CCMC Specification D5 and Mercedes Benz MB228.3
- CCMC Specification D4 and Mercedes Benz MB228.1

Viscosity grade SAE 15W-40 is preferred.

If diesel fuel with sulfur content greater than 0.5% is used, reduce the service interval by 50%.



-UN-12SEP94

TS1619

DX,ENOIL -19-16SEP94

ENGINE BREAK-IN OIL

New engines are filled at the factory with John Deere ENGINE BREAK-IN OIL. During the break-in period, add John Deere ENGINE BREAK-IN OIL as needed to maintain the specified oil level.

Change the oil and filter after the first 100 hours of operation of a new or rebuilt engine.

After engine overhaul, fill the engine with John Deere ENGINE BREAK-IN OIL.

If John Deere ENGINE BREAK-IN OIL is not available, use a diesel engine oil meeting one of the following during the first 100 hours of operation:

- API Service Classification CE
- CCMC Specification D4

After the break-in period, use John Deere PLUS-50® or other diesel engine oil as recommended in this manual.

IMPORTANT: Do not use John Deere PLUS-50 oil or engine oils meeting API CG4, API CF4, or CCMC D5 performance levels during the first 100 hours of operation of a new or rebuilt engine. These oils will not allow the engine to break-in properly.



DX,ENOIL4 -19-17OCT94

OILSCAN® AND COOLSCAN™

OILSCAN and COOLSCAN are John Deere sampling programs to help you monitor machine performance and identify potential problems before they cause serious damage.

Oil and coolant samples should be taken from each system prior to its recommended change interval.

Check with your John Deere dealer for the availability of OILSCAN and COOLSCAN kits.



DX,OILSCAN -19-16APR92

02
3
-UN-15JUN89

T6828AB

-UN-18OCT88

T6829AB

GREASE

Use grease based on the expected air temperature range during the service interval.


The following greases are preferred:

- John Deere MOLY HIGH TEMPERATURE EP GREASE
- John Deere HIGH TEMPERATURE EP GREASE
- John Deere GREASE-GARD™

Other greases may be used if they meet one of the following:

- SAE Multipurpose EP Grease with a maximum of 5% molybdenum disulfide
- SAE Multipurpose EP Grease

Greases meeting Military Specification MIL-G-10924F may be used as arctic grease.



02
4

DX,GREA1

-19-02NOV94

TS1622 -UN-02NOV94