

Product: John Deere Horicon Hydraulic Attachments Service Repair Technical Manual

Full Download: <https://www.arepairmanual.com/downloads/john-deere-horicon-hydraulic-attachments-service-repair-technical-manual/>

# **Horicon Hydraulic Attachments:**

**7, 8, 8A, 10, &10A Backhoes**

**40, 44, 51, 52, 60, 67, 70, & 70A Loaders**

**365, 375, 380, 380A, & 390 Front Blades**

**30-Inch Hydraulic Tiller**

**Hydraulic Dump MCS**

# **TECHNICAL MANUAL**

**John Deere  
Lawn & Grounds Care Division**

**TM1593 (May 95)  
Replaces TM1429**

Sample of manual. Download All 73 pages at:

<https://www.arepairmanual.com/downloads/john-deere-horicon-hydraulic-attachments-service-repair-technical-manual/>

Litho in U.S.A

**Product: John Deere Horicon Hydraulic Attachments Service Repair Technical Manual**

**Full Download: <https://www.arepairmanual.com/downloads/john-deere-horicon-hydraulic-attachments-service-repair-technical-manual/>**

This technical manual is written for an experienced technician and contains sections that are specifically for this product. It is a part of a total product support program.

The manual is organized so that all the information on a particular system is kept together. The order of grouping is as follows:

- Table of Contents
- Specifications
- Component Location
- System Schematic
- Theory of Operation
- Troubleshooting Chart
- Diagnostics
- Tests & Adjustments
- Repair

*Note: Depending on the particular section or system being covered, not all of the above groups may be used.*

Each section will be identified with a symbol rather than a number. The groups and pages within a section will be consecutively numbered.

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.


We appreciate your input on this manual. To help, there are postage paid post cards included at the back. If you find any errors or want to comment on the layout of the manual please fill out one of the cards and mail it back to us.

COPYRIGHT<sup>©</sup> 1995  
JOHN DEERE LAWN AND  
GROUNDS CARE DIVISION  
Horicon, Wisconsin  
All rights reserved

Sample of manual. Download All 73 pages at:

<https://www.arepairmanual.com/downloads/john-deere-horicon-hydraulic-attachments-service-repair-technical-manual/>

**Safety****Specifications and Information****Backhoes****Loaders****Tillers****Blades****Hydraulic Dump****Miscellaneous**

**RECOGNIZE SAFETY INFORMATION**

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe servicing practices.

**Understand Signal Words**

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.


**REPLACE SAFETY SIGNS**

TS201

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.

**HANDLE FLUIDS SAFELY-AVOID FIRES****Be Prepared For Emergencies**

TS227



TS291

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.


Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.

## USE CARE AROUND HIGH-PRESSURE FLUID LINES

### Avoid High-pressure Fluids



Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid injury from escaping fluid under pressure by stopping the engine and relieving pressure in the system before disconnecting or connecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.

### Avoid Heating Near Pressurized Fluid Lines



TS953

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.

## USE SAFE SERVICE PROCEDURES



### Wear Protective Clothing



Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing. Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



TS228

### Service Machines Safely

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.


Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.

### Use Proper Tools

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards. Use power tools only to loosen threaded parts and fasteners. For loosening and tightening hardware, use the correct size tools. **DO NOT** use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches. Use only service parts meeting John Deere specifications.



## Park Machine Safely




TS230

### Before working on the machine:

1. Lower all equipment to the ground.
2. Stop the engine and remove the key.
3. Disconnect the battery ground strap.
4. Hang a "DO NOT OPERATE" tag in operator station.

## Support Machine Properly And Use Proper Lifting Equipment



TS229

If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.

Lifting heavy components incorrectly can cause severe injury or machine damage. Follow recommended procedure for removal and installation of components in the manual.

## Work In Clean Area

### Before starting a job:

1. Clean work area and machine.
2. Make sure you have all necessary tools to do your job.
3. Have the right parts on hand.
4. Read all instructions thoroughly; do not attempt shortcuts.


## Using High Pressure Washers

Directing pressurized water at electronic/electrical components or connectors, bearings, hydraulic seals, fuel injection pumps or other sensitive parts and components may cause product malfunctions. Reduce pressure and spray at a 45 to 90 degree angle.

## Illuminate Work Area Safely

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.

## Work In Ventilated Area




Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.

## Remove Paint Before Welding Or Heating


Avoid potentially toxic fumes and dust. Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch. Do all work outside or in a well ventilated area. Dispose of paint and solvent properly. Remove paint before welding or heating: If you sand or grind paint, avoid breathing the dust. Wear an approved respirator. If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

## AVOID INJURY FROM ROTATING BLADES, AUGERS AND PTO SHAFTS



Keep hands and feet away while machine is running. Shut off power to service, lubricate or remove mower blades, augers or PTO shafts.

## HANDLE CHEMICAL PRODUCTS SAFELY



Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques. Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

## Dispose of Waste Properly



Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries. Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them. Do not pour waste onto the ground, down a drain, or into any water source. Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.

## LIVE WITH SAFETY




Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.



# CONTENTS

Page



## SPECIFICATIONS AND INFORMATION

<b>7, 8, 8A, 10, &amp; 10A BACKHOES.....</b>	<b>3</b>
HYDRAULIC SYSTEM REQUIREMENTS AND SPECIFICATIONS.....	3
BACKHOE HYDRAULIC SPECIFICATIONS.....	3
INTERNAL VALVE LEAKAGE.....	4
LIFT CYLINDER DROP RATE.....	4
STABILIZER CYLINDER DROP RATE.....	4
STABILIZER CYLINDER RETRACT RATE.....	4
7 BACKHOE FUNCTION TIMES.....	5
8 AND 8A BACKHOE FUNCTION TIMES—TRACTORS.....	5
8 AND 8A BACKHOE FUNCTION TIMES—SKID-STEER LOADERS.....	6
10 AND 10A BACKHOE FUNCTION TIMES.....	6
<b>LOADERS.....</b>	<b>7</b>
CAPACITY—44 Loader, 316, 318, 330, 420 and 430 Tractor .....	7
CAPACITY—40 Loader, 415, 425, 445 and 455 Tractor	
(Two-Wheel Steer) .....	7
CAPACITY—60 Loader, 650, and 655 Tractor.....	7
CAPACITY—60 Loader, 670 Tractor .....	7
CAPACITY—70, Loader, 750 Tractor.....	7
CAPACITY—70, 70A Loader, 755, 770 and 855 Tractor .....	7
CAPACITY—70A Loader, 955 Tractor .....	7
DIMENSIONS—40 Loader, 415, 425, 445, 455	
(Two-Wheel Steer) .....	8
DIMENSIONS—44 LOADER.....	9
DIMENSIONS—60, 70, 70A .....	10
CYCLE TIMES.....	11
BUCKET STRUCK CAPACITY .....	11
INTERNAL VALVE LEAKAGE .....	11
LIFT CYLINDER DROP RATE .....	11
BUCKET CYLINDER DROP RATE .....	11
<b>FITTINGS .....</b>	<b>12</b>
SERVICE RECOMMENDATIONS FOR O-RING BOSS FITTINGS .....	12
SERVICE RECOMMENDATIONS FOR FLAT FACE O-RING SEAL FITTINGS .....	13
FLAT FACE O-RING SEAL FITTING TORQUE.....	13
<b>UNIFIED INCH TORQUE VALUES.....</b>	<b>14</b>
<b>METRIC TORQUE VALUES .....</b>	<b>15</b>
<b>LUBRICANTS .....</b>	<b>16</b>
GREASE .....	16
ANTI-CHATTER TRANSMISSION/HYDRAULIC OIL .....	16
ALTERNATIVE LUBRICANTS .....	16
LUBRICANT STORAGE .....	16



**Page**

## 7, 8, 8A, 10, & 10A BACKHOES

### HYDRAULIC SYSTEM REQUIREMENTS AND SPECIFICATIONS



#### Hydraulic Pump Flow Rates

650 .....	18.2 L/min, (4.8 gpm), 2600 RPM—Eng.
650 w/Power Steering .....	14.6 L/min (3.7 gpm), 2600 RPM—Eng.
750 .....	21.6 L/min (5.7 gpm), 2400 RPM—Eng.
750 w/Power Steering .....	17.4 L/min (4.6 gpm), 2400 RPM—Eng.
755 .....	15.4 L/min (3.9 gpm), 3200 RPM—Eng.
850 (9 cc) .....	23.5 L/min (6.2 gpm), 2600 RPM—Eng.
850 (9 cc) w/Power Steering .....	16.7 L/min (4.4 gpm), 2600 RPM—Eng.
850 (11 cc) .....	28.8 L/min (4.4 gpm), 2600 RPM—Eng.
850 (11 cc) w/Power Steering .....	22 L/min (5.8 gpm), 2600 RPM—Eng.
855 .....	15.4 L/min (3.9 gpm), 3200 RPM—Eng.
950, 1050 (9 cc) w/Power Steering .....	14.8 L/min (3.9 gpm), 2400 RPM—Eng.
950, 1050 (11 cc) .....	26.5 L/min (7.0 gpm), 2400 RPM—Eng.
950, 1050 (11 cc) w/Power Steering .....	19.7 L/min (5.2 gpm), 2400 RPM—Eng.
5200, 5300, 5400 .....	43.2 L/min (11.4 gpm), 2500 RPM—Eng.
570 Skid-Steer Loader .....	27.2 L/min (7.2 gpm), 2500 RPM—Eng.
575 Skid-Steer Loader .....	30.3 L/min (8.0 gpm), 2800 RPM—Eng.
675 Skid-Steer Loader .....	53.0 L/min (14.0 gpm), 2800 RPM—Eng.

### BACKHOE HYDRAULIC SPECIFICATIONS

#### Main System Relief Valve

Test Engine Speed .....	1500 RPM
Pressure	
7 Backhoe .....	11713 (10680 min.) kPa (117.3 [106.9 min.] bar) (1700 [1550 min.] psi)
8 & 8A Backhoe .....	14124.5 [13091.5 min.] kPa (141.5 [131.1 min.] bar) (2050 [1900 min.] psi)
10A Backhoe .....	15847 [14814 min.] kPa (158.7 [148.3 min.] bar) (2300 [2150 min.] psi)

#### Circuit Relief Valve Setting

Boom and Diggerstick	
7 Backhoe .....	14469 $\pm$ 689 kPa (79 $\pm$ 5 bar) (2100 $\pm$ 100 psi)
8, 8A, 10 and 10A Backhoe .....	19981 $\pm$ 689.5 kPa (179.5 $\pm$ 6.5 bar) (2600 $\pm$ 100 psi)
Shim Sizes	
7 and 8, 8A Backhoe .....	1.02 mm (0.04 in.), 0.51 mm (0.02 in.), (0.254 mm (0.01 in.)

#### Crossover Relief Valve Setting

Test Engine Speed .....	800 RPM
7, 8, and 8A Backhoe .....	7407—8440 kPa (74.2—84.5 bar) (1075—1225 psi)
10 and 10A Backhoe .....	10335—11369 kPa (103.5—113.9 bar) (1500—1650 psi)

#### Boom

Restrictor Orifice I.D.	
7 Backhoe .....	1.575 mm (0.062 in.)
8 and 8A Backhoe .....	1.88 mm (0.074 in.),
10 and 10A Backhoe .....	1.88 mm (0.074 in.)



## Swing

Restrictor Orifice I.D. (2)	
7 Backhoe	1.575 mm (0.062 in.)
8 and 8A Backhoe	1.19 mm (0.046 in.)
10 and 10A Backhoe	1.4 mm (0.055 in.)

## Stabilizer

Restrictor Orifice I.D. (2)	
7 Backhoe (after Nov. 1989)	1.575 mm (0.062 in.)
8 and 8A Backhoe (after April 1990)	1.88 mm (0.074 in.)

## INTERNAL VALVE LEAKAGE

(Maximum acceptable limit)

Stabilizer Circuit	12 ML/min (0.73 cu. in./min)
Lift Circuit (with relief and check)	22 ML/min (1.34 cu.in./min)

## LIFT CYLINDER DROP RATE

(Maximum acceptable limit from transport position)

7	14.48 mm/min (.57 in./min)
8, 8A	9.15 mm/min (.36 in./min)
10, 10A	7.62 mm/min (.30 in./min)

## STABILIZER CYLINDER DROP RATE

(Maximum acceptable limit from transport position)

7	8.64 mm/min (.34 in./min)
8, 8A	5.85 mm/min (.23 in./min)
10, 10A	5.85 mm/min (.23 in./min)

## STABILIZER CYLINDER RETRACT RATE

(Maximum acceptable limit from working position)

7	5.85 mm/min (.23 in./min)
8, 8A	3.81 mm/min (.15 in./min)
10, 10A	3.81 mm/min (.15 in./min)

## 7 BACKHOE FUNCTION TIMES

NOTE: All times in seconds.



	650	650 w/p.s. <sup>b</sup>	670 w/p.s. <sup>b</sup>	750	750 w/p.s. <sup>b</sup>	770 w/p.s. <sup>b</sup>	755	855	955 w/p.s. <sup>b</sup>
Boom up*	2.1	2.7	2.0	1.8	2.2	2.0	1.8	1.8	1.6
Boom down*	2.5	3.2	2.3	2.1	2.6	2.4	2.3	2.3	2.1
Dipperstick in	3.0	3.8	2.8	2.5	3.1	2.8	3.5	3.5	3.2
Dipper stick out	2.3	3.0	2.2	2.0	2.5	2.2	2.9	2.9	2.6
Bucket open	2.0	2.6	1.9	1.7	2.1	1.9	2.0	2.0	1.8
Bucket closed	2.3	3.0	2.2	2.0	2.5	2.2	2.6	2.6	2.3
Swing left to right	2.5	2.5	2.8	2.5	2.5	2.8	2.8	2.8	2.5
Swing right to left	2.5	2.5	2.8	2.5	2.5	2.8	2.8	2.8	2.5
Stabilizer up	1.2	1.5	1.2	1.0	1.2	1.1	1.6	1.6	1.7
Stabilizer down	1.7	2.3	1.7	1.5	1.8	1.7	2.3	2.3	2.1

\*Arm extended, bucket in closed position, ground level to full boom extension.

<sup>b</sup> With power steering.

## 8 AND 8A BACKHOE FUNCTION TIMES—TRACTORS

NOTE: All times in seconds

	850	850 9 cc pump w/p.s. <sup>b</sup>	870	950, 1050 9 cc pump	950, 1050 9 cc pump w/p.s. <sup>b</sup>	970	850 11 cc pump	850 11 cc pump w/p.s. <sup>b</sup>	950, 1050 11 cc pump	950, 1050 11 cc pump w/p.s. <sup>b</sup>	1070
Boom up*	2.4	3.4	2.0	2.6	3.9	2.0	2.0	2.6	2.2	2.9	1.9
Boom down*	2.8	3.9	2.3	3.0	4.4	2.3	2.3	3.0	2.5	3.3	2.2
Dipperstick in	4.4	6.3	3.5	4.8	7.1	3.5	3.7	4.8	3.9	5.3	3.4
Dipper stick out	3.5	5.0	2.8	3.8	5.6	2.8	2.9	3.8	3.1	4.2	2.7
Bucket open	2.2	3.1	1.7	2.4	3.5	1.7	1.8	2.3	1.9	2.6	1.6
Bucket closed	2.9	4.1	2.6	3.2	4.7	2.6	2.4	3.1	2.6	3.5	2.2
Swing left to right	3.5	5.0	3.8	3.9	5.7	3.8	4.2	4.2	4.2	4.2	3.6
Swing right to left	3.5	5.0	3.8	3.9	5.7	3.8	4.2	4.2	4.2	4.2	3.6
Stabilizer up	2.0	2.8	1.6	2.2	3.2	1.6	1.7	2.2	1.8	2.4	2.1
Stabilizer down	3.2	4.5	2.5	3.5	5.1	2.5	2.6	3.4	2.8	3.8	2.4

\*Arm extended, bucket in closed position, ground level to full boom extension.

<sup>b</sup> With power steering.

## 8 AND 8A BACKHOE FUNCTION TIMES—SKID-STEER LOADERS

NOTE: All times in seconds.



### MODEL

	570	575	675	675B
Boom up*	7.8	7.0	4.0	4.0
Boom down*	6.7	6.0	3.4	3.4
Dipperstick in	5.6	5.0	2.9	2.9
Dipper stick out	6.7	6.0	3.4	3.4
Bucket open	3.4	3.8	2.2	2.2
Bucket closed	3.8	4.2	2.4	2.4
Swing left to right	5.0	5.0	5.0	5.0
Swing right to left	5.0	5.0	5.0	5.0
Stabilizer up	2.9	2.6	1.7	1.7
Stabilizer down	2.9	2.6	1.7	1.7

\*Arm extended, bucket in closed position, ground level to full boom extension.

## 10 AND 10A BACKHOE FUNCTION TIMES

NOTE: All times in seconds.

### MODEL

	1250	1450	1650	2150	2350 13 GPM	2350 23 GPM	5000 SERIES	675, 675B SSL
Boom up*	3.3	3.4	3.6	2.8	2.8	1.6	3.2	5.3
Boom down*	3.1	3.2	3.3	2.6	2.6	1.5	3.0	1.0
Dipperstick in	1.2	1.3	1.3	1.1	1.1	0.6	1.3	2.4
Dipper stick out	1.5	1.5	1.6	1.2	1.2	0.7	1.4	2.0
Bucket open	1.5	1.5	1.6	1.2	1.2	0.7	1.4	2.0
Bucket closed	1.2	1.3	1.3	1.1	1.1	0.6	1.3	3.0
Swing left to right	5.0	5.0	5.0	5.0	5.0	5.0	5.7	5.0
Swing right to left	5.0	5.0	5.0	5.0	5.0	5.0	5.7	5.0
Stabilizer up	2.3	2.4	2.5	1.9	1.9	1.1	1.3	1.5
Stabilizer down	2.3	2.4	2.5	1.9	1.9	1.1	1.3	1.5

\*Arm extended, bucket in closed position, ground level to full boom extension.

## LOADERS

### CAPACITY—44 Loader, 316, 318, 330, 420 and 430 Tractor

	316, 318 & 330	420 & 430
Lift Capacity .....	180 kg (400 lb.)	225 kg (500 lb.)
Rated Breakout Capacity .....	260 kg (575 lb.)	328 kg (725 lb.)
1220 mm (48 in.) Bucket .....	0.164 m <sup>3</sup> (5.80 ft. <sup>3</sup> )	
1370 mm (54 in.) Bucket .....	0.185 m <sup>3</sup> (6.54 ft. <sup>3</sup> )	



### CAPACITY—40 Loader, 415, 425, 445 and 455 Tractor (Two-Wheel Steer)

Lift Capacity at Full Height .....	.98 kg (215 lb.)
at 450 mm (18 in.) .....	159 kg (350 lb.)
Breakout (Boom) .....	226 kg (500 lb.)
Breakout (Bucket) .....	272 kg (600 lb.)

### CAPACITY—60 Loader, 650, and 655 Tractor

Lift Capacity at Full Height .....	273 kg (600 lb.)
at 450 mm (18 in.) .....	385 kg (845 lb.)
at 900 mm (36 in.) .....	335 kg (735 lb.)
Breakout (Boom) .....	4010 N (900 lb.)
Breakout (Bucket) .....	6660 N (1495 lb.)

### CAPACITY—60 Loader, 670 Tractor

Lift Capacity at Full Height .....	297 kg (655 lb.)
at 450 mm (18 in.) .....	385 kg (845 lb.)
at 900 mm (36 in.) .....	335 kg (735 lb.)
Breakout (Boom) .....	4010 N (900 lb.)
Breakout (Bucket) .....	6660 N (1495 lb.)

### CAPACITY—70, Loader, 750 Tractor

Lift Capacity at Full Height .....	318 kg (700 lb.)
at 450 mm (18 in.) .....	540 kg (1190 lb.)
at 900 mm (36 in.) .....	460 kg (1010 lb.)
at 1800 mm (72 in.) .....	335 kg (735 lb.)
Breakout (Boom) .....	5790 N (1300 lb.)
Breakout (Bucket) .....	6995 N (1570 lb.)


### CAPACITY—70, 70A Loader, 755, 770 and 855 Tractor

Lift Capacity at Full Height .....	342 kg (755 lb.)
at 450 mm (18 in.) .....	540 kg (1190 lb.)
at 900 mm (36 in.) .....	460 kg (1010 lb.)
at 1800 mm (72 in.) .....	335 kg (735 lb.)
Breakout (Boom) .....	5790 N (1300 lb.)
Breakout (Bucket) .....	6995 N (1570 lb.)

### CAPACITY—70A Loader, 955 Tractor

Lift Capacity at Full Height .....	422 kg (930 lb.)
at 450 mm (18 in.) .....	659 kg (1450 lb.)
at 900 mm (36 in.) .....	559 kg (1230 lb.)
at 1800 mm (72 in.) .....	407 kg (895 lb.)
Breakout (Boom) .....	7060 N (1585 lb.)
Breakout (Bucket) .....	8530 N (1915 lb.)

## DIMENSIONS—40 Loader, 415, 425, 445, 455 (Two-Wheel Steer)



M78226

### Tractor Tire Size Specifications

Front	16x6050-8 4 PR	18x8.50-8 4 PR
Rear	23x10.50-12 2 PR	26x12.00-12 2 PR

### Loader Dimensions

A—Maximum Lift Height (lowest point on bucket)	175 cm (69 in.)	178 cm (70 in.)
B—Maximum Clearance Under Fully Dumped Bucket	132 cm (52 in.)	135 cm (53 in.)
C—Reach With Fully Dumped Bucket 45°	65 cm (25.5 in.)	65 cm (25.5 in.)
D—Maximum Bucket Dump Angle	50°	50°
E—Reach With Bucket On Ground	109 cm (43 in.)	108 cm (42.5 in.)
F—Bucket Rollback Angle On Ground	19°	18°
G—Digging Depth Below Ground	10 cm (4 in.)	8 cm (3 in.)


### Required Tractor Ballasting

w/23 in. Tires .....	Minimum of 295 kg (650 lb.) rear ballast, 113 kg (250 lb.) on rear wheels
w/26 in. Tires .....	Minimum of 340 kg (750 lb.) rear ballast, 113 kg (250 lb.) on rear wheels

### Hydraulic System

Pump, Reservoir, and Controls .....	Tractor
Rated Pressure .....	6890 kPa (1000 psi)
Lift Cylinder Diameter .....	38 mm (1.5 in.)
Bucket Cylinder Diameter .....	44 mm (1.75 in.)

## DIMENSIONS—44 LOADER



M78226

## Loader Dimensions

	316, 318, & 330	420	430
A—Maximum Lift Height (lowest point on bucket)	1816 mm (71.5 in.)	1854 mm (73 in.)	1854 mm (73 in.)
B—Maximum Clearance (Fully Dumped Bucket)	1320 mm (52 in.)	1358 mm (53.5 in.)	1358 mm (53.5 in.)
C—Reach (Fully Dumped Bucket 45°)	533 mm (21 in.)	558 mm (22 in.)	558 mm (22 in.)
D—Maximum Bucket Dump Angle	50°	50°	50°
E—Reach With Bucket On Ground	1117 mm (44 in.)	1130 mm (44.5 in.)	1300 mm (51.25 in.)
F—Bucket Rollback Angle	20°	20°	20°
G—Digging Depth Below Ground	114 mm (4.5 in.)	100 mm (4 in.)	100 mm (4 in.)

**NOTE:** Operating dimensions vary with tractor size, and bucket used. Dimensions for the 44 Loader are given on the John Deere 318 Tractor with 6.50x16 front tires, 10.5x23 rear tires and a 1220 mm (48 in.) bucket. The John Deere 420 and 430 Tractors are equipped with 8.50x18 front tires, 12.00x26 rear tires and a 1220 mm (48 in.) bucket.

## Required Tractor Ballasting

34 kg (75 lb.) of rear wheel weights (total), Maximum liquid in rear tires, & 77 kg (170 lb.) on rear wheels (min.)


## Hydraulic System

## 316, 318 &amp; 330

## 420 &amp; 430

Pump, Reservoir, and Controls	Independent	Independent
Rated Pressure	6890 kPa (1000 psi)	8274 kPa (1200 psi)
Lift Cylinder Diameter	44 mm (1.75 in.)	4 mm (1.75 in.)
Bucket Cylinder Diameter	44 mm (1.75 in.)	44 mm (1.75 in.)
Lift Cylinder Stroke	44 mm (1.75 in.)	4 mm (1.75 in.)
Bucket Cylinder Stroke	466 mm (18.38 in.)	368 mm (14.5 in.)

## DIMENSIONS—60, 70, 70A



M78221

## MODEL

	60 Loader 655 Tractor	60 Loader 650 Tractor	60 Loader 670 Tractor	70 Loader 755 Tractor	70A Loader 855 Tractor	70 Loader 750 Tractor	70 Loader 770 Tractor	70A Loader 955 Tractor
--	--------------------------	--------------------------	--------------------------	--------------------------	---------------------------	--------------------------	--------------------------	---------------------------

A—Maximum Lift Height)	1765 mm (69.5 in.)	1765 mm (69.5 in.)	1765 mm (69.5 in.)	1965 mm (77.3 in.)				
B—Clearance With Bucket Level	1670 mm (65.8 in.)	1670 mm (65.8 in.)	1670 mm (65.8 in.)	1875 mm (73.8 in.)				
C—Clearance With Bucket Dumped	1370 mm (54 in.)	1370 mm (54 in.)	1370 mm (54 in.)	1575 mm (62 in.)				
D—Clearance, Digging Depth	125 mm (5 in.)	125 mm (5 in.)						
E—Reach at max. Height & Dumped	655 mm (25.8 in.)	655 mm (25.8 in.)	700 mm (27.5 in.)	700 mm (27.5 in.)	700 mm (27.5 in.)	685 mm (27 in.)	762 mm (30 in.)	787 mm (31 in.)
F—Reach at Ground Level & Level	1265 mm (49.8 in.)	1255 mm (49.5 in.)	1265 mm (49.8 in.)	1215 mm (47.8 in.)	1215 mm (47.8 in.)	1265 mm (49.8 in.)	1219 mm (48 in.)	1219 mm (48 in.)
G—Max. Dump Angle	45°	45°	45°	45°	45°	45°	45°	45°
H—Rollback Angle on Ground	22°	22°	22°	22°	22°	22°	22°	22°
I—Overall Length	2980 mm (117.2 in.)	3100 mm (122.1 in.)	3080 mm (121.2 in.)	3080 mm (121.2 in.)	3255 mm (128.2 in.)	3340 mm (131.5 in.)	3107 mm (125.5 in.)	3225 mm (127 in.)

## Based On Tractor Tire Size:

• Front	6-12	6-12	6-12	6-12	6-12	6-12	6-12	25x8.5-14
• Rear	9.5-16	9.5-16	9.5-16	9.5-16	9.5-16	9.5-16	9.5-16	36x13.5-15

## CYCLE TIMES

NOTE: All times in seconds



	MODEL							
	60 Loader 655 Tractor	60 Loader 650 Tractor	60 Loader 670 tractor	70 Loader 755 Tractor	70A Loader 855 Tractor	70 Loader 750 Tractor	70 Loader 770 Tractor	70A Loader 955 Tractor
Loader raising time	4.3	4.8	2.2	3.2	3.2	3.9	2.7	2.8
Loader lowering time	2.7	5.4	2.0	2.0	2.0	5.5	2.6	2.4
Bucket dumping time	3.7	4.3	2.1	2.2	2.2	3.6	2.0	2.5
Bucket rollback time	3.6	1.7	1.7	2.2	2.2	1.5	2.0	2.1
Hydraulic flow	15 L/m 4.0 gpm	21.1 L/m 5.6 gpm	20.9 L/m 5.5 gpm	21.1 L/m 5.6gpm	21.1 L/m 5.6gpm	23.9 L/m 6.3 gpm	21.1 L/m 5.6 gpm	27.6 L/m 7.2 gpm

Cycle times are based on flow rates at S.C.V. and with power steering.  
1220 mm (48 in.) bucket size used.

## BUCKET STRUCK CAPACITY

48-Inch.....	0.17 mm <sup>3</sup> (6.2 cu-ft.)
54-Inch.....	0.19 mm <sup>3</sup> (7.0 cu-ft.)
60-Inch.....	0.22 mm <sup>3</sup> (7.8 cu-ft.)

## INTERNAL VALVE LEAKAGE

(Maximum acceptable limit)

655, 670, 770, 755, 855, and 955 .....	12ML/min (0.73 cu. in.)
--	-------------------------

## LIFT CYLINDER DROP RATE

(Maximum acceptable limit from transport position)

60, 70, 70A.....	10.4 mm/min (.41 in./min)
------------------	---------------------------

## BUCKET CYLINDER DROP RATE

(Maximum acceptable limit from rollback position)

60, 70, and 70A .....	13 mm/min (.51 in./min)
-----------------------	-------------------------


## FITTINGS




### SERVICE RECOMMENDATIONS FOR O-RING BOSS FITTINGS

#### STRAIGHT FITTING

1. Inspect O-ring boss seal for dirt or defects.
2. Lubricate O-rings with petroleum jelly. Place electrical tape over threads to protect O-ring. Slide O-ring over tape and into O-ring groove of fitting. Remove tape.
3. Tighten fitting to torque value shown on chart.



M82649A



M82650A

*NOTE: Do not allow hoses to twist when tightening fittings.*

#### TORQUE VALUE

Thread Size	N·m	lb·ft
3/8-24 UNF	8	6
7/16-20 UNF	12	9
1/2-20 UNF	16	12
9/16-18 UNF	24	18
3/4-16 UNF	46	34
7/8-14UNF	62	46
1-1/16-12 UN	102	75
1-3/16-12 UN	122	90
1-5/16-12 UN	142	105
1-5/8-12 UN	190	140
1-7/8-12 UN	217	160

*NOTE: Torque tolerance is  $\pm 10\%$*


#### ANGLE FITTING

1. Back-off lock nut (A) and back-up washer (B) completely to head-end (C) of fitting.
2. Turn fitting into threaded boss until back-up washer contacts face of boss.
3. Turn fitting head-end counterclockwise to proper index (maximum of one turn).
4. Hold fitting head-end with a wrench and tighten locknut and back-up washer to proper torque value.

## SERVICE RECOMMENDATIONS FOR FLAT FACE O-RING SEAL FITTINGS

1. Inspect the fitting sealing surfaces. They must be free of dirt or defects.
2. Inspect the O-ring. It must be free of damage or defects.
3. Lubricate O-rings and install into groove using petroleum jelly to hold in place.
4. Push O-ring into the groove with plenty of petroleum jelly so O-ring is not displaced during assembly.

5. Index angle fittings and tighten by hand pressing joint together to insure O-ring remains in place.
6. Tighten fitting or nut to torque value shown on the chart per dash size stamped on the fitting. Do not allow hoses to twist when tightening fittings.



M82651A



## FLAT FACE O-RING SEAL FITTING TORQUE

Nominal Tube O.D.		Dash Size	Thread Size (in.)	Swivel Nut Torque		Bulkhead Nut Torque	
mm	(in.)			N·m	(lb-ft)	N·m	(lb-ft)
6.35	0.250	-4	9/16-18	16	12	5.0	3.5
9.52	0.375	-6	11/16-16	24	18	9.0	6.5
12.70	0.500	-8	13/16-16	50	51	17.0	12.5
15.88	0.625	-10	1-14	69	51	17.0	12.5
19.05	0.750	-12	1-3/16-12	102	75	17.0	12.5
22.22	0.875	-14	1-3/16-12	102	75	17.0	12.5
25.40	1.000	-16	1-7/16-12	142	105	17.0	12.5
31.75	1.250	-20	1-11/16-12	190	140	17.0	12.5
38.10	1.500	-24	2-12	217	160	17.0	12.5

NOTE: Torque tolerance is +15 -20%.

## UNIFIED INCH TORQUE VALUES



SAE Grade and Head Markings	1 or 2 <sup>b</sup> No Marks 				5 5.1 5.2 			8 8.2 	
	2 No Marks 				5 	5 	8 	8 	TS1162

Size	Grade 1				Grade 2 <sup>b</sup>				Grade 5, 5.1 or 5.2				Grade 8 or 8.2			
	Lubricated <sup>a</sup>		Dry <sup>a</sup>													
	Nm	lb-ft	Nm	lb-ft												
1/4	3.8	2.8	4.7	3.5	6	4.4	7.5	5.5	9.5	7	12	9	13.5	10	17	12.5
5/16	7.7	5.7	9.8	7.2	12	9	15.5	11.5	19.5	14.5	25	18.5	28	20.5	35	26
3/8	13.5	10	17.5	13	22	16	27.5	20	35	26	44	32.5	49	36	63	46
7/16	22	16	28	20.5	35	26	44	32.5	56	41	70	52	80	59	100	74
1/2	34	25	42	31	53	39	67	49	85	63	110	80	120	88	155	115
9/16	48	35.5	60	45	76	56	95	70	125	92	155	115	175	130	220	165
5/8	67	49	85	63	105	77	135	100	170	125	215	160	240	175	305	225
3/4	120	88	150	110	190	140	240	175	300	220	380	280	425	315	540	400
7/8	190	140	240	175	190	140	240	175	490	360	615	455	690	510	870	640
1	285	210	360	265	285	210	360	265	730	540	920	680	1030	760	1300	960
1-1/8	400	300	510	375	400	300	510	375	910	670	1150	850	1450	1075	1850	1350
1-1/4	570	420	725	535	570	420	725	535	1280	945	1630	1200	2050	1500	2600	1920
1-3/8	750	550	950	700	750	550	950	700	1700	1250	2140	1580	2700	2000	3400	2500
1-1/2	990	730	1250	930	990	730	1250	930	2250	1650	2850	2100	3600	2650	4550	3350

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.

Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head.

Tighten toothed or serrated-type lock nuts to the full torque value.

<sup>a</sup> "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication.

<sup>b</sup> Grade 2 applies for hex cap screws (not hex bolts) up to 152 mm (6 in.) long. Grade 1 applies for hex cap screws over 152 mm (6 in.) long, and for all other types of bolts and screws of any length.

## METRIC TORQUE VALUES

Property Class and Head Markings	4.8		8.8 9.8		10.9		12.9		Ts1163
									
Property Class and Nut Markings	5		10		10		12		
									

Size	Class 4.8				Class 8.8 or 9.8				Class 10.9				Class 12.9			
	Lubricated <sup>a</sup>		Dry <sup>a</sup>		Lubricated <sup>a</sup>		Dry <sup>a</sup>		Lubricated <sup>a</sup>		Dry <sup>a</sup>		Lubricated <sup>a</sup>		Dry <sup>a</sup>	
	Nm	lb-ft	Nm	lb-ft.	Nm	lb-ft	Nm	lb-ft	Nm	lb-ft	Nm	lb-ft	Nm	lb-ft	Nm	lb-ft
M6	4.7	3.5	6	4.4	9	6.6	11.5	8.5	13	9.5	16.5	12.5	15.5	11.5	19.5	14.5
M8	11.5	8.5	14.5	10.7	22	16	28	20.5	32	23.5	40	29.5	37	27.5	47	35
M10	23	17	29	21	43	32	55	40	63	46	80	59	75	55	95	70
M12	40	29.5	50	37	75	55	95	70	110	80	140	105	130	95	165	120
M14	63	46	80	59	120	88	150	110	175	130	220	165	205	150	260	190
M16	100	74	125	92	190	140	240	175	275	200	350	225	320	235	400	300
M18	135	100	175	125	265	195	330	245	375	275	475	350	440	325	560	410
M20	190	140	245	180	375	275	475	350	530	390	675	500	625	460	790	580
M22	265	195	330	245	510	375	650	480	725	535	920	680	850	625	1080	800
M24	330	245	425	315	650	480	820	600	920	680	1150	850	1080	800	1350	1000
M27	490	360	625	460	950	700	1200	885	1350	1000	1700	1250	1580	1160	2000	1475
M30	660	490	850	625	1290	950	1630	1200	1850	1350	2300	1700	2140	1700	2700	2000
M33	900	665	1150	850	1750	1300	2200	1625	2500	1850	3150	2325	2900	2150	3700	2730
M36	1150	850	1450	1075	2250	1650	2850	2100	3200	2350	4050	3000	3750	2770	4750	3500

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class.

Fasteners should be replaced with the same or higher property class. If higher property class fasteners are used, these should only be tightened to the strength of the original.

Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

<sup>a</sup> "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication.

## LUBRICANTS


### GREASE



Use grease based on the expected air temperature range during the service interval.

The following greases are preferred:

- John Deere MOLY HIGH TEMPERATURE EP GREASE
- John Deere HIGH TEMPERATURE EP GREASE
- John Deere GREASE-GARD™



TS1417

Other greases may be used if they meet one of the following:

- SAE Multipurpose EP Grease with a maximum of 5% molybdenum disulfide.
- SAE Multipurpose EP Grease

Greases meeting Military Specification MIL-G-10924F may be used as arctic grease.

### ANTI-CHATTER TRANSMISSION/HYDRAULIC OIL

**NOTE:** *This transmission is filled with John Deere Hy-Gard™ (J20C) Transmission and Hydraulic oil at the factory. DO NOT mix oils.*

This transmission is equipped with wet disk brakes. To avoid chatter, use only John Deere HY-GARD™ (J20C or J20D) Transmission/Hydraulic Oil. It is specifically formulated to minimize wet brake chatter, and to provide maximum protection against mechanical wear, corrosion, and foaming.

**DO NOT** use type "F" automatic transmission fluid.

**Use** J20C Transmission/Hydraulic Oil when ambient operating temperatures are **above** -18° C. (0° F.).

**Use** J20D Low Viscosity HY-Gard Transmission/Hydraulic Oil when ambient operating temperatures are **below** -18° C. (0° F.).

### ALTERNATIVE LUBRICANTS

Conditions in certain geographical areas outside the United States and Canada may require different lubricant recommendations than those printed in this manual or the operator's manual. Consult with your John Deere Dealer, or Sales Branch to obtain the alternative lubricant recommendations.

### LUBRICANT STORAGE

This machine can operate at top efficiency only if clean lubricants are used.

Use clean containers to handle all lubricants. Store them in an area protected from dust, moisture, and other contamination. Store drums on their sides.

# CONTENTS


Page

## BACKHOES

<b>BACKHOE COMPONENT LOCATION</b> .....	<b>3</b>
<b>THEORY OF OPERATION</b> .....	<b>4</b>
CONTROL VALVES .....	4
LOAD CHECK VALVES .....	4
CROSSOVER RELIEF VALVES .....	4
MMAIN SYSTEM RELIEF VALVE .....	4
CIRCUIT RELIEF AND ANTI-CAVITATION CHECK VALVES .....	4
RESTRICTORS .....	4
BACKHOE HYDRAULIC SYSTEM .....	5
<b>TROUBLESHOOTING</b> .....	<b>6</b>
TROUBLESHOOTING CONTINUED .....	7
<b>DIAGNOSTICS</b> .....	<b>9</b>
<b>TESTS AND ADJUSTMENTS</b> .....	<b>10</b>
MAIN SYSTEM RELIEF VALVE TEST (7, 8, 8A AND 10A BACKHOES ONLY) .....	11
CROSSOVER RELIEF VALVE TEST .....	11
RESTRICTOR INSPECT ION .....	11
<b>REPAIR</b> .....	<b>12</b>
SYSTEM RELIEF VALVE INSPECTION (7, 8, 8A AND 10A BACKHOES ONLY) .....	12
SPOOL REMOVAL .....	12
SPOOL ASSEMBLY .....	13
LOAD CHECK VALVES INSPECT ION .....	13
DIPPERSTICK CIRCUIT RELIEF VALVE INSPECT ION .....	13
ANTI-CAVITATION VALVE	
INSPECT ION .....	14
BUCKET CIRCUIT RELIEF VALVE INSPECTION (10 BACKHOE ONLY) .....	14
BOOM CIRCUIT RELIEF VALVE INSPECT ION .....	14
ASSEMBLE VALVE HOUSING .....	15
VALVE LINKAGE INSPECTION .....	16
VALVE HOUSING INSTALLATION .....	17
CROSSOVER RELIEF VALVE DISASSEMBLY AND REPAIR .....	18




Continued on next page



	Page
<b>CYLINDER REPAIR.....</b>	<b>19</b>
BUCKET, BOOM, AND DIPPERSTICK CYLINDERS	
DISASSEMBLY AND REPAIR—7 BACKHOE .....	19
STABILIZER CYLINDER DISASSEMBLY AND REPAIR—7 BACKHOE .....	20
SWING CYLINDER DISASSEMBLY AND REPAIR—7 BACKHOE .....	21
BUCKET, BOOM, AND DIPPERSTICK CYLINDERS	
DISASSEMBLY AND REPAIR—8 AND 8A BACKHOE.....	22
STABILIZER CYLINDERS	
DISASSEMBLY AND REPAIR—8, 8A, 10, AND 10A BACKHOE .....	23
SWING CYLINDERS	
DISASSEMBLY AND REPAIR—8, 8A, 10, AND 10A BACKHOE .....	24
BUCKET AND DIPPERSTICK CYLINDER	
DISASSEMBLY AND REPAIR—10 AND 10A BACKHOE.....	25
BOOM CYLINDER	
DISASSEMBLY AND REPAIR—10 AND 10A BACKHOE.....	26

## BACKHOE COMPONENT LOCATION

NOTE: The 8A backhoe shown, is typical of the backhoes covered in this manual.



M58375

## THEORY OF OPERATION

### CONTROL VALVES

The hydraulic control valve consists of individual valve sections stacked side-by-side with a continuous open center for all tractors except the 2150 and 2350. All sections have a self centering spool that directs pressure to one of the hydraulic cylinders.



The open center systems have a main system relief valve that protects the whole backhoe hydraulic system from sharp pressure shocks. It is adjustable by adding or removing shims but should not be adjusted to a higher or lower value than recommended. In addition, three of the individual circuits are protected by circuit relief valves that are adjustable, but again, they should not be adjusted to a value that is higher or lower than recommended.

**NOTE:** *The Model 10 & 10A Backhoes have three individual circuits that are protected by circuit relief valves.*

### LOAD CHECK VALVES

Each valve section is equipped with load check valves. These check valves prevent reverse fluid flow if supply pressure were lost (The engine stopped running). This feature would prevent opposite direction movement of an implement should supply pressure be lost.

### CROSSOVER RELIEF VALVES

In a swing to the left or right-hand side, if pressure exceeds rated crossover relief valve pressure, the relief valve opens and pressure oil flow is diverted through the valve to the opposite swing cylinder and to the return oil passage. This protects the swing circuit from excessive hydraulic pressure that is created from unexpected side loads when the valve is in the neutral position.

### MAIN SYSTEM RELIEF VALVE

High pressure can be generated by continuing to operate a function after its cylinder has reached its limit. When pressure reaches system relief valve pressure, the valve opens, diverting inlet oil to the return oil passage and the rockshaft housing, or to the skid-steer loader.

### CIRCUIT RELIEF AND ANTI-CAVITATION CHECK VALVES

Circuit relief and anti-cavitation check valves are included in bucket (Model 10 & 10A only), boom, and dipperstick valve sections.

During some operations, when the valve spool is in a neutral position, a sudden external force against the bucket will cause a pressure increase in the head end of the cylinder. To relieve that pressure and avoid damage to the valve section, the circuit relief valve opens and allows oil flow to the return oil passage.

When the circuit relief valve opens to relieve pressure oil in the head end of the cylinder, a void is created in the rod end (no incoming oil, valve section in neutral). Oil from the return oil passage unseats the anti-cavitation check valve ball and replaces that void in the rod end.


### RESTRICTORS

Restrictors are installed in both ports of the swing valve section, the IN port of the boom valve section, and the IN port of the stabilizer section (Model 7 & 8A only).

The restrictor is a one-way orifice that acts to slow or dampen return oil flow to the valve section. This provides for smooth operation when the boom is lowered or when it is swung from side-to-side. Pressure oil flows around the restrictor and is not affected by the orifice.

## BACKHOE HYDRAULIC SYSTEM

NOTE: Model 8, 8A, 10 & 10A swing system shown.



## TROUBLESHOOTING




Problem or Symptom	Check or Solution							
	Backhoe will not operate	Backhoe loses power	Loss of power in any one cylinder	Loss of power in boom or dipperstick only	Loss of power in swing cylinders only	Cannot obtain full swing	Slow operation	Spongy, jerking operation
Low oil level/wrong viscosity/air in system	●	●				●	●	
No hydraulic pressure	●	●						
Improper hose connection	●	●						
Excessive back pressure, check for restriction between outlet and reservoir	●	●				●		
System relief valve malfunctioning	●	●			●		●	
Loose or leaking connectors/ hoses (see Miscellaneous Sec.)		●	●		●			
Oil bypassing in cylinder		●	●		●			
Hydraulic system malfunction		●					●	●
Pinched/restricted hydraulic hoses (see Miscellaneous Sec.)		●	●		●			
Control not positioned full open			●	●	●		●	
Load check valve leaking			●	●				●
Worn valve section		●	●		●		●	
Circuit relief valve malfunctioning		●		●				
Anti-cavitation check valve/ball stuck or not seating properly				●				●
Cross-over relief valve malfunctioning		●			●		●	
Bent piston rod or swing linkage interference						●	●	
Engine speed too slow		●					●	
Foreign material in backhoe valve swing restrictor orifices							●	

Product: John Deere Horicon Hydraulic Attachments Service Repair Technical Manual

Full Download: <https://www.arepairmanual.com/downloads/john-deere-horicon-hydraulic-attachments-service-repair-technical-manual/>

## TROUBLESHOOTING CONTINUED

Problem or Symptom	Load drops or settles	Spool sticking, can't be pushed in or won't return to neutral	Work port leakage			Backhoe control valve leaks around spool	Boom cylinder locks up, may raise the first time	Backhoe stabilizers will not hold rear of tractor off ground	Oil leaking from differential housing vent	System is dumping pressure to relief when pushing dirt in hole
			Work port leakage	Backhoe control valve leaks around spool	Boom cylinder locks up, may raise the first time					
Paint on spool or scored spool	●	●								
Oil leaking passed spool into spool cap		●								
Broken return spring		●								
Bent spool		●								
Cylinder leaking	●									
Loose/leaking connectors	●									
Load check valve failure	●									
Worn valve section	●									
Hydraulic oil contaminated		●								
Misaligned control valve linkage		●								
Relief valve cartridge seals bad			●							
Spool to bore fit too tight		●								
Valve body distorted (improper mounting)		●								
Positioner assembly out of alignment due to "bumping" of positioner end		●								
Oil viscosity too heavy		●								
Spool and section seal dry (stored too long without use)		●								
Improper assembly after rebuild		●								
Excessive clearance between spool and bore of casting. Spool and casting worn due to heavy use or by contaminants introduced into spool area.	●			●						



Sample of manual. Download All 73 pages at:

<https://www.arepairmanual.com/downloads/john-deere-horicon-hydraulic-attachments-service-repair-technical-manual/>