

Product: Kubota RCK60-30BB RC72-30BB Service Manual

Full Download: <https://www.arepairmanual.com/downloads/kubota-rck60-30bb-rc72-30bb-service-manual/>

# WSM

---

**WORKSHOP MANUAL**

**MOWER**

**RCK60-30BB,  
RC72-30BB**

---

**Kubota**

Sample of manual. Download All 81 pages at:

<https://www.arepairmanual.com/downloads/kubota-rck60-30bb-rc72-30bb-service-manual/>

KiSC issued 02, 2020 A

Product: Kubota RCK60-30BB RC72-30BB Service Manual

Full Download: <https://www.arepairmanual.com/downloads/kubota-rck60-30bb-rc72-30bb-service-manual/>

## TO THE READER

This workshop manual provides safety information for service activity, general information such as specifications and dimensions of the machine, mechanisms and structure descriptions of the machine, and service procedures.

### **Safety**

This section contains safety service descriptions and safety label information.

### **General**

This section contains general instructions, tightening torques, general machine information and special tools.

### **Maintenance**

This section contains information for the recommended oil and general maintenance procedures.

Each section basically consists of mechanism and servicing.

### **Mechanism**

Mechanism part contains information and explanations for the structure, functions, and specifications of the machine or component parts. This part should be comprehended before proceeding with troubleshooting, disassembling, assembling, and servicing works.

### **Servicing**

Servicing part contains information and procedures for maintenance, troubleshooting and repair works. The reader should follow these instructions in order to satisfy any servicing work safely, correctly and quickly.

In this WSM, service specifications and service limits are defined as followings.

### **Service specifications:**

Specification which corresponds to new machine's ex-factory. It is based on quality standard, drawings, or actual measurements conducted by Kubota. This value is used to determine whether there is a problem with the machine in the event of a troubleshooting. However, it is necessary to consider degradation due to wear, based on the operating time of the machine, application or maintenance condition.

### **Service limits:**

Service limit is a value corresponding to the recommended performance limit by taking long term-use wear into account. When the service limit is reached, the machine is required to have proper repair, overhaul or replacement in order to keep safe and adequate performance.

All of the illustrations, photographs, specifications, and other information in this manual were created based on the latest model at the time of publication.

The parts names used in this manual are unified into names representing the functions of the parts. Therefore, it does not necessarily correspond to the names used in other materials (parts list, operators manual etc.) and the name on the label / identification plates on the product.

Kubota reserves the right to change all information at any time without notice.

**February 2020**

© KUBOTA Corporation

Sample of manual. Download All 81 pages at:

<https://www.arepairmanual.com/downloads/kubota-rck60-30bb-rc72-30bb-service-manual/>

KiSC issued 02, 2020 A

# SUPPLEMENTARY INFORMATION

## Model name and related manuals

This manual applies to the following model.

Model name
RCK60-30BB, RC72-30BB



# CONTENTS

## 1. SAFETY

SAFETY FIRST .....	1-1
1. Working precautions .....	1-1
2. Preparing for emergencies .....	1-1
3. Working cautions .....	1-2
4. Starting machine safely .....	1-3
5. Preventing fires .....	1-3
6. Preventing acid burns .....	1-4
7. Avoiding high pressure fluid .....	1-4
8. Avoiding hot exhaust .....	1-4
SAFETY LABELS .....	1-5
1. Care of danger, warning and caution labels .....	1-7

## 2. GENERAL

GENERAL WORKING PRECAUTIONS .....	2-1
1. Tightening bolts and nuts .....	2-1
2. Applying thread-locking fluid .....	2-1
3. Installing circlips .....	2-1
4. Installing spring pins .....	2-2
5. Handling split pin .....	2-2
6. Handling chain joint and split pin .....	2-2
7. Handling liquid gasket .....	2-2
8. Replacing O-rings .....	2-3
9. Replacing oil seals .....	2-3
10. Replacing floating seals .....	2-3
11. Connecting hydraulic hoses .....	2-4
12. Wrapping thread seal tape .....	2-4
13. Installing elbows with male seat .....	2-4
14. Connecting and disconnecting quick hose couplings .....	2-5
15. Handling the battery .....	2-5
16. Handling wire harness .....	2-5
17. Handling fuses .....	2-6
18. Handling connectors .....	2-7
19. Wiring color .....	2-8
20. Washing the machine with a high pressure washer .....	2-8
21. Dispose fluids correctly .....	2-9
TIGHTENING TORQUES .....	2-11
1. General use screws, bolts and nuts .....	2-11
2. Stud bolts .....	2-11
3. Hydraulic fitting .....	2-12
3.1 Hydraulic hose fittings .....	2-12
3.2 Hydraulic pipe cap nuts .....	2-12
3.3 Adapters, elbows and others .....	2-12
4. Metric screws, bolts and nuts .....	2-13
5. American standard screws, bolts and nuts with UNC or UNF threads .....	2-13
6. Plugs .....	2-13
GENERAL MACHINE INFORMATION .....	2-15
1. Mower identification .....	2-15
2. Specifications .....	2-16
3. Terminology of the mower .....	2-17
4. Setting up of the mower .....	2-18
4.1 Setting-up procedure of the mower .....	2-18
4.1.1 Checking the parts of the mower before assembly .....	2-19
4.1.2 Setting up the mower .....	2-19

4.2 Mounting the mower to the tractor with titan turf tires .....	2-21
4.2.1 Installation of mower stopper extension .....	2-21
5. Mounting the mower to the tractor .....	2-22
5.1 Mounting the front hanger brackets to the tractor .....	2-22
5.2 Mounting the mid and rear hanger brackets to the tractor .....	2-23
5.3 Setting up the link.....	2-23
5.4 Mounting the mower to the tractor .....	2-25
5.5 Mounting the mower to the tractor with front loader .....	2-28
6. Adjustments of the mower .....	2-29
6.1 Adjusting the front link and connecting rod .....	2-29
6.2 Tractor hydraulic stop adjustment .....	2-30

### 3. MAINTENANCE

MAINTENANCE CHECK LIST .....	3-1
LUBRICANTS .....	3-3
CHECK AND MAINTENANCE.....	3-5
1. Checking and changing the gear box oil .....	3-5
2. Greasing .....	3-5
CHECKING AND REPLACING THE BLADE.....	3-9
1. Cleaning the mower deck .....	3-9
2. Checking the blade.....	3-9
3. Replacing the blade.....	3-9
REPLACING THE BELT .....	3-11
CHECKING AND REPLACING THE GEAR BOX OIL SEAL.....	3-13

### 4. MOWER

MECHANISM .....	4-1
1. Structure of power transmission of mower .....	4-1
2. Structure of lifting mechanism of mower .....	4-2
SERVICING .....	4-3
1. Troubleshooting for mower .....	4-3
2. Service specifications for mower .....	4-5
3. Tightening torques for mower .....	4-6
4. Checking and adjusting .....	4-7
4.1 Mower blade.....	4-7
4.1.1 Checking mower blade .....	4-7
4.2 Mower belt.....	4-7
4.2.1 Checking mower belt .....	4-7
4.3 Cutting height .....	4-8
4.3.1 Adjusting cutting height (RCK60-30BB).....	4-8
4.3.2 Adjusting cutting height (RC72-30BB).....	4-8
5. Disassembling and assembling .....	4-8
5.1 Removing universal joint and belt cover .....	4-8
5.2 Removing mower blade (center blade and outer blade) .....	4-9
5.3 Removing blade boss.....	4-9
5.4 Removing gear box and mower belt .....	4-10
5.5 Disassembling gear box.....	4-10
5.6 Removing center pulley holder.....	4-11
5.7 Removing outer pulley and blade shaft.....	4-11
6. Servicing .....	4-12
6.1 Adjusting turning torque of pinion shaft.....	4-12
6.2 Adjusting backlash between bevel gears .....	4-13

# 1. SAFETY

# SAFETY FIRST

This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully. It is essential that you read the instructions and safety regulations before you try to repair or use this unit.

## DANGER

- Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

## WARNING

- Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

## CAUTION

- Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury.


## ■ IMPORTANT

- Indicates that equipment or property damage could result if instructions are not followed.

## ■ NOTE


- Gives helpful information.

## 1. Working precautions




- Understand all safety instructions and safety labels in this manual.
- Park the machine on a stable and level ground then lower the attachment to check the machine safely.

- Stop the engine and remove the key when leaving the operator's seat for cleaning, maintenance, and servicing.



- Hang a DO NOT OPERATE tag near the operator's seat.
- Do not use worn or cracked tools. Use tools in a proper way with enough strength.
- In regards to the facility which is used in the workshop, follow each safety instruction.

## 2. Preparing for emergencies




- Keep a first aid kit and fire extinguisher ready at all times.
- Keep emergency numbers near your telephone at all times.

## 1. SAFETY

### 3. Working cautions




- Wear a uniform suited for service working. Do not wear loose clothes as they could get caught on the control lever.
- Wear the proper protective equipment when checking the machine. For example helmet, eye protector and protective shoes.
- Do not check the machine after you have consumed alcohol or drugs or when you are tired.



- Park the machine on a stable and level ground. Keep the machine away from obstacles and hazardous materials.
- Make sure to ventilate the work area in cases of working indoors.
- Do not allow third parties to come near the machine.
- Keep the machine clean. Remove dirt, debris, and oil attached to the machine.



- Make sure you have the support of the 3 points with both hands holding the handle and one foot at the step when getting on and off the machine.




- Make sure the coolant temperature and release pressure when opening the radiator cap.
- Release residual pressure in the hydraulic circuit before removing the hydraulic components.
- Pay attention when releasing pressure in hydraulic circuit, the machine or attachment might move unexpectedly.
- When working under the machine, make sure the machine does not move back and forth.
- When working under the machine, provide secure support for the machine.
- When using a garage jack, always use with a rigid rack to prevent the machine from falling.

## 4. Starting machine safely




- Do not do the following work when starting the engine.
  - Short across starter terminals.
  - Bypass the safety start switch.
- Make sure it is safe around the machine from the operator's seat before starting the engine.
- Do not start the engine unless seating in the operator's seat.
- Make sure that the pilot levers are in neutral before starting the engine.




- Lock the covers before starting the machine.
- Keep away from rotating and moving objects.
- Keep tools and waste cloth away from rotating and moving objects.

## 5. Preventing fires



- Keep fire (welding sparks, grinding sparks, cigarettes) away from the fuel.
- Wipe the fuel off when spilled.
- Keep fire (welding sparks, grinding sparks, cigarettes) away from the battery. The battery produces oxygen and hydrogen gas that are flammable.
- Make sure to disconnect the negative (-) terminal first when disconnecting the battery cable.
- Make sure to connect the positive (+) terminal first when connecting the battery cable.
- Follow notes on handling diesel particulate filter (DPF).
- Do not make a short-circuit.
- Do not splash the hydraulic oil on the exhaust components.

## 6. Preventing acid burns



IBM008A

- Keep the electrolyte away from your eyes, hands, and clothes. Sulfuric acid in the battery electrolyte is poisonous: it can cause blindness and strong enough to burn your skin and clothing. If you spill electrolyte on yourself, clean yourself with water and get a medical aid immediately.


## 7. Avoiding high pressure fluid



9Y1200165INI019A


- Keep away from high pressure fluids bursting from a hose or pipe. The fluid can penetrate your skin and cause serious injuries.
- Get a medical aid immediately if the accident occurs.

## 8. Avoiding hot exhaust



9Y1200165INI020A

- Avoid skin exposure and contact with hot exhaust gas or components.
- Exhaust gas and components are extremely hot during operation.




2KBTA00065A01

- Do not work immediately after stopping the engine. The engine, muffler, radiator, and hydraulic components are extremely hot.
- Do not remove caps and plugs soon after stopping the engine. The temperature and pressure of the coolant, hydraulic oil, and fuel are still high.

# SAFETY LABELS

RCK60-30BB



(1) Part No. K5112-7311-2



(2) Part No. K5112-7312-2




(3) Part No. K5384-4715-1



1SAPY00009A01enUS

## 1. SAFETY

## RC72-30BB



(1) Part No. K5112-7311-2



(2) Part No. K5384-4715-1



(3) Part No. K5112-7312-2



1SAPY00010A01enUS

## 1. Care of danger, warning and caution labels

- Keep danger, warning and caution labels clean and free from obstructing material.
- Clean danger, warning and caution labels with soap and water, dry with a soft cloth.
- Replace damaged or missing danger, warning and caution labels with new labels.
- If a component with danger, warning and caution label(s) affixed is replaced with new part, make sure new label(s) is (are) attached in the same location(s) as the replaced component.
- Mount new danger, warning and caution labels by applying on a clean dry surface and pressing any bubbles to outside edge.



## **2. GENERAL**

# GENERAL WORKING PRECAUTIONS

- When servicing, observe the safety regulations in the operator's manual and workshop manual.
- Clean the machine before maintenance.
- Before working, remove the negative (-) terminal from the battery or turn off the battery isolator switch.
- Disassemble the machine at a clean location.
- Whenever a special tool is required, use the special tool that Kubota recommends. Or, craft the special tools according to the illustrations in this manual.
- Use genuine Kubota parts to ensure safety and machine performance.




## 1. Tightening bolts and nuts

- Tighten the bolts and nuts with their specified torque.

**NOTE**


- Tighten the bolts and nuts alternately from top to bottom and left to right so the torque is distributed evenly.
- Gradually tighten the bolts and nuts two or three times.



(A) Alternately  
(B) Diagonally  
(C) Diagonally from center to outside

## 2. Applying thread-locking fluid

1. Clean and dry the location where a thread-locking fluid will be applied with a solvent to remove moisture, oil, and dirt.
2. Apply the thread-locking fluid to the tip of the bolt.
3. If the threads are large, apply the thread-locking fluid all around the bolt hole.




(A) Bolt hole (bolts, nuts)      (B) Screw hole


## 3. Installing circlips

- When installing the circlip, assemble the circlip's angular side (3) toward the side that receives force (4) as shown in the figure.

2. GENERAL




(1) Circlip (2) Rounded side (3) Angular side



(4) Side that receives force (5) Force (A) External circlip (B) Internal circlip

4. Installing spring pins

- When installing the spring pin, assemble the slit of the spring pin in the direction that receive force as shown in the figure.




(1) Parallel movement (2) Rotational movement

5. Handling split pin

- Replace split pins with new ones. Insert the split pins: once inserted, the two ends of the pin are bent apart to fix it in place.


- Tighten a grooved nut to the specified torque, align the hole of the split split to the tighten direction and use an S-shaped split.



(A) Single side split (B) Double side split (C) S-shaped split

6. Handling chain joint and split pin

- Assemble the chain joint with its opening facing the opposite direction of travel.
- Assemble the split pin with its opening facing the direction of travel.




(1) Chain joint (2) Split pin (A) Direction of chain moving

7. Handling liquid gasket

- Use the specified liquid gasket.
- When using liquid gasket, fully remove the old gasket and grease or oil.
- When applying liquid gasket, apply it on the joint surface with a thickness of 3.0 to 5.0 mm (0.12 to 0.13 in.) without making any gaps.
- When applying liquid gasket near the bolt hole (2), apply it in the inner side.
- If there is a risk of oil leakage or if the hole goes all the way through when applying liquid gasket near the dowel pin (3) hole, apply it in the inner side.

If there is no concern of oil leakage, apply it on the outer side.

- Reassemble within 15 minutes after applying; wait for 30 minutes or more then fill with oil.




## 8. Replacing O-rings

1. Remove the burr and clean the O-ring groove.
2. Lubricate the O-ring. Do not apply any grease to the floating seal.
3. Put the O-ring in the groove.

**NOTE**

- Do not twist the O-ring.
- Remove the burr to avoid damage on the O-ring caused by the burr.



- (1) O-ring groove  
 (2) O-ring  
 (3) Burr

## 9. Replacing oil seals

1. Do not face the lip of the oil seal in the wrong direction. Face the seal lip toward the material to be sealed.
2. Use a press to install the oil seal until firmly fixed to the boss.


**NOTE**

- In cases when installing an oil seal without a press, place a wooden board on the seal and gently tap the board with a hammer; install the oil seal straightly and evenly.

3. Grease the seal lip and dust lip.

**NOTE**

- If the seal has a dust lip, grease the gap between the lips.
- After oil seals are replaced, grease the moving parts around the lip to prevent the dry surfaces from wearing against each other during engine start up.




- (1) Packing  
 (2) Metal ring  
 (3) Spring  
 (4) Seal lip  
 (5) Grease  
 (6) Dust lip  
 (A) Air side  
 (B) Oil side

## 10. Replacing floating seals

1. Apply oil appropriately to both sides of the O-ring and the contact surface.
2. Do not twist the O-ring when installing the floating seal.
3. Apply oil thinly to the sliding surfaces.
4. Install the floating seal in parallel to the sliding surfaces, O-rings, and housings.
5. After installation, rotate the floating seal for 3 times to make an oil film on the sliding surface.

2. GENERAL



2KBTA00043A01  
(1) Sliding surface (2) O-ring

11. Connecting hydraulic hoses


1. Clean the inside of the hose fittings.
2. Tighten with the specified torque.
3. Apply pressure on the hydraulic hose to check for oil leakage.

12. Wrapping thread seal tape

1. Wrap the thread seal tape around the taper threads two or three turns.
2. Tighten the taper thread with the specified torque.

■ NOTE


- Do not loosen the taper thread after tightening to avoid oil leakage.
- Do not wrap the thread seal tape on the first and second threads to avoid contamination in the hydraulic circuit.



2KBTA00044A01  
(1) Thread seal tape (2) Male thread (3) Female thread (4) Clearance (5) First and second threads from the screw tip

13. Installing elbows with male seat

1. Clean the male seat surface and seal.
2. Loosen the lock-nut until the top end.
3. Install and tighten the elbow by hand until the male seat touches the material surface.




2KBTA00045A01  
(1) Lock-nut (2) Seal (3) Seal

4. Adjust the direction of the elbow.

■ NOTE

- Do not loosen to more than one turn.



5. Tighten the lock-nut with the specified torque.


■ NOTE

- Check for oil leakage.

## GENERAL WORKING PRECAUTIONS

### 14. Connecting and disconnecting quick hose couplings

## 2. GENERAL




2KBTA00047A01

(4) Wrench  
(5) Hose

(6) Torque wrench

### 14. Connecting and disconnecting quick hose couplings

1. Push the metal fittings in the direction of the arrow mark.



2KBTA00048A01

(1) Plastic part

(2) Metal fitting


2. Pull the plastic part in the opposite direction of the arrow mark.
3. Disconnect the quick hose coupling.
4. Push the quick hose coupling in the direction of the arrow mark to connect.
5. Make sure that the hose is installed correctly.

### 15. Handling the battery

#### ⚠ CAUTION

- When removing battery cables, disconnect negative (-) terminal first.
- When installing battery cables, connect positive (+) terminal first.
- Do not install any battery with a capacity (Ah) other than is specified.

- Securely attach the terminal covers on the cables when connecting the cables to the battery terminal posts. There is a danger of short-circuiting if the tip of the cables attached to the battery terminal post is exposed.
- Do not allow dirt and dust to collect on the battery.
- Connect the battery terminals after removing dust, old grease, blue rust and others.
- Apply conductive grease thinly to the battery terminal posts to prevent corrosion.




2KBTA00049A01

(1) Battery negative (-) terminal (2) Battery positive (+) terminal

### 16. Handling wire harness

#### ⚠ CAUTION

- Do not let an unprotected wire harness to come in contact with other components.
- Do not clamp the wire harness to fuel hoses.
- If the wire harness is damaged, replace it immediately with a new one.
- Do not alter the electrical device and wire harness.
- Tighten the electrical terminals securely.




2KBTA00050A01

(A) Good

(B) Bad: Loose bolt


- Check the electrical terminal protection and clamping conditions before connecting the battery cable.

2. GENERAL




(C) Covered completely with a protection cover

- Keep the wire harness away from hazardous positions such as rotating parts or high-temperature sections.




(D) Hazardous position (G) Hazardous position  
(E) Wiring position: bad  
(F) Wiring position: good

- If wire harness is damaged or degraded, replace immediately.




(H) Damaged (I) Torn

- Install the grommet securely.




(1) Grommet (K) Bad: poor installation  
(J) Good

- Clamp the wire harness securely. Do not damage the wire harness by the clamp.
- Clamp the wire harness correctly. Do not slack, twist, and pull.



(2) Wire harness (3) Clamp

- Do not pinch the wire harness when installing parts.




(4) Wire harness (L) Bad

## 17. Handling fuses

- Always use fuses of the specified capacity.
- Do not use steel or copper wiring instead of fuse.
- Do not install work light or radio without auxiliary power line.


- Do not install auxiliaries to the fuses. The fuses may blow.



- (1) Fuse
- (2) Fusible link
- (3) Slow blow fuse


### 18. Handling connectors

- When disconnecting the locking connectors, be sure to disengage the lock before disconnecting. There are two kinds of locks: one requires pressing and the other requires pulling.




- (A) Press

- Hold on tightly to the connectors when disconnecting them.
- Do not pull wire harness itself.




- (B) Good
- (C) Bad

- Make sure the terminal condition of the connectors is not bent, rusty, and so on.
- If the terminal is rusted, remove rust with sandpaper. However, do not polish the terminal of the waterproof connector or the plated terminal.



- (1) Missing terminal
- (2) Bent terminal
- (3) Sandpaper
- (4) Rust


- Cover the female bullet terminals and male bullet terminals securely with the plastic covers.
- Make sure that the bullet terminals are secure and connected securely to the tip.



- (D) Good
- (E) Bad: damaged cover
- (F) Bad: poor connection

2. GENERAL


- Cover the female connectors and male connectors securely with the plastic covers.



(5) Cover (H) Bad: damaged cover  
(G) Good

19. Wiring color

- Wire colors are specified in the color codes.



(1) Wire color (2) Stripe

Wiring Colors	Color code
Black	B
Brown	BR, Br
Green	G
Gray	GY, GR, Gr
Blue	L
Light green	LG, Lg
Orange	OR, Or
Pink	P
Purple	PU, Pu, V
Red	R
Sky blue	SB, Sb
White	W
Yellow	Y

- This symbol of "/" shows color with stripe(s).  
(An example)

**W/R:**

White with red stripe

20. Washing the machine with a high pressure washer


Use a high pressure washer properly to avoid personal injuries and damages to the machine.

**CAUTION**

- Damaged or cut the wire harness may cause fire.
- Damaged hydraulic hoses or oil seals may cause injury due to hydraulic oil gushing out.

**IMPORTANT**

- Water infiltration may cause machine problems.
- Adjust the high pressure washer nozzle for a wide spray. Do not adjust to pencil point spray.
- Spray the water at least 2 m away from the machine.



2KBTA00063A01

- (1) Adjusting the washer power
- (2) Washing distance
- (A) Pencil point spray
- (B) Wide spray
- (C) Less than 2 m (80 in.)
- (D) Over 2 m (80 in.)

## 21. Dispose fluids correctly

- Do not dispose fluids on the ground, down the drain, into a stream, pond, or lake. Obey related environmental protection regulations when you dispose of oil, fuel, coolant, electrolyte, and other dangerous materials.



IBM009A

**2. GENERAL**

---

# TIGHTENING TORQUES

Refer to the following table if the tightening torques of screws, bolts and nuts are not specified in each part.

## 1. General use screws, bolts and nuts

Indication on top of bolt	 <b>4</b> No-grade or 4T						 <b>7</b> 7T						 <b>9</b> 9T		
	Indication on top of nut														
Material of opponent part	Ordinariness			Aluminum			Ordinariness			Aluminum			Ordinariness		
	Unit	N · m	kgf · m	lbf · ft	N · m	kgf · m	lbf · ft	N · m	kgf · m	lbf · ft	N · m	kgf · m	lbf · ft	N · m	kgf · m
M6	7.9 to 9.3	0.80 to 0.95	5.8 to 6.8	7.9 to 8.8	0.80 to 0.90	5.8 to 6.5	9.81 to 11.2	1.00 to 1.15	7.24 to 8.31	7.9 to 8.8	0.80 to 0.90	5.8 to 6.5	12.3 to 14.2	1.25 to 1.45	9.05 to 10.4
M8	18 to 20	1.8 to 2.1	13 to 15	17 to 19	1.7 to 2.0	13 to 14	24 to 27	2.4 to 2.8	18 to 20	18 to 20	1.8 to 2.1	13 to 15	30 to 34	3.0 to 3.5	22 to 25
M10	40 to 45	4.0 to 4.6	29 to 33	32 to 34	3.2 to 3.5	24 to 25	48 to 55	4.9 to 5.7	36 to 41	40 to 44	4.0 to 4.5	29 to 32	61 to 70	6.2 to 7.2	45 to 52
M12	63 to 72	6.4 to 7.4	47 to 53	—	—	—	78 to 90	7.9 to 9.2	58 to 66	63 to 72	6.4 to 7.4	47 to 53	103 to 117	10.5 to 12.0	76.0 to 86.7
M14	108 to 125	11.0 to 12.8	79.6 to 92.5	—	—	—	124 to 147	12.6 to 15.0	91.2 to 108	—	—	—	167 to 196	17.0 to 20.0	123 to 144
M16	167 to 191	17.0 to 19.5	123 to 141	—	—	—	197 to 225	20.0 to 23.0	145 to 166	—	—	—	260 to 304	26.5 to 31.0	192 to 224
M18	246 to 284	25.0 to 29.0	181 to 209	—	—	—	275 to 318	28.0 to 32.5	203 to 235	—	—	—	344 to 402	35.0 to 41.0	254 to 296
M20	334 to 392	34.0 to 40.0	246 to 289	—	—	—	368 to 431	37.5 to 44.0	272 to 318	—	—	—	491 to 568	50.0 to 58.0	362 to 419

## 2. Stud bolts

Material of opponent part	Ordinariness			Aluminum			
	Unit	N · m	kgf · m	lbf · ft	N · m	kgf · m	lbf · ft
M8		12 to 15	1.2 to 1.6	8.7 to 11	8.9 to 11	0.90 to 1.2	6.5 to 8.6
M10		25 to 31	2.5 to 3.2	18 to 23	20 to 25	2.0 to 2.6	15 to 18
M12		30 to 49	3.0 to 5.0	22 to 36	31	3.2	23
M14		62 to 73	6.3 to 7.5	46 to 54	—	—	—
M16		98.1 to 112	10.0 to 11.5	72.4 to 83.1	—	—	—
M18		172 to 201	17.5 to 20.5	127 to 148	—	—	—

### 3. Hydraulic fitting

#### 3.1 Hydraulic hose fittings

Hose size	Thread side	Tightening torque		
		N · m	kgf · m	lbf · ft
02	1/8	13.8 to 15.6	1.40 to 1.60	10.2 to 11.5
03	1/4	22.6 to 27.4	2.30 to 2.80	16.7 to 20.2
04				
05	3/8	45.2 to 52.9	4.60 to 5.40	33.3 to 39.0
06				

#### 3.2 Hydraulic pipe cap nuts

Pipe size	Tightening torque		
	N · m	kgf · m	lbf · ft
φ4 × t1.0	19.7 to 29.4	2.00 to 3.00	14.5 to 21.6
φ6 × t1.0	24.6 to 34.3	2.50 to 3.50	18.1 to 25.3
φ8 × t1.0	29.5 to 39.2	3.00 to 4.00	21.7 to 28.9
φ10 × t1.0	39.3 to 49.0	4.00 to 5.00	29.0 to 36.1
φ12 × t1.5	49.1 to 68.6	5.00 to 7.00	36.2 to 50.6
φ15 × t1.6	108 to 117	11.0 to 12.0	79.6 to 86.7
φ18 × t1.6	108 to 117	11.0 to 12.0	79.6 to 86.7

#### 3.3 Adapters, elbows and others

Item	Thread side	Tightening torque		
		N · m	kgf · m	lbf · ft
Fitting with O-ring	G 1/8	45 to 53	4.5 to 5.5	33 to 39
	G 1/4	74 to 83	7.5 to 8.5	55 to 61
	G 3/8	93.2 to 102	9.50 to 10.5	68.8 to 75.9
	G 1/2	113 to 122	11.5 to 12.5	83.2 to 90.4
Elbow with O-ring	G 1/8	23 to 26	2.3 to 2.7	17 to 19
	G 1/4	36 to 43	3.6 to 4.4	26 to 31
	G 3/8	54 to 63	5.5 to 6.5	40 to 47
	G 1/2	73 to 83	7.4 to 8.5	54 to 61
Adapter	G 1/8	9.8 to 14	1.0 to 1.5	7.3 to 10
	G 1/4	30 to 34	3.0 to 3.5	22 to 25
	G 3/8	49 to 68	5.0 to 7.0	37 to 50
	G 1/2	69 to 88	7.0 to 9.0	51 to 65

## 4. Metric screws, bolts and nuts

Grade	8.8 Property class 8.8			10.9 Property class 10.9		
	N · m	kgf · m	lbf · ft	N · m	kgf · m	lbf · ft
M8	24 to 27	2.4 to 2.8	18 to 20	30 to 34	3.0 to 3.5	22 to 25
M10	48 to 55	4.9 to 5.7	36 to 41	61 to 70	6.2 to 7.2	45 to 52
M12	78 to 90	7.9 to 9.2	58 to 66	103 to 117	10.5 to 12.0	76.0 to 86.7
M14	124 to 147	12.6 to 15.0	91.2 to 108	167 to 196	17.0 to 20.0	123 to 144
M16	197 to 225	20.0 to 23.0	145 to 166	260 to 304	26.5 to 31.0	192 to 224

## 5. American standard screws, bolts and nuts with UNC or UNF threads

Grade	SAE GR.5			SAE GR.8		
	N · m	kgf · m	lbf · ft	N · m	kgf · m	lbf · ft
1/4	11.7 to 15.7	1.20 to 1.60	8.63 to 11.5	16.3 to 19.7	1.67 to 2.00	12.0 to 14.6
5/16	23.1 to 27.7	2.36 to 2.82	17.0 to 20.5	33 to 39	3.4 to 3.9	25 to 28
3/8	48 to 56	4.9 to 5.7	36 to 41	61 to 73	6.3 to 7.4	45 to 53
1/2	110 to 130	11.3 to 13.2	81.2 to 95.8	150 to 178	15.3 to 18.1	111 to 131
9/16	150 to 178	15.3 to 18.1	111 to 131	217 to 260	22.2 to 26.5	160 to 191
5/8	204 to 244	20.8 to 24.8	151 to 179	299 to 357	30.5 to 36.4	221 to 263

## 6. Plugs

Shape	Size	Material of opponent part					
		Ordinariness			Aluminum		
		N · m	kgf · m	lbf · ft	N · m	kgf · m	lbf · ft
 Tapered screw	R1/8	13 to 21	1.3 to 2.2	9.4 to 15	13 to 19	1.3 to 2.0	9.4 to 14
	R1/4	25 to 44	2.5 to 4.5	18 to 32	25 to 34	2.5 to 3.5	18 to 25
	R3/8	49 to 88	5.0 to 9.0	37 to 65	49 to 58	5.0 to 6.0	37 to 43
	R1/2	58.9 to 107	6.00 to 11.0	43.4 to 79.5	59 to 78	6.0 to 8.0	44 to 57
 Straight screw	G1/4	25 to 34	2.5 to 3.5	18 to 25	—	—	—
	G3/8	62 to 82	6.3 to 8.4	46 to 60	—	—	—
	G1/2	49 to 88	5.0 to 9.0	37 to 65	—	—	—

