

Product: Kubota BX1860 BX2360 BX2660 RCK48 RCK54 RCK60 LA203 LA243 Service Manual  
Full Download: <https://www.arepairmanual.com/downloads/kubota-bx1860-bx2360-bx2660-rck48-rck54-rck60-la203-la243-service-manual/>

# WSM

---

WORKSHOP MANUAL  
TRACTOR, MOWER,  
FRONT LOADER

**BX1860, BX2360, BX2660,  
RCK48-18BX, RCK54-23BX,  
RCK60B-23BX, RCK48P-18BX,  
RCK54P-23BX, LA203, LA243**

---

**Kubota**

KiSC issued 08, 2019 A

Sample of manual. Download All 396 pages at:

<https://www.arepairmanual.com/downloads/kubota-bx1860-bx2360-bx2660-rck48-rck54-rck60-la203-la243>

## TO THE READER

This Workshop Manual has been prepared to provide servicing personnel with information on the mechanism, service and maintenance of KUBOTA Tractor BX1860, BX2360, BX2660, KUBOTA Rotary Mower RCK48-18BX, RCK54-23BX, RCK60B-23BX, RCK48P-18BX, RCK54P-23BX and KUBOTA Front Loader LA203, LA243. It is divided into three parts, "General", "Mechanism" and "Servicing" for each section.

### ■ General

Information on the tractor identification, the general precautions, maintenance check list, check and maintenance and special tools are described.

### ■ Mechanism

Information on the construction and function are included. This part should be understood before proceeding with troubleshooting, disassembling and servicing.

Refer to Diesel Engine / Tractor Mechanism Workshop Manual (Code No. 9Y021-01875 / 9Y021-18201) for the one which has not been described to this workshop manual.

### ■ Servicing

Information on the troubleshooting, servicing specification lists, tightening torque, checking and adjusting, disassembling and assembling and servicing which cover procedures, precautions, factory specifications and allowable limits.

All information illustrations and specifications contained in this manual are based on the latest product information available at the time of publication.

The right is reserved to make changes in all information at any time without notice.

August 2008

© KUBOTA Corporation 2008

**Record of Revisions**

For pdf, use search function {Search word} to find all the revised locations.

<b>Last digit of the Code No.</b>	<b>Month of Revision</b>	<b>Main Revised Point and Corrective Measures {Search word}</b>	<b>Reference Page</b>
<b>2</b>	2013.05	Add a special tool information and correction. {Valve Guide Replacing Tool, Check and High Pressure Relief Valve Assembly Tool}	G-35, G-43 and others
<b>3</b>	2019.08	Changed checking hydraulic pump oil flow	5-S5, 5-S6



## SAFETY FIRST

This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully.

It is essential that you read the instructions and safety regulations before you attempt to repair or use this unit.



### DANGER

: Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



### WARNING

: Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



### CAUTION


: Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

### ■ IMPORTANT

: Indicates that equipment or property damage could result if instructions are not followed.

### ■ NOTE

: Gives helpful information.




### BEFORE SERVICING AND REPAIRING

- Read all instructions and safety instructions in this manual and on your machine safety decals.
- Clean the work area and machine.
- Park the machine on a firm and level ground, and set the parking brake.
- Lower the implement to the ground.
- Stop the engine, and remove the key.
- Disconnect the battery negative cable.
- Hang a "DO NOT OPERATE" tag in operator station.





**SAFETY STARTING**


- Do not start the engine by shorting across starter terminals or bypassing the safety start switch.
- Do not alter or remove any part of machine safety system.
- Before starting the engine, make sure that all shift levers are in neutral positions or in disengaged positions.
- Never start the engine while standing on ground. Start the engine only from operator's seat.



**SAFETY WORKING**

- Do not work on the machine while under the influence of alcohol, medication, or other substances or while fatigued.
- Wear close fitting clothing and safety equipment appropriate to the job.
- Use tools appropriate to the work. Makeshift tools, parts, and procedures are not recommended.
- When servicing is performed together by two or more persons, take care to perform all work safely.
- Do not work under the machine that is supported solely by a jack. Always support the machine by safety stands.
- Do not touch the rotating or hot parts while the engine is running.
- Never remove the radiator cap while the engine is running, or immediately after stopping. Otherwise, hot water will spout out from radiator. Only remove radiator cap when cool enough to touch with bare hands. Slowly loosen the cap to first stop to relieve pressure before removing completely.
- Escaping fluid (fuel or hydraulic oil) under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting hydraulic or fuel lines. Tighten all connections before applying pressure.
- Do not open high-pressure fuel system. High-pressure fluid remaining in fuel lines can cause serious injury. Do not disconnect or attempt repair fuel lines, sensors, or any other components between the high-pressure fuel pump and injectors on engines with high pressure common rail fuel system.
- High voltage exceeding 100 V is generated in the ECU, and is applied to the injector. Pay sufficient caution to electric shock when performing work activities.






**AVOID FIRES**

- Fuel is extremely flammable and explosive under certain conditions. Do not smoke or allow flames or sparks in your working area.
- To avoid sparks from an accidental short circuit, always disconnect the battery negative cable first and connect it last.
- Battery gas can explode. Keep sparks and open flame away from the top of battery, especially when charging the battery.
- Make sure that no fuel has been spilled on the engine.



**VENTILATE WORK AREA**

- If the engine must be running to do some work, make sure the area is well ventilated. Never run the engine in a closed area. The exhaust gas contains poisonous carbon monoxide.




**PREVENT ACID BURNS**

- Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, clothing and cause blindness if splashed into eyes. Keep electrolyte away from eyes, hands and clothing. If you spill electrolyte on yourself, flush with water, and get medical attention immediately.



**DISPOSE OF FLUIDS PROPERLY**

- Do not pour fluids into the ground, down a drain, or into a stream, pond, or lake. Observe relevant environmental protection regulations when disposing of oil, fuel, coolant, electrolyte and other harmful waste.



**PREPARE FOR EMERGENCIES**

- Keep a first aid kit and fire extinguisher handy at all times.
- Keep emergency numbers for doctors, ambulance service, hospital and fire department near your telephone.

# SAFETY DECALS

The following safety decals are installed on the machine.

If a decal becomes damaged, illegible or is not on the machine, replace it. The decal part number is listed in the parts list.

(1) Part No. K2581-6557-1



**WARNING**  
TO AVOID PERSONAL INJURY OR DEATH FROM ROLL-OVER

1 Kubota recommends the use of a Roll-Over Protective Structures (ROPS) and seat belt in almost all applications.  
2 Remove the ROPS only when it substantially interferes with operation or itself presents a safety risk. (Examples include work in orchards and vineyards.)

ALWAYS REINSTALL IT BEFORE USING THE TRACTOR IN OTHER APPLICATIONS.  
3 Never use just the seat belt or just the ROPS. They must be used together. For further details, consult your Operator's Manual or your local dealer.

1AGAJAXAP041E

(2) Part No. K2581-6548-1

**CAUTION**

**TO AVOID PERSONAL INJURY:**

1. Read and understand the operator's manual before operation.
2. Before starting the engine, make sure that everyone is at a safe distance from the tractor and that the PTO is OFF.
3. Do not allow passengers on the tractor at any time.
4. Before allowing other people to use the tractor, have them read the operator's manual.
5. Check the tightness of all nuts and bolts regularly.
6. Keep all shields in place and stay away from all moving parts.
7. Slow down for turns, or rough roads.
8. On public roads use SMV emblem and hazard lights, if required by local traffic and safety regulations.
9. Pull only from the hitch.
10. Before dismounting, lower the implement to the ground, set the parking brake, stop the engine and remove the key.
11. Securely support tractor and implements before working underneath.

1AGAJAXAP042E

(5) Part No. K2581-6549-1

Diesel fuel only



1AGAMAAAP2480

(3) Part No. 6C140-4746-1

**WARNING**

**TO AVOID PERSONAL INJURY:**

Do not modify or repair a ROPS because welding, grinding, drilling or cutting any portion may weaken the structure.

1AGAJAXAP045E



(4) Part No. K2581-6552-1

Do not put hands under the rear fender.

**WARNING**

**TO AVOID PERSONAL INJURY: KEEP HANDS AWAY FROM PINCH POINTS OF LIFT ARMS.**

1AGAJAXAP047E



3TAAAFCP003A

(1) Part No. K2581-6554-1

	<b>⚠ WARNING</b>
	<p><b>TO AVOID PERSONAL INJURY:</b></p> <ol style="list-style-type: none"> <li>1. Keep PTO shield in place at all times.</li> <li>2. Do not operate the PTO at speeds faster than the speed recommended by the implement manufacturer.</li> <li>3. For trailing PTO-driven implements, set hitch at towing position. (see operator's manual)</li> </ol>

1AGA JAXAP044E

(2) Part No. K2581-6555-1


<b>⚠ CAUTION</b>	
<p><b>TO AVOID PERSONAL INJURY FROM SEPARATION:</b></p>	
	<p>GROOVE →</p> 
<p>← GROOVE</p>	
<p><b>DO NOT EXTEND LIFT ROD BEYOND THE GROOVE ON THE THREADED ROD.</b></p>	

1AGA JAXAP043E

(3) Part No. K2581-6556-1


<b>⚠ WARNING</b>
<p><b>TO AVOID PERSONAL INJURY:</b></p> <ol style="list-style-type: none"> <li>1. Attach pulled or towed loads to the hitch only.</li> <li>2. Use the 3-point hitch only with equipment designed for 3-point hitch usage.</li> </ol>

1AGA JAXAP046E




3TAAAKCP001A

(1) Part No. K2581-6541-1




1AGAJAXAP048E

(2) Part No. K2581-6542-1  
Do not touch hot surface like muffler, etc.





1AGAJAXAP050E

(3) Part No. K2581-6543-1  
Stay clear of engine fan and fanbelt.




1AGAJAXAP052E



3TAAAAICP004A

(1) Part No. K2561-6115-1




1AGAJAXAP053E

(2) Part No. K2561-6116-1



1AGAJAXAP054E



**CARES FOR SAFETY ALERT LABELS**

1. Always keep the labels clean and avoid damaging them.  
If a label is dirty, clean it with soap and water. Then wipe it with a soft cloth.  
Never use a solvent like thinner or acetone, which may erase letters or symbols.
2. When you wash the machine using a high pressure washer, do not pour high pressure water directly on any label to prevent it from peeling off.
3. If any label is damaged or missing, place an order with your dealer for replacement.
4. Before you affix a new label, completely clean the surface on which the label is placed. Wait until the surface is dry, and then affix the label in its place.
5. When you replace any part carrying a label, replace the label with a new one at the same time.

3TAAAF006A

# SPECIFICATIONS

Model		BX1860	BX2360	BX2660
PTO power		10.2 kW (13.7 HP)*	13.2 kW (17.7 HP)*	14.5 kW (19.5 HP)*
Engine	Maker	KUBOTA		
	Model	D722-E3-BX-2	D902-E3-BX-2	D1005-E3-BX
	Type	Indirect Injection, vertical, water-cooled, 4-cycle diesel		
	Number of cylinders	3		
	Bore and stroke	67 × 68 mm (2.64 × 2.68 in.)	72 × 73.6 mm (2.83 × 2.90 in.)	76 × 73.6 mm (2.99 × 2.90 in.)
	Total displacement	719 cm <sup>3</sup> (43.9 cu.in.)	898 cm <sup>3</sup> (54.8 cu.in.)	1001 cm <sup>3</sup> (61.1 cu.in.)
	Engine gross power	13.4 kW (18.0 HP)	17.1 kW (23.0 HP)	19.0 kW (25.5 HP)
	Rated revolution	3200 min <sup>-1</sup> (rpm)		
	Maximum torque	44.9N·m (4.6kgf·m, 33.1 lbf·ft)	56.1 N·m (5.7kgf·m, 41.4lbf·ft)	60.2 N·m (6.1 kgf·m, 44.4 lbf·ft)
	Battery	12 V, RC : 62 min., CCA : 435 A	12 V, RC : 80 min., CCA : 535 A	
	Fuel	Diesel fuel No. 1 [below -10 °C (14 °F)], Diesel fuel No. 2 [above -10 °C (14 °F)]		
Capacities	Fuel tank	25 L (6.6 U.S.gals, 5.5 Imp.gals.)		
	Engine crankcase (with filter)	2.9 L (3.1 U.S.qts., 2.6 Imp.qts.)	3.1 L (3.3 U.S.qts., 2.7 Imp.qts.)	3.5 L (3.7 U.S.qts., 3.1 Imp.qts.)
	Engine coolant	2.5 L (2.6 U.S.qts., 2.2 Imp.qts.)	2.7 L (2.8 U.S.qts., 2.4 Imp.qts.)	2.9 L (3.1 U.S.qts., 2.6 Imp.qts.)
	Recovery tank	0.4 L (0.4 U.S.qts., 0.4 Imp.qts.)		
	Transmission case	11.6 L (3.06 U.S.gals, 2.55 Imp.gals.)		
Dimensions	Overall length (without 3P)	2035 mm (80.1 in.)	2120 mm (83.5 in.)	
	Overall length (with 3P)	2340 mm (92.1 in.)	2425 mm (95.5 in.)	
	Overall width (min. tread)	1145 mm (45.1 in.)		
	Overall height (with ROPS)	1760 mm (69.3in.)	1785 mm (70.3 in.)	
	Overall height (Top of seat)	1230 mm (48.4 in.)	1255 mm (49.4 in.)	1330 mm (52.4 in.)
	Wheel base	1340 mm (52.8 in.)	1400 mm (55.1 in.)	
	Minimum ground clearance	150 mm (5.9 in.)	175 mm (6.9 in.)	
Tread	Front	880 mm (34.6 in.)	910 mm (35.8 in.)	
	Rear	820 mm (32.2 in.)		
Weight (with ROPS)	570 kg (1256.6 lbs)	585 kg (1289.7 lbs)	636 kg (1402.1 lbs)	
Clutch	N / A			
Travelling system	Tires	Front	16 × 7.50 – 8	18 × 8.50 – 10
		Rear	24 × 12.00 – 12	26 × 12.00 – 12
	Steering	Hydrostatic type power steering		
	Transmission	Main: hydrostatic transmission, High-Low gear shift (2 forward and 2 reverse)		
	Brake	Wet disk type		
Min. turning radius (without brake)	2.18 m (7.15 feet)	2.3 m (7.5 feet)		
Hydraulic system	Hydraulic control system	Directional control, auto-return lever system		
	Pump capacity	23.5 L/min. (6.2 U.S.gals./min., 5.2 Imp.gals./min.)		
	Three point hitch	SAE Category I		
	Max. lift force	At lift points	5390 N (1210 lbs)**	
24 in. behind lift points		3040 N (680 lbs)**		
PTO	Rear PTO	PTO shaft	SAE 1-3/8, 6 splines	
		Revolution	1 speed (540 min <sup>-1</sup> (rpm) at engine 3142 min <sup>-1</sup> (rpm))	
	Mid	PTO shaft	USA No. 5 (KUBOTA 10-tooth) involute spline	
		Revolution	1 speed (2500 min <sup>-1</sup> (rpm) at engine 3043 min <sup>-1</sup> (rpm))	

NOTE: \* Manufacture's estimate The company reserves the right to change the specifications without notice.

\*\* See and check "IMPLEMENT LIMITATIONS".

W1028103

# TRAVELING SPEEDS


(At rated engine rpm)

Model		BX1860		BX2360 BX2660	
Tire size (Rear)		24 × 12.00 – 12		26 × 12.00 – 12	
	Range gear shift lever	km/h	mph	km/h	mph
Forward	Low	0 to 5.5	0 to 3.4	0 to 6.0	0 to 3.7
	High	0 to 12.0	0 to 7.5	0 to 13.0	0 to 8.1
Reverse	Low	0 to 4.5	0 to 2.5	0 to 4.5	0 to 2.8
	High	0 to 9.0	0 to 5.6	0 to 10.0	0 to 6.2

The company reserves the right to change the specifications without notice.

W1035065

# DIMENSIONS



3TAAAFP005E

# **G GENERAL**

# GENERAL

## CONTENTS

1. TRACTOR IDENTIFICATION .....	G-1
[1] SERIAL NUMBER.....	G-1
[2] CYLINDER NUMBER .....	G-1
2. GENERAL PRECAUTIONS.....	G-2
3. HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING..	G-3
[1] WIRING.....	G-3
[2] BATTERY.....	G-5
[3] FUSE.....	G-5
[4] CONNECTOR.....	G-5
[5] HANDLING OF CIRCUIT TESTER.....	G-6
4. LUBRICANTS, FUEL AND COOLANT .....	G-7
5. TIGHTENING TORQUES .....	G-9
[1] GENERAL USE SCREWS, BOLTS AND NUTS.....	G-9
[2] STUD BOLTS.....	G-9
[3] AMERICAN STANDARD SCREWS, BOLTS AND NUTS WITH UNC OR UNF THREADS .....	G-10
[4] PLUGS .....	G-10
6. MAINTENANCE CHECK LIST.....	G-11
7. CHECK AND MAINTENANCE.....	G-12
[1] DAILY CHECK.....	G-12
[2] CHECK POINTS OF INITIAL 50 HOURS.....	G-13
[3] CHECK POINTS OF EVERY 50 HOURS.....	G-15
[4] CHECK POINTS OF EVERY 100 HOURS.....	G-17
[5] CHECK POINTS OF EVERY 200 HOURS.....	G-22
[6] CHECK POINTS OF EVERY 400 HOURS.....	G-24
[7] CHECK POINT OF EVERY 500 HOURS .....	G-25
[8] CHECK POINT OF EVERY 800 HOURS .....	G-25
[9] CHECK POINT OF EVERY 1500 HOURS .....	G-25
[10]CHECK POINT OF EVERY 3000 HOURS .....	G-25
[11]CHECK POINT OF EVERY 1 YEAR.....	G-25
[12]CHECK POINTS OF EVERY 2 YEARS.....	G-26
[13]OTHERS .....	G-30
8. SPECIAL TOOLS.....	G-32
[1] SPECIAL TOOLS FOR ENGINE .....	G-32
[2] SPECIAL TOOLS FOR TRACTOR.....	G-39
9. TIRES.....	G-44
[1] TIRE PRESSURE .....	G-44
[2] WHEEL TREAD .....	G-45
(1) Front Wheels.....	G-45
(2) Rear Wheels .....	G-46
[3] BALLAST .....	G-47
(1) Front Ballast.....	G-47
(2) Rear Ballast .....	G-48
10. IMPLEMENT LIMITATIONS.....	G-49




# 1. TRACTOR IDENTIFICATION

## [1] SERIAL NUMBER

When contacting your local KUBOTA distributor, always specify engine serial number, tractor serial number and hour meter reading.

- (1) Tractor Identification Plate
- (2) Tractor Serial Number
- (3) Engine Serial Number
- (4) Hour Meter

W1010590




## [2] CYLINDER NUMBER


The cylinder numbers of KUBOTA diesel engine are designated as shown in the figure.

The sequence of cylinder numbers is given as No.1, No.2 and No.3 starting from the gear case side.

W1011077



## 2. GENERAL PRECAUTIONS




- During disassembly, carefully arrange removed parts in a clean area to prevent confusion later. Screws, bolts and nuts should be installed in their original position to prevent reassembly errors.
- When special tools are required, use KUBOTA genuine special tools. Special tools which are not frequently used should be made according to the drawings provided.
- Before disassembling or servicing electrical wires, always disconnect the ground cable from the battery first.
- Remove oil and dirt from parts before measuring.
- Use only KUBOTA genuine parts for parts replacement to maintain machine performance and to assure safety.
- Gaskets and O-rings must be replaced during reassembly. Apply grease to new O-rings or oil seals before assembling. See the figure left side.
- When reassembling external snap rings or internal snap rings, they must be positioned so that sharp edge faces against the direction from which a force is applied. See the figure left side.
- When inserting spring pins, their splits must face the direction from which a force is applied. See the figure left side.
- To prevent damage to the hydraulic system, use only specified fluid or equivalent.

- (1) Grease
- (2) Force
- (3) Sharp Edge
- (4) Axial Force
- (5) Rotating Movement

- (A) External Snap Ring
- (B) Internal Snap Ring

W10109040

### 3. HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING



To ensure safety and prevent damage to the machine and surrounding equipment, heed the following precautions in handling electrical parts and wiring.


**■ IMPORTANT**

- Check electrical wiring for damage and loosened connection every year. To this end, educate the customer to do his or her own check and at the same time recommend the dealer to perform periodic check for a fee.
- Do not attempt to modify or remodel any electrical parts and wiring.
- When removing the battery cables, disconnect the negative cable first. When installing the battery cables, connect the positive cable first.

(1) Negative Terminal (2) Positive Terminal

W10111140


#### [1] WIRING



- Securely tighten wiring terminals.

(1) Correct (Securely Tighten) (2) Incorrect (Loosening Leads to Faulty Contact)


W10112160



- Do not let wiring contact dangerous part.

(1) Dangerous Part (2) Wiring (Incorrect) (3) Wiring (Correct) (4) Dangerous Part


W10113130



- Securely insert grommet.


(1) Grommet (A) Correct (B) Incorrect

W10113880



- Securely clamp, being careful not to damage wiring.
- |                       |                  |
|-----------------------|------------------|
| (1) Clamp             | (3) Clamp        |
| • Wind Clamp Spirally | (4) Welding Dent |
| (2) Wire Harness      |                  |


W10114580



- Clamp wiring so that there is no twist, unnecessary sag, or excessive tension, except for movable part, where sag be required.

- |            |               |
|------------|---------------|
| (1) Wiring | (A) Correct   |
| (2) Clamp  | (B) Incorrect |


W10115870



- In installing a part, take care not to get wiring caught by it.

- |            |               |
|------------|---------------|
| (1) Wiring | (A) Incorrect |
|------------|---------------|

W10116700




- After installing wiring, check protection of terminals and clamped condition of wiring, only connect battery.

- |           |                          |
|-----------|--------------------------|
| (1) Cover | • Securely Install Cover |
|-----------|--------------------------|

W10117350

## [2] BATTERY




- Take care not to confuse positive and negative terminal posts.
- When removing battery cables, disconnect negative cable first. When installing battery cables, check for polarity and connect positive cable first.
- Do not install any battery with capacity other than is specified (Ah).
- After connecting cables to battery terminal posts, apply high temperature grease to them and securely install terminal covers on them.
- Do not allow dirt and dust to collect on battery.

### **!** CAUTION

- Take care not to let battery liquid spill on your skin and clothes. If contaminated, wash it off with water immediately.
- Before recharging the battery, remove it from the machine.
- Before recharging, remove cell caps.
- Do recharging in a well-ventilated place where there is no open flame nearby, as hydrogen gas and oxygen are formed.

W10118160

## [3] FUSE




- Use fuses with specified capacity. Neither too large or small capacity fuse is acceptable.
- Never use steel or copper wire in place of fuse.
- Do not install working light, radio set, etc. on machine which is not provided with reserve power supply.
- Do not install accessories if fuse capacity of reserve power supply is exceeded.

(1) Fuse

(2) Slow Blow Fuse

W10120920


## [4] CONNECTOR



- For connector with lock, push lock to separate.

(A) Push

W10122110




- In separating connectors, do not pull wire harnesses.
- Hold connector bodies to separate.

(A) Correct

(B) Incorrect


W10122720



- Use sandpaper to remove rust from terminals.
- Repair deformed terminal. Make certain there is no terminal being exposed or displaced.

(1) Exposed Terminal (3) Sandpaper  
 (2) Deformed Terminal (4) Rust


W10123460



- Make certain that there is no female connector being too open.

(A) Correct (B) Incorrect

W10124300




- Make certain plastic cover is large enough to cover whole connector.

(1) Cover (A) Correct (B) Incorrect

W10125190

**[5] HANDLING OF CIRCUIT TESTER**



- Use tester correctly following manual provided with tester.
- Check for polarity and range.

W10126840

## 4. LUBRICANTS, FUEL AND COOLANT

No.	Place	Capacity			Lubricants, fuel and coolant
		BX1860	BX2360	BX2660	
1	Fuel tank	25.0 L 6.6 U.S.gals 5.5 Imp.gals			No. 2-D diesel fuel No. 1-D diesel fuel if temperature is below -10 °C (14 °F)
2	Cooling system with recovery tank	2.9 L 3.1 U.S.qts 2.6 Imp.qts	3.1 L 3.3 U.S.qts 2.7 Imp.qts	3.3 L 3.5 U.S.qts 2.9 Imp.qts	Fresh clean water with anti-freeze
3	Engine crankcase	2.9 L 3.1 U.S.qts 2.6 Imp.qts	3.1 L 3.3 U.S.qts 2.7 Imp.qts	3.5 L 3.7 U.S.qts 3.1 Imp.qts	Engine oil : API Service Classification CF or better Below 0 °C (32 °F) : SAE10W, 10W-30 or 15W-40 0 to 25 °C (32 to 77 °F): SAE20, 10W-30 or 15W-40 Above 25 °C (77 °F): SAE30, 10W-30 or 15W-40
4	Transmission case	11.6 L 3.1 U.S.gals 2.6 Imp.gals			KUBOTA SUPER UDT fluid*
5	Front axle case	2.3 L 2.4 U.S.qts 2.0 Imp.qts	4.7 L 5.0 U.S.qts 4.1 Imp.qts		KUBOTA SUPER UDT fluid or SAE80, SAE90 gear oil
<b>Greasing</b>					
	Place	No. of greasing point		Capacity	Type of grease
6	Battery terminal	2		Moderate amount	Multipurpose type Grease NLGI-2 or NLGI-1 (GC-LG)
7	Speed control pedal	1		Until grease overflows	

\* KUBOTA original transmission hydraulic fluid.

■ **NOTE**

● **Engine Oil :**

- Oil used in the engine should have an American Petroleum Institute (API) service classification and Proper SAE Engine Oil according to the ambient temperature as shown above.
- With the emission control now in effect, the CF-4 and CG-4 lubricating oils have been developed for use of a low-sulfur fuel on on-road vehicle engines. When an off-road vehicle engine runs on a high-sulfur fuel, it is advisable to employ the "CF or better" lubricating oil with a high Total Base Number (TBN). **If the "CF-4 or CG-4, CH-4 or CI-4" lubricating oil is used with a high-sulfur fuel, change the lubricating oil at shorter intervals. (approximately half)**
- Lubricating oil recommended when a low-sulfur or high-sulfur fuel is employed.

○ : Recommendable    X : Not Recommendable

Lubricating oil class	Fuel		Remark
	Low-sulfur	High-sulfur	
CF	○	○	TBN ≥ 10
CF-4	○☆	X	
CG-4	○☆	X	
CH-4	○☆	X	
CI-4	○	X	

- ☆ Class CF-4, CG-4 and CH-4 engine oils cannot be used on EGR (Exhaust Gas Re-circulation) type engines.
- The CJ-4 engine oil is intended for DPF (Diesel Particulate Filter) type engines, and cannot be used on this tractor.

● **Fuel :**

- Cetane number of 45 minimum. Cetane number greater than 50 is preferred, especially for temperatures below – 20 °C (–4 °F) or elevations above 1500 m (5000 ft).
- If diesel fuel with sulfur content greater than 0.5 % sulfur content is used, reduce the service interval for engine oil and filter by 50 %.
- Do not use diesel fuel with sulfur content greater than 1.0 %.
- Diesel fuels specified to EN 590 or ASTM D975 are recommended.
- No. 2-D is distillate fuel of lower volatility for engines in industrial and heavy mobile service. (SAE J313 JUN87)
- Since this engine adopts EPA Tier 4 and Interim Tier 4 standards, the use of low sulfur fuel or ultra low sulfur fuel is mandatory in EPA regulated area (North America). Therefore, please use No. 2-D S500 or S15 diesel fuel as an alternative to No. 2-D, or use No. 1-D S500 or S15 diesel fuel as an alternative to No. 1-D if outside air temperature is below –10 °C (14 °F)

● **Transmission Oil :**

- The oil used to lubricate the transmission is also used as hydraulic fluid. To insure proper operation of the hydraulic system and to complete lubrication of the transmission, it is important that a multi-grade transmission fluid is used in this system. We recommend the use of **KUBOTA UDT or SUPER UDT fluid** for optimum protection and performance.  
Do not mix different brands together.
- Indicated capacities of water and oil are manufacture's estimate.

## 5. TIGHTENING TORQUES

### [1] GENERAL USE SCREWS, BOLTS AND NUTS

Screws, bolts and nuts whose tightening torques are not specified in this Workshop Manual should be tightened according to the table below.

Indication on top of bolt	④ No-grade or 4T						⑦ 7T						⑨ 9T		
Material of bolt	SS400, S20C						S43C, S48C						SCr435, SCM435		
Material of opponent part	Ordinariness			Aluminum			Ordinariness			Aluminum			Ordinariness		
Unit															
Diameter	N-m	kgf-m	lbf-ft	N-m	kgf-m	lbf-ft	N-m	kgf-m	lbf-ft	N-m	kgf-m	lbf-ft	N-m	kgf-m	lbf-ft
<b>M6</b> (6 mm, 0.24 in.)	7.9	0.80	5.8	7.9	0.80	5.8	9.81	1.00	7.24	7.9	0.80	5.8	12.3	1.25	9.05
	to 9.3	to 0.95	to 6.8	to 8.8	to 0.90	to 6.5	to 11.2	to 1.15	to 8.31	to 8.8	to 0.90	to 6.5	to 14.2	to 1.45	to 10.4
<b>M8</b> (8 mm, 0.31 in.)	18	1.8	13	17	1.7	13	24	2.4	18	18	1.8	13	30	3.0	22
	to 20	to 2.1	to 15	to 19	to 2.0	to 14	to 27	to 2.8	to 20	to 20	to 2.1	to 15	to 34	to 3.5	to 25
<b>M10</b> (10 mm, 0.39 in.)	40	4.0	29	32	3.2	24	48	4.9	36	40	4.0	29	61	6.2	45
	to 45	to 4.6	to 33	to 34	to 3.5	to 25	to 55	to 5.7	to 41	to 44	to 4.5	to 32	to 70	to 7.2	to 52
<b>M12</b> (12 mm, 0.47 in.)	63	6.4	47	-	-	-	78	7.9	58	63	6.4	47	103	10.5	76.0
	to 72	to 7.4	to 53	-	-	-	to 90	to 9.2	to 66	to 72	to 7.4	to 53	to 117	to 12.0	to 86.7
<b>M14</b> (14 mm, 0.55 in.)	108	11.0	79.6	-	-	-	124	12.6	91.2	-	-	-	167	17.0	123
	to 125	to 12.8	to 92.5	-	-	-	to 147	to 15.0	to 108	-	-	-	to 196	to 20.0	to 144
<b>M16</b> (16 mm, 0.63 in.)	167	17.0	123	-	-	-	197	20.0	145	-	-	-	260	26.5	192
	to 191	to 19.5	to 141	-	-	-	to 225	to 23.0	to 166	-	-	-	to 304	to 31.0	to 224
<b>M18</b> (18 mm, 0.71 in.)	246	25.0	181	-	-	-	275	28.0	203	-	-	-	344	35.0	254
	to 284	to 29.0	to 209	-	-	-	to 318	to 32.5	to 235	-	-	-	to 402	to 41.0	to 296
<b>M20</b> (20 mm, 0.79 in.)	334	34.0	246	-	-	-	368	37.5	272	-	-	-	491	50.0	362
	to 392	to 40.0	to 289	-	-	-	to 431	to 44.0	to 318	-	-	-	to 568	to 58.0	to 419

W1034542

### [2] STUD BOLTS

Material of opponent part	Ordinariness			Aluminum		
Unit						
Diameter	N-m	kgf-m	lbf-ft	N-m	kgf-m	lbf-ft
<b>M8</b> (8 mm, 0.31 in.)	12	1.2	8.7	8.9	0.90	6.5
	to 15	to 1.6	to 11	to 11	to 1.2	to 8.6
<b>M10</b> (10 mm, 0.39 in.)	25	2.5	18	20	2.0	15
	to 31	to 3.2	to 23	to 25	to 2.6	to 18
<b>M12</b> (12 mm, 0.47 in.)	29.5	3.0	21.7	-	-	-
	to 49.0	to 5.0	to 36.1	31.4	3.2	23.1

W1048139

**[3] AMERICAN STANDARD SCREWS, BOLTS AND NUTS WITH UNC OR UNF THREADS**

Grade	SAE GR.5 			SAE GR.8 			
	Unit	N-m	kgf-m	lbf-ft	N-m	kgf-m	lbf-ft
Nominal Diameter							
5/16	23.1 to 27.7	2.35 to 2.83	17.0 to 20.5	32.6 to 39.3	3.32 to 4.00	24.0 to 29.0	
3/8	48 to 56	4.9 to 5.8	35.0 to 42.0	61.1 to 73.2	6.23 to 7.46	45.0 to 54.0	
1/2	109 to 130	11.1 to 13.2	80.0 to 96.0	149.2 to 178.9	15.21 to 18.24	110.0 to 132.0	
9/16	149.2 to 178.9	15.21 to 18.24	110.0 to 132.0	217.0 to 260.3	22.12 to 26.54	160.0 to 192.0	
5/8	203.4 to 244	20.74 to 24.88	150.0 to 180.0	298.3 to 357.9	30.42 to 36.49	220.0 to 264.0	

W1022485

**[4] PLUGS**

Shape	Size	Material of opponent part					
		Ordinariness			Aluminum		
		N-m	kgf-m	lbf-ft	N-m	kgf-m	lbf-ft
Tapered screw 	R1/8	13 to 21	1.3 to 2.2	9.4 to 15	13 to 21	1.3 to 2.0	9.4 to 15
	R1/4	25 to 44	2.5 to 4.5	18 to 32	25 to 34	2.5 to 3.5	18 to 25
Straight screw 	G1/4	25 to 34	2.5 to 3.5	18 to 25	–	–	–
	G3/8	62 to 82	6.3 to 8.4	46 to 60	–	–	–
	G1/2	49 to 88	5.0 to 9.0	37 to 65	–	–	–

000001666E

## 6. MAINTENANCE CHECK LIST

No.	Item	Period	Service Interval														Since then	Important	Reference page
			50	100	150	200	250	300	350	400	450	500	550	600	650	700			
1	Engine oil	Change	★			☆				☆					☆		every 200 Hr		G-13
2	Engine oil filter	Replace	★			☆				☆					☆		every 200 Hr		G-13
3	Transmission oil filter	Replace	★			☆				☆					☆		every 200 Hr		G-14
4	Transmission fluid	Change								☆							every 400 Hr		G-24
5	Transmission strainer	Clean	★							☆							every 400 Hr		G-14
6	Front axle case oil	Change								☆							every 400 Hr		G-24
7	Front axle pivot	Adjust								☆							every 400 Hr		G-24
8	Engine start system	Check	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	every 50 Hr		G-15
9	Greasing	—	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	every 50 Hr		G-16
10	Wheel bolt torque	Check	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	every 50 Hr		G-16
11	Battery condition	Check		☆		☆		☆		☆		☆		☆		☆	every 100 Hr	*4	G-17
12	Air cleaner element	Clean		☆		☆		☆		☆		☆		☆		☆	every 100 Hr	*1	G-19
		Replace															every 1 year	*2	G-25
13	Fuel filter element	Check		☆		☆		☆		☆		☆		☆		☆	every 100 Hr		G-20
		Replace										☆					every 500 Hr		G-25
14	Fan belt	Adjust		☆		☆		☆		☆		☆		☆		☆	every 100 Hr		G-20
15	HST neutral spring	Adjust		☆		☆		☆		☆		☆		☆		☆	every 100 Hr		G-21
16	Brake	Adjust		☆		☆		☆		☆		☆		☆		☆	every 100 Hr		G-22
17	Radiator hose and clamp	Check				☆				☆				☆			every 200 Hr		G-22
		Replace															every 2 years		G-26
18	Power steering oil line	Check				☆				☆				☆			every 200 Hr		G-23
		Replace															every 2 years		G-26
19	Fuel line	Check		☆		☆		☆		☆		☆		☆		☆	every 100 Hr		G-20
		Replace															every 2 years		G-26
20	Intake air line	Check				☆				☆				☆			every 200 Hr		G-23
		Replace															every 2 years	*3	G-26
21	Toe-in	Adjust				☆				☆				☆			every 200 Hr		G-23
22	Engine valve clearance	Adjust															every 800 Hr		1-S12
23	Fuel injection nozzle injection pressure	Check															every 1500 Hr	@	1-S24
24	Injection pump	Check															every 3000 Hr	@	1-S23
25	Cooling system	Flush															every 2 years		G-27
26	Coolant	Change															every 2 years		G-27
27	Fuel system	Bleed																	G-30
28	Fuse	Replace															Service as required		G-30
29	Light bulb	Replace																	G-31

### ■ IMPORTANT

- The jobs indicated by ★ must be done after the first 50 hours of operation.
- \*1 : Air cleaner should be cleaned more often in dusty conditions than in normal conditions.
- \*2 : Every year or every 6 times of cleaning.
- \*3 : Replace only if necessary.
- \*4 : When the battery is used for less than 100 hours per year, check the fluid level annually.
- The items listed above (@ marked) are registered as emission related critical parts by KUBOTA in the U.S.EPA nonroad emission regulation. As the engine owner, you are responsible for the performance of the required maintenance on the engine according to the above instruction.  
Please see the Warranty Statement in detail.

W1035769

## 7. CHECK AND MAINTENANCE

### CAUTION

- **Be sure to check and service the tractor on a level surface with the engine shut off and the parking brake "ON" and implement lowered to the ground.**

### [1] DAILY CHECK

To prevent trouble from occurring, it is important to know the condition of the tractor. Check the following items before starting.



#### ■ Walk Around Inspection

Look around the under the tractor for such items as loose bolts, trash build-up, oil or coolant leaks, broken or worn parts.

#### Checking

1. Checking and refueling.
2. Check the engine oil level.
3. Check the transmission fluid level.
4. Check the coolant level.
5. Clean panel and radiator screen.
6. Check the brake pedal.
7. Check the gauge, the meters and easy checkers.
8. Check the head light, the hazard light etc..
9. Check and clean the electrical wiring and the battery cables.
10. Check the seat belt and ROPS.

## [2] CHECK POINTS OF INITIAL 50 HOURS



### Changing Engine Oil

#### ⚠ CAUTION

To avoid personal injury :


- Be sure to stop the engine and remove the key before changing the oil.
  - Allow engine to cool down sufficiently, oil can be hot and can burn.
1. To drain the used oil, remove the drain plug at the bottom of the engine and drain the oil completely into the oil pan.  
All the used oil can be drained out easily when the engine is still warm.
  2. After draining reinstall the drain plug.
  3. Fill with the new oil up to the upper notch on the dipstick.
  4. Properly dispose of used oil.

Engine oil	Capacity	BX1860	2.9 L 3.1 U.S.qts 2.6 Imp.qts
		BX2360	3.1 L 3.3 U.S.qts 2.7 Imp.qts
		BX2660	3.5 L 3.7 U.S.qts 2.9 Imp.qts

- (1) Drain Plug
- (2) Oil Inlet
- (3) Dipstick

(A) Oil level is acceptable within this range.

W1014065



### Replacing Engine Oil Filter

#### ⚠ CAUTION


- Be sure to stop the engine before changing oil filter cartridge.
1. Remove the oil filter.
  2. Put a film of clean engine oil on the rubber seal of the new filter.
  3. Tighten the filter quickly until it contacts the mounting surface.  
Tighten filter by hand an additional 1/2 turn only.
  4. After the new filter has been replaced, the engine oil normally decrease a little. Make sure that the engine oil does not leak through the seal and be sure to check the oil level on the dipstick. Then, replenish the engine oil up to the specified level.
  5. Properly dispose of used oil.

#### ■ IMPORTANT

- To prevent serious damage to the engine, use only a KUBOTA genuine filter.

- (1) Engine Oil Filter Cartridge

W1014316



### Replacing Transmission Oil Filter

#### ⚠ CAUTION


- **Allow engine to cool down sufficiently, oil can be hot and can burn.**
1. Remove the oil filter.
  2. Put a film of clean transmission oil on the rubber seal of the new filter.
  3. Tighten the filter quickly until it contacts the mounting surface. Tighten filter by hand an additional 1/2 turn only.
  4. After the new filter has been replaced, the transmission fluid level will decrease a little. Make sure that the transmission fluid does not leak through the seal, and check the fluid level. Top off if necessary.
  5. Properly dispose of used oil.

#### ■ IMPORTANT

- **To prevent serious damage to the hydraulic system, use only a KUBOTA genuine filter.**

(1) Transmission Oil Filter

W1014458



### Cleaning Transmission Oil Strainer

1. When changing the transmission fluid, disassemble and rinse the strainer with nonflammable solvent to completely clean off fillings.
2. When reassembling, be careful not to damage the parts.

#### ■ NOTE

- **Since the fine fillings in the oil can damage the precision component parts of the hydraulic system, the end of the suction line is provided with an oil strainer.**

(1) Strainer

(2) Filter Plate

W1019390

