

Product: KKubota B3000-AUS Service Manual

Full Download: <https://www.arepairmanual.com/downloads/kkubota-b3000-aus-service-manual/>

# WSM

---

**WORKSHOP MANUAL  
TRACTOR**

**B3000-AUS**

---

**Kubota**

Sample of manual. Download All 428 pages at:

<https://www.arepairmanual.com/downloads/kkubota-b3000-aus-service-manual/>

KiSC issued 11, 2011 A

Product: KKubota B3000-AUS Service Manual

Full Download: <https://www.arepairmanual.com/downloads/kkubota-b3000-aus-service-manual/>

## TO THE READER

This Workshop Manual tells the servicing personnel about the mechanism, servicing and maintenance of the B3000-AUS. It contains 4 parts: "**Information**", "**General**", "**Mechanism**" and "**Servicing**".

### ■ **Information**

This section primarily contains information below.

- Safety First
- Safety Decal
- Specification
- Dimension

### ■ **General**

This section primarily contains information below.

- Engine Identification
- Model Identification
- General Precautions
- Maintenance Check List
- Check and Maintenance
- Special Tools

### ■ **Mechanism**

This section contains information on the structure and the function of the unit. Before you continue with the subsequent sections, make sure that you read this section.

Refer to the latest version of Workshop Manual (Code No. 9Y021-01870 / 9Y021-18200) for the diesel engine / tractor mechanism that this workshop manual does not include.

### ■ **Servicing**

This section primarily contains information below.

- Troubleshooting
- Servicing Specifications
- Tightening Torques
- Checking, Disassembling and Servicing

All illustrations, photographs and specifications contained in this manual are of the newest information available at the time of publication.

KUBOTA reserves the right to change all information at any time without notice.

November, 2011

© KUBOTA Corporation 2011

Sample of manual. Download All 428 pages at:

<https://www.arepairmanual.com/downloads/kkubota-b3000-aus-service-manual/>

KiSC issued 11, 2011 A

# I INFORMATION

# INFORMATION

## CONTENTS

1. SAFETY FIAST.....	I-1
2. SAFETY DECALS .....	I-4
3. SPECIFICATIONS.....	I-8
4. TRAVELING SPEEDS.....	I-9
5. DIMENSIONS .....	I-10

# 1. SAFETY FIRST

## ⚠ SAFETY FIRST

- This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully.
- It is essential that you read the instructions and safety regulations before you attempt to repair or use this unit.

### ⚠ DANGER

- Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

### ⚠ WARNING

- Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

### ⚠ CAUTION

- Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.


### ■ IMPORTANT

- Indicates that equipment or property damage could result if instructions are not followed.

### ■ NOTE

- Gives helpful information.

WSM000001IN10001US1



### BEFORE YOU START SERVICE

- Read all instructions and safety instructions in this manual and on your machine safety decals.
- Clean the work area and machine.
- Park the machine on a stable and level ground, and set the parking brake.
- Lower the implement to the ground.
- Stop the engine, then remove the key.
- Disconnect the battery negative cable.
- Hang a "DO NOT OPERATE" tag in the operator station.


WSM000001IN10010US1



### START SAFELY

- Do not do the procedures below when you start the engine.
  - short across starter terminals
  - bypass the safety start switch
- Do not alter or remove any part of machine safety system.
- Before you start the engine, make sure that all shift levers are in neutral positions or in disengaged positions.
- Do not start the engine when you stay on the ground. Start the engine only from operator's seat.


WSM000001IN10015US0




IBM003A



IBM004A



IBM005A



IBM006A

## OPERATE SAFELY


- Do not use the machine after you consume alcohol or medication or when you are tired.
- Put on applicable clothing and safety equipment.
- Use applicable tools only. Do not use alternative tools or parts.
- When 2 or more persons do servicing, make sure that you do it safely.
- Do not operate below the machine that only a jack holds. Always use a safety stand to hold the machine.
- Do not touch the hot parts or parts that turn when the engine operates.
- Do not remove the radiator cap when the engine operates, or immediately after it stops. If not, hot water can spout out from the radiator. Only remove the radiator cap when it is at a sufficiently low temperature to touch with bare hands. Slowly loosen the cap to release the pressure before you remove it fully.
- Released fluid (fuel or hydraulic oil) under pressure can cause damage to the skin and cause serious injury. Release the pressure before you disconnect hydraulic or fuel lines. Tighten all connections before you apply the pressure.
- Do not open a fuel system under high pressure. The fluid under high pressure that stays in fuel lines can cause serious injury. Do not disconnect or repair the fuel lines, sensors, or any other components between the fuel pump and injectors on engines with a common rail fuel system under high pressure.
- Put on an applicable ear protective device (earmuffs or earplugs) to prevent injury against loud noises.
- Be careful about electric shock. The engine generates a high voltage of more than DC100 V in the ECU and is applied to the injector.

WSM000001INI0012US1

## PREVENT A FIRE

- Fuel is very flammable and explosive under some conditions. Do not smoke or let flames or sparks in your work area.
- To prevent sparks from an accidental short circuit, always disconnect the battery negative cable first and connect it last.
- The battery gas can cause an explosion. Keep the sparks and open flame away from the top of battery, especially when you charge the battery.
- Make sure that you do not spill fuel on the engine.

WSM000001INI0005US1

**KEEP A GOOD AIRFLOW IN THE WORK AREA**


- If the engine is in operation, make sure that the area has good airflow. Do not operate the engine in a closed area. The exhaust gas contains poisonous carbon monoxide.

WSM000001INI0006US1

**DISCARD FLUIDS CORRECTLY**


- Do not discard fluids on the ground, down the drain, into a stream, pond, or lake. Obey related environmental protection regulations when you discard oil, fuel, coolant, electrolyte and other dangerous waste.

WSM000001INI0007US1

**PREVENT ACID BURNS**

- Keep electrolyte away from your eyes, hands and clothing. Sulfuric acid in battery electrolyte is poisonous and it can burn your skin and clothing and cause blindness. If you spill electrolyte on yourself, clean yourself with water, and get medical aid immediately.

WSM000001INI0008US1

**PREPARE FOR EMERGENCIES**

- Keep a first aid kit and fire extinguisher ready at all times.
- Keep the emergency contact telephone numbers near your telephone at all times.


WSM000001INI0009US1

## 2. SAFETY DECALS

The following safety decals are installed on the machine. If a decal becomes damaged, illegible or is not on the machine, replace it. The decal part number is listed in the parts list.

WSM000001INI0013USO

(1) Part No. 6C070-4742-2



1AGAEBMAP068E

(3) Part No. TC420-4956-1






1AGAIDHAP154F

(2) Part No. 6C150-4743-1




1AGAEBMAP074E



9Y1210623IC001US

9Y1210623INI0001USO

(1) Part No. 6C300-3012-1



(2) Part No. 32751-4958-1

Do not get your hands close to engine fan and fan belt.




1AGAEBMAP073A

(3) Part No. TA040-4958-1


Do not touch hot surface like muffler, etc.



1AGAEBMAP078A



9Y1210623IC1002US



9Y1210623IN10002US0

(1) Part No. 6C200-4751-1



1AGAEBNAP004E




(2) Part No. 6C200-4959-1



(3) Part No. 6C300-4744-1



1AGAIHFAP069A



9Y1210623IC|003US

9Y1210623INI|0003US

(1) Part No. TA040-4902-1





1AGAMAOAP0780

(2) Part No. 6C230-4743-1



1AGAMAOAP0790



9Y1210623IC1004US

9Y1210623INI0004USO

#### **CARE OF DANGER, WARNING AND CAUTION LABELS**

1. Keep danger, warning and caution labels clean and free from obstructing material.
2. Clean danger, warning and caution labels with soap and water, dry with a soft cloth.
3. Replace damaged or missing danger, warning and caution labels with new labels.
4. If a component with danger, warning or caution label(s) affixed is replaced with new part, make sure new label(s) is (are) attached in the same location(s) as the replaced component.
5. Mount new danger, warning and caution labels by applying on a clean dry surface and pressing any bubbles to outside edge.

no caption

### 3. SPECIFICATIONS

Model		B3000-AUS	
PTO power		17.1 kW (23.0 HP)*	
Engine	Maker	KUBOTA	
	Model	V1505-E3-D21-Q	
	Type	E-TVCS, water-cooled, 4-cycle diesel	
	Number of cylinders	4	
	Bore and stroke	78 × 78.4 mm (3.1 × 3.1 in.)	
	Total displacement	1498 cm <sup>3</sup> (91.5 cu.in.)	
	Engine gross power	22.3 kW (30.0 HP)*	
	Rated revolution	2600 min <sup>-1</sup> (rpm)	
	Maximum torque	98.7 N·m (72.7 lbf·ft)	
	Battery	12 V, RC: 80 min, CCA: 430 A	
	Starting system	Electric starting with cell starter 12 V, 1.4 kW	
	Lubricating system	Forced lubrication by trochoidal pump	
Capacities	Cooling system	Pressurized radiator, forced circulation with water pump	
	Fuel	Diesel fuel No. 2-D [above -10 °C (14 °F)], Diesel fuel No. 1 [below -10 °C (14 °F)]	
	Fuel tank	31 L (8.1 U.S.gals, 6.8 Imp.gals)	
	Engine crankcase (with filter)	4.1 L (4.3 U.S.qts, 3.6 Imp.qts)	
	Engine coolant	5.2 L (5.5 U.S.qts, 4.6 Imp.qts)	
	Transmission case	15 L (4.0 U.S.gals, 3.3 Imp.gals)	
	Front axle case	4.7 L (5.0 U.S.qts, 4.1 Imp.qts)	
	Tires	Front	Front: 7 - 12
		Rear	Farm: 12.4 - 16
Dimensions	Turf: 24 × 8.5 - 14		Turf:13.6 - 16
	Overall length (without 3P)	2640 mm (103.9 in.)	
	Overall width	1365 mm (53.7 in.)	
	Overall height	2150 mm (84.6 in.)	
	Wheel base	1666 mm (65.6 in.)	
	Minimum ground clearance	370 mm (14.6 in.)	
Weight	Tread	Front	935 mm (36.8 in.)
		Rear	1050 mm (41.3 in.)
	1030 kg (2271 lbs)		
	Clutch	N/A	
	Steering	Hydrostatic power steering	
	Transmission	Main-hydrostatic transmission, 3 range gear shift (3 forward and 3 reverse)	
	Brake	Wet disk type	
Travelling system	Min. turning radius (with brake)	2.1 m (6.9 feet)	
	Differential	Bevel gear	
	Hydraulic control system	Position control	
	Pump capacity	3P: 19.7 L/min (7.5 gals/min) Power steering: 14.8 L/min (5.6 gals/min)	
	Three point hitch	SAE Category 1	
	Max. lift force	At lift points	970 kg (2139 lbs)
		24 in. behind lift points	760 kg (1676 lbs)
PTO system	Rear	Front	SAE 1-3/8, 6 splines
		Rear	1 speed (540 min <sup>-1</sup> (rpm) at 2592 engine min <sup>-1</sup> (rpm))
	Mid	Front	U.S.A. No.5 (KUBOTA 10-tooth) involute spline
		Rear	1 speed (2500 min <sup>-1</sup> (rpm) at 2600 engine min <sup>-1</sup> (rpm))

#### ■ NOTE

- \* Manufacturer's estimate

The company reserves the right to change the specifications without notice.

9Y1210623IN10005US0


## 4. TRAVELING SPEEDS

Model		B3000-AUS			
Tire Size (Rear)		12.4 - 16 Farm		13.6 - 16 Turf	
	Range gear shift lever	km/h	mph	km/h	mph
Forward	Low	0 to 5.0	0 to 3.1	0 to 5.2	0 to 3.2
	Middle	0 to 9.4	0 to 5.8	0 to 9.6	0 to 6.0
	High	0 to 19.5	0 to 12.1	0 to 20.0	0 to 12.4
Reverse	Low	0 to 4.0	0 to 2.5	0 to 4.1	0 to 2.6
	Middle	0 to 7.4	0 to 4.6	0 to 7.6	0 to 4.7
	High	0 to 15.5	0 to 9.6	0 to 15.9	0 to 9.9

The company reserves the right to change the specifications without notice.

9Y1210623INI0006US0

## 5. DIMENSIONS




# **G GENERAL**

# GENERAL

## CONTENTS

1. TRACTOR IDENTIFICATION.....	G-1
2. GENERAL PRECAUTIONS.....	G-2
3. HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING .....	G-3
[1] WIRING .....	G-3
[2] BATTERY .....	G-5
[3] FUSE .....	G-5
[4] CONNECTOR .....	G-5
[5] HANDLING OF CIRCUIT TESTER .....	G-6
[6] COLOR OF WIRING .....	G-7
4. LUBRICANTS, FUEL AND COOLANT.....	G-8
5. TIGHTENING TORQUES .....	G-10
[1] GENERAL USE SCREWS, BOLTS AND NUTS .....	G-10
[2] STUD BOLTS .....	G-10
[3] HYDRAULIC FITTINGS .....	G-11
(1) Hydraulic Hose Fittings.....	G-11
(2) Hydraulic Pipe Cap Nuts .....	G-11
(3) Adaptors, Elbows and Others.....	G-11
[4] METRIC SCREWS, BOLTS AND NUTS.....	G-12
[5] AMERICAN STANDARD SCREWS, BOLTS AND NUTS WITH UNC OR UNF THREADS .....	G-12
[6] PLUGS .....	G-12
6. MAINTENANCE CHECK LIST.....	G-13
7. CHECK AND MAINTENANCE .....	G-15
[1] DAILY CHECK.....	G-15
[2] CHECK POINTS OF INITIAL 50 HOURS .....	G-19
[3] CHECK POINTS OF EVERY 50 HOURS .....	G-22
[4] CHECK POINTS OF EVERY 100 HOURS .....	G-24
[5] CHECK POINTS OF EVERY 200 HOURS .....	G-28
[6] CHECK POINTS OF EVERY 300 HOURS .....	G-31
[7] CHECK POINTS OF EVERY 400 HOURS .....	G-31
[8] CHECK POINTS OF EVERY 800 HOURS .....	G-32
[9] CHECK POINT OF EVERY 1500 HOURS.....	G-32
[10]CHECK POINT OF EVERY 3000 HOURS.....	G-32
[11]CHECK POINTS OF EVERY 1 YEAR.....	G-33
[12]CHECK POINTS OF EVERY 2 YEARS .....	G-34
[13]OTHERS.....	G-37
8. SPECIAL TOOLS .....	G-42
[1] SPECIAL TOOLS FOR ENGINE .....	G-42
[2] SPECIAL TOOLS FOR TRACTOR .....	G-48
[3] SPECIAL TOOLS FOR CABIN.....	G-51
9. TIRES .....	G-55
[1] TIRE PRESSURE.....	G-55
[2] TREAD .....	G-56
(1) Front Wheels .....	G-57
(2) Rear Wheels.....	G-58
[3] TIRE LIQUID INJECTION AND BALLAST .....	G-59
10. IMPLEMENT LIMITATIONS .....	G-62

# 1. TRACTOR IDENTIFICATION




When contacting your local KUBOTA distributor, always specify engine serial number, tractor serial number and hour meter reading.


- (1) Tractor Identification Plate  
(2) Tractor Serial Number  
(3) Engine Serial Number

- (4) CABIN Identification Plate  
(CABIN Serial Number)

9Y1210623GEG0001US0



## 2. GENERAL PRECAUTIONS




- When you disassemble, carefully put the parts in a clean area to make it easy to find the parts. You must install the screws, bolts and nuts in their initial position to prevent the reassembly errors.
- When it is necessary to use special tools, use KUBOTA special tools. Refer to the drawings when you make special tools that you do not use frequently.
- Before you disassemble or repair machine, make sure that you always disconnect the ground cable from the battery first.
- Remove oil and dirt from parts before you measure.
- Use only KUBOTA genuine parts for replacement to keep the machine performance and to make sure of safety.
- You must replace the gaskets and O-rings when you assemble again. Apply grease (1) to new O-rings or oil seals before you assemble.
- When you assemble the external or internal snap rings, make sure that the sharp edge (3) faces against the direction from which force (2) is applied.
- When inserting spring pins, their splits must face the direction from which a force is applied. See the figure left side.
- To prevent damage to the hydraulic system, use only specified fluid or equivalent.
- Clean the parts before you measure them.
- Tighten the nipples to the specified torque. Too much torque can cause damage to the hydraulic units or the nipples. Not sufficient torque can cause oil leakage.
- When you use a new hose or pipe, tighten the nuts to the specified torque. Then loosen (approx. by 45 °) and let them be stable before you tighten to the specified torque (This is not applied to the parts with seal tape).
- When you remove the two ends of a pipe, remove the lower end first.
- Use two pliers in removal and installation. One to hold the stable side, and the other to turn the side you remove to prevent twists.
- Make sure that the sleeves of flared connectors and taper s of hoses are free of dust and scratches.
- After you tighten the nipples, clean the joint and apply the maximum operation pressure 2 to 3 times to examine oil leakage.

- (1) Grease  
 (2) Force  
 (3) Sharp Edge  
 (4) Axial Force  
 (5) Rotating Movement

- (A) External Snap Ring  
 (B) Internal Snap Ring

WSM000001GEG0106US1

### 3. HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING



To ensure safety and prevent damage to the machine and surrounding equipment, heed the following precautions in handling electrical parts and wiring.

■ **IMPORTANT**


- Check electrical wiring for damage and loosened connection every year. To this end, educate the customer to do his or her own check and at the same time recommend the dealer to perform periodic check for a fee.
- Do not attempt to modify or remodel any electrical parts and wiring.
- When removing the battery cables, disconnect the negative cable first. When installing the battery cables, connect the positive cable first.

(1) Negative Terminal

(2) Positive Terminal

WSM000001GEG0062US1

#### [1] WIRING




- Securely tighten wiring terminals.

(1) Correct  
(Securely Tighten)

(2) Incorrect  
(Loosening Leads to Faulty Contact)


WSM000001GEG0063US1



- Do not let wiring contact dangerous part.

(1) Dangerous Part (Sharp Edge)      (3) Wiring (Correct)  
(2) Wiring (Incorrect)      (4) Dangerous Part

WSM000001GEG0064US1




- Repair or change torn or aged wiring immediately.

(1) Aged  
(2) Torn

(3) Insulating Vinyl Tape

WSM000001GEG0065US1



3TMABAB0P009A


- Securely insert grommet.

(1) Grommet

(A) Correct

(B) Incorrect

WSM000001CEG0066US1




3TMABAB0P010A

- Securely clamp, being careful not to damage wiring.

(1) Clamp  
(Wind Clamp Spirally)(3) Clamp  
(4) Welding Dent

(2) Wire Harness

WSM000001GEG0067US1




3TMABAB0P011A

- Clamp wiring so that there is no twist, unnecessary sag, or excessive tension, except for movable part, where sag be required.

(1) Wiring  
(2) Clamp(A) Correct  
(B) Incorrect

WSM000001GEG0068US1




3TMABAB0P012A

- In installing a part, take care not to get wiring caught by it.

(1) Wiring

(A) Incorrect

WSM000001GEG0069US1




3TMABAB0P013A

- After installing wiring, check protection of terminals and clamped condition of wiring, only connect battery.

(1) Cover  
(Securely Install Cover)

WSM000001GEG0070US1

## [2] BATTERY



3TMABAB0P006B


- Take care not to confuse positive and negative terminal posts.
- When removing battery cables, disconnect negative cable first. When installing battery cables, check for polarity and connect positive cable first.
- Do not install any battery with capacity other than is specified (Ah).
- After connecting cables to battery terminal posts, apply high temperature grease to them and securely install terminal covers on them.
- Do not allow dirt and dust to collect on battery.

### CAUTION

- Take care not to let battery liquid spill on your skin and clothes. If contaminated, wash it off with water immediately.
- Before recharging the battery, remove it from the machine.
- Before recharging, remove cell caps.
- Do recharging in a well-ventilated place where there is no open flame nearby, as hydrogen gas and oxygen are formed.

WSM000001GEG0071US1

## [3] FUSE



WSM000001GES001A


- Use fuses with specified capacity. Neither too large or small capacity fuse is acceptable.
- Never use steel or copper wire in place of fuse.
- Do not install working light, radio set, etc. on machine which is not provided with reserve power supply.
- Do not install accessories if fuse capacity of reserve power supply is exceeded.

(1) Fuse  
(2) Fusible Link

(3) Slow Blow Fuse

WSM000001GEG0072US1


## [4] CONNECTOR



3TMABAB0P015A

- For connector with lock, push lock to separate.
- (A) Push

WSM000001GEG0073US1




3TMABAB0P016A

- In separating connectors, do not pull wire harnesses.
- Hold connector bodies to separate.

(A) Correct

(B) Incorrect

WSM000001GEG0074US1




- Use sandpaper to remove rust from terminals.
  - Repair deformed terminal. Make certain there is no terminal being exposed or displaced.

- (1) Exposed Terminal
- (2) Deformed Terminal

- (3) Sandpaper
- (4) Rust

WSM000001GEG0075US1




- Make certain that there is no female connector being too open.

(A) Correct

(B) Incorrect

WSM000001GEG0076US1



- Make certain plastic cover is large enough to cover whole connector.


### (1) Cover

(A) Correct

(B) Incorrect

WSM000001GEG0077US1


## [5] HANDLING OF CIRCUIT TESTER



- Use tester correctly following manual provided with tester.
  - Check for polarity and range.

WSM000001GEG0078US1

## [6] COLOR OF WIRING



- Colors of wire are specified to the color codes.
- This symbol of "/" shows color with stripe(s).

**(An example)**

Red stripe on white color: W/R

Color of wiring	Color code
Black	B
Brown	Br
Green	G
Gray	Gy or Gr
Blue	L
Light Green	Lg
Orange	Or
Pink	P
Purple	Pu or V
Red	R
Sky Blue	Sb
White	W
Yellow	Y

(1) Wire Color

(2) Stripe

WSM00001GEG0079US0

## 4. LUBRICANTS, FUEL AND COOLANT

No.	Place	Capacity	Lubricants, fuel and coolant
		B3000	
1	Fuel tank	31 L 8.1 U.S.gals 6.8 Imp.gals	<ul style="list-style-type: none"> <li>• No. 2-D diesel fuel</li> <li>• No. 1-D diesel fuel if temperature is below –10 °C (14 °F)</li> </ul>
2	Coolant (with recovery tank)	5.2 L 5.5 U.S.qts 4.6 Imp.qts	Fresh clean water with anti-freeze
3	Engine crankcase (with filter)	4.1 L 4.3 U.S.qts 3.6 Imp.qts	<b>Engine oil</b> Refer to next page <ul style="list-style-type: none"> <li>• Below 0 °C (32 °F) SAE10W,</li> <li>SAE10W-30 or 15W-40</li> <li>• 0 to 25 °C (32 to 77 °F) SAE20, SAE10W-30 or 15W-40</li> <li>• Above 25 °C (77 °F) SAE30, 10W-30 or 15W-40</li> </ul>
4	Transmission case	15 L 4.0 U.S.gals 3.3 Imp.gals	KUBOTA UDT fluid or SUPER UDT fluid*
5	Front axle case	4.7 L 5.0 U.S.qts 4.1 Imp.qts	KUBOTA UDT, SUPER UDT fluid* or SAE 80-90 gear oil
6	Washer liquid tank	1.5 L 0.40 U.S.qts 0.33 Imp.qts	Automobile washer liquid

### Greasing

No.	Place	No. of greasing point	Capacity	Type of grease
7	Top link	1	Until grease overflows	Multipurpose grease NLGI-2 or NLGI-1 (GC-LB)
	Lift rod [RH]	1		
	Speed control pedal	1		
	Battery terminals	2		

#### ■ NOTE

- \* KUBOTA original transmission hydraulic fluid.

9Y1210623GEG0002US0

**■ NOTE****Engine Oil :**

- Oil used in the engine should have an American Petroleum Institute (API) service classification and Proper SAE Engine Oil according to the ambient temperatures as shown above:
- With the emission control now in effect, the CF-4 and CG-4 lubricating oils have been developed for use of a low-sulfur fuel on on-road vehicle engines. When an off-road vehicle engine runs on a high-dulfur fuel, it is advisable to employ the "CF or better" lubricating oil with a high Total Base Number (TBN of 10 minimum).
- Refer to the following table for the suitable API classification of engine oil according to the Fuel : (Low Sulfur or High Sulfur Fuels).

Fuel used	Engine oil classification (API classification)
High Sulfur Fuel ( $\geq$ 500 ppm)	CF (If the "CF-4, CG-4, CH-4, or CI-4" lubricating oil is used with a high-sulfur fuel, change the lubricating oil at shorter intervals. (approximately half))
Low Sulfur Fuel ( $<$ 500 ppm) or Ultra Low Sulfur Fuel ( $<$ 15 ppm)	CF, CF-4, CG-4, CH-4 or CI-4

- The CJ-4 engine oil is intended for DPF (Diesel Particulate Filter) type engines, and cannot be used on this tractor.

**Fuel :**

- Cetane number of 45 minimum. Cetane number greater than 50 is preferred, especially for temperatures below  $-20^{\circ}\text{C}$  ( $-4^{\circ}\text{F}$ ) or elevations above 1500 m (5000 ft).
- If diesel sulfur content greater than 0.5 % sulfur content is used, reduce the service interval for engine oil and filter by 50 %.
- DO NOT use diesel fuel with sulfur content greater than 1.0 %.
- Diesel fuels specified to EN 590 or ASTM D975 are recommended.
- No.2-D is a distillate fuel of lower volatility for engines in industrial and heavy mobile service. (SAE J313 JUN87)
- Since this engine adopts EPA Tier 4 and Interim Tier 4 standards, the use of low sulfur fuel or ultra low sulfur fuel is mandatory in EPA regulated area (North America). Therefore, please use No.2-D S500 or S15 diesel fuel as an alternative to No.2-D, or use No.1-D S500 or S15 diesel fuel as an alternative to No.1-D if outside air temperature is below  $-10^{\circ}\text{C}$  ( $14^{\circ}\text{F}$ ).

**Transmission Oil :**

The oil used to lubricate the transmission is also used as hydraulic fluid. To insure proper operation of the hydraulic system and to complete lubrication of the transmission, it is important that a multi-grade transmission fluid is used in this system. We recommend the use of KUBOTA UDT or SUPER UDT fluid for optimum protection and performance.

- Do not mix different brands together.
- Indicated capacities of water and oil are manufacturer's estimate.

9Y1210623GEG0003US0

## 5. TIGHTENING TORQUES

### [1] GENERAL USE SCREWS, BOLTS AND NUTS

Screws, bolts and nuts whose tightening torques are not specified in this Workshop Manual should be tightened according to the table below.

Indication on top of bolt	4 No-grade or 4T						7 7T						9 9T					
Indication on top of nut	No-grade or 4T												6T					
Material of opponent part	Ordinariness			Aluminum			Ordinariness			Aluminum			Ordinariness					
Unit	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
M6	7.9 to 9.3	0.80 to 0.95	5.8 to 6.8	7.9 to 8.8	0.80 to 0.90	5.8 to 6.5	9.81 to 11.2	1.00 to 1.15	7.24 to 8.31	7.9 to 8.8	0.80 to 0.90	5.8 to 6.5	12.3 to 14.2	1.25 to 1.45	9.05 to 10.4			
M8	18 to 20	1.8 to 2.1	13 to 15	17 to 19	1.7 to 2.0	13 to 14	24 to 27	2.4 to 2.8	18 to 20	18 to 20	1.8 to 2.1	13 to 15	30 to 34	3.0 to 3.5	22 to 25			
M10	40 to 45	4.0 to 4.6	29 to 33	32 to 34	3.2 to 3.5	24 to 25	48 to 55	4.9 to 5.7	36 to 41	40 to 44	4.0 to 4.5	29 to 32	61 to 70	6.2 to 7.2	45 to 52			
M12	63 to 72	6.4 to 7.4	47 to 53	—	—	—	78 to 90	7.9 to 9.2	58 to 66	63 to 72	6.4 to 7.4	47 to 53	103 to 117	10.5 to 12.0	76.0 to 86.7			
M14	108 to 125	11.0 to 12.8	79.6 to 92.5	—	—	—	124 to 147	12.6 to 15.0	91.2 to 108	—	—	—	167 to 196	17.0 to 20.0	123 to 144			
M16	167 to 191	17.0 to 19.5	123 to 141	—	—	—	197 to 225	20.0 to 23.0	145 to 166	—	—	—	260 to 304	26.5 to 31.0	192 to 224			
M18	246 to 284	25.0 to 29.0	181 to 209	—	—	—	275 to 318	28.0 to 32.5	203 to 235	—	—	—	344 to 402	35.0 to 41.0	254 to 296			
M20	334 to 392	34.0 to 40.0	246 to 289	—	—	—	368 to 431	37.5 to 44.0	272 to 318	—	—	—	491 to 568	50.0 to 58.0	362 to 419			

WSM000001GEG0001US1

### [2] STUD BOLTS

Material of opponent part	Ordinariness			Aluminum		
Unit	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
M8	12 to 15	1.2 to 1.6	8.7 to 11	8.9 to 11	0.90 to 1.2	6.5 to 8.6
M10	25 to 31	2.5 to 3.2	18 to 23	20 to 25	2.0 to 2.6	15 to 18
M12	30 to 49	3.0 to 5.0	22 to 36	31	3.2	23
M14	62 to 73	6.3 to 7.5	46 to 54	—	—	—
M16	98.1 to 112	10.0 to 11.5	72.4 to 83.1	—	—	—
M18	172 to 201	17.5 to 20.5	127 to 148	—	—	—

WSM000001GEG0002US1

## [3] HYDRAULIC FITTINGS

### (1) Hydraulic Hose Fittings

Hose size	Thread side	Tightening torque		
		N·m	kgf·m	lbf·ft
02	1/8	13.8 to 15.6	1.40 to 1.60	10.2 to 11.5
03	1/4	22.6 to 27.4	2.30 to 2.80	16.7 to 20.2
04				
05	3/8	45.2 to 52.9	4.60 to 5.40	33.3 to 39.0
06				

WSM000001GEG0097US0

### (2) Hydraulic Pipe Cap Nuts

Pipe size	Tightening torque		
	N·m	kgf·m	lbf·ft
φ4 × t1.0	19.7 to 29.4	2.00 to 3.00	14.5 to 21.6
φ6 × t1.0	24.6 to 34.3	2.50 to 3.50	18.1 to 25.3
φ8 × t1.0	29.5 to 39.2	3.00 to 4.00	21.7 to 28.9
φ10 × t1.0	39.3 to 49.0	4.00 to 5.00	29.0 to 36.1
φ12 × t1.5	49.1 to 68.6	5.00 to 7.00	36.2 to 50.6
φ15 × t1.6	108 to 117	11.0 to 12.0	79.6 to 86.7
φ18 × t1.6	108 to 117	11.0 to 12.0	79.6 to 86.7

WSM000001GEG0098US0

### (3) Adaptors, Elbows and Others

Item	Thread side	Tightening torque		
		N·m	kgf·m	lbf·ft
POA-PF (Nipple with O-ring)	PF 1/8	45 to 53	4.5 to 5.5	33 to 39
	PF 1/4	74 to 83	7.5 to 8.5	55 to 61
	PF 3/8	93.2 to 102	9.50 to 10.5	68.8 to 75.9
	PF 1/2	113 to 122	11.5 to 12.5	83.2 to 90.4
POB-PF (Elbow with O-ring and no nut)	PF 1/8	23 to 26	2.3 to 2.7	17 to 19
	PF 1/4	36 to 43	3.6 to 4.4	26 to 31
	PF 3/8	54 to 63	5.5 to 6.5	40 to 47
	PF 1/2	73 to 83	7.4 to 8.5	54 to 61
Adaptor (NPT)	PF 1/8	9.8 to 14	1.0 to 1.5	7.3 to 10
	PF 1/4	30 to 34	3.0 to 3.5	22 to 25
	PF 3/8	49 to 68	5.0 to 7.0	37 to 50
	PF 1/2	69 to 88	7.0 to 9.0	51 to 65

WSM000001GEG0099US0

## [4] METRIC SCREWS, BOLTS AND NUTS

Grade	8.8 Property class 8.8			10.9 Property class 10.9		
Unit	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
M8	24 to 27	2.4 to 2.8	18 to 20	30 to 34	3.0 to 3.5	22 to 25
M10	48 to 55	4.9 to 5.7	36 to 41	61 to 70	6.2 to 7.2	45 to 52
M12	78 to 90	7.9 to 9.2	58 to 66	103 to 117	10.5 to 12.0	76.0 to 86.7
M14	124 to 147	12.6 to 15.0	91.2 to 108	167 to 196	17.0 to 20.0	123 to 144
M16	197 to 225	20.0 to 23.0	145 to 166	260 to 304	26.5 to 31.0	192 to 224

WSM000001GEG0003US1

## [5] AMERICAN STANDARD SCREWS, BOLTS AND NUTS WITH UNC OR UNF THREADS

Grade	SAE GR.5			SAE GR.8		
Unit	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
1/4	11.7 to 15.7	1.20 to 1.60	8.63 to 11.5	16.3 to 19.7	1.67 to 2.00	12.0 to 14.6
5/16	23.1 to 27.7	2.36 to 2.82	17.0 to 20.5	33 to 39	3.4 to 3.9	25 to 28
3/8	48 to 56	4.9 to 5.7	36 to 41	61 to 73	6.3 to 7.4	45 to 53
1/2	110 to 130	11.3 to 13.2	81.2 to 95.8	150 to 178	15.3 to 18.1	111 to 131
9/16	150 to 178	15.3 to 18.1	111 to 131	217 to 260	22.2 to 26.5	160 to 191
5/8	204 to 244	20.8 to 24.8	151 to 179	299 to 357	30.5 to 36.4	221 to 263

WSM000001GEG0008US1

## [6] PLUGS

Shape	Size	Material of opponent part					
		Ordinariness			Aluminum		
		N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
Tapered screw	R1/8	13 to 21	1.3 to 2.2	9.4 to 15	13 to 19	1.3 to 2.0	9.4 to 14
	R1/4	25 to 44	2.5 to 4.5	18 to 32	25 to 34	2.5 to 3.5	18 to 25
	R3/8	49 to 88	5.0 to 9.0	37 to 65	49 to 58	5.0 to 6.0	37 to 43
	R1/2	58.9 to 107	6.00 to 11.0	43.4 to 79.5	59 to 78	6.0 to 8.0	44 to 57
Straight screw	G1/4	25 to 34	2.5 to 3.5	18 to 25	—	—	—
	G3/8	62 to 82	6.3 to 8.4	46 to 60	—	—	—
	G1/2	49 to 88	5.0 to 9.0	37 to 65	—	—	—

WSM000001GEG0005US1

## 6. MAINTENANCE CHECK LIST

No.	Item	Indication on hour meter														Interval	Refer- ence page	Important
		Dai- ly	50	100	150	200	250	300	350	400	450	500	550	600	650			
1	Clogging of air conditioner condenser screen	Clean	☆													Daily	G-17	
2	Engine oil	Change	★	☆		☆	☆		☆		☆		☆			every 100 Hr	G-24	
3	Engine oil filter	Replace	★		☆				☆				☆			every 200 Hr	G-28	
4	Transmission oil filter	Replace	★					☆					☆			every 300 Hr	G-31	
5	Transmission fluid	Change	★					☆					☆			every 300 Hr	G-31	
6	Front axle case oil	Change						☆					☆			every 300 Hr	G-31	
7	Front axle pivot	Adjust							☆							every 400 Hr	G-31	
8	Engine start system	Check	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	every 50 Hr	G-22	
9	Greasing	—	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	every 50 Hr	G-23	
10	Wheel bolt torque	Check	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	every 50 Hr	G-23	
11	Battery condition	Check		☆		☆		☆		☆		☆		☆		every 100 Hr	G-24	*3
12	Air cleaner element [Double element type] Primary element	Clean		☆		☆		☆		☆		☆		☆		every 100 Hr	G-26	*1
		Replace														every 1 year	G-33	*2
	Air cleaner element [Double element type] Secondary element	Replace														every 1 year	G-33	
13	Fuel filter element	Check		☆		☆		☆		☆		☆		☆		every 100 Hr	G-26	
		Replace								☆						every 400 Hr	G-32	
14	Fan belt	Adjust		☆		☆		☆		☆		☆		☆		every 100 Hr	G-27	
15	Brake	Adjust		☆		☆		☆		☆		☆		☆		every 100 Hr	G-27	
16	Radiator hose and clamp	Check				☆				☆				☆		every 200 Hr	G-28	
		Replace														every 2 year	G-34	

Full Download: <https://www.arepairmanual.com/downloads/kkubota-b3000-aus-service-manual/>

No.	Item	Indication on hour meter												Interval	Reference page	
		50	100	150	200	250	300	350	400	450	500	550	600	650		
17	Fuel line	Check		☆		☆		☆		☆		☆		every 100 Hr	G-27	@
		Replace												every 2 year	G-34	
18	Intake air line	Check			☆			☆				☆		every 200 Hr	G-28	@
		Replace												every 2 year	G-34	
19	Toe-in	Adjust			☆			☆				☆		every 200 Hr	G-29	
20	Tension of air conditioner drive belt	Adjust			☆			☆				☆		every 200 Hr	G-29	
21	Clogging of inner air filter	Clean			☆			☆				☆		every 200 Hr	G-29	
22	Clogging of fresh air filter	Clean			☆			☆				☆		every 200 Hr	G-30	
23	Clogging of air conditioner condenser	Check			☆			☆				☆		every 200 Hr	G-30	
24	Engine valve clearance	Adjust												every 800 Hr	G-32	
25	Air conditioner pipes and hoses	Check												every 1 year	G-33	
		Replace												every 2 year	G-34	
26	CAB isolation cushion	Check												every 2 year	G-34	
27	Fuel injection nozzle injection pressure	Check												every 1500 Hr	G-32	@
28	Injection pump	Check												every 3000 Hr	G-32	
29	Cooling system	Flush												every 2 year	G-35	
30	Coolant	Change												every 2 year	G-35	
31	Fuel system	Bleed												Service as required	G-37	
32	Clutch housing water	Drain													G-38	
33	Fuse	Replace													G-39	
34	Light bulb	Replace													G-40	
35	Washer liquid	Check													G-38	
36	Amount of refrigerant (gas)	Check													G-41	

**■ IMPORTANT**

- The jobs indicated by ★ must be done after the first 50 hours of operation.
- \*1: Air cleaner should be cleaned more often in dusty conditions than in normal conditions.
- \*2: Every year or every 6 times of cleaning.
- \*3: When the battery is used for less than 100 hours per year, check the battery condition by reading the indicator annually.
- The items listed above (@ marked) are registered as emission related critical parts by KUBOTA in the U.S.EPA nonroad emission regulation. As the engine owner, you are responsible for the performance of the required maintenance on the engine according to the above instruction.

Please see the Warranty Statement in detail.

9Y1210623GEG0004US0