

Product: Kubota B3150 B3150SU Service Manual

Full Download: <https://www.arepairmanual.com/downloads/kubota-b3150-b3150su-service-manual/>

# WSM

---

WORKSHOP MANUAL  
TRACTOR

B3150,B3150SU

---

Kubota

Sample of manual. Download All 486 pages at:

<https://www.arepairmanual.com/downloads/kubota-b3150-b3150su-service-manual/>

KiSC issued 05, 2021 A

Product: Kubota B3150 B3150SU Service Manual

Full Download: <https://www.arepairmanual.com/downloads/kubota-b3150-b3150su-service-manual/>

## TO THE READER

This Workshop Manual tells the servicing personnel about the mechanism, servicing and maintenance of the B3150HSD, B3150HSDCC and B3150SUHSD. It contains 4 parts: "**Information**", "**General**", "**Mechanism**" and "**Servicing**".

### ■ **Information**

This section primarily contains information below.

- Safety First
- Safety Decal
- Specifications
- Dimensions

### ■ **General**

This section primarily contains information below.

- Engine Identification
- Model Identification
- General Precautions
- Maintenance Check List
- Check and Maintenance
- Special Tools

### ■ **Mechanism**

This section contains information on the structure and the function of the unit. Before you continue with the subsequent sections, make sure that you read this section.

Refer to the latest version of Workshop Manual (Code No. 9Y021-01870 / 9Y021-18200) for the diesel engine / tractor mechanism that this workshop manual does not include.

### ■ **Servicing**

This section primarily contains information below.

- Troubleshooting
- Servicing Specifications
- Tightening Torques
- Checking, Disassembling and Servicing

All illustrations, photographs and specifications contained in this manual are of the newest information available at the time of publication.

KUBOTA reserves the right to change all information at any time without notice.

Since this manual includes many models, information or illustrations and photographs can show more than one model.

September 2014

© KUBOTA Corporation 2014

Sample of manual. Download All 486 pages at:

<https://www.arepairmanual.com/downloads/kubota-b3150-b3150su-service-manual/>

KiSC issued 05, 2021 A

### **Record of Revisions**

For pdf, use search function {Search word} to find all the revised locations.

<b>Last digit of the Code No.</b>	<b>Month of Revision</b>	<b>Main Revised Point and Corrective Measures {Search word}</b>	<b>Reference Page</b>
<b>1</b>	2015.03	Change the ELECTRICAL CIRCUIT.	8-M1
<b>2</b>	2016.04	Change the location of PTO clutch hydraulic pressure measuring port.	2-M25, 2-S12, 2-S13, 7-M1, 7-M2
<b>3</b>	2021.05	Correcting lift arm free play.	7-S2, 7-S7

# I INFORMATION

# INFORMATION

## CONTENTS

1. SAFETY FIRST .....	I-1
2. SAFETY DECALS .....	I-4
3. SPECIFICATIONS.....	I-8
4. TRAVELING SPEEDS.....	I-9
5. DIMENSIONS .....	I-10

# 1. SAFETY FIRST

## ⚠ SAFETY FIRST

- This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully.
- It is essential that you read the instructions and safety regulations before you try to repair or use this unit.

### ⚠ DANGER

- Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

### ⚠ WARNING

- Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

### ⚠ CAUTION

- Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury.


### ■ IMPORTANT

- Indicates that equipment or property damage could result if instructions are not followed.

### ■ NOTE

- Gives helpful information.


WSM000001INT0001US1



### BEFORE YOU START SERVICE

- Read all instructions and safety instructions in this manual and on your machine safety decals.
- Clean the work area and machine.
- Park the machine on a stable and level ground, and set the parking brake.
- Lower the implement to the ground.
- Stop the engine, then remove the key.
- Disconnect the battery negative cable.
- Hang a "DO NOT OPERATE" tag in the operator station.


WSM000001INT0010US0



### START SAFELY

- Do not do the procedures below when you start the engine.
  - short across starter terminals
  - bypass the safety start switch
- Do not alter or remove any part of machine safety system.
- Before you start the engine, make sure that all shift levers are in neutral positions or in disengaged positions.
- Do not start the engine when you stay on the ground. Start the engine only from operator's seat.


WSM000001INT0015US0




IBM003A



IBM004A



IBM005A



IBM006A

### OPERATE SAFELY


- Do not use the machine after you consume alcohol or medication or when you are tired.
- Put on applicable clothing and safety equipment.
- Use applicable tools only. Do not use alternative tools or parts.
- When 2 or more persons do servicing, make sure that you do it safely.
- Do not operate below the machine that only a jack holds. Always use a safety stand to hold the machine.
- Do not touch the hot parts or parts that turn when the engine operates.
- Do not remove the radiator cap when the engine operates, or immediately after it stops. If not, hot water can spout out from the radiator. Only remove the radiator cap when it is at a sufficiently low temperature to touch with bare hands. Slowly loosen the cap to release the pressure before you remove it fully.
- Released fluid (fuel or hydraulic oil) under pressure can cause damage to the skin and cause serious injury. Release the pressure before you disconnect hydraulic or fuel lines. Tighten all connections before you apply the pressure.
- Do not open a fuel system under high pressure. The fluid under high pressure that stays in fuel lines can cause serious injury. Do not disconnect or repair the fuel lines, sensors, or any other components between the fuel pump and injectors on engines with a common rail fuel system under high pressure.
- Put on an applicable ear protective device (earmuffs or earplugs) to prevent injury against loud noises.
- Be careful about electric shock. The engine generates a high voltage of more than DC100 V in the ECU and is applied to the injector.

WSM000001INI0012USO

### PREVENT A FIRE

- Fuel is very flammable and explosive under some conditions. Do not smoke or let flames or sparks in your work area.
- To prevent sparks from an accidental short circuit, always disconnect the battery negative cable first and connect it last.
- The battery gas can cause an explosion. Keep the sparks and open flame away from the top of battery, especially when you charge the battery.
- Make sure that you do not spill fuel on the engine.

WSM000001INI0005USO



#### KEEP A GOOD AIRFLOW IN THE WORK AREA

- If the engine is in operation, make sure that the area has good airflow. Do not operate the engine in a closed area. The exhaust gas contains poisonous carbon monoxide.


WSM000001INT0006USO



#### DISCARD FLUIDS CORRECTLY

- Do not discard fluids on the ground, down the drain, into a stream, pond, or lake. Obey related environmental protection regulations when you discard oil, fuel, coolant, electrolyte and other dangerous waste.


WSM000001INT0007USO



#### PREVENT ACID BURNS

- Keep electrolyte away from your eyes, hands and clothing. Sulfuric acid in battery electrolyte is poisonous and it can burn your skin and clothing and cause blindness. If you spill electrolyte on yourself, clean yourself with water, and get medical aid immediately.

WSM000001INT0008USO



#### PREPARE FOR EMERGENCIES

- Keep a first aid kit and fire extinguisher ready at all times.
- Keep the emergency contact telephone numbers near your telephone at all times.

WSM000001INT0009USO

## 2. SAFETY DECALS

The following safety decals are installed on the machine. If a decal becomes damaged, illegible or is not on the machine, replace it. The decal part number is listed in the parts list.


WSM000001INT0013US0

(1) Part No. TA240-9848-2 [ROPS Type Only]



1AGAEBMAP071E

(2) Part No. TC230-4956-1





1AGAPAJAP068A

(3) Part No. 6C090-4958-2

Do not get your hands close to engine fan and fan belt.




1AGAIAZAP110A



9Y1211107IC001US

9Y1211107INT0001US0

(1) Part No. 6C200-4959-1



1AGAECEAP013E

(2) Part No. 6C090-4958-2

Do not get your hands close to engine fan and fan belt.



1AGAIJAZAP110A


(3) Part No. 6C430-4965-1



1AGAEAAP003A



(4) Part No. 6C430-4959-1

Do not touch hot surface like muffler, etc.



1AGAEAAP002A

9Y1211107IC002US




9Y1211107INT0002US0

(1) Part No. 6C300-3012-2







(2) Part No. 6C070-4742-2



(3) Part No. 6C150-4743-1 [ROPS Type Only]



(4) Part No. 6C230-4743-1 [CAB Type Only]



9Y1211107IC1003US

9Y1211107IN10003USO

(1) Part No. 3A111-9554-1  
[ROPS Type Only]




1AGAEBMAP080E

(2) Part No. TA040-4902-1  
[CAB Type Only]




1AGAMAOAP0780

(3) Part No. 6C430-4752-1  
[CAB Type Only]




1AGAEEAAP001A

(4) Part No. 6C200-4751-1  
[CAB Type Only]




1AGAEBNAP004E

[ROPS Type]



9Y1211107IC004US

[CAB Type]



9Y1211107INI0004US0

#### **CARE OF DANGER, WARNING AND CAUTION LABELS**

1. Keep danger, warning and caution labels clean and free from obstructing material.
2. Clean danger, warning and caution labels with soap and water, dry with a soft cloth.
3. Replace damaged or missing danger, warning and caution labels with new labels.
4. If a component with danger, warning and caution label(s) affixed is replaced with new part, make sure new label(s) is (are) attached in the same location(s) as the replace component.
5. Mount new danger, warning and caution labels by applying on a clean dry surface and pressing any bubbles to outside edge.

9Y1211107INI0005US0

### 3. SPECIFICATIONS

Model	B3150HSD	B3150SUHSD	B3150HSDCC
PTO power*	17.7 kW (23.7 HP)*		
Engine	Maker	KUBOTA	
	Model	V1505-E3-D26BH-A	V1505-T-E3-D26BHQ-A
	Type	Indirect Injection, Vertical, water-cooled, 4 cycle diesel	
	Number of cylinders	4	
	Bore and stroke	78 × 78.4 mm (3.1 × 3.1 in.)	
	Total displacement	1498 cm <sup>3</sup> (91.5 cu.in.)	
	Engine gross power*	22.8 kW (31.0 HP)*	
	Rated revolution	2500 min <sup>-1</sup> (rpm)	
	Low idling revolution	1100 min <sup>-1</sup> (rpm)	
Capacities	Maximum torque	97.9 N·m (9.98 kgf·m, 72.2 lbf·ft)	
	Battery	12 V, RC: 80 min, CCD: 430 A	
Dimensions	Fuel tank	27 L (7.1 U.S.gals, 5.9 Imp.gals)	
	Engine crankcase (with filter)	4.0 L (4.2 U.S.qts, 3.5 Imp.qts)	
	Engine coolant	4.3 L (4.5 U.S.qts, 3.8 Imp.qts)	5.4 L (5.7 U.S.qts, 4.8 Imp.qts)
	Transmission case	15 L (4.0 U.S.gals, 3.3 Imp.gals)	
Traveling system	Overall length (without 3P)	2570 mm (101.2 in.)	
	Overall width (min. tread)	1365 mm (53.7 in.)	
	Overall height	2245 mm (88.4 in.)	2150 mm (84.6 in.)
	Wheel base	1666 mm (65.6 in.)	
	Minimum ground clearance	370 mm (14.6 in.)	
	Tread	Front	935 mm (36.8 in.)
		Rear	1050 mm (41.3 in.)
Weight		850 kg (1874 lbs)	1070 kg (2359 lbs)
Clutch		Not applicable	
Hydraulic unit	Tires	Front	7-12
		Rear	12.4-16
	Steering		
	Transmission		
	Brake		
	Minimum turning radius (with brake)		
PTO	Hydraulic control system		Position control
	Pump capacity		33.1 L/min (8.7 U.S.gals/min, 7.3 Imp.gals/min)
	3-point hitch		SAE Category 1
	Max. lift force	At lift points 24 in. behind lift point	970 kg (2139 lbs) 760 kg (1676 lbs)
PTO	Rear-PTO		SAE 1-3/8, 6 splines
	PTO / Engine speed		1 speed 540 / 2398 min <sup>-1</sup> (rpm)
	Mid-PTO		—
	PTO / Engine speed		1 speed 2500 / 2500 min <sup>-1</sup> (rpm)

■ NOTE

• \*SAE J1995

The company reserves the right to change the specifications without notice.

9Y1211107INI0006US0

## 4. TRAVELING SPEEDS

(At rated engine rpm)



Model		B3150HSD / B3150SUHSD / B3150HSDCC		
Tire size (Rear)		12.4 - 16 Farm	13.6 - 16 Turf	12.4 - 16 Industry
	Range gear shift lever	km/h (mph)	km/h (mph)	km/h (mph)
Forward	Low	0 to 5.7 (0 to 3.6)	0 to 5.9 (0 to 3.6)	0 to 5.6 (0 to 3.4)
	Middle	0 to 8.5 (0 to 5.3)	0 to 8.7 (0 to 5.4)	0 to 8.3 (0 to 5.1)
	High	0 to 18.0 (0 to 11.2)	0 to 18.5 (0 to 11.5)	0 to 17.6 (0 to 10.9)
Reverse	Low	0 to 4.3 (0 to 2.7)	0 to 4.4 (0 to 2.7)	0 to 4.2 (0 to 2.6)
	Middle	0 to 6.4 (0 to 3.9)	0 to 6.5 (0 to 4.1)	0 to 6.2 (0 to 3.9)
	High	0 to 13.5 (0 to 8.4)	0 to 13.9 (0 to 8.6)	0 to 13.2 (0 to 8.2)

The company reserves the right to change the specifications without notice.

9Y1211107IN10007US0


## 5. DIMENSIONS

### ROPS



9Y1211107IFI001US

9Y1211107INT0008USO

**CABIN**

# **G GENERAL**






# GENERAL

## CONTENTS


1. TRACTOR IDENTIFICATION.....	G-1
[1] MODEL NAME AND SERIAL NUMBER .....	G-1
[2] CYLINDER NUMBER .....	G-2
2. GENERAL PRECAUTIONS.....	G-3
3. HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING .....	G-4
[1] WIRING .....	G-4
[2] BATTERY .....	G-6
[3] FUSE .....	G-6
[4] CONNECTOR .....	G-6
[5] HANDLING OF CIRCUIT TESTER .....	G-7
[6] COLOR OF WIRING .....	G-8
4. LUBRICANTS, FUEL AND COOLANT.....	G-9
5. TIGHTENING TORQUES.....	G-11
[1] GENERAL USE SCREWS, BOLTS AND NUTS .....	G-11
[2] STUD BOLTS .....	G-11
[3] HYDRAULIC FITTINGS .....	G-12
(1) Hydraulic Hose Fittings.....	G-12
(2) Hydraulic Pipe Cap Nuts .....	G-12
(3) Adaptors, Elbows and Others.....	G-12
[4] METRIC SCREWS, BOLTS AND NUTS.....	G-13
[5] AMERICAN STANDARD SCREWS, BOLTS AND NUTS WITH UNC OR UNF THREADS .....	G-13
[6] PLUGS .....	G-13
6. MAINTENANCE CHECK LIST .....	G-14
7. CHECK AND MAINTENANCE .....	G-16
[1] DAILY CHECK.....	G-16
[2] CHECK POINTS OF INITIAL 50 HOURS .....	G-20
[3] CHECK POINTS OF EVERY 50 HOURS .....	G-23
[4] CHECK POINTS OF EVERY 100 HOURS .....	G-26
[5] CHECK POINTS OF EVERY 200 HOURS .....	G-31
[6] CHECK POINTS OF EVERY 400 HOURS .....	G-34
[7] CHECK POINT OF EVERY 800 HOURS .....	G-36
[8] CHECK POINT OF EVERY 1500 HOURS .....	G-36
[9] CHECK POINTS OF EVERY 3000 HOURS .....	G-36
[10] CHECK POINTS OF EVERY 1 YEAR.....	G-36
[11] CHECK POINTS OF EVERY 2 YEARS .....	G-37
[12] OTHERS.....	G-39
8. SPECIAL TOOLS .....	G-44
[1] SPECIAL TOOLS FOR ENGINE .....	G-44
[2] SPECIAL TOOLS FOR TRACTOR .....	G-52
[3] SPECIAL TOOLS FOR CABIN.....	G-56
9. TIRES .....	G-59
[1] TIRE PRESSURE.....	G-59
[2] TREAD ADJUSTMENT .....	G-60
(1) Front Wheels .....	G-60
(2) Rear Wheels.....	G-60
[3] BALLAST .....	G-61
[4] TIRE LIQUID INJECTION .....	G-62
10. IMPLEMENT LIMITATIONS .....	G-64

# 1. TRACTOR IDENTIFICATION

## [1] MODEL NAME AND SERIAL NUMBER



When contacting your local KUBOTA distributor, always specify engine serial number, tractor serial number, ROPS serial number, CAB serial number and hour meter reading.




- (1) Tractor Identification Plate
- (2) Tractor Serial Number
- (3) ROPS Identification  
(ROPS Serial Number)
- (4) CAB Identification Plate  
(CAB Serial Number)
- (5) Engine Serial Number
- (6) Hour Meter

[A] ROPS  
[B] CABIN

9Y1211107GEG0001US0

## [2] CYLINDER NUMBER




The cylinder numbers of KUBOTA diesel engine are designated as shown in the figure.

The sequence of cylinder numbers is given as No.1, No.2, No.3 and No.4 starting from the gear case side.

9Y1211107GEG0002US0

## 2. GENERAL PRECAUTIONS



3TMABAB0P005A


- When you disassemble, carefully put the parts in a clean area to make it easy to find the parts. You must install the screws, bolts and nuts in their initial position to prevent the reassembly errors.
- When it is necessary to use special tools, use KUBOTA special tools. Refer to the drawings when you make special tools that you do not use frequently.
- Before you disassemble or repair machine, make sure that you always disconnect the ground cable from the battery first.
- Remove oil and dirt from parts before you measure.
- Use KUBOTA genuine parts for replacement to keep the machine performance and to make sure of safety.
- You must replace the gaskets and O-rings when you assemble again. Apply grease (1) to new O-rings or oil seals before you assemble.
- When you assemble the external or internal circlips, make sure that the sharp edge (3) faces against the direction from which force (2) is applied.
- When inserting spring pins, their splits must face the direction from which a force is applied. See the figure on the left side.
- To prevent damage to the hydraulic system, use only specified fluid or equivalent.
- Clean the parts before you measure them.
- Tighten the fittings to the specified torque. Too much torque can cause damage to the hydraulic units or the fittings. Not sufficient torque can cause oil leakage.
- When you use a new hose or pipe, tighten the nuts to the specified torque. Then loosen (approx. by 45°) and let them be stable before you tighten to the specified torque (This is not applied to the parts with seal tape).
- When you remove the two ends of a pipe, remove the lower end first.
- Use two pliers in removal and installation. One to hold the stable side, and the other to turn the side you remove to prevent twists.
- Make sure that the sleeves of flared connectors and tapers of hoses are free of dust and scratches.
- After you tighten the fittings, clean the joint and apply the maximum operation pressure 2 to 3 times to check oil leakage.

- (1) Grease  
 (2) Force  
 (3) Sharp Edge  
 (4) Axial Force  
 (5) Rotating Movement

- (A) External Circlip  
 (B) Internal Circlip

WSM000001GEG0106US0

### 3. HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING



3TMABAB0P006A

To ensure safety and prevent damage to the machine and surrounding equipment, obey the following precautions in handling electrical parts and wiring.

■ **IMPORTANT**


- Check electrical wiring for damage and loosened connection every year.
- When removing the battery cables, disconnect the negative cable first. When installing the battery cables, connect the positive cable first.

(1) Negative Terminal

(2) Positive Terminal

WSM000001GEG0062US0

#### [1] WIRING



3TMABAB0P007A

- Securely tighten wiring terminals.


(1) Correct

(Securely Tighten)

(2) Incorrect

(Loosening Leads to damaged Contact)

WSM000001GEG0063US0



3TMABAB0P008A

- Do not let wiring contact dangerous part.


(1) Dangerous Part (Sharp Edge)

(3) Wiring (Correct)

(2) Wiring (Incorrect)

(4) Dangerous Part

WSM000001GEG0064US0



3GFABAB0P003A


- Repair or change torn or aged wiring immediately.

(1) Aged

(3) Electrical Tape

(2) Torn

WSM000001GEG0065US0




- Securely insert grommet.

(1) Grommet

**(A) Correct**  
**(B) Incorrect**

WSM000001GEG0066USO




- Securely clamp, being careful not to damage wiring.

(1) Clamp  
(Wind Clamp Spirally)  
(2) Wire Harness

(3) Clamp  
(4) Welding Dent

WSM000001GEG0067USO




- Clamp wiring so that there is no twist, unnecessary sag, or excessive tension, except for movable part, where sag be required.

(1) Wiring  
(2) Clamp

**(A) Correct**  
**(B) Incorrect**

WSM000001GEG0068USO




- In installing a part, be careful not to get wiring caught by it.

(1) Wiring

**(A) Incorrect**

WSM000001GEG0069USO




- After installing wiring, check protection of terminals and clamped condition of wiring.

(1) Cover  
(Securely Install Cover)

WSM000001GEG0070USO

## [2] BATTERY



3TMABAB0P006B

- Be careful not to confuse positive and negative terminal posts.
- When you remove battery cables, disconnect negative cable first. When you install battery cables, check for polarity and connect positive cable first.
- Do not install any battery with capacity other than is specified (Ah).
- After you connect cables to battery terminal posts, apply high temperature grease to them and securely install terminal covers on them.
- Do not allow dirt and dust to collect on battery.


### DANGER

#### To avoid serious injury or death:

- Be careful not to let battery liquid spill on your skin and clothes. If contaminated, wash it off with water immediately.
- Before you recharge the battery, remove it from the machine.
- Before you recharge, remove cell caps.
- Recharge in a well-ventilated place where there is no open flame nearby, as hydrogen gas and oxygen are formed.

WSM000001GEG0071USO

## [3] FUSE



WSM00001GES001A


- Use fuses with specified capacity. Neither too large nor small capacity fuse is acceptable.
- Never use steel nor copper wire in place of fuse.
- Do not install working light, radio set, etc. on machine which is not provided with reserve power supply.
- Do not install accessories if fuse capacity of reserve power supply is exceeded.

(1) Fuse  
(2) Fusible Link

(3) Slow Blow Fuse

WSM000001GEG0072USO

## [4] CONNECTOR




3TMABAB0P015A

- For connector with lock, push lock to separate.

(A) Push

WSM000001GEG0073USO




3TMABAB0P016A

- In separating connectors, do not pull wire harnesses.
- Hold connector bodies to separate.

(A) Correct

(B) Incorrect

WSM000001GEG0074USO




- Use sandpaper to remove rust from terminals.
- Repair deformed terminal. Make sure that there is no terminal being exposed or displaced.

(1) Exposed Terminal  
(2) Deformed Terminal

(3) Sandpaper  
(4) Rust

WSM000001GEG0075USO




- Make sure that there is no female connector being too open.

(A) Correct

(B) Incorrect

WSM000001GEG0076USO




- Make sure that plastic cover is large enough to cover whole connector.

(1) Cover

(A) Correct  
(B) Incorrect

WSM000001GEG0077USO


## [5] HANDLING OF CIRCUIT TESTER



- Use tester correctly following manual provided with tester.
- Check for polarity and range.

WSM000001GEG0078USO

## [6] COLOR OF WIRING



- Colors of wire are specified to the color codes.
- This symbol of "/" shows color with stripe (s).

**(An example)**

Red stripe on white color: W/R

Color of wiring	Color code
Black	B
Brown	Br
Green	G
Gray	Gy or Gr
Blue	L
Light Green	Lg
Orange	Or
Pink	P
Purple	Pu or V
Red	R
Sky Blue	Sb
White	W
Yellow	Y

(1) Wire Color

(2) Stripe

WSM000001GEG0079US0

## 4. LUBRICANTS, FUEL AND COOLANT

No.	Locations	Capacities		Lubricants
		B3150HSD / B3150HSDCC / B3150SUHSD		
1	Fuel	27 L 7.1 U.S.gals 5.9 Imp.gals		No.2-D S15 diesel fuel No. 1-D diesel fuel if temperature is below -10 °C (14 °F)
2	Coolant (with recovery tank)	[ROPS] 4.3 L 4.5 U.S.qts 3.8 Imp.qts	[CAB] 5.4 L 5.7 U.S.qts 4.8 Imp.qts	Fresh clean soft water with anti-freeze
3	Washer liquid	1.5 L 1.6 U.S.qts 1.3 Imp.qts		Automobile washer liquid
4	Engine crankcase (with filter)	4.0 L 4.2 U.S.qts 3.6 Imp.qts		<b>Engine oil</b> Refer to next page. <ul style="list-style-type: none"> <li>Above 25 °C (77 °F) SAE30, SAE10W-30 or 15W-40</li> <li>-10 to 25 °C (14 to 77 °F) SAE20, SAE10W-30 or 15W-40</li> <li>Below -10 °C (14 °F) SAE10W-30</li> </ul>
5	Transmission case	15 L 4.0 U.S.gals 3.3 Imp.gals		KUBOTA UDT or SUPER UDT fluid*
6	Front axle case	4.7 L 5.0 U.S.qts 4.1 Imp.qts		KUBOTA UDT or SUPER UDT fluid* or SAE80 - SAE 90 gear oil

Grease				
No.	Greasing	No. of greasing points	Capacity	Type of grease
7	Top link	1	Until grease overflows	Multipurpose grease NLGI-2 or NLGI-1 (GC-LB)
	Lifting rod (RH)	1		
	Speed control pedal	1 [CAB Type]		
	Brake pedal	1 [ROPS Type]		
	Battery terminal	2	Moderate amount	

### ■ NOTE

- The product name of KUBOTA genuine UDT fluid may be different from that in the Operator's Manual depending on countries or territories.

9Y1211107GEG0003US0

**■ NOTE****Engine Oil:**

- Oil used in the engine should have an American Petroleum Institute (API) service classification and Proper SAE Engine Oil according to the ambient temperatures as shown above.
- With the emission control now in effect, the CF-4 and CG-4 lubricating oils have been developed for use of a low-sulfur fuel on on-road vehicle engines. When an off-road vehicle engine runs on a high-sulfur fuel, it is advisable to employ the "CF or better" lubricating oil with a high Total Base Number (TBN of 10 minimum).
- Refer to the following table for the suitable API classification engine oil according to the engine type (with internal EGR, external EGR or non-EGR) and the fuel (low-sulfur or high-sulfur fuel).

Fuel used	Engine oil classification (API classification)	
	Oil class of engines except external EGR	Oil class of engines with external EGR
High Sulfur Fuel [ $\geq 0.05\%$ (500 ppm)]	<b>CF</b> (If the "CF-4, CG-4, CH-4 or CI-4" lubricating oil is used with a high-sulfur fuel, change the lubricating oil at shorter intervals. (approximately half))	—
Low Sulfur Fuel [ $< 0.05\%$ (500 ppm)] or Ultra Low Sulfur Fuel [ $< 0.0015\%$ (15 ppm)]	<b>CF, CF-4, CG-4, CH-4 or CI-4</b>	<b>CF or CI-4</b> (Class CF-4, CG-4 and CH-4 engine oils cannot be used on EGR type engines)

EGR: Exhaust Gas Re-circulation

- The CJ-4 engine oil is intended for DPF (Diesel Particulate Filter) type engines, and cannot be used on this tractor.

	Except external EGR	With external EGR
Models	B3150, B3150SU	—

**Fuel:**

- Cetane number of 45 minimum. Cetane number greater than 50 is preferred, especially for temperatures below  $-20^{\circ}\text{C}$  or elevations above 1500 m.
- If diesel fuel with sulfur content greater than 0.5 % (5000 ppm) sulfur content is used, reduce the service interval for engine oil and filter by 50 %.
- NEVER use diesel fuel with sulfur content greater than 0.05 % (500 ppm) for EXTERNAL EGR type engine.
- DO NOT use diesel fuel with sulfur content greater than 1.0 % (10000 ppm).
- Diesel fuels specified to EN 590 or ASTM D975 are recommended.
- No.2-D is a distillate fuel of lower volatility for engines in industrial and heavy mobile service (SAE J313 JUN87).

**Transmission Oil:**

- The oil used to lubricate the transmission is also used as hydraulic fluid. To insure proper operation of the hydraulic system and to complete lubrication of the transmission, it is important that a multi-grade transmission fluid is used in this system. We recommend the use of KUBOTA UDT or SUPER UDT fluid for optimum protection and performance. (Consult your local KUBOTA Dealer for further detail.) Do not mix different brands together.
- Indicated capacities of water and oil are manufacturer's estimate.

9Y1211107GEG0004USO

## 5. TIGHTENING TORQUES

### [1] GENERAL USE SCREWS, BOLTS AND NUTS

Tighten screws, bolts and nuts whose tightening torques are not specified in this Workshop Manual according to the table below.

Indication on top of bolt	No-grade or 4T			7 7T			9 9T								
Indication on top of nut	No-grade or 4T									6T					
Material of opponent part	Ordinariness			Aluminum			Ordinariness			Aluminum			Ordinariness		
Unit	N·m	kgf·m	Ibf·ft	N·m	kgf·m	Ibf·ft	N·m	kgf·m	Ibf·ft	N·m	kgf·m	Ibf·ft	N·m	kgf·m	Ibf·ft
M6	7.9 to 9.3	0.80 to 0.95	5.8 to 6.8	7.9 to 8.8	0.80 to 0.90	5.8 to 6.5	9.81 to 11.2	1.00 to 1.15	7.24 to 8.31	7.9 to 8.8	0.80 to 0.90	5.8 to 6.5	12.3 to 14.2	1.25 to 1.45	9.05 to 10.4
M8	18 to 20	1.8 to 2.1	13 to 15	17 to 19	1.7 to 2.0	13 to 14	24 to 27	2.4 to 2.8	18 to 20	18 to 20	1.8 to 2.1	13 to 15	30 to 34	3.0 to 3.5	22 to 25
M10	40 to 45	4.0 to 4.6	29 to 33	32 to 34	3.2 to 3.5	24 to 25	48 to 55	4.9 to 5.7	36 to 41	40 to 44	4.0 to 4.5	29 to 32	61 to 70	6.2 to 7.2	45 to 52
M12	63 to 72	6.4 to 7.4	47 to 53	—	—	—	78 to 90	7.9 to 9.2	58 to 66	63 to 72	6.4 to 7.4	47 to 53	103 to 117	10.5 to 12.0	76.0 to 86.7
M14	108 to 125	11.0 to 12.8	79.6 to 92.5	—	—	—	124 to 147	12.6 to 15.0	91.2 to 108	—	—	—	167 to 196	17.0 to 20.0	123 to 144
M16	167 to 191	17.0 to 19.5	123 to 141	—	—	—	197 to 225	20.0 to 23.0	145 to 166	—	—	—	260 to 304	26.5 to 31.0	192 to 224
M18	246 to 284	25.0 to 29.0	181 to 209	—	—	—	275 to 318	28.0 to 32.5	203 to 235	—	—	—	344 to 402	35.0 to 41.0	254 to 296
M20	334 to 392	34.0 to 40.0	246 to 289	—	—	—	368 to 431	37.5 to 44.0	272 to 318	—	—	—	491 to 568	50.0 to 58.0	362 to 419

WSM000001GEG0001US0

### [2] STUD BOLTS

Material of opponent part	Ordinariness			Aluminum		
Unit	N·m	kgf·m	Ibf·ft	N·m	kgf·m	Ibf·ft
M8	12 to 15	1.2 to 1.6	8.7 to 11	8.9 to 11	0.90 to 1.2	6.5 to 8.6
M10	25 to 31	2.5 to 3.2	18 to 23	20 to 25	2.0 to 2.6	15 to 18
M12	30 to 49	3.0 to 5.0	22 to 36	31	3.2	23
M14	62 to 73	6.3 to 7.5	46 to 54	—	—	—
M16	98.1 to 112	10.0 to 11.5	72.4 to 83.1	—	—	—
M18	172 to 201	17.5 to 20.5	127 to 148	—	—	—

WSM000001GEG0002US0

**[3] HYDRAULIC FITTINGS**[-service-manual/](https://www.arepairmanual.com/downloads/kubota-b3150-b3150su-service-manual/)**(1) Hydraulic Hose Fittings**

Hose size	Thread size	Tightening torque		
		N·m	kgf·m	lbf·ft
02	1/8	13.8 to 15.6	1.40 to 1.60	10.2 to 11.5
03	1/4	22.6 to 27.4	2.30 to 2.80	16.7 to 20.2
04				
05	3/8	45.2 to 52.9	4.60 to 5.40	33.3 to 39.0
06				

WSM000001GEG0097US0

**(2) Hydraulic Pipe Cap Nuts**

Pipe size	Tightening torque		
	N·m	kgf·m	lbf·ft
φ4 × t1.0	19.7 to 29.4	2.00 to 3.00	14.5 to 21.6
φ6 × t1.0	24.6 to 34.3	2.50 to 3.50	18.1 to 25.3
φ8 × t1.0	29.5 to 39.2	3.00 to 4.00	21.7 to 28.9
φ10 × t1.0	39.3 to 49.0	4.00 to 5.00	29.0 to 36.1
φ12 × t1.5	49.1 to 68.6	5.00 to 7.00	36.2 to 50.6
φ15 × t1.6	108 to 117	11.0 to 12.0	79.6 to 86.7
φ18 × t1.6	108 to 117	11.0 to 12.0	79.6 to 86.7

WSM000001GEG0098US0

**(3) Adaptors, Elbows and Others**

Item	Thread size	Tightening torque		
		N·m	kgf·m	lbf·ft
Fitting with O-ring	G 1/8	45 to 53	4.5 to 5.5	33 to 39
	G 1/4	74 to 83	7.5 to 8.5	55 to 61
	G 3/8	93.2 to 102	9.50 to 10.5	68.8 to 75.9
	G 1/2	113 to 122	11.5 to 12.5	83.2 to 90.4
Elbow with O-ring	G 1/8	23 to 26	2.3 to 2.7	17 to 19
	G 1/4	36 to 43	3.6 to 4.4	26 to 31
	G 3/8	54 to 63	5.5 to 6.5	40 to 47
	G 1/2	73 to 83	7.4 to 8.5	54 to 61
Adaptor	G 1/8	9.8 to 14	1.0 to 1.5	7.3 to 10
	G 1/4	30 to 34	3.0 to 3.5	22 to 25
	G 3/8	49 to 68	5.0 to 7.0	37 to 50
	G 1/2	69 to 88	7.0 to 9.0	51 to 65

WSM000001GEG0099US0