

Product: Kubota L2900 L3300 L3600 L4200 Service Manual

Full Download: <https://www.arepairmanual.com/downloads/kubota-l2900-l3300-l3600-l4200-service-manual/>

## TO THE READER

This Workshop Manual has been prepared to provide servicing personnel with information on the mechanism, service and maintenance of KUBOTA Tractors L2900, L3300, L3600 and L4200. It is divided into two parts, "Mechanism" and "Servicing" for each section.

### ■ Mechanism

Information on the construction and function are included. This part should be understood before proceeding with troubleshooting, disassembling and servicing.

### ■ Servicing

Under the heading "General" section comes general precautions, check and maintenance and special tools. Other section, there are troubleshooting, servicing specification lists, checking and adjusting, disassembling and assembling, and servicing which cover procedures, precautions, factory specifications and allowable limits.

All information, illustrations and specifications contained in this manual are based on the latest production information available at the time of publication.

The right is reserved to make changes in all information at any time without notice.

September '94

© KUBOTA Corporation 1994

Sample of manual. Download All 791 pages at:

<https://www.arepairmanual.com/downloads/kubota-l2900-l3300-l3600-l4200-service-manual/>

## SAFETY FIRST

This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and decals on the machine itself to warn of the possibility of personal injury. Read these instructions carefully. It is essential that you read the instructions and safety regulations before you attempt to repair or use this unit.

 **DANGER** : Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

 **WARNING** : Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

 **CAUTION** : Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

**■ IMPORTANT** : Indicates that equipment or property damage could result if instructions are not followed.

**■ NOTE** : Gives helpful information.

## SAFETY SERVICING AND REPAIRING

**(1) Before working on the machine :**

- Park the machine on a firm and level ground, and set the parking brake.
  - Lower the implement or mower to the ground.
  - Stop the engine, and remove the key.
  - Disconnect the battery's ground cable.
  - Clean the work area and machine.
- (2) Do not work on the machine while under the influence of alcohol, medication, or other substances or while fatigued.
- (3) Do not wear a necktie, scarf, necklace, loose or bulky clothing when you work near machine tools or moving parts.
- (4) Use tools appropriate to the work. Makeshift tools, parts, and procedures will not make good repairs.
- (5) When servicing is performed together by two or more persons, take care to perform all work safely.
- (6) Do not work under the machine that is supported solely by a jack. Always support the machine by safety stands.

- (7) If the engine must be running to do same work, make sure the area is well ventilated. Never run the engine in a closed area. The exhaust gas contains poisonous carbon monoxide.
- (8) Do not touch the rotating or hot parts while the engine is running.
- (9) Fuel is extremely flammable and explosive under certain conditions. Do not smoke or allow flames or sparks in your working area.
- (10) To avoid sparks from an accidental short circuit, always disconnect the battery's ground cable first and connect it last.
- (11) Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, clothing and cause blindness if splashed into eyes. Keep electrolyte away from eyes, hands and clothing. If you spill electrolyte on yourself, flush with water, and get medical attention immediately.
- (12) Battery gas can explode. Keep sparks and open flame away from the top of battery, especially when charging the battery.
- (13) Never remove the radiator cap while the engine is running, or immediately after stopping. Otherwise, hot water will spout out from radiator. Wait for more than ten minutes to cool the radiator, before removing the cap.
- (14) Escaping fluid (fuel or hydraulic oil) under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting hydraulic or fuel lines. Tighten all connections before applying pressure.
- (15) Do not start the engine by shorting across starter terminals.
- (16) Unauthorized modifications to the machine may impair the function and / or safety and affect machine life.
- (17) Do not alter or remove any part of machine safety system.
- (18) Keep a first aid kit and fire extinguisher handy at all times.
- (19) Be sure to chock the wheels to prevent accident during servicing the machine.

## SAFETY DECALS

- The following safety decals are installed on the machine.

If a decal becomes damaged, illegible or is not on the machine, replace it. The decal part number is listed in the parts list.

① Part No. TA040-49652



**DANGER** TA040-49652 ©  
TO AVOID POSSIBLE INJURY OR DEATH  
FROM A MACHINE RUNAWAY.  
1. Do not start engine by shorting across  
starter terminals or bypassing the safety start  
switch. Machine may start in gear and move  
if normal starting circuitry is bypassed.  
2. Start engine only from operator's seat with  
transmission and PTO OFF.  
Never start engine while standing on the ground.

② Part No. TA044-4932-1



TO AVOID PERSONAL INJURY OR DEATH FROM ROLL-OVER:  
1. Kubota recommends the use of a Roll-Over Protective  
Structures (ROPS) in almost all applications.  
2. Remove the ROPS only when it substantially interferes with  
operation or itself presents a safety risk. (Examples  
include work in orchards and vineyards.) ALWAYS REINSTALL  
IT BEFORE USING THE TRACTOR IN OTHER APPLICATIONS.  
3. For further details, consult your Operator's Manual or your  
local dealer.

TA044-49321 ©

③ Part No. TA040-4933-2



BEFORE DISMOUNTING TRACTOR:

1. PARK ON LEVEL GROUND WHENEVER POSSIBLE.  
If parking on a gradient, position tractor at right angles  
to the slope
2. ALWAYS SET PARKING BRAKE.  
Leaving transmission in gear with the engine stopped will  
not prevent tractor from rolling.
3. LOWER ALL IMPLEMENTS TO THE GROUND.  
Failure to comply to this warning may allow the wheels to  
slip, and could cause injury or death
4. LOCK SHUTTLE SHIFT LEVER IN NEUTRAL  
POSITION AND STOP THE ENGINE.

TA040-49332 ©

④ Part No. TA040-4959-3



**WARNING** TA040-49593 ©


TO AVOID PERSONAL INJURY.

1. Keep PTO shield in place at all times.
2. Do not operate the PTO at speeds faster  
than the speed recommended by the  
implement manufacturer.
3. For trailing PTO-driven implements, set  
drawbar at towing position.  
(see operator's manual)


⑤ Part No. TA040-4956-1

Diesel fuel  
only

No fire



TA040-49561



## ⑨ Part No. 35260-3491-3

**CAUTION**

35260-34913 ⑨

**TO AVOID PERSONAL INJURY:**


1. Read and understand the operator's manual before operation.
2. Before starting the engine, make sure that everyone is at a safe distance from the tractor and that the PTO is OFF.
3. Do not allow passengers on the tractor at any time.
4. Before allowing other people to use the tractor, have them read the operator's manual.
5. Check the tightness of all nuts and bolts regularly.
6. Keep all shields in place and stay away from all moving parts.
7. Lock the two brake pedals together before driving on the road.
8. Slow down for turns, or rough roads, or when applying individual brakes.
9. On public roads use SMV emblem and hazard lights, if required by local traffic and safety regulations.
10. Pull only from the drawbar.
11. Before dismounting, lower the implement, set the parking brake, stop the engine and remove the key.

⑩ Part No. TA040-4957-1  
Stay clear of engine fan and fanbelt.


TA040-49571




⑪ Part No. TA040-4958-1  
Do not touch hot surface like muffer, etc.

TA040-49581



B167F002





## SPECIFICATIONS

Model	L2900 with ROPS		
	4WD		
Maximum PTO power		18.7 kW (25.4 PS)*	
Engine NET power (DIN)		22.7 kW (30.9 PS)*	
Engine	Model	D1503-L-A	
	Type	Indirect injection, Vertical, Water-Cooled, 4-cycle diesel engine	
	Number of cylinders	3	
	Bore and stroke	83 x 92.4 mm (3.3 x 3.6 in.)	
	Total displacement	1499 cm <sup>3</sup> (91.5 cu.in.)	
	Rated revolution	2700 min <sup>-1</sup> (45.0 r/s, 2700 rpm)	
	Combustion chamber	Spherical type (E-TVCS)	
	Fuel injection pump	Bosch type mini pump (PFR3M)	
	Governor	Centrifugal ball mechanical governor	
	Injection nozzle	Throttle type	
	Injection timing	Before T.D.C. 0.314 rad (18°)	
	Injection order	1-2-3	
	Injection pressure	13.73 MPa (140 kgf/cm <sup>2</sup> , 1991 psi)	
	Compression ratio	23 : 1	
	Lubricating system	Forced lubrication by trochoidal pump	
	Cooling system	Pressurized radiator, Forced circulation with water pump	
	Starting system	Electric starting with cell starter 12 V, 1.2 kW	
	Alternator	12 V, 480 W (40 AMPS)	
	Battery	SAE 490- Cold cranking Amps at -18 °C (- 0.4 °F) 12 V (65 AH) (75D26R-MF)	
Capacities	Fuel	Diesel fuel No. 1 [below - 10 °C (14 °F)] Diesel fuel No. 2 [above - 10 °C (14 °F)]	
	Lubricating oil	CC or CD (API grade)	
	Weight (Dry)	176 kg (388 lbs)	
	Fuel tank	35.0 l (9.2 U.S.gals., 7.7 Imp.gals.)	
	Engine crankcase	5.5 l (5.8 U.S.qts., 4.8 Imp.qts.)	
Dimensions with Std. tires)	Engine coolant	7.0 l (7.4 U.S.qts., 6.2 Imp.qts.)	
	Transmission case	39.0 l (10.3 U.S.gals., 8.6 Imp.gals.)	
	Front axle case	5.5 l (5.8 U.S.qts., 4.8 Imp.qts.)	
	Overall length (without 3P)	2820 mm (111.0 in.)	
	Overall length (with 3P)	3060 mm (120.5 in.)	
	Overall width (minimum tread)	1365 mm (53.7 in.)	
	Overall height (Top of ROPS)	2320 mm (91.3 in.)	
	Overall height (Top of steering wheel)	1510 mm (59.4 in.)	
	Wheel base	1670 mm (65.7 in.)	
	Min. ground clearance	340 mm (13.4 in.)	
	Tread	Front mm (in.)	1100 (43.3)
		Rear mm (in.)	1035 (40.7), 1125 (44.3), 1220 (48.0), 1305 (51.4), 1400 (55.1)

Note : \* Manufacturer's estimate

Model			L2900 with ROPS	
			4WD	
Traveling system	Tire size (Std. tires)	Front	7 – 16	
		Rear	11.2 – 24	
	Clutch		Dry type single stage	
	Steering		Hydrostatic power steering	
	Transmission		Synchronized shuttle and synchronized transmission (8 forward and 8 reverse speeds)	
	Brake	Traveling	Wet disc type	
		Parking	Connected with the traveling brake	
Differential		Bevel gear		
Hydraulic system	Hydraulic control system		Position control, Draft and Mixed control (if equipped)	
	Pump capacity (Max. flow rate)		Main pump 26.4 $\ell/\text{min}$ (7.0 GPM) Power steering pump 17.7 $\ell/\text{min}$ (4.7 GPM)	
	Three point hitch		SAE Category I	
	Maximum lifting capacity (24 in. behind lower link end)		1000 kg (2200 lbs)	
Rear PTO	PTO shaft		SAE 1-3/8, 6-splines (with overrunning clutch)	
	Revolution	Transmission PTO	1 speed : 540 $\text{min}^{-1}$ (9.0 r/s, 540 rpm) / engine 2670 $\text{min}^{-1}$ (44.5 r/s, 2670 rpm)	
		Independent PTO	1 speed : 540 $\text{min}^{-1}$ (9.0 r/s, 540 rpm) / engine 2700 $\text{min}^{-1}$ (45.0 r/s, 2700 rpm)	
Mid PTO	PTO shaft		USA No. 5 (KUBOTA 10-tooth) involute spline	
	Revolution	Transmission PTO	1 speed : 2000 $\text{min}^{-1}$ (33.3 r/s, 2000 rpm) / engine 2623 $\text{min}^{-1}$ (43.7 r/s, 2623 rpm)	
		Independent PTO	1 speed : 2000 $\text{min}^{-1}$ (33.3 r/s, 2000 rpm) / engine 2653 $\text{min}^{-1}$ (44.2 r/s, 2653 rpm)	
Min. turning radius (with brake)		2.3 m (7.6 ft)		
Traction system		Fixed drawbar		
Weight (with ROPS)		1290 kg (2844 lbs)		

## SPECIFICATIONS (Continued)

Model	L3300 with ROPS		L3300 with CABIN
	4WD	4WD-GST	4WD
Maximum PTO power	20.9 kW (28.4 PS)*		
Engine NET power (DIN)	24.9 kW (33.8 PS)*		
Engine	Model	D1703-A	
	Type	Indirect injection, Vertical, Water-Cooled, 4-cycle diesel engine	
	Number of cylinders	3	
	Bore and stroke	87 x 92.4 mm (3.4 x 3.6 in.)	
	Total displacement	1647 cm <sup>3</sup> (100.5 cu.in.)	
	Rated revolution	2700 min <sup>-1</sup> (45.0 r/s, 2700 rpm)	
	Combustion chamber	Spherical type (E-TVCS)	
	Fuel injection pump	Bosch type mini pump (PFR3M)	
	Governor	Centrifugal ball mechanical governor	
	Injection nozzle	Throttle type	
	Injection timing	Before T.D.C. 0.314 rad (18°)	
	Injection order	1-2-3	
	Injection pressure	13.73 MPa (140 kgf/cm <sup>2</sup> , 1991 psi)	
	Compression ratio	23 : 1	
	Lubricating system	Forced lubrication by trochoidal pump	
	Cooling system	Pressurized radiator, Forced circulation with water pump	
Capacities	Starting system	Electric starting with cell starter 12 V, 1.2 kW	
	Alternator	12 V, 480 W (40 AMPS)	12 V, 540 W (45 AMPS)
	Battery	SAE 490- Cold cranking Amps at -18 °C (-0.4 °F) 12 V (65 AH) (75D26R-MF)	
	Fuel	Diesel fuel No. 1 [below - 10 °C (14 °F)] Diesel fuel No. 2 [above - 10 °C (14 °F)]	
	Lubricating oil	CC or CD (API grade)	
Dimensions (with Std. tires)	Weight (Dry)	176 kg (388 lbs)	
	Fuel tank	35.0 l (9.2 U.S.gals., 7.7 Imp.gals.)	
	Engine crankcase	5.5 l (5.8 U.S.qts., 4.8 Imp.qts.)	
	Engine coolant	7.0 l (7.4 U.S.qts., 6.2 Imp.qts.)	8.2 l (9.2 U.S.qts., 7.2 Imp.qts.)
	Transmission case	39.0 l (10.3 U.S.gals., 8.6 Imp.gals.)	
	Front axle case	5.5 l (5.8 U.S.qts., 4.8 Imp.qts.)	
	Overall length (without 3P)	2850 mm (112.2 in.)	
	Overall length (with 3P)	3060 mm (120.5 in.)	
	Overall width (minimum tread)	1365 mm (53.7 in.)	
	Overall height	2340 mm (92.1 in.)	2165 mm (85.2 in.)
	Overall height (Top of steering wheel)	1520 mm (59.8 in.)	
	Wheel base	1670 mm (65.7 in.)	
	Min. ground clearance	340 mm (13.4 in.)	
	Tread	Front mm (in.)	1100 (43.3)
		Rear mm (in.)	1035 (40.7), 1125 (44.3), 1220 (48.0), 1305 (51.4), 1400 (55.1)

Note : \* Manufacturer's estimate

Model	L3300 with ROPS			L3300 with CABIN			
	4WD	4WD-GST	4WD				
Traveling system	Tire size (Std. tires)	Front	7 – 16				
		Rear	12.4 – 24				
	Clutch		Dry type single stage				
	Steering		Hydrostatic power steering				
	Transmission		Synchronized shuttle and synchronized transmission (8 forward and 8 reverse speeds)	Glide shift transmission (8 forward and 8 reverse)	Synchronized shuttle and synchronized transmission (8 forward and 8 reverse speeds)		
	Brake	Traveling	Wet disc type				
		Parking	Connected with the traveling brake				
Hydraulic system	Differential		Bevel gear				
	Hydraulic control system		Position control, Draft and Mixed control (if equipped)				
	Pump capacity (Max. flow rate)		Main pump 26.4 l/min (7.0 GPM) Power steering pump 17.7 l/min (4.7 GPM)				
	Three point hitch		SAE Category I				
	Maximum lifting capacity	At lift point	1300 kg (2866 lbs)				
		24 in. behind lift point	1000 kg (2200 lbs)				
Rear PTO	PTO shaft		SAE 1-3/8, 6-splines				
	Revolution	Transmission PTO	1 speed : 540 min <sup>-1</sup> (9.0 r/s, 540 rpm) / engine 2670 min <sup>-1</sup> (44.5 r/s, 2670 rpm)				
		Independent PTO	1 speed : 540 min <sup>-1</sup> (9.0 r/s, 540 rpm) / engine 2700 min <sup>-1</sup> (45.0 r/s, 2700 rpm)				
Mid PTO	PTO shaft		USA No. 5 (KUBOTA 10-tooth) involute spline				
	Revolution	Transmission PTO	1 speed : 2000 min <sup>-1</sup> (33.3 r/s, 2000 rpm) / engine 2623 min <sup>-1</sup> (43.7 r/s, 2623 rpm)				
		Independent PTO	1 speed : 2000 min <sup>-1</sup> (33.3 r/s, 2000 rpm) / engine 2653 min <sup>-1</sup> (44.2 r/s, 2653 rpm)				
Min. turning radius (with brake)			2.3 m (7.6 ft)				
Traction system			Fixed drawbar				
Weight		1320 kg (2910 lbs)	1330 kg (2932 lbs)	1465 kg (3230 lbs)			

## SPECIFICATIONS (Continued)

Model	L3600 with ROPS		L3600 with CABIN			
	4WD	4WD-GST	4WD	4WD-GST		
Maximum PTO power	23.1 kW (31.4 PS)*					
Engine NET power (DIN)	27.3 kW (37.1 PS)*					
Engine	Model	V1903-A				
	Type	Indirect injection, Vertical, Water-Cooled, 4-cycle diesel engine				
	Number of cylinders	4				
	Bore and stroke	80 x 92.4 mm (3.1 x 3.6 in.)				
	Total displacement	1857 cm <sup>3</sup> (113.3 cu.in.)				
	Rated revolution	2600 min <sup>-1</sup> (43.3 r/s, 2600 rpm)				
	Combustion chamber	Spherical type (E-TVCS)				
	Fuel injection pump	Bosch type mini pump (PFR4M)				
	Governor	Centrifugal ball mechanical governor				
	Injection nozzle	Throttle type				
	Injection timing	Before T.D.C. 0.314 rad (18°)				
	Injection order	1-3-4-2				
	Injection pressure	13.73 MPa (140 kgf/cm <sup>2</sup> , 1991 psi)				
	Compression ratio	23 : 1				
	Lubricating system	Forced lubrication by trochoidal pump				
	Cooling system	Pressurized radiator, Forced circulation with water pump				
Capacities	Starting system	Electric starting with cell starter 12 V, 1.4 kW				
	Alternator	12 V, 480 W (40 AMPS)	12 V, 540 W (45 AMPS)			
	Battery	SAE 447- Cold cranking Amps at -18 °C (-0.4 °F) 12 V (70 AH) (75D31R-MF)				
	Fuel	Diesel fuel No. 1 [below - 10 °C (14 °F)] Diesel fuel No. 2 [above - 10 °C (14 °F)]				
	Lubricating oil	CC or CD (API grade)				
	Weight (Dry)	206.5 kg (455 lbs)				
	Fuel tank	35.0 l (9.2 U.S.gals., 7.7 Imp.gals.)				
	Engine crankcase	7.6 l (8.0 U.S.qts., 7.0 Imp.qts.)				
	Engine coolant	7.5 l (7.9 U.S.qts., 7.0 Imp.qts.)	8.7 l (9.2 U.S.qts., 7.6 Imp.qts.)			
	Transmission case	39.0 l (10.3 U.S.gals., 8.6 Imp.gals.)				
Dimensions (with Std. tires)	Front axle case	5.5 l (5.8 U.S.qts., 4.8 Imp.qts.)				
	Overall length (without 3P)	3000 mm (118.1 in.)				
	Overall length (with 3P)	3210 mm (126.4 in.)				
	Overall width (minimum tread)	1435 mm (56.5 in.)				
	Overall height	2315 mm (91.1 in.)	2155 mm (84.8 in.)			
	Overall height (Top of steering wheel)	1530 mm (60.2 in.)				
	Wheel base	1805 mm (71.1 in.)				
	Min. ground clearance (Under transmission)	340 mm (13.4 in.)				
Tread	Front mm (in.)	1145 (45.1)				
	Rear mm (in.)	1080 (42.5), 1175 (46.3), 1205 (47.4), 1300 (51.2)				

Note : \* Manufacturer's estimate

Model			L3600 with ROPS		L3600 with CABIN		
			4WD	4WD-GST	4WD	4WD-GST	
	Tire size (Std. tires)	Front	8 - 16				
Traveling system	Tire size (Std. tires)	Rear	13.6 - 24				
		Clutch	Dry type single stage				
	Steering		Hydrostatic power steering				
	Transmission		Synchronized shuttle and synchronized transmission (8 forward and 8 reverse speeds)	Glide shift transmission (8 forward and 8 reverse speeds)	Synchronized shuttle and synchronized transmission (8 forward and 8 reverse speeds)	Glide shift transmission (8 forward and 8 reverse speeds)	
	Brake	Traveling	Wet disc type				
		Parking	Connected with the traveling brake				
	Differential		Bevel gear				
Hydraulic system	Hydraulic control system		Position control, Draft and Mixed control (if equipped)				
	Pump capacity (Max. flow rate)		Main pump 29.5 L/min (7.8 GPM) Power steering pump 15.3 L/min (4.0 GPM)				
	Three point hitch		SAE Category I				
	Maximum lifting capacity	At lift point	1300 kg (2866 lbs)				
		24 in. behind lift points	1050 kg (2315 lbs)				
Rear PTO	PTO shaft		SAE 1-3/8, 6-splines (with overrunning clutch)				
	Revolution	Transmission PTO	1 speed : 540 min <sup>-1</sup> (9.0 r/s, 540 rpm) / engine 2447 min <sup>-1</sup> (40.8 r/s, 2447 rpm)				
		Independent PTO	1 speed : 540 min <sup>-1</sup> (9.0 r/s, 540 rpm) / engine 2475 min <sup>-1</sup> (41.3 r/s, 2475 rpm)				
Mid PTO	PTO shaft		USA No. 5 (KUBOTA 10-tooth) involute spline				
	Revolution	Transmission PTO	1 speed : 2000 min <sup>-1</sup> (33.3 r/s, 2000 rpm) / engine 2404 min <sup>-1</sup> (40.1 r/s, 2404 rpm)				
		Independent PTO	1 speed : 2000 min <sup>-1</sup> (33.3 r/s, 2000 rpm) / engine 2432 min <sup>-1</sup> (40.5 r/s, 2432 rpm)				
Min. turning radius (with brake)			2.3 m (7.5 ft)				
Traction system			Fixed drawbar				
Weight		1420 kg (3131 lbs)	1430 kg (3153 lbs)	1545 kg (3406 lbs)	1555 kg (3428 lbs)		

## SPECIFICATIONS (Continued)

Model	L4200 with ROPS		L4200 with CABIN			
	4WD	4WD-GST	4WD	4WD-GST		
Maximum PTO power			27.6 kW (37.5 PS)*			
Engine NET power (DIN)			32.1 kW (43.7 PS)*			
Engine	Model	V2203-A				
	Type	Indirect injection, Vertical, Water-Cooled, 4-cycle diesel engine				
	Number of cylinders	4				
	Bore and stroke	87 x 92.4 mm (3.4 x 3.6 in.)				
	Total displacement	2197 cm <sup>3</sup> (134.1 cu.in.)				
	Rated revolution	2600 min <sup>-1</sup> (43.4 r/s, 2600 rpm)				
	Combustion chamber	Spherical type (E-TVCS)				
	Fuel injection pump	Bosch type mini pump (PFR4M)				
	Governor	Centrifugal ball mechanical governor				
	Injection nozzle	Throttle type				
	Injection timing	Before T.D.C. 0.314 rad (18°)				
	Injection order	1-3-4-2				
	Injection pressure	13.73 MPa (140 kgf/cm <sup>2</sup> , 1991 psi)				
	Compression ratio	23 : 1				
	Lubricating system	Forced lubrication by trochoidal pump				
	Cooling system	Pressurized radiator, Forced circulation with water pump				
Capacities	Starting system	Electric starting with cell starter 12 V, 1.4 kW				
	Alternator	12 V, 480 W (40 AMPS)	12 V, 540 W (45 AMPS)			
	Battery	SAE 447- Cold cranking Amps at -18 °C (-0.4 °F) 12 V (70 AH) (75D31R-MF)				
	Fuel	Diesel fuel No. 1 [below - 10 °C (14 °F)] Diesel fuel No. 2 [above - 10 °C (14 °F)]				
	Lubricating oil	CC or CD (API grade)				
Dimensions (with Std. tires)	Weight (Dry)	206.5 kg (455 lbs)				
	Fuel tank	35.0 l (9.2 U.S.gals., 7.7 Imp.gals.)				
	Engine crankcase	7.6 l (8.0 U.S.qts., 7.0 Imp.qts.)				
	Engine coolant	7.5 l (7.9 U.S.qts., 7.0 Imp.qts.)	8.7 l (9.2 U.S.qts., 7.6 Imp.qts.)			
	Transmission case	39.0 l (10.3 U.S.gals., 8.6 Imp.gals.)				
	Front axle case	5.5 l (5.8 U.S.qts., 4.8 Imp.qts.)				
	Overall length (without 3P)	3020 mm (118.9 in.)				
	Overall length (with 3P)	3230 mm (127.2 in.)				
	Overall width (minimum tread)	1435 mm (56.5 in.)				
	Overall height	2340 mm (92.1 in.)	2175 mm (85.6 in.)			
Dimensions (with Std. tires)	Overall height (Top of steering wheel)	1540 mm (60.6 in.)				
	Wheel base	1805 mm (71.1 in.)				
	Min. ground clearance (Under transmission)	390 mm (15.4 in.)				
	Tread	Front mm (in.)	1145 (45.1)			
		Rear mm (in.)	1055 (41.5), 1155 (45.5), 1225 (48.2), 1325 (52.2), 1350 (53.1)			

Note : \* Manufacturer's estimate

Model			L4200 with ROPS		L4200 with CABIN			
	4WD	4WD-GST	4WD	4WD-GST				
Traveling system	Tire size (Std. tires)	Front	8 - 16					
		Rear	13.6 - 26					
	Clutch		Dry type single stage					
	Steering		Hydrostatic power steering					
	Transmission		Synchronized shuttle and synchronized transmission (8 forward and 8 reverse speeds)	Glide shift transmission (8 forward and 8 reverse speeds)	Synchronized shuttle and synchronized transmission (8 forward and 8 reverse speeds)	Glide shift transmission (8 forward and 8 reverse speeds)		
	Brake	Traveling	Wet disc type					
		Parking	Connected with the traveling brake					
	Differential		Bevel gear					
Hydraulic system	Hydraulic control system		Position control, Draft and Mixed control (if equipped)					
	Pump capacity (Max. flow rate)		Main pump 29.5 l/min (7.8 GPM) Power steering pump 15.3 l/min (4.0 GPM)					
	Three point hitch		SAE Category I					
	Maximum lifting capacity	At lift point	1300 kg (2866 lbs)					
		24 in. behind lift points	1050 kg (2315 lbs)					
Rear PTO	PTO shaft		SAE 1-3/8, 6-splines (with overrunning clutch)					
	Revolution	Transmission PTO	1 speed : 540 min <sup>-1</sup> (9.0 r/s, 540 rpm) / engine 2447 min <sup>-1</sup> (40.8 r/s, 2447 rpm)					
		Independent PTO	1 speed : 540 min <sup>-1</sup> (9.0 r/s, 540 rpm) / engine 2475 min <sup>-1</sup> (41.3 r/s, 2475 rpm)					
Min. turning radius (with brake)			2.5 m (8.2 ft)					
Traction system			Fixed drawbar					
Weight (with ROPS)			1420 kg (3131 lbs)	1430 kg (3153 lbs)	1545 kg (3406 lbs)	1555 kg (3428 lbs)		

## TRAVELING SPEEDS

(At rated engine speed)


Model				L2900		L3300		L3600		L4200		
Tire size (Rear)				11.2-24		12.4-24		13.6-24		13.6-26		
Creep gear shift lever	Shuttle shift lever	GST Type	Manual Transmission Type	km/h	mph	km/h	mph	km/h	mph	km/h	mph	
High	Forward	1	Low	1	1.5	0.93	1.6	0.99	1.4	0.87	1.5	0.93
				2	2.2	1.37	2.3	1.43	2.0	1.24	2.1	1.30
				3	3.5	2.17	3.7	2.30	3.3	2.05	3.4	2.11
				4	5.2	3.23	5.4	3.36	4.8	2.98	5.0	3.11
		5	High	1	7.4	4.60	7.7	4.78	6.9	4.29	7.2	4.47
				2	10.4	6.46	10.8	6.71	9.7	6.03	10.1	6.28
				3	16.9	10.50	17.6	10.94	15.7	9.76	16.4	10.19
				4	24.9	15.47	26.0	16.16	23.2	14.42	24.2	15.04
	Reverse	1	Low	1	1.4	0.87	1.5	0.93	1.3	0.81	1.4	0.87
				2	2.0	1.24	2.1	1.30	1.9	1.18	1.9	1.18
				3	3.2	1.99	3.4	2.11	3.0	1.86	3.1	1.93
				4	4.8	2.98	4.9	3.04	4.4	2.73	4.6	2.86
		5	High	1	6.7	4.16	7.0	4.35	6.3	3.91	6.6	4.10
				2	9.5	5.90	9.9	6.15	8.9	5.53	9.3	5.78
				3	15.5	9.63	16.1	10.00	14.4	8.95	15.1	9.38
				4	22.9	14.23	23.8	14.79	21.3	13.24	22.2	13.79
Low	Forward	1	Low	1	0.17	0.11	0.18	0.11	0.16	0.10	0.17	0.11
				2	0.24	0.15	0.25	0.16	0.23	0.14	0.24	0.15
				3	0.39	0.24	0.41	0.25	0.37	0.23	0.38	0.24
				4	0.58	0.36	0.60	0.37	0.54	0.34	0.56	0.35
		5	High	1	0.82	0.51	0.86	0.53	0.77	0.48	0.80	0.50
				2	1.2	0.75	1.2	0.75	1.1	0.68	1.1	0.68
				3	1.9	1.18	2.0	1.24	1.8	1.12	1.8	1.12
				4	2.8	1.74	2.9	1.80	2.6	1.62	2.7	1.68
	Reverse	1	Low	1	0.16	0.10	0.16	0.10	0.15	0.09	0.15	0.09
				2	0.22	0.14	0.23	0.14	0.21	0.13	0.22	0.14
				3	0.36	0.22	0.38	0.23	0.34	0.21	0.35	0.22
				4	0.53	0.33	0.55	0.34	0.50	0.31	0.52	0.32
		5	High	1	0.76	0.47	0.79	0.49	0.70	0.43	0.73	0.45
				2	1.1	0.68	1.1	0.68	1.0	0.62	1.0	0.62
				3	1.7	1.06	1.8	1.12	1.6	0.99	1.7	1.06
				4	2.6	1.62	2.7	1.68	2.4	1.49	2.5	1.55

● The speeds in the  part are tractor with creep gear only.


● The company reserves the right to change the specifications without notice.

## DIMENSIONS (ROPS)

Unit : mm (in.)




B161F003



B161F004

## **DIMENSIONS (CABIN)**

Unit : mm (in.)



B167F010

**G GENERAL**

# **G GENERAL**

## CONTENTS

[1] FEATURES .....	G-1
[2] TRACTOR IDENTIFICATION .....	G-2
[3] GENERAL PRECAUTIONS .....	G-3
[4] HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING .....	G-4
[5] LUBRICANTS, FUEL AND COOLING WATER .....	G-8
[6] TIGHTENING TORQUES (GENERAL USE SCREWS, BOLTS AND NUTS) .....	G-9
[7] MAINTENANCE CHECK LIST .....	G-10
[8] CHECK AND MAINTENANCE .....	G-11
(1) Daily Check .....	G-11
(2) Check Points of Initial 50 Hours .....	G-12
(3) Check Points of Every 50 Hours .....	G-14
(4) Check Points of Every 100 Hours .....	G-17
(5) Check Points of Every 200 Hours .....	G-18
(6) Check Points of Every 400 Hours .....	G-20
(7) Check Points of Every 800 Hours .....	G-21
(8) Check Points of Every 1 Year .....	G-22
(9) Check Points of Every 2 Years .....	G-22
(10) Others .....	G-24
[9] SPECIAL TOOLS .....	G-26
[10] TIRES .....	G-35
(1) Types of Tire .....	G-35
(2) Tread Adjustment .....	G-36
(2)-1 Front Wheels .....	G-36
(2)-2 Rear Wheels .....	G-37
(3) Wheel Hub .....	G-38
(4) Tire Pressure .....	G-39
(5) Tire Liquid Injection .....	G-40

## [1] FEATURES



B167F011





L2900, L3300, L3600 and L4200 tractors have the unique KUBOTA E-TVCS (Three Vortex Combustion System) Diesel Engine that delivers a more dynamic output and a greater torque with cleaner emissions.

The drive mechanisms are either the New GST (Glide Shift Transmission) or the Manual Transmission which incorporates the Synchro-Shuttle and the Full-Synchro Main Transmission. The some models are available CABIN specification. The comfortable integral cabin by KUBOTA.

Other distinctive features which contribute to making tractors in this series outperform all other tractors in the same class in comfort, durability, maneuverability, mobility, and ease of operation include the hydraulically actuated Independent PTO, the large-capacity Clutch, the large lift capacity of the 3-Point Hitch, Hydrostatic Power Steering, the Full-Floating Type Flat Deck, and the Hanging-Type Pedals.


## [2] TRACTOR IDENTIFICATION

When contacting your local KUBOTA distributor, always specify engine serial number, tractor serial number and hourmeter reading.



- |                                  |                                |
|----------------------------------|--------------------------------|
| (1) Tractor Identification Plate | (4) Hour Meter                 |
| (2) Engine Serial Number         | (5) Cabin Identification Plate |
| (3) Tractor Serial Number        | Cabin Serial Number            |

### [3] GENERAL PRECAUTIONS




- During disassembly, carefully arrange removed parts in a clean area to prevent confusion later. Bolts and nuts should be installed in their original position to prevent reassembly errors.
- When special tools are required, use KUBOTA genuine special tools. Special tools which are not frequently used should be made according to the drawings provided.
- Before disassembling or servicing electrical wires, always disconnect the ground cable from the battery first.
- Remove oil and dirt from parts before measuring.
- Use only KUBOTA genuine parts for parts replacement to maintain tractor performance and to assure safety.
- Gaskets and O-rings must be replaced during reassembly. Apply grease to new O-rings or oil seals before assembling. See the figure left side.
- When reassembling external snap rings or internal snap rings, they must be positioned so that sharp edge faces against the direction from which a force is applied. See the figure left side.
- When inserting spring pins, their splits must face the direction from which a force is applied. See the figure left side.
- To prevent damage to the hydraulic system, use only specified fluid or equivalent.

- (1) Grease  
(2) Force  
(3) Sharp Edge  
(4) Axial Force  
(5) Rotating Movement

- [A] External Snap Ring  
[B] Internal Snap Ring

## [4] HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING




To ensure safety and prevent damage to the machine and surrounding equipment, heed the following precautions in handling electrical parts and wiring.

### ■ IMPORTANT


- Check electrical wiring for damage and loosened connection every year. To this end, educate the customer to do his or her own check and at the same time recommend the dealer to perform periodic check for a fee.
- Do not attempt to modify or remodel any electrical parts and wiring.
- When removing the battery cord, disconnect the negative wire first. When installing the battery cord, connect the positive wire first.

### ■ Wiring


- Securely tighten wiring terminals.




- Repair or change torn or aged wiring immediately.




- Do not let wiring contact dangerous part.




- Securely insert grommet.



- Securely clamp, being careful not to damage wiring.



C079F007




C079F008

- Clamp wiring so that there is no twist, unnecessary sag, or excessive tension, except for movable part, where sag may be required.




C079F009

- In installing a part, take care not to get wiring caught by it.



C079F010


- After installing wiring, check protection of terminals and clamped condition of wiring, only then connect battery.



C079F011

## ■ Battery

Take care not to confuse positive and negative terminals.



C079F001


- When removing battery cord, disconnect negative wire first. When installing battery cord, check for polarity and connect positive wire first.
- Do not install any battery with capacity other than is specified (Ah).
- After connecting cord to battery terminals, apply grease to them and securely install terminal covers on them.
- Do not allow dirt and dust to collect on battery.

### ⚠ CAUTION

- Take care not to let battery liquid spill on your skin and clothes. If contaminated, wash it off with water immediately.
- Before recharging the battery, remove it from the machine.
- Before recharging, remove cell caps.

### ⚠ CAUTION


- Do recharging in a well-ventilated place where there is no open flame nearby, as hydrogen gas and oxygen are formed.



C079F013


## ■ Fuse

- Use fuses with specified capacity.
- Never use steel or copper wire in place of fuse.



C079F014


- Do not install working light, radio set, etc. on machine which is not provided with reserve power supply.
- Do not install accessories if fuse capacity of reserve power supply is exceeded.



C079F015


## ■ Connector

- For connector with lock, push lock to separate.




C079F016

- Use sandpaper to remove rust from terminals.
- Repair deformed terminal. Make certain there is no terminal being exposed or displaced.



C079F018



C079F019


- Make certain plastic cover is large enough to cover whole connector.

CORRECT

Plastic cover large enough to cover entire connector



INCORRECT


No coming off  
No tear off

C079F021


- In separating connectors, do not pull wire harnesses.

CORRECT

Hold connector bodies to separate



INCORRECT



- Make certain that there is no female connector being too open.

CORRECT

INCORRECT

C079F020


CORRECT

INCORRECT


C079F021

### ■ Handling of Circuit Testers

- Use tester correctly following manual provided with tester.
- Check for polarity and range.




C079F026



C079F027


### ■ Handling of Parts

- Do not throw or drop electrical parts and wire harnesses.



C079F023

- Do not pour water on electrical parts such as main switch and alternator.



C079F025

### ■ Oil, Dust and Dirt

- If flammable material such as fuel, or lubricant spills, wipe it off with dry piece of cloth. Do not approach it with an open flame.
- Replace fuel pipe that is aged.
- Remove dirt and dust accumulated on heated part, wire harness, battery, etc.



C079F024

## [5] LUBRICANTS, FUEL AND COOLING WATER

Place	Capacity				Lubricants, fuel and cooling water		
	L2900	L3300	L3600	L4200			
Fuel tank	35 ℥ 9.2 U.S.gals. 7.7 Imp.gals.				No.2-D diesel fuel No.1-D diesel fuel if temperature is below - 10 °C (14 °F)		
Cooling system (with ROPS)	7.0 ℥ 7.4 U.S.qts. 6.2 Imp.qts.	7.5 ℥ 7.9 U.S.qts. 6.6 Imp.qts.					
Cooling system (with CABIN)	— 8.2 ℥ 8.7 U.S.qts. 7.2 Imp.qts.	8.7 ℥ 9.2 U.S.qts. 7.7 Imp.qts.			Fresh clean water with anti-freeze		
Engine crankcase	5.5 ℥ 5.8 U.S.qts. 4.8 Imp.qts.	7.6 ℥ 8.0 U.S.qts. 7.0 Imp.qts.			Engine oil : API Service CC or CD Below 0 °C (32 °F) ..... SAE10W, 10W-30 or 10W-40 0 to 25 °C (32 to 77 °F) ..... SAE20, 10W-30 or 10W-40 Above 25 °C (77 °F) ..... SAE30, 10W-30 or 10W-40		
Transmission case	39 ℥ 41.2 U.S.qts. 34.3 Imp.qts.				KUBOTA SUPER UDT fluid *		
Front axle case [4WD]	5.5 ℥ 5.8 U.S.qts. 4.8 Imp.qts.				KUBOTA SUPER UDT fluid * or SAE 80, 90 gear oil		
Window washer liquid	— 1.2 ℥ 1.3 U.S.qts. 1.1 Imp.qts.				Automobile washer liquid		
Greasing							
Top link	Until grease overflows	1 or 2 points		SAE multi-purpose type grease			
Top link bracket (with draft control)		2 points					
Lift rod		1 point					
Power steering cylinder		1 point					
Battery terminal	Moderate amount		2 points				
Lubricating points							
Hinges (Doors, Rear and front windows)	Small amount of lubricating liquid			Lubricating liquid			

\* : KUBOTA original transmission hydraulic fluid

## [6] TIGHTENING TORQUES (GENERAL USE SCREWS, BOLTS AND NUTS)

Screws, bolts and nuts whose tightening torques are not specified in this Workshop Manual should be tightened according to the table below.

Indication on top of bolt	No-grade or 4T						7T						9T		
Material of bolt	SS400, S20C						S43C, S48C						SCr435, SCM435		
Material of opponent part	Ordinariness			Aluminum			Ordinariness			Aluminum			Ordinariness		
Diameter	N·m	kgf·m	ft-lbs												
M 6 (6 mm, 0.24 in.)	7.84 to 9.31	0.80 to 0.95	5.79 to 6.87	7.84 to 8.83	0.80 to 0.90	5.79 to 6.51	9.80 to 11.2	1.00 to 1.15	7.24 to 8.32	7.84 to 8.83	0.80 to 0.90	5.79 to 6.51	12.3 to 14.2	1.25 to 1.45	9.05 to 10.5
M 8 (8 mm, 0.31 in.)	17.7 to 20.5	1.8 to 2.1	13.0 to 15.2	16.7 to 19.6	1.7 to 2.0	12.3 to 14.5	23.6 to 27.4	2.4 to 2.8	17.4 to 20.2	17.7 to 20.6	1.8 to 2.1	13.0 to 15.2	29.4 to 34.3	3.0 to 3.5	21.7 to 25.3
M 10 (10 mm, 0.39 in.)	39.2 to 45.0	4.0 to 4.6	29.0 to 33.2	31.4 to 34.3	3.2 to 3.5	23.1 to 25.3	48.1 to 55.8	4.9 to 5.7	35.5 to 41.2	39.2 to 44.1	4.0 to 4.5	28.9 to 32.5	60.8 to 70.5	6.2 to 7.2	44.9 to 52.1
M 12 (12 mm, 0.47 in.)	62.8 to 72.5	6.4 to 7.4	46.3 to 53.5				77.5 to 90.1	7.9 to 9.2	57.2 to 66.5	62.8 to 72.5	6.4 to 7.4	46.3 to 53.5	103 to 117	10.5 to 12.0	76.0 to 86.8
M 14 (14 mm, 0.55 in.)	108 to 125	11.0 to 12.8	79.6 to 92.5				124 to 147	12.6 to 15.0	91.2 to 108				167 to 196	17.0 to 20.0	123 to 144
M 16 (16mm, 0.63 in.)	167 to 191	17.0 to 19.5	123 to 141				196 to 225	20.0 to 23.0	145 to 166				260 to 303	26.5 to 31.0	192 to 224
M 18 (18 mm, 0.71 in.)	245 to 284	25.0 to 29.0	181 to 210				275 to 318	28.0 to 32.5	203 to 235				343 to 401	35.0 to 41.0	254 to 297
M 20 (20mm, 0.79 in.)	334 to 392	34.0 to 40.0	246 to 289				368 to 431	37.5 to 44.0	272 to 318				490 to 568	50.0 to 58.0	362 to 420

## [7] MAINTENANCE CHECK LIST

No.	Check point	Indication on hour meter (Change or check every interval shown below)																After purchase		Reference page
		50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	1 year	2 years	
1	Greasing	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			G-14
2	Engine starting system checking	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			G-15
3	Wheel bolt torque checking	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			G-16
4	Battery condition checking	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			G-15
5	Engine oil changing	◎	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			G-12
6	Air cleaner element cleaning★	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			G-17
7	Fuel filter element cleaning	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			G-17
8	Fan belt tension adjustment	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			G-18
9	Clutch pedal free travel adjustment	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			G-18
10	Brake pedal free travel adjustment	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			G-18
11	Engine oil filter cartridge replacement	◎	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			G-12
12	Hydraulic oil filter cartridge replacement	◎	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			G-12
13	Radiator hose and clamp checking		○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			G-19
14	Power steering oil line checking		○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			G-19
15	Fuel line checking		○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			G-20
16	Toe-in adjustment		○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			G-19
17	Transmission fluid changing	◎														○				G-13
18	Front axle case oil changing	◎														○				G-13
19	Front axle pivot adjustment	◎														○				G-14
20	Fuel filter element replacement															○				G-20
21	Engine valve clearance adjustment															○				G-21
22	Air cleaner element replacement															○				G-22
23	Heater pipes and hoses checking															○				G-22
24	Cabin isomounts checking															○				G-22
25	Radiator hose and clamp replacement															○				G-22
26	Power steering oil line replacement															○				G-22
27	Fuel line replacement															○				G-23

Note : The jobs indicated by ◎ must be done by all means 50 hours after the break-in respectively.

The jobs indicated by ★ service as required.

★ Air cleaner should be cleaned more often in dusty conditions than in normal conditions.