

Product: Kubota M8200SDNB M8200SDNBC Service Manual

Full Download: <https://www.arepairmanual.com/downloads/kubota-m8200sdnb-m8200sdnbc-service-manual/>

WSM

WORKSHOP MANUAL TRACTOR

M8200DNB(SUPPLEMENT), M8200SDNB, M8200SDNBC

Кубота

KiSC issued 10, 2018 A

Sample of manual. Download All 152 pages at:

<https://www.arepairmanual.com/downloads/kubota-m8200sdnb-m8200sdnbc-service-manual/>

Product: Kubota M8200SDNB M8200SDNBC Service Manual

Full Download: <https://www.arepairmanual.com/downloads/kubota-m8200sdnb-m8200sdnbc-service-manual/>

N M8200DNB (Supplement) M8200SDNB M8200SDNBC

KiSC issued 10, 2018 A

Sample of manual. Download All 152 pages at:

<https://www.arepairmanual.com/downloads/kubota-m8200sdnb-m8200sdnbc-service-manual/>

CONTENTS

SAFETY INSTRUCTIONS.....	N1
SPECIFICATIONS	N4
DIMENSIONS	N5
G. GENERAL	NG-1
[1] FEATURES	NG-1
[2] LUBRICANTS, FUEL AND COOLANT	NG-3
[3] MENTENANCE	NG-4
[4] CHECK AND MAINTENANCE	NG-5
[5] SPECIAL TOOL	NG-8
[6] OTHERS	NG-9
[7] IMPLEMENT LIMITATIONS	NG-13
1. ENGINE.....	N1-S1
[2] SERVICING.....	N1-S1
2. CLUTCH.....	N2-S1
[2] SERVICING.....	N2-S1
3. TRANSMISSION	N3-M1
[1] MECHANISM	N3-M1
[2] SERVICING.....	N3-S1
4. REAR AXLE.....	N4-S1
[2] SERVICING.....	N4-S1
6. FRONT AXLE.....	N6-M1
[1] MECHANISM	N6-M1
[2] SERVICING.....	N6-S1
7. STEERING	N7-S1
[2] SERVICING.....	N7-S1
8. HYDRAULIC SYSTEM.....	N8-M1
[1] MECHANISM	N8-M1
[2] SERVICING.....	N8-S1
9. ELECTRICAL SYSTEM	N9-M1
[1] MECHANISM	N9-M1
[2] SERVICING.....	N9-S1
10. CABIN	N10-1

TO THE READER

In this section, the main additional functions and altered points of M8200DNB, M8200SDNB, M8200SDNBC tractors from M6800, M8200, M9000 tractors are explained separately in two items, "Mechanism" and "Servicing" for each section.

As for the items which are not explained in this section, refer to M6800, M8200, M9000 Workshop Manual.

■ Mechanism

Information on the construction and function are included for M8200DNB, M8200SDNB, M8200SDNBC tractors. This part should be understood before proceeding with troubleshooting, disassembling and servicing.

■ Servicing

For M8200DNB, M8200SDNB, M8200SDNBC tractors, there are troubleshooting, servicing specification lists, checking and adjusting, disassembling and assembling, and servicing which cover procedures, precautions, factory specifications and allowable limits.

All information illustrations and specifications contained in this manual are based on the latest product information available at the time of publication.

The right is reserved to make changes in all information at any time without notice.

March 2001

© KUBOTA Corporation 2001

SAFETY DECALS

The following safety decals are installed on the machine.
 If a decal becomes damaged, illegible or is not on the machine, replace it. The decal part number is listed in the parts list.

(1) Part No. TA040-4965-2



⚠ DANGER

TO AVOID POSSIBLE INJURY OR DEATH FROM A MACHINE RUNAWAY.

1. Do not start engine by shorting across starter terminals or bypassing the safety start switch. Machine may start in gear and move if normal starting circuitry is bypassed.
2. Start engine only from operator's seat with transmission and PTO OFF. Never start engine while standing on the ground.

(5) Part No. 3A431-9849-2

⚠ WARNING

Never modify or repair a ROPS because welding, drilling, grinding or cutting any portion may weaken the structure.


⚠ DANGER

TO AVOID INJURY WHEN RAISING OR FOLDING ROPS :

- Set parking brake and stop engine.
- Remove any obstruction that may prevent raising or folding of the ROPS.
- Do not allow any bystanders.
- Hold center of ROPS when folding to avoid free-fall.
- Make sure all pins are installed and locked.


IMPORTANT

UPRIGHT POSITION




Secure both lock pins with lynch pins.

FOLDED POSITION



Secure both lock pins with lynch pins.

(2) Part No. TA040-4958-1
 Do not touch hot surface like muffler, etc.





(3) Part No. TA040-4957-1
 Stay clear of engine fan and fanbelt.



(4) Part No. 35080-6528-2

⚠ CAUTION

Pull the engine stop knob back and hold it until the engine stops in case of emergency.



T12730ZZ00101

(1) Part No. 35260-3491-3

⚠ CAUTION

TO AVOID PERSONAL INJURY:

1. Read and understand the operator's manual before operation.
2. Before starting the engine, make sure that everyone is at a safe distance from the tractor and that the PTO is OFF.
3. Do not allow passengers on the tractor at any time.
4. Before allowing other people to use the tractor, have them read the operator's manual.
5. Check the tightness of all nuts and bolts regularly.
6. Keep all shields in place and stay away from all moving parts.
7. Lock the two brake pedals together before driving on the road.
8. Slow down for turns, or rough roads, or when applying individual brakes.
9. On public roads use SMV emblem and hazard lights, if required by local traffic and safety regulations.
10. Pull only from the drawbar.
11. Before dismounting, lower the implement, set the parking brake, stop the engine and remove the key.

(5) Part No. 3A481-9852-1



(2) Part No. 3A481-9890-1

⚠ WARNING

TO AVOID THE POSSIBILITY OF MACHINE RUNAWAY BEFORE DISMOUNTING TRACTOR:

1. ALWAYS SET PARKING BRAKE.

When engine is stopped, parking brake operates with rear wheels only regardless of front axle engagement.

2. PARK ON LEVEL GROUND WHENEVER POSSIBLE.

If parking on a slope, position tractor across the slope. If that is not possible, choke wheels securely.

3. LOWER ALL IMPLEMENTS TO THE GROUND.


(3) Part No. TA431-9848-1

	⚠ WARNING
	<p>TO AVOID INJURY OR DEATH FROM ROOL-OVER :</p> <ul style="list-style-type: none"> • Keep Roll-Over Protective Structures (ROPS) in the upright and locked position. • Check operating environment or vertical clearance for ROPS • Fasten SEAT BELT before operating.
	<p>IN FOLDED POSITION ROPS PROTECTION IS ELIMINATED</p> <ul style="list-style-type: none"> • Do not fasten SEAT BELT when ROPS is folded. • Raise ROPS as soon as vertical clearance allows and read related instructions and warning.

(4) Part No. 3F240-4905-2


⚠ WARNING

To avoid personal injury:
Use "Bi-speed Turn" only in low gears and slow speed. Do not use "Bi-speed Turn" in high gears or road speed.



T12321ZZ00101


(1) Part No. TA040-4959-3




(4) Part No. TA040-4935-1



(2) Part No. 3A111-9856-3



(3) Part No. TA040-4956-2



CARE OF DANGER, WARNING AND CAUTION LABELS

1. Keep danger, warning and caution labels clean and free from obstructing material.
2. Clean danger, warning and caution labels with soap and water, dry with a soft cloth.
3. Replace damaged or missing danger, warning and caution labels with new labels from your local KUBOTA distributor.
4. If a component with danger, warning and caution label(s) as the replaced component.
5. Mount new danger, warning and caution labels by applying on a clean dry surface and pressing any bubbles to outside edge.


T12321ZZ00201

SPECIFICATIONS

Model		M8200DNB	M8200SDNB	
PTO power (Factory Observed)		54.5 kW [73 HP, 2600 min ⁻¹ (rpm)]		
Engine	Model	V3300-TE		
	Type	Vertical, water-cooled, 4-cycle diesel engine		
	No. of cylinders	4		
	Total displacement	3318 cm ³ (202.5 cu.in.)		
	Bore and stroke	98 × 110 mm (3.9 × 4.3 in.)		
	Engine rated output	61.2 kW (82 HP)		
	Rated revolution	2600 min ⁻¹ (rpm)		
	Maximum torque	285 N·m (29.1 kgf·m, 210 ft·lbs) / 1300 to 1500 min ⁻¹ (rpm)		
	Battery	12 V, CCA1000A		
	Fuel	Diesel fuel No. 1-D [below -10 °C (14 °F)], Diesel fuel No. 2-D [above -10 °C (14 °F)]		
	Fuel tank capacity	60 L (15.9 U.S.gals., 13.2 Imp.gals.)		
	Engine crankcase capacity	10.7 L (11.3 U.S.qts., 9.4 Imp.gal.)		
	Engine coolant capacity	9.0 L (9.5 U.S.qts., 7.9 Imp.gal.)		
Dimensions	Overall length	3410 mm (134.3 in.)		
	Overall width (Minimum tread)	1220 mm (48 in.)		
	Overall height (Top steering)	1386 mm (54.6 in.)		
	Wheel base	2000 mm (78.7 in.)		
	Tread	Front	1030 mm (40.6 in.)	
		Rear	900 mm (35.0 in.) to 1413 mm (55.6 in.)	
Minimum ground clearance	228 mm (9.0 in.) (SWAY BLOCK)			
Weight (with ROPS)		1850 kg (4080 lbs)		
Travelling system	Standard tire size	Front	8.0 - 16	
		Rear	12.4 - 24	
	Clutch	Dry, Single plate		
	Steering	Full hydraulic power steering		
	Transmission	Shuttle synchtomesh, 12F/4R	12 forward and 12 reverse fully synchronized main and shuttle transmission with creep speed.	
	Brake	Travelling	Wet type multiple discs (mechanical)	
		Parking	Connected with the travelling brake	
	Differential	Bevel gears (with differential lock)		
Hydraulic system	Hydraulic control system	Position, draft and mix control		
	Pump-up capacity	41.3 L (10.9 U.S.gal., 9.1 Imp.gal.)/min.		
	Three point hitch	Category I (CAT.II Link End)		
	Maximum lifting force	1900 kg (4189 lbs) at lower link end 1500 kg (3307 lbs) at 610 mm (24 in.) behind lifting point		
	System pressure	19.1 MPa (195 kgf/cm ² , 2773 psi)		
PTO	Independance clutch		Wet type, multiple discs	
	Live PTO	Direction of turning	Clock wise, viewed from tractor rear	
		PTO speed	540 rpm at 2160 engine rpm	
Traction system		Swing drawbar, adjustable in direction		


W1028103

DIMENSIONS




G. GENERAL

[1] FEATURES



T12321GE00101

1. Foldable ROPS
2. Synchro-Shuttle Shift : Forward - Reverse (M8200SDNB)
3. New Design
4. Double-Element Air Cleaner
5. E-TVCS (Three Vortex Combustion System)
6. Shuttle Synchronesh, 12F/4R : Lo-Reverse (M8200DNB)
12F/12R : Fully Synchronized Main and Shuttle Transmission (M8200SDNB)
7. Hanging Type Clutch Pedal
8. Full Hydrostatic Power Steering



T12730GE00202

- 9. Single / Double Acting Hydraulic Control Valve with Self-Cancelling Feature
- 10. Rear ROPS
- 11. Rear Wheel (12.4-24)
- 12. Three Point Hitch with Sway Block
Three Point Hitch Fully Equipped with Position, Draft and Mixed Control
- 13. PTO (540 rpm at 2160 engine rpm)

[2] LUBRICANTS, FUEL AND COOLANT

	Place	Capacity		Lubricants, fuel and coolant
		M8200DNB, M8200SDNB		
1	Fuel tank	60 L 15.9 U.S.gals. 13.2 Imp.gals.		No. 2-D diesel fuel No. 1-D diesel fuel if temperature is below -10 °C (14 °F)
2	Coolant	9.0 L 9.5 U.S.qts. 7.9 Imp.qts.		Fresh clean water with anti-freeze Do not mix different brand anti-freeze together
3	Engine crankcase	10.7 L 11.3 U.S.qts. 9.4 Imp.qts.		Engine oil : API service CC or CD class Below 0 °C (32 °F) : SAE10W, 10W-30 or 10W-40 0 to 25 °C (32 to 77 °F): SAE20, 10W-30 or 10W-40 Above 25 °C (77 °F): SAE30, 10W-30 or 10W-40
4	Transmission case	33 L 34.9 U.S.gals. 29.0 Imp.gals.		KUBOTA SUPER UDT fluid*
5	Front axle case	6.0 L 6.3 U.S.qts. 5.3 Imp.qts.		KUBOTA SUPER UDT fluid* or SAE80, 90 gear oil
Greasing				
	Place	No. of greasing point	Capacity	Type of grease
6	Front wheel case support	2	Until grease overflows	Multipurpose type grease
	Front axle support	2		
	Top link	2		
	Top link bracket	2		
	Lift rod	2		
	Battery terminal	2	Moderate amount	

* KUBOTA original transmission hydraulic fluid.

[3] MAINTENANCE

No.	Item	Period	Indication on hour meter																Since then	Reference page
			50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800		
1	Engine oil	Change	★			☆						☆					☆	every 200 Hr	G-13	
2	Engine Oil Filter	Replace	★									☆					☆	every 400 Hr	G-14	
3	Fuel filter element	Replace										☆					☆	every 400 Hr	G-23 @	
4	Water separator	Clean	★									☆					☆	every 400 Hr	G-23	
5	Hydraulic oil filter	Replace	★					☆									☆	every 300 Hr*	G-14	
6	Front axle gear case oil	Change	★														☆	every 600 Hr	NG-7	
7	Engine start system	Check	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	every 50 Hr	G-16	
8	Wheel bolt torque	Check	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	every 50 Hr	NG-6	
9	Battery condition	Check		☆		☆		☆		☆		☆		☆		☆	☆	every 100 Hr	G-17	
10	Greasing	—		☆		☆		☆		☆		☆		☆		☆	☆	every 100 Hr	G-20	
11	Fan belt	Adjust		☆		☆		☆		☆		☆		☆		☆	☆	every 100 Hr	G-19	
12	Clutch	Adjust	★	☆		☆		☆		☆		☆		☆		☆	☆	every 100 Hr	G-15	
13	Brake	Adjust		☆		☆		☆		☆		☆		☆		☆	☆	every 100 Hr	G-19	
14	Air cleaner element [Double type]	Primary element	Clean		☆		☆		☆		☆		☆		☆		☆	every 100 Hr	G-18	
		Secondary element	Replace															every 1 year	G-18	
			Replace																every 1 year	G-18 @
15	Radiator hose and clamp	Check				☆				☆							☆	every 200 Hr	G-21	
		Replace																every 2 years	G-21	
16	Power steering oil line	Check				☆				☆							☆	every 200 Hr	G-21	
		Replace																every 2 years	G-21	
17	Fuel line	Check				☆				☆							☆	every 200 Hr	G-21 @	
		Replace																every 2 years	G-21	
18	Toe-in	Adjust				☆				☆							☆	every 200 Hr	G-22	
19	Transmission fluid	Change	★														☆	every 600 Hr	NG-5	
20	Front axle pivot	Adjust															☆	every 600 Hr	G-25	
21	Engine valve clearance	Adjust															☆	every 800 Hr	1-S15	
22	Cooling system	Flush																every 2 years	G-26, 27	
23	Coolant	Change																every 2 years	G-26, 27	
24	Fuel system	Bleed																	G-28	
25	Clutch housing water	Drain																Service as required	G-28	
26	Fuse	Replace																	NG-8	
27	Light bulb	Replace																	G-29	
28	Intake air line	Check				☆				☆							☆	every 200 Hr	—	
		Replace																every 2 years	— @	
29	Fuel injection nozzle injection pressure	Check																every 1500 Hr	1-S48 @	
30	Injection pump	Check																every 3000 Hr	1-S47 @	

■ IMPORTANT




- The jobs indicated by ★ must be done after the first 50 hours of operation.
- * : Air cleaner and hydraulic oil filter should be cleaned more often in dusty conditions than in normal conditions.
- The items listed above (@ marked) are registered as emission related critical parts by KUBOTA in the U.S.EPA nonroad emission regulation. As the engine owner, you are responsible for the performance of the required maintenance on the engine according to the above instruction.

Please see the Warranty Statement in detail.

W1035769

[4] CHECK AND MAINTENANCE

(1) Check Points of Initial 50 Hours



Changing Transmission Fluid

CAUTION

- Allow engine to cool down sufficiently, oil can be hot and can burn.

1. To drain the used oil, remove the drain plug at the bottom of the transmission case and drain the oil completely into the oil pan.
2. After draining reinstall the drain plug.
3. Fill with the new KUBOTA SUPER UDT fluid up to the upper notch on the dipstick (1).
4. After running the engine for a few minutes, stop it and check the oil level again; add oil to prescribed level.

IMPORTANT

- Do not operate the tractor immediately after changing the transmission fluid.
- Run the engine at medium speed for a few minutes to prevent damage to the transmission.

Oil capacity	33.0 L 34.9 U.S.qts. 29.0 Imp.qts.
--------------	--

- (1) Dipstick
- (2) Drain Plug
- (3) Oil Inlet

A : Oil level is acceptable within the range.


W1024997

(2) Check Points of Every 50 Hours

Checking Engine Start System

1. See page G-16. (Same as model M6800.)

W1025228



Checking Wheel Mounting Nuts Tightening Torque

⚠ CAUTION

- Never operate tractor with a loose rim, wheel, or axle.
 - Any time bolts and nuts are loosened, retighten to specified torque.
 - Check all bolts and nuts frequently and keep them tight.
1. Check the wheel mounting nuts regularly especially when new. If there are loosened, tighten as follows.


Tightening torque	Front wheel mounting nut	168 to 296 N-m 17.1 to 20.0 kgf-m 123.7 to 144.7 ft-lbs
	Rear wheel mounting nut and rear disc mounting nut	260 to 304 N-m 26.5 to 31.0 kgf-m 191.7 to 224.2 ft-lbs

(1) Front Wheel Mounting Nut

(2) Rear Wheel Mounting Nut and Rear Disc Mounting Nut

W1025274

(3) Check Points of Every 100 Hours



Lubricating Grease Fitting


1. Apply a small amount of multipurpose grease to following points every 100 hours.
2. If you operated the machine in extremely wet and muddy condition, lubricate grease fittings more often.

(1) Grease Fitting (Front Axle Support)


(3) Grease Fitting (Front Axle Support)

(2) Grease Fitting (Front Wheel Case Support) [R.H., L.H.]

W1025453



(4) Check Points of Every 200 Hours







Checking Intake Air Line

1. Check to see that hoses and hose clamps are tight and not damaged.
2. If hoses and clamps are found worn or damaged, replace or repair them at once.

(1) Hose

W1025564

(5) Check Points of Every 600 Hours



Changing Transmission Fluid

⚠ CAUTION

- Allow engine to cool down sufficiently, oil can be hot and can burn.
1. To drain the used oil, remove the drain plug (1) at the bottom of the transmission case and drain the oil completely into the oil pan.
 2. After draining reinstall the drain plug (1).
 3. Fill with the new KUBOTA SUPER UDT fluid up to the upper notch on the dipstick (2).
 4. After running the engine for a few minutes, stop it and check the oil level again; add oil to prescribed level.

■ IMPORTANT

- Do not operate the tractor immediately after changing the transmission fluid.
- Run the engine at medium speed for a few minutes to prevent damage to the transmission.

Oil capacity	33.0 L 34.9 U.S.qts. 29.0 Imp.qts.
--------------	--

- (1) Drain Plug
- (2) Dipstick
- (3) Oil Inlet

A : Oil level is acceptable within the range.

W1025656

Changing Front Axle Case Oil



1. To drain the used oil, remove the right and left drain plugs (2) and filling plug (1) at the front axle case and drain the oil completely into the oil pan.
2. after draining reinstall the drain plugs (2).
3. Remove the right and left breather plugs (3).
4. Fill with the new oil. Refer to “LUBRICANTS, FUEL AND COOLANT”. (See page NG-3.)
5. After filling reinstall the filling plugs and breather plugs.

Oil capacity	6.0 L 6.3 U.S.qts. 5.3 Imp.qts.
--------------	---------------------------------------

- (1) Filling Plug
- (2) Drain Plug
- (3) Breather Plug

W1025900

(6) Others



Replacing Fuse

1. The tractor electrical system is protected from potential damage by fuses.
A blown fuse indicates that there is an overload or short somewhere in the electrical system.
2. If any of the fuses should blow, replace with a new one of the same capacity.


■ **IMPORTANT**

- **Before replacing the blown fuse, determine why the fuse blew and make any necessary repairs. Failure to follow this procedure may result in serious damage the tractor electrical system. Refer to ELECTRICAL section for specific information dealing with electrical problem.**

Fuse No.	Capacity (A)	Protected circuit
1	20	Main Key
2	15	Head Light
3	10	Parking, Flasher (Hazard)
4	10	Work Light
5	10	4WD, Bi-speed Turn
6	Slow blow fuse 50 A	Check circuit against wrong battery connection.

W1026314

[5] SPECIAL TOOL




Pinion Shaft Remover

Application: Use for removing a pinion shaft.

A	106 mm (4.17 in.)
B	350 mm (13.78 in.)
C	6 mm (0.24 in.)
D	90 mm (3.54 in.)
E	10 mm (0.39 in.)
F	40 mm (1.57 in.)
G	10 mm (0.39 in.)
H	35.6 mm (1.40 in.)
I	36 mm (1.42 in.)
J	41.6 mm (1.64 in.)
K	Part code No. 3A201-41301 nut
L	M27 × P1.5
M	M10 × P1.25

W1031593



Shuttle Case Assembling Stand


Application: Use for assembling the shuttle case.

■ **NOTE**

- This special tool is not provided so make it referring to the figure.

A	300 mm (11.81 in.)
B	175 mm (6.89 in.)
C	195 mm (7.68 in.)
D	85 mm dia. (3.35 in. dia.)
E	75 mm dia. (2.95 in. dia.)
F	21 mm dia. (0.83 in.) dia.
G	150 mm (5.91 in.)
H	75 mm (2.95 in.)
I	220 mm (8.665 in.)
J	80 mm (3.15 in.)
K	75 mm (2.95 in.)
T1	15 mm (0.59 in.)
T2	15 mm (0.59 in.)

W1031821




[6] OTHERS

(1) Type of Tire

■ **IMPORTANT**

- Do not use tires larger than specified.



Type of Tire	Front	Rear
Farm Tire	8.0 – 16	12.4 – 24
	9.5 – 16	14.9 – 24

W1026739

(2) Tread Adjustment

(A) Front Wheel

■ **IMPORTANT**

- This is not adjustable.

8.0 – 16	1030 mm (40.6 in.)
9.5 – 16	1100 mm (43.3 in.)

W1026893

(B) Rear Wheels

Rear tread can be adjusted in 6 steps depending on the model.

To change the tread.


1. Lift the rear tires off the ground.
2. Follow the illustrations below to get the desired tread width.

12.4-24	900 m (35.4 in.)	1004 m (39.5 in.)	1208 m (47.6 in.)	1312 m (51.7 in.)
14.9-24	986 m (38.8 in.)	1090 m (42.9 in.)	1138 m (44.8 in.)	1242 m (48.9 in.)

T12730GE00301

1309 m (51.5 in.)	1413 m (55.6 in.)
1373 m (54.1 in.)	1477 m (58.1 in.)

T12730GE00401



T12321GE01101

⚠ CAUTION

- When working on slopes or working with trailer, set the wheel tread as wide as practical for the job for maximum stability.


■ **IMPORTANT**

- Always attach tires as shown in the drawings above.
- If not attached as illustrated, transmission parts may be damaged.
- Do not use tires larger than specified.
- When re-fitting or adjusting a wheel, tighten the nuts to the following torques then recheck after driving the tractor 200 m (200 yards) and there after daily check service.

- (1) Rear Wheel mounting Nut and Rear Disc Mounting Nut (A) Tread
 [Refer to "Checking Wheel Mounting Nuts Tightening Torque". (See page N3-S1)] (B) Rear Wheel Disc
 (C) Rear Wheel Rim

W1011765

(3) Wheel Hub



• Wheel Hub Dimension

	Front wheel hub	Rear wheel hub
Screw circle diameter (A)	152.4 mm (6 in.)	203.2 mm (8 in.)
Number of screw	6	8
Screw size	M14 × 1.5	M16 × 1.5
Hub pilot diameter (B) [4WD]	117.4 mm (4.625 in.)	152.4 mm (6 in.)
Hub pilot diameter (B) [2WD]	114.0 mm (4.488 in.)	

W1012151


(4) Tire Pressure

⚠ CAUTION

- Do not attempt mount a tire. This should be done by a qualified person with the proper equipment.

■ IMPORTANT

- Do not use tires larger than specified.
- When you intend to mount different size of tires from equipped ones, consult your distributor about front drive gear ratio for detail.
- Excessive wear of tires may occur due to improper gear ratio.



Through the tire pressure is factory-set to the prescribed level, it naturally drops slowly in the course of time. Thus, check it every day and inflate as necessary.

To inflate the wheel tires, use an air compressor or hand pump.

■ Recommended Inflation Pressure

- Maintain the pressure shown below for normal use.

	Tire sizes	Inflation pressure
Front	8.0 – 16	240 kPa (2.4 kgf/cm ² , 34 psi)
	9.5 – 16	196 kPa (2.0 kgf/cm ² , 29 psi)
Rear	12.4 – 24	160 kPa (1.6 kgf/cm ² , 23 psi)
	14.9 – 24	138 kPa (1.4 kgf/cm ² , 20 psi)

■ NOTE

- Maintain the maximum pressure in front tires, if using a front loader or when equipped with lots of front weight.

(A) Insufficient
(B) Standard

(C) Excessive
(D) Ground

W1027488

(5) Tire Liquid Injection

Preparation of Calcium chloride Solution

1. See page G-54.

W1029225

Attaching Injector

1. See page G-54.

W1029271

Injection

⚠ CAUTION

- When a calcium chloride solution is used, cool it before pouring it into the tire.
- Do not fill tires with water or solution more than 75 % of full capacity (to the valve stem level).

The following four ways can be used to inject water or a calcium chloride solution into tires.

1. Gravity injection (Fig. 1)
2. Pump injection (Fig. 2)
3. Pressure tank injection (Fig. 3)
4. Injection directly from tap (only when water is being used).

■ NOTE

- Once injection is completed, reset the air valve, and pump air into the tire to the specified pressure.


Weight of Calcium Chloride Solution Filling 75 % of Full Capacity of a Tire

Tire sizes	12.4-24	14.9-24
Slush free at -24 °C (-11 °F) Solid at -47 °C (-53 °F) [Approx. 1.5 kg (3.5 lbs.) CaCl ₂ per 4 L (1 gal.) of water]	139.7 kg (308 lbs)	215.0 kg (474 lbs)
Slush free at -47 °C (-53 °F) Solid at -52 °C (-62 °F) [Approx. 2.25 kg (5 lbs.) CaCl ₂ per 4 L (1 gal.) of water]	151.0 kg (333 lbs)	230.0 kg (507 lbs)

- (1) Pump
- (2) Pressure Tank
- (3) Compressor
- (4) Air
- (5) Water

- (A) Correct : 75 %
Air Compresses Like A Cushion
(B) Incorrect : 100 % Full
Water Can Not Be Compressed

W1033435




[7] IMPLEMENT LIMITATIONS

The KUBOTA Tractor has been thoroughly tested for proper performance with implements sold or approved by KUBOTA. Use with implements which exceed the maximum specifications listed below, or which are otherwise unfit for use with the KUBOTA Tractor may result in malfunctions or failures of the tractor, damage to other property and injury to the operator or others. [Any malfunctions or failures of the tractor resulting from use with improper implements are not covered by the warranty.]

Tread (Max. width) with farm tires		Lower link end max. lifting capacity W ₀
Front	Rear	
1030 mm (40.6 in.)	1413 mm (55.6 in.)	1900 kg (4190 lbs)
Actual figures		
Implement weight W ₁ and / or size	Lift capacity 24 inches behind lower link end W ₁	Trailer loading weight W ₃ Max. capacity
As in the following list	1000 kg (2200 lbs)	5000 kg (11000 lbs)

W₀ :Lower link end max. hydraulic lifting capacity
 W₁ :The implement's weight which can be put on the lower link (Implement weight)
 W₂ :Max. drawbar load
 W₃ :The max. loading weight for trailer (without trailer's weight) (Trailer loading weight)



T12630GE07101

- **NOTE**
- Implement size may vary depending on soil operating conditions.

No.	Implement		Remarks	Limitations	
1	Trailer		Max. Load Capacity	5000 kg (11000 lbs)	
			Max. Drawbar Load	1000 kg (2200 lbs)	
2	Mower	Rotary-Cutter	Max. Cutting Width	2130 mm (84 in.)	
			Max. Weight	540 kg (1200 lbs)	
		Flail Mower (Heavy)	Max. Cutting Width	3050 mm (120 in.)	
			Max. Weight	800 kg (1760 lbs)	
Sickle Bar	Max. Cutting Width	2130 mm (84 in.)			
3	Sprayer		Max. Tank Capacity	Mid	680 L (180 U.S.gals.)
				Rear 3P	680 L (180 U.S.gals.)
				Drawbar	4000 L (1050 U.S.gals.)
4	Rotary Tiller		Max. Tilling Width	2130 mm (84 in.)	
			Max. Weight	800 kg (1760 lbs)	
5	Bottom Plow		Max. Size	14 in. × 3, 16 in. × 2, 18 in. × 1	
			Max. Weight	450 kg (1000 lbs)	
6	Disc-harrow	3P Type	Max. Size	18 in. × 24	
			Max. Harrowing Width	2130 mm (84 in.)	
			Max. Weight	450 kg (1000 lbs)	
		Drawbar Type	Max. Harrowing Width	2750 mm (108 in.)	
7	Disc Plow		Max. Size	24 in. × 3, 24 in. × 2	
			Max. Weight	450 kg (1000 lbs)	
8	Sub Soiler		Numbers of Cultivating Tines	2	
			Cultivating Depth	400 mm (16 in.)	
9	Cultivator		Max. Width	3660 mm (144 in.)	
			Number of Rows	4	
			Max. Weight	450 kg (1000 lbs)	

■ **NOTE**

- **Implement size may vary depending on soil operating conditions. Must remove front weight with this implement.**

W1012736

1. ENGINE

[2] SERVICING

(1) Tightening Torques

Tightening torques of screws, bolts and nuts on the table below are especially specified.
 (For general use screws, bolts and nuts : See page G-11.)

Item	N·m	kgf·m	ft-lbs
ROPS frame	196.1 to 225.6	20.0 to 23.0	144.7 to 166.4
Foldable ROPS	29.4 to 49.0	3.0 to 5.0	21.7 to 36.2
Power steering hoses retaining nut	24.5 to 29.4	2.5 to 3.0	18.1 to 21.7
Front axle support mounting screw	167 to 196	17.0 to 20.0	123 to 144
Starter's terminal B mounting nut	8.8 to 11.8	0.9 to 1.2	6.5 to 8.7
Bonnet support mounting screw	48.1 to 55.8	4.9 to 5.7	35.5 to 41.2
Support frame mounting screw	48.1 to 55.8	4.9 to 5.7	35.3 to 41.2
Engine and clutch housing mounting screw, nut	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
Engine and clutch housing mounting stud bolt	39.2 to 49.0	4.0 to 5.0	28.9 to 36.2

W1012736


(2) Checking, Disassembling and Servicing

(A) Separating Engine from Tractor

Draining Coolant

1. See page 1-S7.

W1010746



Draining Engine Oil

1. Start and warm up the engine for approx. 5 minutes.
2. Place an oil pan underneath the engine.
3. Remove the drain plugs (1) to drain oil.
4. After draining, screw in the drain plugs (1).


(When refilling)

- Fill the engine oil up to the upper line on the dipstick (3).

Engine oil	Capacity	10.7 L 11.3 U.S.qts. 9.4 Imp.qts.

■ IMPORTANT


- Never mix two different type oil.
- Use the proper SAE Engine Oil according to ambient temperatures.
 Refer to "LUBRICANTS, FUEL AND COOLANT". (See page NG-3.)



- (1) Drain Plug
- (2) Oil Inlet Plug
- (3) Dipstick

A : Oil level is acceptable within this range.

W1010792



Draining Transmission Fluid

1. Place oil pans underneath the transmission case.
2. Remove the drain plugs (1).
3. Drain the transmission fluid.
4. Reinstall the drain plugs (1).

(When reassembling)

- Fill up from filling port after removing the filling plug until reaching the dipstick.
- After running the engine for few minutes, stop it and check the fluid level again, add the fluid to prescribed level if it is not correct level.


Transmission fluid	Capacity	33.0 L 34.88 U.S.qts. 29.04 Imp.qts.
--------------------	----------	--

■ IMPORTANT

- Use only KUBOTA SUPER UDT fluid. Use of other oils may damage the transmission or hydraulic system.
- Refer to “LUBRICANTS, FUEL AND COOLANT”. (See page NG-3.)
- Do not mix different brands fluid together.

(1) Drain Plug

W1011006



Foldable ROPS

1. Remove the foldable ROPS (1).
2. Remove the ROPS frame right and left (2).


(When reassembling)

Tightening torque	ROPS frame (L and R)	193.1 to 225.6 N·m 20.0 to 23.0 kgf·m 144.7 to 166.4 ft·lbs
	Foldable ROPS	29.4 to 49.0 N·m 3.0 to 5.0 kgf·m 21.7 to 36.7 ft·lbs

(1) Foldable ROPS

(2) ROPS Frame

W1011362



Bonnet and Covers

1. Remove the exhaust pipe (1).
2. Remove the bonnet (2).
3. Disconnect the battery's cable.
4. Disconnect the head light 3P connectors.
5. Remove the front lower cover (4) and side cover (5).
6. Remove the bonnet stay (6).

(1) Exhaust Pipe

(4) Front Lower Cover


(2) Bonnet

(5) Side Cover

(3) Battery

(6) Bonnet Stay

W1011547



Radiator Hoses and Air Cleaner Hoses

1. Disconnect the radiator hoses (2) and (4) from engine side.
2. Disconnect the air cleaner hose (3) from the intake manifold.
3. Disconnect the radiator hose (5).
4. Remove the delivery pipe clamp.
5. Remove the muffler (1).

(1) Muffler


(4) Radiator Hose

(2) Radiator Hose

(5) Radiator Hose

(3) Air Cleaner Hose

W1011745



T12321EN00601

Power Steering Hoses


1. Disconnect the power steering hoses (1), (2).

(When reassembling)

Tightening torque	Power steering hose retaining nut	24.5 to 29.4 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 ft·lbs
-------------------	-----------------------------------	---

- (1) Power Steering Hose (2) Power Steering Hose

W1011890



T12321EN00701

Propeller Shaft


1. Slide the propeller shaft cover (3), (4) after removing the screws (7), (8).
2. Tap out the spring pin (2), (6) and then slide the coupling (1), (9) to the front and rear.

(When reassembling)


- Apply grease to the splines of the propeller shaft (5) and pinion shaft.

- (1) Coupling (2) Spring Pin (3) Propeller Shaft Cover (4) Propeller Shaft Cover (5) Propeller Shaft (6) Spring Pin (7) Screw (8) Screw (9) Coupling

W1012089



T12680TR01301




T12321EN00801

Wire Harness L.H.

1. Disconnect the battery positive cable (1).
2. Disconnect the head light cable (2) and 4WD / Bi-speed turn connectors (4).
3. Remove the hose clamps (3).

- (1) Battery Positive Cable (2) Head Light Cable (3) Hose Clamp (4) 4WD / Bi-speed Turn Connector

W1012261



T12321EN00900


Front Axle Support as a Unit

1. Check the front axle and clutch housing case are securely mounted on the disassembling stands.
2. Separate the front axle support as a unit after removing the front axle support mounting screws.


(When reassembling)

Tightening torque	Front axle support mounting screw (M14, UBS)	167 to 196 N·m 17.0 to 20.0 kgf·m 123 to 144 ft·lbs
-------------------	--	---


W1012372




T12321EN01001




T12553TR00602



T12321EN01101



T12553TR02202



T12680TR01001

Steering Wheel, Meter Panel and Rear Bonnet

1. Remove the steering wheel (1) with a steering wheel puller (Code No. 07916-51090).
2. Remove the shuttle lever grip (8).
3. Remove the meter panel mounting screws open the meter panel (2).
4. Disconnect the two connectors (3) and meter cable (4).
5. Disconnect the main switch connector (5) and combination switch connector (6).
6. Disconnect the hazard switch connector (9).
7. Disconnect the engine stop cable (7) at the engine side.
8. Remove the rear bonnet (10) and lower cover (11).

- | | |
|----------------------------------|-----------------------------|
| (1) Steering Wheel | (7) Engine Stop Cable |
| (2) Meter Panel | (8) Shuttle Lever Grip |
| (3) Connector | (9) Hazard Switch Connector |
| (4) Meter Cable | (10) Rear Bonnet |
| (5) Main Switch Connector | (11) Lower Cover |
| (6) Combination Switch Connector | |

W1012482

Piping for 3-Point Hydraulic System

1. Remove the accelerator rod (1).
2. Remove the suction pipe (3).
3. Remove the delivery pipe (4) for 3-point hydraulic system.
4. Remove the delivery pipe (2) for power steering.

- | | |
|---------------------|-------------------|
| (1) Accelerator Rod | (3) Suction Pipe |
| (2) Delivery Pipe | (4) Delivery Pipe |


W1012667

Wire Harness R.H. and Fuel Pipes

1. Disconnect the **3P** connector for solenoid valve (3).
2. Disconnect the wiring lead (2) from the glow plug.
3. Disconnect the coolant thermo sensor **1P** connector (1).
4. Remove the fuel pipes (4).

- | | |
|---|--|
| (1) Coolant Thermo Sensor 1P Connector | (3) 3P Connector for Solenoid Valve |
| (2) Wiring Lead for Glow Plug | (4) Fuel Pipe |

W1013162




Wire Harness L.H.

1. Disconnect the alternator **2P** connector (1) and **B** terminal (2).
2. Disconnect the starter motor **C** terminal (5) and **B** terminal (4).
3. Disconnect the engine oil pressure switch terminal (3).

Tightening torque	Starter's terminal B mounting nut	8.8 to 11.8 N·m 0.9 to 1.2 kgf·m 6.5 to 8.7 ft-lbs
-------------------	--	--

- (1) Alternator **2P** Connector (4) Starter Motor **B** Terminal
 (2) Alternator **B** Terminal (5) Starter Motor **C** Terminal
 (3) Engine Oil Pressure Switch Terminal

W1013300



Bonnet Support


1. Remove the bonnet support (1).
2. Remove the support frame (2).

(When reassembling)

Tightening torque	Bonnet support mounting screw	48.1 to 55.8 N·m 4.9 to 5.7 kgf·m 35.5 to 41.2 ft-lbs
	Support frame mounting screw	48.1 to 55.8 N·m 4.9 to 5.7 kgf·m 35.5 to 41.2 ft-lbs

- (1) Bonnet Support (2) Support Frame

W1013588



Separating Engine from Clutch Housing

1. Hoist the engine by the hoist and chain.
2. Remove the engine mounting screws and nuts, and separate the engine from the clutch housing.

(When reassembling)

- Apply molybdenum disulphide (Three Bond 1901 or equivalent) to the splines of clutch disc boss.
- Apply liquid gasket (Three Bond 1141, 1211 or equivalent) to joint face of the engine and clutch housing.

Tightening torque	Engine and clutch housing mounting screw and nut	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Engine and clutch housing mounting stud bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft-lbs

W1013765

2. CLUTCH

[2] SERVICING

(1) Tightening Torques


Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts : See page G-11.)

Item	N·m	kgf·m	ft-lbs
ROPS frame (L and R)	196.1 to 225.6	20.0 to 23.0	144.7 to 166.4
Foldable ROPS	29.4 to 49.0	3.0 to 5.0	21.7 to 36.2
Power steering hose retaining nut	24.5 to 29.4	2.5 to 3.0	18.1 to 21.7
Starter's terminal B mounting nut	8.8 to 11.8	0.9 to 1.2	6.5 to 8.7
Bonnet support mounting screw	48.1 to 55.8	4.9 to 5.7	35.5 to 41.2
Support frame mounting screw	48.1 to 55.8	4.9 to 5.7	35.5 to 41.2
Engine and clutch housing mounting screw, nut	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
Engine and clutch housing mounting stud bolt	38.2 to 45.1	3.9 to 4.6	28.2 to 33.3
Fuel hose cover mounting screw	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
Rear wheel mounting nut	260 to 304	26.5 to 31.0	192 to 224
Rear ROPS mounting U-bolt	196 to 225	20 to 23	144.7 to 166.4
Step mounting screw	48.1 to 55.9	4.9 to 5.7	35.4 to 41.2
Clutch housing and transmission case mounting screw, nut			
M12, grade 11 nut	103.0 to 117.7	10.5 to 12.0	75.9 to 86.8
M12, grade 7 screw, nut	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
M10, grade 9 screw	60.8 to 70.6	6.2 to 7.2	44.8 to 52.1
Clutch housing and transmission case mounting stud bolt	38.2 to 45.1	3.9 to 4.6	28.2 to 33.3
Transmission upper cover mounting screw	23.5 to 27.5	2.4 to 2.8	17.4 to 20.3
PTO clutch valve mounting screw	23.5 to 27.5	2.4 to 2.8	17.4 to 20.3
PTO clutch case bearing holder mounting screw	23.5 to 27.5	2.4 to 2.8	17.4 to 20.3

W1012736

(2) Disassembling and Assembling

(A) Separating Engine from Clutch Housing Case



Foldable ROPS

1. Remove the foldable ROPS (1).
2. Remove the ROPS frame right and left (2).


(When reassembling)

Tightening torque	ROPS frame (L and R)	193.1 to 225.6 N·m 20.0 to 23.0 kgf·m 144.7 to 166.4 ft-lbs
	Foldable ROPS	29.4 to 49.0 N·m 3.0 to 5.0 kgf·m 21.7 to 36.7 ft-lbs

(1) Foldable ROPS

(2) ROPS Frame

W1011362




Bonnet and Covers

1. Remove the exhaust pipe (1).
2. Remove the bonnet (2).
3. Disconnect the battery's cable.
4. Disconnect the head light 3P connectors.
5. Remove the front lower cover (4) and side cover (5).
6. Remove the bonnet stay (6).

- (1) Exhaust Pipe
- (2) Bonnet
- (3) Battery
- (4) Front Lower Cover
- (5) Side Cover
- (6) Bonnet Stay

W1011547




Radiator Hoses and Air Cleaner Hoses

1. Disconnect the radiator hoses (2) and (4) from engine side.
2. Disconnect the air cleaner hose (3) from the intake manifold.
3. Disconnect the radiator hose (5).
4. Remove the delivery pipe clamp.
5. Remove the muffler (1).

- (1) Muffler
- (2) Radiator Hose
- (3) Air Cleaner Hose
- (4) Radiator Hose
- (5) Radiator Hose

W1011745



Power Steering Hoses


1. Disconnect the power steering hoses (1), (2).

(When reassembling)

Tightening torque	Power steering hose retaining nut	24.5 to 29.4 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 ft-lbs
-------------------	-----------------------------------	---

- (1) Power Steering Hose
- (2) Power Steering Hose

W1011890



Propeller Shaft

1. Slide the propeller shaft cover (3), (4) after removing the screws (7), (8).
2. Tap out the spring pin (2), (6) and then slide the coupling (1), (9) to the front and rear.

(When reassembling)

- Apply grease to the splines of the propeller shaft (5) and pinion shaft.

- (1) Coupling
- (2) Spring Pin
- (3) Propeller Shaft Cover
- (4) Propeller Shaft Cover
- (5) Propeller Shaft
- (6) Spring Pin
- (7) Screw
- (8) Screw
- (9) Coupling

W1012089

