


Product: STIHL 031,032 Chain Saws Service Repair Workshop Manual  
Full Download: <https://www.arepairmanual.com/downloads/stihl-031032-chain-saws-service-repair-workshop-manual/>

# STIHL 031, 032



Sample of manual. Download All 94 pages at:  
<https://www.arepairmanual.com/downloads/stihl-031032-chain-saws-service-repair-workshop-manual/>

## FOREWORD

This service manual covers model 032 chain saws from machine No. 532 9921 onward (start of production) and can thus be used as a basis for professional overhauls and repairs.

The previous service manual for models 030 AV and 031 AV has been discontinued. As the models are substantially identical in their engineering design, the repair procedures in this manual can also be used for models 031/030.


Differences in construction have been dealt with separately and identified by the supplement "031 (030)".

In the event of faults it is quite possible that a single condition may have several causes. It is therefore advisable to consult the "Troubleshooting Charts" in all chapters when tracing faults. We also recommend you make use of the exploded views in the illustrated parts lists when carrying out repairs.

Our technical information bulletins give details of engineering changes which have been introduced since publication of this service manual.

This service manual and all technical information bulletins are intended exclusively for the use of STIHL servicing dealers and staff and must not be passed on to third parties.


Assembly stand



Repair work is made considerably easier if the chain saw is mounted on assembly stand 5910 850 3100. The saw is quickly attached to the stand by means of the two bar mounting studs and collar nuts.

While on the assembly stand the saw can be swivelled into any required position to suit the repair in question. This not only has the advantage of keeping the component in the best position for the repair but also leaves both hands free for the work and thus effects a considerable time saving.

Special tool manual



Our special tool manual illustrates and lists the part numbers of all available machine-related tools as well as general purpose tools for all machines.

The special tool manual is available in various languages and can be ordered by quoting the appropriate part number listed hereunder.

German	0455 901 0023
English	0455 901 0123
French	0455 901 0223
Spanish	0455 901 0323
Yugoslav	0455 901 0423
Swedish	0455 901 0523
Italian	0455 901 0723
Portuguese	0455 901 1223

# STIHL®

Andreas Stihl  
Postfach 1760  
D-7050 Waiblingen  
West Germany

## CONTENTS

1.	<b>Specifications - 032</b>	5	3.3.1	Exposing the Cylinder (Heated Handles)	23	3.8.2	Vacuum Test	38
1.1	Specifications - 031 (030)	8	3.4	Visual Inspection	23	3.8.3	Leakage Testing the Crankcase - 031 (030)	38
			3.5	Exposing the Cylinder - 031 (030)	23	3.8.4	Replacing the Oil Seals	39
			3.5.1	Exposing the Cylinder - 031 (030)				
2.	<b>Clutch, Chain Drive and Chain Brake</b>	9		Heated Handles	25	4.	<b>Ignition System</b>	
			3.6	Cylinder and Piston	26	4.1	Construction	40
			3.6.1	Removal	26	4.2	Description of Operation	40
2.1	Clutch and Chain Sprocket	9	3.6.1.1	Removal, Heated Handles	26	4.2.1	General	40
2.1.1	Construction and Operation	9	3.6.2	Removal on 031 (030)	27	4.2.2	Breaker-Controlled Magneto Ignition	40
2.1.2	Troubleshooting Chart	10	3.6.2.1	Removal on 031 (030) with Heated Handles	27	4.2.3	Transistor-Controlled Magneto Ignition	42
2.1.3	Disassembly and Repair	11	3.6.3	Visual Inspection	27	4.3	Troubleshooting Chart	43
2.1.3.1	Standard Clutch with 3 Springs	11	3.6.4	Installation	27	4.3.1	Breaker-Controlled Ignition	43
2.1.3.2	Standard Clutch with Ring Spring	12	3.6.4.1	Installation with Heated Handles	30	4.3.2	Electronic Ignition	44
2.1.3.3	Quickstop Clutch (with Isolating Clutch)	12	3.6.5	Installation on 031 (030)	30	4.4	Spark Plug	45
2.1.4	Installation	13	3.6.5.1	Installation on 031 (030) with Heated Handles	30	4.4.1	Description of Operation	45
2.1.4.1	Standard Clutch	13	3.7	Crankcase, Crankshaft	31	4.4.2	Troubleshooting Chart	45
2.1.4.2	Quickstop Clutch (with Isolating Clutch)	13	3.7.1	Removal of Crankshaft	31	4.4.3	Checking and Cleaning Spark Plug	45
2.2	Chain Brake	14	3.7.1.1	Removal of Crankshaft (Heated Handles)	33	4.4.4	Installation of Spark Plug	46
2.2.1	Construction and Operation	14	3.7.2	Removal of Crankshaft - 031 (030)	34	4.5	Ignition Lead	46
2.2.1.1	Band Brake	14	3.7.2.1	Removal of Crankshaft on 031 (030) with Heated Handles	34	4.5.1	Description of Operation	46
2.2.1.2	Shoe Brake	15	3.7.3	Visual Inspection	34	4.5.2	Removal of Ignition Lead on 032 with Heated Handles	46
2.2.2	Troubleshooting Chart	15	3.7.4	Installation of Crankshaft	34	4.5.3	Removal of Ignition Lead 031 (030)	47
2.2.3	Disassembly and Repair	16	3.7.4.1	Installation of Crankshaft (Heated Handles)	35	4.5.4	Visual Inspection	47
2.2.3.1	Band Brake	16	3.7.5	Installation of Crankshaft - 031 (030)	36	4.5.5	Installation of Ignition Lead (Heated Handles)	47
2.2.3.2	Shoe Brake	17	3.7.5.1	Installation of Crankshaft on 031 (030) with Heated Handles	36	4.5.6	Installation of Ignition Lead - 031 (030)	47
2.2.4	Installation	18	3.8	Leakage Testing the Crankcase	36	4.6	Ground Lead	48
2.2.4.1	Band Brake	18	3.8.1	Pressure Test	37	4.6.1	Description of Operation	48
2.2.4.2	Shoe Brake	19				4.6.2	Checking the Ground Lead	48
3.	<b>Engine</b>	20						
3.1	Construction	20						
3.2	Troubleshooting Chart	20						
3.3	Exposing the Cylinder	21						

4.6.3	Exposing the Ground Lead	48	4.11	Contact Set	56	5.3	Removal of Rope Rotor	67
4.6.4	Exposing the Ground Lead - 031 (030)	48	4.11.1	Construction	56	5.3.1	Visual Inspection	67
4.7	Stop Switch	48	4.11.2	Description of Operation	56	5.3.2	Replacing the Starter Rope	67
4.7.1	Description of Operation	48	4.11.3	Replacing the Contact Set	56	5.3.3	Replacing the Rewind Spring	68
4.7.2	Checking the Stop Switch	48	4.11.4	Replacing the Contact Set - 031	57	5.3.3.1	Tensioning the Rewind Spring	68
4.7.3	Removal of Stop Switch	48	4.11.5	Replacing the Contact Set - 030	58	5.3.4	Starter Rope Guide Bush	69
4.7.4	Installation of Stop Switch	48	4.12	Trigger Plate	58	5.3.4.1	Replacing the Rope Guide Bush	69
4.8	Flywheel	49	4.12.1	Construction	58	5.4	Rewind Starter - 031 (030)	70
4.8.1	Description of Operation	49	4.12.2	Checking the Trigger Plate	58	5.4.1	Construction and Operation	70
4.8.2	Removal of Flywheel	49	4.12.3	Replacing the Trigger Plate	58	5.4.2	Troubleshooting Chart	70
4.8.3	Installation of Flywheel	50	4.12.4	Replacing the Trigger Plate - 031	59	5.4.3	Removal of Rope Rotor	71
4.8.4	Removal of Flywheel - 031 (030)	50	4.13	Ignition Timing	59	5.4.4	Visual Inspection	71
4.8.5	Installation of Flywheel - 031 (030)	50	4.13.1	Checking Breaker - Controlled Ignition	59	5.4.5	Replacing the Starter Rope	71
4.9	Ignition Armature	51	4.13.2	Adjusting Breaker - Controlled Ignition	60	5.4.6	Replacing the Rewind Spring	71
4.9.1	Construction	51	4.13.3	Checking Breaker - Controlled Ignition - 031	61	5.4.6.1	Tensioning the Rewind Spring	72
4.9.2	Resistance Test on Primary Winding	51	4.13.4	Adjusting Breaker - Controlled Ignition - 031	61	5.4.7	Replacing the Starter Rope Guide Bush	72
4.9.3	Resistance Test on Secondary Winding	51	4.13.5	Adjusting Breaker - Controlled Ignition - 031	62	5.5	Routine Maintenance	72
4.9.4	Testing with Ignition Coll Tester	52	4.13.6	Checking Electronic Ignition	63	5.6	Replacing the Pawls and Springs	72
4.9.5	Removal of Ignition Armature	52	4.13.7	Correcting Electronic Ignition	64	6.	<b>AV Handle System</b>	73
4.9.6	Installation of Ignition Armature	53	4.14	Magneto Edge Gap	65	6.1	Construction and Operation	73
4.9.7	Removal of Ignition Armature - 031 (030)	54	4.14.1	Magneto Edge Gap - 031 (030)	65	6.2	Replacing the Vibration Dampers	73
4.9.8	Installation of Ignition Armature - 031 (030)	54	5.	<b>Rewind Starter</b>	66	6.2.1	Rear Handle	73
4.10	Condenser	54	5.1	Construction and Operation	66	6.2.2	Handlebar	73
4.10.1	Description of Operation	54	5.2	Troubleshooting Chart	66	6.2.3	Handle Frame	73
4.10.2	Checking the Condenser	54				6.3	AV Handle System - 031 (030)	73
4.10.3	Replacing the Condenser	55				6.3.1	Replacing the Vibration Dampers	73
4.10.4	Replacing the Condenser - 031 (030)	55						

7.	<b>Electrically Heated Handles</b>	74	9.	<b>Fuel System</b>	82
7.1	Construction	74	9.1	Construction	82
7.2	Description of Operation	74	9.2	Operation of Fuel Pump	82
7.3	Troubleshooting	74	9.3	Operation of Carburetor	82
7.4	Component Parts	76	9.4	Troubleshooting Chart	84
7.4.1	Switch	76	9.5	Leakage Testing the Carburetor	86
7.4.2	Heating Element in Rear Handle	76	9.6	Removal of Carburetor	86
7.4.3	Heating Element in Handlebar	76	9.7	Repairing Fuel Pump	86
7.4.4	Generator	76	9.7.1	Removal	86
7.5	Heated Handles - 031	77	9.7.2	Visual Inspection	86
7.5.1	Construction and Operation	77	9.8	Repairing the Carburetor	87
7.5.2	Troubleshooting	77	9.8.1	Disassembly	87
7.5.3	Disassembly	77	9.8.2	Reassembly	88
			9.9	Repairing the Carburetor - 031 (030)	88
			9.10	Adjusting the Carburetor	89
8.	<b>Chain Lubrication</b>	78	9.10.1	Fine Adjustment of Carburetor	89
8.1	Construction	78	9.11	Adjusting the Carburetor - 031 (030)	89
8.2	Description of Operation	78	9.12	Fuel Line and Tank Vent	90
8.3	Troubleshooting Chart	79	9.12.1	Operation	90
8.4	Oil Tank/Tank Vent	80	9.12.2	Cleaning the Pickup Body	90
8.4.1	Construction and Operation	80	9.12.3	Removal and Installation of Hose	90
8.5	Pickup Body	80			
8.5.1	Removal and Installation, Repair	80	10.	<b>Air Filter and Choke Valve</b>	91
8.6	Valve	80	10.1	Operation	91
8.6.1	Removal and Installation	80	10.2	Removing and Cleaning the Filter	91
8.7	Oil Pump	81		Set of Special Tools	92
8.7.1	Removal	81		Set of Testing Tools	92
8.7.2	Disassembly of Oil Pump	81			
8.7.3	Assembly of Oil Pump	81			
8.7.4	Installation of Oil Pump	81			

## 1. SPECIFICATIONS — 032

<b>Engine</b>	Single cylinder two-stroke engine with specially processed cylinder bore.	
	Displacement:	51 cm <sup>3</sup>
	Bore:	45 mm
	Stroke:	32 mm
	Compression ratio:	9,5:1
	Power output:	2.6 kW (3.5 DIN HP) at 10,000 r.p.m.
	Max. torque:	3 Nm at 6,500 r.p.m.
	Max. permissible engine speed:	12,000 r.p.m.
	Mean idle speed:	2,200 r.p.m.
	Crankshaft:	two-part drop forging
	Crankshaft bearings:	2 deep-groove ball bearings
	Crankpin:	14.4 mm diam.
	Big-end bearing:	Needle cage
	Piston pin:	10 mm diam.
	Small-end bearing:	Needle cage
	Rewind starter:	Pawl engagement with automatic starter rope rewind mechanism
	Starter rope:	3.5 mm diam., 1060 mm long
Clutch:	Centrifugal clutch without linings, 69 mm diam.	
Clutch engages at:	3,200 r.p.m.	
Crankcase leakage test with overpressure:	0.5 bar	
Crankcase leakage test with vacuum:	0.5 bar	
<b>Fuel System</b>	Carburetor:	All position diaphragm carburetor with integral fuel pump
	Adjustment:	
	High-speed adjustment screw H:	Open 1½ turns
	Low-speed adjustment screw L:	Open 1½ turns (basic setting with screws initially lightly against their seats)
	Carburetor leakage test with overpressure:	0.4 bar
	Fuel capacity:	0.53 liter
	Fuel mixture:	Regular grade gasoline and two-cycle engine oil Mix ratio 1:40 with STIHL two-cycle engine oil; 1:25 with other branded two-cycle engine oils
Air filter:	Large area, double sided flat wire mesh element	

**Ignition System****032 AV and 032 AVQ**

Type:	Breaker-controlled magneto ignition
Magneto edge gap:	4.7-8.5 mm
Air gap:	0.2-0.3 mm
Ignition timing:	2.1-2.3 mm before T.D.C.
Advance angle:	27-28°
Breaker point gap:	0.3-0.4 mm
Condenser:	Capacitance 0.15-0.19 $\mu$ F
Ignition armature:	Coil winding resistances
	Primary                      Secondary
	0.7-1.0 $\Omega$ 7.7-10.3 k $\Omega$

**032 AVE**

Type:	Transistor-controlled (breakerless) magneto ignition with automatic advance
Air gap:	0.2-0.3 mm
Ignition timing:	2.7 mm before T.D.C. at 8,000 r.p.m.
Advance angle:	30° at 8,000 r.p.m.
Ignition armature:	as 032 AV/032 AVQ

**All models**

Spark plug (suppressed):	Bosch WSR 6 F or Champion RCJ 6 Y Heat range 200 Electrode gap 0.5 mm Spark plug thread M 14 x 1.25, 9.5 mm long
--------------------------	---

**Tightening torques**

Crankshaft nut (ignition side) M 8 x 1:	30 Nm
Hub/clutch carrier (sprocket side):	40 Nm
M 5 socket head screws:	8 Nm
M 5 pan head screws:	5 Nm
M 4 pan head screws:	2.5 Nm
M 5 nuts:	5 Nm
Spark plug:	25 Nm

CHAIN DRIVE AND  
CHAIN BRAKE

SHOIFACHIDING  
NR 000 10 100

Chain and Chain  
Sprocket

STIHL Chain

STIHL Chain

STIHL Chain

STIHL Chain

STIHL Chain

STIHL Chain

### Cutting Attachement

Guide bars:

STIHL Duromatic guide bars with stellite-tipped nose.  
STIHL Rollomatic guide bars with sprocket nose.  
Both types with corrosion-resistant finish and induction hardened rails.

Bar lengths:

Duromatic 40, 45 and 50 cm  
Rollomatic 32, 37, 40 and 45 cm

Chain:

8.25 mm (0.325") Oilomatic  
Rapid-Micro  
8.25 mm (0.325") Oilomatic  
Rapid-Micro S

Chain sprocket:

9.32 mm (3/8") Oilomatic  
Rapid-Standard  
9.32 mm (3/8") Oilomatic  
Rapid-Standard S

Chain speed:

7-tooth for 3/8" pitch  
8-tooth for 0.325" pitch  
18.5 m/s at 8,500 r.p.m.

Chain lubrication:

Fully automatic speed-controlled oil pump with plunger; operative only when chain is running.  
Additional flow quantity control by means of adjusting screw.

Oil delivery rate:

10 cm<sup>3</sup> at 6,000 r.p.m.

Oil tank capacity:

0.31 liter

### Weights

Model:

AV/AVE/

AVQ/AVEQ/

AVEW

AVEQW

Dry powerhead less  
bar and chain:

5.6 kg

6.0 kg

Dry powerhead with  
32 cm bar and chain:

6.5 kg

6.9 kg

### Special Accessoires

STIHL repair kit 032

1113 900 5001

STIHL repair kit 030

1113 900 5000

and 031

Gasket set 032

1113 007 1051

Gasket set 031

1113 007 1050

**SPECIFICATIONS**  
**031 AV (030 AV)**

<b>Engine</b>	Displacement:	48 cm <sup>3</sup> (45 cm <sup>3</sup> )
	Bore:	44 mm (42 mm)
	Power output:	2.4 kW/3.2 DIN HP (2.2 kW/3.0 DIN HP) at 8,500 r.p.m.
	Max. torque:	2.85 Nm at 6,000 r.p.m.
	Rewind starter:	Two-pawl starter with automatic starter rope rewind mechanism
	Starter rope:	3.5 mm diam., 960 mm long
<b>Fuel System</b>	Carburetor setting:	
	High-speed adjustment screw H:	Open 1/4 turns
	Low-speed adjustment screw L:	Open 1/4 turns
<b>Ignition System</b>	Type:	Breaker-controlled magneto ignition
	Magneto edge gap:	3.5–7.5 mm
	Ignition timing:	2.0–2.3 mm before T.D.C.
	Ignition armature:	Coil winding resistance
		Primary            Secondary
		0.8–1.1 Ω        6.5–8.0 kΩ
	<b>031 AVE</b>	
	Type:	Transistor-controlled (breakerless) magneto ignition
	Magneto edge gap:	0.15–0.25 mm
	Ignition timing:	2.5 mm before T.D.C. at 8,000 r.p.m.
	Advance angle:	25° at 8,000 r.p.m.

## 2. CLUTCH, CHAIN DRIVE AND CHAIN BRAKE

### 2.1 Clutch and Chain Sprocket

#### 2.1.1 Construction and Operation



The transmission of power from the engine to the saw chain is effected via a centrifugal clutch. On "Quickstop" models (up to machine No. 6375950) the centrifugal clutch incorporates an isolating clutch which is actuated by the chain brake.

On the **standard clutch** the carrier screwed to the crankshaft is the clutch element which absorbs the torque and acceleration of the crankshaft. It is essential that the carrier is always tightened down to the specified torque load.

On **Quickstop models with an isolating clutch** the driving plate is the element which absorbs the torque and acceleration of the crankshaft and must, therefore, always be tightened down to the specified torque load. The clutch spider is supported on the hub of the driving plate by a plain bearing bush, but not connected to it in any other way. The release plate and locking ring are positively connected to the driving plate, but free to move radially.

When the chain brake is disengaged the release plate is moved radially into its normal position by the cam of the actuating lever, while the locking ring is moved into mesh with the lugs of the clutch spider by spring force. The engine torque is transmitted positively to the clutch spider in this way. To sa-



Top:  
Standard Clutch  
Bottom:  
Component parts of standard clutch



eguard against wear the shape of the locking ring and strength of the springs are designed so that the locking ring only engages below approx. 3,500 r.p.m. At higher speeds the centrifugal force of the asymmetric locking ring acts against the spring force - the locking ring does not engage.

When the chain brake is activated, the cam of the actuating lever disengages the release plate and thus the locking ring from the

Top:  
Isolating clutch  
Bottom:  
Component parts of isolating clutch



clutch spider. The clutch spider and driving plate can then rotate independently.

The centrifugal clutch has three clutch shoes; the clutch drum is rigidly connected to the chain sprocket.

When the engine is running at idle speed the clutch shoes are in a state of rest because the tension of the clutch spring(s) is greater than the centrifugal force. As engine speed increases the centrifugal force presses the clutch shoes outward against the clutch drum and thus transmit engine torque via

the clutch drum and chain sprocket to the saw chain.

The preload and strength of the clutch spring(s) are designed so that the clutch shoes begin to make contact with the clutch drum at an engine speed of approx. 3,200 r.p.m. (engagement speed). The clutch engages fully above this speed. It is therefore very important to set the carburetor to the correct idle speed in order to ensure that the clutch engagement

speed is not reached when the engine is idling.

### 2.1.2 Troubleshooting Chart


Condition	Cause	Remedy
Saw chain turns at idle speed	Engine idle speed too high	Readjust at idle speed adjusting screw
	Clutch spring(s) stretched or fatigued, spring hooks broken	Replace spring(s)
Isolating clutch does not engage when chain brake is released	Engine idle speed too high	Readjust at idle speed adjusting screw
	Locking ring, release plate or spring broken	Fit new locking ring, release plate or spring
Chain wears at high rate	Incorrect chain tension	Tension chain correctly

## 2.1.3 Disassembly and Repair


Disengage chain brake



Locking screw in position



Top:  
Unscrew starter cover on 031  
Center:  
Unscrewing clutch spider  
Bottom:  
Refitting clutch shoes



### 2.1.3.1. Standard Clutch with 3 Springs

First disengage the chain brake on Quickstop models and take off the sprocket cover, saw chain and bar. Remove the spark plug and fit the locking screw in its place – screw down by hand as far as it will go. On model 031 it is necessary to remove the starter cover as well.



Use a ring or socket wrench to release the clutch spider (left-hand thread – turn clockwise) and unscrew it from the crankshaft. Then take the support washer, chain sprocket with needle cage and cover plate off the crankshaft.

Pull the clutch shoes off the spider and detach the clutch springs. Wash out component parts of the clutch, including the clutch drum and the needle cage, in clean gasoline and blow out with compressed air, if available. If the clutch shoes have linings, use em-


ery cloth to roughen the friction faces of the cleaned shoes.

Replace any damaged or worn parts. Clutch shoes and springs may only be replaced **in complete sets!**

To assemble, place the clutch shoes on the arms of the spider and then attach springs one by one.



Standard clutch with ring spring




### 2.1.3.2 Standard Clutch with Ring Spring

Proceed as described under 2.1.3.2 for removal and disassembly.

Replace damaged or worn parts. The clutch shoes may only be replaced **in complete sets**.

To assemble, first hook the two ends of the spring together and place the spring in the spring groove of one clutch shoe, making sure that the spring hooks are approximately in the center of the shoe. Then place all three clutch shoes on the arms of the spider so that the spring grooves face away from the triangular plate on the spider. Now press the ring spring into the spring grooves of the other two clutch shoes with both your thumbs. Use a blunt tool to push the whole length of the spring down to the bottom of the clutch shoes.

Pressing ring spring into position






### 2.1.3.3 Quickstop Clutch (with Isolating Clutch)

First disengage the chain brake and take off the sprocket cover, chain and bar. Remove the spark plug and fit the locking screw in its place - screw down by hand as it will go. On model 031 it is necessary to remove the starter cover as well.

Use the face wrench to release the driving plate (left-hand thread - turn clockwise) and unscrew it together with the centrifugal clutch from the crankshaft.


The repair procedure is otherwise as described under 2.1.3.1.

Top:  
Unscrew starter cover on 031  
Center:  
Face wrench 11138903600  
Bottom:  
Releasing the driving plate




## 2.1.4 Installation




Top:  
Drive pin must engage in spur gear  
Bottom:  
Tightening the clutch spider



Fit chain sprocket on needle cage



Top:  
Support washer correctly positioned  
Bottom:  
Fit clutch correctly on hub of spider



### 2.1.4.1 Standard Clutch

First fit the cover plate on the crankshaft so that the drive pin (bearing pin) for the oil pump drive engages in the spur gear. Lubricate needle cage with antifriction bearing grease and fit along with chain sprocket and support washer on the crankshaft.

Now screw clutch spider onto crankshaft (left-hand thread) so

that its triangular plate faces away from the crankshaft and tighten it down with a 19 mm ring or socket wrench to a torque load of 40 Nm.

Finish off by removing the locking screw, refitting the spark plug and sprocket cover. The starter cover must also be fitted on the model 031.


### 2.1.4.2 Quickstop Clutch (with Isolating Clutch)

First fit the cover plate on the crankshaft so that the drive pin (bearing pin) for the oil pump drive engages in the spur gear. Lubricate needle cage with antifriction bearing grease and fit along with chain sprocket and support washer on the crankshaft.

## 2.2 Chain Brake

### 2.2.1 Construction and Operation

Tightening the clutch spider




Then fit the clutch on the greased hub of the driving plate so that the spider's washer locates against the locking ring. Carefully screw driving plate with clutch onto the crankshaft (left-hand thread!) and use the face wrench to tighten down to a torque load of 40 Nm.

**Important:** Once installed, the release plate and locking ring must move freely and the centrifugal clutch must be free to rotate when the locking ring is disengaged.

Finish off by removing the locking screw, refitting spark plug and sprocket cover. The starter cover must also be fitted on the model 031.

Chain brake released



#### 2.2.1.1 Band Brake

The main components of this chain brake are the brake band, tension spring and a system of levers.

The chain brake is actuated by means of the hand guard which is used to disengage as well as engage the brake.

The **chain brake is disengaged** by pulling the hand guard back toward the handlebar. This movement is transmitted via a lever system which preloads the tension spring and releases the brake band. The brake lever, which is connected to the tension spring and brake band, is thus locked in the idle position by the relay lever and remains so even when the hand guard is released.

If the chain brake has been activated at full throttle, the throttle must be released immediately (back to

Chain brake engaged



idle speed) because the clutch shoes would otherwise run against the blocked clutch drum and generate excessive frictional heat.

The **chain brake is engaged** by moving the hand guard toward the bar nose. This movement unlatches the brake lever and causes the brake band to be clamped around the clutch drum by the force of the preloaded tension spring. The clutch drum (chain sprocket) and saw chain are brought to a standstill in a fraction of a second.


### 2.2.1.2 Shoe Brake

The main components of this chain brake are the brake shoe, compression springs and the actuating lever with cam – which controls the isolating clutch as well.


The chain brake is actuated by means of the hand guard which is used to disengage as well as engage the brake.

The **chain brake is disengaged** by pulling the hand guard back against the handlebar. This causes one part of the cam on the end of the actuating lever to lift the brake shoe off the clutch drum and the other part of the cam to move the rotating release plate into its normal position. This makes the isolating clutch engage (providing the engine is running at idle speed). The cam is locked in position by the brake shoe so that the hand guard can then be released.

Chain brake released



Chain brake engaged



The **chain brake is engaged** by moving the hand guard toward the bar nose. This causes one part of the cam to displace the rotating release plate radially and thus disengage the isolating clutch. At the same time the brake shoe is pressed against the clutch drum by the force of the preloaded compression springs. This brings the chain sprocket to a standstill in a split second even if the engine continues running at high speed.

### 2.2.2 Troubleshooting Chart


Condition	Cause	Remedy
Saw chain does not stop immediately when chain brake is engaged	Brake spring(s) broken	Fit new brake spring(s)
	Brake band broken	Fit new brake band

## 2.2.3 Disassembly and Repair


## 2.2 Chain Brake

## 2.2.1 Construction and Operation





Top:  
Release chain brake  
Bottom:  
Engage chain brake on disassembled sprocket cover



Top:  
Unscrew side plate and cover  
Bottom:  
Lever brake band out of its seat



Top:  
Detaching brake band and tension spring  
Bottom:  
Removing retaining washers



## 2.2.3.1 Band Brake

Release the chain brake by pulling the hand guard toward the handlebar and take off the sprocket cover. Then re-engage the chain brake and unscrew the side plate and cover.

Detach brake band and tension spring from the pivot pin.

Remove pin for tension spring from sprocket cover and withdraw the tension spring. Remove the retain-

ing washers and take off the actuating lever, relay lever and cam.


The brake band can now be levered out of its seat in the sprocket cover.

Wash all disassembled component parts in clean gasoline and inspect them for signs of wear. It is best to compare them against new parts.





Top:  
Release chain brake  
Bottom:  
Engage chain brake on disassembled sprocket cover



Top:  
Drive out notched pins  
Bottom:  
Unscrew cover plate



Top:  
Drive out pivot pin  
Bottom:  
Detach compression springs



### 2.2.3.2 Shoe Brake

Release the chain brake by pulling the hand guard toward the handlebar and take off the sprocket cover. Then re-engage the chain brake so as to relieve the compression springs.

Use a suitable punch to drive out the notched pins which secure the outer side plate. Then remove the two screws which hold the cover


plate (they will be difficult to remove because they are secured with adhesive). Use a suitable punch to drive the cam's pivot pin - riveted to the cover plate - out of the sprocket cover, from the outside inwards. The cover plate can now be lifted off; the pivot pin slips out of the cam. Detach the compression springs and pull off the brake shoe.

Examine all disassembled parts for signs of wear - compare with new


parts where necessary. The brake shoe lining must have a minimum thickness of 1 mm or braking efficiency will otherwise be impaired.

## 2.2.4 Installation





Top:  
Actuating lever in position with pivot pin fitted  
Bottom:  
Tension spring and brake band fitted on cam



Top:  
Carefully drive retaining pin into loop  
Bottom:  
Fit tension spring in sprocket cover slot



Top:  
Use a screwdriver to position tip of cam in notch  
Bottom:  
Relay lever correctly positioned



## 2.2.4.1. Band Brake


Insert actuating lever through slot in sprocket cover, grease the pivot pin and fit the cam so that its tip engages in the opening in the actuating lever. Fit the retaining washer on the cam pivot pin. Fit closed loop of tension spring in the slot in the brake band's loop and then slip both over the pin (lubricate with grease!) on the cam. At the same time engage the hook at the other end of the tension spring in the slot in the sprocket cover.

Then press the bent end of the brake band into its seat in the sprocket cover and carefully drive the retaining pin into the loop. Use a small screwdriver and insert it in the tension spring's pivot pin hole from the front of the sprocket cover and push the spring loop forward up to the edge of the hole. Fit the pivot pin in the hole from the inside and push it in until the spring loop engages in the groove.

Use a screwdriver to turn the cam against the spring until its tip engages the notch in the actuating lever; the cam is thus locked in this position for the time being. Now push the relay lever over the pivot pin and line it up by hand so that it can be pressed into its seat in the actuating lever.


Then fit plain and retaining washers on the relay lever's pivot pin. Coat friction faces of cam and relay lever with ample grease.

Actuating lever assembled



Finish off by checking function of chain brake; refit plastic cover and side plate as well as the sprocket cover. The chain brake must be released before the sprocket cover can be fitted.

Top:  
Brake shoe in position  
Bottom:  
Compression springs correctly  
positioned




#### 2.2.4.2 Shoe Brake

Slip the brake shoe over the short pivot pin (lubricate with grease first!). Fit the large diameter compression spring outside and the other spring inside between the cover plate and brake shoe.

Then push the cam onto the pivot pin in the cover plate (lubricate with grease first!) so that the cam which controls the brake shoe en-

Cam engages in recess



gages in the semicircular recess next to the pivot pin. Coat friction faces of cam and brake shoe with ample grease.

Now insert the actuating lever through the slot in the sprocket cover, locate the pivot pins on the cover plate in their respective holes and use a hammer to drive home the cam pivot pin until it is flush with the front side of the sprocket cover. Coat cover mounting screws with adhesive 0786111109 (LOCTITE 270 or 73), insert them and tighten down securely.

Finish off by refitting the side plate, checking the function of the chain brake and mounting the sprocket cover. The chain brake must be released before the sprocket cover can be fitted.

## 3. ENGINE

## 3.1. Construction

Model 032 and 031 (030) chain saws are powered by an air-cooled, single cylinder two-stroke engine.

The crankcase is a two-part pressure die casting made of a special magnesium alloy. The two-piece, drop-forged crankshaft is supported in two-ball bearings. Two oil seals, in the crankcase at the igni-

tion side and in the ball bearing at the sprocket side, hermetically seal the crank chamber.

The connecting rod, also drop-forged, is supported in needle cages on both the crankpin and the piston pin. Once the needle cage and the connecting rod have been fitted, the two halves of the crankshaft are pressed together to

form a torsionally rigid assembly and then machine finished. For this reason **a replacement crankshaft can only be supplied complete with connecting rod and needle cage.**

The cylinder and piston are made of a special aluminium alloy. The cylinder bore is coated on a special process.

## 3.2 Troubleshooting Chart



Check fuel system, carburetor, air filter and ignition system before looking for faults in the engine.

Condition	Cause	Remedy
Engine does not start easily, stalls at idle speed, but runs normally at full throttle	Oil seals in crankcase leaking	Replace oil seals
	Manifold leaking	Seal or replace manifold
	Crankcase damaged (cracks)	Replace crankcase
Engine does not deliver full power or runs erratically	Secondary air seepage into engine through poorly mounted or faulty manifold	Mount manifold correctly or replace
	Piston rings leaking or broken	Replace piston rings
Engine overheats	Insufficient cylinder cooling. Air inlets in fan housing blocked or cylinder cooling fins clogged with dirt	Thoroughly clean all cooling air passages

### 3.3 Exposing the Cylinder

See Chapter 1.2

Top:  
Unscrew slotted nut on carburetor  
box cover  
Bottom:  
Uncrew slotted nuts on air filter





Disassemble the sprocket cover, cutting attachment and fan housing. (Disengage the chain brake on Quickstop models.)

Unscrew the slotted nut on the carburetor box cover and take off the carburetor box cover.

Remove both slotted nuts on the air filter and pull off the air filter.

Top:  
Remove retaining washer and  
disconnect throttle rod  
Bottom:  
Remove carburetor mounting nuts





Press the retaining washer out of the groove in the throttle shaft and disconnect the throttle rod.

Unscrew the two mounting nuts from the carburetor studs. Pull the carburetor off the studs but use pliers to hold the impulse hose securely in its housing slot. Take off the fuel hose. Remove shim on right-hand stud and take sleeve out of manifold. Push the manifold and the impulse hose into the space



3.4 Exposing the Cylinder  
(3-330)

Top:  
Pull off carburetor, hold impulse hose  
securely  
Bottom:  
Take out shim and sleeve



between the cylinder and handle frame.

Top:  
Push manifold and impulse hose  
inwards  
Bottom:  
Unscrew handlebar




Unscrew handlebar at handle frame and crankcase.

Remove the two collar screws in the handle frame (rear vibration dampers) and one collar screw at the annular buffer.

Pull the fuel hose off the elbow connector. The elbow connector is behind the fuel filler cap.

Top:  
Remove collar screws from handle frame  
Bottom:  
Pull fuel hose off elbow connector






Take off the handle frame.

Remove the socket head screw(s) securing the muffler cover. Separate the muffler cover from the casing by tapping lightly with a plastic-faced hammer.

Unscrew the muffler casing at the cylinder exhaust port. The socket head screw on the crankcase is located directly above the front collar screw.



Top:  
Unscrew muffler cover  
Center:  
Split muffler cover and casing  
Bottom:  
Unscrew muffler casing



### 3.3.1 Exposing the Cylinder (Heated Handles)

See Chapter 3.3

Top:  
Remove handle cover retaining screw  
Bottom:  
Unscrew ground wire




#### Difference

Unscrew the handle cover retaining screw and remove the handle cover and lever (safety throttle lock).

Disconnect the ground wire at the terminal strip.

Remove the nut on the stop switch.

Unscrew nut on stop switch



Take off the handle frame and handlebar. Handlebar is still connected to leads of electric handle heating.



### 3.4 Visual Inspection

Thoroughly clean dirt off the cylinder fins, especially in the cooling air intake area (fan housing).

Examine cylinder for broken cooling fins.

### 3.5 Exposing the Cylinder 031 (030)


Top:  
Remove slotted nuts from air filter  
Bottom:  
Remove retaining washer and disconnect throttle rod




Disassemble the sprocket cover and cutting attachment. Take off the carburetor box cover.

Remove both slotted nuts from the air filter; pull off the air filter, press off the retaining washer and disconnect the throttle rod.





Top:  
Unscrew handlebar  
Bottom:  
Remove collar screws from vibration dampers



Top:  
Remove pan head screws from carburetor box cover  
Bottom:  
Unscrew carburetor mounting nuts



Top:  
Take off carburetor and hold impulse hose securely  
Center:  
Take sleeve out of muffler  
Bottom:  
Take off carburetor box cover and pull out impulse hose




Unscrew the handlebar at the handle frame and crankcase and remove. Take out the two collar screws in the handle frame (rear vibration dampers) and one collar screw at the front annular buffer. Unscrew handle frame at carburetor box cover (three pan head screws); lift off the handle frame.


Unscrew the two carburetor mounting nuts from the studs. Pull carburetor off the studs while holding the impulse hose firmly in position with a pair of pliers.

Pull off the fuel hose.


Take the sleeve out of the manifold. Push the manifold into the space between the cylinder and carburetor box. Take off the carburetor box and pull the impulse hose off the connector on the crankcase at the same time.





Top:  
Pull short circuit lead out of stop switch  
Bottom:  
Remove pan head screws from fan housing



Top:  
Unscrew pan head screw at sprocket side  
Bottom:  
Unscrew muffler from cylinder




Unscrew muffler from crankcase



Pull off short circuit lead at the stop switch. Disassemble the fan housing and tank housing. To do this, unscrew 3 pan head screws at the fan housing side and 1 pan head screw at the sprocket side.

Unscrew the muffler at the cylinder exhaust port and crankcase. The pan head screw on the crankcase is located directly above the front collar screw.



Take off the muffler with air guide plate.

### 3.5.1 Exposing the Cylinder - 031 (030) Heated Handles

See Chapter 3.5

#### Difference



The flexible heating tube is located about 40 mm down inside the handlebar. Take care when removing the handlebar that the heating tube is not torn away.

The clamp at the transition point between the valve and muffler must be unscrewed and the valve pushed off the muffler connection before the handle frame is removed.

## 3.6 Cylinder and Piston

### 3.6.1 Removal

Top:  
Unscrewing the cylinder  
Bottom:  
Release clamp on manifold





Preparations – see 3.3 or 3.3.1.

Detach the spark plug terminal and unscrew the spark plug. Remove the four socket head screws which secure the cylinder. Pull the cylinder off the piston. Release the clamp on the manifold sufficiently for the clamp to be removed over the manifold. Take manifold off cylinder intake port.

Before removing the piston it must be decided whether or not the



Top:  
Wooden assembly block  
1108 893 4800  
Bottom:  
Lock crankshaft with wooden assembly block



crankshaft is to be removed as well. This is important because the wooden block has to be fitted between the crankcase and piston in order to lock the crankshaft for removal of the flywheel and clutch.

Take out the wire retainers. Use the drift to push out the piston pin out of the piston and needle cage. If the piston pin is stuck as a result of carbonization of the piston boss, tap it out lightly with a hammer. It is essential to counterhold the piston

Top:  
Removing wire retainers  
Bottom:  
Pushing out piston pin with drift  
1110 893 4700



to ensure that no jolts are transmitted to the connecting rod.

#### 3.6.1.1 Removal, Heated Handles

See Chapter 3.6.1 and preparations in chapter 3.3.1.

**3.6.2 Removal on 031 (030)**  
See Chapter 3.6.1 and preparations in chapter 3.5.

### 3.6.4 Installation

**3.6.2.1 Removal on 031 (030) with Heated Handles**  
See Chapter 3.6.1 and preparations in chapter 3.5.1.


If the cylinder has to be replaced, the new cylinder must always be installed with a matching piston. Replacement cylinders are only supplied complete with matching pistons.

If only the piston is to be renewed on the 032 it is possible to use any replacement piston (marked "B") with any cylinder.

Pistons and cylinders of model 031 AV (030 AV) were previously available in 5 size groups with the letter codes A to E and subdivided into the 3 main groups A-B, C-D and E. The size group code is stamped on the piston crown and cylinder head.

For reasons of rationalization these groups were reduced to cylinders A, B and C with piston B and cylinders D and E with piston C. The pistons B and C can be installed in all cylinders of their respective groups.

Arrow and "A" point towards exhaust port



Coat the needle cage with oil and insert it in the piston boss. Place new cylinder gasket on the crankcase - cutouts face intake port. Position piston on connecting rod so that the arrow and "A" stamped on the piston crown point towards the cylinder exhaust port.

### 3.6.3 Visual Inspection


Examine the piston. Piston rings must move freely and not stick in their grooves. If the edges of the piston rings are worn round, fit new rings. Inspect small end needle cage. Make sure that manifold is in good condition.

Check cylinder bore. In the case of excessive wear and deep scores, fit a new cylinder.

**Table - 031 (030)**

Previous version for new cylinders		Previous version for broken-in cylinders		Simplified system	
Piston	for cylinder	Piston	for cylinder	Piston	for cylinder
A	AB	A	AB	-	-
B (AB)	BC	B	ABC	B	ABC
C (CD)	CD	C	BCD	C	DE
D (E)	DE	D	CDE	-	-
E	E	E	DE	-	-

Fit piston pin  
on assembly drift





Fit the piston pin in the piston and connecting rod. To do this, push assembly drift through the piston bore and the connecting rod to align both bores concentrically. Fit piston pin on the spigot of the assembly drift and slide it into the piston. Gently move the piston to and fro to easy insertion of the piston pin.

Light thumb pressure is all that should be required to install the piston pin. Do not use any force during assembly. Fit the two wire retainers and make sure they are properly seated in their grooves.

In the case of a new cylinder or if the manifold is faulty, it is necessary to fit the manifold before mounting the cylinder.

Push the manifold on to the intake port; it must point upwards (towards cylinder head) and the molding seam should be vertical (parallel with the cylinder axis).

Top:  
Wire retainer fitted  
Bottom:  
Manifold correctly positioned on  
intake port





Attach and secure the hose clamp.

Make sure that manifold is correctly seated and properly sealed. Coat piston and its rings with engine oil (do not use old oil for this purpose).

Place the wooden assembly block on the crankcase so that the piston is resting on it. Turn the piston rings in their grooves so that the radii at the ring gaps locate (when the


Top:  
Clamp in position  
Bottom:  
Piston rings correctly  
positioned




rings are compressed) against the fixing pins in the grooves.

Insert four M5x18 socket head screws (with captive washers) in the cylinder mounting holes. Use the clamping strap to encircle and compress the piston rings around the piston, but ensure they do not move out of position in the process.




Top:  
4 socket head screws in position  
Bottom:  
Clamping strap  
0000 893 2600



Top:  
Compress piston rings  
Bottom:  
Fitting the cylinder



Tightening cylinder base screws



Fit the cylinder over the piston with the exhaust port facing in the direction of the bar nose. The cylinder must be exactly aligned in its normal installed position. If this is not done there is a risk of the piston rings breaking!

Assembly is then a reversal of the sequence in chapter 3.3.

**Note:** The M 5 x 16 screws used on early machines (before machine No. 5 090 200) should be replaced by M 5 x 18 screws.

Take off the clamping strap and the wooden assembly block. Line up the gasket and cylinder. Screw down the cylinder base screws in turn to a torque load of 8 Nm.