


Product: Bobcat 1600 Skid Steer Loader Service Repair Workshop Manual
Full Download: <https://www.aresairmanual.com/downloads/bobcat-1600-skid-steer-loader-service-repair-workshop-manual/>



1600

SERVICE MANUAL



MELBOE
INGERSOLL-RAND
Sample Manual. Download All 280 pages at:
<https://www.aresairmanual.com/downloads/bobcat-1600-skid-steer-loader-service-repair-workshop-manual/>



Product: Bobcat 1600 Skid Steer Loader Service Repair Workshop Manual
Full Download: <https://www.arepairmanual.com/downloads/bobcat-1600-skid-steer-loader-service-repair-workshop-manual/>

Sample of manual. Download All 280 pages at:
<https://www.arepairmanual.com/downloads/bobcat-1600-skid-steer-loader-service-repair-workshop-manual/>

MAINTENANCE SAFETY




WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903




Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.




⚠ Never service the Bobcat Loader without instructions. See Service Manual.

⚠ Check engine and hydraulic fluids daily.


⚠ Use recommended fluids.




⚠ Cleaning and maintenance are required daily.



⚠ Disconnecting or loosening any hydraulic tubeline, hose, fitting, component or a part failure can cause lift arms to drop. Do not go under lift arms when raised unless supported by an approved lift arm support device. Replace it if damaged.



⚠ Always connect steering frame lock before working on the loader.




⚠ Do not fill the fuel tank with engine running, while smoking or when near an open flame.



⚠ Never work on loader with lift arms up unless lift arms are held by an approved lift arm support device.


⚠ Never modify equipment or add attachments not approved by Bobcat Company.



⚠ Stop, cool and clean engine of flammable materials before checking fluids.

⚠ Never service or adjust loader with the engine running unless instructed to do so in the manual.

⚠ Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate the skin or eyes.



⚠ Keep body, jewelry and clothing away from moving parts, electrical contact, hot parts and exhaust.

⚠ Wear eye protection to guard from battery acid, compressed springs, fluids under pressure and flying debris when engines are running or tools are used. Use eye protection approved for type of welding.

⚠ Keep rear door closed except for service. Close and latch door before operating the loader.



⚠ Lead-acid batteries produce flammable and explosive gases.

⚠ Keep arcs, sparks, flames and lighted tobacco away from batteries.

⚠ Batteries contain acid which burns eyes or skin on contact. Wear protective clothing. If acid contacts body, flush well with water. For eye contact flush well and get immediate medical attention.

Maintenance procedures which are given in the Operation & Maintenance Manual can be performed by the owner/operator without any specific technical training. Maintenance procedures which are **not** in the Operation & Maintenance Manual must be performed **ONLY BY QUALIFIED BOBCAT SERVICE PERSONNEL**. Always use genuine Bobcat replacement parts. The Service Safety Training Course is available from your Bobcat dealer.

MSW04-0805



Bobcat®

CONTENTS

SAFETY INSTRUCTIONS.....	i
SERIAL NUMBER LOCATIONS.....	ii
DELIVERY REPORT.....	ii
BOBCAT ARTICULATED LOADER IDENTIFICATION.....	iii
PREVENTIVE MAINTENANCE.....	1-1
HYDRAULIC SYSTEM.....	2-1
HYDROSTATIC SYSTEM.....	3-1
DRIVE SYSTEM.....	4-1
MAIN FRAME.....	5-1
ELECTRICAL SYSTEM.....	6-1
ENGINE SERVICE.....	7-1
TECHNICAL DATA.....	8-1

PREVENTIVE
MAINTENANCE

HYDRAULIC
SYSTEM

HYDROSTATIC
SYSTEM

DRIVE
SYSTEM

MAIN
FRAME

ELECTRICAL
SYSTEM

ENGINE
SERVICE

TECHNICAL
DATA




bobcat

FOREWORD

This manual is for the Bobcat loader mechanic. It provides necessary servicing and adjustment procedures for the Bobcat loader and its component parts and systems. Refer to the Operation & Maintenance Manual for operating instructions, starting procedure, daily checks, etc.

A general inspection of the following items must be made after the loader has had service or repair:


1. Check that the ROPS/FOPS is in good condition and is not modified.




2. Check that ROPS mounting hardware is tightened and is Melroe approved.



3. The seat belt must be correctly installed, functional and in good condition.




4. The operator restraint arm must function correctly.



5. Machine signs must be legible and in the correct location.




6. Foot pedal must return to neutral.




7. Check for correct function of the work lights.




8. The parking brake must function correctly.




9. Enclosure door latches must open and close freely.




10. Bob-Tach wedges and linkages must function correctly and be in good condition.




11. Safety treads must be in good condition.




12. Check for correct function of indicator lamps.



13. Check hydraulic fluid level, engine oil level and fuel supply.




14. Inspect for fuel, oil or hydraulic fluid leaks.




15. Lubricate the loader.




16. Check the condition of the battery and cables.




17. Inspect the air cleaner for damage or leaks. Check the condition of the element.




18. Check the electrical charging system.



19. Check tires for wear and pressure.



20. Inspect for loose or broken parts or connections.



Recommend to the owner that all necessary corrections be made before the machine is returned to service.



SAFETY INSTRUCTIONS

WARNING

Instructions are necessary before operating or servicing machine. Read Operation & Maintenance Manual, Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Failure to follow instructions can cause injury or death.

W-2003-1289

The following publications provide information on the safe use of the loader and attachments:

1. The Delivery Report is used to assure that complete instructions have been given to the new owner and that the machine is in safe operating condition.
2. The Operation & Maintenance Manual delivered with the loader gives operating information as well as routine maintenance and service procedures. It is a part of the loader and must stay with the machine when it is sold.
3. The loader has machine signs (decals) which instruct on the safe care and operation. The signs and their locations are shown in the Operation & Maintenance Manual. Replacement signs are available from Bobcat loader dealers.
4. The FIEI Manual delivered with the loader gives general safety information.
5. The Service Manual and Parts Manual are available from Bobcat loader dealers for use by mechanics to do shop-type service and repair work.



Safety Alert Symbol: This Safety Symbol is used for important safety messages. When you see this symbol follow the safety message to avoid personal injury or death.

- Wear tight fitting clothing and any other required safety apparel when operating or servicing the loader.
- Wear safety glasses when maintaining or servicing the loader.
- Exhaust gases can kill, vent engine exhaust outdoors.
- Know where fire extinguishers and first aid kits are located and how to use them.
- Do not run the Bobcat loader where exhaust, arcs, sparks or hot components can contact flammable material, explosive dust or gases.
- Check fuel and hydraulic tubes, hoses and fittings for damage and leakage. Never use open flame or bare skin to check for leaks. Tighten or replace any parts that show leakage. Always clean fluid spills. Do not use gasoline or diesel fuel for cleaning parts. Use commercial nonflammable solvents.
- Clean the loader before doing any welding. Cover rubber hoses, battery and all other flammable parts. Keep a fire extinguisher near the loader when welding.
- Have good ventilation when welding or grinding painted parts. Wear a dust mask when grinding painted parts. Toxic dust and gas can be produced.
- Stop the engine and let it cool before adding fuel. No smoking!
- Use the procedure in this manual for connecting battery.
- Use the procedure in this manual for cleaning the spark arrestor muffler after each 100 hours of operation.

SERIAL NUMBER LOCATIONS

Always use the serial number of the loader when requesting service information or when ordering parts. Early or later models (identification made by serial number) may use different parts, or it may be necessary to use a different procedure in doing a specific service operation.

LOADER SERIAL NUMBER

The loader serial number plate is located on the inside of the left upright, above the grill [A].

Explanation of loader Serial Number:

XXXX XXXXX



Module 2. – Production Sequence (Series)

Module 1. – Model/Engine Combination

1. The four digit Model/Engine Combination Module number identifies the model number and engine combination. This number (in parenthesis beside the model number) is used in the Operation & Maintenance Manual to more easily identify the standard, optional and field accessory equipment included or available for each specific model.
2. The five digit Production Sequence Number identifies the order which the loader is produced.

ENGINE SERIAL NUMBER

The serial number is above the starter on the engine block [B].




DELIVERY REPORT

The Delivery Report must be filled out by the dealer and signed by the owner or operator when the Bobcat loader is delivered. An explanation of the form must be given to the owner. Make sure it is filled out completely [C].

Diagram D shows a form titled 'DELIVERY REPORT'. The form is divided into several sections. The top right section is titled 'DELIVERY REPORT' and contains several lines of text. The bottom left section is titled 'WARNING' and contains several lines of text. The form is labeled 'D' in the top left corner.

BOBCAT LOADER IDENTIFICATION



B-11466
B-6637

- * BUCKET — Several different buckets and other attachments are available for the Bobcat loader.
- ** TIRES — Tires shown are optional flotation tires which are not standard for this loader.
- *** ROPS — Roll Over Protective Structure.



bobcat

PREVENTIVE MAINTENANCE

PREVENTIVE MAINTENANCE

	Page Number
FRAME LOCK	
Procedure	1-3
LIFT ARM SUPPORT DEVICE	
Procedure	1-3
LIFTING AND BLOCK THE LOADER	
Procedure	1-2
OPERATOR RESTRAINT SYSTEM	
Description	1-5
Inspection of the Operator Restraint System	1-5
Servicing the Operator Restraint System	1-5
SERVICE SCHEDULE	
Chart	1-1
TRANSPORTING THE LOADER	
Procedure	1-4
USING AN EXTRA BATTERY (JUMP STARTING)	
Procedure	1-6



bobcat

SERVICE SCHEDULE

You must do maintenance work at regular intervals. Failure to do so will result in damage to the loader or the engine. The service schedule is a guide for correct maintenance of the Bobcat loader. Follow this service schedule as explained below unless it is to increase the frequency of intervals when the Bobcat is used in very hot, cold, dusty or corrosion conditions.



WARNING

Instructions are necessary before operating or servicing machine. Read Operator's Manual, Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Failure to follow instructions can cause injury or death.

W-2003-1285

SERVICE SCHEDULE		HOURS				
ITEM	SERVICE REQUIRED	8-10	50	100	250	1000
Engine Oil	Check the oil & add as needed.	■				
Air Cleaner Indicator	Replace the outer element when the red ring shows in the condition indicator window.	■				
Tires	Check tires for damage & correct pressure.	■				
Seat Belt & Restraint Arms	Check the condition of the seat belt & restraint arms for correct operation.	■				
Safety Signs (Decals)	Check for damaged decals. Replace any decals that are damaged or missing.	■				
Loader Pivot Points	Add lubricant to all fittings (See Operator's Manual).	■				
Hydraulic Fluid Reservoir	Check the fluid level & add fluid as needed.	■				
Engine Coolant System	Check level & add as needed. Remove any debris from the grill area.	■				
Wheel Nuts	* Tighten wheel nuts to 115 ft.lbs. (155 Nm) torque.		■			
Fuel Filter	Remove any trapped water.		■			
Battery & Cables	Check the battery water level & add as needed. Clean cable ends & cover with grease.		■			
Hyd. Control Levers	Check the levers for correct operation. Make repairs & adjust as needed.		■			
Bob-Tach	Check the locking levers & wedges for condition & correct operation.		■			
Brake	Check the brake for correct operation.		■			
Alternator Belt	Check condition & tension of belt.		■			
Engine Oil & Filter	Replace oil & filter.		■			
Spark Arrestor Muffler	Empty spark chamber.			■		
U-Joints (Drive Shaft)	Lubricate with the correct grease (See Operator's Manual).			■		
Hydraulic Filter	Replace the filter element.				■	
Fuel Filter	Replace the fuel filter element.				■	
Front & Rear Axle	Check oil level & add as needed.				■	
U-Joint (Eng. to Hydro. Pump)	Lubricate with the correct grease (See Operator's Manual).				■	
Hyd./Hydro. System	Replace the fluid & filter. Replace vent filter.					■


* Check the wheel nuts torque every 8 hours for the first 24 hours of operation.

PREVENTIVE MAINTENANCE

! WARNING

Instructions are necessary before operating or servicing machine. Read Operator's Manual, Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Failure to follow instructions can cause injury or death.

W-2003-1285



LIFTING AND BLOCKING THE BOBCAT LOADER

Procedure

Always park the loader on a level surface.

! WARNING


Put jackstands under the front axles and rear corners of the frame before running the engine for service. Failure to use jackstands can allow the machine to fall or move and cause injury or death.

W-2017-0286


Put the floor jack under the rear of the loader **B**.

Lift the rear of the loader and install the heavy duty jackstands **B**.

Put the floor jack under the front axle differential housing **C**.



Lift the front of the loader and put the heavy duty jackstands under the axle housing **C**.



NOTE: Make sure the jackstands do not touch the tires.

LIFT ARM SUPPORT DEVICE

Procedure



WARNING

Never work on a machine with the lift arms up unless the lift arms are secured by a lift arm support device. Failure to use an approved lift arm support device can allow the lift arms or attachment to fall.

W-2059-0991

NOTE: Lift arm support device is available from your Bobcat dealer.

One person must stay in the operator's seat, with the seat belt fastened and operator restraint system lowered, while the other person installs the lift arm support device.

Start the engine and raise the lift arms all the way up.

Have a second person install the lift arm support device over the rod of the lift cylinder **A**.




Lower the lift arms slowly until the support device is held between the lift arms and lift cylinder.

FRAME LOCK

Procedure

Before any service work is done on the Bobcat loader, always install the frame lock **B**.

Never allow anyone in or near the pivot area unless the frame lock is installed **C**.



TRANSPORTING THE BOBCAT LOADER

Procedure



WARNING


Steel loading ramps are needed to support the weight of the machine when loading onto a transport vehicle. Wood ramps may break and cause personal injury.

W-2058-0887


A loader with an empty bucket or no attachment must be loaded backwards onto the transport vehicle **A**.

Use the following procedure to fasten the Bobcat loader to the transport vehicle:


1. Lower the bucket or attachment to the floor. Stop the engine.
2. Install the steering frame lock (See Page 1–3).
3. Install chains to hold the loader in position during sudden stops or when going up or down slopes.
4. Put a chain through the tube on the lift arms **B**. Fasten the chain to both sides of the transport vehicle.
5. Fasten a chain to each frame mount under the rear of the loader and to the transport vehicle **C**.
6. Use chain binders to tighten all the chains.



B-11471



B-6849



B-6850

OPERATOR RESTRAINT SYSTEM

Description

The operator restraint system consists of pivoting restraint arms. The system is provided to give additional restraint to keep an operator within the safety zone of the operator cab **A**.

The restraint arms are connected to the foot pedal interlock which will not allow the machine to be driven when the restraint arms are in the up position. Only when the operator is in the seat with seat belt buckled and with the restraint arms lowered can the loader be driven.



Inspection of the Operator Restraint System

To check the correct function do the following:

1. Sit in the operator seat and fasten the seat belt snugly.
2. Pull the restraint arms down and start the engine.


NOTE: The centering mechanism must be in neutral position before the starter will engage.

3. The loader may be driven forward or backward by toeing or heeling the foot pedal (the back-up alarm must sound when the loader is moved in the reverse direction).
4. With the engine running and loader not moving, raise the restraint arms. Try to operate the foot pedal in both directions. The loader must not move.
5. Stop the engine. Unfasten the seat belt.



Servicing the Operator Restraint System

1. Clean any debris or dirt from moving parts **B**.
2. Inspect the arms, linkage and interlock for correct operation. Make sure all bolts are tight.
3. If the restraint system does not function correctly when inspected, correct or adjust before operating the loader.



USING AN EXTRA BATTERY (JUMP STARTING)

Procedure


If it is necessary to use an extra battery to start the engine, use the following procedure:

This is a two person operation. There must be one person in the operator's seat and one person to connect and disconnect the battery cables.

1. The key switch must be in the "OFF" position.
2. The extra battery must be of the same voltage as the loader battery.
3. Connect the end of the first cable to the positive (+) terminal (Item 1) of the extra battery. Connect the other end of the same cable to the positive (+) terminal (Item 2) of the loader battery **A**.
4. Connect the end of the second cable to the negative (-) terminal (Item 3) of the extra battery. Connect the other end of the same cable to the frame (Item 4) **A**.

NOTE: Do not connect directly to the negative (-) terminal of the loader battery because it can cause a spark and may cause the battery to explode.

5. Keep the cables away from moving parts.
6. Start the engine (See the Operator's Manual "Cold Starting
7. After the engine is running. Remove the cable connected to the frame first.
8. Then remove the cable connected to the loader battery.



B-11473



WARNING

Keep arcs, sparks, flames and lighted tobacco away from batteries. When "jumping" from an extra battery make final connection (negative) at engine frame.

Do not jump start or charge a frozen battery. Warm battery to 60° F. (16° C.) before connecting to a charger. Unplug charger before connecting or disconnecting cables at battery. Battery gas can explode and cause serious injury.

W-2066-1285

IMPORTANT

Damage to the alternator can occur if:

- Engine is operated with battery cables disconnected.
- Battery cables are connected when using a fast charger or when welding on the loader (Remove both cables from the battery).
- Extra battery cables (booster cables) are connected wrong.

I-2023-1285



WARNING

Batteries contain acid which burns eyes and skin on contact. Wear goggles, protective clothing and rubber gloves to keep acid off body.

In case of acid contact, wash immediately with water for several minutes and get medical attention in case of eye contact.

W-2065-1286

HYDRAULIC SYSTEM

	Section Number
HYDRAULIC SYSTEM (S/N 12001 & ABOVE)	2A
HYDRAULIC SYSTEM (S/N 11999 & BELOW)	2B

**HYDRAULIC
SYSTEM**

**2A HYDRAULIC
SYSTEM**

**2B HYDRAULIC
SYSTEM**



bobcat




HYDRAULIC / HYDROSTATIC FLOW CHART

For Model

1600 (S/N 11001 THRU 11999)

Chart # 6566839 (Printed February 1986)

- RED - - - - - High Pressure
- BLUE - - - - - Low Pressure
- GREEN - - - - - Case Drain & Reservoir
- ORANGE - - - - - Charge Pressure
- LT. ORANGE - Hydraulic Pump Charge



* Pump Inlet

E-1545

NOTE
Chart shows oil flow in Forward Drive Position and with Hydraulic Cylinders Partially Extended. For Hydraulic/Hydrostatic System Operation, refer to Sheet 2 of this publication.



HYDRAULIC / HYDROSTATIC SYSTEM OPERATION

To Be Used With
HYDRAULIC / HYDROSTATIC FLOW CHART

For Model
1600 (S/N 11001 THRU 11999)

Chart # 6566839 (Printed February 1986)

CHART LEGEND

- | | |
|--|--|
| 1 RESERVOIR, Capacity: (Steel) 12 qts.
(11,4 L.) System Capacity:
(Nylon) 16 qts. (15,1 L) | 24 ORIFICE 0.179" (4,55 mm) Dia. |
| 2 BRAKE VALVE | 25 CHARGE PRESS. RELIEF, 130 PSI
(896 kPa) |
| 3 PRIORITY VALVE | 26 PORT BLOCK |
| 4 STEERING RELIEF VALVE, . 1800 PSI
(12411 kPa) | 27 COLD WEATHER BY-PASS . . 120 PSI
(827 kPa) |
| 5 PRIORITY VALVE SHUTTLE | 28 HYDRAULIC PUMP (Vane) . . 14 GPM
(53 L/min.) @ 2800 RPM |
| 6 STEERING CONTROL VALVE | 29 SERVO RELIEF VALVE . 250-260 PSI
(1723-1793 kPa) |
| 7 STEERING CYLINDER | 30 SERVO |
| 8 LIFT CYLINDER | 31 ORIFICE (Bleed Hole) |
| 9 BUCKET POSITION VALVE | 32 ORIFICE 0.07" (1,78 mm) Dia. |
| 10 TILT CYLINDER | 33 CHARGE RELIEF VALVE 75 PSI
(517 kPa) @ 36 RPM (11,2 L) |
| 11 AUXILIARY LINES (OPT.) | 34 MANIFOLD BLOCK |
| 12 PORT RELIEF, Tilt Cylinder 3500 PSI
(24132 kPa) | 35 SHUTTLE VALVE |
| 13 PORT RELIEF, Lift Cylinder 3500 PSI
(24132 kPa) | 36 BRAKE . . . Release Pressure 190 PSI
(1310 kPa) |
| 14 MAIN RELIEF VALVE, 2200-2400 PSI
(15169-16548 kPa) (Measured at Aux.
Couplers) | 37 HIGH PRESS. RELIEF VALVES
5000 PSI (34475 kPa) |
| 15 RESTRICTOR, . 0.189" (4,8 mm) Dia. | 38 TOW VALVE |
| 16 HYDRAULIC CONTROL VALVE | 39 HYDROSTATIC MOTOR |
| 17 LOAD CHECK VALVES (3) | 40 REPLENISHING VALVES 10 PSI (69 kPa) |
| 18 PORT RELIEF, Lift Cylinder 1500 PSI
(10343 kPa) | 41 OIL COOLER |
| 19 PORT RELIEF, Tilt Cylinder 1500 PSI
(10343 kPa) | 42 CHARGE RELIEF VALVE,
(Non-Functional) |
| 20 PLUG | 43 HYDROSTATIC PUMPS |
| 21 RESTRICTOR, 0.156" (3,96 mm) Dia. | 44 OIL COOLER |
| 22 ^a DIAGNOSTIC CHECK POINT (Servo) | 45 TEMPERATURE SWITCH 225-232°F.
(105-111°C.) |
| 22 ^b DIAGNOSTIC CHECK POINT (Charge) | 46 FILTER |
| 22 ^c DIAGNOSTIC CHECK POINT (Pump) | 47 FILTER BY-PASS . . . 25 PSI (172 kPa) |
| 23 FILTER Bronze, 25 Micron | 48 SWITCH, Differential, 19 PSI (131 kPa) |

OIL FLOW EXPLANATION

The fluid flows from the reservoir ① to the port block ②⑥ . The return fluid from the oil cooler ④④ , priority valve ③ and cold weather by-pass valve ②⑦ also joins the reservoir fluid and goes to the hydraulic pump ②⑧ . "Case drain" fluid from the hydrostatic motor ③⑨ and hydrostatic pump ④③ flows back to the reservoir ① .

The hydraulic pump ②⑧ is driven by a shaft through the hydrostatic pumps ④③ . The fluid flows from one part of the flow divider in the hydraulic pump ②⑧ through the bronze filter ②③ against the servo relief valve ②⑨ , to the brake valve ② and the servo control ③⑩ . Fluid pressure in the valve ② disengages the brake ③⑥ . The brake ③⑥ is locked when the pedal is engaged or when the engine is stopped (no fluid pressure).

The steering control valve ⑥ controls the steering cylinder ⑦ . When the steering control valve ⑥ is activated, the fluid goes to either the base or rod end of the steering cylinder ⑦ . The return fluid from the opposite end of the steering cylinder goes to the steering control valve ⑥ . A steering relief valve ④ is located in the priority valve ③ . The priority valve ③ sends only as much fluid as is necessary to operate the steering control valve ⑥ , then when there is enough fluid flow to operate the steering control valve ⑥ the priority valve ③ sends the excess fluid flow to the hydraulic control valve ①⑥ . If the steering circuit is not used all of the flow is directed to the hydraulic control valve.

The hydraulic control valve ①⑥ is a 3-spool, open center, closed port tandem type valve with an adjustable main relief valve ①④ . When all three spools are in the neutral position, the fluid flows through the control valve ①⑥ and joins the return fluid from the steering control valve ⑥ . This fluid then goes through the #3 element filter ④⑥ , against the charge relief ②⑤ and through the orifice ②④ . Part of the fluid goes over the charge relief ②⑤ ; the extra fluid goes through the oil cooler ④④ and to the port block ②⑥ . The fluid which is not regulated by the charge relief ②⑤ goes through the orifice ②④ and then flows through the oil cooler ④① and to the hydrostatic pumps ④③ for "charge pressure fluid".

If one of the spools is activated in the control valve ①⑥ , the fluid goes out the respective port to either the base end or rod end of the cylinders ⑧ ⑩ or to the bucket position valve ⑨ , return fluid comes from the cylinders ⑧ ⑩ or the bucket position valve ⑨ back to the control valve ①⑥ .

When the cylinders ⑧ ⑩ reach the end of the stroke, the fluid flow stops and causes the hydraulic pressure to increase. When the pressure reaches the setting of the main relief valve ①④ , it will open and let the fluid by-pass the hydraulic circuit (internally) and go through the #3 element filter ④⑥ , oil cooler ④① and back to the hydrostatic pumps ④③ .

When the spool is in neutral position, there is fluid available for the other sections of the control valve 16 . Two sections of the control valve 16 can be used at the same time if the main relief valve 14 is not open.

Fluid from the steering control valve 6 and the hydraulic control valve 16 which goes through the #3 element filter 46 normally goes through the oil cooler 41 and to the hydrostatic pumps 43 , but as the pressure increases the charge relief valve 25 will open and put the excess fluid thru the cooler circuit.

The #3 element filter 46 is located in the engine compartment. There is a filter bypass 47 and a pressure differential switch 48 located on the filter housing.

The hydrostatic system has a engine driven, variable displacement tandem pumps 43 which provides fluid flow to a fixed displacement motor 39 .

Engine RPM is adjustable by a throttle control and is constant. Loader speed and direction of travel is controlled by adjusting the amount and direction of fluid flow from the hydrostatic pumps 43 to the hydrostatic motor 39 . The fluid called "charge pressure fluid" in the center section of the hydrostatic pumps 43 is against four replenishing valves 40 . The replenishing valves 40 on the low (charge pressure) side of the pump will open and let fluid into the pumps for replenishing, lubrication and cooling. The hydrostatic pumps 43 do not need the full volume of fluid flow, so there is extra fluid. This extra fluid goes to the charge relief valve 25 . When the pressure reaches the setting of the charge relief valve 25 , the valve will open and let the extra fluid go to the oil cooler 24 and to the hydraulic pump 28 .

A foot pedal controls the speed and the direction of the loader's travel. Speed is controlled by adjusting the amount of fluid that goes to the hydrostatic motor 39 . The direction is controlled by changing the direction of fluid flow to the hydrostatic motor 39 . The foot pedal is mechanically connected to a servo control cylinder 30 which controls the amount and the direction of fluid flow from the hydrostatic pumps 43 by adjusting the angle of the swashplates in the pumps 43 . There is a servo relief valve 29 in the port block 26 , to control the pressure from the hydraulic pump 28 to the servo control 30 .

The two hydrostatic pumps 43 are activated in forward direction together as one unit. In reverse, only one pump is used. When the foot pedal is in neutral position, the pumps 43 and motor 39 are not working, but do have charge pressure.

When the swashplates are angled and the fluid is forced out of the pressure side of the hydrostatic pumps 43 . This fluid is called "drive pressure fluid". Drive pressure fluid is much higher than charge pressure fluid which causes the replenishing valves 40 to close allowing

the flow of fluid to go to the hydrostatic motor 39 . The manifold block 34 on the hydrostatic motor 39 contains a stroked charge relief valve 33 which allows extra flow of fluid for cooling in forward and reverse direction. There is also a shuttle valve 35 which moves, depending on the travel direction of the loader, and allows fluid to the stroked charge relief valve 33 which allows fluid to return to the reservoir 1 .

When the loader is driven into a pile of dirt with the bucket down there is resistance causing high drive pressure in the drive loop. There are two high pressure drive relief valves 37 in the manifold block 34 . These relief valves 37 relieve the high pressure in the drive loop to protect the hydrostatic system.

There is tow valve 38 located in the manifold block 34 . When the loader is unable to move with its own drive system, the tow valve 38 may be turned to push the high pressure relief valves 37 off their seats so the loader can be moved for a short distance at a low speed. If the engine is not running, the brake is engaged (locked) and the loader can not be moved.

BUCKET POSITIONING VALVE

When the lift arms are raised, the return oil from the rod end of the lift cylinders 8 goes to the flow divider in the bucket positioning valve 9 . The flow divider allows only a metered amount of oil to go to the base end of the cylinder 10 . The remaining oil goes to the control valve 15 (rod end port of the lift cylinder 8).

Before the oil will enter the base end of the tilt cylinder 10 , the pressure will increase until it opens an unloading valve (in the bucket positioning valve 9) which allows oil to flow from the rod end of the tilt cylinder 10 . This oil returns to the control valve 16 (rod end of the lift cylinder).

If the bucket is tilted all the way out, the tilt cylinder 10 (base end) will not accept any oil and the pressure will increase until it opens the port relief valve 19 and that oil is returned to the hydraulic system.



HYDRAULIC / HYDROSTATIC FLOW CHART


For Model

1600 (With S/N 12001 Thru 12026)

Chart # 6570591 (Printed November 1990)

- RED - - - - - High Pressure
- BLUE - - - - - Low Pressure
- GREEN - - - - - Case Drain & Reservoir
- ORANGE - - - - - Charge Pressure
- LT. ORANGE - Hydraulic Pump Charge

NOTE
Chart shows oil flow in Forward Drive Position and with Hydraulic Cylinders Partially Extended. For Hydraulic/Hydrostatic System Operation, refer to Sheet 2 of this publication.



MC-1008

Product: Bobcat 1600 Skid Steer Loader Service Repair Workshop Manual
Full Download: <https://www.arepairmanual.com/downloads/bobcat-1600-skid-steer-loader-service-repair-workshop-manual/>

Sample of manual. Download All 280 pages at:
<https://www.arepairmanual.com/downloads/bobcat-1600-skid-steer-loader-service-repair-workshop-manual/>