

Product: Bobcat 440B Skid Steer Loader Service Repair Workshop Manual
Full Download: <https://www.arepairmanual.com/downloads/bobcat-440b-skid-steer-loader-service-repair-workshop-manual/>




4

4

0

B

Service Manual



MELROE
INGERSOLL-RAND

Sample of manual. Download All 178 pages at:

<https://www.arepairmanual.com/downloads/bobcat-440b-skid-steer-loader-service-repair-workshop-manual/>

6570160 (1-87)

Printed in U.S.A.


bobcat[®]

© Melroe Company 1987

Product: Bobcat 440B Skid Steer Loader Service Repair Workshop Manual

Full Download: <https://www.arepairmanual.com/downloads/bobcat-440b-skid-steer-loader-service-repair-workshop-manual/>

Sample of manual. Download All 178 pages at:

<https://www.arepairmanual.com/downloads/bobcat-440b-skid-steer-loader-service-repair-workshop-manual/>

MAINTENANCE SAFETY



WARNING


Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903



Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.

CORRECT



B-10731a

CORRECT



B-12365


CORRECT



B-7469

⚠ Never service the Bobcat Skid-Steer Loader without instructions.

WRONG



B-11799

⚠ Have good ventilation when welding or grinding painted parts.
⚠ Wear dust mask when grinding painted parts. Toxic dust and gas can be produced.
⚠ Avoid exhaust fume leaks which can kill without warning. Exhaust system must be tightly sealed.


WRONG



B-15231

⚠ Disconnecting or loosening any hydraulic tubeline, hose, fitting, component or a part failure can cause lift arms to drop. Do not go under lift arms when raised unless supported by an approved lift arm support device. Replace it if damaged.


WRONG



B-15280

⚠ Never work on loader with lift arms up unless lift arms are held by an approved lift arm support device. Replace if damaged.
⚠ Never modify equipment or add attachments not approved by Bobcat Company.


WRONG



B-6590

⚠ Stop, cool and clean engine of flammable materials before checking fluids.
⚠ Never service or adjust loader with the engine running unless instructed to do so in the manual.
⚠ Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate the skin or eyes.
⚠ Never fill fuel tank with engine running, while smoking or when near open flame.

WRONG



B-6580

⚠ Keep body, jewelry and clothing away from moving parts, electrical contact, hot parts and exhaust.
⚠ Wear eye protection to guard from battery acid, compressed springs, fluids under pressure and flying debris when engines are running or tools are used. Use eye protection approved for type of welding.
⚠ Keep rear door closed except for service. Close and latch door before operating the loader.

WRONG



B-6589

⚠ Lead-acid batteries produce flammable and explosive gases.
⚠ Keep arcs, sparks, flames and lighted tobacco away from batteries.
⚠ Batteries contain acid which burns eyes or skin on contact. Wear protective clothing. If acid contacts body, flush well with water. For eye contact flush well and get immediate medical attention.

Maintenance procedures which are given in the Operation & Maintenance Manual can be performed by the owner/operator without any specific technical training. Maintenance procedures which are **not** in the Operation & Maintenance Manual must be performed **ONLY BY QUALIFIED BOBCAT SERVICE PERSONNEL**. Always use genuine Bobcat replacement parts. The Service Safety Training Course is available from your Bobcat dealer.

MSW01-0805



Bobcat®

FOREWORD

This manual gives the owner/operator necessary operating, servicing and adjustment of the Bobcat loader and overhaul instructions of the drive system, loader hydraulic/hydrostatic system and general main frame parts.

Refer to the Operator's Manual for operating instructions (Starting Procedure, Daily Checks, Bucket Operation, etc.)

A general inspection of the following items must be made whenever the loader has had service or repair:

1. Check hydraulic fluid level, engine oil level and fuel supply.
2. Inspect for any sign of fuel, oil or hydraulic fluid leaks.
3. Lubricate the loader.
4. Check the condition of the battery and cables.
5. Inspect air cleaner for damage or leaks. Check element and replace as needed.
6. Check electrical charging system.
7. Check tires for wear and pressure.
8. Inspect Operator Cab, Seat Belt, Seat Bar, Safety Treads, Lights, Horn, Safety Signs (Decals), Brake etc.
9. Inspect for loose or broken parts or connections.
10. Operate the loader and check all functions.
11. Inform the Owner/Operator of any items that need service.

PREVENTIVE MAINTENANCE

HYDRAULIC SYSTEM

HYDROSTATIC SYSTEM

DRIVE SYSTEM

MAIN FRAME

ELECTRICAL SYSTEM

ENGINE SERVICE

TECHNICAL DATA

CONTENTS

SAFETY INSTRUCTIONS	i
FIRE PREVENTION	ii
SERIAL NUMBER LOCATIONS	iii
DELIVERY REPORT	iii
BOBCAT LOADER IDENTIFICATION	iv
PREVENTIVE MAINTENANCE	1
HYDRAULIC SYSTEM	2
HYDROSTATIC SYSTEM	3
DRIVE SYSTEM	4
MAIN FRAME	5
ELECTRICAL SYSTEM	6
ENGINE SERVICE	7
TECHNICAL DATA	8



I. SAFETY INSTRUCTIONS

A. SAFETY IS YOUR RESPONSIBILITY

The Skid Steer loader is a highly maneuverable and compact machine. In operation, it is rugged and useful under a wide variety of conditions. This presents an operator with hazards which are common for off highway, rough terrain applications but are not unique for use of Bobcat loaders. The loader has an internal combustion engine with resultant heat and exhaust. All exhaust gases can kill so the loader must be used with adequate ventilation. The loader must not be used in an area with explosive dusts or gases or so that the engine can contact flammable material. The loader has a spark arrestor muffler which is required for operation in certain areas.

For loader applications, the dealer recommends the capabilities and restrictions of the loader and attachments for each application. The dealer demonstrates the safe operation of the loader according to the manufacturer's instructional materials; which are also available to all operators. The dealer can also identify unsafe modifications or use of unapproved attachments. The attachments and buckets are designed for rated capacity and secure fastening to the loader. For each model loader, the user must check with the dealer, or manufacturer's literature, to identify each bucket or attachment for safe loads of materials of specified densities.

The following publications provide information on the safe use of the loader and attachments:

1. The Delivery Report is used to check whether complete instructions have been given to the new owner.
2. The Operator's Manual delivered with each loader gives operating information as well as routine maintenance and service.
3. Every loader has machine signs (decals) which instruct on the safe care and operation of the loader. The complete signs and their locations are shown in the Operator's Manual. All signs are available from your Bobcat dealer.
4. The loader has a plastic Operator Handbook fastened to the operator cab. It has brief instructions always available to the operator. The handbook is available from your Bobcat dealer.
5. The Service Manual and Parts Book are optional manuals from your Bobcat dealer for use by mechanics to do shop-type service and repair work.


The dealer and owner/operator review the recommended uses of the loader and attachments at the time of delivery of the loader. If change of the use of the loader occurs in the future, the owner/operator must remember to ask the dealer for recommendations on the new use of the loader.

B. BEFORE YOU OPERATE THE BOBCAT LOADER



B-10731

This Service Manual was written to give the service personnel instructions on the safe service of the Bobcat loader. READ AND UNDERSTAND THIS SERVICE MANUAL BEFORE SERVICING YOUR BOBCAT.



C. SAFE OPERATION NEEDS A QUALIFIED OPERATOR

A QUALIFIED OPERATOR* MUST DO THE FOLLOWING:

1. UNDERSTAND THE WRITTEN INSTRUCTIONS, RULES AND REGULATIONS
 - a. The written instructions from the Melroe Co. include the delivery report, loader operator's handbook and manual, attachment manual and machine signs (decals).
 - b. Check the rules and regulations at your location. The rules may include an employer's work safety requirements. Regulations may identify a hazard such as utility supply line.
2. HAVE TRAINING WITH ACTUAL OPERATION
 - a. Operator training must consist of a demonstration and verbal instruction. This training is given by the Bobcat dealer before the loader is delivered.
 - b. The new operator should start in an area without bystanders and use all the controls until he can control the loader at full use under the conditions for his work area.
3. KNOW THE WORK CONDITIONS
 - a. For each material to be handled, the operator must know how to avoid exceeding the rated operating capacity of the loader. For example in handling a certain loose material with a given bucket, he must know whether he can safely take a full or part of a bucket load.
 - b. The operator must know any prohibited uses or work areas for the loader. For example he needs to know about excessive slopes.

* For an operator to be qualified, he must not use drugs or alcoholic drinks which change his alertness or coordination while working. An operator who is taking prescription drugs must get medical advice on whether or not he can safely operate a machine.

II. FIRE PREVENTION

The loader has several components which are at high temperature under normal operating conditions. The primary source of high temperatures in the engine and exhaust system. The electrical system, if damaged or incorrectly maintained, can be a source of arcs or sparks. These conditions make it important to avoid applications where explosive dust or gases can be ignited by arcs, sparks or heat.

Flammable debris (leaves, straw, etc.) must be removed regularly. If flammable debris is allowed to accumulate, it will increase the condition for fire hazard. The loader must be cleaned as often as necessary to avoid this accumulation. This flammable debris in the engine compartment can be a fire hazard when the loader is parked with a hot engine.

The spark arrestor muffler is designed to control the emission of hot particles from the engine and exhaust system, but the muffler and the exhaust gases are still hot. This spark arrestor muffler does not change the need to avoid use of the loader in an atmosphere with explosive dust or gases or where the exhaust can contact flammable material.

1. Do not use the Bobcat loader in applications where explosive dust or gases can be ignited by arcs, sparks, hot components or exhaust gases.
2. The operator cab, engine compartment and engine cooling system must be inspected every day and cleaned if necessary to prevent overheating. Remove all flammable material.
3. Check all electrical wiring and connections for damage. Keep the battery terminals clean and tight. Repair or replace any damaged part.
4. Check for damage and leakage at all the fuel, oil and hydraulic tubes, hoses and fittings. Tighten or replace any that show leakage. Always clean fluid spills.
5. Use ether or starting fluids only when approved by the engine manufacturer. Do not use ether or starting fluids on any engine which has glow plugs. These starting aids can explode and injure bystanders.
6. Always clean the loader before doing any welding. Cover rubber hoses, battery and all other flammable parts. Keep a fire extinguisher near the loader when welding.
7. Stop the engine and let it cool before adding fuel. No smoking.
8. Use the procedure in Operator's Manual for connecting and charging batteries.
9. Use the procedure in Operator's Manual for servicing the spark arrestor muffler every 100 hours of operation.



III. SERIAL NUMBER LOCATIONS

It is important to make the correct reference to the Serial Number of the Bobcat loader and/or engine when repairs are done or when ordering parts. It is possible that the present loaders do not use the same parts as the earlier loaders.

LOADER SERIAL NUMBER

The Bobcat loader serial number plate location is on the inside of the operator cab on the right fender and in the front of the seat **[A]**.


Explanation of loader Serial Number:



B-09067

ENGINE SERIAL NUMBER LOCATION


The engine serial number is located on the engine shrouding on the rear of the engine [B].



B-09074



IV. DELIVERY REPORT

The Delivery Report **[C]** is to be filled out by the dealer and signed by the owner or operator when the Bobcat loader is delivered. An explanation of the form must be given to the owner. Make sure it is filled out completely before you sign it.



Revised Jan 87

V. BOBCAT LOADER IDENTIFICATION



B-09039
B-09040

* TIRES – Flotation (Optional) tires are shown. Bobcats are base-equipped with standard tires.

** BUCKET – Several different buckets and other attachments are available for the Bobcat loader.

*** ROPS, FOPS – Roll-Over Protective Structure, Falling Object Protective Structure.

	Page Number
LIFT ARM STOP Procedure	1-4
LIFT AND BLOCKING THE LOADER Procedure	1-2
OPERATOR CAB Lowering the Operator Cab	1-7
Raising the Operator Cab	1-7
Seat Bar Inspection	1-5
Seat Bar Maintenance	1-6
Seat Bar System	1-5
TRANSPORTING THE LOADER Procedure	1-3
USING AN EXTRA BATTERY (JUMP START) Procedure	1-8



SERVICE SCHEDULE

Maintenance work must be done at regular intervals. Failure to do so will result in damage to the Bobcat loader or the engine. The service is a guide for correct maintenance of the Bobcat loader.

HOURS CONVERSION CHART

An average work day is approximately 8 hours. If you use the loader for the following hours a day, do the service as recommended in the Service Schedule.

Use Loader Hours Per Day	CHECK OR SERVICE AS INDICATED BELOW						
	Service Schedule Hours						
	10 Hrs.	25 Hrs.	50 Hrs.	100 Hrs.	250 Hrs.	500 Hrs.	1000 Hrs.
2-3	4 days	10 days	3 wks.	6 wks.	6 mnths.	10 mnths.	20 mnths.
4-5	3 days	5 days	11 days	4 wks.	3 mnths.	5 mnths.	10 mnths.
6-7	2 days	4 days	8 days	2 wks.	5 wks.	4 mnths.	7 mnths.
8	each day	3 days	6 days	10 days	4 wks.	2 mnths.	5 mnths.

SERVICE SCHEDULE		HOURS							
ITEM	SERVICE REQUIRED	5	8-10	25	50	100	250	500	1000
Engine Oil	Change engine oil (New Engine Only).								
Engine Oil	Check level and add oil as needed.								
Engine Cooling System	Check and clean as needed.								
Tires	Check air pressure and for damage to the tires.								
Seat Belt & Seat Bar	Check the condition of seat belt. Check the seat bar for correct operation to lock both foot pedals.								
Safety Signs (Decals) &	Check for damaged signs (decals) & safety treads.								
Safety Treads	Replace any signs (decals) & safety treads that are damaged.								
All Loader Pivot Points	Add grease to the fittings until the extra grease shows.								
Hydraulic Fluid	Check the fluid level in the reservoir & add fluid as needed.								
Engine Oil	Replace oil.								
Engine Air Cleaner	Clean or replace filter element as needed.								
Battery	Check water level and add as needed. Clean the cables.								
Control Pedals & Steering	Check operation. Make repairs & adjustments as needed.								
Wheel Nuts	Check for loose wheel nuts and tighten to 40-50 ft.- lbs. (54-61 Nm) torque.								
Parking Brake	Check operation. Make adjustments as needed.								
Hydraulic Filter Element	Replace filter element.								
Spark Arrestor Muffler	Clean the spark chamber.								
Steering Levers	Lubricate the grease fittings and the oil hole in the steering shaft.								
Engine Ignition System	Replace the spark plugs.								
Engine Air Shrouding	Remove and clean shrouding and cooling fins.								
Engine Fuel Filter	Replace the filter element.								
Hydraulic Reservoir Fill Cap (Breather)	Replace the breather cap.								
Final Drive Transmission (Chaincase)	Replace the fluid.								
Hydraulic/Hydrostatic (Reservoir)	Replace the fluid.								

1 PREVENTIVE MAINTENANCE

! WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0199

A



B-07023

LIFTING AND BLOCKING THE FELLER BUNCHER

Procedure


Always park the loader on a level surface.

! WARNING

Put jackstands under the front axles and rear corners of the frame before running the engine for service. Failure to use jackstands can allow the machine to fall or move and cause injury or death.

W-2017-0286

B



B-09135

Lower the lift arms, stop the engine.

Put the floor jack under the rear of the loader.


Lift the loader and install jackstands [B].

Put the floor jack under the front of the loader.

Lift the front of the loader and install jackstands [C].

NOTE: Make sure the jackstands do not touch the tires.

C



B-09134

TRANSPORTING THE LOADER


Procedure



WARNING

Adequately designed ramps of sufficient strength are needed to support the weight of the machine when loading onto a transport vehicle. Wood ramps can break and cause personal injury.

W-2058-0494





A loader with empty bucket or no attachment must be loaded backwards onto the transport vehicle [A].

After the loader is loaded onto the transport vehicle, lower the lift arms and stop the engine.

Engage the parking brake. Lift the seat bar and move the foot pedals until both pedals are locked.

Install chains (at the front and rear of the loader) to hold the loader in position to prevent it from moving during sudden stops or going up and down slopes [B].



LIFT ARM STOP

Procedure




WARNING

Never work on a machine with the lift arms up unless the lift arms are secured by an approved lift arm support device. Failure to use an approved lift arm support device can allow the lift arms or attachment to fall and cause injury or death.

W-2059-0598

NOTE: Lift arm stops are available from your local dealer.

One person must stay in the operator's seat, with the seat belt fastened and the seat bar lowered, while the second person installs the lift arm stop [A].



WARNING

Put jackstands under the front axles and rear corners of the frame before running the engine for service. Failure to use jackstands can allow the machine to fall or move and cause injury or death.

W-2017-0286

Start the engine and raise the lift arms all the way up. Have the second person install the lift arm stop over the rod of one lift cylinder.

The lift arm stop must be tight against the cylinder rod. Lower the lift arms until the stop is held between and the lift arm and lift cylinder.

OPERATOR CAB

The loader has an operator cab (ROPS and FOPS) as standard equipment. The ROPS and FOPS protect the operator from rollover and falling objects.

! WARNING

Never modify operator cab by welding, grinding, drilling holes or adding attachments unless instructed to do so by Melroe Company. Changes to the cab can cause loss of operator protection from rollover and falling objects, and result in injury or death.

W-2069-1285

Check with your dealer if the operator cab has been damaged.

The operator cab fastening bolts and nuts must be tight [A].

Tighten to 40–59 ft.-lbs. (54–68 Nm torque).


! WARNING

Both sets of fasteners at the front of the operator cab (ROPS) must be assembled as shown in this manual. Failure to secure ROPS correctly can cause injury or death.


W-2005-1189

Before the cab or the lift arms are raised for service, jackstands must be put under the rear corners of the frame. Failure to use jackstands can allow the machine to tip backward causing injury or death.

W-2014-0895



B



Seat Bar System

The seat bar system has a pivoting seat bar with arm rests and has spring loaded latches for the lift and tilt control pedals. The operator controls the use of the seat bar. The seat bar in the down position keeps the operator in the seat and unlocks the foot pedals. When the seat bar is up, the lift and tilt pedals are locked in neutral position.

Seat Bar Inspection

Sit in the seat and fasten the seat belt snugly [B]. Engage the brake.

Put the seat bar all the way down [B] and start the engine.

Operate each foot pedal to check both the lift arm and tilt functions. Raise the lift arms until the bucket is about two feet (600 mm) off the ground.

OPERATOR CAB (Cont'd)

Raise the seat bar. Try to move each foot pedal [A]. Pedals must be firmly locked in the neutral position. There must be no motion of the lift arms or tilt (bucket) when the pedals are pushed.

Pull the seat bar down, lower the lift arms fully and place the bucket flat on the ground.

Stop the engine. Engage the brake. Raise the seat bar and operate the foot pedals to be sure that the pedals are firmly locked in the neutral position. Release the seat belt.

Seat Bar Maintenance

Clean the debris or dirt from moving parts [A] and [B].

Inspect the linkage bolts and nuts for tightness 25–28 ft.-lbs. (34–38 Nm) torque.

Use general purpose grease to lubricate the seat bar pivot points at each side of the cab [B].

If seat bar system does not function correctly, check for free movement of each linkage part. Check for excessive wear. Adjust pedal control linkages. Replace parts that are worn, bent or broken.




WARNING


AVOID INJURY OR DEATH

The seat bar system must lock the lift and tilt control pedals in neutral when the seat bar is up. Service the system if pedals do not lock correctly.

W-2105-1285



A-02940



B-07387

OPERATOR CAB (Cont'd)

Raising the Operator Cab

Stop the loader on a level surface. Put the lift arms all the way down.

If the lift arms must be up while raising the cab, install a lift arm stop (See Page 1-4).



WARNING

Before the cab or the lift arms are raised for service, jackstands must be put under the rear corners of the frame. Failure to use jackstands can allow the machine to tip backward causing injury or death.

W-2014-0895

Remove the two (2) fasteners (including the washers or plates) at the front corners of the operator cab [A].

Two (2) persons are needed to raise the operator cab. Stand on the ground (one person on each side) and lift slowly until the operator cab is all the way up [B].

The operator cab will lock in this position.

Lowering the Operator Cab




Two (2) persons are needed to lower the operator cab. Avoid slippery surfaces when lowering the cab.

Release the lock mechanism by pushing and turning the locking lever until it stays disengaged [C]. REMOVE YOUR HAND BEFORE LOWERING THE OPERATOR CAB.

Stand on the ground (one person on each side) and pull down on the operator cab [B].

Both persons must slowly lower the operator cab by holding the bottom of the cab and grab handles [B].

Install the two (2) fasteners (including the washers or plates) and tighten the nuts [A].



USING AN EXTRA BATTERY (JUMP START)

Procedure

If it is necessary to use an extra battery to start the engine. BE CAREFUL! There must be one person in the operator's seat and one person to connect and disconnect the battery cables.

The extra battery must be the same voltage as the loader battery.

1. Turn the start switch "OFF".
2. Connect the first jumper cable to the positive (+) terminal of the extra battery (Item 1) and to the positive (+) terminal of the battery (Item 2) [A].

NOTE: Never connect the negative (-) cable to the negative (-) terminal of the battery.


3. Connect the second jumper cable to the negative (-) terminal of the extra battery (Item 3) and the engine (Item 4) [A].
4. Keep jumper cables away from moving parts.
5. Start the engine.
6. Immediately remove the negative (-) cable (Item 4) from the engine [A].
7. Remove the positive (+) cable from the battery terminal.
8. Remove the cables from the extra battery.

IMPORTANT

Damage to the alternator can occur if:

- Engine is operated with battery cables disconnected.
- Battery cables are connected when using a fast charger or when welding on the loader. (Remove both cables from the battery.)
- Extra battery cables (booster cables) are connected wrong.

I-2023-1285



WARNING

Keep arcs, sparks, flames and lighted tobacco away from batteries. When *jumping* from booster battery make final connection (negative) at engine frame.

Do not jump start or charge a frozen or damaged battery. Warm battery to 60°F. (16°C.) before connecting to a charger. Unplug charger before connecting or disconnecting cables to battery. Never lean over battery while boosting, testing or charging.

Battery gas can explode and cause serious injury.

W-2066-1296

Batteries contain acid which burns eyes and skin on contact. Wear goggles, protective clothing and rubber gloves to keep acid off body.

In case of acid contact, wash immediately with water. In case of eye contact get prompt medical attention and wash eye with clean, cool water for at least 15 minutes.

If electrolyte is taken internally drink large quantities of water or milk! DO NOT induce vomiting. Get prompt medical attention.

W-2065-1296

HYDRAULIC SYSTEM

	Page Number
HYDRAULIC CONTROL PEDALS	
Removal and Installation	2-23
HYDRAULIC CONTROL VALVE	
Checking the Main Relief Valve	2-11
Disassembly and Assembly	2-14
Inspection	2-15
Removal and Installation	2-12
HYDRAULIC CYLINDER REPAIR	
Assembly	2-8
Disassembly	2-6
HYDRAULIC/HYDROSTATIC FLUID RESERVOIR	
Removing Fluid from Reservoir	2-22
Removal and Installation	2-22
HYDRAULIC PUMP	
Checking Output of Hydraulic Pump	2-6
Disassembly and Assembly	2-19
Inspection	2-21
Removal and Installation	2-18
HYDRAULIC SYSTEM INFORMATION	
Flare Connections	2-2
Straight Thread O-ring Fitting	2-2
Tubelines and Hoses	2-2
LIFT CYLINDER	
Checking the Lift Cylinder(s)	2-3
Removal and Installation	2-4
PEDAL LOCK LINKAGE	
Removal and Installation	2-24
PEDAL LOCK LINKAGE	
Removal and Installation	2-25
TILT CYLINDER	
Checking the Tilt Cylinder	2-5
Removal and Installation	2-5
TROUBLESHOOTING	
Chart	2-1

HYDRAULIC
SYSTEM






HYDRAULIC / HYDROSTATIC FLOW CHART
For Model
440B and Farmboy
Chart # 6570190 (Printed January 1987)

RED - - - - - High Pressure
BLUE - - - - - Low Pressure
GREEN - - - - - Case Drain & Reservoir
ORANGE - - - - - Charge Pressure

NOTE
Chart shows oil flow in Forward Drive Position and with Hydraulic Cylinders Partially Extended. For Hydraulic/Hydrostatic System Operation, refer to Sheet 2 of this publication.



E-1715



HYDRAULIC / HYDROSTATIC SYSTEM OPERATION

To Be Used With

HYDRAULIC / HYDROSTATIC FLOW CHART

For Model

440B and Farmboy

Chart # 6570190 (Printed January 1987)

CHART LEGEND

1 FLUID RESERVOIR,

Cap: 2.4 Gals. (9.0 L)

Working Cap: 4.5-5.5 Gals. (4.3-5.2 L)

2 HYDROSTATIC MOTOR

**3 AUXILIARY QUICK COUPLERS
(OPTIONAL)**

4 TILT CYLINDER

5 LIFT CYLINDERS

6 HYDRAULIC CONTROL VALVE

**7 MAIN RELIEF VALVE, 1300-1350 PSI
(8964-9370 kPa)**

8 LOAD CHECK VALVES

9 10 MICRON FILTER

10 BY-PASS VALVE, 84 PSI (579 kPa)

11 BY-PASS VALVE, 120 PSI (827 kPa)

12 ORIFICE 0.244" (6,198 mm) Dia.

13 PORT BLOCK

14 HYDROSTATIC PUMPS

**15 HYDRAULIC PUMP 6.8 GPM
(25.7 L/min.) @ 3200 Engine RPM
(2240 RPM @ Hydraulic Pump)**

OIL FLOW EXPLANATION

The fluid flows from the reservoir 1 to the hydraulic pump 15. "Case drain" fluid from the hydrostatic pumps 14 also supplies fluid to the hydraulic pump 15.

The hydraulic pump 15 is a "gear type" pump and is driven by a shaft through the hydrostatic pumps 14. The fluid from the hydraulic pump 15 goes to the control valve 6. The control valve 6 has a pilot-operated main relief valve 7. When all three spools are in the neutral position, the fluid goes to the port block 13. If one of the spools is activated, the fluid goes out the respective port and to either the base end or rod end of the hydraulic cylinder(s) 4 5. As the fluid goes into one end of the cylinder(s), return fluid comes back from the opposite end of the cylinder(s) and back to the control valve 6. When the cylinder(s) reaches the end of the stroke, the fluid flow stops and causes hydraulic pressure to increase. When the pressure reaches the setting of the main relief valve 7 it opens and lets the fluid bypass the hydraulic circuit (internally). When this happens, there is no fluid to the down stream sections of the control 6. If the spool goes back to the neutral position, then there is fluid available for the other sections. Two sections of the control valve 6 can be used at the same time if the main relief 7 is not open.

The fluid goes through an orifice 12 and through the 10 micron filter 9 and to the hydrostatic pumps 14 for charge supply fluid. The by-pass valve 11 will open during any of the following conditions: (a) during cold weather operation (when the fluid is cold), (b) if there is excessive flow from the cylinder(s) 4 5. and (c) will allow fluid flow when it cannot go through the filter element 9 (plugged).

The normal flow of the fluid called "charge pressure" goes to the front and rear hydrostatic pumps 14 from the 10 micron filter 9. The charge relief valve 10 regulates charge pressure. Excessive fluid will go back to the fluid reservoir 1.

When the fluid gets to the pumps 14, it activates the replenishing valves. As the pressure increases the replenishing valves will open and let fluid into the pumps 14 and the motors 2 for replenishing of fluid.

When the replenishing valves open and charge fluid goes into the pumps 14, the flow becomes "drive loop fluid". When the steering levers are in the neutral position, the pumps 14 and motors 2 are not working but do have charge pressure. When the steering levers are moved, the swashplates in the pumps 14 are angled and the fluid is pumped out of the pressure side of the pumps 14 to the motors 2. This fluid is called "drive pressure fluid". Drive pressure fluid is much higher than charge pressure fluid causing the replenishing valves to close to allow the flow of the fluid to go to the motors 2.

One hydrostatic pump 14 and hydrostatic motor 2 work together as a pair to drive one side of the loader. The other pump and motor work as a pair to drive the opposite side of the loader.

The hydrostatic motors 2 are a "geroller type" and have a built in balls and springs. The balls are held on their seats by the drive loops pressure. The balls will remain on their seats as long as the case drain line is not plugged. The case drain fluid in the motors 2 is used for lubrication and cooling and flows back to the fluid reservoir 1.

2 HYDRAULIC SYSTEM

TROUBLESHOOTING

The following troubleshooting chart is provided for assistance in locating and correcting problems which are most common. Many of the recommended procedures must be done by authorized Bobcat Service Personnel only.

PROBLEM	CAUSE
The hydraulic system will not operate.	1, 2, 3, 4
Slow hydraulic system action.	1, 3, 5, 6,
Hydraulic action is not smooth.	1, 5, 6, 7
Lift arms go up slowly at full engine RPM.	1, 3, 5, 6, 8,10
The lift arms or bucket will move the pedal in neutral position.	9
The lift arms come down slowly with the pedals in the neutral position.	9, 10, 11


KEY TO CORRECT THE CAUSE

1. The fluid level is not correct.
2. The pedal linkage is disconnected.
3. The hydraulic pump is not working correctly.
4. The relief valve is not working correctly.
5. Relief valve is not at the correct pressure.
6. Suction leak on the inlet side of the hydraulic pump.
7. Fluid is cold.
8. Using the loader for more than its rated capacity.
9. Spool in the valve section is not centering or the centering spring is broken.
10. Internal leak at the lift cylinder(s).
11. External leak at the lift cylinder(s).

IMPORTANT

When repairing hydrostatic and hydraulic systems, clean the work area before disassembly and keep all parts clean. Always use caps and plugs on hoses, tubelines and ports to keep dirt out. Dirt can quickly damage the system.

I-2003-0888



Flare Connections

Use the following procedure to tighten the flare fitting:

Tighten the nut until it makes contact with the seat.

Make a mark across the "flats" of both the male and female parts of the connection [A].

Use the chart to find the correct tightness needed [B].

If the fitting leaks after tightening, disconnect it and inspect the seat area for damage.

Straight Thread O-ring Fitting

When installing this fitting, the O-ring must be first lubricated. Loosen the jam nut, install the fitting into place, then tighten the jam nut. Tighten the jam nut until it and the washer are tight against the surface [C].


Tubelines and Hoses

Make replacement of tubelines which are bent or have become flat. There will be a restriction of fluid flow, which will give a slow hydraulic action and cause heat.

Make replacement of hoses which show signs of wear, damage or weather cracked rubber.

When installing tubelines or hoses, make sure you use two wrenches when loosening and tighten them.

B	Wrench Size	Tube Size Outside Dia.	Thread Size	Rotate No. of Hex Flats
5/8"	5/16"	1/2" - 20	2-1/2	
11/16"	3/8"	9/16" - 18	2	
7/8"	1/2"	3/4" - 16	2	
1"	5/8"	7/8" - 14	1-1/2 - 2	
1-1/4"	3/4"	1-1/16" - 12	1	
1-3/8"	1"	1-5/16" - 12	3/4 - 1	
2"	1-1/4"	1-5/8" - 12	3/4 - 1	
2-1/4"	1-1/2"	1-7/8" - 12	1/2 - 3/4	



Sample of manual. Download All 178 pages at:

<https://www.arepairmanual.com/downloads/bobcat-440b-skid-steer-loader-service-repair-workshop-manual/>