

Product: 2009 Bobcat 425,428 Compact Excavator Service Repair Workshop Manual(425 S/N AACJ11001 & Above,425 S/N A

Full Download: <https://www.arepairmanual.com/downloads/2009-bobcat-425428-c>

ompact-excavator-service-repair-workshop-manual425-s-n-aacj1

1001-above425-s-n-a9k311001-above428-s-n-a9k411001-above/



Bobcat®


Service Manual

425, 428 Compact Excavator

425 S/N AACJ11001 & Above

425 S/N A9K311001 & Above

428 S/N A9K411001 & Above



Sample of manual. Download All 744 pages at:

<https://www.arepairmanual.com/downloads/2009-bobcat-425428-compact-excavator-service-repair-workshop-manual425-s-n-a>
6986952 (5-09) Printed in U.S.A.



© Bobcat Company 2009

Product: 2009 Bobcat 425,428 Compact Excavator Service Repair Workshop Manual(425 S/N AACJ11001 & Above,425 S/N A
Full Download: <https://www.arepairmanual.com/downloads/2009-bobcat-425428-compact-excavator-service-repair-workshop-manual425-s-n-aacj11001-above425-s-n-a9k311001-above428-s-n-a9k411001-above/>

Sample of manual. Download All 744 pages at:

<https://www.arepairmanual.com/downloads/2009-bobcat-425428-compact-excavator-service-repair-workshop-manual425-s-n-aacj11001-above425-s-n-a9k311001-above428-s-n-a9k411001-above/>

MAINTENANCE SAFETY



WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0807



Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.

CORRECT



P-90216

⚠ Never service the Bobcat Excavator without instructions.

CORRECT



B-19964

⚠ Use the correct procedure to lift and support the excavator.

CORRECT



B-19959

⚠ Cleaning and maintenance are required daily.

WRONG



B-19965

⚠ Have good ventilation when welding or grinding painted parts.
⚠ Wear dust mask when grinding painted parts. Toxic dust and gas can be produced.


WRONG



B-19960

⚠ Vent exhaust to outside when engine must be run for service.
⚠ Exhaust system must be tightly sealed. Exhaust fumes can kill without warning.

WRONG



B-19966

⚠ Always lower the bucket and blade to the ground before doing any maintenance.
⚠ Never modify equipment or add attachments not approved by Bobcat Company.

WRONG



B-19962

⚠ Stop, cool and clean engine of flammable materials before checking fluids.
⚠ Never service or adjust machine with the engine running unless instructed to do so in the manual.
⚠ Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate the skin or eyes.
⚠ Never fill fuel tank with engine running, while smoking, or when near open flame.

WRONG



B-19958

⚠ Keep body, jewelry and clothing away from moving parts, electrical contact, hot parts and exhaust.
⚠ Wear eye protection to guard from battery acid, compressed springs, fluids under pressure and flying debris when engines are running or tools are used. Use eye protections approved for type of welding.
⚠ Keep tailgate closed except for service. Close and latch tailgate before operating the excavator.

WRONG



B-19798

⚠ Lead-acid batteries produce flammable and explosive gases.
⚠ Keep arcs, sparks, flames and lighted tobacco away from batteries.
⚠ Batteries contain acid which burns eyes or skin on contact.
⚠ Wear protective clothing. If acid contacts body, flush well with water. For eye contact flush well and get immediate medical attention.

Maintenance procedures which are given in the Operation & Maintenance Manual can be performed by the owner/operator without any specific technical training. Maintenance procedures which are **not** in the Operation & Maintenance Manual must be performed **ONLY BY QUALIFIED BOBCAT SERVICE PERSONNEL**. Always use genuine Bobcat replacement parts. The Service Safety Training Course is available from your Bobcat dealer.

MSW28-0409



Bobcat®

ALPHABETICAL INDEX

AIR CLEANER	60-01	HEATER COIL	70-01
AIR CLEANER SERVICE	10-01	HEATER SYSTEM	70-01
ALTERNATOR	50-01	HEATER UNIT	70-01
ALTERNATOR BELT	10-01	HEATER VALVE	70-01
ARM	40-01	HORN	40-01
ARM CYLINDER	20-01	HYDRAULIC CONTROL VALVE	20-01
 BATTERY	50-01	HYDRAULIC CONNECTION SPECS	SPEC-01
BLADE	30-01	HYDRAULIC FLUID SPECIFICATIONS	SPEC-01
BLADE CONTROL	40-01	HYDRAULIC FILTER	20-01
BLADE CYLINDER	20-01	HYDRAULIC PUMP	20-01
BLOWER FAN	70-01	HYDRAULIC RESERVOIR	20-01
BOOM	40-01	HYDRAULIC SYSTEM	10-01
BOOM CYLINDER	20-01	HYDRAULIC SYSTEM INFORMATION	20-01
BOOM SWING CYLINDER	20-01	HYDRAULIC X-CHANGE VALVE	20-01
BOOM SWING PEDAL	40-01	 LEFT CONTROL LEVER (JOYSTICK)	20-01
BUCKET	40-01	LEFT CONSOLE	40-01
BUCKET CYLINDER	20-01	LEFT SIDE COVER	40-01
 CAB	40-01	LIFTING AND BLOCKING THE EXCAVATOR	10-01
CAMSHAFT AND TIMING GEARS	60-01	LIFTING THE EXCAVATOR	10-01
CANOPY	40-01	LIGHTS	50-01
CASE DRAIN FILTER	20-01	LUBRICATION SYSTEM	60-01
CLAMP	40-01	LUBRICATING THE EXCAVATOR	10-01
CLAMP CYLINDER	20-01	 MAGNETIC LOCKOUT SENSOR	50-01
CONVERSIONS	SPEC-01	MAIN RELIEF VALVE	20-01
CONTROL PATTERN SELECTOR VALVE	20-01	MANIFOLD ASSEMBLY / ACCUMULATOR	20-01
COUNTERWEIGHT	40-01	MOTION ALARM SYSTEM (IF EQUIPPED)	20-01
CRANKSHAFT AND PISTONS	60-01	 NON-PRESSURIZED ACCUMULATOR	20-01
CROSSPORT RELIEF VALVES	20-01	OIL COOLER	20-01
CYLINDER HEAD	60-01	OPERATOR CAB (ROPS/TOPS)	10-01
 DIAGNOSTICS SERVICE CODES	50-01	 PIVOT PINS	10-01
DIRECT TO TANK VALVE	20-01	PORT RELIEF VALVES	20-01
 ELECTRICAL SYSTEM INFORMATION	50-01	PRESSURE REDUCING VALVE	20-01
ENGINE COOLING SYSTEM	10-01, 60-01	 REGULAR MAINTENANCE	70-01
ENGINE INFORMATION	60-01	RIGHT CONTROL LEVER (JOYSTICK)	20-01
ENGINE LUBRICATION SYSTEM	10-01	RIGHT CONSOLE	40-01
ENGINE SPEED CONTROL	60-01	RIGHT SIDE COVER	10-01, 40-01
EXCAVATOR SPECIFICATIONS	SPEC-01		
EXCAVATOR STORAGE AND RETURN TO SERVICE	10-01		
 FLOOR MAT AND FLOOR PANELS	40-01		
FLYWHEEL AND HOUSING	60-01		
FUEL LEVEL SENDER	50-01		
FUEL SYSTEM	10-01, 60-01		
FUEL TANK	40-01		

Continued On Next Page

ALPHABETICAL INDEX (CONT'D)

SEAT AND SEAT MOUNT	40-01
SEAT BELT	10-01
SERVICE SCHEDULE	10-01
SLEW LOCK VALVE	20-01
SPARK ARRESTOR MUFFLER	10-01, 60-01
STARTER	50-01
STOPPING THE ENGINE AND LEAVING	
THE EXCAVATOR	10-01
SWING CIRCLE GEAR	30-01
SWING FRAME	40-01
SWING MOTOR	20-01
SWING MOTOR DRIVE CARRIER	20-01
SWIVEL JOINT	20-01
TAILGATE	10-01, 40-01
TORQUE SPECIFICATIONS FOR BOLTS	SPEC-01
TRACK FRAME COMPONENTS	30-01
TRANSPORTING THE EXCAVATOR	
ON A TRAILER	10-01
TRAVEL LEVER / PEDALS	40-01
TRAVEL MOTOR	10-01, 20-01
TROUBLESHOOTING	70-01
UPPERSTRUCTURE	40-01
UPPERSTRUCTURE SLEW LOCK	10-01, 40-01
X-CHANGE	40-01
X-CHANGE (HYDRAULIC)	40-01

CONTENTS

FOREWORD.....	II
SAFETY INSTRUCTIONS	IV
FIRE PREVENTION	VI
SERIAL NUMBER LOCATIONS	VIII
DELIVERY REPORT.....	IX
EXCAVATOR IDENTIFICATION	X
SAFETY AND MAINTENANCE.....	10-01
HYDRAULIC SYSTEM	20-01
UNDERCARRIAGE.....	30-01
UPPERSTRUCTURE & SWING SECTION	40-01
ELECTRICAL SYSTEM AND ANALYSIS	50-01
ENGINE SERVICE	60-01
HEATER	70-01
SPECIFICATIONS.....	SPEC-01

**SAFETY AND
MAINTENANCE**

**HYDRAULIC
SYSTEM**

UNDERCARRIAGE

**UPPERSTRUCTURE
& SWING
SECTION**

**ELECTRICAL
SYSTEM AND
ANALYSIS**

**ENGINE
SERVICE**

HEATER


SPECIFICATIONS

FOREWORD


This manual is for the Bobcat excavator mechanic. It provides necessary servicing and adjustment procedures for the Bobcat excavator and its component parts and systems. Refer to the Operation & Maintenance Manual for operating instructions, starting procedure, daily checks, etc.

A general inspection of the following items must be made after the excavator has had service or repair:


1. Check that the ROPS/TOPS/ FOPS is in good condition and is not modified.




2. Check that ROPS/TOPS mounting hardware is tightened and is Bobcat approved.




3. The seat belt must be correctly installed, functional and in good condition.



4. Machine signs (decals) must be legible and in the correct location.




5. Travel levers, control levers and foot pedals must return to neutral. Check that the pedal locks are in working order.




6. Check for correct function of the work lights.




7. Enclosure door latches must open and close freely.




8. Attachment locking pins must function correctly and be in good condition.




9. Safety treads must be in good condition.




10. Check for correct function of indicator lamps.



11. Check hydraulic fluid level, engine oil level and fuel supply.




12. Inspect for fuel, oil or hydraulic fluid leaks.




13. Lubricate the excavator.




14. Check the condition of the battery and cables.




15. Inspect the air cleaner for damage or leaks. Check the condition of the element.




16. Check the electrical charging system.



17. Check tracks for wear and tension. Use only approved tracks.




18. Inspect for loose or broken parts or connections.




19. Check for any field modification not completed.




20. Operate the machine and check all functions.



21. Check the control console interlocks for correct function.




22. Inspect the X-Change™ for wear or damage. Repair or replace damaged parts.



23. Check function or condition of all equipped options and accessories (examples: special applications kit, motion alarm, etc.).



24. Recommend to the owner that all necessary corrections be made before the machine is returned to service.



**CALIFORNIA
PROPOSITION 65 WARNING**

Diesel engine exhaust and some of its constituents are known to the state of California to cause cancer, birth defects and other reproductive harm.

SAFETY INSTRUCTIONS



Safety Alert Symbol

This symbol with a warning statement means:
"Warning, be alert! Your safety is involved!"
Carefully read the message that follows.



WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903

IMPORTANT

This notice identifies procedures which must be followed to avoid damage to the machine.

I-2019-0284



DANGER

The signal word DANGER on the machine and in the manuals indicates a hazardous situation which, if not avoided, will result in death or serious injury.

D-1002-1107



WARNING

The signal word WARNING on the machine and in the manuals indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

W-2044-1107

The following publications provide information on the safe use and maintenance of the Bobcat machine and attachments:

- The Delivery Report is used to assure that complete instructions have been given to the new owner and that the machine is in safe operating condition.
- The Operation & Maintenance Manual delivered with the machine or attachment contains operating information as well as routine maintenance and service procedures. It is a part of the machine and can be stored in a container provided on the machine. Replacement Operation & Maintenance Manuals can be ordered from your Bobcat dealer.
- Machine signs (decals) instruct on the safe operation and care of your Bobcat machine or attachment. The signs and their locations are shown in the Operation & Maintenance Manual. Replacement signs are available from your Bobcat dealer.
- An Operator's Handbook fastened to the operator cab. It's brief instructions are convenient to the operator. The handbook is available from your dealer in an English edition or one of many other languages. See your Bobcat dealer for more information on translated versions.
- The AEM Safety Manual delivered with the machine gives general safety information.
- The Service Manual and Parts Manual are available from your dealer for use by mechanics to do shop-type service and repair work.
- The Compact Excavator Operator Training Course is available through your local dealer or at www.training.bobcat.com or www.bobcat.com. This course is intended to provide rules and practices of correct operation of the Bobcat excavator. The course is available in English and Spanish versions.
- Service Safety Training Courses are available from your Bobcat dealer or at www.training.bobcat.com or www.bobcat.com. They provide information for safe and correct service procedures.
- The Bobcat compact excavator Safety Video is available from your Bobcat dealer or at www.training.bobcat.com or www.bobcat.com.

SI EXC-0308 SM

SAFETY INSTRUCTIONS (CONT'D)

The dealer and owner / operator review the recommended uses of the product when delivered. If the owner / operator will be using the machine for a different application(s) he or she must ask the dealer for recommendations on the new use.



Cutting or drilling concrete containing sand or rock containing quartz may result in exposure to silica dust. Do not exceed Permissible Exposure Limits (PEL) to silica dust as determined by OSHA or other job site Rules and Regulations. Use a respirator, water spray or other means to control dust. Silica dust can cause lung disease and is known to the state of California to cause cancer.

Call Before You Dig Dial 811 (USA Only) 1-888-258-0808 (USA & Canada)

When you call, you will be directed to a location in your state / province, or city for information about buried lines (telephone, cable TV, water, sewer, gas, etc.).

FIRE PREVENTION



Maintenance

The machine and some attachments have components that are at high temperatures under normal operating conditions. The primary source of high temperatures is the engine and exhaust system. The electrical system, if damaged or incorrectly maintained, can be a source of arcs or sparks.

Flammable debris (leaves, straw, etc.) must be removed regularly. If flammable debris is allowed to accumulate, it can cause a fire hazard. Clean often to avoid this accumulation. Flammable debris in the engine compartment is a potential fire hazard.

The operator's area, engine compartment and engine cooling system must be inspected every day and cleaned if necessary to prevent fire hazards and overheating.

All fuels, most lubricants and some coolants mixtures are flammable. Flammable fluids that are leaking or spilled onto hot surfaces or onto electrical components can cause a fire.

Operation

Do not use the machine where exhaust, arcs, sparks or hot components can contact flammable material, explosive dust or gases.

Electrical



Check all electrical wiring and connections for damage. Keep the battery terminals clean and tight. Repair or replace any damaged part or wires that are loose or frayed.

Battery gas can explode and cause serious injury. Use the procedure in the Operation & Maintenance Manual for connecting the battery and for jump starting. Do not jump start or charge a frozen or damaged battery. Keep any open flames or sparks away from batteries. Do not smoke in battery charging area.

Hydraulic System

Check hydraulic tubes, hoses and fittings for damage and leakage. Never use open flame or bare skin to check for leaks. Hydraulic tubes and hoses must be properly routed and have adequate support and secure clamps. Tighten or replace any parts that show leakage.

Always clean fluid spills. Do not use gasoline or diesel fuel for cleaning parts. Use commercial nonflammable solvents.

Fueling



Stop the engine and let it cool before adding fuel. No smoking! Do not refuel a machine near open flames or sparks. Fill the fuel tank outdoors.

Starting

Do not use ether or starting fluids on any engine that has glow plugs. These starting aids can cause explosion and injure you or bystanders.

Use the procedure in the Operation & Maintenance Manual for connecting the battery and for jump starting.

Spark Arrestor Exhaust System

The spark arrestor exhaust system is designed to control the emission of hot particles from the engine and exhaust system, but the muffler and the exhaust gases are still hot.

Check the spark arrestor exhaust system regularly to make sure it is maintained and working properly. Use the procedure in the Operation & Maintenance Manual for cleaning the spark arrestor muffler (if equipped).

FIRE PREVENTION (CONT'D)


Welding And Grinding

Always clean the machine and attachment, disconnect the battery, and disconnect the wiring from the Bobcat controllers before welding. Cover rubber hoses, battery and all other flammable parts. Keep a fire extinguisher near the machine when welding.

Have good ventilation when grinding or welding painted parts. Wear dust mask when grinding painted parts. Toxic dust or gas can be produced.

Dust generated from repairing nonmetallic parts such as hoods, fenders or covers can be flammable or explosive. Repair such components in a well ventilated area away from open flames or sparks.

Fire Extinguishers




Know where fire extinguishers and first aid kits are located and how to use them. Inspect the fire extinguisher and service the fire extinguisher regularly. Obey the recommendations on the instructions plate.

SERIAL NUMBER LOCATIONS

Always use the serial number of the excavator when requesting service information or when ordering parts. Early or later models (identification made by serial number) may use different parts, or it may be necessary to use a different procedure in doing a specific service operation.

Excavator Serial Number

Figure 1



The excavator serial number plate (Item 1) is located on the frame of the machine in the location shown [Figure 1].

Explanation of Excavator Serial Number:

XXXX XXXX

Module 2. - Production Sequence (Series)


Module 1. - Model / Engine Combination

1. The four digit Model/Engine Combination Module number identifies the model number and engine combination.

2. The five digit Production Sequence Number identifies the order which the excavator is produced.

Engine Serial Number


Figure 2



The engine serial number (Item 1) is located on the engine in the location shown [Figure 2].

DELIVERY REPORT


Figure 3



The image shows a template for a 'DELIVERY REPORT' form. At the top, there are two sets of horizontal lines for signatures. Below these is a box labeled 'DELIVERY REPORT'. To the left of the main body is a box labeled 'WARNING' containing several lines of text. The main body of the form is divided into two columns, each containing several lines of text. In the bottom right corner of the form, there is a box containing the code 'B-16315'.

The delivery report must be filled out by the dealer and signed by the owner or operator when the Bobcat Excavator is delivered. An explanation of the form must be given to the owner. Make sure it is filled out completely [Figure 3].

EXCAVATOR IDENTIFICATION



† BUCKET - Several different buckets and other attachments are available from the Bobcat Excavator.

● ROPS, TOPS - (Roll Over Protective Structure / Tip Over Protective Structure) as standard equipment. The ROPS/TOPS meets SAE J1040, ISO 3471 and ISO 12117.

AIR CLEANER SERVICE	10-60-1
Daily Check	10-60-1
Replacing Filter Elements	10-60-2
ALTERNATOR BELT	10-140-1
Belt Adjustment	10-140-1
Belt Replacement	10-140-1
ENGINE COOLING SYSTEM	10-70-1
Checking Level	10-70-2
Cleaning	10-70-1
Removing And Replacing Coolant	10-70-3
ENGINE LUBRICATION SYSTEM	10-90-1
Checking And Adding Engine Oil	10-90-1
Engine Oil Chart	10-90-1
Removing And Replacing Oil Filter	10-90-2
EXCAVATOR STORAGE AND RETURN TO SERVICE	10-170-1
Storage	10-170-1
Return To Service	10-170-1
FUEL SYSTEM	10-80-1
Biodiesel Blend Fuel	10-80-1
Draining The Fuel Tank	10-80-5
Filling The Fuel Tank	10-80-2
Fuel Filters	10-80-3
Fuel Specifications	10-80-1
Removing Air From The Fuel System	10-80-5
HYDRAULIC SYSTEM	10-100-1
Checking And Adding Fluid	10-100-1
Hydraulic Fluid Chart	10-100-1
Removing And Replacing The Case Drain Filter	10-100-2
Removing And Replacing The Hydraulic Filter	10-100-2
Removing And Replacing The Hydraulic Fluid	10-100-3
LIFTING AND BLOCKING THE EXCAVATOR	10-10-1
Procedure	10-10-1
LIFTING THE EXCAVATOR	10-12-1
Procedure	10-12-1
LUBRICATING THE EXCAVATOR	10-110-1
Lubrication Locations	10-110-1

Continued On Next Page

SAFETY AND MAINTENANCE (CONT'D)

OPERATOR CAB (ROPS / TOPS)	10-20-1
Cab Door	10-20-1
Description	10-20-1
Front Window	10-20-2
Front Wiper	10-20-3
Heating, Ventilation, and Air Conditioning Duct	10-20-5
Right Side Window	10-20-4
Window Washer Reservoir	10-20-3
PIVOT PINS	10-160-1
Inspection And Maintenance	10-160-1
RIGHT SIDE COVER	10-41-1
Opening And Closing	10-41-1
SEAT BELT	10-150-1
Inspection And Maintenance	10-150-1
SERVICE SCHEDULE	10-50-1
Chart	10-50-1
SPARK ARRESTOR MUFFLER	10-130-1
Cleaning Procedure	10-130-1
STOPPING THE ENGINE AND LEAVING THE EXCAVATOR ..	10-180-1
Emergency Exits	10-180-2
Procedure	10-180-1
TAILGATE	10-40-1
Opening And Closing	10-40-1
TRANSPORTING THE EXCAVATOR ON A TRAILER	10-30-1
Fastening	10-30-1
Loading And Unloading	10-30-1
TRAVEL MOTOR	10-120-1
Checking And Adding Oil	10-120-1
Removing And Replacing Oil	10-120-1
UPPERSTRUCTURE SLEW LOCK	10-11-1
Operation	10-11-1

TIGHTEN ALL HARDWARE PER SIZE TO GRADE 5 TORQUE (SEE STANDARD TORQUE SPECIFICATIONS FOR BOLTS, SECTION SPEC-01) UNLESS OTHERWISE SPECIFIED.

SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE AND STANDARD ITEMS MAY VARY.

LIFTING AND BLOCKING THE EXCAVATOR

Procedure

Always park the machine on a level surface.

Figure 10-10-1



Raise one side of the machine (approximately 4 in.) using the boom and arm as shown in **[Figure 10-10-1]**.

Raise the blade fully and install jackstands under the blade and the track frame. Lower the boom until all machine weight is on the jackstands.

Stop the engine.



WARNING

Put jackstands under the blade and rear corners of the undercarriage before working under the machine. Failure to block up the machine may allow it to move or fall and result in injury or death.

W-2218-1195



WARNING

AVOID INJURY

Keep fingers and hands out of pinch points when checking the track tension.

W-2142-0903



WARNING




Bobcat®

UPPERSTRUCTURE SLEW LOCK

Operation

Figure 10-11-1



Push down on the front (Item 1) [Figure 10-11-1] of the foot pedal to engage the upperstructure swing lock.

Push down on the rear (Item 2) [Figure 10-11-1] to disengage the upperstructure slew lock.

NOTE: Upperstructure must be in the straight forward or straight rearward position for upperstructure to lock.




Bobcat®

LIFTING THE EXCAVATOR

Procedure

Figure 10-12-1




Fully extend the cylinders of the bucket, arm, and boom so that the excavator is in the position as shown [Figure 10-12-1].

Raise the blade all the way.

Put all the control levers in neutral.

Figure 10-12-2



Fasten chains to the ends of the blade (Item 1) [Figure 10-12-1] and [Figure 10-12-2] and up to a lifting fixture above the canopy/cab. The lifting fixture must extend over the sides of the canopy/cab to prevent the chains from hitting the ROPS/TOPS.

Install a 1 in. (25 mm) bolt and nut (Grade 5 or 8) through the holes at the boom (Item 2) [Figure 10-12-1] and [Figure 10-12-2]. Fasten a chain from the bolt to the lift fixture.



WARNING

AVOID INJURY OR DEATH

- Use a lifting fixture with sufficient capacity for the weight of the excavator plus any added attachments.
- Maintain center of gravity and balance when lifting.
- Do not swing boom or upperstructure. Engage the upperstructure slew lock.
- Never lift with operator on machine.

W-2202-0607



Bobcat®

OPERATOR CAB (ROPS / TOPS)

Description

The excavator has an optional operator cab (ROPS/TOPS) (Roll Over Protective Structure/Tip Over Protective Structure). The ROPS/TOPS meets SAE J1040, ISO 3471 and ISO 12117.

An enclosed cab (ROPS/TOPS) is an Option or can be installed as a Field Accessory.

Both the cab and canopy provide operator protection if the excavator is tipped over. The seat belt must be worn for ROPS /TOPS protection.




WARNING

Never modify operator cab by welding, grinding, drilling holes or adding attachments unless instructed to do so by Bobcat Company. Changes to the cab can cause loss of operator protection from rollover and falling objects, and result in injury or death.

W-2069-0200

Cab Door

Figure 10-20-1




P-68192

The cab door can be locked (Item 1) [Figure 10-20-1] with the same key as the starter switch.

Push the door all the way open (Item 2) [Figure 10-20-1] until the latch engages to hold the door in the open position.

Figure 10-20-2



P-68193

When the door is in the open position, push down on the latch (Item 1) [Figure 10-20-2] and close the door.


From inside the cab, open the door using handle (Item 2) [Figure 10-20-2].

OPERATOR CAB (ROPS / TOPS) (CONT'D)

Front Window


Opening The Front Window

Figure 10-20-3



Retract the two top window latch pins (Item 1) [Figure 10-20-3].

Figure 10-20-4



Turn the two top latches (Item 1) [Figure 10-20-4] to the unlocked position.


Figure 10-20-5



Use both window grab handles to pull the top of the window in [Figure 10-20-5].

Continue moving the window in and up over the operator's head until the window is fully raised.

Figure 10-20-6



When the window is fully raised, the latch (Item 1) will close on the bracket. Turn the two top latches (Item 2) [Figure 10-20-6] to the locked position.

Closing The Front Window

Support the window while releasing both window latch pins and placing the pins in the unlocked position [Figure 10-20-6].

Support the window using the left grab handle and pull down on the latch (Item 1) [Figure 10-20-5] to release the window.

Use both window grab handles to pull the window down [Figure 10-20-5].

Rotate the top latches (Item 1) [Figure 10-20-4] to the locked position (Item 1) [Figure 10-20-3].

OPERATOR CAB (ROPS / TOPS) (CONT'D)

Front Wiper


Figure 10-20-7




The front window is equipped with a wiper (Item 1) [Figure 10-20-7] and washer.

Window Washer Reservoir


Figure 10-20-8



The window washer reservoir (Item 1) [Figure 10-20-8] is located under the right side cover.

Right Side Window<https://www.arepairmanual.com/downloads/2009-bobcat-425428-compact-excavator-service-repair-workshop-manual425-s-n-a9k311001-above428-s-n-a9k411001-above/>*Opening The Right Rear Window***Figure 10-20-9**


Pull forward on the latch / handle (Item 1) [Figure 10-20-9].

Figure 10-20-10


Pull the latch / handle (Item 1) [Figure 10-20-10] forward to open the window.

Closing The Right Rear Window

Push the handle back to close the window.

Figure 10-20-11

Pull back on the latch / handle (Item 1) [Figure 10-20-11].

Figure 10-20-12

Pull the latch / handle (Item 1) [Figure 10-20-12] back to open the window.

Closing The Right Front Window

Push the handle forward to close the window.

Sample of manual. Download All 744 pages at:

<https://www.arepairmanual.com/downloads/2009-bobcat-425428-compact-excavator-service-repair-workshop-manual425-s-n-a9k311001-above428-s-n-a9k411001-above/>