

Product: 2010 Bobcat T200 Compact Track Loader Service Repair Workshop Manual

Full Download: <https://www.arepairmanual.com/downloads/2010-bobcat-t200-compact-track-loader-service-repair-workshop-manual/>




Bobcat®

Service Manual

S/N 518915001 & Above

S/N 516815001 & Above

S/N 517515001 & Above



EQUIPPED WITH
BOBCAT INTERLOCK
CONTROL SYSTEM (BICS™)

Sample of manual. Download All 867 pages at:

<https://www.arepairmanual.com/downloads/2010-bobcat-t200-compact-track-loader-service-repair-workshop-manual/>

Product: 2010 Bobcat T200 Compact Track Loader Service Repair Workshop Manual

Full Download: <https://www.arepairmanual.com/downloads/2010-bobcat-t200-compact-track-loader-service-repair-workshop-manual/>

Sample of manual. Download All 867 pages at:

<https://www.arepairmanual.com/downloads/2010-bobcat-t200-compact-track-loader-service-repair-workshop-manual/>

MAINTENANCE SAFETY



WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0807



Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.

CORRECT



P-90216

CORRECT



B-15659

CORRECT



B-15660

⚠ Never service the Bobcat Compact Track Loader without instructions.


WRONG



B-15664

⚠ Have good ventilation when welding or grinding painted parts.
⚠ Wear dust mask when grinding painted parts. Toxic dust and gas can be produced.
⚠ Avoid exhaust fume leaks which can kill without warning. Exhaust system must be tightly sealed.


WRONG



B-15661

⚠ Disconnecting or loosening any hydraulic tubeline, hose, fitting, component or a part failure can cause lift arms to drop. Do not go under lift arms when raised unless supported by an approved lift arm support device. Replace it if damaged.

WRONG



B-15662

⚠ Never work on loader with lift arms up unless lift arms are held by an approved lift arm support device. Replace if damaged.
⚠ Never modify equipment or add attachments not approved by Bobcat Company.


WRONG



B-15665

⚠ Stop, cool and clean engine of flammable materials before checking fluids.
⚠ Never service or adjust loader with the engine running unless instructed to do so in the manual.
⚠ Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate the skin or eyes.
⚠ Never fill fuel tank with engine running, while smoking or when near open flame.

WRONG



B-15663

⚠ Keep body, jewelry and clothing away from moving parts, electrical contact, hot parts and exhaust.
⚠ Wear eye protection to guard from battery acid, compressed springs, fluids under pressure and flying debris when engines are running or tools are used. Use eye protection approved for type of welding.
⚠ Keep rear door closed except for service. Close and latch door before operating the loader.

WRONG



B-6589

⚠ Lead-acid batteries produce flammable and explosive gases.
⚠ Keep arcs, sparks, flames and lighted tobacco away from batteries.
⚠ Batteries contain acid which burns eyes or skin on contact. Wear protective clothing. If acid contacts body, flush well with water. For eye contact flush well and get immediate medical attention.

Maintenance procedures which are given in the Operation & Maintenance Manual can be performed by the owner/operator without any specific technical training. Maintenance procedures which are **not** in the Operation & Maintenance Manual must be performed **ONLY BY QUALIFIED BOBCAT SERVICE PERSONNEL**. Always use genuine Bobcat replacement parts. The Service Safety Training Course is available from your Bobcat dealer.

MSW09-0409



Bobcat®

ALPHABETICAL INDEX

ADVANCED CONTROL SYSTEM (ACS)	
SELECTABLE HAND / FOOT CONTROL	60-01
ADVANCED CONTROL SYSTEM (ACS)	
ADVANCED HAND CONTROL	60-01
AIR CLEANER	70-01
AIR CLEANER SERVICE	10-01
AIR CONDITIONING SERVICE	80-01
AIR CONDITIONING SYSTEM FLOW	80-01
ALTERNATOR (90 AMP)	60-01
 BASIC TROUBLESHOOTING	80-01
BATTERY	60-01
BICS™ SYSTEM	60-01
BOB-TACH	10-01, 50-01
BOBCAT CONTROLLER	60-01
BRAKE	40-01
BUCKET POSITION VALVE	20-01
 CHARGE PRESSURE	30-01
COMPONENTS	80-01
COMPRESSOR	80-01
CONDENSER	80-01
CONTROL HANDLE (ADVANCED CONTROL SYSTEM) (ACS) SELECTABLE HAND / FOOT CONTROL	50-01
CONTROL HANDLE (ADVANCED CONTROL SYSTEM) (ACS) ADVANCED HAND CONTROL	50-01
CONTROL PANEL	50-01
CONTROL PEDALS	50-01
CONTROL PEDALS (ACS)	50-01
CONVERSIONS	SPEC-01
COOLING FAN	70-01
CYLINDER (LIFT)	20-01
CYLINDER (POWER BOB-TACH)	20-01
CYLINDER (TILT)	20-01
 DIAGNOSTICS	60-01
DRIVE BELT	30-01
DRIVE COMPONENTS	40-01
 ELECTRICAL SYSTEM INFORMATION	60-01
ELECTRICAL / HYDRAULIC CONTROLS	
REFERENCE	60-01
ENGINE & ENGINE MOUNTS	70-01
ENGINE COMPONENTS AND TESTING	70-01
ENGINE COOLING SYSTEM	10-01
ENGINE LUBRICATION SYSTEM	10-01
ENGINE SPEED CONTROL	70-01
EVAPORATOR	80-01
EVAPORATOR / HEATER UNIT	80-01
EXPANSION VALVE	80-01
 FAN GEARBOX	10-01
FLYWHEEL AND HOUSING	70-01
FRONT AUXILIARY PRESSURE RELIEF BLOCK	20-01
FUEL SYSTEM	10-01
 FUEL TANK	50-01
GENERAL AIR CONDITIONING SERVICE	
GUIDELINES	80-01
HEATER COIL	80-01
HEATER VALVE	80-01
HEATER / AC FAN	80-01
HYDRAULIC CONTROL VALVE (ADVANCED CONTROL SYSTEM) (ACS)	20-01
HYDRAULIC CONNECTION	
SPECIFICATIONS	SPEC-01
HYDRAULIC CONTROL VALVE (FOOT)	20-01
HYDRAULIC FILTER HOUSING	20-01
HYDRAULIC FLUID RESERVOIR	20-01
HYDRAULIC PUMP	20-01
HYDRAULIC PUMP (HI FLOW)	20-01
HYDRAULIC SYSTEM INFORMATION	20-01
HYDRAULIC / HYDROSTATIC FILTER	20-01
HYDRAULIC / HYDROSTATIC FLUID	
SPECIFICATIONS	SPEC-01
HYDRAULIC / HYDROSTATIC SYSTEM	10-01
HYDROSTATIC MOTOR	30-01
HYDROSTATIC PUMP	30-01
HYDROSTATIC SYSTEM INFORMATION	30-01
 INSTRUMENT PANEL	60-01
LIFT ARM	50-01
LIFT ARM BYPASS CONTROL VALVE	20-01
LIFT ARM SUPPORT DEVICE	10-01
LIFTING AND BLOCKING THE LOADER	10-01
LIGHTS	60-01
LOADER SPECIFICATIONS	SPEC-01
LOADER TORQUE	SPEC-01
LUBRICATION OF THE BOBCAT LOADER	10-01
 MAIN RELIEF VALVE	20-01
MUFFLER	70-01
 OIL COOLER	30-01
OPERATOR CAB	10-01, 50-01
OPERATOR SEAT	50-01
OPERATOR SEAT (SUSPENSION)	50-01
 POWER BOB-TACH	50-01
POWER BOB-TACH (OPTION)	10-01
POWER BOB-TACH BLOCK	20-01
PRESSURE RELIEF VALVE	80-01
PRESSURE SWITCH	80-01

ALPHABETICAL INDEX

RADIATOR.....	70-01
REAR AUXILIARY DIVERTER VALVE (DUAL SHUTTLE)	20-01
REAR DOOR	50-01
REAR GRILL	50-01
RECEIVER / DRIER	80-01
RECONDITIONING	70-01
REGULAR MAINTENANCE	80-01
REMOTE START	10-01
RPM SENSOR	70-01
 SAFETY.....	80-01
SEAT BAR	50-01
SEAT BAR SENSOR	60-01
SELECT VALVE.....	20-01
SERVICE SCHEDULE	10-01
SPARK ARRESTOR MUFFLER	10-01
STARTER	60-01
SYSTEM CHARGING AND RECLAMATION	80-01
SYSTEM TROUBLESHOOTING CHART	80-01
 TEMPERATURE / PRESSURE	80-01
THERMOSTAT.....	80-01
TORQUE SPECIFICATIONS FOR BOLTS.....	SPEC-01
TOWING THE LOADER	10-01
TRACTION LOCK.....	60-01
TRANSPORTING THE BOBCAT LOADER.....	10-01
TROUBLESHOOTING.....	70-01
TURBOCHARGER	70-01

ACS-ADVANCED CONTROL SYSTEM

AHC-ADVANCED HAND CONTROL SYSTEM

BICS-BOBCAT INTERLOCK CONTROL SYSTEM

CONTENTS

FOREWORD	II
SAFETY INSTRUCTIONS	V
FIRE PREVENTION	VII
SERIAL NUMBER LOCATIONS	IX
DELIVERY REPORT	X
BOBCAT LOADER IDENTIFICATION	XI
SAFETY AND MAINTENANCE	10-01
HYDRAULIC SYSTEM	20-01
HYDROSTATIC SYSTEM	30-01
DRIVE SYSTEM	40-01
MAINFRAME	50-01
ELECTRICAL SYSTEM & ANALYSIS	60-01
ENGINE SERVICE	70-01
HEATING, VENTILATION, AIR CONDITIONING	80-01
SPECIFICATIONS	SPEC-01

**SAFETY &
MAINTENANCE**

**HYDRAULIC
SYSTEM**

**HYDROSTATIC
SYSTEM**

**DRIVE
SYSTEM**

MAINFRAME

**ELECTRICAL
SYSTEM**

**ENGINE
SERVICE**


HVAC















SPECIFICATIONS

FOREWORD


This manual is for the Bobcat loader mechanic. It provides necessary servicing and adjustment procedures for the Bobcat loader and its component parts and systems. Refer to the Operation & Maintenance Manual for operating instructions, starting procedure, daily checks, etc.

A general inspection of the following items must be made after the loader has had service or repair:


1. Check that the ROPS/FOPS (Including side screens) is in good condition and is not modified.

2. Check that ROPS mounting hardware is tightened and is Bobcat approved.

3. The seat belt must be correctly installed, functional and in good condition.

4. The seat bar must be correctly adjusted, clean and lubricated.

5. Check lift arm support device, replace if damaged.

6. Machine signs (decals) must be legible and in the correct location.

7. Steering levers, hand controls and foot pedals must return to neutral (as applicable).

8. Check for correct function of the work lights.

9. The parking brake must function correctly.

10. Enclosure door latches must open and close freely.

11. Bob-Tach wedges and linkages must function correctly and be in good condition.

12. Safety treads must be in good condition.

13. Check for correct function of indicator lamps.

14. Check hydraulic fluid level, engine oil level and fuel supply.

15. Inspect for fuel, oil or hydraulic fluid leaks.

16. Lubricate the loader.



17. Check the condition of the battery and cables.




18. Inspect the air cleaner for damage or leaks. Check the condition of the element.




19. Check the electrical charging system.



20. Check tires for wear and pressure. Check tracks for wear and tension. Use only approved tires or tracks.




21. Inspect for loose or broken parts or connections.




22. Check for any field modification not completed.




23. Operate the machine and check all functions.



24. Check for correct function of the Bobcat Interlock Control System (BICS™) before the machine is returned to the customer.




25. Check for proper function of front horn and back-up alarm (if equipped).



26. Check function or condition of all equipped options and accessories (examples: fire extinguisher, rotating beacon, lift kits, etc.).



27. Recommend to the owner that all necessary corrections be made before the machine is returned to service.



CALIFORNIA PROPOSITION 65 WARNING

Diesel engine exhaust and some of its constituents are known to the state of California to cause cancer, birth defects and other reproductive harm.



Bobcat®

SAFETY INSTRUCTIONS



Safety Alert Symbol

**This symbol with a warning statement means:
"Warning, be alert! Your safety is involved!"
Carefully read the message that follows.**



WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903

IMPORTANT

This notice identifies procedures which must be followed to avoid damage to the machine.

I-2019-0284



DANGER

The signal word DANGER on the machine and in the manuals indicates a hazardous situation which, if not avoided, will result in death or serious injury.

D-1002-1107



WARNING

The signal word WARNING on the machine and in the manuals indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

W-2044-1107

The following publications provide information on the safe use and maintenance of the Bobcat machine and attachments:

- The Delivery Report is used to assure that complete instructions have been given to the new owner and that the machine is in safe operating condition.
- The Operation & Maintenance Manual delivered with the machine or attachment contains operating information as well as routine maintenance and service procedures. It is a part of the machine and can be stored in a container provided on the machine. Replacement Operation & Maintenance Manuals can be ordered from your Bobcat dealer.
- Machine signs (decals) instruct on the safe operation and care of your Bobcat machine or attachment. The signs and their locations are shown in the Operation & Maintenance Manual. Replacement signs are available from your Bobcat dealer.
- An Operator's Handbook fastened to the operator cab. It's brief instructions are convenient to the operator. The handbook is available from your dealer in an English edition or one of many other languages. See your Bobcat dealer for more information on translated versions.
- The AEM Safety Manual delivered with the machine gives general safety information.
- The Service Manual and Parts Manual are available from your dealer for use by mechanics to do shop-type service and repair work.
- The Skid-Steer Loader Operator Training Course is available through your local dealer or at www.training.bobcat.com or www.bobcat.com. This course is intended to provide rules and practices of correct operation of the Skid-Steer Loader. The course is available in English and Spanish versions.
- Service Safety Training Courses are available from your Bobcat dealer or at www.training.bobcat.com or www.bobcat.com. They provide information for safe and correct service procedures.
- The Skid-Steer Loader Safety Video is available from your Bobcat dealer or at www.training.bobcat.com or www.bobcat.com.

SAFETY INSTRUCTIONS (CONT'D)

The dealer and owner / operator review the recommended uses of the product when delivered. If the owner / operator will be using the machine for a different application(s) he or she must ask the dealer for recommendations on the new use.



Cutting or drilling concrete containing sand or rock containing quartz may result in exposure to silica dust. Do not exceed Permissible Exposure Limits (PEL) to silica dust as determined by OSHA or other job site Rules and Regulations. Use a respirator, water spray or other means to control dust. Silica dust can cause lung disease and is known to the state of California to cause cancer.

Call Before You Dig

Dial 811 (USA Only)
1-888-258-0808 (USA & Canada)

When you call, you will be directed to a location in your state / province, or city for information about buried lines (telephone, cable TV, water, sewer, gas, etc.).

FIRE PREVENTION



Maintenance

The machine and some attachments have components that are at high temperatures under normal operating conditions. The primary source of high temperatures is the engine and exhaust system. The electrical system, if damaged or incorrectly maintained, can be a source of arcs or sparks.

Flammable debris (leaves, straw, etc.) must be removed regularly. If flammable debris is allowed to accumulate, it can cause a fire hazard. Clean often to avoid this accumulation. Flammable debris in the engine compartment is a potential fire hazard.

The operator's area, engine compartment and engine cooling system must be inspected every day and cleaned if necessary to prevent fire hazards and overheating.

All fuels, most lubricants and some coolants mixtures are flammable. Flammable fluids that are leaking or spilled onto hot surfaces or onto electrical components can cause a fire.

Operation

Do not use the machine where exhaust, arcs, sparks or hot components can contact flammable material, explosive dust or gases.

Electrical



Check all electrical wiring and connections for damage. Keep the battery terminals clean and tight. Repair or replace any damaged part or wires that are loose or frayed.

Battery gas can explode and cause serious injury. Use the procedure in the Operation & Maintenance Manual for connecting the battery and for jump starting. Do not jump start or charge a frozen or damaged battery. Keep any open flames or sparks away from batteries. Do not smoke in battery charging area.

Hydraulic System

Check hydraulic tubes, hoses and fittings for damage and leakage. Never use open flame or bare skin to check for leaks. Hydraulic tubes and hoses must be properly routed and have adequate support and secure clamps. Tighten or replace any parts that show leakage.

Always clean fluid spills. Do not use gasoline or diesel fuel for cleaning parts. Use commercial nonflammable solvents.

Fueling



Stop the engine and let it cool before adding fuel. No smoking! Do not refuel a machine near open flames or sparks. Fill the fuel tank outdoors.

Starting

Do not use ether or starting fluids on any engine that has glow plugs or air intake heater. These starting aids can cause explosion and injure you or bystanders.

Use the procedure in the Operation & Maintenance Manual for connecting the battery and for jump starting.

Spark Arrestor Exhaust System

The spark arrestor exhaust system is designed to control the emission of hot particles from the engine and exhaust system, but the muffler and the exhaust gases are still hot.

Check the spark arrestor exhaust system regularly to make sure it is maintained and working properly. Use the procedure in the Operation & Maintenance Manual for cleaning the spark arrestor muffler (if equipped).

FIRE PREVENTION (CONT'D)


Welding And Grinding

Always clean the machine and attachment, disconnect the battery, and disconnect the wiring from the Bobcat controllers before welding. Cover rubber hoses, battery and all other flammable parts. Keep a fire extinguisher near the machine when welding.

Have good ventilation when grinding or welding painted parts. Wear dust mask when grinding painted parts. Toxic dust or gas can be produced.

Dust generated from repairing nonmetallic parts such as hoods, fenders or covers can be flammable or explosive. Repair such components in a well ventilated area away from open flames or sparks.

Fire Extinguishers




Know where fire extinguishers and first aid kits are located and how to use them. Inspect the fire extinguisher and service the fire extinguisher regularly. Obey the recommendations on the instructions plate.

SERIAL NUMBER LOCATIONS

Always use the serial number of the loader when requesting service information or when ordering parts. Early or later models (identification made by serial number) may use different parts, or it may be necessary to use a different procedure in doing a specific service operation.

Loader Serial Number

Figure 1



The loader serial number plate is located on the outside of the loader frame **[Figure 1]**.

Explanation of loader Serial Number:

XXXX	XXXXXX
Model 1.-Model / Engine Combination	Model 2.-Production Sequence (Series)

1. The four digit Model / Engine Combination Module number identifies the model number and engine combination.
2. The five digit Production Sequence Number identifies the order which the loader is produced.

Engine Serial Number

Figure 2






Figure 3



The engine serial number is located on the valve cover at the right side of the engine **[Figure 2]**. There is also an extra S/N tag attached to the engine **[Figure 3]**.

DELIVERY REPORT


Figure 4



The image shows a 'DELIVERY REPORT' form. At the top left, there is a section with several horizontal lines for signatures or initials. To its right is a box labeled 'DELIVERY REPORT' containing more horizontal lines. Below these sections is a box labeled 'WARNING' containing several horizontal lines. To the right of the 'WARNING' box is a large area with many horizontal lines for detailed reporting. At the bottom right of the form is a small box containing the code 'B-16315'.

The Delivery Report must be filled out by the dealer and signed by the owner or operator when the Bobcat loader is delivered. An explanation of the form must be given to the owner. Make sure it is filled out completely [Figure 4].

BOBCAT LOADER IDENTIFICATION



B-15982
B-16983

◆ OPTIONAL OR FIELD ACCESSORY (Not Standard Equipment)

† BUCKET - Several different buckets and other attachments are available for the Bobcat loader.

● ROPS, FOPS - Roll Over Protective Structure, per SAE J1040 and ISO 3471, and Falling Object Protective Structure per SAE J1043 and ISO 3449, Level I. Level II is available. The Bobcat loader is base-equipped with a standard operator cab as shown. Extra insulated cab is available as an option (Reduced noise level).



Bobcat®

SAFETY AND MAINTENANCE

SAFETY & MAINTENANCE

AIR CLEANER SERVICE	10-80-1
Replacing Filter Element	10-80-1
BOB-TACH	10-140-1
Inspection And Maintenance	10-140-1
ENGINE COOLING SYSTEM.....	10-90-1
Cleaning The Cooling System	10-90-1
ENGINE LUBRICATION SYSTEM	10-110-1
Checking Engine Oil	10-110-1
Replacing Oil And Filter.....	10-110-2
FAN GEARBOX.....	10-130-1
Checking And Adding Oil.....	10-130-1
FUEL SYSTEM.....	10-100-1
Filling the Fuel Tank.....	10-100-1
Fuel Filter.....	10-100-2
Fuel Lift Pump Strainer	10-100-3
Fuel Specifications.....	10-100-1
Removing Air From The Fuel System	10-100-3
HYDRAULIC / HYDROSTATIC SYSTEM	10-120-1
Checking And Adding Fluid	10-120-1
Hydraulic / Hydrostatic Filter Replacement	10-120-1
Replacing Hydraulic Fluid (518911353 & Below).....	10-120-2
Replacing Hydraulic Fluid (518911354 & Above)	10-120-4
LIFT ARM SUPPORT DEVICE.....	10-20-1
Disengaging The Lift Arm Support Device.....	10-20-3
Engaging The Lift Arm Support Device	10-20-1
LIFTING AND BLOCKING THE LOADER	10-10-1
Procedure	10-10-1
LUBRICATING THE LOADER	10-150-1
Procedure	10-150-1
OPERATOR CAB	10-30-1
Emergency Exit	10-30-3
Lowering the Operator Cab	10-30-2
Raising The Operator Cab.....	10-30-1
POWER BOB-TACH (OPTION)	10-141-1
Inspection And Maintenance	10-141-1

Continued On Next Page

SAFETY & MAINTENANCE (CONT'D)

REMOTE START.....	10-60-1
Procedure	10-60-4
Procedure For Loader With Attachments Control Harness	10-60-2
Procedure For Loader Without Attachments Control Harness...	10-60-1
SERVICE SCHEDULE	10-70-1
Chart	10-70-1
TOWING THE LOADER	10-50-1
Procedure (S/N 517515079, 516815098, 518916041 and Above).....	10-50-3
Procedure (S/N 517515079, 516815098, 518916041 And Below).....	10-50-1
TRANSPORTING THE BOBCAT LOADER	10-40-1
Procedure	10-40-1
Stopping The Bobcat Loader	10-40-1

LIFTING AND BLOCKING THE LOADER



WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2408-0801

Figure 10-10-1



B-7023

Read the Removal & Installation, Disassembly & Assembly, etc. completely to become familiar with the procedure before beginning [Figure 10-10-1].

Procedure

Always park the loader on a level surface.



WARNING

Put jackstands under the front axles and rear corners of the frame before running the engine for service. Failure to use jackstands can allow the machine to fall or move and cause injury or death.

W-2017-0286

Figure 10-10-2




P-24728

Put floor jack under the rear of the loader [Figure 10-10-2]

Lift the rear of the loader and install jackstands [Figure 10-10-2].

Figure 10-10-3



N-18267

Put the floor jack under the front of the loader [Figure 10-10-3].

Lift the front of the loader and put jackstands under the loader frame [Figure 10-10-3].

NOTE: Make sure the jackstands do not touch the tracks. Make sure tracks clear floor or any obstacles.



Bobcat®

LIFT ARM SUPPORT DEVICE

Maintenance and service work can be done with the lift arms lowered. If the lift arms are raised, use the following procedures to engage and disengage an approved lift arm support device:



WARNING

Never work on a machine with the lift arms up unless the lift arms are secured by an approved lift arm support device. Failure to use an approved lift arm support device can allow the lift arms or attachment to fall and cause injury or death.

W-2059-0598




WARNING

Repair the support device if damaged or if parts are missing. Using a damaged support device or with missing parts can cause lift arms or boom to fall causing serious injury or death.

W-2271-1007


Engaging The Lift Arm Support Device

Figure 10-20-1



Install jackstands under the rear of the loader frame. Disconnect the spring from the lift arm support device retaining pin (Item 1) [Figure 10-20-1]. Support the lift arm support device (Item 2) [Figure 10-20-1] with your hand and remove the retaining pin.

Figure 10-20-2




Lower the lift arm support device on top of the lift cylinder. Hook the free end of the spring (Item 1) [Figure 10-20-2] to the lift arm support device so there will be no interference with the support device engagement.

With the operator in the seat, seat belt fastened and seat bar lowered, start the engine.

LIFT ARM SUPPORT DEVICE (CONT'D)

Engaging The Lift Arm Support Device (Cont'd)




AVOID DEATH

- Disconnecting or loosening any hydraulic tubeline, hose, fitting, component or a part failure can cause lift arms to drop.
- Keep out of this area when lift arms are raised unless supported by an approved lift arm support. Replace if damaged.

D-1009-0409

Figure 10-20-3



Raise the lift arms, until the lift arm support device drops onto the lift cylinder rod (Inset) [Figure 10-20-3].


Lower the lift arms slowly until the support device is held between the lift arm and the lift cylinder. Stop the engine. Raise the seat bar and move pedals until both pedals lock.

Install pin (Item 1) [Figure 10-20-3] into the rear of the lift arm support device below the cylinder rod.

LIFT ARM SUPPORT DEVICE (CONT'D)

Disengaging The Lift Arm Support Device

Figure 10-20-4



Raise the support device into storage position and insert pin through lift arm support device and bracket. (See (Item 1) [Figure 10-20-1 on Page 10-20-1])

Connect spring to pin. (See (Item 1) [Figure 10-20-1 on Page 10-20-1])

Remove the pin from the lift arm support device.

Connect the spring (Item 1) [Figure 10-20-4] from the lift arm support device to the bracket below the lift arms.

With the operator in the seat, seat belt fastened and seat bar lowered, start the engine.

Figure 10-20-5



Raise the lift arms a small amount and the spring will lift the support device off the lift cylinder rod [Figure 10-20-5]. Lower the lift arms. Stop the engine.

Raise the seat bar and move pedals until both pedals lock.

Disconnect the spring from the bracket.



Bobcat®

OPERATOR CAB

The Bobcat loader has an operator cab (ROPS and FOPS) as standard equipment to protect the operator from rollover and falling objects. Check with your dealer if the operator cab has been damaged. The seat belt must be worn for roll over protection.

ROPS / FOPS - Roll Over Protective Structure per SAE J1040 and ISO 3471, and Falling Object Protective Structure per SAE J1043 and ISO 3449, Level I. Level II is available.

Level I - Protection from falling bricks, small concrete blocks, and hand tools encountered in operations such as highway maintenance, landscaping, and other construction site services.

Level II - Protection from falling trees, rocks; for machines involved in site clearing, overhead demolition or forestry.

Raising The Operator Cab

Always stop the engine before raising or lowering the cab.

Stop the loader on a level surface. Lower the lift arms. If the lift arms must be up while raising the operator cab, install the lift arm support device. (See LIFT ARM SUPPORT DEVICE on Page 10-20-1.)

Figure 10-30-1



Loosen the nut (both sides) at the front corners of the operator cab [Figure 10-30-1].

Figure 10-30-2



Remove the nuts and plates [Figure 10-30-2] (both sides).

OPERATOR CAB (CONT'D)

Raising The Operator Cab (Cont'd)

Figure 10-30-3



Lift on the grab handle and bottom of the operator cab slowly until the cab is all the way up and the latching mechanism engages [Figure 10-30-3].

Advanced Control System (ACS) And Advance Hand Control (AHC)


! WARNING

Never modify operator cab by welding, grinding, drilling holes or adding attachments unless instructed to do so by Bobcat Company. Changes to the cab can cause loss of operator protection from rollover and result in injury or death.

W-2217-0100

Lowering the Operator Cab

Figure 10-30-4



Always stop the engine before raising or lowering the cab.

NOTE: Make sure the seat bar is fully raised or lowered when lowering the cab. Always use the grab handles to lower the cab.

Pull down on the bottom of the operator cab until it stops at the latching mechanism.

Release the latching mechanism (Inset) [Figure 10-30-4] and pull the cab all the way down.

! WARNING


**UNEXPECTED LOADER, LIFT ARM OR ATTACHMENT
MOVEMENT CAUSED BY CAB CONTACT WITH
CONTROLS CAN CAUSE SERIOUS
INJURY OR DEATH**

- **STOP ENGINE before raising or lowering cab.**

W-2758-0908

OPERATOR CAB (CONT'D)

Lowering The Operator Cab (Cont'd)




AVOID DEATH

- Disconnecting or loosening any hydraulic tubeline, hose, fitting, component or a part failure can cause lift arms to drop.
- Keep out of this area when lift arms are raised unless supported by an approved lift arm support. Replace if damaged.

D-1009-0409


Figure 10-30-5



Install the plate and nut (both sides) [Figure 10-30-5].

Tighten the nuts to 40 - 50 ft.-lb. (54 - 68 N•m) torque.

Figure 10-30-6



Emergency Exit

Figure 10-30-7



The front opening on the operator cab and rear window provide exits.

Rear Window (If Equipped)

Pull on the tag on the top of the rear window to remove the rubber cord [Figure 10-30-7].


Figure 10-30-8



Push the rear window out of the rear of the operator cab.

Exit through the rear of the operator cab [Figure 10-30-8].

Figure 10-30-9



FRONT DOOR (If Equipped)

NOTE: When an Operator Cab Enclosure Kit is installed, the window of the front door can be used as an emergency exit [Figure 10-30-9].


NOTE: When the special applications kit is installed, the front door cannot be used for an emergency exit.

Pull the plastic loop at the top of the window in the front door to remove the rubber cord [Figure 10-30-9].

Sample of manual. Download All 867 pages at:

<https://www.arepairmanual.com/downloads/2010-bobcat-t200-compact-track-loader-service-repair-workshop-manual/>

T220 Bobcat Loader
Service Manual



Push the window out with your foot [Figure 10-30-10] at any corner of the window.

Exit through the front door.