



Bobcat®

Service Manual

Angle Broom

S/N 068700101 & Above

S/N 797301001 & Above

S/N 690100101 & Above


S/N 055000101 & Above

S/N 231000101 & Above

S/N 231311101 & Above

S/N 231411101 & Above

S/N 700000101 & Above



Product: Bobcat Angle Broom Service Repair Workshop Manual

Full Download: <https://www.arepairmanual.com/downloads/bobcat-angle-broom-service-repair-workshop-manual-2/>

Sample of manual. Download All 190 pages at:

<https://www.arepairmanual.com/downloads/bobcat-angle-broom-service-repair-workshop-manual-2/>

MAINTENANCE SAFETY



WARNING


Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0807



Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.

CORRECT



P-90216

-  Never service attachments / implements without instructions. See Operation & Maintenance Manual and Attachment / Implement Service Manual.
-  Cleaning and maintenance are required daily.
-  Never service or adjust attachment / implement with the engine running unless instructed to do so in manual.
-  Always lower the attachment / implement to the ground before lubricating or servicing.
-  Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate skin or eyes.
-  Stop, cool and clean engine of flammable materials before checking fluids.
-  Keep body, loose objects and clothing away from moving parts, electrical contacts, hot parts and exhaust.
-  Safety glasses are needed for eye protection from electrical arcs, battery acid, compressed springs, fluids under pressure and flying debris or when tools are used. Use eye protection approved for type of welding.



Bobcat®

CONTENTS

SAFETY & MAINTENANCE	10-01
HYDRAULIC SYSTEM	20-01
MAINFRAME	30-01
SPECIFICATIONS	SPEC-01
ALPHABETICAL INDEX	INDEX-01



FOREWORD

SERIAL NUMBER LOCATION	1-7
ATTACHMENT IDENTIFICATION	1-8
(S/N 068700101 & Above)	1-8
(S/N 797301001 & Above)	1-9
(S/N 690100101 & Above)	1-10
(S/N 055000101 & Above), (S/N 231000101 & Above), (S/N 231311101 & Above) And (S/N 231411101 & Above)	1-11
(S/N 700000101 & Above)	1-12



SERIAL NUMBER LOCATION

Figure 1




Figure 2




Figure 3






Figure 4




Always use the serial number of the machine when requesting service information or when ordering parts. Early or later models (identification made by serial number) may use different parts, or it may be necessary to use a different procedure in doing a specific service operation [Figure 1], [Figure 2], [Figure 3] and [Figure 4].

ATTACHMENT IDENTIFICATION

(S/N 068700101 & Above)




P-96014



P-96015


ATTACHMENT IDENTIFICATION (CONT'D)

(S/N 797301001 & Above)



ATTACHMENT IDENTIFICATION (CONT'D)



(S/N 690100101 & Above)



P-94999



ATTACHMENT IDENTIFICATION (CONT'D)

(S/N 055000101 & Above), (S/N 231000101 & Above), (S/N 231311101 & Above) And (S/N 231411101 & Above)



ATTACHMENT IDENTIFICATION (CONT'D)

(S/N 700000101 & Above)



SAFETY & MAINTENANCE

LUBRICATION	10-10-1
Lubrication Points (S/N 797301001 & Above)	10-10-1
Lubrication Points (S/N 068700101 & Above)	10-10-2
Lubrication Points (S/N 690100101 & Above)	10-10-3
Lubrication Points (S/N 055000101 & Above), (S/N 231000101 & Above), (S/N 231311101 & Above) And (S/N 231411101 & Above)	10-10-4
Lubrication Points (S/N 700000101 & Above)	10-10-4
DAILY INSPECTION	10-20-1
Attachment Mounting Frame	10-20-1
Broom Mount Inspection	10-20-1
Bob-Tach	10-20-1
TROUBLESHOOTING	10-30-1
Chart	10-30-1



LUBRICATION

Always use a good quality lithium base multipurpose grease when lubricating the angle broom. Apply the lubricant until extra grease shows.

IMPORTANT

Fluid such as engine oil, hydraulic fluid, coolants, grease, etc. must be disposed of in an environmentally safe manner. Some regulations require that certain spills and leaks on the ground must be cleaned in a specific manner. See local, state and federal regulations for the correct disposal.


I-2067-0499

Lubrication Points (S/N 797301001 & Above)

Lubricate the following grease fittings **EVERY 7-10 HOURS**:




Figure 10-10-1



There are eleven grease fittings (Item 1) [Figure 10-10-1].

Figure 10-10-2



The rear caster wheels each have two fittings (Item 1) [Figure 10-10-2]. The height adjustment cranks need only occasional lubrication.


LUBRICATION (CONT'D)

Lubrication Points (S/N 068700101 & Above)

Lubricate the following grease fittings **EVERY 8 - 10 HOURS**:




Figure 10-10-3




The front wheel bushings (2 fittings) (Item 1) [Figure 10-10-3].

Figure 10-10-4




The bolster (1 fitting) (Item 1) [Figure 10-10-4].

Figure 10-10-5



The caster pivots (2 fittings) (Item 1) [Figure 10-10-5].

Figure 10-10-6




The angle pivot (2 fittings) (Item 1) [Figure 10-10-6].

LUBRICATION (CONT'D)

Lubrication Points (S/N 068700101 & Above) (Cont'd)

Figure 10-10-7




The rear broom pivot (1 fitting) (Item 1) [Figure 10-10-7].

Lubrication Points (S/N 690100101 & Above)

Lubricate the following grease fittings **EVERY 20 HOURS**:




Figure 10-10-8



The broom pivot (1 fitting) (Item 1) [Figure 10-10-8].

Figure 10-10-9



The oscillating pivots (2 fittings) (Item 1) [Figure 10-10-9].


LUBRICATION (CONT'D)

Lubrication Points (S/N 055000101 & Above), (S/N 231000101 & Above), (S/N 231311101 & Above) And (S/N 231411101 & Above)

Lubricate the following grease fittings EVERY 20 HOURS:




Figure 10-10-10



- 1. Broom Pivot (Item 1) [Figure 10-10-10].
- 2. Cylinder Rod End (Item 2) [Figure 10-10-10].

Figure 10-10-11




- 3. Cylinder Base End (Item 1) [Figure 10-10-11].

Lubrication Points (S/N 700000101 & Above)

Lubricate the following grease fitting EVERY 200 HOURS:



Figure 10-10-12




- 1. Broom Pivot Bushing (Item 1) [Figure 10-10-12].

DAILY INSPECTION

Attachment Mounting Frame

Broom Mount Inspection

Figure 10-20-1



Inspect the Bob-Tach wedge mounts (Item 1), mounting flange (Item 2) [Figure 10-20-1] and all welds on the Angle Broom mount for wear and damage each time the Angle Broom is removed from the loader.

Look for cracked welds. Contact your bobcat dealer for repair or replacement parts.

Bob-Tach

Hand Lever Bob-Tach


WARNING

AVOID INJURY OR DEATH

The Bob-Tach wedges must extend through the holes in the attachment mounting frame. Levers must be fully down and locked. Failure to secure wedges can allow attachment to come off.

W-2715-0208


Figure 10-20-2



Push down on the Bob-Tach levers until they are fully engaged in the locked position [Figure 10-20-2] (wedges fully extended through the attachment mounting frame holes).

The levers and wedges must move freely [Figure 10-20-2].

Figure 10-20-3



The wedges must extend through the holes in the attachment mounting frame, securely fastening the attachment to the Bob-Tach [Figure 10-20-3].

NOTE: If the wedge does not contact the lower edge of the hole, the attachment will be loose and can come off the Bob-Tach.

Inspect the mounting frame on the attachment. (See the machine's Operation and Maintenance Manual for inspecting the Bob-Tach). Replace any parts that are damaged, bent or missing. Keep all fasteners tight. Look for cracked welds. Contact your Bobcat dealer for repair or replacement parts.

Lubricate the wedges. (See the machine's Operation & Maintenance Manual for the correct procedure.)

Bob-Tach (Cont'd)

Power Bob-Tach



AVOID INJURY OR DEATH

The Bob-Tach wedges must extend through the holes in the attachment mounting frame. Levers must be fully down and locked. Failure to secure wedges can allow attachment to come off.

W-2715-0208

Figure 10-20-4




Figure 10-20-5






Figure 10-20-6



Push and hold the BOB-TACH “WEDGES DOWN” switch (Item 1) [Figure 10-20-4] or [Figure 10-20-5] until the levers are fully engaged in the locked position [Figure 10-20-6] (wedges fully extended through the attachment mounting frame holes).

Figure 10-20-7



The wedges must extend through the holes in the attachment mounting frame, securely fastening the attachment to the Bob-Tach [Figure 10-20-7].

NOTE: If the wedge does not contact the lower edge of the hole, the attachment will be loose and can come off the Bob-Tach.

Inspect the mounting frame on the attachment. (See the machine's Operation and Maintenance Manual for inspecting the Bob-Tach). Replace any parts that are damaged, bent or missing. Keep all fasteners tight. Look for cracked welds. Contact your Bobcat dealer for repair or replacement parts.

Lubricate the wedges. (See the machine's Operation & Maintenance Manual for the correct procedure.)

Chart

**WARNING**

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0199

If the attachment is not working correctly, check the hydraulic system of the loader thoroughly before making any repairs on the attachment. Attachment problems can be affected by a hydraulic system that is not operating to specifications.

If the loader operation is found to be correct, use the following troubleshooting chart to locate and correct problems with the attachment.

PROBLEM	CAUSE	CORRECTION
Broom will not rotate.	Auxiliary hydraulic lever not engaged.	Engage auxiliary hydraulic lever.
	Broken drive chain.	Repair/replace chain.
Broom bristles wear quickly.	Too much down pressure being applied to the broom.	Use the correct amount of down pressure needed for the conditions present.
Broom operation not effective.	Broom bristles worn to minimum length.	Replace broom bristle sections.



Bobcat®

HYDRAULIC SYSTEM

HYDRAULIC CYLINDER (S/N 055000101 & ABOVE), (S/N 231000101 & ABOVE), (S/N 231311101 & ABOVE) AND (S/N 231411101 & ABOVE)	20-10-1
Removal And Installation	20-10-1
Parts Identification	20-10-3
Disassembly	20-10-4
Assembly	20-10-6
Cylinders With Cushioned Piston:	20-10-9
Torque Specifications	20-10-12
Torque Chart	20-10-12
 HYDRAULIC CONTROL VALVE (S/N 055000101 & ABOVE), (S/N 231000101 & ABOVE), (S/N 231311101 & ABOVE) AND (S/N 231411101 & ABOVE)	20-20-1
Removal And Installation	20-20-1
Parts Identification	20-20-2
Disassembly	20-20-3
Assembly	20-20-6
 HYDRAULIC MOTOR (S/N 797301001 & ABOVE)	20-30-1
Parts Identification	20-30-1
Disassembly And Assembly	20-30-2
Inspection	20-30-6
 HYDRAULIC MOTOR (S/N 690100101-690100899) AND (S/N 068700101 & ABOVE)	20-31-1
Removal and Installation	20-31-1
Parts Identification (S/N 690100101-690100899)	20-31-2
Parts Identification (S/N 068700101 & Above)	20-31-3
Disassembly And Assembly	20-31-4
Inspection	20-31-9
 HYDRAULIC MOTOR (S/N 690100900 & ABOVE)	20-32-1
Removal and Installation	20-32-1
Parts Identification	20-32-2
Disassembly and Assembly	20-32-3
Inspection	20-32-7
Timing the Hydraulic Motor	20-32-8
 HYDRAULIC MOTOR (S/N 055000101 & ABOVE), (S/N 231000101 & ABOVE),(S/N 231311101 & ABOVE) AND (S/N 231411101 & ABOVE)	20-33-1
Removal And Installation	20-33-1
Parts Identification	20-33-2
Disassembly	20-33-3
Inspection	20-33-6
Assembly	20-33-7

HYDRAULIC MOTOR (S/N 700000101 & ABOVE) 20-34-1

Removal And Installation 20-34-1

Parts Identification 20-34-2

Disassembly 20-34-3

Assembly 20-34-6

HYDRAULIC MOTOR (S/N 231314993 & ABOVE, S/N 231413710 & ABOVE) 20-35-1

Removal and Installation 20-35-1

Disassembly 20-35-2

Inspection 20-35-3

Parts Identification 20-35-4


Assembly 20-35-5

**HYDRAULIC CYLINDER (S/N 055000101 & ABOVE),
(S/N 231000101 & ABOVE), (S/N 231311101 & ABOVE)
AND (S/N 231411101 & ABOVE)**

Removal And Installation


Remove the mounting frame pivot springs. (See Removal And Installation on Page 30-60-1.)

Figure 20-10-1



Mark and remove the hoses (Item 1) [Figure 20-10-1] at the control valve.


Figure 20-10-2



Remove the retaining bolt and nut (Item 1) [Figure 20-10-2].


Installation: Tighten the bolt to 25 - 28 ft.-lb. (34 - 38 N•m) torque.

Figure 20-10-3



Remove the pin (Item 1) [Figure 20-10-3] from the rod end of the cylinder.

Figure 20-10-4




Remove the retaining bolt and nut (Item 1) [Figure 20-10-4].

Installation: Tighten the bolt to 25 - 28 ft.-lb. (34 - 38 N•m) torque.

HYDRAULIC CYLINDER (S/N 055000101 & ABOVE),
(S/N 231000101 & ABOVE), (S/N 231311101 & ABOVE)
AND (S/N 231411101 & ABOVE) (CONT'D)

Removal And Installation (Cont'd)

Figure 20-10-5




Remove the pin (Item 1) [Figure 20-10-5] from the base end of the cylinder.

Remove the cylinder.

HYDRAULIC CYLINDER (S/N 055000101 & ABOVE), (S/N 231000101 & ABOVE), (S/N 231311101 & ABOVE) AND (S/N 231411101 & ABOVE) (CONT'D)

Parts Identification

1. Grease Fitting
2. Plug
3. O-ring
4. Nut
5. O-ring
6. Ring
7. Piston
8. O-ring
9. Back-up Ring
10. Rod Seal
11. O-ring
12. Rod Seal
13. Head
14. Rod



B-05435

Disassembly

Use the following tools to disassemble the hydraulic cylinder:


MEL1074 O-Ring Seal Hook
MEL1075 Adjustable Gland Nut Wrench
OEM 6194 Cylinder Wrench

NOTE: The drawings may not show the cylinder exactly as it appears, but the procedure is correct for all the cylinders.

Put the base end of the hydraulic cylinder in a drain pan. Move the rod in and out to remove the fluid from the cylinder. Move the rod slowly so the fluid will go directly into the drain pan.


Put the base end of the cylinder in a vise.

Figure 20-10-6



Use the adjustable gland nut wrench (OEM 6194) to loosen the head [Figure 20-10-6].

Figure 20-10-7




Remove the rod assembly from the cylinder case [Figure 20-10-7].

Remove the cylinder case from the vise

Put the rod end in the vise

Figure 20-10-8



Remove the nut from the piston end of the rod [Figure 20-10-8].