

Product: 2011 Bobcat S100 Skid-Steer Loader Service Repair Workshop Manual(S/N A2G711001 & Above,/N A89L11001 & Above)

Full Download: <https://www.arepairmanual.com/downloads/2011-bobcat-s100-skid-steer-loader-service-repair-workshop-manuals-n-a2g711001-and-above-n-a89l11001-above/>



**Bobcat**®

---


# Service Manual

## S100 Skid-Steer Loader

---

**S/N A2G711001 & Above**

**S/N A89L11001 & Above**



**EQUIPPED WITH**

**BOBCAT INTERLOCK**

**CONTROL SYSTEM (RIGST™)** 502 pages at:

<https://www.arepairmanual.com/downloads/2011-bobcat-s100-skid-steer-loader-service-repair-workshop-manuals-n-a2g711001-and-above-n-a89l11001-above/>

6904926 (4-11)

Printed in U.S.A.



© Bobcat Company 2011

Product: 2011 Bobcat S100 Skid-Steer Loader Service Repair Workshop Manual(S/N A2G711001 & Above,/N A89L11001 & Above)

Full Download: <https://www.arepairmanual.com/downloads/2011-bobcat-s100-skid-steer-loader-service-repair-workshop-manuals-n-a2g711001-and-above-n-a89l11001-above/>

Sample of manual. Download All 502 pages at:

<https://www.arepairmanual.com/downloads/2011-bobcat-s100-skid-steer-loader-service-repair-workshop-manuals-n-a2g711001-and-above-n-a89l11001-above/>

# MAINTENANCE SAFETY



## WARNING


Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903




**Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.**

### CORRECT



B-10731a

### CORRECT



B-15590


### CORRECT



B-15591

⚠ Never service the Bobcat Skid-Steer Loader without instructions.

### WRONG



B-15592

⚠ Have good ventilation when welding or grinding painted parts.  
⚠ Wear dust mask when grinding painted parts. Toxic dust and gas can be produced.  
⚠ Avoid exhaust fume leaks which can kill without warning. Exhaust system must be tightly sealed.


### WRONG



B-15593

⚠ Disconnecting or loosening any hydraulic tubeline, hose, fitting, component or a part failure can cause lift arms to drop. Do not go under lift arms when raised unless supported by an approved lift arm support device. Replace it if damaged.


### WRONG



B-15599

⚠ Never work on loader with lift arms up unless lift arms are held by an approved lift arm support device. Replace if damaged.  
⚠ Never modify equipment or add attachments not approved by Bobcat Company.

### WRONG



B-15600

⚠ Stop, cool and clean engine of flammable materials before checking fluids.  
⚠ Never service or adjust loader with the engine running unless instructed to do so in the manual.  
⚠ Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate the skin or eyes.  
⚠ Never fill fuel tank with engine running, while smoking or when near open flame.

### WRONG



B-15601

⚠ Keep body, jewelry and clothing away from moving parts, electrical contact, hot parts and exhaust.  
⚠ Wear eye protection to guard from battery acid, compressed springs, fluids under pressure and flying debris when engines are running or tools are used. Use eye protection approved for type of welding.  
⚠ Keep rear door closed except for service. Close and latch door before operating the loader.

### WRONG



B-6589

⚠ Lead-acid batteries produce flammable and explosive gases.  
⚠ Keep arcs, sparks, flames and lighted tobacco away from batteries.  
⚠ Batteries contain acid which burns eyes or skin on contact. Wear protective clothing. If acid contacts body, flush well with water. For eye contact flush well and get immediate medical attention.

Maintenance procedures which are given in the Operation & Maintenance Manual can be performed by the owner/operator without any specific technical training. Maintenance procedures which are **not** in the Operation & Maintenance Manual must be performed **ONLY BY QUALIFIED BOBCAT SERVICE PERSONNEL**. Always use genuine Bobcat replacement parts. The Service Safety Training Course is available from your Bobcat dealer.

MSW08-0805



**Bobcat**®

## ALPHABETICAL INDEX

AIR CLEANER .....	70-01	HYDROSTATIC MOTOR .....	30-01
AIR CLEANER SERVICE .....	10-01	HYDROSTATIC PUMP .....	30-01
ALTERNATOR .....	60-01	HYDROSTATIC SYSTEM INFORMATION.....	30-01
BACK-UP ALARM SYSTEM.....	60-01	INSTRUMENT PANELS .....	60-01
BATTERY.....	60-01		
BOBCAT CONTROLLER (MAIN).....	60-01	LIFT ARMS .....	50-01
BOBCAT INTERLOCK CONTROL SYSTEM (BICS) .....	60-01	LIFT ARM BYPASS CONTROL VALVE .....	20-01
BOB-TACH (HAND LEVER) .....	10-01, 50-01	LIFT ARM SUPPORT DEVICE.....	10-01
BRAKE.....	40-01	LIFTING AND BLOCKING THE LOADER .....	10-01
BUCKET POSITION VALVE .....	20-01	LIGHTS.....	60-01
		S100 LOADER SPECIFICATIONS.....	SPEC-01
CAMSHAFT AND TIMING GEARS.....	70-01	LOADER STORAGE AND RETURN TO SERVICE	10-01
CHAINCASE .....	40-01	LUBRICATING THE LOADER .....	10-01
CHARGE PRESSURE .....	30-01	LUBRICATION SYSTEM .....	70-01
CONTROL HANDLE / LEVER .....	50-01		
CONTROL PANEL.....	50-01	MAIN RELIEF VALVE .....	20-01
CONTROL PEDALS AND LINKAGE .....	50-01	MAINTENANCE CLOCK .....	60-01
CONVERSIONS .....	SPEC-01	MUFFLER.....	70-01
CRANKSHAFT AND PISTONS .....	70-01		
CYLINDER (LIFT) .....	20-01	OIL COOLER.....	20-01
CYLINDER (TILT) .....	20-01	OPERATOR CAB .....	10-01, 50-01
CYLINDER HEAD .....	70-01	OPERATOR SEAT.....	50-01
		OPERATOR SEAT (SUSPENSION).....	50-01
DIAGNOSTICS SERVICE CODES.....	60-01		
DRIVE BELT .....	30-01	PIVOT PINS .....	10-01
DRIVE COMPOENETS.....	40-01		
		REAR DOOR .....	50-01
ELECTRICAL SYSTEM INFORMATION .....	60-01	REAR GRILL .....	50-01
ENGINE COOLING SYSTEM.....	10-01, 70-01	REGULAR MAINTENANCE .....	80-01
ENGINE LUBRICATION SYSTEM .....	10-01	REMOTE START TOOL .....	10-01
ENGINE INFORMATION .....	70-01		
ENGINE SPEED CONTROL .....	70-01	SEAT BAR .....	50-01
		SEAT BAR SENSOR.....	60-01
FINAL DRIVE TRANSMISSION (CHAINCASE) .....	10-01	SERVICE PC (LAPTOP COMPUTER).....	60-01
FLYWHEEL RPM SENSOR.....	60-01	SERVICE SCHEDULE.....	10-01
		SPARK ARRESTOR MUFFLER.....	10-01
FLYWHEEL.....	70-01	STARTER .....	60-01
FRONT AUXILIARY HYDRAULIC COUPLERS .....	20-01	STOPPING THE ENGINE AND LEAVING THE LOADER .....	10-01
FUEL TANK.....	50-01		
		TIRE MAINTENANCE .....	10-01
HEATER COIL .....	80-01	TORQUE SPECIFICATIONS FOR BOLTS .....	SPEC-01
HEATER FAN.....	80-01	TOWING THE LOADER .....	10-01
HEATER SYSTEM.....	80-01	TRACTION LOCK .....	60-01
HEATER UNIT.....	80-01	TRANSPORTING THE LOADER ON A TRAILER ..	10-01
HEATER VALVE.....	80-01	TROUBLESHOOTING .....	80-01
HYDRAULIC CONNECTION SPECS.....	SPEC-01		
HYDRAULIC CONTROL VALVE.....	20-01	WINDOW (FRONT DOOR) .....	50-01
HYDRAULIC FLUID RESERVOIR .....	20-01	WINDOW (REAR) .....	50-01
HYDRAULIC / HYDROSTATIC FILTERS.....	20-01	WINDOW (SIDE) .....	50-01
HYDRAULIC / HYDROSTATIC FLUID SPECIFICATIONS.....	SPEC-01	WINDOW (TOP) .....	50-01
HYDRAULIC / HYDROSTATIC SYSTEM .....	10-01		
HYDRAULIC PUMP .....	20-01		
HYDRAULIC SYSTEM INFORMATION.....	20-01		



**Bobcat**®

## CONTENTS

FOREWORD.....	II
SAFETY INSTRUCTIONS .....	V
FIRE PREVENTION .....	VII
SERIAL NUMBER LOCATIONS .....	IX
DELIVERY REPORT.....	X
LOADER IDENTIFICATION .....	XI
SAFETY AND MAINTENANCE.....	10-01
HYDRAULIC SYSTEM .....	20-01
HYDROSTATIC SYSTEM.....	30-01
DRIVE SYSTEM.....	40-01
MAIN FRAME .....	50-01
ELECTRICAL SYSTEM & ANALYSIS.....	60-01
ENGINE SERVICE .....	70-01
HEATER .....	80-01
SPECIFICATIONS.....	SPEC-01

**SAFETY &  
MAINTENANCE**

**HYDRAULIC  
SYSTEM**

**HYDROSTATIC  
SYSTEM**

**DRIVE  
SYSTEM**

**MAIN FRAME**

**ELECTRICAL  
SYSTEM &  
ANALYSIS**

**ENGINE  
SERVICE**


**HEATER**



**SPECIFICATIONS**

# FOREWORD


This manual is for the Bobcat loader mechanic. It provides necessary servicing and adjustment procedures for the Bobcat loader and its component parts and systems. Refer to the Operation & Maintenance Manual for operating instructions, starting procedure, daily checks, etc.









A general inspection of the following items must be made after the loader has had service or repair:

1. Check that the ROPS/FOPS (Including side screens) is in good condition and is not modified.  

2. Check that ROPS mounting hardware is tightened and is Bobcat approved.  


3. The seat belt must be correctly installed, functional and in good condition.  

4. The seat bar must be correctly adjusted, clean and lubricated.  

5. Check lift arm support device, replace if damaged.  

6. Machine signs (decals) must be legible and in the correct location.  


7. Steering levers, hand controls and foot pedals must return to neutral (as applicable).  

8. Check for correct function of the work lights.  

9. The parking brake must function correctly.  

10. Enclosure door latches must open and close freely.  

11. Bob-Tach wedges and linkages must function correctly and be in good condition.  

12. Safety treads must be in good condition.  

13. Check for correct function of indicator lamps.  

14. Check hydraulic fluid level, engine oil level and fuel supply.  

15. Inspect for fuel, oil or hydraulic fluid leaks.  

16. Lubricate the loader.  



17. Check the condition of the battery and cables.




18. Inspect the air cleaner for damage or leaks. Check the condition of the element.




19. Check the electrical charging system.



20. Check tires for wear and pressure. Check tracks for wear and tension. Use only approved tires or tracks.




21. Inspect for loose or broken parts or connections.




22. Check for any field modification not completed.



23. Operate the machine and check all functions.




24. Check for correct function of the Bobcat Interlock Control System (BICS™) before the machine is returned to the customer.



25. Check function or condition of all equipped options and accessories (examples: back-up alarm, fire extinguisher, rotating beacon, lift kits, etc.).



26. Recommend to the owner that all necessary corrections be made before the machine is returned to service.



**CALIFORNIA  
PROPOSITION 65 WARNING**

Diesel engine exhaust and some of its constituents are known to the state of California to cause cancer, birth defects and other reproductive harm.



**Bobcat**®

FW SSL-0308 SM

## SAFETY INSTRUCTIONS



### Safety Alert Symbol

**This symbol with a warning statement means:  
"Warning, be alert! Your safety is involved!"  
Carefully read the message that follows.**



### WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903

### IMPORTANT

This notice identifies procedures which must be followed to avoid damage to the machine.

I-2019-0284



### DANGER

The signal word DANGER on the machine and in the manuals indicates a hazardous situation which, if not avoided, will result in death or serious injury.

D-1002-1107



### WARNING

The signal word WARNING on the machine and in the manuals indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

W-2044-1107

The following publications provide information on the safe use and maintenance of the Bobcat machine and attachments:

- The Delivery Report is used to assure that complete instructions have been given to the new owner and that the machine is in safe operating condition.
- The Operation & Maintenance Manual delivered with the machine or attachment contains operating information as well as routine maintenance and service procedures. It is a part of the machine and can be stored in a container provided on the machine. Replacement Operation & Maintenance Manuals can be ordered from your Bobcat dealer.
- Machine signs (decals) instruct on the safe operation and care of your Bobcat machine or attachment. The signs and their locations are shown in the Operation & Maintenance Manual. Replacement signs are available from your Bobcat dealer.
- An Operator's Handbook fastened to the operator cab. It's brief instructions are convenient to the operator. The handbook is available from your dealer in an English edition or one of many other languages. See your Bobcat dealer for more information on translated versions.
- The AEM Safety Manual delivered with the machine gives general safety information.
- The Service Manual and Parts Manual are available from your dealer for use by mechanics to do shop-type service and repair work.
- The Skid-Steer Loader Operator Training Course is available through your local dealer or at [www.training.bobcat.com](http://www.training.bobcat.com) or [www.bobcat.com](http://www.bobcat.com). This course is intended to provide rules and practices of correct operation of the Skid-Steer Loader. The course is available in English and Spanish versions.
- Service Safety Training Courses are available from your Bobcat dealer or at [www.training.bobcat.com](http://www.training.bobcat.com) or [www.bobcat.com](http://www.bobcat.com). They provide information for safe and correct service procedures.
- The Skid-Steer Loader Safety Video is available from your Bobcat dealer or at [www.training.bobcat.com](http://www.training.bobcat.com) or [www.bobcat.com](http://www.bobcat.com).

## SAFETY INSTRUCTIONS (CONT'D)

The dealer and owner / operator review the recommended uses of the product when delivered. If the owner / operator will be using the machine for a different application(s) he or she must ask the dealer for recommendations on the new use.



Cutting or drilling concrete containing sand or rock containing quartz may result in exposure to silica dust. Do not exceed Permissible Exposure Limits (PEL) to silica dust as determined by OSHA or other job site Rules and Regulations. Use a respirator, water spray or other means to control dust. Silica dust can cause lung disease and is known to the state of California to cause cancer.

## Call Before You Dig Dial 811 (USA Only) 1-888-258-0808 (USA & Canada)

When you call, you will be directed to a location in your state / province, or city for information about buried lines (telephone, cable TV, water, sewer, gas, etc.).

## FIRE PREVENTION



### Maintenance

The machine and some attachments have components that are at high temperatures under normal operating conditions. The primary source of high temperatures is the engine and exhaust system. The electrical system, if damaged or incorrectly maintained, can be a source of arcs or sparks.

Flammable debris (leaves, straw, etc.) must be removed regularly. If flammable debris is allowed to accumulate, it can cause a fire hazard. Clean often to avoid this accumulation. Flammable debris in the engine compartment is a potential fire hazard.

The operator's area, engine compartment and engine cooling system must be inspected every day and cleaned if necessary to prevent fire hazards and overheating.

All fuels, most lubricants and some coolants mixtures are flammable. Flammable fluids that are leaking or spilled onto hot surfaces or onto electrical components can cause a fire.

### Operation

Do not use the machine where exhaust, arcs, sparks or hot components can contact flammable material, explosive dust or gases.

### Electrical



Check all electrical wiring and connections for damage. Keep the battery terminals clean and tight. Repair or replace any damaged part or wires that are loose or frayed.

Battery gas can explode and cause serious injury. Use the procedure in the Operation & Maintenance Manual for connecting the battery and for jump starting. Do not jump start or charge a frozen or damaged battery. Keep any open flames or sparks away from batteries. Do not smoke in battery charging area.

### Hydraulic System

Check hydraulic tubes, hoses and fittings for damage and leakage. Never use open flame or bare skin to check for leaks. Hydraulic tubes and hoses must be properly routed and have adequate support and secure clamps. Tighten or replace any parts that show leakage.

Always clean fluid spills. Do not use gasoline or diesel fuel for cleaning parts. Use commercial nonflammable solvents.

### Fueling



Stop the engine and let it cool before adding fuel. No smoking! Do not refuel a machine near open flames or sparks. Fill the fuel tank outdoors.

### Starting

Do not use ether or starting fluids on any engine that has glow plugs. These starting aids can cause explosion and injure you or bystanders.

Use the procedure in the Operation & Maintenance Manual for connecting the battery and for jump starting.

### Spark Arrestor Exhaust System

The spark arrestor exhaust system is designed to control the emission of hot particles from the engine and exhaust system, but the muffler and the exhaust gases are still hot.

Check the spark arrestor exhaust system regularly to make sure it is maintained and working properly. Use the procedure in the Operation & Maintenance Manual for cleaning the spark arrestor muffler (if equipped).

## **FIRE PREVENTION (CONT'D)**


### **Welding And Grinding**

Always clean the machine and attachment, disconnect the battery, and disconnect the wiring from the Bobcat controllers before welding. Cover rubber hoses, battery and all other flammable parts. Keep a fire extinguisher near the machine when welding.

Have good ventilation when grinding or welding painted parts. Wear dust mask when grinding painted parts. Toxic dust or gas can be produced.

Dust generated from repairing nonmetallic parts such as hoods, fenders or covers can be flammable or explosive. Repair such components in a well ventilated area away from open flames or sparks.

### **Fire Extinguishers**




Know where fire extinguishers and first aid kits are located and how to use them. Inspect the fire extinguisher and service the fire extinguisher regularly. Obey the recommendations on the instructions plate.

## SERIAL NUMBER LOCATIONS


Always use the serial number of the loader when requesting service information or when ordering parts. Early or later models (identification made by serial number) may use different parts, or it may be necessary to use a different procedure in doing a specific service operation.

**Figure 1**



## Engine Serial Number

**Figure 2**




The engine serial number is located on top of the engine (Item 1) [Figure 2].

## Loader Serial Number

The loader serial number plate (Item 1) [Figure 1] is located inside the cab on the right-hand side.

Explanation of loader Serial Number:

XXXX XXXXX



The diagram shows the loader serial number structure. It consists of two groups of four digits each, separated by a space. A bracket under the first group of digits points to the text 'Module 1. - Model / Engine Combination'. A bracket under the second group of digits points to the text 'Module 2. - Production Sequence (Series)'.

1. The four digit Model / Engine Combination Module number identifies the model number and engine combination.
2. The five digit Production Sequence Number identifies the order which the loader is produced.


## DELIVERY REPORT

Figure 3


The image shows a 'DELIVERY REPORT' form. At the top right, it says 'DELIVERY REPORT'. To the left of this, there is a 'WARNING' section containing several lines of text. Below the 'WARNING' section is a large area with many horizontal lines for filling in information. At the bottom right of the form, the code 'B-16315' is printed.

The delivery report must be filled out by the dealer and signed by the owner or operator when the Bobcat Loader is delivered. An explanation of the form must be given to the owner. Make sure it is filled out completely [Figure 3].

## LOADER IDENTIFICATION



S0183



S0184

\* TIRES - Tires shown may not be standard. The machine is factory equipped with standard tires. Other tires are available.  
 ● ROPS, FOPS - Roll Over Protective Structure, per ISO 3471, and Falling Object Protective Structure per ISO 3449, Level I. Level II is available.

† Bucket - Several different Buckets and other Attachments are available.



**Bobcat**®

## SAFETY AND MAINTENANCE

## SAFETY AND MAINTENANCE

AIR CLEANER SERVICE .....	10-80-1
Replacing Filter Elements .....	10-80-1
BOB-TACH (HAND LEVER) .....	10-140-1
Inspection And Maintenance .....	10-140-1
ENGINE COOLING SYSTEM.....	10-90-1
Checking Level .....	10-90-1
Cleaning.....	10-90-1
Removing And Replacing Coolant.....	10-90-2
ENGINE LUBRICATION SYSTEM .....	10-110-1
Checking And Adding Engine Oil.....	10-110-1
Engine Oil Chart.....	10-110-1
Removing And Replacing Oil And Filter.....	10-110-1
FINAL DRIVE TRANSMISSION (CHAINCASE) .....	10-130-1
Checking And Adding Oil.....	10-130-1
Removing And Replacing Oil.....	10-130-1
FUEL SYSTEM .....	10-100-1
Biodiesel Blend Fuel .....	10-100-1
Filling The Fuel Tank .....	10-100-2
Fuel Filter.....	10-100-3
Fuel Specifications.....	10-100-1
Removing Air From The Fuel System .....	10-100-3
HYDRAULIC / HYDROSTATIC SYSTEM .....	10-120-1
Breather Cap .....	10-120-5
Checking And Adding Fluid .....	10-120-1
Hydraulic / Hydrostatic Fluid Chart .....	10-120-1
Removing And Replacing Case Drain Filters.....	10-120-4
Removing And Replacing Hydraulic Charge Filter.....	10-120-5
Removing And Replacing Hydraulic Fluid .....	10-120-2
Removing And Replacing Hydraulic / Hydrostatic Filter .....	10-120-3
LIFT ARM SUPPORT DEVICE .....	10-20-1
Installing.....	10-20-1
Removing.....	10-20-2

Continued On Next Page

## **SAFETY AND MAINTENANCE (CONT'D)**

LIFTING AND BLOCKING THE LOADER .....	10-10-1
Procedure .....	10-10-1
LOADER STORAGE AND RETURN TO SERVICE .....	10-190-1
Return To Service .....	10-190-1
Storage.....	10-190-1
LUBRICATING THE LOADER .....	10-150-1
Lubrication Locations.....	10-150-1
OPERATOR CAB .....	10-30-1
Cab Door Sensor.....	10-30-3
Description.....	10-30-1
Lowering .....	10-30-2
Raising.....	10-30-1
PIVOT PINS .....	10-180-1
Inspection And Maintenance .....	10-180-1
REMOTE START TOOL KIT-MEL1563.....	10-60-1
Remote Start Procedure .....	10-60-4
Remote Start Tool - MEL1563 .....	10-60-1
Service Tool Harness Communicator - MEL1566 .....	10-60-3
Service Tool Harness Control - MEL1565 .....	10-60-2
REMOTE START TOOL (SERVICE TOOL) KIT - 7003031 ..	10-61-1
Computer Service Tool Harness - 6689746.....	10-61-4
Description.....	10-61-1
Loader Service Tool Harness - 6689747 .....	10-61-3
Remote Start Procedure .....	10-61-5
Remote Start Tool (Service Tool) - 7003030 .....	10-61-2
SERVICE SCHEDULE .....	10-70-1
Chart .....	10-70-1
SPARK ARRESTOR MUFFLER .....	10-170-1
Cleaning Procedure .....	10-170-1

**Continued On Next Page**

## **SAFETY AND MAINTENANCE (CONT'D)**

STOPPING THE ENGINE AND LEAVING THE LOADER . .	10-200-1
Emergency Exit . . . . .	10-200-2
Procedure . . . . .	10-200-1
 TIRE MAINTENANCE . . . . .	10-160-1
Mounting . . . . .	10-160-1
Rotating . . . . .	10-160-1
Wheel Nuts . . . . .	10-160-1
 TOWING THE LOADER . . . . .	10-50-1
Procedure . . . . .	10-50-1
 TRANSPORTING THE LOADER ON A TRAILER . . . . .	10-40-1
Fastening . . . . .	10-40-1
Loading And Unloading . . . . .	10-40-1

**TIGHTEN ALL HARDWARE PER SIZE TO GRADE 5 TORQUE (SEE STANDARD TORQUE SPECIFICATIONS FOR BOLTS, SECTION SPEC-01) UNLESS OTHERWISE SPECIFIED.**



**Bobcat**®

## LIFTING AND BLOCKING THE LOADER

### Procedure

Figure 10-10-1




Figure 10-10-2



Put the floor jack under the rear of the loader.

Lift the rear of the loader and install jack stands [Figure 10-10-2].

Figure 10-10-3



Put the floor jack under the front of the loader [Figure 10-10-3].

Lift the front of the loader and put jack stands under the axle tubes [Figure 10-10-3].

**NOTE:** Make sure the jack stands do not touch the tires. Make sure tires clear floor or any obstacles.

Always park the loader on a level surface.



## WARNING

Put jackstands under the front axles and rear corners of the frame before running the engine for service. Failure to use jackstands can allow the machine to fall or move and cause injury or death.

W-2017-0286



**Bobcat**®

## LIFT ARM SUPPORT DEVICE

### Installing




## WARNING

Never work on a machine with the lift arms up unless the lift arms are secured by an approved lift arm support device. Failure to use an approved lift arm support device can allow the lift arms or attachment to fall and cause injury or death.

W-2059-0598

Figure 10-20-1



## WARNING

Repair the support device if damaged or if parts are missing. Using a damaged support device or with missing parts can cause lift arms or boom to fall causing serious injury or death.


W-2271-1007



## DANGER

### AVOID DEATH


- Disconnecting or loosening any hydraulic tubeline, hose, fitting, component or a part failure can cause lift arms to drop.
- Keep out of this area when lift arms are raised unless supported by an approved lift arm support. Replace if damaged.



67110 SW 6717343A-001US

Install jackstands (Item 1) [Figure 10-20-1] under the rear corners of the loader frame.

Figure 10-20-2




Disconnect the spring (Item 1) from the lift arm support device retaining pin. Support the lift arm support device (Item 2) with your hand and remove the retaining pin (Item 3) [Figure 10-20-2].

## LIFT ARM SUPPORT DEVICE (CONT'D)

### Installing (Cont'd)


Figure 10-20-3



Lower the lift arm support device to the top of the lift cylinder. Hook the free end of the spring (Item 1) [Figure 10-20-3] to the lift arm support device so the spring does not interfere with the support device engagement.

Sit in the operator seat, fasten the seat belt and lower the seat bar. Start the engine.

Figure 10-20-4



Raise the lift arms until the lift arm support device drops onto the lift cylinder rod [Figure 10-20-4].


Lower the lift arms slowly until the support device is held between the lift arm and the lift cylinder. Stop the engine. Raise the seat bar and move the pedals until both lock.

Install the retaining pin (Item 1) [Figure 10-20-4] into the rear of the lift arm support device below the cylinder rod.

### Removing

Remove the retaining pin (Item 1) [Figure 10-20-4] from the lift arm support device.


Figure 10-20-5



Connect the spring (Item 1) [Figure 10-20-5] from the lift arm support device to the bracket below the lift arms.

Sit in the operator's seat, fasten the seat belt and lower the seat bar. Start the engine.

Figure 10-20-6



Raise the lift arms a small amount. The spring will lift the support device off the lift cylinder rod. Lower the lift arms. Stop the engine.

Raise the seat bar, unbuckle the seat belt, move the pedals until both lock and exit the cab.

Disconnect the spring from the bracket.

Raise the support device into storage position and insert the retaining pin (Item 1) [Figure 10-20-6] through the lift arm support device and through the bracket. Connect the spring to the retaining pin.

Remove the jackstands.

## OPERATOR CAB

### Description

The Bobcat loader has an operator cab (ROPS and FOPS) as standard equipment to protect the operator from rollover and falling objects. Check with your dealer if the operator cab has been damaged. The seat belt must be worn for rollover protection.

**ROPS / FOPS** - Roll Over Protective Structure per ISO 3471, and Falling Object Protective Structure per ISO 3449, Level I. Level II is available.

**Level I** - Protection from falling bricks, small concrete blocks, and hand tools encountered in operations such as highway maintenance, landscaping, and other construction sites.


**Level II** - Protection from falling trees, rocks: for machines involved in site clearing, overhead demolition or forestry.



### WARNING

Never modify operator cab by welding, grinding, drilling holes or adding attachments unless instructed to do so by Bobcat Company. Changes to the cab can cause loss of operator protection from rollover and falling objects, and result in injury or death.

W-2069-0200




### Raising

Always stop the engine before raising or lowering the cab.


Stop the loader on a level surface and lower the lift arms. If the lift arms must be up while raising the operator cab, install the lift arm support device. (See **LIFT ARM SUPPORT DEVICE** on Page 10-20-1.)

**Figure 10-30-1**



Install jackstands (Item 1) [Figure 10-30-1] under the rear corners of the loader frame.

**Figure 10-30-2**



Remove the nut and plate (Items 1 and 2) [Figure 10-30-2] on the inside front corner of the cab (Both sides).

## OPERATOR CAB (CONT'D)

### Raising (Cont'd)

Figure 10-30-3



Lift on the grab handle and bottom of the operator cab slowly until the cab is all the way up and the latching mechanism engages [Figure 10-30-3].

### Lowering

Always stop the engine before raising or lowering the cab.

**NOTE: Always use the grab handles (once you can reach them) to lower the cab.**

Figure 10-30-4



Pull down on the bottom of the operator cab until it stops at the latching mechanism [Figure 10-30-4].

**NOTE: The weight of the cab increases when equipped with options and accessories such as cab door, heater, air conditioning, etc. In these cases, the cab may need to be raised slightly from the latch to be able to release the latch.**

## WARNING


### PINCH POINT CAN CAUSE INJURY

Remove your hand from the latching mechanism when the cab is past the latch stop.

W-2469-0803

Support the cab and release the latching mechanism (Inset) [Figure 10-30-4]. Remove your hand from the latching mechanism when the cab is past the latch stop. Use both hands to lower the cab all the way.

Figure 10-30-5



Install the plates and nuts (Items 1 and 2) [Figure 10-30-5] (both sides).


Tighten the nuts to 40-50 ft.-lb. (54-68 N•m) torque.

## OPERATOR CAB (CONT'D)

### Cab Door Sensor

This machine may be equipped with a Cab Door Sensor.

**Figure 10-30-6**




The cab door (option) has a sensor (Item 1) [Figure 10-30-6] installed which deactivates the lift and tilt valves when the door is open.

A decal is located on the latch mechanism (Item 2) [Figure 10-30-6].

The LIFT & TILT VALVE light (Item 3) [Figure 10-30-6] will be OFF when the door is closed, the key switch is turned to RUN or the RUN / ENTER button is pressed, the seat bar is lowered and the PRESS TO OPERATE LOADER button is pressed.

**Figure 10-30-7**



The LIFT & TILT VALVE light (Item 3) [Figure 10-30-6] will be ON when the door is open, the key switch is turned to RUN or the RUN / ENTER button is pressed, the seat bar is lowered and the PRESS TO OPERATE LOADER button is pressed.

[DOOR] will appear in the data display [Figure 10-30-7].

Product: 2011 Bobcat S100 Skid-Steer Loader Service Repair Workshop Manual(S/N A2G711001 & Above,/N A89L11001 & Above)

Full Download: <https://www.arepairmanual.com/downloads/2011-bobcat-s100-skid-steer-loader-service-repair-workshop-manuals-n-a2g711001-above-n-a89l11001-above/>



Sample of manual. Download All 502 pages at:

<https://www.arepairmanual.com/downloads/2011-bobcat-s100-skid-steer-loader-service-repair-workshop-manuals-n-a2g711001-above-n-a89l11001-above/>