


Product: 1993 Acura Vigor Car Service Repair Workshop Manual

Full Download: <https://www.automotomanual.com/downloads/1993-acura-vigor-car-service-repair-workshop-manual/>

1993 VIGOR SERVICE MANUAL

Published by Honda Motor Co., Ltd. Printed in U.S.A.
© 1992 American Honda Motor Co., Inc. All Rights Reserved
P/N 61SL501 (© A H M C 1992) O.D.S. 20009269P



This manual is divided into 23 sections. The first page of each section is marked with a black tab that lines up with its corresponding thumb index tab on this page and the back cover. You can quickly find the first page of each section without looking through a full table of contents. The symbols printed at the top corner of each page can also be used as a quick reference system.

Each section includes:

1. A table of contents, or an exploded view index showing:
 - Parts disassembly sequence.
 - Bolt torques and thread sizes.
 - Page references to descriptions in text.
2. Disassembly/assembly procedures and tools.
3. Inspection.
4. Testing/troubleshooting.
5. Repair.
6. Adjustments.

Special Information

WARNING Indicates a strong possibility of severe personal injury or loss of life if instructions are not followed.

CAUTION: Indicates a possibility of personal injury or equipment damage if instructions are not followed.

NOTE: Gives helpful information.

CAUTION: Detailed descriptions of *standard workshop* procedures, safety principles and service operations are not included. Please note that this manual contains warnings and cautions against some specific service methods which could cause PERSONAL INJURY, damage a vehicle or make it unsafe. Please understand that these warnings cannot cover all conceivable ways in which service, whether or not recommended by HONDA might be done, or of the possible hazardous consequences of every conceivable way, nor could HONDA investigate all such ways. Anyone using service procedures or tools, whether or not recommended by HONDA, *must satisfy himself thoroughly* that neither personal safety nor vehicle safety will be jeopardized.

All information contained in this manual is based on the latest product information available at the time of printing. We reserve the right to make changes at any time without notice. No part of this publication may be reproduced, stored in retrieval system, or transmitted, in any form by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of the publisher. This includes text, figures and tables.

First Edition 9/92 1364 pages
All Rights Reserved
Specification apply to U.S.A. and Canada

HONDA MOTOR CO., LTD.
Service Publication Office

Sample of manual. Downloaded at <https://www.arepairmanual.com/repairmanual.com/downloads/1993-acura-vigor-car-service-repair-workshop-manual/>

Special Tools



Specifications



Maintenance



Engine



Cooling



Fuel and Emissions



* Transaxle



* Steering



Suspension



* Brakes (Including ABS)



* Body



* Heater and Air Conditioner



* Electrical (Including SRS)



As sections with * include SRS components,
special precautions are required when
servicing.

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

The VIGOR SRS includes a driver's side airbag, located in the steering wheel hub. In addition, the GS model has a front passenger's airbag located in the dashboard above the glove box. Information necessary to safely service the SRS is included in this Service Manual. Items marked with an asterisk (*) on the contents page include, or are located near, SRS components. Servicing, disassembling or replacing these items will require special precautions and tools, and should therefore be done by an authorized Acura dealer.

WARNING

- To avoid rendering the SRS inoperative, which could lead to personal injury or death in the event of a severe frontal collision, all maintenance must be performed by an authorized Acura dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, could lead to personal injury caused by unintentional activation of the airbag (s).
- All SRS electrical wiring harnesses are covered with yellow outer insulation. Related components are located in the steering column, center console, dash, and dashboard lower panel, and in the dashboard above the glove box. Do not use electrical test equipment on these circuits.

NOTE: The radio may have a coded theft protection circuit. Be sure to get the customer's code number before

- Disconnecting the battery.
- Removing the No. 39 (10 A) fuse in the under-hood fuse/relay box.
- Removing the radio.

After service, reconnect power to the radio and turn it on. When the word "CODE" is displayed, enter the customer's 5-digit code to restore radio operation.

General Information

Chassis and Paint Codes	1-2
Identification Number Locations	1-4
Warning/Caution Label Locations	1-5
Lift and Support Points	
Lift	1-9
Floor Jack	1-10
Safety Stands	1-11
Towing	1-12
Service Precautions	1-13

Chassis and Paint Codes

U.S. Model

Vehicle Identification Number

Manufacturer, Make and Type of Vehicle

Body Type

Body and Transmission Type

Vehicle Grade

Check Digit

Model Year

Serial Number


Engine Number

Engine Type

Emission Group

Serial Number

Paint Code
**COLOR
BG-30P**



Transmission Number (Manual Transmission)

Transmission Type

Serial Number


Transmission Number (Automatic Transmission)

Transmission Type

Serial Number

Paint Code	
Paint Code	Color
BG-30P	Arcadia Green Pearl
NH-503P	Granada Black Pearl
NH-536M	Solaris Silver Metallic
NH-538	Frost White
R-82P	Cassis Red Pearl
RP-18P	Regal Plum Pearl

Vehicle Identification Number and Federal Motor Vehicle Safety Standard Certification



CANADA Model

Vehicle Identification Number

Manufacturer, Make and Type of Vehicle

Body Type

Body and Transmission Type

Vehicle Grade

Check Digit

Model Year

Serial Number

Engine Number

Engine Type

Serial Number

Paint Code
**COLOR
BG-30P**

Transmission Number (Manual Transmission)

Transmission Type



Serial Number

Transmission Number (Automatic Transmission)


Transmission Type

Serial Number


Vehicle Identification Number and Canadian Motor Vehicle Safety Standard Certification



Identification Number Locations




Warning/Caution Label Locations





Warning/Caution Label Locations

(cont'd)



G: DRIVER INFORMATION

SRS ALWAYS WEAR YOUR SEAT BELT
 • THIS CAR IS EQUIPPED WITH A DRIVER AIRBAG AS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS).
 • IT IS DESIGNED TO SUPPLEMENT THE SEAT BELT.
 • BEFORE DRIVING READ LABEL INSIDE THE CONSOLE BOX.

*G: DRIVER INFORMATION

SRS ALWAYS WEAR YOUR SEAT BELT
 • THIS CAR IS EQUIPPED WITH A DRIVER AIRBAG AND A FRONT SEAT PASSENGER AIRBAG AS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS).
 • IT IS DESIGNED TO SUPPLEMENT THE SEAT BELT.
 • BEFORE DRIVING READ LABEL INSIDE THE CONSOLE BOX.

H: STEERING COLUMN NOTICE

NOTICE
 TO PREVENT SRS DAMAGE, REMOVE STEERING WHEEL BEFORE REMOVING STEERING SHAFT CONNECTING BOLT

I: LABEL [AIRBAG]

J: SRS UNIT CAUTION

CAUTION [SRS]
 • NO SERVICEABLE PARTS INSIDE.
 • DO NOT DISASSEMBLE OR TAMPER.
 • DO NOT DROP.
 • STORE IN A CLEAN, DRY AREA.

K: FRONT SEAT PASSENGER AIRBAG MODULE DANGER

△ DANGER EXPLOSIVE/FLAMMABLE

CONTACT WITH ACID, WATER OR HEAVY METALS SUCH AS COPPER, LEAD OR MERCURY MAY PRODUCE HARMFUL AND IRRITATING GASES OR EXPLOSIVE COMPOUNDS. STORAGE TEMPERATURES MUST NOT EXCEED 200°F (100°C) FOR PROPER HANDLING, STORAGE AND DISPOSAL PROCEDURES REFER TO SERVICE MANUAL, SRS SUPPLEMENT.

POISON

CONTAINS POISONOUS SODIUM AZIDE AND POTASSIUM NITRATE.

FIRST AID

IF CONTENTS ARE SWALLOWED, INDUCE VOMITING.

FOR EYE CONTACT, FLUSH EYES WITH WATER FOR 15 MINUTES. IF GASES (FROM ACID OR WATER CONTACT) ARE INHALED, SEEK FRESH AIR. IN EVERY CASE, GET PROMPT MEDICAL ATTENTION.

KEEP OUT OF REACH OF CHILDREN.

△ WARNING

THE AIRBAG INFLATOR IS EXPLOSIVE AND, IF ACCIDENTALLY DEPLOYED, CAN SERIOUSLY HURT OR KILL YOU.


- DO NOT USE ELECTRICAL TEST EQUIPMENT OR PROBING DEVICES. THEY CAN CAUSE ACCIDENTAL DEPLOYMENT.
- NO SERVICEABLE PARTS INSIDE. DO NOT DISASSEMBLE.
- PLACE AIRBAG UPRIGHT WHEN REMOVED.
- FOLLOW SERVICE MANUAL INSTRUCTIONS CAREFULLY.

L: SRS CONSOLE INFORMATION

AIRBAG INFORMATION

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

- THE SRS MUST BE INSPECTED TEN YEARS AFTER IT IS INSTALLED. THE DATE OF INSTALLATION IS SHOWN ON THE CERTIFICATION PLATE LOCATED ON THE DRIVER'S DOORJAMB.
- DIAGNOSTIC CHECKS AND REPLACEMENT OF SRS COMPONENTS MUST BE DONE BY AN AUTHORIZED DEALER.
- SEE YOUR OWNER'S MANUAL FOR ADDITIONAL SRS INFORMATION.



M: SRS WARNING (ENGINE HOOD)

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

THIS VEHICLE IS EQUIPPED WITH DRIVER AND FRONT SEAT PASSENGER AIRBAGS AND FRONT SEAT BELT TENSIONER SYSTEMS.


ALL SRS ELECTRICAL WIRING AND CONNECTORS ARE COLORED YELLOW.
 TAMPERING WITH, DISCONNECTING OR USING ELECTRICAL TEST EQUIPMENT ON THE SRS WIRING CAN MAKE THE SYSTEM INOPERATIVE OR CAUSE ACCIDENTAL FIRING OF THE INFLATOR.

△ WARNING
 THE AIRBAG INFLATOR IS EXPLOSIVE AND, IF ACCIDENTALLY DEPLOYED, CAN SERIOUSLY HURT YOU.
 FOLLOW SERVICE MANUAL INSTRUCTIONS CAREFULLY.

(cont'd)

Warning/Caution Label Locations

(cont'd)





Lift and Support Points




Lift

1. Place the lift blocks as shown.
2. Raise the hoist a few inches and rock the car to be sure it is firmly supported.
3. Raise the hoist to full height and inspect lift points for solid support.



FRONT SUPPORT POINT



REAR SUPPORT POINT


(cont'd)

Lift and Support Points

Floor Jack

1. Set the parking brake and block the wheels that are not being lifted.
2. When lifting the rear of the car, put the gearshift lever in reverse (Automatic transmission in **P** position).
3. Raise the car high enough to insert the safety stands.
4. Adjust and place the safety stands as shown on page 1-11 so the car will be approximately level, then lower the car onto them.


Front




Center the jack bracket in the middle of the jack lift platform.

WARNING

- Always use safety stands when working on or under any vehicle that is supported by only a jack.
- Never attempt to use a bumper jack for lifting or supporting the car.





Rear



Center the jack bracket in the middle of the jack lift platform.

Safety Stands



FRONT SUPPORT POINT

SAFETY STANDS

REAR SUPPORT POINT

Towing

If the car needs to be towed, call a professional towing service. Never tow the car behind another car with just a rope or chain. It is very dangerous.

Emergency Towing

There are three popular methods of towing a car:

Flat-bed Equipment — The operator loads the car on the back of a truck. This is the best way of transporting the car.

Wheel Lift Equipment — The tow truck uses two pivoting arms that go under the tires (front or rear) and lifts them off the ground. The other two wheels remain on the ground.

Sling-type Equipment — The tow truck uses metal cables with hooks on the ends. These hooks go around parts of the frame or suspension and the cables lift that end of the car off the ground. The car's suspension and body can be seriously damaged if this method of towing is attempted.

If the car cannot be transported by flat-bed, it should be towed with the front wheels off the ground. If due to damage, the car must be towed with the front wheels on the ground, do the following:

5-speed Manual Transmission

- Release the parking brake.
- Shift the transmission to neutral.

Automatic Transmission


- Release the parking brake.
- Start the engine.
- Shift to **D₄** position, then to **N** position.
- Turn off the engine.

NOTICE: Improper towing preparation will damage the transmission. Follow the above procedure exactly. If you can not shift the transmission or start the engine (automatic transmission), the car must be transported on a flat-bed.

- It is best to tow the car no farther than 50 miles (80 km), and keep the speed below 35 mph (55 km/h).


NOTICE: Trying to lift or tow the car by the bumpers will cause serious damage. The bumpers are not designed to support the car's weight.

Front:



TOWING HOOKS and
TIE DOWN BRACKETS

Rear:



TIE DOWN BRACKETS


Service Precautions

Handling of Special Nuts and Bolts

Because the front sub frame sections on this car are constructed with aluminum alloys, use only the special "Dacro" type nuts and bolts recommended by Acura.


NOTE:

- Dacro finish can be identified by gray plating.
- Some Dacro finish bolts have a green coating on the thread section of the bolt for easier application. This type of bolt is called a "Torquer" bolt.
- Use of other types of nuts and bolts may cause electrolysis and corrosion which in turn could cause the bolt to loosen.



Gray plating: "Dacro" type
Gray plating + Green coating on the threads:
"Torquer" type

1. When replacing nuts and bolts, use only the same type.
2. Tighten the nuts and bolts with a torque wrench to the specifications provided in this manual.
3. Clean all thread ridges with a non wire type bristle brush. Foreign matter in the threads may cause the bolt to loosen.
4. Sections on this car requiring the use of Dacro nuts and bolts will be indicated by a (★) in this manual.





Special Tools

Individual tool lists are located at the front of each section.

Specifications

Standards and Service Limits	3-2
Design Specifications	3-13
Body Specifications	3-16

Standards and Service Limits

Cylinder Head/Valve Train—Section 6

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Compression	250 rpm and wide open throttle kPa (kg/cm ² , psi) Nominal Minimum Maximum variation	1,450 (14.5, 206) 950 (9.5, 135) 200 (2.0, 28)	
Cylinder head	Warpage Height	99.95–100.05 (3.935–3.939)	0.05 (0.002) —
Camshaft	End play Camshaft-to-holder oil clearance Total runout Cam lobe height IN EX	0.05–0.15 (0.002–0.006) 0.050–0.089 (0.002–0.004) 0.03 (0.001) max. 39.203 (1.5434) 38.875 (1.5305)	0.5 (0.02) 0.15 (0.006) 0.06 (0.002) — —
Valve	Valve clearance Valve stem O.D. Stem-to-guide clearance	IN EX IN EX IN EX	0.24–0.28 (0.009–0.011) 0.28–0.32 (0.011–0.013) 5.475–5.485 (0.2156–0.2159) 5.450–5.460 (0.2146–0.2150) 0.020–0.045 (0.0008–0.0018) 0.05–0.08 (0.002–0.003)
Valve seat	Width Stem installed height	IN EX IN EX	1.25–1.55 (0.049–0.061) 1.25–1.55 (0.049–0.061) 48.745–49.215 (1.9191–1.9376) 51.315–51.785 (2.0203–2.0388)
Valve spring	Free length	IN EX	52.13 (2.052) *1 52.12 (2.052) *2 56.10 (2.209) *1 56.08 (2.208) *2
Valve guide	I.D. Installed height	IN EX IN EX	5.505–5.520 (0.2167–0.2173) 5.51–5.53 (0.217–0.218) 24.75–25.25 (0.974–0.994) 16.05–16.55 (0.632–0.652)
Rocker arm	Arm-to-shaft clearance	IN EX	0.017–0.050 (0.0007–0.0020) 0.018–0.054 (0.0007–0.0021)
			0.08 (0.003) 0.08 (0.003)

*1: NIHON HATSUJO manufactured valve spring, *2: CHUO HATSUJO manufactured valve spring.

Engine Block—Section 7

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Cylinder block	Warpage of deck surface Bore diameter Bore taper Reboring limit	A B — —	0.07 (0.003) max. 85.010–85.020 (3.3468–3.3472) 85.000–85.010 (3.3465–3.3468) — — 0.10 (0.004) 85.070 (3.3492) 85.070 (3.3492) 0.05 (0.002) 0.5 (0.02)
Piston	Skirt O.D. * Clearance in cylinder Groove width (for ring)	No Letter (A) B Top Second Oil	84.980–84.990 (3.3457–3.3461) 84.970–84.980 (3.3453–3.3457) 0.010–0.040 (0.0004–0.0016) 1.22–1.23 (0.048–0.048) 1.22–1.23 (0.048–0.048) 2.805–2.825 (0.1104–0.1112) 84.970 (3.3453) 84.960 (3.3449) 0.05 (0.002) 1.25 (0.049) 1.25 (0.049) 2.85 (0.112)
Piston ring	Ring-to-groove clearance Ring end gap	Top Second Top Second Oil	0.035–0.060 (0.0014–0.0024) 0.030–0.055 (0.0012–0.022) 0.20–0.35 (0.008–0.014) 0.40–0.55 (0.016–0.022) 0.20–0.70 (0.008–0.028) 0.13 (0.005) 0.13 (0.005) 0.60 (0.024) 0.70 (0.028) 0.80 (0.031)
Piston Pin	O.D. Pin-to-piston clearance		21.994–22.000 (0.8659–0.8661) 0.012–0.024 (0.0005–0.0009) — —
Connecting rod	Pin-to-rod interference Small end bore diameter Large end bore diameter End play installed on crankshaft Small end bore-to-large end bore parallelism	Nominal	0.013–0.032 (0.0005–0.0013) 21.968–21.981 (0.8649–0.8654) 48.0 (1.89) 0.15–0.30 (0.006–0.012) 0.12 (0.005)/100 max. — — — — —
Crankshaft	Main journal diameter Rod journal diameter Taper Out-of-round End play Total runout		54.976–55.000 (2.1644–2.1654) 44.976–45.000 (1.7707–1.7717) 0.010 (0.0004) max. 0.010 (0.0004) max. 0.10–0.35 (0.004–0.014) 0.03 (0.001) max. — — 0.01 (0.0004) 0.01 (0.0004) 0.45 (0.18) 0.06 (0.002)
Bearings	Main bearing-to-journal oil clearance Rod bearing-to-journal oil clearance		0.018–0.048 (0.0007–0.0019) 0.015–0.043 (0.0006–0.0017) 0.053 (0.0021) 0.05 (0.002)

*: Measured at 21.0 mm (0.83 in) from bottom at skirt

Engine Lubrication—Section 8

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Engine oil	Capacity ℥ (US qt, Imp qt)	5.2 (5.5, 4.6) for engine overhaul 4.3 (4.5, 3.8) for oil change, including filter	
Oil pump	Displacement ℥ (US qt, Imp qt)/min @rpm	60.0 (63.4, 52.8) @6,000	
	Inner-to-outer rotor radial clearance Housing-to-outer rotor radial clearance Housing-to-rotor axial clearance	0.04–0.16 (0.002–0.006) 0.10–0.18 (0.004–0.007) 0.02–0.07 (0.001–0.003)	0.20 (0.008) 0.20 (0.008) 0.12 (0.005)
Relief valve	Pressure setting at oil temperature 176°F (80°C) kPa (kg/cm ² , psi)	at idle 350 (3.5, 50) min. 70 (0.7, 10) min. 3500 rpm	

Standards and Service Limits

Cooling—Section 10

	MEASUREMENT	STANDARD (NEW)
Radiator	Engine coolant capacity ℓ (US qt, Imp qt) including engine, heater, cooling line and reservoir reservoir capacity: 0.70 ℓ (0.74 US qt, 0.62 Imp qt)	M/T: 7.6 (8.0, 6.7) for overhaul 6.0 (6.3, 5.3) for coolant change A/T: 7.5 (7.9, 6.6) for overhaul 5.9 (6.2, 5.2) for coolant change
Radiator cap	Opening pressure kPa (kg/cm ² , psi)	95–125 (0.95–1.25, 13.5–17.8)
Thermostat	Start to open °F (°C) Fully open °F (°C) Valve lift at fully open	Primary 176–183 (80–84) 181–189 (83–87) 203 (95) Secondary 10.0 (0.39) min. 8.5 (0.33) min.
Water pump	Displacement ℓ (US qt, Imp qt)/min @rpm	150.0 (158.5, 132.0) @6,000
Radiator fan	Thermoswitch "ON" temperature °F (°C) Thermoswitch "OFF" temperature °F (°C)	194–205 (90–96) 181–196 (83–91)

Fuel and Emission—Section 11

	MEASUREMENT	STANDARD (NEW)
Fuel pump	Displacement cc (US oz, Imp oz) in 10 seconds Relief valve opening pressure kPa (kg/cm ² , psi)	230 (7.8, 8.1) min. 450–600 (4.5–6.0, 64.0–85.3)
Pressure	Pressure with regulator vacuum hose disconnected kPa (kg/cm ² , psi)	300–350 (3.0–3.5, 43–50)
Fuel tank	Capacity ℓ (US gal, Imp gal)	65 (17.2, 14.3)
Engine	Fast idle rpm Idle speed rpm Idle CO %	1400 M/T 700 (neutral) A/T 700 (P or N position) 0.1 max.

Clutch—Section 12

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Clutch pedal	Clutch pedal height to the floor panel Stroke at pedal Total clutch pedal free play (include the pedal play) Pedal play Clutch pedal disengagement height to the floor panel to carpet (Reference)	207.5 (8.17) 140–150 (5.51–5.91) 9–15 (0.35–0.59) 1.0–7.0 (0.04–0.28) 116.4 (4.58) min. 82.0 (3.23) min.	— — — — — —
Flywheel	Runout	0.05 (0.002) max.	0.15 (0.006)
Clutch disc	Rivet depth Surface runout Thickness	1.3 (0.05) min. 0.6 (0.02) max. 8.6–9.3 (0.34–0.37)	0.2 (0.01) 0.8 (0.03) 6.2 (0.24)
Pressure plate	Warpage	0.03 (0.001) max.	0.8 (0.03)

Manual Transmission—Section 13

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Transmission oil	Capacity ℓ (US qt, Imp qt)	2.0 (2.1, 1.8) for overhaul 1.8 (1.9, 1.6) for oil change	
Mainshaft	Diameter of needle bearing contact area Clutch housing side 3rd gear Diameter of ball bearing contact area Transmission housing side Runout	27.977–27.990 (1.1015–1.1020) 35.984–36.000 (1.4167–1.4173) 28.987–29.000 (1.1412–1.1417) 0.02 (0.001) max.	27.930 (1.0996) 35.930 (1.4146) 28.940 (1.1394) 0.05 (0.002)
Mainshaft 3rd gear	I.D. End play Thickness	41.009–41.025 (1.6145–1.6152) 0.05–0.20 (0.002–0.008) 27.92–27.97 (1.099–1.101)	41.080 (1.6173) 0.3 (0.01) 27.85 (1.097)
Mainshaft 4th gear	I.D. End play Thickness	41.009–41.025 (1.6145–1.6152) 0.05–0.17 (0.002–0.007) 34.92–34.97 (1.375–1.377)	41.080 (1.6173) 0.3 (0.012) 34.85 (1.372)
Distance collar (Mainshaft 4th gear)	I.D. O.D. Length	29.002–29.012 (1.1418–1.1422) 35.989–36.000 (1.4169–1.4173) 27.050–27.070 (1.0650–1.0657)	29.060 (1.1441) 35.940 (1.4150) 27.03 (1.064)
Mainshaft 5th gear	I.D. End play Thickness	41.009–41.025 (1.6145–1.6152) 0.05–0.17 (0.002–0.007) 31.42–31.47 (1.237–1.239)	41.080 (1.6173) 0.3 (0.01) 31.35 (1.234)
Distance collar (Mainshaft 5th gear)	I.D. O.D. Length	29.002–29.012 (1.1418–1.1422) 35.989–36.000 (1.4169–1.4173) 27.050–27.070 (1.0650–1.0657)	29.060 (1.1441) 35.940 (1.4150) 27.03 (1.064)
Countershaft	Diameter of needle bearing contact area Clutch housing side 1st gear Diameter of ball bearing contact area Transmission housing side Transmission cover side Runout	33.000–33.015 (1.2992–1.2998) 43.984–44.000 (1.7317–1.7323) 27.977–27.990 (1.1015–1.1020) 24.980–24.993 (0.9835–0.9840) 0.02 (0.001) max.	32.950 (1.2972) 43.930 (1.7295) 27.930 (1.0996) 24.930 (0.9815) 0.05 (0.002)
Countershaft 1st gear	I.D. End play (when tightened by the specified torque) Thickness	50.009–50.025 (1.9689–1.9695) 0.05–0.11 (0.002–0.004) 35.95–36.00 (1.415–1.417)	50.080 (1.9716) Adjust with a thrust shim 35.88 (1.413)
Countershaft 2nd gear	I.D. End play (when tightened by the specified torque) Thickness	46.009–46.025 (1.8114–0.8120) 0.06–0.135 (0.002–0.005) 33.92–33.97 (1.335–1.337)	46.080 (1.8142) 0.3 (0.01) 33.85 (1.333)
Distance collar (Countershaft 2nd gear)	I.D. O.D. Thickness	34.980–34.990 (1.3772–1.3776) 40.989–41.000 (1.6137–1.6142) 34.085–34.105 (1.3419–1.3427)	35.038 (1.3794) 40.940 (1.6118) —
Reverse idler gear	I.D. Gear-to-shaft clearance	20.054–20.081 (0.7895–0.7906) 0.074–0.122 (0.0029–0.0048)	20.109 (0.7917) 0.150 (0.0059)

(cont'd)

Standards and Service Limits

Manual Transmission (cont'd) — Section 13

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Synchro ring	Ring-to-gear clearance (ring pushed against)	0.85–1.10 (0.034–0.043)	0.4 (0.02)
Double cone synchro ring	Clearance (ring pushed against gear)	0.95–1.68 (0.037–0.066)	0.6 (0.02)
	Outer synchro ring-to-gear	0.5–1.0 (0.02–0.04)	0.3 (0.01)
	Synchro cone-to-gear	0.5–1.0 (0.02–0.04)	0.3 (0.01)
1st/2nd shift fork	Outer synchro ring-to-synchro cone	12.2–12.4 (0.48–0.49)	—
	Finger thickness	7.4–7.6 (0.29–0.30)	—
	Finger-to-synchro sleeve clearance	0.35–0.65 (0.014–0.026)	1.0 (0.04)
	Fork-to-shift piece clearance	0.2–0.5 (0.01–0.02)	0.7 (0.03)
3rd/4th shift fork	Groove width of shift piece contact point	12.2–12.4 (0.48–0.49)	—
	Finger thickness	7.4–7.6 (0.29–0.30)	—
	Finger-to-synchro sleeve clearance	0.35–0.65 (0.014–0.026)	1.0 (0.04)
	Fork-to-shift piece clearance	0.2–0.5 (0.01–0.02)	0.7 (0.03)
5th/reverse shift fork	Groove width of shift piece contact point	12.2–12.4 (0.48–0.49)	—
	Finger thickness	7.4–7.5 (0.29–0.30)	—
5th/reverse shift piece	Finger-to-synchro sleeve clearance	0.35–0.65 (0.014–0.026)	1.0 (0.04)
	Width of 5th/reverse shift piece pin	6.9–7.0 (0.27–0.28)	—
Reverse shift holder	Groove width of shift piece contact point	12.2–12.4 (0.48–0.49)	—
	Finger groove width	14.0–14.3 (0.55–0.56)	—
	Groove-to-reverse idler gear clearance	0.5–1.1 (0.02–0.04)	1.7 (0.07)
	Groove width	7.05–7.25 (0.278–0.285)	—
	Groove-to-5th/reverse shift piece pin clearance	7.4–7.7 (0.29–0.30)	—
		0.05–0.35 (0.002–0.014)	0.5 (0.02)
Shift arm	0.4–0.8 (0.02–0.03)	1.0 (0.04)	
	Diameter of change piece contact point	12.8–13.0 (0.50–0.51)	—
	Shift arm-to-change piece clearance	0.10–0.40 (0.004–0.016)	0.5 (0.02)
	Diameter of shift piece contact point	12.8–13.0 (0.50–0.51)	—
Change piece	Shift arm-to-shift piece clearance	0.10–0.40 (0.004–0.016)	0.6 (0.02)
	Groove width of shift arm contact point	13.10–13.20 (0.516–0.520)	—
	Groove width of select arm contact point	12.05–12.15 (0.474–0.478)	—
Shift piece	Change piece-to-select arm clearance	0.05–0.35 (0.002–0.014)	0.5 (0.02)
	Groove width of shift arm contact point	13.10–13.20 (0.516–0.520)	—
	Shift piece to shift fork shafts or 5th/reverse shift piece clearance	0.2–0.5 (0.01–0.02)	0.7 (0.03)
Select arm	Width of shift fork shafts and 5th/reverse shift piece contact point	11.9–12.0 (0.469–0.472)	—
	Diameter of change piece contact point	11.8–12.0 (0.46–0.47)	—
	Diameter of bearing contact area	40.002–40.018 (1.5749–1.5755)	—
Secondary gear	Transmission housing side: Clutch housing side:	50.002–50.018 (1.9685–1.9692)	—
	Diameter of oil seal contact area	39.738–39.800 (1.5645–1.5669)	—
	Backlash	0.058–0.116 (0.0023–0.0046)	0.176 (0.0069)
Oil pump	Preload N·m (kg·cm, lb·in)	1.8–3.0 (18–30, 15.6–26.0)	Adjust with a thrust shim
	Inner rotor-to-outer rotor tip clearance	0.14 (0.006) max.	0.20 (0.008)
	Clutch housing-to-outer rotor clearance	0.10–0.20 (0.004–0.008)	0.22 (0.009)
	Clutch housing-to-rotor axial clearance	0.03–0.15 (0.001–0.006)	0.20 (0.008)

Automatic Transmission — Section 14

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Transmission fluid	Capacity ℓ (US qt, Imp qt)	7.2 (7.6, 6.3) for overhaul 2.5 (2.6, 2.2) for fluid change	
Hydraulic pressure kPa (kg/cm ² , psi)	Line pressure at 2,000 rpm [N] or [P] position 1st clutch pressure at 2,000 rpm [D ₄] or [1] position 2nd clutch pressure at 2,000 rpm [D ₄] position 3rd clutch pressure at 2,000 rpm [D ₄] position 4th clutch pressure at 2,000 rpm [D ₄] position 2nd clutch pressure at 2,000 rpm [2] position 1st and 1st-hold clutch pressure at 2,000 rpm [1] position	850–900 (8.5–9.0, 121–128)	800 (8.0, 114)
Throttle B pressure	Throttle fully closed Throttle fully open	500 (5.0, 71) 900 (9.0, 128)	450 (4.5, 64) 800 (8.0, 114)
Modulator pressure			
Stall speed rpm (check with car on level ground)		2,200–2,500	—
Clutch	Clutch initial clearance 1st-hold 1st 2nd, 3rd, 4th Clutch return spring free length 1st, 3rd 2nd, 4th 1st-hold Clutch disc thickness Clutch plate thickness 1st, 3rd, 1st-hold 2nd, 4th	0.80–1.00 (0.031–0.039) 0.65–0.85 (0.026–0.033) 0.55–0.75 (0.022–0.030) 33.2 (1.31) 33.9 (1.33) 32.0 (1.30) 31.0 (1.22) 1.88–2.00 (0.074–0.079) 1.95–2.05 (0.077–0.081)	— — — 31.2 (1.23) 31.9 (1.26) 30.0 (1.18) 29.0 (1.14) Until grooves worn out Discoloration
Clutch end plate thickness (1st, 1st-hold and 3rd)	Mark 1 Mark 2 Mark 3 Mark 4 Mark 5 Mark 6 Mark 7 Mark 8 Mark 9 Mark 10 Mark 11 [*] Mark 12 [*] Mark 13 [*] Mark 14 [*]	2.05–2.10 (0.081–0.083) 2.15–2.20 (0.085–0.087) 2.25–2.30 (0.089–0.091) 2.35–2.40 (0.093–0.094) 2.45–2.50 (0.096–0.098) 2.55–2.60 (0.100–0.102) 2.65–2.70 (0.104–0.106) 2.75–2.80 (0.108–0.110) 2.85–2.90 (0.112–0.114) 2.95–3.00 (0.116–0.118) 3.05–3.10 (0.120–0.122) 3.15–3.20 (0.124–0.126) 3.25–3.30 (0.128–0.130) 3.35–3.40 (0.132–0.134)	Discoloration
Clutch end plate thickness (2nd and 4th)	Mark 1 Mark 2 Mark 3 Mark 4 Mark 5 Mark 6 Mark 7 Mark 8 Mark 9 Mark 10 Mark 11 [*] Mark 12 [*] Mark 13 [*] Mark 14 [*]	2.05–2.10 (0.081–0.083) 2.15–2.20 (0.085–0.087) 2.25–2.30 (0.089–0.091) 2.35–2.40 (0.093–0.094) 2.45–2.50 (0.096–0.098) 2.55–2.60 (0.100–0.102) 2.65–2.70 (0.104–0.106) 2.75–2.80 (0.108–0.110) 2.85–2.90 (0.112–0.114) 2.95–3.00 (0.116–0.118) 3.05–3.10 (0.120–0.122) 3.15–3.20 (0.124–0.126) 3.25–3.30 (0.128–0.130) 3.35–3.40 (0.132–0.134)	Discoloration
* 1st and 1st-hold only			
Clutch end plate thickness (2nd and 4th)	Mark 1 Mark 2 Mark 3 Mark 4 Mark 5 Mark 6 Mark 7 Mark 8 Mark 9	2.05–2.10 (0.081–0.083) 2.15–2.20 (0.085–0.087) 2.25–2.30 (0.089–0.091) 2.35–2.40 (0.093–0.094) 2.45–2.50 (0.096–0.098) 2.55–2.60 (0.100–0.102) 2.65–2.70 (0.104–0.106) 2.75–2.80 (0.108–0.110) 2.85–2.90 (0.112–0.114)	Discoloration

Standards and Service Limits

Automatic Transmission (cont'd) – Section 14

Automatic Transmission (cont'd) – Section 14

Automatic Transmission (cont'd) — Section 14			
	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Transmission (cont'd)	Mainshaft feed pipe O.D. Mainshaft feed pipe O.D. Countershaft feed pipe O.D. Countershaft feed pipe O.D. Mainshaft bushing I.D. Mainshaft bushing I.D. Countershaft bushing I.D. Countershaft bushing I.D. Diameter of needle bearing contact area On mainshaft and stator shaft On mainshaft 1st gear collar On mainshaft 4th gear collar On mainshaft 2nd collar On countershaft (Fr side) On countershaft 3rd gear distance collar On countershaft 1st gear collar On countershaft 4th gear On countershaft reverse gear collar On reverse idler gear shaft Reverse idler gear shaft holder I.D. Diameter of one-way clutch contact area Countershaft 1st gear I.D. Parking gear O.D. Selector hub O.D. Inside diameter Mainshaft 1st gear Mainshaft 2nd gear Mainshaft 4th gear Countershaft 1st gear Countershaft 3rd gear Countershaft 4th gear Countershaft reverse gear Reverse idler gear End play Mainshaft 1st gear Mainshaft 2nd gear Mainshaft 4th gear Countershaft 1st gear Countershaft 3rd gear Countershaft 4th gear Countershaft reverse gear Reverse idler gear	11.47–11.48 (0.4516–0.4520) 5.97–5.98 (0.2350–0.2354) 11.47–11.48 (0.4516–0.4520) 7.97–7.98 (0.3138–0.3142) 11.500–11.518 (0.4528–0.4535) 6.018–6.030 (0.2369–0.2374) 11.500–11.518 (0.4528–0.4535) 8.000–8.015 (0.3150–0.3156) 22.980–22.993 (0.9047–0.9052) 32.975–32.991 (1.2982–1.2989) 33.975–33.991 (1.3376–1.3382) 36.975–36.991 (1.4557–1.4563) 38.505–38.515 (1.5159–1.5163) 43.975–43.991 (1.7313–1.7319) 33.975–33.991 (1.3376–1.3382) 31.975–31.991 (1.2589–1.2595) 32.975–32.991 (1.2982–1.2989) 13.990–14.000 (0.5508–0.5512) 14.416–14.434 (0.5676–0.5683) 83.339–83.365 (3.2811–3.2821) 66.685–66.696 (2.6254–2.6258) 51.87–51.90 (2.042–2.043) 37.000–37.016 (1.4567–1.4573) 43.000–43.016 (1.6929–1.6935) 40.000–40.016 (1.5748–1.5754) 40.000–40.016 (1.5748–1.5754) 49.000–49.016 (1.9291–1.9298) 38.000–38.016 (1.4961–1.4967) 39.000–39.016 (1.5354–1.5361) 18.007–18.020 (0.7089–0.7094)	11.45 (0.451) 5.95 (0.234) 11.45 (0.451) 7.95 (0.313) 11.530 (0.4539) 6.045 (0.2380) 11.530 (0.4539) 8.030 (0.3161) Wear or damage ↑ ↓
Secondary gear shaft taper roller bearing starting torque N·m (kg-cm, lb-in)	2.3–3.3 (23–33, 20–29)	—	

Standards and Service Limits

Automatic Transmission (cont'd) – Section 14

	MEASUREMENT	STANDARD (NEW)			
		Wire Dia.	O.D.	Free Length	No. of Coils
Springs	1st one-way ball spring	0.29 (0.011)	4.0 (0.157)	14.0 (0.551)	13.0
	Regulator valve spring A	1.8 (0.071)	14.7 (0.579)	88.6 (3.488)	16.5
	Regulator valve spring B	1.8 (0.071)	9.6 (0.378)	44.0 (1.732)	7.5
	Stator reaction spring	6.0 (0.236)	38.4 (1.512)	30.3 (1.193)	2.0
	Torque converter check valve spring	1.1 (0.043)	8.4 (0.331)	41.8 (1.646)	15.7
	Relief valve spring	1.1 (0.043)	8.4 (0.331)	41.8 (1.646)	15.7
	Cooler relief valve spring	1.1 (0.043)	8.4 (0.331)	46.8 (1.843)	17.0
	3-4 orifice control valve spring	0.7 (0.028)	6.6 (0.260)	34.8 (1.370)	22.0
	2-3 orifice control valve spring	0.7 (0.028)	6.6 (0.260)	39.1 (1.539)	22.0
	Throttle valve spring	1.0 (0.039)	7.6 (0.299)	28.3 (1.114)	12.1
	4th exhaust valve spring	0.6 (0.024)	5.6 (0.220)	49.1 (1.933)	21.0
	1-2 shift valve spring	0.9 (0.035)	8.6 (0.339)	40.4 (1.591)	14.5
	2-3 shift valve spring	0.9 (0.035)	9.6 (0.378)	43.0 (1.693)	12.1
	1st accumulator spring A	2.2 (0.087)	17.2 (0.677)	88.6 (3.488)	15.0
	1st accumulator spring B	1.9 (0.075)	19.8 (0.386)	51.5 (2.028)	8.3
	4th accumulator spring	3.3 (0.130)	20.5 (0.807)	74.1 (2.917)	11.2
	2nd accumulator spring	3.0 (0.118)	18.7 (0.736)	88.1 (3.468)	14.2
	1st-hold accumulator spring A	3.5 (0.138)	21.6 (0.850)	55.9 (2.201)	7.7
	3rd accumulator spring	3.2 (0.126)	20.5 (0.807)	89.0 (3.504)	12.6
	1st-hold accumulator spring B	2.3 (0.091)	12.8 (0.504)	53.4 (2.102)	12.6
	Lock-up shift valve spring	0.9 (0.035)	7.6 (0.299)	73.7 (2.902)	32.0
	Lock-up timing valve spring	0.8 (0.031)	6.6 (0.260)	59.3 (2.335)	38.8
	Servo control valve spring	1.0 (0.039)	8.1 (0.319)	52.1 (2.051)	20.8
	Lock-up control valve spring	0.7 (0.028)	6.6 (0.260)	38.0 (1.496)	14.1
	Modulator valve spring	1.4 (0.055)	9.4 (0.370)	32.4 (1.276)	10.5
	CPC valve spring	1.0 (0.039)	6.8 (0.268)	36.1 (1.421)	17.8
	4th kick-down spring	1.0 (0.039)	7.6 (0.299)	48.2 (1.898)	22.2
	3rd kick-down spring	1.0 (0.039)	7.4 (0.291)	38.6 (1.520)	16.0

Differential – Section 15

	MEASUREMENT		STANDARD (NEW)	SERVICE LIMIT
Differential oil	Capacity ℓ (US qt, Imp qt)		1.0 (1.11, 0.92) for overhaul 0.9 (1.00, 0.84) for oil change	
Differential carrier	Pinion shaft contact area I.D. Carrier-to-pinion shaft clearance Driveshaft or intermediate shaft contact area I.D. Carrier-to-driveshaft clearance Carrier-to-intermediate shaft clearance		18.000–18.018 (15.8382–15.8540) 0.013–0.047 (0.0114–0.0019) 30.025–30.045 (1.1821–1.1829) 0.045–0.086 (0.0018–0.0034) 0.080–0.116 (0.0031–0.0046)	0.10 (0.004) 0.12 (0.005) 0.15 (0.006)
Differential pinion gear	Backlash I.D. Pinion gear-to-pinion shaft clearance		0.05–0.15 (0.002–0.006) 18.042–18.066 (0.7103–0.7113) 0.055–0.095 (0.0022–0.0037)	0.30 (0.012) 0.15 (0.006)
Drive pinion and ring gear	Backlash at inspection hole at gear circumference		0.04–0.10 (0.002–0.004) 0.06–0.14 (0.002–0.006)	Adjust with a shim
Drive pinion	Preload N·m (kg-cm, lb-in)	New bearing Reused bearing	1.30–1.70 (13.0–17.0, 11.3–14.8) 0.65–1.05 (6.5–10.5, 5.6–9.1)	Adjust with a shim
Total bearing preload	Preload N·m (kg-cm, lb-in) New bearings Reused bearings Replace only the bearing on the ring gear side Replace only the bearing on the drive pinion side		2.58–3.30 (25.8–33.0, 22.4–28.6) 1.56–2.20 (15.6–22.0, 13.5–19.1) 1.93–2.65 (19.3–26.5, 16.8–23.0) 2.21–2.85 (22.1–28.5, 19.2–24.7)	Adjust with a shim

Steering – Section 17

MEASUREMENT		STANDARD (NEW)
Steering wheel	Play at steering wheel circumference Starting load at steering wheel circumference N (kg, lbs) Engine running When the hydraulic system to the speed sensor is cut off	1—10 (0.04—0.4) 32 (3.2, 5.1) max. 50 (5.0, 11.0) min.
Gearbox	Angle of rack-guide-screw loosened from locked position	20°
Pump	Pump pressure with valve closed (oil temp./speed: 105°F (40°C) min./idle. Do not run for more than 5 seconds). kPa (kg/cm ² , psi)	8,000—9,000 (80—90, 1,138—1,280)
Power steering fluid	Fluid capacity l (US qt, Imp qt)	1.8 (1.9, 1.6) System Reservoir 0.5 (0.5, 0.4)
Power steering pump belt	Deflection with 100 N (10 kg, 22 lbs) between pulleys	6.5—9.0 (0.26—0.35) with used belt 4.5—6.5 (0.18—0.26) with new belt

Suspension – Section 18

	MEASUREMENT		STANDARD (NEW)	SERVICE LIMIT
Wheel alignment	Camber	Front	0° 00' ± 1°	—
		Rear	-0° 30' ± 1°	—
	Caster	Front	1° 38' ± 1°	—
	Total toe	Front	0 ± 2.0 (0 ± 0.08)	—
		Rear	IN 3.0 ± 2.0 (0.12 ± 0.08)	—
	Front wheel turning angle	Inward wheel	39° 24' ± 2°	—
Wheel	Rim runout (Steel wheel)	Axial	0—1.0 (0—0.04)	2.0 (0.08)
		Radial	0—1.0 (0—0.04)	1.5 (0.06)
	Rim runout (Aluminum wheel)	Axial	0—0.7 (0—0.03)	2.0 (0.08)
		Radial	0—0.7 (0—0.03)	1.5 (0.06)
	End play	Front	0—0.05 (0—0.002)	—
		Rear	0—0.05 (0—0.002)	—

Brakes – Section 19

MEASUREMENT		STANDARD (NEW)		SERVICE LIMIT
Parking brake lever	Play in stroke at 200 N (20 kg, 44 lbs) lever force	To be locked when pulled 7–11 notches		—
Foot brake pedal	Pedal height (with floor mat removed)	A/T	199 (7.8) min.	—
		M/T	194 (7.6) min. 1–5 (1/16–13/64)	— — —
	Free play			
Master cylinder	Piston-to-pushrod clearance	0–0.4 (0–0.02)		—
Disc brake	Disc thickness	Front	23.0 (0.91)	21.0 (0.83)
		Rear	10.0 (0.39)	8.0 (0.31)
	Disc runout	Front	—	0.10 (0.004)
		Rear	—	0.10 (0.004)
	Disc parallelism	Front and rear	—	0.015 (0.0006)
	Pad thickness	Front	11.0 (0.43)	1.6 (0.06)
		Rear	9.0 (0.35)	1.6 (0.06)

Standards and Service Limits

Air Conditioning—Section 22

MEASUREMENT			STANDARD (NEW)
Air conditioning system	Lubricant capacity cc (US oz, Imp oz)	Condenser Evaporator Line or hose Receiver	20 (0.68, 0.70) 30 (1.01, 1.06) 10 (0.34, 0.35) 10 (0.34, 0.35)
Compressor	Lubricant capacity cc (US oz, Imp oz)	130–160 (4.40–5.41 4.58–5.63)	
	Stator coil resistance at 68°F (20°C) Ω	3.4–3.8	
	Pulley-to-pressure plate clearance	0.35–0.65 (0.014–0.026)	
Compressor belt	Deflection with 100 N (10 kg, 22 lbs) between pulleys	6.0–9.0 (0.24–0.35) with used belt 3.5–5.5 (0.14–0.22) with new belt	

Unit of length: mm (in)

Electrical—Section 23

MEASUREMENT			STANDARD (NEW)
Ignition coil	Rated voltage V	12	
	Primary winding resistance Ω at 77°F (25°C)	0.3–0.5	
	Secondary winding resistance kΩ at 77°F (25°C)	10.8–16.2	
Spark plug	Type	See Section 23	
	Gap	1.1 (0.43)	
Ignition timing	At idling °BTDC	15° ± 2° (Red)	
Alternator belt	Deflection with 100 N (10 kg, 22 lbs) between pulleys	7.5–9.5 (0.30–0.37) with used belt 5.0–7.0 (0.20–0.28) with new belt	
MEASUREMENT		STANDARD (NEW)	SERVICE LIMIT
Alternator (NIPPON-DENSO)	Output 13.5 V at hot A	100	—
	Brush length	10.5 (0.41)	1.5 (0.06)
Starter motor (MITSUBA 1.6 kW)	Type	Spur gear reduction, Permanent magnet	
	Mica depth	0.4–0.5 (0.016–0.020)	0.15 (0.006)
	Commutator runout	0–0.02 (0–0.001)	0.05 (0.002)
	Commutator O.D.	28.0–28.1 (1.102–1.106)	27.5 (1.083)
	Brush length	15.8–16.2 (0.62–0.64)	11.0 (0.43)
	Brush spring tension (new) N (kg, lbs)	16.0–18.0 (1.60–1.80, 3.53–3.93)	—
Starter motor (MITSUBA 2.0 kW)	Type	Planetary gear reduction, Permanent magnet	
	Mica depth	0.4–0.5 (0.016–0.020)	0.15 (0.006)
	Commutator runout	0–0.02 (0–0.001)	0.05 (0.002)
	Commutator O.D.	32.0–32.1 (1.260–1.264)	31.5 (1.240)
	Brush length	16.8–17.2 (0.66–0.68)	11.0 (0.43)
	Brush spring tension (new) N (kg, lbs)	17.0–19.0 (1.70–1.90, 3.75–4.19)	—
Starter motor (MITSUBISHI 2.0 kW)	Type	Planetary gear reduction, Field coil	
	Mica depth	0.5–0.8 (0.020–0.031)	0.20 (0.008)
	Commutator runout	0–0.05 (0–0.002)	0.10 (0.004)
	Commutator O.D.	31.9–32.1 (1.256–1.264)	31.5 (1.240)
	Brush length	18.0 (0.71)	11.0 (0.43)
	Brush spring tension (new) N (kg, lbs)	29.7–36.3 (2.97–3.63, 6.55–8.00)	—

Design Specifications

	ITEM	METRIC	ENGLISH	NOTES
Dimensions	Overall Length Overall Width Overall Height Wheelbase Track Front/Rear Ground Clearance Seating Capacity	4,835 mm 1,780 mm 1,370 mm 2,805 mm 1,520/1,510 mm 150 mm	190.4 in 70.1 in 53.9 in 110.4 in 59.8/59.4 in 5.9 in	Five
Weight (USA)	Gross Vehicle Weight Rating (GVWR)	1,925 kg	4,245 lbs	
Weight (CANADA)	Gross Vehicle Weight Rating (GVWR)	1,925 kg	4,245 lbs	
ENGINE	Type Cylinder Arrangement Bore and Stroke Displacement Compression Ratio Valve Train Lubrication System Fuel Required	Water-cooled, 4-stroke SOHC gasoline engine Inline 5-cylinder 30° slant mount 85.0 x 86.4 mm 2,451 cm ³ (cc)	3.35 x 3.40 in 149 cu-in 9.0 Belt driven, SOHC 4 valves per cylinder Forced and wet sump, trochoid pump Premium UNLEADED grade gasoline with 91 Pump Octane Number or higher	
STARTER	Make/Type Normal Output Nominal Voltage Hour Rating Direction of Rotation Weight	MITSUBA/Spur gear reduction, permanent magnet 1.6 kW and Planetary gear reduction, permanent magnet 2.0 kW MITSUBISHI/Planetary gear reduction, field coil 2.0 kW M/T: 1.6 kW A/T: 2.0 kW 12 V 30 seconds Counterclockwise as viewed from gear end Approximate 4.7 kg	10.4 lbs	
CLUTCH	Clutch Type Clutch Facing Area	M/T A/T 239 cm ²	Single plate dry, diaphragm spring Torque converter 37 sq-in	
TRANSMISSION	Transmission Primary Reduction Type Gear Ratio	M/T A/T 1st 2nd 3rd 4th 5th Reverse	Synchronized 5-speed forward, 1 reverse Electronically controlled 4-speed automatic, 1 reverse Direct 1 : 1 Manual Automatic 3.071 1.652 1.156 0.864 0.666 -3.075	
	Secondary Reduction Final Reduction	Gear type Gear ratio Gear type Gear ratio	Single helical gear 1.625 1.621 Hypoid spiral bevel gear 2.764 2.764	


Design Specifications

(cont'd)




	ITEM	METRIC	ENGLISH	NOTES
AIR CONDITIONING	Cooling Capacity	4.320 Kcal/h	17,142 BTU/h	
	Conditions:			
	Engine Speed	1,800 rpm		
	Outside Air Temperature	27°C	81°F	
	Outside Air Humidity	50%		
	Condenser Air Temperature	35°C	95°F	
	Condenser Air Velocity	4.5 m/sec	14.8 ft/sec	
	Blower Capacity	500 m ³ /h	17,660 cu ft/h	at 12 V
	Compressor	Type/Makes	Swash-plate type/NIPPONDENSO	
		No. of Cylinder	10	
EVAPORATOR	Capacity	177.7 cc/rev	10.84 cu-in/rev	
	Max. Speed		8,800 rpm	
	Lubricant Capacity	140 cc	4.73 US oz, 4.93 Imp oz	
	Condensor	Type	Corrugated fin type	
	Evaporator	Type	Corrugated fin type	
	Blower	Type	Sirocco fan	
		Motor Input	200 W/12 V	
		Speed Control	Infinitely variable	
		Max. Capacity	500 m ³ /h min.	17,660 cu-ft/h min.
	Temp. Control		Air-mix type	
COMP. CLUTCH	Comp. Clutch	Type	Dry, single plate, Poly-V-belt drive	
		Power Consumption	40 W max./12 V	
	Refrigerant	Type	R 12	
		Quantity	800 ⁺⁵⁰ ₀ g	26.5 ^{+1.8} ₀ oz
	STEERING SYSTEM	Type	Power assisted, rack and pinon	
		Overall Ratio	17.34	
		Turns, Lock-to-Lock	3.52	
		Steering Wheel Dia.	380 mm	15.0 in
	SUSPENSION	Type, Front	Independent double wishbone, coil spring with stabilizer	
		Type, Rear	Independent double wishbone, coil spring with stabilizer	
		Shock Absorber, Front and Rear	Telescopic, hydraulic nitrogen gas-filled	

	ITEM	METRIC	ENGLISH	NOTES
WHEEL ALIGNMENT	Camber	Front	0°00'	
	Rear		-0°30'	
	Caster	Front	1°38'	
	Toe	Rear	0 mm In 3.0 mm	0 in In 0.12 in
BRAKE SYSTEM	Type	Front	Power-assisted self-adjusting ventilated disc	
	Rear		Power-assisted self-adjusting solid disc	
	Pad Surface Area:	Front	58.0 cm ² x 2	8.99 sq-in x 2
		Rear	27.9 cm ² x 2	4.32 sq-in x 2
	Parking Brake Kind and Type			Mechanical actuating, rear two wheel brakes
TIRE	Size		205/60 R 15 91 H T135/80 D 15 (Spare tire)	
ELECTRICAL	Battery		12 V-52 AH/5 HR	
	Starter		M/T: 12 V-1.6 kW, A/T: 12 V-2.0 kW	
	Alternator		12 V-100 A	
	Fuses			
	In The Under-dash Fuse/Relay Box		7.5 A, 10 A, 15 A, 20 A, 30 A	
	In The Under-hood Fuse/Relay Box		7.5 A, 10 A, 15 A, 20 A, 30 A, 40 A, 50 A, 120 A	
	Headlights	High	12 V-65 W	
		Low	12 V-55 W	
	Front Turn Signal Lights		12 V-45 CP	
	Front Parking Lights		12 V-3 CP	
	Rear Turn Signal Lights		12 V-45 CP	
	Brake/Taillights			
	(and Rear Side Marker Lights)		12 V-32/2 CP	
	Front Fog Lights		12 V-35 W	
	High Mount Brake Light		12 V-45 CP	
	Front Side Marker Lights		12 V-5 W	
	Back-up Lights		12 V-32 W	
	License Plate Light		12 V-8 W	
	Dome Lights			
	(front and rear reading lights)		12 V-5 W	
	Trunk Light		12 V-3.4 W	
	Door Courtesy Lights		12 V-3.4 W	
	Vanity mirror light		12-2 W	
	Gauge Lights		12 V-3.0 W, 1.4 W, 1.7 W	
	Indicator Lights		12 V-0.84 W, 1.12 W, 1.4 W, 2.0 W	
	Warning Lights		12 V-1.4 W	
	Illumination and Pilot Lights		12 V-1.4 W, 1.12 W, 0.84 W	
	Heater Illumination Lights		12 V-0.91 W, 0.56 W, LED	
			12 V-1.4 W	

Body Specifications



Unit: mm (in)



Maintenance

Lubrication Points 4-2
Maintenance Schedule 4-4



Maintenance

Lubrication Points	4-2
Maintenance Schedule	4-4




Lubrication Points


For the details of lubrication points and types of lubricants to be applied, refer to the Illustrated Index and various work procedures (such as Assembly/Reassembly, Replacement, Overhaul, Installation, etc.) contained in each section.

NO.	LUBRICATION POINTS	LUBRICANT
1	Engine	API Service Grade: Use "Energy Conserving II" SG grade oil 5 W-30 preferred SAE Viscosity: See chart below.
2	Transmission Manual Automatic	API Service Grade: SF or SG SAE Viscosity: 10 W-30 or 10 W-40 Honda Premium Formula Automatic Transmission Fluid or an equivalent DEXRON® II Automatic Transmission Fluid (ATF)
3		
4	Clutch Line	Brake fluid DOT3 or DOT4
5	Power steering gearbox	Steering grease P/N 08733-B070E
6	Shift lever pivots (Manual transmission)	Grease with molybdenum disulfide
7	Release fork (Manual transmission)	Multi-purpose grease
8	Steering boots	
9	Throttle cable end	
10	Steering ball joints	
11	Select lever (Automatic transmission)	
12	Pedal linkage	
13	Intermediate shaft	
14	Brake master cylinder pushrod	
15	Trunk hinges	
16	Door hinges upper and lower	
17	Door opening detents	
18	Fuel fill lid	
19	Engine hood hinges and engine hood latch	
20	Clutch master cylinder pushrod	
21	Brake pipe joint (Front and rear wheel house)	Rust preventives
22	Caliper Piston seal, Dust seal, Caliper pin, Piston	Silicone grease
23	Power steering system	Honda power steering fluid-V
24	Differential	Hypoid gear Oil GL4 or GL5 Viscosity: at above -18°C (0°F): SAE 90 at less than -18°C (0°F): SAE 80 W 90

Recommended Engine Oil
API Service Grade: Use "Energy Conserving II"
SG grade oil 5 W-30 preferred



Engine oil viscosity for
ambient temperature ranges



R - Replace I - Inspect After inspection, clean, adjust, repair or replace if necessary.

Service at the interval listed $\times 1,000$ miles (or km) or after that number of months, whichever comes first.																	
Maintenance item	Brakes	1,000 miles	15	22.5	30	37.5	45	52.5	60	67.5	75	82.5	90	97.5	105	NOTE	SEC and PAGE
Anti-lock brake system operation																Function test Wheel sensor signal confirmation Anti-lock brake system indicator light Bleed high pressure fluid	19-3
Anti-lock brake system high pressure hose																	19-71
Steering, Suspension, Miscellaneous									R								
Front wheel alignment																	
Steering tie rod ends, steering sharbox and boots																	18-4
<input type="checkbox"/> Power steering system																	17-3
<input type="checkbox"/> Power steering pump belt																	17-20
Suspension mounting bolts																	17-17
Supplemental restraint system																	18-8
<input type="checkbox"/> Under severe driving conditions, service these items more often.		Inspect system 10 years after production												-		-	


Severe Driving Conditions
Items with an or need service more often if you drive in some severe
conditions.

- A: Repaired short distance driving
- B: Dusty conditions
- C: Severe cold weather
- D: Areas with road salt or other corrosive materials
- E: Rough or muddy roads
- F: Towing a trailer

Services for Severe Driving Conditions
Clean the air cleaner element every 15,000 miles (24,000 km) or 12 months and replace every 30,000
miles (48,000 km) or 24 months under condition B or E.

- Replace engine oil and oil filter every 3,750 miles (6,000 km) or 3 months under condition A, B or F.
- Replace transmission oil every 15,000 miles (24,000 km) or 12 months under condition F.
- Replace front differential oil every 15,000 miles (24,000 km) or 12 months under condition F.
- Inspect front brake discs and calipers, and rear brake discs, calipers and pads every 7,500 miles (12,000
km) or 6 months under condition A, B, D, E or F.
- Inspect the power steering system every 7,500 miles (12,000 km) or 6 months under condition B, C or E.

Engine Removal/Installation




Engine

Engine Removal/Installation.....	5-1
Cylinder Head/Valve Train.....	6-1
Engine Block.....	7-1
Engine Lubrication.....	8-1
Intake Manifold/Exhaust System.....	9-1
Cooling	10-1

Special Tools

Ref. No.	Tool Number	Description	Qty	Page Reference
①	07LAC-PW50101	Extension Shaft Puller	1	5-7



①

Engine Removal/Installation



WARNING

- Make sure jacks and safety stands are placed properly and hoist brackets are attached to the correct positions on the engine (see section 1).
- Make sure the car will not roll off stands and fall while you are working under it.

CAUTION:

- Use fender covers to avoid damaging painted surfaces.
- Unspecified items are common.
- Unplug the wiring connectors carefully while holding the coupler and the connector portion to avoid damage.
- Mark all wiring and hoses to avoid mis-connection. Also, be sure that they do not contact other wiring or hoses or interfere with other parts.

NOTE: Anti-theft radios have a coded theft protection circuit. Be sure to get the customer's code number before

- Disconnecting the battery.
- Removing the No. 39 (10 A) fuse in the under-hood fuse/relay box.
- Removing the radio.

After service, reconnect power to the radio and turn it on.

When the word "CODE" is displayed, enter the customer's 5-digit code to restore radio operation.


1. Disconnect the battery negative terminal first, then the positive terminal.

2. Remove the radiator cap.

WARNING: Use care when removing the radiator cap to avoid scalding by hot engine coolant or steam.

3. Raise the hoist to full height.

4. Remove the engine splash shield.



5. Drain the engine coolant (page 10-5).
 - Loosen the drain plug in the radiator.

6. Drain transmission and differential oil/fluid. Reinstall the drain plugs using new washers.


7. Drain the engine oil. Reinstall the drain bolt using a new washer.

CAUTION: Do not overtighten the drain bolt.

8. Lower the hoist.


9. Secure the hood as far open as possible.

10. Remove the ignition coil wire, condenser wire and engine ground cable.



11. Remove the ABS motor relay box and the battery heat shield, then remove the battery.

6 x 10 mm
10 N·m (1.0 kg·m, 7 lb·ft)




(cont'd)

Engine Removal/Installation

(cont'd)

12. Remove the intake air duct and the air cleaner (ACL) housing.




13. Relieve fuel pressure by slowly loosening the service bolt on the fuel filter about one turn (see section 11).

WARNING Do not smoke while working on the fuel system. Keep open flame away from work area. Drain fuel only into an approved container.

CAUTION:

- Before disconnecting any fuel line, relieve the fuel pressure as described above.
- Place a shop towel over the fuel filter to prevent pressurized fuel from spraying over the engine.


14. Remove the fuel feed hose from the fuel filter and the fuel return hose from the fuel pressure regulator (see section 11).




15. Remove the throttle cable by loosening the locknut, then slip the cable end out of the accelerator linkage.

NOTE:


- Take care not to bend the cable when removing it. Always replace any kinked cable with a new one.
- Adjust the throttle cable when installing (see section 11).




16. Remove the throttle cable clamp and the injector resistor connector.



17. Remove the engine wire harness connectors and clamps.




19. Remove the heater hoses and disconnect the transmission sub-wire harness connector (A/T) or back-up light switch connector (M/T).



20. Disconnect the ignition wires, then remove the distributor.

NOTE: When installing the distributor, first install the collar on the distributor.




O-RINGS
Replace.

Engine Removal/Installation


(cont'd)

21. Remove the engine wire harness from the under-hood fuse/relay box, then remove the transmission ground cable.




ENGINE WIRE HARNESS

22. Loosen the adjusting bolt, then remove the mounting bolt/nut, the power steering (P/S) pump belt and pump.




23. Loosen the idler pulley center nut and adjusting bolt, then remove the air conditioning (A/C) compressor belt and compressor.

- Do not disconnect the hoses.
- Disconnect the connector.




24. Remove the vehicle speed sensor (VSS)/power steering speed sensor.

- Do not disconnect the fluid hoses.




25. Remove the radiator.

- Disconnect the connectors and automatic transmission fluid (ATF) cooler hoses.




26. Remove the torque converter cover (A/T). Remove the drive plate bolts one at a time while rotating the crankshaft pulley.



27. Remove the transmission housing mounting bolts and the 26 mm shim.

28. Remove the transmission sub-harness connector.




29. Remove the damper forks.

30. Disconnect the suspension lower arm ball joints with the special tool. Refer to section 18 for the proper procedure.

31. Remove the driveshafts.

NOTE:

- Coat all precision finished surfaces with clean engine oil or grease.
- Tie plastic bags over the driveshaft ends.




(cont'd)

Engine Removal/Installation


(cont'd)

32. Raise the hoist.

33. Remove the exhaust pipe A.




34. Remove the transmission mount and mount bracket.




35. Shift the manual transmission to 1st gear or automatic transmission to **P** position.

36. Remove the secondary cover and 33 mm sealing bolt.

37. Remove the extension shaft from the differential using the special tool as shown.




38. Attach a chain hoist to the engine.




39. Remove the left front engine mount nut and engine mount damper bolt.

40. Remove the right front engine mount nut.




41. Remove the mid mounts.



42. Remove the transmission housing mounting bolts and clutch cover (M/T) or torque converter cover (A/T), then separate the engine and the transmission.

- Attach the transmission jack with a rubber pad or wooden block.



43. Install the mid mounts to the transmission and retorque the mounting bolts.

44. Raise the chain hoist to remove all slack from the chain.

45. Check that the engine is completely free of vacuum hoses, fuel and coolant hoses, and electrical wiring.

46. Slowly raise the engine approximately 150 mm (6 in).

Check once again that all hoses and wires have been disconnected from the engine.

47. Raise the engine all the way and remove it from the car.

(cont'd)

Engine Removal/Installation

(cont'd)

48. Install the engine in the reverse order of removal.

NOTE:

- If engine block and/or differential case are replaced, the 26 mm shim thickness must be adjusted (see section 15).
- Fill the opening of the drive pinion and extension shaft with Super High Temp Urea Grease (P/N 08798-9002) and apply the same grease to the spines before installing the transmission (see section 13 (M/T) and 14 (A/T)).
- After service, reconnect power to the radio and turn it on, the word "CODE" will be displayed. Enter the customer's 5-digit code to restore radio operation.


After the engine is in place:

- Torque the engine mount bolts and nuts in sequence shown below.

CAUTION: Failure to tighten the bolts in the proper sequence can cause excessive noise and vibration, and reduce bushing life; check that the bushings are not twisted or offset.

RIGHT FRONT ENGINE MOUNT

⑤ 75 N·m (7.5 kg-m, 54 lb-ft)



Engine Mount Bolts and Nuts Torque Sequence:

CAUTION: After loosening the special bolts, be sure to replace them with new ones.

⑥ 55 N·m (5.5 kg-m, 40 lb-ft)

TRANSMISSION MOUNT

⑥ 55 N·m (5.5 kg-m, 40 lb-ft)

⑦ 65 N·m (6.5 kg-m, 47 lb-ft) Replace.

LEFT FRONT ENGINE MOUNT

④ 75 N·m (7.5 kg-m, 54 lb-ft)


③ 55 N·m (5.5 kg-m, 40 lb-ft)

② 44 N·m (4.4 kg-m, 32 lb-ft)

① 44 N·m (4.4 kg-m, 32 lb-ft)

② 44 N·m (4.4 kg-m, 32 lb-ft)

① 44 N·m (4.4 kg-m, 32 lb-ft)



- Check that the spring clip on the end of each driveshaft clicks into place.

CAUTION: Use new spring clips.

- Bleed air from the cooling system at the bleed bolt with the heater valve open.
- Adjust the throttle cable tension.
- Check the clutch pedal freeplay.
- Check that the transmission shifts into gear smoothly.
- Adjust the tension of the following drive belts: Alternator belt (see section 23). Power steering pump belt (see section 17). A/C compressor belt (see section 22).
- Clean battery posts and cable terminals with sandpaper, assemble, then apply grease to prevent corrosion.
- Inspect for fuel leakage.

• After assembling fuel line parts, turn on the ignition switch (Do not operate the starter) so that the fuel pump operates for approximately two seconds and the fuel line is pressurized. Repeat this operation two or three times and check for fuel leakage at any point in the fuel line.

Mount and Bracket Bolts/Nuts Torque Value Specifications:

12 x 1.25 mm
75 N·m (7.5 kg-m, 54 lb-ft)

10 x 1.25 mm
60 N·m (6.0 kg-m, 43 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

12 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)


12 x 1.25 mm
55 N·m (5.5 kg-m,

Engine Removal/Installation

(cont'd)

Additional Torque Value Specifications:

NOTE: For manifold replacement, refer to section 9.



Product: 1993 Acura Vigor Car Service Repair Workshop Manual
Full Download: <https://www.arepairmanual.com/downloads/1993-acura-vigor-car-service-repair-workshop-manual/>

Cylinder Head/Valve Train

Special Tools	6-2
Illustrated Index	6-3
Valve Seats	
Replacement (Cylinder head removal not required)	6-5
Cylinder Head	
Removal	6-7
Warpage	6-16
Installation	6-24
Camshaft Pulley	
Removal	6-10
Rocker Arm Assembly	
Removal	6-10
Rocker Arms	
Overhaul	6-11
Camshaft	
Inspection	6-12
Rocker Arms and Shafts	
Clearance	6-14
Valves, Valve Springs and Valve Seats	
Removal	6-15
Installation Sequence	6-21
Valve Installation	6-22
Valve Guides	
Valve Movement	6-17
Replacement	6-19
Reaming	6-20
Valve Seats	
Reconditioning	6-18
Camshaft/Rocker Arms and Camshaft Seals	
Installation	6-22
Timing Belt	
Illustrated Index	6-26
Inspection	6-27
Tension Adjustment	6-27
Crankshaft Pulley Bolt	
Replacement	6-28
Removal	6-29
Installation	6-31
Valve Clearance	
Adjustment	6-33
TDC/CKP/CYP Sensors	
Replacement	6-35

Sample of manual. Download All 21 pages at
<https://www.arepairmanual.com/downloads/1993-acura-vigor-car-service-repair-workshop-manual/>

