

GROUP 04

CONTENTS

4 cylinders **16 18 20**

AIR CLEANER	04-3	ON VEHICLE ACCELERATING	
Removal	04-4	PUMP OUTPUT TEST	04-18
Inspection	04-4	FUEL SYSTEM DIAGRAM	04-20
Installation	04-4	Removal	04-24
AIR MIXER	04-4	Inspection	04-24
Description	04-4	Installation	04-24
Inspection	04-4	EXHAUST SYSTEM	04-25
FUEL PUMP	04-5	Inspection	04-28
Inspection	04-5	Removal	04-28
CARBURETTERS	04-6	Installation	04-28
Weber twin barrel carburetters	04-6	SPECIFICATIONS AND GENERAL	
Solex twin barrel carburetters	04-9	REQUIREMENTS	04-29
Dellorto twin barrel carburetters	04-12	Specifications	04-29
Dellorto twin barrel carburetters		General requirements	04-29
(for Switzerland, Sweden, Australia) ..	04-13	Checks and adjustments	04-38/1
General overhaul	04-16	Tightening torques	04-39
ACCELERATOR LINKAGE	04-17	TROUBLESHOOTING	04-39
LOAD SENSOR ADJUSTMENT	04-17	SPECIAL TOOLS	04-42

4 cylinders **2.0** iniezione

DESCRIPTION	04-43	Fuel tank	04-53
General	04-43	Fuel level gauge	04-53
Motronic injection system	04-43	Submerged pump and grid filter	04-54
Ignition system	04-43	Fuel piping	04-54
Valve timing variator system	04-44	Main fuel pump	04-54
Motronic fuel system diagram	04-44	Fuel filter (*)	
Wiring and main components of		Hammering damper	04-55
Motronic system	04-45	Electroinjectors	04-55
Important general information	04-45	Fuel pressure regulator	04-57
AIR SUPPLY SYSTEM	04-46	SETTINGS AND ADJUSTMENTS	04-58
Air filter	04-47	Setting of throttle body	
Air flow gauge	04-48	(check with flowmeter)	04-58
Auxiliary air solenoid valve	04-48	Setting of accelerator throttle switch ..	04-58
Throttle body	04-49	Check of fuel system pressure and	
Intake air box	04-50	system tightness (*)	
FUEL SUPPLY SYSTEM	04-52	Adjustment of accelerator control cable (*)	

CONTENTS (Contd)

4 cylinders **2.0** Iniezione

Adjustment of idle r.p.m. (*)		TROUBLE DIAGNOSIS AND	
Adjustment of exhaust CO percentage (*)		CORRECTIVE ACTION	04-64
EXHAUST SYSTEM (**)	04-59	SPECIAL SERVICE TOOLS	04-66
SERVICE DATA AND SPECIFICATIONS	04-60	MOTRONIC INJECTION WIRING	
Technical data	04-60	DIAGRAM	04-67
Checks and adjustments	04-61	ELECTRICAL TESTS	04-68
General requirements	04-63	ELECTRICAL DATA	04-70

4 cylinders **Alfa 75 1.8** turbo

DESCRIPTION	04-70/1	Setting of throttle body	
Fuel supply system diagram		(with flowmeter)	04-70/21
(LE2 Jetronic and		Throttle position sending unit	
EZ 201K TURBO)	04-70/1	adjustment	04-70/22
General description	04-70/2	Minimum cutout switch	
Wiring and main components		adjustment	04-70/23
of combined LE2 Jetronic		Waste-gate valve check and	
and EZ 201K TURBO system	04-70/3	adjustment	04-70/24
Important general information	04-70/4	Adjustment of	
AIR SUPPLY AND		accelerator control	04-70/25
SUPERCHARGING SYSTEM	04-70/5	Check and adjustment of	
Air filter	04-70/6	idle R.P.M.	04-70/25
Air flow gauge	04-70/6	Check and adjustment of	
Supercharging pressure regulation		exhaust emissions (C.O.)	04-70/25
solenoid valve	04-70/7	EXHAUST SYSTEM	04-70/27
Auxiliary air valve	04-70/7	Manifold and silencers	04-70/28
Throttle body	04-70/8	Rubber support	04-70/28
Throttle position sending unit	04-70/9	SERVICE DATA AND	
Minimum cutout switch	04-70/10	SPECIFICATIONS	04-70/29
Intercooler	04-70/10	Technical data	04-70/29
Turbocharger	04-70/11	Checks and adjustments	04-70/31
Waste-gate valve	04-70/14	General specifications	04-70/33
FUEL SUPPLY SYSTEM	04-70/15	ELECTRICAL TESTS	04-70/35
Fuel tank	04-70/16	TROUBLE DIAGNOSIS AND	
Fuel level gauge	04-70/16	CORRECTIONS	04-70/37
Auxiliary fuel pump and		Ignition ECU self test	04-70/37
grid filter	04-70/17	Engine	04-70/38
Fuel piping	04-70/17	Fuel supply and ignition system ...	04-70/41
Main fuel pump	04-70/18	SPECIAL TOOLS	04-70/63
Fuel pressure regulator	04-70/18	INJECTION (LE2 JETRONIC) AND	
Hammering damper	04-70/18	IGNITION (EZ 201K TURBO)	
Electroinjectors	04-70/19	WIRING DIAGRAM	04-70/65
SETTINGS AND ADJUSTMENTS	04-70/21		

CONTENTS (Contd)

6 cylinders Alfa 90 2.5  iniezione

6 cylinders Alfa 75 2.5  6V iniezione

6 cylinders GTV 6 2.5

DESCRIPTION	04-71	Cold starting electroinjector	04-83
General	04-71	Electroinjectors	04-83
L-Jetronic injection system	04-71	Fuel pressure regulator	04-85
Ignition system	04-71	SETTING AND ADJUSTMENTS	04-85
L-Jetronic fuel supply diagram (except Switzerland, Sweden, Australia)	04-72	Setting of throttle body (check with flowmeter)	04-85
L-Jetronic fuel supply diagram (for Switzerland, Sweden, Australia)	04-72/1	Setting of accelerator throttle switch	04-86
Wiring and main components of L-Jetronic system GTV 6 2.5	04-72/2	Check of fuel system pressure and system tightness (*)	
Wiring and main components of L-Jetronic system Alfa 90 - Alfa 75 ...	04-73	Adjustment of accelerator control cable (*)	
Important general information	04-74	Adjustment of engine idle r.p.m. (*)	
AIR SUPPLY SYSTEM	04-74	Adjustment of exhaust CO percentage (*)	
Air filter	04-75	EXHAUST EMISSION CONTROL	
Air flow gauge	04-76	SYSTEM Alfa 90 - Alfa 75	
Auxiliary air solenoid valve	04-76	(for Australia only)	04-86/1
Throttle body	04-77	EXHAUST EMISSION CONTROL	
Intake air box (except Switzerland, Sweden, Australia)	04-78	SYSTEM GTV 6 2.5	
Intake air box (for Switzerland, Sweden, Australia)	04-78/1	(for Australia only)	04-86/2
Vacuum regulating valve (for Switzerland, Sweden, Australia only)	04-79	EXHAUST SYSTEM	04-87
FUEL SUPPLY SYSTEM		Manifold and silencers	04-88
Alfa 90 - Alfa 75	04-80	Rubber supports	04-88
FUEL SUPPLY SYSTEM GTV 6 2.5	04-80/1	SPECIFICATIONS AND GENERAL	
Complete fuel tank	04-81	REQUIREMENTS	04-90
Fuel level gauge	04-81	Specifications	04-90
Submerged pump and grid filter		Checks and adjustments	04-92
Alfa 90 - Alfa 75	04-82	General requirements	04-93
Fuel piping	04-82	TROUBLE DIAGNOSIS AND	
Main fuel pump	04-82	CORRECTIVE ACTION	04-94
Fuel filter (*)		SPECIAL SERVICE TOOLS	04-96
Dashpot Alfa 90 - Alfa 75	04-83	L-JETRONIC INJECTION WIRING	
		DIAGRAM Alfa 90	04-97
		L-JETRONIC INJECTION WIRING	
		DIAGRAM Alfa 75	04-98
		L-JETRONIC INJECTION WIRING	
		DIAGRAM GTV 6 2.5	04-99
		ELECTRICAL DATA	04-101

CONTENTS (Contd)

6 cylinders Alfa 90 2.0 6V iniezione

DESCRIPTION	04-103	Installation	04-127
CEM System	04-103	RPM AND TIMING SENSOR	04-128
Fuel injection system	04-103	Description	04-128
Ignition system	04-103	Inspection	04-128
CEM fuel system diagram	04-104	Replacement	04-128
CEM wiring and main components ..	04-105	Installation	04-128
Important	04-106	TUNING AND ADJUSTMENTS	04-130
AIR SUPPLY SYSTEM	04-107	Throttle unit tuning	04-130
Air cleaner	04-108	Accelerator control adjustment	04-130
Air temperature sensor	04-110	Main pump check and system	
Air induction chambers	04-111	leakage testing (*)	
Throttle unit		Idle adjustment (*)	
(front - center - rear)	04-113	Emission check and adjustment	04-131
Injector supports	04-116	Throttle stop actuator check (*)	
Throttle stop actuator		Throttle angle sensor check (*)	
(steady-state idle)	04-117	Pressure regulator check (*)	
Throttle angle sensor	04-118	EXHAUST SYSTEM (**)	
Coolant temperature sensor	04-120	SPECIFICATIONS AND GENERAL	
FUEL SUPPLY SYSTEM	04-121	REQUIREMENTS	04-133
Fuel tank	04-122	Specifications	04-133
Fuel level gauge sender	04-122	Checks and adjustment	04-137
Tank pump and strainer	04-123	General requirements	04-138
Fuel lines	04-123	TROUBLESHOOTING	04-139
Main fuel pump	04-123	SELF-DIAGNOSTIC SYSTEM	04-149
Fuel filter	04-124	TROUBLESHOOTING USING	
Fuel injectors	04-124	DIAGNOSTIC TESTER	04-151
Fuel pressure regulator	04-125	SPECIAL TOOLS	04-153
ELECTRONIC CONTROL UNIT	04-127	CEM SYSTEM INJECTION	
Description	04-127	WIRING DIAGRAM	04-155
Inspection	04-127	ELECTRICAL TESTS	04-157
Replacement	04-127	ELECTRICAL DATA	04-160

(*) Refer to: Workshop Manual Alfa 90 - GROUP 00

(**) Refer to 1.6 - 1.8 - 2.0 EXHAUST SYSTEM

(*) Refer to: Workshop Manual Alfa 90 2.0 6V iniezione - GROUP 00

(**) Refer to: 6 cylinders Alfa 90 2.5 iniezione - GROUP 04 - Exhaust System

ACCELERATOR LINKAGE ADJUSTMENT


1.6 1.8 2.0

- Check that flexible shafting does not bind in its conduit.
- With the accelerator pedal fully depressed check distance «G» from throttle lever pivot ① to stop.

Pivot pin to stop clearance:

Gap «G» = 1 to 2 mm
(0.04 to 0.08 in).

- To adjust work from the car interior proceeding as follows:
 - Back off locknut on accelerator pedal stop screw.
 - Adjust stop screw to obtain the specified clearance.
 - Tighten locknut.



LOAD SENSOR ADJUSTMENT


Alfa 90 1.8 2.0

Alfa 75 1.6 1.8 2.0

- Supply load sensor ① at 4.9 ± 0.05 V through terminals 1 and 3.
- Keep throttle shaft on rear carburettor against stop in idle position.
- Turn sensor ① to obtain a 4 ± 0.1 V output measured across terminals 1 and 2.
- Tighten load sensor capscrews ② to the specified torque.


CAUTION:

When tightening capscrews ② ensure that output voltage is not altered by possible load sensor rotation.



- Load sensor
- Capscrews

Connections diagram



Cables	Terminals	Colours
A	1	Orange
B	2	Green
C	3	Black


T : Tightening torque
Load sensor capscrews
 11 to 18 Nm
 (1.17 to 1.8 kgm
 8.1 to 13.3 ft.lb)

ON VEHICLE ACCELERATING PUMP OUTPUT TEST

1.6 1.8 2.0

With the carburettor on vehicle, and preferably with the engine cold, check the accelerating pump as follows:

a. Remove four capscrews (1) and lift out the accelerating pump jets from the respective venturi.



1. Jet capscrews

b. Screw four tester rods (1) into jet holes according to type of carburettor.


Horizontal carburettor tester:

Weber:	C.4.0124
Solex:	C.4.0123
Dellorto:	C.4.0125

c. Install four supports (2) complete with respective graduated test tubes (3) on top of four rods (1).

d. Connect four plastic hoses (4) to the ends of the four rods (1).


e. Connect free ends of plastic hoses (4) to the respective accelerating pump jets (5), previously removed.



NOTE:
For SOLEX carburettors insert a reducing tube (6) between jet and plastic hose.

f. Place four pump jets (5) inside the respective graduated test tubes (3).

g. To ensure that the carburettor chamber is filled turn the engine over for a few seconds through the starter.



- 1. Rods
- 2. Supports
- 3. Graduated test tubes
- 4. Plastic hoses
- 5. Accelerating pump jets
- 6. Reducing tube



FUEL SYSTEM

2. If not so, loosen screws ① and rotate switch until contact ($\sim 0 \Omega$ resistance) between terminals 2 and 18 is obtained, with throttle fully closed; retighten the screws.

3. Rotate throttle by 72° and verify that the full load contact closes, by measuring the following resistances with a tester on male connector:

- 0Ω resistance (approx.) must be measured between terminals 3 and 18, when accelerator throttle is open by an angle of $\alpha \approx 72^\circ$.

4. If the values measured are not those prescribed check accelerator control, or replace switch.



- 1 Screws securing switch to throttle body
- 2 Idle r.p.m. terminal (corresponding to position A: throttle closed)

- 3 Peak r.p.m. terminal (corresponding to position B: throttle open)

EXHAUST SYSTEM

Refer to: **16** **18** **20** "Exhaust system".

FUEL SYSTEM

SERVICE DATA AND SPECIFICATIONS

TECHNICAL DATA

SUPPLY AND INJECTION SYSTEM COMPONENTS

Component		ALFA ROMEO Std. Number	Type
Main fuel pump		116.46.04.021.00	BOSCH 0.580.464.020
Fuel pressure regulator		195.00.32.045.00	BOSCH 0.280.160.213
Electroinjectors	Pre-modification	116.85.11.300.00 (1)	BOSCH 0.280.150.128
	Post-modificaion	195.26.11.300.01 (2)	BOSCH 0.280.150.707
Air flow gauge	Pre-modification	195.00.11.013.00	BOSCH 0.281.202.045
	Post-modification	195.26.11.013.00	BOSCH 0.280.202.078
Control unit	Pre-modification	195.00.11.042.00	BOSCH 0.261.200.044
	Post-modification	161.10.11.042.00	BOSCH 0.261.200.063

- (1) Black nozzle
(2) Yellow nozzle


FUEL TANK

Data	Measurement unit	
	litres	(Imp.gall)
Overall capacity	49	10.78
Reserve	8	1.76

DESCRIPTION

Alfa 75 1.3 turbo

FUEL SUPPLY SYSTEM DIAGRAM (LE2 JETRONIC AND EZ 201K TURBO)



- | | |
|--|--|
| <ul style="list-style-type: none"> 1. Fuel tank 2. Intercooler 3. Hammering damper 4. Throttle body 5. Auxiliary air valve 6. Minimum cutout switch 7. Fuel distributor manifold 8. Throttle position sending unit 9. Fuel pressure regulator 10. Electro-injector resistances 11. Fuel supply ECU 12. Speedometer relay 13. Ignition ECU 14. Air filter | <ul style="list-style-type: none"> 15. Supercharging pressure regulation solenoid valve 16. Air flow gauge 17. Intake air temperature sensor 18. Waste-gate valve 19. Compressor 20. Turbine 21. Coolant temperature sensor 22. Knock sensor 23. Ignition distributor 24. HALL effect sensor 25. Power module 26. Ignition coil 27. Electroinjectors 28. Oil vapour sedimenter 29. Fuel filter 30. Main fuel pump 31. Auxiliary fuel pump |
|--|--|

GENERAL DESCRIPTION

The fuel is supplied, by means of the two electric pumps (30) and (31) from tank (1) to the electroinjectors (27) through hammering damper (3).

Pressure regulator (9) regulates the fuel pressure in fuel distributor manifold (7) excluding to the intercooler (2) air intake pressure in order to maintain the difference between the fuel pressure and the pressure in the intake manifold constant.

When the fuel pressure exceeds the maximum pressure set (3 bar; 43.50 psi) the pressure regulator causes the return of the excess fuel to the tank. The quantity of fuel injected therefore depends exclusively on injection time (which is determined by injection control unit (11) on the basis of the quantity of intake air), its temperature and the temperature of the engine.

The quantity of intake air and its temperature are measured, respectively, by air flow gauge (16) and sensor (17), while the temperature of the engine is measured by sensor (21).

From air flow gauge (16) the air enters compressor (19), where it is compressed, and then throttle body (4) composed of two throttles mechanically connected so that when the accelerator is depressed the second throttle begins opening after the first has rotated about 40°.

The degree of opening of the throttles is measured by throttle position sending unit

(8) which sends the relative signal to ignition ECU (13).

A minimum cutout switch (6) is also fitted on the throttle body. When this switch is activated by the release of the accelerator pedal it sends a signal to injection control unit (11) which cuts off the supply of fuel to the electroinjectors.

From the throttle body the compressed intake air, before entering the cylinders, passes through intercooler (2) where it is cooled to reduce the possibility of spark knock is detected by knock sensor (22) which sends a signal to ignition ECU (13) which corrects the spark advance (towards a delay) until the knock is eliminated. If this correction of the advance does not solve the problem the ignition ECU, will, by means of supercharging pressure regulation solenoid valve (15) regulate waste-gate valve (18) in order to reduce the supercharging pressure.

In normal operating conditions the supercharging pressure is regulated by the ignition ECU on the basis of the throttle opening signal from throttle position sending unit (8), the rpm signal provided by the Hall effect sensor (24) on the ignition distributor (23) and engine efficiency.

Engine starting is controlled by speedometer relay (12), injection control unit (11) and ignition ECU (13).

The speedometer relay, receiving the impulse from starting block, is energized and supplies the ECUs, petrol pump and electroinjectors.

After the completion of the starting operation the relay is maintained energized by the feed voltage from ignition coil (26) and by the engine rpm signal from the ignition control unit.


Should there fail to be one of these signals the speedometer relay will be de-energized, thus cutting off the power to the fuel supply system.

During running with a cold engine a greater quantity of mixture is supplied for combustion.

This increased quantity is determined by auxiliary air valve (5) located on bypass of the throttle body (4) which progressively closes with the increase of the engine temperature.

FUEL SYSTEM

WIRING AND MAIN COMPONENTS OF COMBINED LE2 JETRONIC AND EZ 201K TURBO SYSTEM




- | | | |
|--------------------------------|---|--------------------------|
| 1. Injection control unit | 8. Knock sensor | 14. Air flow gauge |
| 2. Ignition ECU | 9. Auxiliary air valve | 15. Hall effect sensor |
| 3. Speedometer relay | 10. Fuel cut-off switch | 16. Ignition distributor |
| 4. Body wiring junction | 11. Throttle position sending unit | 17. Ignition coil |
| 5. Electroinjector resistances | 12. Throttle position sending unit connector | 18. Power module |
| 6. Coolant temperature sensor | 13. Supercharging pressure regulator solenoid valve | |
| 7. Electroinjectors | | |

IMPORTANT GENERAL INFORMATION

- **Never disconnect the battery while the engine is running or with the ignition on (position 2) as this would cause serious and irreversible damage to the electrical and electronic components of the ECUs of the system.**
 - Never start the engine unless the battery terminals are fully tightened.
 - Never start the engine by fast battery charging.
 - Always disconnect the battery completely from the system before recharging.
 - Never start the engine if electrical connections are incorrect or if components have been removed from their seats.
 - Never ground the high/low voltage parts or break connections while the engine is running.
- Remove the electronic control units if vehicle is to be furnace-painted at temperatures higher than 80°C (176°F).
 - In the event of installation or ancillary equipment, always disconnect the electronic control units in order to carry out the functional test of ancillary equipment itself with ECUs disconnected.
Never connect other devices to ECU wiring.
 - Before beginning work on the various components of the system check for disconnected connectors, loose clamps or cut or visibly obstructed tubes.
 - Never connect the plug to the ECU leads (or disconnect it) with ignition on.
 - Never ground the high/low voltage cables for test purposes.
 - Verify that shielded wire connectors are correctly secured.
 - Verify the efficiency of the ignition system and the spark plugs and check that the timing cover is not wet or cracked. Check that the cables between coil and distributor and between distributor and spark plugs are correctly connected and that the insulation reveals no trace of burning or abrasion.
- When replacing fuses disconnect the power supply (disconnect the contact). If a fuse burns repeatedly seek the cause of the short circuit.
Never replace a fuse with a piece of cable.
A burnt fuse must be replaced with another of the same amperage.

AIR SUPPLY AND SUPERCHARGING SYSTEM



- 1. Intercooler
- 2. Throttle body
- 3. Throttle position sending unit
- 4. Supercharging pressure gauge
- 5. Auxiliary air valve
- 6. Oil vapour sedimenter
- 7. Air flow gauge

- 8. Air filter
- 9. Supercharging pressure regulation solenoid valve
- 10. Waste-gate valve
- 11. Compressor
- 12. Turbine



FUEL SYSTEM



AIR FILTER

REMOVAL

Remove air filter unit operating as follows:


1. Slacken clamp ① and detach sleeve ② from air flow gauge ③.
2. Detach connector ④ from air flow gauge ③ and remove securing bolt ⑤.
3. Remove nuts ⑥ and solenoid valve ⑦ from air filter cover ⑧.
4. Release the five clips securing the cover and remove it together with air flow gauge.

Remove filtering element.



1. Clamps
2. Air duct
3. Air flow gauge
4. Air flow gauge connector
5. Air duct securing bolt
6. Solenoid valve securing nuts
7. Supercharging pressure regulation solenoid valve
8. Air filter cover

5. If required, unscrew the screws ⑨ securing air filter container ⑩ to body and remove.




9. Container securing nuts
10. Air filter container

CHECKS AND INSPECTIONS

1. Thoroughly clean the filtering element by blowing low-pressure compressed air through it.
- Replace the filtering element if required.

1. Air flow gauge securing screws
2. Air flow gauge
3. Air filter cover
4. Gaskets
5. Inlet flange



INSTALLATION

Install air filter by reversing the order of removal.

NOTE:

Position the filtering element on air filter container, complying with the mark indicating upper part (on filtering element upper side).


AIR FLOW GAUGE

ELECTRICAL TESTS

Refer to «Electrical Tests».

REMOVAL

1. Remove air filter unit (see «Air Filter — Removal»).
2. Unscrew the four screws ① securing the air flow gauge ② to the filter cover ③.
3. Remove air flow gauge ② with relative gaskets ④ and inlet flange ⑤ from the filter cover.



FUEL SYSTEM

CHECKS AND INSPECTIONS

Press the floating blade of the air flow gauge and check that it rotates without sticking, that there are no impediments up to stop position, and that there is no scoring or traces of dirt.

If necessary, clean the internal surfaces of the air flow gauge with a clean, dry cloth.

INSTALLATION

1. Install the air flow gauge by reversing the order of removal; replace gaskets.

CAUTION:

Pay particular attention to the tightening of the unions in order to prevent local air inlets.

2. After installation check (and adjust if necessary) the exhaust CO percentage (refer to: «Settings and Adjustments»).

SUPERCHARGING PRESSURE REGULATION SOLENOID VALVE


ELECTRICAL TESTS

Refer to: «Electrical Tests».

REMOVAL



1. Disconnect connector (1).
2. Disconnect hoses (2), (3) and (4) from solenoid valve (5).
3. Remove nuts (6) and then the solenoid valve from air filter cover (7).

1. Solenoid valve connector
2. Pressure intake hose from compressor
3. Waste-gate valve connecting hose
4. Oil vapour sedimenter connecting hose
5. Solenoid valve
6. Solenoid valve retaining nuts
7. Air filter cover



CHECKS AND INSPECTIONS

1. Pass compressed air (the pressure must not be excessive so as not to damage the solenoid valve) through inlet (1) and check that the air comes out outlet (2).
2. Apply a voltage of 12 V to connector (3) and check that air comes out outlet (4).



1. Waste-gate valve connection
2. Pressure intake from compressor
3. Solenoid valve connector
4. Oil vapour sedimenter connection

INSTALLATION

Install the supercharging pressure regulation solenoid valve by reversing the order of removal.

CAUTION:

When re-connecting the hoses take care that they are in exactly the same positions (it is especially important that the waste-gate valve be connected to the blue connector of the solenoid valve).

AUXILIARY AIR VALVE


CHECKS AND INSPECTIONS

1. Valve opening check

- a. Make sure that the engine is cold, then start it and throttle (several times) outlet hose (1) of valve (2).
- b. Verify that engine r.p.m. decreases, and that this decrease is more and more gradual (at an ambient temperature of 20°C (68°F) the r.p.m. decrease is no longer evident after about 3 min.).

2. Valve closing check

With the engine at normal running temperature, throttle outlet hose (1) of the solenoid valve and verify that engine r.p.m. does not decrease.



1. Air outlet hose
2. Auxiliary air valve


FUEL SYSTEM

3. Check of valve electrical continuity

Refer to: «Electrical Tests».


REPLACEMENT

1. Detach connector (4).
2. Loosen clamps and detach hoses (1) and (3) from valve (2).
3. Unscrew screws (6) and remove valve (2) from timing system cover, disconnecting ground cables (5).




1. Cover retaining screws
2. Protective cover
3. Sending unit connector

3. Detach cables (4) from minimum cutout switch (5).




4. Minimum cutout switch feed cables
5. Minimum cutout switch

4. Remove stop ring (6), detach accelerator control cable (7) and release sheath (8) from bracket.




6. Stop ring
7. Accelerator cable
8. Sheath

5. Loosen clamp (9) securing throttle body union (10) to turbocharger.




9. Clamp
10. Union

6. Loosen clamps (11) securing throttle body to intercooler (12).



11. Clamps
12. Intercooler



1. Air outlet hose
2. Auxiliary air valve
3. Air inlet hose
4. Valve connector
5. Ground cables
6. Screw securing valve to timing system cover

4. Position the new valve on the timing system cover and secure it together with the ground cables, using new washers. Reconnect both inlet and outlet air hoses and make the electrical connection.

THROTTLE BODY


REMOVAL

Remove throttle body assembly in the following manner:

1. Detach the negative terminal from the battery.
2. Unscrew retaining screws (1), remove protective cover (2) and detach connector (3).


FUEL SYSTEM

7. Unscrew the screw (13) and screws (14) securing the throttle body to the timing system cover.
8. Detach hose (15) from auxiliary air valve (16).



13. Intercooler retaining screw
14. Throttle body retaining screws
15. Auxiliary air hose
16. Auxiliary air valve

9. Remove throttle body (17) complete.




17. Throttle body

CAUTION:

- Never tamper with throttle body adjustment.
- Plug the turbocharger delivery duct and intercooler intake to prevent the entrance of foreign matter.

Throttle body disassembly

1. Remove throttle body complete with union connecting turbocharger and rubber sleeve connecting intercooler.
2. Detach tie rod (1) from cam (2).



1. Tie rod
2. Cam
3. Throttle body retaining screws
4. Throttle body

3. Remove the four retaining screws (3), withdraw throttle body (4) and retrieve gasket (5) and bracket (6).
4. Unscrew the two screws (7) and remove throttle sending unit (8).

5. Gasket
6. Accelerator cable support bracket
7. Sending unit retaining screws
8. Sending unit

Throttle body assembly

Carry out the installation by reversing the order of removal.

Check gasket (5), replacing it if necessary and adjust throttle position sending unit (8) (refer to: «Settings and Adjustments»).

THROTTLE POSITION SENDING UNIT

ELECTRICAL TESTS

Refer to: «Electrical Tests».


INSTALLATION

Carry out installation of the complete throttle body by reversing the order of removal, taking care to restore the electrical connections correctly and fully tighten the clamps on the supercharging air intake. If necessary, set the throttle body (refer to: «Settings and Adjustments»).


REPLACEMENT

1. Detach connector (1).
2. Remove nut (2) and withdraw tie rod (3).
3. Remove screws (4) and throttle position sending unit (5).

FUEL SYSTEM



1. Connector
2. Tie rod retaining nut
3. Tie rod
4. Sending unit retaining screws
5. Sending unit



1. Switch connectors
2. Minimum cutout switch
3. Switch retaining screw

3. Fit a new switch and set it (refer to: «Setting and Adjustments»).

4. Install a new throttle position sending unit and register it (refer to paragraph: «Settings and Adjustments»).


MINIMUM CUTOUT SWITCH

ELECTRICAL TESTS

Refer to: «Electrical Tests».


REPLACEMENT

1. Detach connectors (1) from switch (2).
2. Remove the two screws (3) and remove the switch



1. Mask retaining screw
2. Duct retaining screws
3. Air intake duct

4. Then remove duct (3) together with sleeve (4).




3. Air intake duct
4. Sleeve

5. Detach the following hoses and wires from the intercooler:

- Pressure intake hose (5)
- Servobrake vacuum line (6)
- Auxiliary air hose (7)
- Supercharging pressure sender cable (8)

6. Loosen clamp (9) securing supercharging air intake rubber sleeve (10).

7. Remove screw (11) securing reinforcing bracket.



5. Pressure regulator pressure intake
6. Servobrake vacuum intake hose
7. Auxiliary air valve
8. Supercharging pressure sender cable
9. Clamp
10. Sleeve
11. Screw


INTERCOOLER

REMOVAL

Remove the intercooler in the following way:

1. Disconnect battery terminals.
2. Unscrew screw (1) and remove front mask.
3. Unscrew and remove the four screws (2) securing air intake duct (3) to the body front panel and remove the bolt securing the duct to the battery bracket.

8. Unscrew the two securing screws and disconnect intercooler (12) from support bracket (13), paying attention to ground cable (14) secured to one of the two screws.
9. Loosen clamps (15) securing intercooler to rubber connectors (16) of the air intake manifold and remove intercooler (12).



- 12. Intercooler
- 13. Intercooler support bracket
- 14. Ground cable
- 15. Clamp
- 16. Rubber connector

CHECKS AND INSPECTIONS

1. Clean the intercooler thoroughly by blowing compressed air over the finning.

INSTALLATION

Proceed with the installation of the Intercooler by reversing the order of removal, paying particular attention to the following:


- Clamps (15) securing rubber connectors (16) to intercooler must be tightened to prevent the leakage of supercharged air.
- Re-connect the ground cable (14) to one of the screws securing the intercooler to bracket (13).

TURBOCHARGER

REMOVAL


Proceed with the removal of the turbocharger as follows:

1. Remove the air filter together with the air flow gauge (with relative air intake ducts and filter casing) (see paragraph «Air filter — Removal»).
2. Unscrew the three bolts (1) and remove thermal shield (2).



- 1. Thermal shield securing screws
- 2. Thermal shield

3. Loosen clamps (3) and (4) and remove throttle body union (5).



- 3. Clamp
- 4. Clamp
- 5. Throttle body union


CAUTION:

Plug turbocompressor openings to prevent the entry of foreign matter which could damage the rotors.

4. Loosen clamp (6) and disconnect sleeve (7) from the radiator.


NOTE:

Place a suitable container under the vehicle to collect coolant.



- 6. Clamp
- 7. Radiator water drain sleeve


5. Remove the two screws (8) and disconnect hose (9) from the connector on the turbocharger. Remove the gasket.



- 8. Screws
- 9. Turbocharger oil delivery hose


FUEL SYSTEM

6. Remove the two screws (10) and disconnect hose (11) from the union on the oil sump.
Remove the gasket.




10. Screws
11. Oil-to-sump return hose

7. Unscrew the two bolts (12) and remove collar (13).
8. Unscrew the two nuts (14) and the two bolts (15) securing the turbocharger exhaust gas union (16) to lower support bracket (17).
Remove union (16) and the interposed gasket.




12. Bolts
13. Exhaust pipe retaining collar
14. Nuts
15. Bolts
16. Turbocharger exhaust gas union
17. Union support bracket

9. Remove bolt (18) and disconnect coolant-to-turbocharger delivery hose.




18. Coolant delivery hose securing bolt

10. Loosen nut (19) and disconnect coolant return hose from turbocharger.





19. Nut retaining coolant return hose

11. Unscrew the four nuts (20) retaining the turbocharger to the exhaust manifold (21).



20. Turbocharger retaining nuts
21. Exhaust manifold

12. Withdraw the turbocharger group (22) from the exhaust manifold studs and retrieve the interposed gasket (23).



22. Turbocharger
23. Gasket

FUEL SYSTEM

CHECKS AND INSPECTIONS

1. Check all the hoses and check that there are no cracks in the manifold and that the mating surfaces of the flanges are sound.
2. Check that the turbocharger shaft turns freely and that the play of the rotor is not excessive and that they do not touch the outer casing.
3. Visually check the integrity of the blading of the turbine and compressor.

INSTALLATION

Proceed with the installation of the turbocharger by reversing the order of removal, paying particular attention to the following:

- Replace the gaskets mentioned in «Removal».
- Replace the self-locking nuts securing the turbine to the exhaust manifold, the turbine to the exhaust union, the bolts

securing the turbine to the support and the bolts securing the exhaust union to the exhaust pipe.

- Tighten the following to the prescribed torques:
 - Nuts retaining turbocharger to exhaust manifold (1).
 - Nuts retaining turbo exhaust union to turbine (2).

T : Tightening torque
38 to 47 N·m
(3.9 to 4.8 kg·m
28.02 to 34.66 ft·lb)

- Bolts securing turbocharger exhaust union to exhaust pipe (3).
- Nuts securing exhaust manifold to cylinder head (4).
- Bolts securing turbocharger lower support to engine block (5).
- Bolts securing turbocharger to lower support (6).

- Bolts securing oil delivery hose to turbocharger (7).


T : Tightening torque
19 to 24 N·m
(1.9 to 2.4 kg·m
14.01 to 17.70 ft·lb)

- Bolt securing oil delivery hose to engine block (8).

T : Tightening torque
40 to 50 N·m
(4.0 to 5.0 kg·m
29.50 to 36.90 ft·lb)

- Bolt securing water delivery hose union to turbocompressor (9).
- Bolt securing water delivery hose union to engine block (10).

T : Tightening torque
50 to 62 N·m
(5.0 to 6.2 kg·m
36.90 to 45.73 ft·lb)



1. Nuts securing turbocharger to exhaust manifold
2. Nuts securing turbocharger exhaust union to turbine
3. Bolts securing turbocharger exhaust union to exhaust pipe
4. Nuts securing exhaust manifold to cylinder head

5. Bolts securing turbocompressor lower support to engine block
6. Bolts securing turbocharger to lower support
7. Bolts securing oil delivery hose to turbocharger
8. Bolts securing oil delivery hose union to engine block

9. Bolt securing water delivery hose union to turbocharger
10. Bolt securing water delivery hose union to engine block

FUEL SYSTEM


WASTE-GATE VALVE

CHECKS AND INSPECTIONS

Consult the paragraph: «Settings and Adjustments».

REMOVAL

1. Detach hose ① from waste-gate valve ②.
2. Remove snap ring ③ and detach control stem ④.
3. Unscrew the two retaining screws ⑤ and remove waste-gate valve ②.




1. Hose connecting waste-gate to supercharging pressure regulation solenoid valve
2. Waste-gate valve
3. Snap ring
4. Waste-gate valve control stem
5. Nuts

INSTALLATION


Proceed with the installation of the waste-gate valve by reversing the order of removal.

If necessary adjust as prescribed in the paragraph «Settings and Adjustments».

FUEL SUPPLY SYSTEM



 FUEL DELIVERY CIRCUIT

 FUEL RETURN CIRCUIT

- 1. Tank
- 2. Filler
- 3. Fill-up breather hose
- 4. Fuel level gauge
- 5. Check valve

- 6. Submerged pump
- 7. Filter
- 8. Main pump
- 9. Fuel return piping
- 10. Fuel delivery piping

- 11. Hammering damper
- 12. Fuel distributor manifold
- 13. Fuel pressure regulator

FUEL SYSTEM


WARNING:

Strictly follow the below indications before replacing the fuel system components:

- a. Ensure that the workshop is correctly equipped to enable operations to be performed safely (fire extinguishers, etc.).
- b. Detach the battery ground cable.
- c. Pour the fuel drawn from the tank into a suitable container fitted with safety cover.

CAUTION:

After having reassembled the fuel system components, verify system tightness when at 4 bar (58 psi) pressure.



1. Submerged pump supply connector
2. Fuel filler
3. Sleeve connecting filler to tank
4. Fuel level gauge connector
5. Fuel level gauge

CHECKS AND INSPECTIONS

Check for cracks or deformations in the tank; replace if required.


INSTALLATION

1. Install tank on vehicle by reversing the order of removal, verifying that the rubber gasket between tank and luggage compartment floor is correctly positioned in correspondence with filler.

FUEL TANK

REMOVAL

1. Set vehicle on a lift; remove filler plug and suck fuel from tank by means of a suitable pump.
2. Remove lower trim of luggage compartment, move side trim (right-hand side), and remove the fuel level gauge cover.
3. Detach connectors ① and ④, then extract connector ① from the related cable-raceway withdrawing it from under the vehicle.
4. Loosen the clamp and detach sleeve ③ from tank without damaging the rubber gasket underneath.




1. Fuel return hose
2. Submerged pump flange
3. Fuel delivery hose

6. Support tank by means of a column lift, unscrew the three screws which secure tank to body and remove.
7. Disassemble tank, if required.

FUEL LEVEL GAUGE

REPLACEMENT


1. Remove the luggage compartment floor trim.
2. Remove cover of fuel level gauge ② and detach connector ①.



1. Fuel level gauge connector
2. Fuel level gauge

FUEL SYSTEM

3. By means of a suitable tool, rotate fuel level gauge counterclockwise; then withdraw it from tank together with the related gasket.




4. Replace gasket before installing the fuel level gauge on tank.

AUXILIARY FUEL PUMP AND GRID FILTER


REPLACEMENT

1. Set vehicle on lift; remove filler cap and suck fuel from tank by means of a suitable pump.
2. Lift the luggage compartment floor trim, detach the submerged pump supply connector, and extract it from the related cable raceway withdrawing it from under the vehicle.
3. Raise vehicle by means of the lift, then detach hoses ① and ③ from flange ②.



1. Fuel return hose
2. Submerged pump flange
3. Fuel delivery hose

4. By means of tool A.5.0197 rotate the submerged pump flange counterclockwise, then withdraw the unit from tank, together with the related gasket.



5. Replace gasket before installing the submerged pump unit; reinstall it by means of tool A.5.0197.

FUEL PIPING

STACCO

CAUTION:

Disconnect fuel system piping only when strictly required.

1. Set vehicle on lift.
2. Remove filler plug and, by means of a suitable pump, suck fuel from the tank.
3. Loosen the clamps which secure the ends of the hoses to be removed.

CAUTION:

When disassembling, plug both pipes and hoses so as to prevent dust or impurities from entering.

4. To remove the piping located on the floor inside the passenger compartment, remove the floor trim on the right-hand side.

CHECKS AND INSPECTIONS

1. Check for porosity and deterioration of hoses; replace the faulty ones.
2. Check for oxidation, clogging and dents of pipes.

INSTALLATION

Carefully install piping by reversing the order of removal and complying with the following.


CAUTION:

- a. Carefully install clamps on system joints.
Do not tighten clamps excessively so as to prevent damaging piping.
- b. Do not bend or twist pipes when installing them on vehicle.
- c. The piping inside the vehicle must be inserted into the related pipe-raceway up to the red reference strips marked on each pipe/hose.
- d. Start the engine and check for leaks from joints.

MAIN FUEL PUMP

REPLACEMENT

1. Set vehicle on a garage lift and disconnect the battery negative terminal.
2. Working from under the vehicle, disconnect pump supply cables (1).
3. Throttle hoses (2) and (3), remove clamp (4), unscrew union (5) and then detach hoses (2) and (3) from pump (6).
4. Loosen clamp (7) and remove pump (6).



1. Pump supply cables
2. Fuel inlet hose to pump
3. Fuel outlet hose from pump
4. Clamp
5. Union
6. Fuel pump
7. Pump clamp

5. Install the new fuel pump by reversing the order of removal, paying special attention to the following:

- The pump is supplied by spares in a sealed package, filled with protective oil and with unions plugged.

It is not necessary to empty it when installing.

- Take care not to invert the supply cable connections (1).
- Lock the following to the prescribed torque:
 - Union (5) of pump fuel outlet hose.

T : Tightening torque
 10 to 16 N·m
 (1.02 to 1.6 kg·m
 7.37 to 11.80 ft·lb)


— Pump support clamp retaining nut (7).

T : Tightening torque
 1.9 to 2.4 N·m
 (0.19 to 0.24 kg·m
 1.40 to 1.77 ft·lb)

FUEL PRESSURE REGULATOR

REPLACEMENT

1. Remove intercooler (see paragraph «Intercooler — Removal»).
2. Guarding against the possibility of fuel escaping, loosen clamp (1) and disconnect hose (2) from pressure regulator (3) and plug hose.
3. Unscrew union (4), applying a second spanner to checking nut (5).
4. Unscrew nut (6) securing the pressure regulator to bracket (7), retrieve the washer under it and remove regulator.



1. Clamp
2. Fuel return hose
3. Pressure regulator
4. Union
5. Checking nut
6. Regulator retaining nut
7. Support bracket


5. Assemble a new pressure regulator by proceeding in the opposite order to removal.

6. Assemble the intercooler (see paragraph «Intercooler — Installation»).

HAMMERING DAMPER

REPLACEMENT

1. Remove intercooler (see paragraph «Intercooler — Removal»).
2. Taking precautions against fuel escape, loosen union (1), disconnect hose (2) from hammering damper (3) and plug hose.
3. Unscrew union (4) applying a second spanner to checking nut (5).
4. Unscrew nut (6) securing hammering damper to bracket (7), retrieve the washer under it and remove damper.



1. Fuel delivery hose union
2. Fuel delivery hose
3. Hammering damper
4. Union
5. Checking nut
6. Damper securing nut
7. Support bracket

5. Assemble a new hammering damper by proceeding in the opposite order to removal.

6. Assemble intercooler (see paragraph «Intercooler — Installation»).

ELECTROINJECTORS

CHECKS AND INSPECTIONS

1. Electrical tests

Refer to: «Electrical Tests».

2. Check of electroinjectors opening

a. Measurement of exhaust CO emission (see paragraph «Settings and Adjustments»).

b. Detach electroinjector connectors one at a time, check the CO percentage each time, a verify that value is constant at each check.

c. If not so, identify the faulty electroinjector and replace it (see paragraph «Replacement»).

d. However, a visual confirmation of electroinjectors functioning can be obtained by comparing the spark plug electrodes colour:

- Black colour indicates a too rich mixture.
- Light colour indicates a too lean mixture.

3. Check of electroinjector tightness

a. Detach the electroinjector-fuel distributor manifold unit operating as indicated in «Replacement», keeping the fuel supply system connected.

b. Detach electroinjector connectors.

c. Operate starter and check for fuel leaks from electroinjectors; if leaks are present, replace the faulty electroinjector.


REMOVAL

1. Remove intercooler (see paragraph «Intercooler — Removal»).

2. Place a suitable container under the vehicle and drain engine coolant system.

3. Detach supply connectors from electroinjectors, from water temperature sensor and sender, and from oil level sensor. Remove clamps securing the electrical wiring to the fuel distributor manifold.

4. Loosen clamp (1), remove screw (2) securing thermostatic cup (3) and then disconnect sleeve (4).




1. Clamp
2. Screw
3. Thermostatic cup
4. Sleeve

5. Detach hoses (5) and (6) from hammering damper (7) and pressure regulator (8) respectively.


WARNING:

When detaching hose (5) operate carefully as residual pressure in the fuel system may cause fuel to escape.




5. Fuel delivery hose
6. Fuel return hose
7. Hammering damper
8. Pressure regulator

6. Remove the eight screws (9) securing electroinjectors (10) to fuel intake manifold.




9. Electroinjector retaining screws
10. Electroinjectors

7. Unscrew nut on bracket (11) and retrieve silentblock (12).



11. Intercooler support bracket and fuel distributor manifold
12. Silentblock

8. Remove fuel distributor manifold (13) complete with electroinjectors.



13. Fuel distributor manifold with electroinjectors



FUEL SYSTEM

REPLACEMENT

CAUTION:

Before replacing an electroinjector, take note of connector position on electroinjector so that it can be correctly repositioned when installing the new electroinjector.

1. Cut hose (1) using a welder, detach it from fuel distributor manifold (2) and recover bush (3).



1. Electroinjector supply hose
2. Fuel distributor manifold
3. Bush
4. Flange
5. Rubber gasket
6. Seeger ring
7. O-ring

2. Install a new electroinjector fitting bush and supply hose on fuel distributor manifold until it strikes against bush itself.


CAUTION:

Electroinjector must be fitted on fuel distributor manifold with the related connector towards cylinder heads.

To fit the electroinjector, it is recommended to wet the related rubber hose with fuel. However, for this operations never use grease or vaseline.

INSTALLATION

1. Replace O-ring (4).
2. Install electroinjectors into the related seats, taking care to position seal ring (5) correctly.



1. Flange
2. Electroinjector securing screw
3. Washer
4. O-ring
5. Seal ring

3. Install the other components by reversing the order of removal, complying with the following indications:


- Restore coolant correct level.
- Check the exhaust CO percentage; adjust if necessary (see paragraph «Setting and Adjustments»).

SETTINGS AND ADJUSTMENTS

SETTING OF THROTTLE BODY (Check with Flowmeter)


Check the tightness of the throttle body discs as follows:

1. Remove the three screws (1) and remove protective cover (2). Then loosen clamps (3) and detach union (4) from throttle body.



1. Cover retaining screws
2. Protective cover
3. Union retaining clamps
4. Throttle body union

2. Stop the hole of the auxiliary air valve supply duct hole (5) and check that there is no leakage through idle r.p.m. adjustment screw (6) (which must be fully tightened).




5. Auxiliary air valve supply duct hole
6. Idle r.p.m. adjustment screw

3. Loosen clamp (7) and place a suitable tool in sleeve (8) to permit air to escape during the flowmeter check.
4. Rest the flowmeter tap C.2.0055 on throttle body inlet.
5. Measure the air flow through throttle and verify that it is within prescribed values.

Air flow from accelerator throttle in closed position (Solex flowmeter): 350 on scale N

6. If the flowmeter does not show this value adjust screw (9) until it is obtained.

7. Install the components detached by reversing the order of removal.
8. Adjust idle r.p.m. (see paragraph «Check and Adjustment of Idle r.p.m.»).



7. Clamp
8. Sleeve
9. Primary throttle regulation screw

[-75-model-car-service-repair-workshop-manual/](#)

THROTTLE POSITION SENDING UNIT ADJUSTMENT

NOTE:

Before adjusting the throttle position sending unit ensure that the throttle body is correctly adjusted (see paragraph «Setting of Throttle Body»).

1. Disconnect the connector (multi-pin) from the ignition control unit (located inside the vehicle on the front right wheelhouse) and connect it to interface **C.1.0134**.

2. Working from inside the engine compartment, remove protective cover detach the throttle position sending unit connector and connect it to adjustment device **C.1.0131**.

3. Take a 2 V FSR multimeter and insert the black prod in bush no. 1 of adjustment device **C.1.0131** and red prod in bush no. 2.


4. Insert the ignition key and check that the multimeter indicates

1050 to 1100 mV

5. If the prescribed value is not obtained adjust throttle position sending unit (1) by loosening retaining screws (2) and rotating it until a reading of 1050 to 1100 mV is

obtained on the multimeter.

6. Then lock the sending unit, take out the ignition key, disconnect the test instrument and fit the protective cover.



C.1.0131

1. Throttle position sending unit
2. Sending unit retaining screws