


Product: 1994 Asia Rocsta AM102 Car Service Repair Workshop Manual
Full Download: <https://www.arepairmanual.com/downloads/1994-asia-rocsta-am102-car-service-repair-workshop-manual/>

ROCSTA WORKSHOP MANUAL

● AM102



Sample of manual. Download All 427 pages at:
<https://www.arepairmanual.com/downloads/1994-asia-rocsta-am102-car-service-repair-workshop-manual/>

 **ASIA MOTORS**

ROCSTA WORKSHOP MANUAL

FOREWORD

This workshop manual has been prepared to provide information covering normal service, repair and maintenance for ASIA ROCSTA.

Information in this manual is divided into Groups, each Group covers a general vehicle system like transmission, steering, etc.

Each Group also contains Summary, Specification, Troubleshooting, Removal and Installation, Adjustment, Diagnosis and Testing.

For satisfaction of Asia customer, proper service and maintenance by technician is essential.

So it is important that service personnel fully understand the contents of this manual and should keep in a handy place for quick and easy reference.

The information, photographs, drawings and specifications contained in this manual are best available at the time of printing. So, it is recommended that this manual should be kept up-to-date by receiving of new information.

Asia Motors reserves the right to change the specifications and contents of this manual without obligation and advance notice.

We sure this workshop manual will help you with maintaining and keeping the best condition of this vehicle.

December, 1994
ASIA MOTORS Co., Inc.

CONTENTS

GENERAL INFORMATION	0
ENGINE	1A·B
LUBRICATION SYSTEM	2A·B
COOLING SYSTEM	3A·B
FUEL, IN. AND EXH. SYSTEM	4A·B
ENGINE ELECTRICAL SYSTEM	5
CLUTCH	6
TRANSMISSION	7
PROPELLER SHAFT	8
FRONT & REAR AXLE	9
STEERING	10
BRAKES	11
WHEELS AND TIRES	12
SUSPENSION	13
BODY	14
BODY ELECTRICAL SYSTEM	15
TECHNICAL DATA	22
SPECIAL TOOLS	23

GENERAL INFORMATION

<input checked="" type="checkbox"/> FUNDAMENTAL PROCEDURES	0-2
<input checked="" type="checkbox"/> JACK AND SAFETY STAND(RIGID RACK) POSITIONS	0-6
<input checked="" type="checkbox"/> VEHICLE LIFT POSITIONS	0-7
<input checked="" type="checkbox"/> TOWING	0-7
<input checked="" type="checkbox"/> TOWING HOOK	0-7
<input checked="" type="checkbox"/> TOW ROPE POSITIONS	0-7
<input checked="" type="checkbox"/> CHASSIS NUMBER LOCATION	0-8
<input checked="" type="checkbox"/> UNITS	0-8
<input checked="" type="checkbox"/> ABBREVIATIONS	0-8

ENGINE

<input checked="" type="checkbox"/> OUTLINE	1A-2
<input checked="" type="checkbox"/> SPECIFICATIONS	1A-4
<input checked="" type="checkbox"/> TROUBLESHOOTING GUIDE	1A-4
<input checked="" type="checkbox"/> INSPECTION AND ADJUSTMENT	1A-6
<input checked="" type="checkbox"/> DISASSEMBLY OF ENGINE	1A-8
<input checked="" type="checkbox"/> INSPECTION AND REPAIR	1A-16
<input checked="" type="checkbox"/> ASSEMBLY OF ENGINE	1A-21

ENGINE (GASOLINE)

<input checked="" type="checkbox"/> STRUCTURAL VIEW	1B-2
<input checked="" type="checkbox"/> SPECIFICATIONS	1B-4
<input checked="" type="checkbox"/> TROUBLESHOOTING GUIDE	1B-4
<input checked="" type="checkbox"/> DISASSEMBLY OF ENGINE	1B-6
<input checked="" type="checkbox"/> INSPECTION AND REPAIR	1B-14
<input checked="" type="checkbox"/> ASSEMBLY OF ENGINE	1B-25

LUBRICATION SYSTEM

<input checked="" type="checkbox"/> OUTLINE	2A-2
<input checked="" type="checkbox"/> SPECIFICATIONS	2A-3
<input checked="" type="checkbox"/> TROUBLESHOOTING GUIDE	2A-4
<input checked="" type="checkbox"/> INSPECTION	2A-5
<input checked="" type="checkbox"/> OIL BYPASS FILTER	2A-5
<input checked="" type="checkbox"/> OIL PAN	2A-7
<input checked="" type="checkbox"/> OIL PUMP	2A-9
<input checked="" type="checkbox"/> OIL COOLER	2A-11
<input checked="" type="checkbox"/> OIL JET	2A-13

LUBRICATION SYSTEM

<input checked="" type="checkbox"/> FLOW CHART	2B-2
<input checked="" type="checkbox"/> SPECIFICATIONS	2B-3
<input checked="" type="checkbox"/> TROUBLESHOOTING GUIDE	2B-3
<input checked="" type="checkbox"/> OIL FILTER	2B-3
<input checked="" type="checkbox"/> OIL PAN	2B-4
<input checked="" type="checkbox"/> OIL PUMP	2B-5
<input checked="" type="checkbox"/> OIL PRESSURE	2B-7

COOLING SYSTEM

<input checked="" type="checkbox"/> OUTLINE	3A-2
<input checked="" type="checkbox"/> SPECIFICATIONS	3A-3
<input checked="" type="checkbox"/> TROUBLESHOOTING GUIDE	3A-4
<input checked="" type="checkbox"/> COOLANT	3A-4
<input checked="" type="checkbox"/> THERMOSTAT	3A-5
<input checked="" type="checkbox"/> RADIATOR	3A-6
<input checked="" type="checkbox"/> RADIATOR CAP	3A-7
<input checked="" type="checkbox"/> WATER PUMP	3A-7

COOLING SYSTEM

<input checked="" type="checkbox"/> OUTLINE	3B-2
<input checked="" type="checkbox"/> SPECIFICATIONS	3B-3
<input checked="" type="checkbox"/> TROUBLESHOOTING GUIDE	3B-3
<input checked="" type="checkbox"/> COOLANT	3E
<input checked="" type="checkbox"/> THERMOSTAT	3B-4
<input checked="" type="checkbox"/> RADIATOR	3B-5
<input checked="" type="checkbox"/> RADIATOR CAP	3B-5
<input checked="" type="checkbox"/> WATER THERMO-SWITCH	3B-6
<input checked="" type="checkbox"/> WATER PUMP	3B-7

FUEL, INTAKE· EXHAUST SYSTEM

☒ OUTLINE	4A-2
☒ SPECIFICATIONS	4A-3
☒ TROUBLESHOOTING GUIDE	4A-4
☒ FUEL LINE	4A-5
☒ FUEL FILTER	4A-5
☒ INJECTION PUMP	4A-7
☒ FUEL CUT VALVE	4A-13
☒ INJECTION NOZZLE	4A-13
☒ CSD CABLE AND LINKAGE	4A-15
☒ ENGINE SPEED	4A-16
☒ AIR-BLEEDING	4A-17

FUEL, INTAKE· EXHAUST SYSTEM

☒ OUTLINE	4B-2
☒ SPECIFICATIONS	4B-5
☒ TROUBLESHOOTING GUIDE	4B-6
☒ ACCELERATOR LINKAGE	4B-7
☒ FUEL PUMP	4B-8
☒ FUEL TANK	4B-9
☒ FUEL FILTER	4B-9
☒ CARBURETOR	4B-10
☒ EGR(Emission Gas Regulation) CONTROL SYSTEM	4B-22
☒ EGR MODULATOR VALVE	4B-23
☒ EGR SOLENOID	4B-23
☒ EVAPORATIVE EMISSION CONTROL SYSTEM	4B-24
☒ IDLE-UP SYSTEM	4B-26
☒ IDLE-UP ELECTRIC LOAD OR POWER STEERING	4B-27
☒ POSITIVE CRANKCASE VENTILATION(PCV) SYSTEM	4B-29
☒ AIR INLET TEMPERATURE CONTROL SYSTEM	4B-30
☒ HOT IDLE COMPENSATION SYSTEM	4B-31

ENGINE ELECTRICAL SYSTEM

☒ OUTLINE	5-2
☒ SPECIFICATIONS	5-3
☒ TROUBLESHOOTING GUIDE	5-3
☒ BATTERY	5-4
☒ ALTERNATOR	5-5
☒ STARTER-A(Diesel engine : 2.0KW type)	5-13
☒ STARTER-B(Gasoline engine : 0.95KW type)	5-21
☒ QUICK START SYSTEM(QSS)	5-28
☒ GLOW PLUG	5-29
☒ VACUUM PUMP	5-29
☒ DRIVE BELT	5-30
☒ SPARK PLUG	5-31
☒ HIGH-TENSION LEAD	5-31
☒ IGNITION COIL	5-32
☒ DISTRIBUTOR	5-32

CLUTCH

☒ OUTLINE	6-2
☒ SPECIFICATIONS	6-3
☒ TROUBLESHOOTING GUIDE	6-3
☒ ON-VEHICLE MAINTENANCE	6-4
☒ INSPECTION AND ADJUSTMENT	6-4
☒ CLUTCH PEDAL	6-5
☒ MASTER CYLINDER	6-7
☒ RELEASE CYLINDER	6-10
☒ CLUTCH AND FLYWHEEL	6-13

TRANSMISSION

☒ OUTLINE	7-2
☒ SPECIFICATIONS	7-3
☒ TROUBLESHOOTING GUIDE	7-3
☒ INSPECTION	7-4
☒ REMOVAL OF TRANSMISSION ASSEMBLY	7-5
☒ INSTALLATION OF TRANSMISSION ASSEMBLY	7-6
☒ CLUTCH HOUSING ASSEMBLY	7-7
☒ CONTROL CASE ASSEMBLY	7-8
☒ EXTENSION HOUSING ASSEMBLY	7-9
☒ TRANSMISSION CASE ASSEMBLY	7-10
☒ MAIN DRIVE SHAFT ASSEMBLY	7-12
☒ ASSEMBLY OF TRANSMISSION ASSEMBLY	7-14
☒ TRANSFER ASSEMBLY	7-18
☒ FRONT & REAR COVER (ONLY INDIRECT TYPE TRANSFER)	7-19
☒ REAR CASE ASSEMBLY	7-20
☒ FRONT CASE, MAIN SHAFT AND IDLE GEAR ASSEMBLY	7-21
☒ ASSEMBLY OF TRANSFER ASSEMBLY	7-22

PROPELLER SHAFT

☒ OUTLINE	8-2
☒ SPECIFICATIONS	8-2
☒ TROUBLESHOOTING GUIDE	8-3
☒ ON-VEHICLE INSPECTION	8-3
☒ REMOVAL	8-4
☒ DISASSEMBLY	8-5
☒ ASSEMBLY	8-6
☒ INSPECTION	8-7
☒ INSTALLATION	8-7

FRONT AND REAR AXLES

☒ OUTLINE	9-2
☒ SPECIFICATIONS	9-3
☒ TROUBLESHOOTING GUIDE	9-4
☒ FRONT AXLE	9-5
☒ REAR AXLE	9-12
☒ DIFFERENTIAL	9-17

STEERING

☒ OUTLINE	10-2
☒ SPECIFICATIONS	10-3
☒ TROUBLESHOOTING GUIDE	10-3
☒ INSPECTION AND ADJUSTMENT	10-5
☒ WHEEL ALIGNMENT	10-6
☒ STEERING WHEEL AND COLUMN	10-8
☒ GEAR BOX	10-10
☒ MANUAL STEERING GEAR BOX	10-12
☒ POWER STEERING GEAR BOX	10-15
☒ POWER STEERING OIL PUMP	10-19

BRAKE

☒ OUTLINE	11-2
☒ SPECIFICATIONS	11-2
☒ TROUBLESHOOTING GUIDE	11-2
☒ ON-VEHICLE MAINTENANCE	11-4
☒ INSPECTION AND ADJUSTMENT	11-4
☒ BRAKE PEDAL	11-6
☒ MASTER CYLINDER	11-8
☒ POWER BRAKE UNIT	11-11
☒ VACUUM PUMP	11-19
☒ FRONT DISC BRAKE	11-21
☒ REAR DRUM BRAKE	11-23
☒ WHEEL CYLINDER	11-25
☒ BACK PLATE	11-26
☒ BRAKE LINES	11-27

☒ FUNDAMENTAL PROCEDURES	0-2
☒ PROTECTION OF THE VEHICLE	0-2
☒ A WORD ABOUT SAFETY	0-2
☒ PREPARATION OF TOOLS AND MEASURING EQUIPMENT	0-2
☒ SPECIAL TOOLS	0-2
☒ REMOVAL OF PARTS	0-3
☒ DISASSEMBLY	0-3
☒ INSPECTION DURING DISASSEMBLY	0-3
☒ ARRANGEMENT OF DISASSEMBLED PARTS	0-3
☒ CLEANING DISASSEMBLED PARTS	0-4
☒ ASSEMBLY	0-4
☒ ADJUSTMENTS	0-4
☒ ELECTRICAL SYSTEM	0-5
☒ RUBBER PARTS AND TUBING	0-5
☒ JACK AND SAFETY STAND (RIGID RACK) POSITIONS	0-5
☒ FRONT END	0-5
☒ REAR END	0-6
☒ VEHICLE LIFT POSITIONS	0-6
☒ FRONT END	0-6
☒ REAR END	0-6
☒ TOWING	0-7
☒ WITH MANUAL TRANSMISSION	0-7
☒ TOWING HOOK	0-7
☒ TOW ROPE POSITIONS	0-7
☒ FRONT END	0-7
☒ REAR END	0-7
☒ CHASSIS NUMBER LOCATION	0-7
☒ UNITS	0-8
☒ ABBREVIATIONS	0-8

0 FUNDAMENTAL PROCEDURES

☒ FUNDAMENTAL PROCEDURES

NOTES, CAUTIONS, AND WARNINGS

As you read through the procedures, you will come across **NOTES**, **CAUTIONS**, and **WARNINGS**. Each one is therefore a specific purpose. **NOTES** give you **added information** that will help you to complete a particular procedure. **CAUTIONS** are given to prevent you from making an error that could **damage the vehicle**. **WARNINGS** remind you to be especially careful in those areas where carelessness can cause **personal injury**. The following list contains some general **WARNINGS** you should follow when you work on a vehicle.

◆ PROTECTION OF THE VEHICLE

Always be sure to cover fenders, seats, and floor areas before starting work.

◆ A WORD ABOUT SAFETY

It is imperative that the following precautions be followed when jacking up the vehicle.

1. Wheels must be blocked.
2. Take care to use only specified jacking positions.
3. Support the vehicle with safety stands (rigid racks).

The engine should be started only after first checking to be sure it is clear of tools, people, etc.

◆ PREPARATION OF TOOLS AND MEASURING EQUIPMENT

Be sure all needed tools and measuring equipment are available and ready for use.

◆ SPECIAL TOOLS

Be sure to use the specified special tools when they are required. Do not attempt to use substitutes.




Fig. 0-1




Fig. 0-2




Fig. 0-3




Fig. 0-4

REMOVAL OF PARTS

When checking a problem, try at the same time to determine the cause, and begin work after first determining which parts must be removed and/or disassembled.




Fig. 0-5

DISASSEMBLY

If the disassembly procedure is complex and/or many parts are to be disassembled, the various parts should be identified (in a way which will not affect their performance of external appearance) so that correct assembly will be easier and faster.




Fig. 0-6

INSPECTION DURING DISASSEMBLY

Each part should be carefully inspected, as it is disassembled, for malfunctioning operation, deformation, damage, etc.




Fig. 0-7

ARRANGEMENT OF DISASSEMBLED PARTS

All disassembled parts should be carefully arranged for later assembly. Be sure to separate parts which are to be replaced from those to be reused.




Fig. 0-8

0 FUNDAMENTAL PROCEDURES

◆ CLEANING DISASSEMBLED PARTS

All parts to be reused should be carefully and thoroughly cleaned by the appropriate method.




Fig. 0-9

◆ ASSEMBLY

All parts should be assembled while carefully following the standard values for such items as tightening torques, adjustment values, etc.

As a rule, the following parts should be replaced with new ones when removing.

1. Oil seals
2. Gaskets
3. O-rings
4. Lock washers
5. Cotter pins
6. Nylon nuts

Depending on their locations, sealant should be applied to gaskets, oil should be applied to moving components of parts, and the specified oil or grease should be applied at the prescribed locations (Oil seals, etc.) before assembly.




Fig. 0-10




Fig. 0-11

◆ ADJUSTMENTS

Gauges and testers should be used to make correct adjustments to standard values.




Fig. 0-12

◆ ELECTRICAL SYSTEM

Be sure to disconnect the battery cable from the negative (-) terminal of the battery.

When connectors are to be disconnected, never pull on the wiring itself.

When locking connectors are to be connected, insert them all the way in until a "click" is heard.

Handle sensors and relays carefully take care not to drop or knock them against other parts.




Fig. 0-13

◆ RUBBER PARTS AND TUBING

Be careful that rubber parts and tubing do not come in contact with gasoline or oil.




Fig. 0-14

◆ JACK AND SAFETY STAND (RIGID RACK) POSITIONS

◆ FRONT END

JACK POSITION

Differential part of the axle housing




Fig. 0-15

SAFETY STAND POSITIONS

Chassis frame part




Fig. 0-16

0 VEHICLE LIFT POSITIONS

REAR END

JACK POSITION

Differential part of the axle housing




Fig. 0-17

SAFETY STAND

Chassis frame part




Fig. 0-18

VEHICLE LIFT POSITIONS

FRONT END

Chassis frame part




Fig. 0-19

REAR END

Chassis frame part




Fig. 0-20

❑ TOWING

Proper towing equipment is necessary to prevent damage to the vehicle during any towing operation. Laws and regulations applicable to vehicles in tow must always be observed.

Release the parking brake, place the transmission shift lever in neutral, set the ignition switch in the ACC position, and the driving mode to the 2WD. As a rule, towed vehicles should be pulled with the driving wheels off the ground.

❑ WITH MANUAL TRANSMISSION

If the transmission, rear axle, and steering system are not damaged, the vehicle may be towed on all four wheels. If any of these components are damaged, use a towing dolly.

❑ TOWING HOOK

After attaching a rope to the towing hook, tow the vehicle.

Caution

Do not attempt to tow with other parts of the vehicle, this could result in serious damage to the vehicle, so only the towing hook can be used in towing.

❑ CHASSIS NUMBER LOCATION




Fig. 0-23

❑ TOW ROPE POSITIONS

❑ FRONT END




Fig. 0-21

❑ REAR END




Fig. 0-22

☒ UNITS

m·kg(ft·lb or in·lb)	Torque
rpm	Revolutions per minute
A	Ampere(s) (current)
V	Volts(S) (Voltage)
Ω	Ohm(s) (resistance)
kg/cm ² (lb/in ²)	Pressure (Usually positive)
mmHg(inHg)	Pressure (Usually positive)
W	Watt
liters(US qt, Imp qt)	Volume
mm(in)	Length

☒ ABBREVIATIONS

ABDC	After bottom dead center
A/C	Air conditioner
ACC	Accessories
ATDC	After top dead center
BBDC	Before bottom dead center
BTDC	Before top dead center
E/L	Electrical load
ELR	Emergency locking retractor
EX	Exhaust
GND	Ground
IC	Electric Integrated circuit
IG	Ignition
IN	Intake
INT	Intermittent
LH	Left hand
M	Motor
M/S	Manual steering
MTX	Manual transaxle
OFF	Switch off
ON	Switch on
PCV	Positive crankcase ventilation
P/S	Power steering
PRC	Pressure regulator control
P/W	Power window
RH	Right hand
SOHC	Single overhead camshaft
SST	Special service tool
ST	Start
SW	Switch
TDC	Top dead center

- ☒ **OUTLINE** **1A-2**
 - ☒ OUTLINE OF CONSTRUCTION 1A-2
 - ☒ VALVE MECHANISM 1A-3
 - ☒ SLANT BOTTOM SWIRL CHAMER 1A-3
 - ☒ CYLINDER HEAD BOLT 1A-3
- ☒ **SPECIFICATIONS** **1A-4**
- ☒ **TROUBLESHOOTING GUIDE** **1A-4**
- ☒ **INSPECTION AND ADJUSTMENT** ... **1A-6**
 - ☒ CHECKING OF COMPRESSION PRESSURE 1A-6
 - ☒ MEASURE OF THE VALVE CLEARANCE 1A-6
 - ☒ ADJUSTMENT OF THE VALVE CLEARANCE ... 1A-7
- ☒ **DISASSEMBLY OF ENGINE** **1A-8**
 - ☒ PARTS RELATED TO ENGINE AUXILIARY 1A-8
 - ☒ PARTS RELATED TO TIMING MECHANISM 1A-9
 - ☒ PARTS RELATED TO CYLINDER HEAD 1A-10
 - ☒ PARTS RELATED TO LUBRICATION SYSTEM AND FLYWHEEL 1A-11
 - ☒ PARTS RELATED TO CRANKSHAFT AND PISTON ASSEMBLY 1A-12
 - ☒ DISASSEMBLY PROCEDURES 1A-13
- ☒ **INSPECTION AND REPAIR** **1A-16**
 - ☒ MAINTENANCE NOTES 1A-16
 - ☒ CYLINDER HEAD COMPLETE 1A-16
 - ☒ CAMSHAFT 1A-22
 - ☒ CYLINDER BLOCK 1A-22
 - ☒ PISTONS AND PISTON RINGS 1A-23
 - ☒ CONNECTING ROD 1A-24
 - ☒ CRANKSHAFT 1A-25
 - ☒ MAIN AND CONNECTING ROD BEARINGS 1A-25
 - ☒ FLYWHEEL 1A-26
 - ☒ TIMING BELT 1A-26
 - ☒ TENSIONER 1A-27

- ☒ TIMING BELT PULLEY, CAMSHAFT PULLEY, INJECTION PUMP PULLEY 1A-27
- ☒ TIMING BELT COVER(LEFT, RIGHT) 1A-27
- ☒ **ASSEMBLY OF ENGINE** **1A-27**
 - ☒ ASSEMBLY NOTES 1A-27
 - ☒ CYLINDER HEAD COMPLETE 1A-28
 - ☒ PISTON AND CONNECTING ROD 1A-28
 - ☒ CRANKSHAFT 1A-29
 - ☒ REAR COVER ASSEMBLY 1A-33
 - ☒ OIL PUMP BODY ASSEMBLY 1A-33
 - ☒ OIL STRAINER, OIL BAFFLE PLATE AND OIL PAN 1A-34
 - ☒ END PLATE, FLYWHEEL ASS'Y CLUTCH COVER 1A-35
 - ☒ TIMING BELT CRANK PULLEY 1A-36
 - ☒ CYLINDER HEAD COMPLETE 1A-36
 - ☒ ENGINE HANGER, OIL LEVEL GAUGE GUIDE, INJECTION PUMP STAY 1A-38
 - ☒ WATER PUMP ASS'Y AND INJECTION PUMP BRACKET 1A-39
 - ☒ FRONT SEAL PLATE AND CAMSHAFT PULLEY 1A-39
 - ☒ THERMOSTAT AND COOLING FAN PULLEY BEARING COMPLETE 1A-40
 - ☒ INJECTION PUMP AND PULLEY 1A-40
 - ☒ TIMING BELT TENSIONER 1A-41
 - ☒ TIMING BELT COVER 1A-42
 - ☒ CRANKSHAFT PULLEY 1A-43
 - ☒ INJECTION PIPE, FUEL LEAK PIPE AND OIL LEVEL GAUGE 1A-43
 - ☒ EXHAUST AND INTAKE MANIFOLD 1A-44
 - ☒ OIL COOLER, OIL FILTER 1A-44

1A OUTLINE

◇ OUTLINE

◆ OUTLINE OF CONSTRUCTION

The new MAGMA diesel engine, by using the latest technological advances, is an excellent balance of output, fuel consumption, durability and quiet operation.

Its main features are

1. Aluminum alloy cylinder head
2. Direct-drive OHC(overhead camshaft)
3. Timing belt
4. New tightening method for cylinder head bolts
5. Oil baffle plate for vibration reduction




Fig. 1A-1

◆ VALVE MECHANISM

By employing a direct-drive OHC(overhead camshaft), the parts, such as the push rods, rocker arms, rocker arm shafts, etc., used in the OHV(overhead valve) engine are not necessary. This has resulted in reduced size and weight, decreased mechanical loss, and a great improvement of high rotation efficiency.




Fig. 1A-2

◆ SLANT BOTTOM SWIRL CHAMBER

By employing the slant bottom swirl chamber having good combustion efficiency, the combustion chamber can maintain high power and low fuel consumption.

◆ CYLINDER HEAD BOLT

The cylinder head bolts are tightened by means of the bolt torque-angle method.

When performing any service procedures related to the cylinder head, special care should be taken. Refer to the main text for detailed information regarding the tightening method.




Fig. 1A-3

1A SPECIFICATIONS/TROUBLESHOOTING GUIDE

☒ SPECIFICATIONS

Items		Engine	MAGMA
Type			Diesel, 4-cycle
Cylinder arrangement and number			In-line, 4 cylinders
Combustion chamber			Swirling flow
Valve system			OHC, belt-drive 8 valves
Displacement		cc (cu in)	2,184
Bore and stroke		mm (in)	86.0 × 94.0 (3.39 × 3.70)
Compression ratio			22.9 ± 0.4 : 1
Compression pressure		kPa (kg/cm ² , psi) - rpm	2,942 (30,426) - 200
Valve timing	IN	Open BTDC	10°
		Close ABDC	42°
	EX	Open BBDC	57°
		Close ATDC	11°
Valve clearance	mm (in)	IN	0.25 (0.0098)
		EX	0.35 (0.0138)
Idle speed		rpm	700 ~ 750
Ignition timing			ATDC 4°
Injection order			1-3-4-2

☒ TROUBLESHOOTING GUIDE

Problem	Possible cause	Correction
Insufficient power	Insufficient compression	
	Improper valve clearance	Adjust
	Compression leakage from valve seat	Repair (grind the valve seat)
	Seized valve stem	Replace
	Weak or broken valve spring	Replace
Excessive oil consumption	Failed cylinder head gasket	Replace
	Cracked or distorted cylinder head	Replace or repair
	Sticking, damaged, or worn piston ring	Replace
	Cracked or worn piston	Replace
	Malfunction of fuel system	Refer to section 4A
	Malfunction of ignition system	Refer to section 5
Excessive oil consumption	Oil working up	
	Worn or sticking piston ring or piston ring groove	Replace
	Worn piston or cylinder	Replace
	Oil working down	
Bad valve seal	Replace	
Worn valve stem and guide	Replace	
	Oil leakage	Refer to section 2A

Problem	Possible cause	Correction
Difficult starting	Malfunction of engine-related components Burned valve Worn piston, piston ring, or cylinder Burned cylinder head gasket	Replace Replace Replace
	Malfunction of fuel system	Refer to section 4A
	Malfunction of electrical system	Refer to section 5
	Malfunction of components related to engine Improper valve clearance Sticking or burned valve Weak or broken valve spring Carbon accumulation in combustion chamber	Adjust Replace Replace Eliminate the carbon
Abnormal combustion	Malfunction of fuel system	Refer to section 4A
	Malfunction of electrical system	Refer to section 5
	Malfunction of components related to engine Improper valve clearance Poor valve to valve seat contact Failure of cylinder head gasket	Adjust Repair or replace Replace
Poor idling	Malfunction of fuel system	Refer to section 4A
	Malfunction of electrical system	Refer to section 5
	Malfunction of components related to engine Excessive main bearing oil clearance Main bearing seized or heat-damaged Excessive crankshaft end play Excessive connecting rod bearing oil clearance Connecting rod bearing seized or heat-damaged	Replace or repair Replace Replace or repair Replace or repair Replace
Engine noise	Piston related parts Worn cylinder Worn piston or piston pin Seized piston Damaged piston Bent connecting rod	Replace Replace Replace Replace Replace
	Valves related parts Excessive valve clearance Broken valve spring Excessive clearance between valve stem and guide Insufficient lubrication of rocker arm	Adjust Replace Replace Replace
	Others Improper drive-belt tension Malfunction of water pump bearing Malfunction of alternator bearing Exhaust gas leakage Malfunction of timing belt tensioner	Adjust Refer to Section 3A Refer to Section 5 Repair Replace

1A INSPECTION AND ADJUSTMENT

☒ INSPECTION AND ADJUSTMENT

◆ CHECKING OF COMPRESSION PRESSURE

1. Make sure the battery is fully charged.
2. Warm up the engine thoroughly.
3. Remove all the fuel injection pipes, nozzles and washers.
4. Install the compression gauge adapter (49 1456 010) to the injection nozzle hole.
5. Connect a compression gauge to the compression gauge adapter.

Compression pressure: $\text{kg/cm}^2(\text{lb/in}^2)\text{-rpm}$
Standard: 30(426) – 200
Limit: 27(384) – 200

Caution

While cranking, disconnect the fuel cut solenoid valve connector.

◆ MEASURE OF THE VALVE CLEARANCE

1. Position No.1 cylinder to the compression top dead center.
2. Measure the valve clearance of No.1 and No.2 of the intake side and No.1 and No.3 of the exhaust side.
3. Turn the crankshaft one turn(forward direction), and then measure the rest of the valve clearance.

Valve clearance;

Engine warm condition

Intake: 0.30mm(0.012in)

Exhaust: 0.40mm(0.016in)

Engine cold condition

Intake: 0.20~0.30mm(0.008~0.012in)

Exhaust: 0.30~0.40mm(0.012~0.016in)




Fig. 1A-4




Fig. 1A-5




Fig. 1A-6

◆ ADJUSTMENT OF THE VALVE CLEARANCE

Adjust the valve clearances by following the procedures below if they are not within the standard.

1. Face the intake cam straight upward.
2. Move the tappet so that its notch is at the manifold side, so that access to the adjusting disc is easy.
3. Using the tappet holder(49 S120 220), press the tappet down to the position where the adjusting disc becomes accessible.
4. Using a small screw driver or similar tool, take out the adjusting disc.
5. Select an appropriate disc depending on the valve clearance measured. Install it and check the clearance again.

Example(Intake valve):

Thickness of original adjusting disc + (measured clearance - standard clearance) = thickness of new adjusting disc.

$$4.00 + (0.30 - 0.25) = 4.05\text{mm}$$

$$0.157 + (0.012 - 0.010) = 0.159\text{in}$$

Note

The number marked on the disc indicates its thickness.

Example: 3825 means 3.825mm(0.1506in).

Adjusting discs are available in 37 different thickness within the 3.400~3.650mm(0.134~0.144in), 4.350~4.600mm(0.171~0.181in) range, at intervals of 0.050mm(0.002in) and 3.700~4.275mm (0.146~0.169in) range, at intervals of 0.25mm(0.00984in).




Fig. 1A-7




Fig. 1A-8

1A DISASSEMBLY OF ENGINE

☒ DISASSEMBLY OF ENGINE

After disassembling the transmission from the engine and transmission complete, put the engine on the engine hanger and remove each part in the numbered order shown in the figure.

◆ PARTS RELATED TO ENGINE AUXILIARY




Fig. 1A-9

- | | | |
|--|---------------------------------------|---------------------------------|
| 1. Engine mounting bracket | 8. Oil filter, oil cooler and bracket | 15. Injection pipe Ass'y |
| 2. Alternator and vacuum pump Ass'y | 9. Heat insulator | 16. Injection pump pulley cover |
| 3. Fan belt | 10. Blow-by hose | 17. Injection pump complete |
| 4. Oil hose (Vacuum pump ~ oil pan) | 11. Intake manifold | 18. Injection pump stay |
| 5. Oil hose (Vacuum pump ~ oil filter) | 12. Exhaust manifold | 19. Oil level gauge guide pipe |
| 6. Alternator bracket | 13. Oil level gauge | 20. Oil pressure switch |
| 7. Water by-pass pipe (for oil cooler) | 14. Fuel leak pipe and hose Ass'y | |

▣ PARTS RELATED TO TIMING MECHANISM




Fig. 1A-10

- | | |
|--|---|
| 22. Crankshaft pulley and damper | 30. Cylinder head cover |
| 23. Timing belt cover, right and seal rubber | 31. Seal cap |
| 24. Timing belt cover, left and seal rubber | 32. Camshaft pulley and key |
| 25. Injection pump pulley and key | 33. Seal plate |
| 26. Timing belt | 34. Injection pump bracket |
| 27. Tensioner spring and tensioner | 35. Alternator strap |
| 28. Cooling fan pulley bearing complete | 36. Water pump complete |
| 29. Thermostat and casing Ass'y and by-pass hose | 37. Timing belt crank pulley and woodruff key |

1A DISASSEMBLY OF ENGINE

◆ PARTS RELATED TO CYLINDER HEAD




Fig. 1A-11

- 38. Cylinder head complete and gasket
- 39. Engine hanger
- 40. Injection pipe and nozzle
- 41. Glow-plug and cable
- 42. Camshaft cap
- 43. Camshaft
- 44. Oil seal
- 45. Tappet and adjusting disc

- 46. Valve cotter
- 47. Valve spring seat, upper
- 48. Valve spring
- 49. Valve
- 50. Valve spring seat, lower
- 51. Valve seal
- 52. Valve guide and clip
- 53. Combustion chamber, inside

◆ PARTS RELATED TO LUBRICATION SYSTEM AND FLYWHEEL




Fig. 1A-12

54. Clutch cover Ass'y
55. Clutch disc
56. Flywheel Ass'y
57. End plate

58. Oil Pan
59. Oil strainer and gasket
60. Rear cover Ass'y and gasket
61. Oil pump body Ass'y

1A DISASSEMBLY OF ENGINE

▣ PARTS RELATED TO CRANKSHAFT AND PISTON ASSEMBLY




Fig. 1A-13

- 62. Connecting rod bearing cap
- 63. Connecting rod bearing
- 64. Connecting rod and piston
- 65. Piston ring
- 66. Snap ring
- 67. Piston pin

- 68. Main bearing cap, main bearing and thrust bearing
- 69. Crankshaft
- 70. Main bearing and thrust bearing(cylinder block side)
- 71. Pilot bearing
- 72. Oil jet and oil jet valve
- 73. Cylinder block Ass'y

NOTES ABOUT DISASSEMBLY

- (1) Inspect each part individually during disassembly for the way it was assembled, and for deformation, wear, and damage.
- (2) Mark or otherwise indicate parts which are similar (pistons, piston rings, connecting rods, valve springs, etc.) so that they can be reinstalled in the cylinder they were removed from.
- (3) Be sure all disassembled parts are placed so that they are in order and for the correct cylinder.
- (4) After steam cleaning the parts, use compressed air to blow off any remaining water (especially from pilot bearing).

DISASSEMBLY PROCEDURES

ENGINE HANGER

1. After separating all connections, install the engine onto the engine hanger (49 G030 005) attached to the engine stand (49 0107 680A).
2. Drain the engine oil.




Fig. 1A-14

INJECTION PUMP PULLEY

1. Make a matching mark on the injection pump body and pump bracket.
2. After tentatively tightening the pulley and the pump bracket not to rotate by using suitable bolt as shown in the figure, loosen the lock nut.
3. After loosening the pump body tightening nut, and then disassemble the pulley by using pulley puller (49 S120 215)
4. Make a matching mark on the pump and bracket.




Fig. 1A-15

TIMING BELT

1. Disassemble the timing belt as shown in the figure 1A-10.

Cautions:

Inspect the timing belt as shown in the figure 1A-63. In case of no problem, express the recognizing mark of the direction of correct rotation on the belt by chalk. That is in order to prevent from wrongly assembling in case of reusing it.




Fig. 1A-16

1A DISASSEMBLY OF ENGINE

CAMSHAFT PULLEY

1. As shown in the figure, hold the camshaft with the wrench(29mm, 1.14 in) to prevent camshaft from turning and loosen the camshaft pulley lock bolt.

Cautions:

- Before removing the camshaft pulley, turn the crankshaft 45° clockwise, to prevent damage to the valve.
- Don't damage the cylinder head edge with the wrench.

2. Separate the camshaft and pulley from the camshaft, using the pulley puller(49 S120 215A).

Caution:

- Do not hit the camshaft pulley with a hammer.



Fig. 1A-17




Fig. 1A-18

CRANKSHAFT PULLEY AND TIMING BELT CRANK PULLEY

1. After setting the ring gear brake(49 V101 060) into the flywheel assembly and preventing the pulley from turning, and then disassemble the pulley.

Cautions:

- Using the pulley puller(49 S120 215A), remove the timing belt crank pulley.
- Don't hit and twist.




Fig. 1A-19

CYLINDER HEAD COMPLETE

Loosen the cylinder head (retaining) bolts in the numbered order shown in the figure. Loosen them each a little at a time, in the order.




Fig. 1A-20

CAMSHAFT CAP

Loosen the camshaft cap nut in the numbered order shown in the figure.

Loosen them each a little at a time, in the order.




Fig. 1A-21

VALVE

Remove the valve cotter, valve seat (upper & lower), valve spring and valve from the cylinder head by using the valve spring lifter and pivot (49 0336 100A & 40 S120 222)

Caution:

When disassembling the valve sets, set the tappet and adjusting disc and then arrange according to the order of being assembled.




Fig. 1A-22

VALVE SEAL

After removing the lower valve seat, remove the valve seal by using the valve seal remover (49 S120 170).




Fig. 1A-23

COMBUSTION CHAMBER INSERT

Bring the suitable round pole into contact with glow plug hole and remove by striking as shown in the figure.

Caution:

When removing the combustion chamber insert, pay attention not to lose the steel ball.




Fig. 1A-24

1A INSPECTION AND REPAIR

CRANKSHAFT

Before removing the main bearing cap and crankshaft, measure the end play of crankshaft and record the measured values. Later, when installing, refer to the selection of the thrust bearing.

Standard end play:

0.04~0.282mm(0.0016~0.0111in)

End play limit:0.3mm(0.0118in)




Fig. 1A-25

PILOT BEARING

Using the needle bearing puller(49 1285 071), remove the pilot bearing from the crankshaft end.




Fig. 1A-26

☒ INSPECTION AND REPAIR

◆ MAINTENANCE NOTES

1. Before inspection, clean each part, and take care to remove any gasket fragment, dirt, oil or grease, carbon, moisture residue, or other foreign materials.
2. Be careful not to damage the joints or sliding parts of aluminum alloy components such as cylinder head, pistons.
3. Inspection and repair must be done in the order specified.

◆ CYLINDER HEAD COMPLETE

1. Inspection and repair of cylinder head
 - (1) Inspect for water leakage, fuel leakage, damage, and cracks. If any problem is found, replace the part.
 - (2) Measure cylinder head for distortion in the six directions shown in the figure.
Distortion limit:0.15mm(0.006in)




Fig. 1A-27

- (3) If cylinder head distortion exceeds the limit, replace the cylinder head.

Cautions:

Do not attempt to repair a cylinder head by milling or grinding.
Handle the cylinder head carefully, taking special care not to damage its lower surface.




Fig. 1A-28

- (4) Measure the distortion of manifold contacting surface.

If the distortion exceeds the limit, grind the surface, or replace the cylinder head.

Distortion limit: 0.20mm (0.008in)




Fig. 1A-29

- (5) Measure the oil clearance of camshaft.

- (a) Remove the tappet and adjusting disc from the cylinder head, and separate them by cylinder.
- (b) Clean away oil or dirt from the camshaft or cylinder head journal.
- (c) Set a plastigauge on the camshaft journal (in the axial direction of the journal.)
- (d) Set the camshaft cap, and tighten to the specified torque.

Camshaft cap tightening torque: 2.0~2.7m·kg (15~20 ft·lb)




Fig. 1A-30

Cautions:

When installing the camshaft cap, note the correct order and arrow marks.
When tightening the camshaft cap nut, do so evenly and in the order shown in the engine assembly section.




Fig. 1A-31