

580 SUPER E LOADER BACKHOE

Product: 1984-1987 Case 580 Super E Loader Backhoe Service Repair Workshop Manual

Full Download: <https://www.arepairmanual.com/downloads/1984-1987-case-580-super-e-loader-backhoe-service-repair-workshop-manual/>

[uper-e-loader-backhoe-service-repair-workshop-manual/](https://www.arepairmanual.com/downloads/1984-1987-case-580-super-e-loader-backhoe-service-repair-workshop-manual/)

TABLE OF CONTENTS

DIVISION/SECTION	SECTION NO.	FORM NO.
1 GENERAL		
Safety Rules, and Service Manual Introduction and Torque Specifications	1001	8-41700
Maintenance and Lubrication	1002	8-41700
General Engine Specifications	1010	8-24621
Detailed Engine Specifications	1024	8-24161
2 ENGINES		
Engine Stall Tests	2000	8-41700
Engine Removal and Installation	2001	8-41701
Engine Accessories (Air Cleaner, Muffler, Exhaust Pipe, Radiator, Cold Start System)	2002	8-41701
Cylinder Head and Valve Train	2415	8-24171
Cylinder Block, Pistons, Rods, Camshaft, Main Bearings, Oil Seals, and Flywheel	2425	8-24181
Lubrication System	2445	8-24191
Cooling System	2455	8-24201
Turbocharger	2465	8-25550
Turbocharger Failure Analysis	2565	9-78235
3 FUEL SYSTEM		
Engine Controls, Fuel Lines, and Fuel Tank	3001	8-41700
Fuel System and Filters	3410	8-24211
Fuel Injection Pump and Drive Gear	3412	8-27080
Fuel Injectors	3413	8-24231
4 ELECTRICAL		
Electrical Specifications and Troubleshooting	4002	8-41701
Wiring Diagrams	4003	8-41701
Battery	4005	8-41700
Starter and Starter Solenoid	4006	8-42910
Alternator	4007	8-41700
Instrument Cluster and Gauges	4009	8-41700
5 STEERING		
Steering System Troubleshooting	5002	8-41700
Steering Control Valve and Steering Column	5007	8-41702
Steering Cylinders	5010	8-41700
Front Axle - Two-Wheel Drive Machines	5021	8-41701
Front Axle - Four-Wheel Drive Machines	5022	8-41701
Steering Relief Valve	See Section 8008	
6 POWER TRAIN		
Power Shuttle Maintenance, Operation, and Troubleshooting ..	6202	8-41701
Power Shuttle and Torque Converter	6210	8-41700
Power Shuttle Controls	6211	9-69271
Transaxle Removal and Installation	6212	8-41700
Transaxle and Differential Lock	6215	8-22911
Transaxle and Differential Lock-Wet Brakes	6217	8-67550
Transfer Gear Box	6216	8-23451
Driveshaft	6222	8-41700
Wheels and Tires	6229	8-41700

J I Case

8-41701-R3

Sample of manual. Download All 1472 pages at:

<https://www.arepairmanual.com/downloads/1984-1987-case-580-super-e-loader-backhoe-service-repair-workshop-manual/>

Printed in U.S.A.
 Issued April 1984
 Revised November 1984
 Revised July 1985
 Revised December 1985
 Revised January 1987

DIVISION/SECTION

SECTION NO.

FORM NO.

7	BRAKES		
	Brake Pedals and Linkage, Master Cylinder, and Parking Brake	7106	8-41700
	Self-Adjusting Differential Brakes	7123	8-22921
	Differential Brakes - Wet Brakes	7125	8-67560
8	HYDRAULICS		
	Hydraulic Specifications, Maintenance, Troubleshooting, Flowmeter Tests, and Pressure Checks	8002	8-41702
	Cleaning the Hydraulic System	8003	9-69271
	Hydraulic Pump	8005	9-69270
	Loader Control Valve Made by J.I. Case	8006	8-41700
	Loader Control Valve Made by Parker Hannifin	8007	8-69272
	Steering Relief Valve and Quick Disconnect Couplings	8008	8-41700
	Three Point Hitch Control Valves	8009	8-41700
	Cylinders	8090	8-41700
	Backhoe Control Valve	8107	8-41700
	Stabilizer Control Valve	8109	9-69271
9	MOUNTED EQUIPMENT/CHASSIS		
	Air Conditioning Troubleshooting	9002	9-69270
	Air Conditioning System	9003	9-69270
	Loader	9010	8-41700
	Three Point Hitch	9033	8-41700
	ROPS Cab and ROPS Canopy	9061	8-41700
	Seats, Seat Belts, and Seat Supports	9064	8-41700
	Backhoe	9100	8-41701
	Decals and Painting	9201	8-41700

1001

SAFETY RULES SERVICE MANUAL INTRODUCTION AND TORQUE SPECIFICATIONS

TABLE OF CONTENTS

Safety Rules	1001-2	Grade 5 Bolts, Nuts, and Studs	1001-6
Service Manual Introduction	1001-4	Grade 8 Bolts, Nuts, and Studs	1001-6
Product Identification Number (PIN) and Serial Numbers	1001-5	Steel Hydraulic Fittings	1001-7
Torque Specifications	1001-6	Split Flange Mounting Bolts	1001-7

Written In *Clear
And
Simple
English*


SAFETY RULES

 This Symbol Shows Important Information About Safety In This Manual. When You See This Symbol, Carefully Read The Information That Follows and Understand The Possible Causes of Injury Or Death. 1-1-A

IMPORTANT: To prevent injury on the job, follow the Warning, Caution, and Danger notes in this section and other sections throughout this manual. Follow the instructions carefully.

The procedures recommended and shown in this manual are good, effective service methods. However, all possible procedures and service hazards may not be covered. Therefore, if you use a tool or procedure not recommended, you must make sure that the method you select is a safe method.

Put the warning tag shown below on the key for the key switch when you are servicing or repairing this machine. One warning tag is on every new machine. You can buy additional warning tags, part number 331-4614, from Service Parts Supply.




780449

 **WARNING:** Read operator's manual to familiarize yourself with control lever functions. 46-27

 **WARNING:** Operate tractor and equipment controls from the seat position only. Any other method could result in serious injury. 48-55

 **WARNING:** This is a one man machine, no riders allowed. 35-8

 **WARNING:** If you wear clothing that is too loose or do not use the correct safety equipment for your job, you can be injured. Always wear clothing that will not catch on objects. Extra safety equipment that can be required includes hard hat, safety shoes, ear protection, eye or face protection, heavy gloves and reflector clothing. 45-3-A



 **DANGER:** Engine exhaust fumes can cause death. If it is necessary to start the engine in a closed place, remove the exhaust fumes from the area with an exhaust pipe extension. If you do not have an exhaust pipe extension, open the doors and get outside air into the area. 48-56


 **WARNING:** Operate controls from the operator's seat only. 35-7

 **WARNING:** When working in the area of the fan belt with the engine running, avoid loose clothing if possible, and use extreme caution. 35-4



WARNING: Whenever the bucket must be raised to aid in servicing, block the loader arms in place with lift cylinder support strut or a suitable safety stand.

23-7-B



1. Lift Cylinder Support Strut

835102



WARNING: When doing checks and tests on the equipment hydraulics, follow the procedures as they are written. **DO NOT** change the procedure. 47-44



WARNING: When putting the hydraulic cylinders on this machine through the necessary cycles to check operation or to remove air from a circuit, make sure all people are out of the way. 47-45



WARNING: Use insulated gloves or mittens when working with hot parts. 47-41A



WARNING: **DO NOT**, for any reason, weld the cast front axle. Welding will cause failure of the cast front axle and result in personal injury. 49-19



WARNING: **DO NOT**, for any reason, weld the following parts.

Cast front axle

Swing tower

Support for swing cylinders

Stabilizer leg

Cast stabilizer foot

Bucket links, loader or backhoe

Welding will cause failure of the part and result in personal injury. 49-20



CAUTION: Pin sized and smaller streams of hydraulic oil under pressure can penetrate the skin and result in serious infection. If hydraulic oil under pressure does penetrate the skin, seek medical treatment immediately. Maintain all hoses and tubes in good condition. Make sure all connections are tight. Make a replacement of any tube or hose that is damaged or thought to be damaged. **DO NOT** use your hand to check for leaks; use a piece of cardboard or wood. 40-6-A



CAUTION: When removing hardened pins such as a pivot pin, or a hardened shaft, use a soft head (brass or bronze) hammer or use a driver made from brass or bronze and a steel head hammer. 46-17



CAUTION: When using a hammer to remove and install pivot pins or separate parts, using compressed air or using a grinder, wear eye protection that completely encloses the eyes (approved goggles or other approved eye protectors). 46-13



CAUTION: When servicing or repairing the machine, keep the shop floor and operator's compartment and steps free of oil, water, grease, tools, etc. Use an oil absorbing material and/or shop cloths as required. Use safe practices at all times. 40-8



CAUTION: Use suitable floor (service) jacks or chain hoists to raise wheels or track off the floor. Always block machine in place with suitable safety stands. 40-7-A





CAUTION: Some components of this machine are very heavy. Use suitable lifting equipment or additional help as instructed in this service manual. 40-10

SERVICE MANUAL INTRODUCTION

This service manual has been prepared with the latest service information available. Troubleshooting, removal, disassembly, inspection and installation procedures, and complete specifications and tightening references can be found in most sections. Some sections have drawings but no written procedure because the job is so easily done. This service manual is one of the most important tools available to the service technician.

Right, Left, Front, and Rear

The terms right-hand and left-hand and front and rear as used in this manual indicate the right and left sides, and front and rear of the machine as seen from the operator's seat for correct operation of the machine or attachment.



811546

- | | |
|------------------------------|-------------------------|
| 1. <i>Right Side-Backhoe</i> | 5. <i>Front-Backhoe</i> |
| 2. <i>Left Side-Backhoe</i> | 6. <i>Rear-Backhoe</i> |
| 3. <i>Left Side-Machine</i> | 7. <i>Rear-Machine</i> |
| 4. <i>Right Side-Machine</i> | 8. <i>Front-Machine</i> |

Text

If the service manual is for more than one machine or different models of components (planetary axles, gear boxes, control valves, etc.) the procedures have the steps necessary to service each model.

Table of Contents

A Table of Contents is in the front of this manual. The Table of Contents shows the main divisions and the sections that are in each division. The individual sections, where necessary, have a Table of Contents on the cover or second page of that section.

Page Numbers

All page numbers are made of two numbers separated by a dash, such as 4002-9. The number before the dash is the section number. The number following the dash is the page number in that section. Page numbers will be found at the upper right or left of each page.

Illustrations

Illustrations are put as near as possible to the text and are to be used as part of the text.

Special Tools

Special tools are needed to remove and install, disassemble and assemble, check, and adjust some components parts of this machine. Some special tools can be easily made locally and the necessary information to make the tool is in this service manual. Other special tools are more difficult to make locally and are available from Service Tools in the U.S. and from Jobborn Manufacturing in Canada. Use these tools according to the instructions in this service manual for your personal safety and to do the job correctly.


Order special tools from either of the following companies:

Service Tools
P.O. Box 314
Owatonna, Minnesota 55060

Jobborn Manufacturing Co.
97 Frid Street
Hamilton, Ontario L8P 4M3
Canada

Product Identification Number (PIN) and Serial Numbers

NOTE: A serial number plate is also on some components such as the starter, alternator, pumps, etc.



TORQUE SPECIFICATIONS - U.S. HARDWARE

Use the torques in this chart when special torques are not given. These torques apply to fasteners with both UNC and UNF threads as received from suppliers, dry, or when lubricated with engine oil. Not applicable if special graphites, moly-disulfide greases, or other extreme pressure lubricants are used.

Grade 5 Bolts, Nuts, and Studs			
  			
Size	Pound-Feet	Newton metres	Kilogram metres
1/4 in 6.4 mm	9-11	12-15	1.2-1.5
5/16 in 7.9 mm	17-21	23-28	2.4-2.9
3/8 in 9.5 mm	35-42	48-57	4.8-5.8
7/16 in 11.1 mm	54-64	73-87	7.5-8.8
1/2 in 12.7 mm	80-96	109-130	11.1-13.3
9/16 in 14.3 mm	110-132	149-179	15.2-18.2
5/8 in 15.9 mm	150-180	203-244	20.8-24.9
3/4 in 19.0 mm	270-324	366-439	37.3-44.8
7/8 in 22.2 mm	400-480	542-651	55.3-66.4
1.0 in 25.4 mm	580-696	787-944	80.2-96.2
1-1/8 in 28.6 mm	800-880	1085-1193	111-122
1-1/4 in 31.8 mm	1120-1240	1519-1681	155-171
1-3/8 in 34.9 mm	1460-1680	1980-2278	202-232
1-1/2 in 38.1 mm	1940-2200	2631-2983	268-304

Grade 8 Bolts, Nuts, and Studs			
  			
Size	Pound-Feet	Newton metres	Kilogram metres
1/4 in 6.4 mm	12-15	16-20	1.7-2.1
5/16 in 7.9 mm	24-29	33-39	3.3-4.0
3/8 in 9.5 mm	45-54	61-73	6.2-7.5
7/16 in 11.1 mm	70-84	95-114	9.7-11.6
1/2 in 12.7 mm	110-132	149-179	15.2-18.2
9/16 in 14.3 mm	160-192	217-260	22.1-26.5
5/8 in 15.9 mm	220-264	298-358	30.4-36.5
3/4 in 19.0 mm	380-456	515-618	52.5-63.0
7/8 in 22.2 mm	600-720	814-976	83.0-99.5
1.0 in 25.4 mm	900-1080	1220-1465	124-149
1-1/8 in 28.6 mm	1280-1440	1736-1953	177-199
1-1/4 in 31.8 mm	1820-2000	2468-2712	252-277
1-3/8 in 34.9 mm	2380-2720	3227-3688	329-376
1-1/2 in 38.1 mm	3160-3560	4285-4827	437-492

TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS

Tube OD Hose ID	Thread Size	Pound- Feet	Newton metres	Kilogram metres
37 Degree Flare Fittings				
1/4 in 6.4 mm	7/16-20	6-12	8-16	0.8-1.7
5/16 in 7.9 mm	1/2-20	8-16	11-21	1.1-2.2
3/8 in 9.5 mm	9/16-18	10-25	14-33	1.4-3.5
1/2 in 12.7 mm	3/4-16	15-42	20-56	2.1-5.8
5/8 in 15.9 mm	7/8-14	25-58	34-78	3.5-8.0
3/4 in 19.0 mm	1-1/16-12	40-80	54-108	5.5-11.1
7/8 in 22.2 mm	1-3/16-12	60-100	81-135	8.3-13.9
1.0 in 25.4 mm	1-5/16-12	75-117	102-158	10.4-16.2
1-1/4 in 31.8 mm	1-5/8-12	125-165	169-223	17.3-22.8
1-1/2 in 38.1 mm	1-7/8-12	210-250	285-338	29.0-34.6

Tube OD Hose ID	Thread Size	Pound- Feet	Newton metres	Kilogram metres
Straight Threads with O-ring				
1/4 in 6.4 mm	7/16-20	12-19	16-25	1.7-2.6
5/16 in 7.9 mm	1/2-20	16-25	22-33	2.2-3.5
3/8 in 9.5 mm	9/16-18	25-40	34-54	3.5-5.5
1/2 in 12.7 mm	3/4-16	42-67	57-90	5.8-9.3
5/8 in 15.9 mm	7/8-14	58-92	79-124	8.0-12.7
3/4 in 19.0 mm	1-1/16-12	80-128	108-174	11.1-17.8
7/8 in 22.2 mm	1-3/16-12	100-160	136-216	13.8-22.1
1.0 in 25.4 mm	1-5/16-12	117-187	159-253	16.2-25.9
1-1/4 in 31.8 mm	1-5/8-12	165-264	224-357	22.8-36.5
1-1/2 in 38.1 mm	1-7/8-12	250-400	339-542	34.6-55.3

Split Flange Mounting Bolts			
Size	Pound- Feet	Newton metres	Kilogram metres
5/16-18	15-20	20-27	2.1-2.8
3/8-16	20-25	26-33	2.8-3.5
7/16-14	35-45	47-61	4.7-6.2
1/2-13	55-65	74-88	7.6-9.0
5/8-11	140-150	190-203	19.4-20.7

1002

MAINTENANCE AND LUBRICATION

TABLE OF CONTENTS

Fluids and Lubricants	1002-2
Maintenance Chart	1002-3
Coolant Recovery System	1002-6

Written In *Clear
And
Simple
English*

FLUIDS AND LUBRICANTS

COMPONENT	CAPACITY		SPECIFICATIONS
	U.S.	METRIC	
Fuel tank	26.5 gallons	100 litres	See Operators Manual
Engine crankcase With filter change	11 quarts	10.4 litres	Recommended Engine Oil: Above 30° F (-1° C) ... SAE 20W-40 CC, CD Above 10° F (-12° C) .. SAE 15W-40 CC, CD Below 90° F (32° C) .. SAE 10W-30 CC, CD Aternate Engine Oil: Above 50° F (10° C) SAE 40 CC, CD Above 39° F (4° C) SAE 30 CC, CD 23° to 68° F (-5° to 20° C) SAE 20W20 CC, CD Below 32° F (0° C) SAE 10W CC, CD
Cooling system With heater Without heater	18.9 quarts 18.2 quarts	17.9 litres 17.2 litres	Mix ethylene glycol with water for the lowest ambient temperature expected. The mixture must be half ethylene glycol and half water.
Hydraulic reservoir System capacity with loader/backhoe	12.5 gallons 23.75 gallons	47.3 litres 89.9 litres	Case TCH Fluid
Power shuttle	8 quarts	7.6 litres	Case TCH Fluid
Transaxle	20 quarts	18.9 litres	Case FDL Fluid Alternate oil: Gear Lubricant (API-GL-4) Above 0° F (-18° C) SAE 90 Below 0° F (-18° C) SAE 80
Front drive axle Center bowl Planetary ends (each)	7 quarts 1.5 quarts	6.6 litres 1.4 litre	Case FDL Fluid
Transfer case (Four wheel drive)	1 pint	0.5 litre	Case FDL Fluid
Brake master cylinders	as required		Case TCH Fluid
	<p>NOTE: Late production machines have master cylinders that are connected to the hydraulic system. See Section 7106.</p>		<p>WARNING: DO NOT use DOT 3 brake fluid. DOT 3 brake fluid will damage the cups in the master cylinders and brake cylinders. Damage to the brake system can cause personal injury or death.</p> <p style="text-align: right;">49-13</p>
Parking Brake cable	as required		Lubriplate 105 grease.
Battery	as required		Add drinking water or distilled water.
Grease fittings	as required		No. 2 Molydisulfide grease.
Wheel bearings	as required		Wheel Bearing Grease.

MAINTENANCE CHART

This chart shows maximum service intervals for the correct maintenance of the machine. Some operating conditions will make it necessary to shorten the service intervals.

INTERVAL	SERVICE	INSTRUCTIONS
After the first 2 hours of operation, new machine only	Tighten the wheel bolts.	Section 6229.
After the first 10, 20, 50, 100, and 200 hours of operation, new machine only	Tighten the tension rod nuts for the backhoe.	Section 9100.
	Tighten the lower swing pivot nut for the backhoe.	Section 9100.
After the first 20 hours of operation, new machine only	Do the After Delivery Check.	Operators Manual.
Every 10 hours of operation or each day, whichever occurs first	Lubricate the loader and backhoe pivot points.	Operators Manual.
	Lubricate the dipper extension, if equipped.	Operators Manual.
	Check the level of the engine oil.	
Every 50 hours of operation	Lubricate the three point hitch pivot points, if equipped.	Operators Manual.
	Check the first stage fuel filter for water or sediment.	Operators Manual.
	Check the level of the oil in the power shuttle.	Operators Manual.
	Check the level of the coolant in the coolant reservoir.	Page 1002-6.
	Check the level of the oil in the reservoir.	Section 8002.
	Lubricate the front axle king pins.	Operators Manual.
	Lubricate the front axle pivot.	Operators Manual.
Every 100 hours of Operation	Lubricate the parking brake cross shaft.	Operators Manual.
	Lubricate the tie rod ends.	Operators Manual.
	Lubricate the rear axle bearings.	Operators Manual.
	Check the air pressure and condition of the tires.	Section 6229.
	Check the level of the oil in the transaxle.	Section 6212.

INTERVAL	SERVICE	INSTRUCTIONS
Every 100 hours of operation(Con't.)	<p>Check the level of the oil in the transfer case, if equipped.</p> <p>Clean the spark arrester muffler, if equipped.</p>	<p>Operators Manual.</p> <p>Section 2002.</p>
Every 250 hours of operation	<p>Lubricate the seat post.</p> <p>Lubricate the cable for the parking brake.</p> <p>Lubricate the pivots for the brake pedals.</p> <p>Lubricate the front and rear pivots for the front drive axle, if equipped.</p> <p>Check the level of the oil in the center bowl and planetaries of the front drive axle, if equipped.</p> <p>Clean the breather for the front drive axle, if equipped.</p> <p>Clean the breather for the transfer case, if equipped.</p> <p>Clean the battery.</p> <p>Check the level of the fluid in the low maintenance battery.</p> <p>Check the tension of the drive belt for the air conditioner compressor.</p> <p>Check the operation of the air conditioning system.</p> <p>Tighten the nuts on the backhoe tension rods.</p> <p>Change the engine oil.</p> <p>Replace the filter for the engine oil.</p> <p>Check the level of the fluid in the brake master cylinders. (Not necessary for master cylinders with clamp retainers.</p> <p>Check the level of the coolant in the radiator.</p>	<p>Operators Manual.</p> <p>Operators Manual.</p> <p>Operators Manual.</p> <p>Operators Manual.</p> <p>Operators Manual.</p> <p>Operators Manual.</p> <p>Section 4005.</p> <p>Section 4005.</p> <p>Section 9003.</p> <p>Section 9002.</p> <p>Section 9100.</p> <p>Operators Manual.</p> <p>Operators Manual.</p> <p>See WARNING on page 1002-2.</p> <p>Page 1002-6.</p>
Every 500 hours of operation	<p>Lubricate the universal joints and the slip joint on the front and rear drive shaft.</p> <p>Lubricate the pivot for the transfer case control lever, if equipped.</p>	<p>Operators Manual.</p> <p>Operators Manual.</p>

INTERVAL	SERVICE	INSTRUCTIONS
Every 500 hours of operation (Con't.)	Lubricate the coupling for the pump drive shaft. Lubricate the pivots for the loader control lever. Lubricate the pivots for the backhoe control levers. Lubricate the front wheel bearings. Lubricate the king pins (4) for the front drive axle, if equipped. Replace the fuel filters. Replace the filter for the hydraulic system.	Operators Manual. Operators Manual. Operators Manual. Section 5021. Operators Manual. Section 3410. Section 8002.
Every 1000 hours of operation	Check the level of the fluid in the maintenance free battery. Service the ROPS cab air filter. Drain water and sediment from the fuel tank. Change the oil in the power shuttle. Clean the screen in the power shuttle. Change the hydraulic oil. Change the gear lubricant in the transaxle. Change the gear lubricant in the front drive axle, if equipped. Change the gear lubricant in the transfer case, if equipped.	Section 4005. Section 9061. Operators Manual. Section 6202. Section 6202. Section 8002. Section 6212. Operators Manual. Operators Manual.
Every 2000 hours of operation or each year whichever occurs first	Flush the cooling system.	Fluids and Lubricants chart.
Every 4000 hours of operation	Replace the drive belt for the fan and the alternator. Inspect the fuel injection pump. Inspect the fuel injection nozzles.	Section 3412. Section 3413.
As required	Service the air cleaner when the warning lamp for the air cleaner stays illuminated during operation. Replace the filter for the hydraulic system when the warning lamp for the filter stays illuminated during operation.	Section 2002. Section 8002.

INTERVAL	SERVICE	INSTRUCTIONS
As required	<p>Tighten the wheel bolts every two hours until the wheel bolts stay tight or whenever a wheel is removed and installed.</p> <p>Tighten the nuts on the tension rods for the backhoe every two hours until the nuts stay tight, and when installing the backhoe or new mounting parts.</p> <p>Adjust the parking brake.</p>	<p>Section 6229.</p> <p>Section 9100.</p> <p>Section 7106.</p>

COOLANT RECOVERY SYSTEM

50 Hour Check

Check the level of the coolant in the reservoir when the engine is cold. If the coolant is below the ADD mark, add a mixture that is half ethylene glycol and half water. If protection against freezing below -34° F (-37° C) is required, use more ethylene glycol.

250 Hour Check

Check the level of the coolant in the radiator when the engine is cold. If the coolant is not even with the opening in the radiator, add a mixture of coolant according to instructions for the 50 Hour Check.

If the level of the coolant in the radiator is low, the reservoir has not been kept full, there is a leak in the coolant recovery system, or a leak in the cooling system.

Section 1010

FLUIDS AND LUBRICANTS

CASE CORPORATION
700 STATE STREET
RACINE, WI 53404 U.S.A.

Rac 7-62780

© 1994 Case Corporation
Printed in U.S.A.
January, 1995

1010

TABLE OF CONTENTS

ENGINE	3
COOLING SYSTEM	3
FUEL SYSTEM	3
TRANSMISSION	3
FINAL DRIVE	3
HYDRAULIC RESERVOIR	4
PTO HOUSING	4
FEEDER AND CLEANING FAN GEARCASE	4
LOWER UNLOADER GEAR CASE	4
ROTOR GEAR CASE	4
STRAW CHOPPER (IF EQUIPPED)	4

ENGINE

Oil Type.....	Case No. 1 Engine Oil
Oil Capacity - Without Filter Change	
2144 Combine	15 U.S. Quarts (14.3 Litres)
2166 Combine	20 U.S. Quarts (19 Litres)
2188 Combine	20 U.S. Quarts (19 Litres)
Oil Capacity - With Filter Change	
2144 Combine	16 U.S. Quarts (15 Litres)
2166 Combine	22 U.S. Quarts (21 Litres)
2188 Combine	22 U.S. Quarts (21 Litres)

NOTE: DO NOT put Performance Additives or other oil additive products in the engine crankcase.

COOLING SYSTEM

Coolant Type	50 Percent Mixture of Water and Ethylene Glycol Solution
Coolant Capacity	
2144 Combine	36 U.S. Quarts (34 Litres)
2166 Combine	40 U.S. Quarts (37.8 Litres)
2188 Combine	40 U.S. Quarts (37.8 Litres)

IMPORTANT: Use only heavy duty low silicate coolant. Automotive antifreeze purchased at local supply store outlets most likely is not low silicate and must not be used in Case engines.

FUEL SYSTEM

Fuel Type	ASTM D975 Grade 2-D Number 2 Diesel Fuel
Fuel Capacity	
2144 Combine	92.5 U.S. Gallons (350 Litres)
2166 Combine	92.5 U.S. Gallons (350 Litres)
2188 Combine	123 U.S. Gallons (466 Litres)

TRANSMISSION

Oil Type.....	Case Hy-Tran Plus®
Oil Capacity.....	17 U.S. Quarts (16 Litres)

NOTE: If brakes are removed from the transmission for service, an additional 1 U.S. Quart (0.95 Litre) per brake assembly must be added to the transmission.

FINAL DRIVE

Oil Type.....	Case Hy-Tran Plus®
Oil Capacity.....	13 U.S. Quarts (12.3 Litres)

HYDRAULIC RESERVOIR

Oil Type Case Hy-Tran Plus®
Reservoir Capacity 10 U.S. Gallons (38 Litres)

PTO HOUSING

Oil Type Case Hy-Tran Plus®
Oil Capacity 14 U.S. Quarts (13.2 Litres)

FEEDER AND CLEANING FAN GEAR CASE

Oil Type Case 135H EP 85W-140 Gear Lubricant
Oil Capacity 2.75 U.S. Quarts (2.6 Litres)

LOWER UNLOADER GEAR CASE

Oil Type Case 135H EP 85W-140 Gear Lubricant
Oil Capacity 0.875 to 0.938 U.S. Quart (0.83 to 0.89 Litre)

ROTOR GEAR CASE

Oil Type Case Hy-Tran Plus®
Oil Capacity 4 U.S. Quarts (3.8 Litres)

STRAW CHOPPER (IF EQUIPPED)

Oil Type Case Hy-Tran Plus®
Oil Capacity 3.3 U.S. Quarts (3.1 Litres)

Section

1024

SPECIFICATION DETAILS

Written In *Clear
And
Simple
English*

IMPORTANT: *This engine was made using the metric measurement system. All measurements and checks must be made with metric tools to make sure of an accurate reading when inspecting parts.*

TABLE OF CONTENTS

RUN-IN INSTRUCTIONS	3
ENGINE SPECIFICATION DETAILS	
Cylinder Block	4
Service Cylinder Sleeve	4
Piston	4
Piston Pin	4
Piston Rings	5
Cylinder Head	5
Tappets	5
Connecting Rod	5
Crankshaft	6
Camshaft	7
Valve Push Rod Lifters	7
Gear Train	7
Rocker Arm Assembly	7
Turbocharger	7
Intake Valve	8
Exhaust Valve	8
Valve Springs	8
SPECIAL TORQUES	9-11

RUN-IN INSTRUCTIONS

Engine Lubrication

Fill the engine crankcase with CC or CD service classification oil that has the correct viscosity rating for the ambient air temperature. Install new oil filters, after the engine has been rebuilt.

Run-In Procedure For Rebuilt Engine

- Step 1 Disconnect the wire to the electric shut-off on the injection pump so that the engine will not start. Crank the engine for 30 seconds until there is oil pressure, then reconnect the wire.
- Step 2 Remove the air from the cooling system at the temperature sending unit.
- Step 3 Run the engine at 1000 RPM minimum load for 5 minutes and check for oil leaks.
- Step 4 During the Run-In, continue to check the oil pressure, coolant level, and coolant temperature.

Run-In Procedure For Rebuilt Engines (With A Dynamometer)

The following procedure must be followed when using a PTO dynamometer to Run-In the engine. The dynamometer will control the engine load at each speed and will remove stress on new parts during Run-In.

During the Run-In, continue to check the oil pressure, coolant level and coolant temperature.

STEP	TIME	ENGINE SPEED	DYNAMOMETER SCALE LOAD
1	5 Minutes	1000 RPM	50
2	5 Minutes	1100 RPM	1/2
3	5 Minutes	2200 RPM	Full

Run-In Procedure for Rebuilt Engines (Without A Dynamometer)

STEP	TIME	ENGINE SPEED	LOAD
1	5 Minutes	1000 RPM	No Load
2	5 Minutes	1100 RPM	Light Load
3	5 Minutes	2200 RPM	Light Load

Run-In Procedure (Agriculture Tractors)

For the first 8 hours of field operation stay one gear lower than normal. For the next 12 hours DO NOT "lug" the engine. Prevent "lugging" by moving the lever to a lower gear. The engine must not be "lugged" below the rated engine RPM during early hours of life.

Run-In Procedure (Construction Equipment)

For the first 8 hours, operate the engine at full throttle maintaining a normal load. DO NOT "baby" the engine, but avoid converter or hydraulic stall. The engine must not be "lugged" below the Rated Engine RPM (Do not stall the engine more than 10 seconds).

ENGINE SPECIFICATION DETAILS

Cylinder Block

	Metric Value
Type	Non-Sleeved
Material	Cast Iron
ID of Cylinder	102.00 to 102.04 mm
Maximum Service Limit	102.116 mm
Cylinder Out of Round (Maximum)	0.038 mm
Cylinder Taper (Maximum)	0.076 mm
0.5 mm Oversize Piston	
Machine Cylinder Bore to	102.50 to 102.54 mm
1.00 mm Oversize Piston	
Machine Cylinder Bore to	103.00 to 103.04 mm

Service Cylinder Sleeve

Type	Dry, Can Be Replaced
Material	Cast Iron
Machine Cylinder Block Bore to	104.500 to 104.515 mm
Installation	Press Fit
Machine Sleeve Bore to:	
Standard Size Piston	102.00 to 102.04 mm
0.5 mm Oversize Piston	102.50 to 102.54 mm
1.0 mm Oversize Piston	103.00 to 103.04 mm

Piston

Type	Cam Ground
Material	Aluminum alloy
OD at 12 mm From the Bottom, 90 Degrees Piston Pin	
Standard Size Piston	101.873 to 101.887 mm
Minimum Service Limit	101.823 mm
0.5 mm Oversize Piston	102.373 to 102.387 mm
Minimum Service Limit	101.323 mm
1.0 mm Oversize Piston	102.873 to 102.887 mm
Minimum Service Limit	102.823 mm
ID of Piston Pin Bore	40.006 to 40.012 mm
Maximum Service Limit	40.025 mm
Width of 1st Ring Groove (Top)	2.465 to 2.485 mm
Width of 2nd Ring Groove (Intermediate)	2.425 to 2.445 mm
Width of 3rd Ring Groove (Oil Ring)	4.040 to 4.060 mm
Protrusion Above Cylinder Block (Maximum)	0.660 mm

Piston Pin

Type	Full Float
OD of Pin	39.997 to 40.003 mm
Minimum Service Limit	39.990 mm

Piston Rings

No. 1 Compression 4T-390 Engine	Key Stone Type (Barrel Face)
End Gap in 102.02 ID	0.4 to 0.70 mm
No. 1 Compression 4-390 Engine	Rectangular Type (Barrel Face)
End Gap in 102.02 ID	0.25 to 0.55 mm
Maximum Service Limit	0.806 mm
Side Clearance	0.075 to 0.120 mm
Maximum Service Limit	0.15 mm
No. 2 Compression	Rectangular Type (Tapper Face)
End Gap in 102.02 ID	0.25 to 0.55 mm
Maximum Service Limit	0.806 mm
Side Clearance	0.075 to 0.120 mm
Maximum Service Limit	0.15 mm
No. 3 Oil Control Rings	Two Piece
End Gap in 102.02 ID	0.25 to 0.55 mm
Maximum Service Limit	0.806 mm
Side Clearance	0.130 mm

Cylinder Head

Warpage (Maximum)	0.20 mm
-------------------	---------

Lifters

Material	Hardened Iron
OD of Lifter	15.961 to 15.977 mm
Minimum Service Limit	15.960 mm
Bore Diameter in Block	16.000 to 16.030 mm
Maximum Service Limit	16.055 mm

Connecting Rod

Bushing	Steel Backed Leaded Bronze
Bushing ID Installed (Ream to Size)	40.053 to 40.067 mm
Maximum Service Limit	40.092 mm
Bearing Liners	Replaceable
Journal ID Without Bearing Liners	72.987 to 73.013 mm
Bearing Oil Clearance	0.038 to 0.116 mm
Maximum Service Limit	0.129 mm
Side Clearance	0.100 to 0.300 mm
Maximum Service Limit	0.330 mm
Connecting Rod Bend (Maximum)	
Without Bushing	0.200 mm
With Bushing	0.150 mm
Connecting Rod Twist (Maximum)	
Without Bushing	0.500 mm
With Bushing	0.300 mm

Crankshaft

Type	Hardened Steel, Balanced
Main Bearing Liners	Replaceable
End Clearance, Center Main Bearing Cap	0.041 to 0.119 mm
Center Main Bearing Thrust Surface Thickness	2.50 mm
Connecting Rod Journal	
OD, Standard	68.987 to 69.013 mm
Minimum Service Limit	68.962 mm
0.25 mm OD Undersize, Grind to	68.737 to 68.763 mm
Minimum Service Limit	68.712 mm
0.50 mm OD Undersize, Grind to	68.487 to 68.513 mm
Minimum Service Limit	68.462 mm
0.75 mm OD Undersize, Grind to	68.237 to 68.263 mm
Minimum Service Limit	68.212 mm
1.00 mm OD Undersize, Grind to	67.987 to 68.013 mm
Minimum Service Limit	67.962 mm
Connecting Rod Journal Maximum Taper	0.013 mm
Journals Out of Round Maximum	0.050 mm
Undersize Main Bearing Liners For Service	0.25, 0.50, 0.75 and 1.00 mm
Main Bearing Oil Clearance	0.041 to 0.119 mm
Maximum Service Limit	0.140 mm
Main Bearing Journal	
OD, Standard	82.987 to 83.013 mm
Minimum Service Limit	82.962 mm
0.25 mm OD Undersize, Grind to	82.737 to 82.763 mm
Minimum Service Limit	82.712 mm
0.50 mm OD Undersize, Grind to	82.487 to 82.513 mm
Minimum Service Limit	82.462 mm
0.75 mm OD Undersize, Grind to	82.237 to 82.263 mm
Minimum Service Limit	82.212 mm
1.00 mm OD Undersize, Grind to	81.987 to 82.013 mm
Minimum Service Limit	81.962 mm
Main Bearing Journal Bore ID No Liners	87.982 to 88.018 mm
Maximum Service Limit	88.031 mm
Main Journal Width:	
1st, 2nd, 3rd, 5th	37.424 to 37.576 mm
4th	37.475 to 37.525 mm
Connect Rod Journals Width	38.950 to 39.050 mm

Camshaft

Type	Hardened Iron
Bushing (Front Only)	1, Replaceable
Bushing Lubrication:	
Front Bushing	Pressure Lubricated
Intermediate	Pressure Lubricated
Rear	Pressure Lubricated
Oil Clearance	0.076 to 0.152 mm
ID of No. 1 Bushing	54.107 to 54.133 mm
Maximum Service Limit	54.146 mm
ID of No. 1 Oversize (57.24 mm OD) Service Bushing	54.089 to 54.139 mm
Maximum Service Limit	54.146 mm
ID of No. 2, 3, 4 and 5 Service Bushing	54.089 to 54.139 mm
Maximum Service Limit	54.146 mm
Width of No. 1 Bushing	25.15 to 25.65 mm
Width of No. 2, 3, 4 and 5 Service Bushing	17.75 to 18.25 mm
Camshaft Bushing Journal OD	53.987 to 54.013 mm
Camshaft Bore Diameter in Block	
No. 1 Bushing	57.222 to 57.258 mm
No. 1 Oversize Bushing, Machine to	57.722 to 57.758 mm
No. 2, 3, 4 and 5, Less Bushings	54.089 to 54.139 mm
No. 2, 3, 4 and 5 Oversize for Bushings, Machine to	57.222 to 57.258 mm
Camshaft Thrust Thickness	9.42 to 9.58 mm
Minimum Service Limit	9.34 mm
Camshaft Thrust Clearance	0.130 to 0.340 mm
Maximum Service Limit	0.470 mm

Turbocharger

Horizontal Travel of Turbine Shaft	0.10 to 0.16 mm
--	-----------------

Gear Train

Backlash:	
Crankshaft Gear to Camshaft Gear	0.08 to 0.33 mm
Crankshaft Gear to Idler Gear	0.08 to 0.33 mm
Camshaft to Fuel Pump Gear	0.08 to 0.33 mm
Idler Gear to Oil Pump	0.08 to 0.33 mm
Camshaft to Auxiliary	0.08 to 0.33 mm
Maximum Service Limit (All Gears)	0.45 mm

Rocker Arm Assembly

OD of Shaft	18.963 to 18.975 mm
Minimum Service Limit	18.938 mm
ID of Arm Bore	19.000 to 19.026 mm
Maximum Service Limit	19.051 mm
Lubrication	Pressure From Oil Gallery

Intake Valve

Tappet Clearance (Cold)	0.254 mm
Face Angle	29 Degrees
Face Run-Out	0.038 mm
Valve Head Edge Thickness, Minimum	1.50 mm
Length	128.84 to 129.46 mm
OD of Stem	7.960 to 7.980 mm
Minimum Service Limit	7.940 mm
OD of Head	44.870 to 45.130 mm
Seat Angle	30 Degrees
Seat Contact Width	1.32 to 1.92 mm
Seat Run-Out	0.10 mm
Insert Height	6.84 to 6.96 mm
OD of Insert	47.063 to 47.089 mm
ID of Insert	Tapered
Valve Recession Below Head Surface	0.99 to 1.52 mm
Maximum Service Limit	1.52 mm
ID of Valve Guide Bore	8.019 to 8.039 mm
Maximum Service Limit	8.089 mm

Exhaust Valve

Tappet Clearance (Cold)	0.508 mm
Face Angle	44 Degrees
Face Run-Out	0.038 mm
Valve Head Edge Thickness, Minimum	1.50 mm
OD of Head	41.870 to 42.130 mm
OD of Stem	7.960 to 7.980 mm
Minimum Service Limit	7.940 mm
Length	128.74 to 129.36 mm
Insert Seat Angle	45 Degrees
Seat Contact Width	1.47 to 2.07 mm
Seat Run-Out	0.10 mm
Insert Height	6.65 to 6.77 mm
OD of Insert	43.713 to 43.739 mm
ID of Insert	Tapered
Valve Recession Below Head Surface	0.99 to 1.52 mm
Maximum Service Limit	1.52 mm
ID of Valve Guide Bore	8.019 to 8.039 mm
Maximum Service Limit	8.089 mm

Valve Springs

Free Length	55.63 mm
Total Coils	7.25
Wire Diameter	4.830 to 4.930 mm
Compressed to 38.53 mm	(Valve Open) 785 to 839 N
Minimum Service Limit	765 N
Compressed to 49.25 mm	(Valve Closed) 285 to 321 N
Minimum Service Limit	270 N

SPECIAL TORQUES

	U.S. Value	Metric Value
Alternator Bracket Bolts (Lower)	18 lb ft	24 Nm (2.4 kgm)
Alternator Bracket Bolts (Upper)	18 lb ft	24 Nm (2.4 kgm)
Alternator Retaining Bolt	18 lb ft	24 Nm (2.4 kgm)
Belt Tensioner Bracket Bolts	18 lb ft	24 Nm (2.4 kgm)
Belt Tensioner Retaining Bolt	32 lb ft	43 Nm (4.3 kgm)
Camshaft Retaining Bolts	18 lb ft	24 Nm (2.4 kgm)
Connecting Rod Bolts	74 lb ft	100 Nm (10.0 kgm)
(Lubricate Threads With Engine Oil)		
Exhaust Manifold Bolts	32 lb ft	43 Nm (4.3 kgm)
Fan Pulley Bracket Bolts	18 lb ft	24 Nm (2.4 kgm)
Fan Pulley Bolts	18 lb ft	24 Nm (2.4 kgm)
Flywheel Housing Bolts	44 lb ft	60 Nm (6.0 kgm)
Flywheel Retaining Bolts	101 lb ft	137 Nm (13.7 kgm)
Flywheel Housing Cover Bolts	18 lb ft	24 Nm (2.4 kgm)
Fuel Filter Inlet Bolt	24 lb ft	32 Nm (3.2 kgm)
Fuel Air Removal Bolt	4 lb ft	6 Nm (0.6 kgm)
Fuel Filter Inlet Nut	24 lb ft	32 Nm (3.2 kgm)
Fuel Line Fitting (High Pressure)	18 lb ft	24 Nm (2.4 kgm)
Fuel Line Fitting (Low Pressure)	18 lb ft	24 Nm (2.4 kgm)
Front Cover Bolts	18 lb ft	24 Nm (2.4 kgm)
Front Housing Bolts	18 lb ft	24 Nm (2.4 kgm)
Cylinder Head Bolts	93 lb ft	126 Nm (12.6 kgm)
Injection Pump Drive Gear Nut	48 lb ft	65 Nm (6.5 kgm)
Injection Pump Lock Bolt	22 lb ft	30 Nm (3.0 kgm)

SPECIAL TORQUES (CONT'D)

	U.S. Value	Metric Value
Injection Pump Retaining Nuts	18 lb ft	24 Nm (2.4 kgm)
Injection Pump Bracket Bolts	18 lb ft	24 Nm (2.4 kgm)
Injector Leak off Bolt	6 lb ft	8 Nm (0.8 kgm)
Injector Retaining Nut	44 lb ft	60 Nm (6.0 kgm)
Intake Manifold Bolts	18 lb ft	24 Nm (2.4 kgm)
Intake Manifold Plug	92 lb ft	125 Nm (12.5 kgm)
Engine Lift Bracket Bolts (Rear)	57 lb ft	77 Nm (7.7 kgm)
Main Bearing Bolts	129 lb ft	175 Nm (17.5 kgm)
(Lubricate The Threads With Engine Oil)		
Oil Fill Tube Bolts	32 lb ft	43 Nm (4.3 kgm)
Oil Pan Drain Plug	55 lb ft	75 Nm (7.5 kgm)
Oil Pan Heater Plug	90 lb ft	122 Nm (12.2 kgm)
Oil Pan Retaining Bolts	18 lb ft	24 Nm (2.4 kgm)
Oil Pump Retaining Bolts	18 lb ft	24 Nm (2.4 kgm)
Oil Inlet Tube Bolts	18 lb ft	24 Nm (2.4 kgm)
Oil Inlet Tube Brace	18 lb ft	24 Nm (2.4 kgm)
Oil Filter Housing Bolts	18 lb ft	24 Nm (2.4 kgm)
Rear Seal Retaining Bolts	7 lb ft	9 Nm (0.9 kgm)
Rocker Arm Bolts	18 lb ft	24 Nm (2.4 kgm)
Starter Retaining Bolts	32 lb ft	43 Nm (4.3 kgm)
Tachometer Drive Retaining Bolts	2 lb ft	3 Nm (0.3 kgm)
Lifter Cover Bolts	18 lb ft	24 Nm (2.4 kgm)
Thermostat Housing Bolts	18 lb ft	24 Nm (2.4 kgm)
Timing Pin Retaining Bolts	4 lb ft	5 Nm (0.5 kgm)
Fuel Shutoff Solenoid	10 lb ft	15 Nm (1.5 kgm)

Sample of manual. Download All 1472 pages at:

<https://www.arepairmanual.com/downloads/1984-1987-case-580-super-e-loader-backhoe-service-repair-workshop-manual/>