

SERVICE MANUAL

Cursor 11 Tier 4B (final) and Stage IV Engine

See the following page for engine model numbers



Part number 47608463

1st edition English
September 2015

Sample of manual. Download All 337 pages at:

<https://www.arepairmanual.com/downloads/case-cursor-11-tier-4b-final-and-stage-iv-engine-service-manual/>

Product: Case Cursor 11 Tier 4B (final) and Stage IV ENGINE Service Manual
Full Download: <https://www.arepairmanual.com/downloads/case-cursor-11-tier-4b-final-and-stage-iv-engine-service-manual/>



SERVICE MANUAL

F3GFE613A*B001

F3GFE613B*B001

Sample of manual. Download All 337 pages at:

<https://www.arepairmanual.com/downloads/case-cursor-11-tier-4b-final-and-stage-iv-engine-service-manual/>

47608463 09/09/2015

EN

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
[10.101] Cylinder heads	10.2
[10.102] Pan and covers	10.3
[10.103] Crankshaft and flywheel.....	10.4
[10.105] Connecting rods and pistons.....	10.5
[10.106] Valve drive and gears	10.6
[10.110] Balancer and damper	10.7
[10.114] Pump drives	10.8
[10.206] Fuel filters	10.9
[10.218] Fuel injection system.....	10.10
[10.250] Turbocharger and lines.....	10.11
[10.254] Intake and exhaust manifolds and muffler	10.12
[10.304] Engine lubrication system.....	10.13
[10.400] Engine cooling system	10.14
[10.408] Oil cooler and lines.....	10.15
[10.414] Fan and drive	10.16
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment	10.17
Electrical systems	55
[55.010] Fuel injection system.....	55.1
[55.012] Engine cooling system	55.2
[55.014] Engine intake and exhaust system.....	55.3
[55.015] Engine control system.....	55.4
[55.202] Cold start aid	55.5
[55.988] Selective Catalytic Reduction (SCR) electrical system	55.6



INTRODUCTION

Contents

INTRODUCTION

Foreword - Important notice regarding equipment servicing	3
Safety rules	4
Safety rules - Ecology and the environment	5
Torque - Minimum tightening torques for normal assembly	6
Basic instructions - Shop and assembly	11

Foreword - Important notice regarding equipment servicing

All repair and maintenance work listed in this manual must be carried out only by qualified dealership personnel, strictly complying with the instructions given, and using, whenever possible, the special tools.

Anyone who performs repair and maintenance operations without complying with the procedures provided herein shall be responsible for any subsequent damages.

The manufacturer and all the organizations of its distribution chain, including - without limitation - national, regional, or local dealers, reject any responsibility for damages caused by parts and/or components not approved by the manufacturer, including those used for the servicing or repair of the product manufactured or marketed by the manufacturer. In any case, no warranty is given or attributed on the product manufactured or marketed by the manufacturer in case of damages caused by parts and/or components not approved by the manufacturer.

The manufacturer reserves the right to make improvements in design and changes in specifications at any time without notice and without incurring any obligation to install them on units previously sold. Specifications, descriptions, and illustrative material herein are as accurate as known at time of publication but are subject to change without notice.

In case of questions, refer to your CNH Sales and Service Networks.

Safety rules

Personal safety



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible death or injury.

Throughout this manual you will find the signal words DANGER, WARNING, and CAUTION followed by special instructions. These precautions are intended for the personal safety of you and those working with you.

Read and understand all the safety messages in this manual before you operate or service the machine.

 DANGER indicates a hazardous situation that, if not avoided, will result in death or serious injury.

 WARNING indicates a hazardous situation that, if not avoided, could result in death or serious injury.

 CAUTION indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

FAILURE TO FOLLOW DANGER, WARNING, AND CAUTION MESSAGES COULD RESULT IN DEATH OR SERIOUS INJURY.

Machine safety

NOTICE: Notice indicates a situation that, if not avoided, could result in machine or property damage.

Throughout this manual you will find the signal word Notice followed by special instructions to prevent machine or property damage. The word Notice is used to address practices not related to personal safety.

Information

NOTE: Note indicates additional information that clarifies steps, procedures, or other information in this manual.

Throughout this manual you will find the word Note followed by additional information about a step, procedure, or other information in the manual. The word Note is not intended to address personal safety or property damage.

Safety rules - Ecology and the environment

Soil, air, and water are vital factors of agriculture and life in general. When legislation does not yet rule the treatment of some of the substances required by advanced technology, sound judgment should govern the use and disposal of products of a chemical and petrochemical nature.

NOTE: *The following are recommendations that may be of assistance:*

- Become acquainted with and ensure that you understand the relative legislation applicable to your country.
- Where no legislation exists, obtain information from suppliers of oils, filters, batteries, fuels, antifreeze, cleaning agents, etc., with regard to their effect on man and nature and how to safely store, use, and dispose of these substances.
- Agricultural consultants will, in many cases, be able to help you as well.

Helpful hints

- Avoid filling tanks using cans or inappropriate pressurized fuel delivery systems that may cause considerable spillage.
- In general, avoid skin contact with all fuels, oils, acids, solvents, etc. Most of them contain substances that may be harmful to your health.
- Modern oils contain additives. Do not burn contaminated fuels and or waste oils in ordinary heating systems.
- Avoid spillage when draining off used engine coolant mixtures, engine, gearbox and hydraulic oils, brake fluids, etc. Do not mix drained brake fluids or fuels with lubricants. Store them safely until they can be disposed of in a proper way to comply with local legislation and available resources.
- Do not allow coolant mixtures to get into the soil. Collect and dispose of coolant mixtures properly.
- Do not open the air-conditioning system yourself. It contains gases that should not be released into the atmosphere. Your CNH dealer or air conditioning specialist has a special extractor for this purpose and will have to recharge the system properly.
- Repair any leaks or defects in the engine cooling or hydraulic system immediately.
- Do not increase the pressure in a pressurized circuit as this may lead to a component failure.
- Protect hoses during welding as penetrating weld splatter may burn a hole or weaken them, allowing the loss of oils, coolant, etc.

Torque - Minimum tightening torques for normal assembly

METRIC NON-FLANGED HARDWARE

NOM. SIZE	CLASS 8.8 BOLT and CLASS 8 NUT		CLASS 10.9 BOLT and CLASS 10 NUT		LOCKNUT CL.8 W/CL8.8 BOLT	LOCKNUT CL.10 W/CL10.9 BOLT
	UNPLATED	PLATED W/ZnCr	UNPLATED	PLATED W/ZnCr		
M4	2.2 N·m (19 lb in)	2.9 N·m (26 lb in)	3.2 N·m (28 lb in)	4.2 N·m (37 lb in)	2 N·m (18 lb in)	2.9 N·m (26 lb in)
M5	4.5 N·m (40 lb in)	5.9 N·m (52 lb in)	6.4 N·m (57 lb in)	8.5 N·m (75 lb in)	4 N·m (36 lb in)	5.8 N·m (51 lb in)
M6	7.5 N·m (66 lb in)	10 N·m (89 lb in)	11 N·m (96 lb in)	15 N·m (128 lb in)	6.8 N·m (60 lb in)	10 N·m (89 lb in)
M8	18 N·m (163 lb in)	25 N·m (217 lb in)	26 N·m (234 lb in)	35 N·m (311 lb in)	17 N·m (151 lb in)	24 N·m (212 lb in)
M10	37 N·m (27 lb ft)	49 N·m (36 lb ft)	52 N·m (38 lb ft)	70 N·m (51 lb ft)	33 N·m (25 lb ft)	48 N·m (35 lb ft)
M12	64 N·m (47 lb ft)	85 N·m (63 lb ft)	91 N·m (67 lb ft)	121 N·m (90 lb ft)	58 N·m (43 lb ft)	83 N·m (61 lb ft)
M16	158 N·m (116 lb ft)	210 N·m (155 lb ft)	225 N·m (166 lb ft)	301 N·m (222 lb ft)	143 N·m (106 lb ft)	205 N·m (151 lb ft)
M20	319 N·m (235 lb ft)	425 N·m (313 lb ft)	440 N·m (325 lb ft)	587 N·m (433 lb ft)	290 N·m (214 lb ft)	400 N·m (295 lb ft)
M24	551 N·m (410 lb ft)	735 N·m (500 lb ft)	762 N·m (560 lb ft)	1016 N·m (750 lb ft)	501 N·m (370 lb ft)	693 N·m (510 lb ft)


NOTE: M4 through M8 hardware torque specifications are shown in pound-inches. M10 through M24 hardware torque specifications are shown in pound-feet.

METRIC FLANGED HARDWARE

NOM. SIZE	CLASS 8.8 BOLT and CLASS 8 NUT		CLASS 10.9 BOLT and CLASS 10 NUT		LOCKNUT CL.8 W/CL8.8 BOLT	LOCKNUT CL.10 W/CL10.9 BOLT
	UNPLATED	PLATED W/ZnCr	UNPLATED	PLATED W/ZnCr		
M4	2.4 N·m (21 lb in)	3.2 N·m (28 lb in)	3.5 N·m (31 lb in)	4.6 N·m (41 lb in)	2.2 N·m (19 lb in)	3.1 N·m (27 lb in)
M5	4.9 N·m (43 lb in)	6.5 N·m (58 lb in)	7.0 N·m (62 lb in)	9.4 N·m (83 lb in)	4.4 N·m (39 lb in)	6.4 N·m (57 lb in)
M6	8.3 N·m (73 lb in)	11 N·m (96 lb in)	12 N·m (105 lb in)	16 N·m (141 lb in)	7.5 N·m (66 lb in)	11 N·m (96 lb in)
M8	20 N·m (179 lb in)	27 N·m (240 lb in)	29 N·m (257 lb in)	39 N·m (343 lb in)	18 N·m (163 lb in)	27 N·m (240 lb in)
M10	40 N·m (30 lb ft)	54 N·m (40 lb ft)	57 N·m (42 lb ft)	77 N·m (56 lb ft)	37 N·m (27 lb ft)	53 N·m (39 lb ft)
M12	70 N·m (52 lb ft)	93 N·m (69 lb ft)	100 N·m (74 lb ft)	134 N·m (98 lb ft)	63 N·m (47 lb ft)	91 N·m (67 lb ft)
M16	174 N·m (128 lb ft)	231 N·m (171 lb ft)	248 N·m (183 lb ft)	331 N·m (244 lb ft)	158 N·m (116 lb ft)	226 N·m (167 lb ft)
M20	350 N·m (259 lb ft)	467 N·m (345 lb ft)	484 N·m (357 lb ft)	645 N·m (476 lb ft)	318 N·m (235 lb ft)	440 N·m (325 lb ft)
M24	607 N·m (447 lb ft)	809 N·m (597 lb ft)	838 N·m (618 lb ft)	1118 N·m (824 lb ft)	552 N·m (407 lb ft)	

IDENTIFICATION


Metric Hex head and carriage bolts, classes 5.6 and up



20083680 1

1. Manufacturer's Identification
2. Property Class

Metric Hex nuts and locknuts, classes 05 and up



20083681 2

1. Manufacturer's Identification
2. Property Class
3. Clock Marking of Property Class and Manufacturer's Identification (Optional), i.e. marks **60 °** apart indicate Class 10 properties, and marks **120 °** apart indicate Class 8.


INCH NON-FLANGED HARDWARE

NOMINAL SIZE	SAE GRADE 5 BOLT and NUT		SAE GRADE 8 BOLT and NUT		LOCKNUT GrB W/ Gr5 BOLT	LOCKNUT GrC W/ Gr8 BOLT
	UN- PLATED or PLATED SILVER	PLATED W/ZnCr GOLD	UN- PLATED or PLATED SILVER	PLATED W/ZnCr GOLD		
1/4	8 N·m (71 lb in)	11 N·m (97 lb in)	12 N·m (106 lb in)	16 N·m (142 lb in)	8.5 N·m (75 lb in)	12.2 N·m (109 lb in)
5/16	17 N·m (150 lb in)	23 N·m (204 lb in)	24 N·m (212 lb in)	32 N·m (283 lb in)	17.5 N·m (155 lb in)	25 N·m (220 lb in)
3/8	30 N·m (22 lb ft)	40 N·m (30 lb ft)	43 N·m (31 lb ft)	57 N·m (42 lb ft)	31 N·m (23 lb ft)	44 N·m (33 lb ft)
7/16	48 N·m (36 lb ft)	65 N·m (48 lb ft)	68 N·m (50 lb ft)	91 N·m (67 lb ft)	50 N·m (37 lb ft)	71 N·m (53 lb ft)
1/2	74 N·m (54 lb ft)	98 N·m (73 lb ft)	104 N·m (77 lb ft)	139 N·m (103 lb ft)	76 N·m (56 lb ft)	108 N·m (80 lb ft)
9/16	107 N·m (79 lb ft)	142 N·m (105 lb ft)	150 N·m (111 lb ft)	201 N·m (148 lb ft)	111 N·m (82 lb ft)	156 N·m (115 lb ft)
5/8	147 N·m (108 lb ft)	196 N·m (145 lb ft)	208 N·m (153 lb ft)	277 N·m (204 lb ft)	153 N·m (113 lb ft)	215 N·m (159 lb ft)
3/4	261 N·m (193 lb ft)	348 N·m (257 lb ft)	369 N·m (272 lb ft)	491 N·m (362 lb ft)	271 N·m (200 lb ft)	383 N·m (282 lb ft)
7/8	420 N·m (310 lb ft)	561 N·m (413 lb ft)	594 N·m (438 lb ft)	791 N·m (584 lb ft)	437 N·m (323 lb ft)	617 N·m (455 lb ft)
1	630 N·m (465 lb ft)	841 N·m (620 lb ft)	890 N·m (656 lb ft)	1187 N·m (875 lb ft)	654 N·m (483 lb ft)	924 N·m (681 lb ft)

NOTE: For Imperial Units, *1/4 in* and *5/16 in* hardware torque specifications are shown in pound-inches. *3/8 in* through *1 in* hardware torque specifications are shown in pound-feet.

INCH FLANGED HARDWARE


NOM- INAL SIZE	SAE GRADE 5 BOLT and NUT		SAE GRADE 8 BOLT and NUT		LOCKNUT GrF W/ Gr5 BOLT	LOCKNUT GrG W/ Gr8 BOLT
	UNPLATED or PLATED SILVER	PLATED W/ZnCr GOLD	UNPLATED or PLATED SILVER	PLATED W/ZnCr GOLD		
1/4	9 N·m (80 lb in)	12 N·m (106 lb in)	13 N·m (115 lb in)	17 N·m (150 lb in)	8 N·m (71 lb in)	12 N·m (106 lb in)
5/16	19 N·m (168 lb in)	25 N·m (221 lb in)	26 N·m (230 lb in)	35 N·m (310 lb in)	17 N·m (150 lb in)	24 N·m (212 lb in)
3/8	33 N·m (25 lb ft)	44 N·m (33 lb ft)	47 N·m (35 lb ft)	63 N·m (46 lb ft)	30 N·m (22 lb ft)	43 N·m (32 lb ft)
7/16	53 N·m (39 lb ft)	71 N·m (52 lb ft)	75 N·m (55 lb ft)	100 N·m (74 lb ft)	48 N·m (35 lb ft)	68 N·m (50 lb ft)
1/2	81 N·m (60 lb ft)	108 N·m (80 lb ft)	115 N·m (85 lb ft)	153 N·m (113 lb ft)	74 N·m (55 lb ft)	104 N·m (77 lb ft)
9/16	117 N·m (86 lb ft)	156 N·m (115 lb ft)	165 N·m (122 lb ft)	221 N·m (163 lb ft)	106 N·m (78 lb ft)	157 N·m (116 lb ft)
5/8	162 N·m (119 lb ft)	216 N·m (159 lb ft)	228 N·m (168 lb ft)	304 N·m (225 lb ft)	147 N·m (108 lb ft)	207 N·m (153 lb ft)
3/4	287 N·m (212 lb ft)	383 N·m (282 lb ft)	405 N·m (299 lb ft)	541 N·m (399 lb ft)	261 N·m (193 lb ft)	369 N·m (272 lb ft)
7/8	462 N·m (341 lb ft)	617 N·m (455 lb ft)	653 N·m (482 lb ft)	871 N·m (642 lb ft)	421 N·m (311 lb ft)	594 N·m (438 lb ft)
1	693 N·m (512 lb ft)	925 N·m (682 lb ft)	979 N·m (722 lb ft)	1305 N·m (963 lb ft)	631 N·m (465 lb ft)	890 N·m (656 lb ft)

IDENTIFICATION**Inch Bolts and free-spinning nuts**

20083682 3

Grade Marking Examples

SAE Grade Identification			
1	Grade 2 - No Marks	4	Grade 2 Nut - No Marks
2	Grade 5 - Three Marks	5	Grade 5 Nut - Marks 120 ° Apart
3	Grade 8 - Five Marks	6	Grade 8 Nut - Marks 60 ° Apart

Inch Lock Nuts, All Metal (Three optional methods)

20090268 4

Grade Identification

Grade	Corner Marking Method (1)	Flats Marking Method (2)	Clock Marking Method (3)
Grade A	No Notches	No Mark	No Marks
Grade B	One Circumferential Notch	Letter B	Three Marks
Grade C	Two Circumferential Notches	Letter C	Six Marks

Basic instructions - Shop and assembly

Shimming

For each adjustment operation, select adjusting shims and measure the adjusting shims individually using a micrometer, then add up the recorded values. Do not rely on measuring the entire shimming set, which may be incorrect, or the rated value shown on each shim.

Rotating shaft seals

For correct rotating shaft seal installation, proceed as follows:

1. Before assembly, allow the seal to soak in the oil it will be sealing for at least thirty minutes.
2. Thoroughly clean the shaft and check that the working surface on the shaft is not damaged.
3. Position the sealing lip facing the fluid.

NOTE: *With hydrodynamic lips, take into consideration the shaft rotation direction and position the grooves so that they will move the fluid towards the inner side of the seal.*

4. Coat the sealing lip with a thin layer of lubricant (use oil rather than grease). Fill the gap between the sealing lip and the dust lip on double lip seals with grease.
5. Insert the seal in its seat and press down using a flat punch or seal installation tool. Do not tap the seal with a hammer or mallet.
6. While you insert the seal, check that the seal is perpendicular to the seat. When the seal settles, make sure that the seal makes contact with the thrust element, if required.
7. To prevent damage to the seal lip on the shaft, position a protective guard during installation operations.

O-ring seals

Lubricate the O-ring seals before you insert them in the seats. This will prevent the O-ring seals from overturning and twisting, which would jeopardize sealing efficiency.

Sealing compounds

Apply a sealing compound on the mating surfaces when specified by the procedure. Before you apply the sealing compound, prepare the surfaces as directed by the product container.

Spare parts

Only use CNH Original Parts or CNH Original Parts.

Only genuine spare parts guarantee the same quality, duration, and safety as original parts, as they are the same parts that are assembled during standard production. Only CNH Original Parts or CNH Original Parts can offer this guarantee.

When ordering spare parts, always provide the following information:

- Machine model (commercial name) and Product Identification Number (PIN)
- Part number of the ordered part, which can be found in the parts catalog

Protecting the electronic and/or electrical systems during charging and welding

To avoid damage to the electronic and/or electrical systems, always observe the following practices:

1. Never make or break any of the charging circuit connections when the engine is running, including the battery connections.
2. Never short any of the charging components to ground.
3. Always disconnect the ground cable from the battery before arc welding on the machine or on any machine attachment.
 - Position the welder ground clamp as close to the welding area as possible.
 - If you weld in close proximity to a computer module, then you should remove the module from the machine.
 - Never allow welding cables to lie on, near, or across any electrical wiring or electronic component while you weld.
4. Always disconnect the negative cable from the battery when charging the battery in the machine with a battery charger.

NOTICE: *If you must weld on the unit, you must disconnect the battery ground cable from the machine battery. The electronic monitoring system and charging system will be damaged if this is not done.*

5. Remove the battery ground cable. Reconnect the cable when you complete welding.

WARNING

Battery acid causes burns. Batteries contain sulfuric acid.

Avoid contact with skin, eyes or clothing. Antidote (external): Flush with water. Antidote (eyes): flush with water for 15 minutes and seek medical attention immediately. Antidote (internal): Drink large quantities of water or milk. Do not induce vomiting. Seek medical attention immediately.

Failure to comply could result in death or serious injury.

W0111A

Special tools

The special tools that CNH suggests and illustrate in this manual have been specifically researched and designed for use with CNH machines. The special tools are essential for reliable repair operations. The special tools are accurately built and rigorously tested to offer efficient and long-lasting operation.

By using these tools, repair personnel will benefit from:

- Operating in optimal technical conditions
- Obtaining the best results
- Saving time and effort
- Working in safe conditions



SERVICE MANUAL

Engine

F3GFE613A*B001
F3GFE613B*B001

Contents

Engine - 10

[10.001] Engine and crankcase	10.1
[10.101] Cylinder heads	10.2
[10.102] Pan and covers	10.3
[10.103] Crankshaft and flywheel.....	10.4
[10.105] Connecting rods and pistons.....	10.5
[10.106] Valve drive and gears	10.6
[10.110] Balancer and damper	10.7
[10.114] Pump drives	10.8
[10.206] Fuel filters	10.9
[10.218] Fuel injection system.....	10.10
[10.250] Turbocharger and lines.....	10.11
[10.254] Intake and exhaust manifolds and muffler	10.12
[10.304] Engine lubrication system.....	10.13
[10.400] Engine cooling system	10.14
[10.408] Oil cooler and lines.....	10.15
[10.414] Fan and drive	10.16
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.17



Engine - 10

Engine and crankcase - 001

F3GFE613A*B001
F3GFE613B*B001

Contents

Engine - 10

Engine and crankcase - 001

TECHNICAL DATA

Engine	
Technical Data	3

FUNCTIONAL DATA

Engine	
Overview	7

SERVICE

Engine	
Service instruction - Finding Top Dead Center (TDC)	9
Crankcase	
Liner - Remove	10
Liner - Install	11
Liner - Measure – Protrusion	12
Under block - Remove	13
Under block - Install	14

Engine - Technical Data

Engine	Power	RPM @ speed	Torque	RPM @ speed1
F3GFE613A*B001	365 kW (496 Hp)	2100 RPM	2000 N·m (1475 lb ft)	1500 RPM
F3GFE613B*B001	345 kW (469 Hp)	2100 RPM	2082 N·m (1536 lb ft)	1500 RPM

Engine specifications	
Compression ratio	16.5 : 1
Bore	128 mm (5 in)
Stroke	144 mm (6 in)
Displacement	11120 cm³
Turbocharging	Inter-cooled, Direct injection
Turbocharger type	Honeywell
Lubrication	Forced by gear pump, relief valve single action
Oil pressure (Warm engine)	
- Idling	3 bar (43.5 psi)
- Peak RPM	4.5 bar (65.3 psi)
Cooling	Liquid cooled
Water pump control	Belt driven
Thermostat (Start of opening)	81 °C (177.8 °F)
Intake valve timing	
- Opens before TDC	17 °
- Closes after BDC	32 °
Exhaust valve timing	
- Opens before BDC	50 °
- Closes after TDC	9 °
Valve lash setting (when engine is cold)	
- Intake	0.35 - 0.45 mm (0.01 - 0.02 in)
- Exhaust	0.55 - 0.65 mm (0.02 - 0.03 in)
Firing order	1 - 4 - 2 - 6 - 3 - 5
Injection pressure	2000 bar (29000 psi)
Injector calibration	
Cylinder block and piston	
Bores for cylinder liners	128.000 - 128.020 mm (5.039 - 5.040 in)
Cylinder liners external diameter:	142.085 - 142.110 mm (5.594 - 5.595 in)
Cylinder liner protrusion	0.080 - 0.140 mm (0.003 - 0.006 in)
Pistons	
- Measuring dimension	23 mm (1 in)
- External diameter	127.930 mm (5.037 in)
- Pin bore	58.070 mm (2.286 in)
OD of piston - ID of cylinder liner	0.050 mm (0.002 in)
Piston protrusion	0.045 - 0.075 mm (0.002 - 0.003 in)
Piston pin diameter	57.994 - 58.000 mm (2.283 - 2.283 in)
Piston pin OD - pin bore	0.070 - 0.086 mm (0.003 - 0.003 in)
Piston ring grooves	
- Top	2.460 mm (0.097 in)
- Middle	2.580 - 2.600 mm (0.102 - 0.102 in)
- Bottom	4.030 - 4.050 mm (0.159 - 0.159 in)
Piston rings	
- Combustion ring	2.296 - 2.340 mm (0.090 - 0.092 in)
- Intermediate ring	2.470 - 2.500 mm (0.097 - 0.098 in)
- Oil control ring	3.970 - 3.990 mm (0.156 - 0.157 in)
Clearance between piston rings and grooves	
- Combustion ring	0.120 - 0.164 mm (0.005 - 0.006 in)
- Intermediate ring	0.080 - 0.130 mm (0.003 - 0.005 in)


- Oil control ring	0.040 - 0.080 mm (0.002 - 0.003 in)
Piston ring end gap in cylinder liners	
- Combustion ring	0.30 - 0.40 mm (0.01 - 0.02 in)
- Intermediate ring	0.65 - 0.80 mm (0.026 - 0.031 in)
- Oil control ring	0.40 - 0.75 mm (0.016 - 0.030 in)
Connecting rod	
Small end bush housing	
- Nominal	62 mm (2 in)
Big end bearing housing	
- Nominal	98.000 - 98.030 mm (3.858 - 3.859 in)
- Class 1	98.000 - 98.010 mm (3.858 - 3.859 in)
- Class 2	98.011 - 98.020 mm (3.859 - 3.859 in)
- Class 3	98.021 - 98.030 mm (3.859 - 3.859 in)
Small end bush diameter	
- Outside	62.360 - 62.976 mm (2.455 - 2.479 in)
- Inside	58.060 - 58.076 mm (2.286 - 2.286 in)
Big end bearing shell thickness	
- Red	2.465 - 2.475 mm (0.097 - 0.097 in)
- Green	2.475 - 2.485 mm (0.097 - 0.098 in)
- Yellow	2.485 - 2.495 mm (0.098 - 0.098 in)
Clearance between piston pin and bush	0.060 - 0.082 mm (0.002 - 0.003 in)
Connecting rod weight	
- Class A	5000 - 5033 g (176 - 178 oz)
- Class B	5034 - 5067 g (178 - 179 oz)
- Class C	5068 - 5100 g (179 - 180 oz)
Maximum connecting rod axis misalignment tolerance	0.08 mm (0.003 in)
Crankshaft	
Main journals	
- Class 1	99.970 - 99.977 mm (3.936 - 3.936 in)
- Class 2	99.978 - 99.985 mm (3.936 - 3.936 in)
- Class 3	99.986 - 99.993 mm (3.936 - 3.937 in)
- Class 4	99.994 - 100.000 mm (3.937 - 3.937 in)
Crankpins	
- Class 1	92.970 - 92.979 mm (3.660 - 3.661 in)
- Class 2	92.980 - 92.989 mm (3.661 - 3.661 in)
- Class 3	92.990 - 93.000 mm (3.661 - 3.661 in)
Main bearing shells	
- Red	3.115 - 3.122 mm (0.123 - 0.123 in)
- Green	3.123 - 3.130 mm (0.123 - 0.123 in)
- Yellow	3.131 - 3.138 mm (0.123 - 0.124 in)
Main bearing housings	
- Rated value	106.300 - 106.330 mm (4.185 - 4.186 in)
- Class 1	106.300 - 106.307 mm (4.185 - 4.185 in)
- Class 2	106.308 - 106.315 mm (4.185 - 4.186 in)
- Class 3	106.316 - 106.323 mm (4.186 - 4.186 in)
Clearance between bearing shells and main journals	0.020 - 0.140 mm (0.001 - 0.006 in)
Clearance between bearing shells and big ends	0.060 - 0.100 mm (0.002 - 0.004 in)
Main journal, thrust bearing	45.95 - 46.00 mm (1.81 - 1.81 in)
Main bearing housing, thrust bearing	38.94 - 38.99 mm (1.53 - 1.54 in)
Thrust bearing thickness	3.350 - 3.400 mm (0.132 - 0.134 in)
Crankshaft end play	0.10 - 0.30 mm (0.0039 - 0.0118 in)
Main journals and crankpins	
- Alignment	Less than or equal to 0.025 mm (0.0010 in)
- Ovalization	0.012 mm (0.00047 in)

- Taper	0.011 mm (0.00043 in)
Cylinder head and valve train	
Valve guide housing in cylinder head	12.980 - 12.997 mm (0.511 - 0.512 in)
Valve guide	
- Inside diameter	9.015 - 9.030 mm (0.355 - 0.356 in)
- Outside diameter	15.012 - 15.025 mm (0.591 - 0.592 in)
Valve guides - housings in the cylinder head	0.015 - 0.045 mm (0.0006 - 0.0018 in)
Intake valves	
- Valve stem diameter	8.960 - 8.975 mm (0.392 - 0.393 in)
- Valve face angle	60 °
Exhaust valves	
- Valve stem diameter	8.960 - 8.975 mm (0.392 - 0.393 in)
- Valve face angle	45 °
Clearance between valve guide and valve stem	0.040 - 0.070 mm (0.0016 - 0.0028 in)
Valve seat in cylinder head.	
Intake	44.185 - 44.220 mm (1.740 - 1.741 in)
Exhaust	42.985 - 43.020 mm (1.692 - 1.694 in)
Outside diameter of valve seat	
- Intake	44.260 - 44.275 mm (1.743 - 1.743 in)
- Exhaust	43.060 - 43.075 mm (1.695 - 1.696 in)
Valve seat angle	
- Intake	60 °
- Exhaust	45 °
Recessing of the valves	
- Intake	0.59 - 0.91 mm (0.02 - 0.04 in)
- Exhaust	1.79 - 2.11 mm (0.07 - 0.08 in)
Clearance between valve seat and cylinder head	
- Intake	0.040 - 0.090 mm (0.0016 - 0.0035 in)
- Exhaust	0.040 - 0.090 mm (0.0016 - 0.0035 in)
Valve spring height	
No load	80.00 mm (3.15 in)
547 - 603 N (123.0 - 135.6 lb) load	62 mm (2 in)
1041 - 1149 N (234.0 - 258.3 lb) load	48 mm (2 in)
Injector protrusion	0.53 - 1.34 mm (0.021 - 0.053 in)
Camshaft bushing housing in the cylinder head	88.000 - 88.030 mm (3.465 - 3.466 in)
Camshaft bearing journals	82.950 - 82.968 mm (3.2657 - 3.2665 in)
O.D. of the camshaft bushings	88.153 - 88.183 mm (3.4706 - 3.4718 in)
I.D. of the camshaft bushings	83.018 - 83.085 mm (3.2684 - 3.2711 in)
Clearance between bushings and housings in the cylinder head	0.103 - 0.163 mm (0.004 - 0.006 in)
Clearance between bushings and bearing journals	0.050 - 0.135 mm (0.0020 - 0.0053 in)
Cam lift	
- Intake lobe	9.30 mm (0.366 in)
- Exhaust lobe	9.30 mm (0.366 in)
Diameter of the rocker shaft	41.984 - 42.000 mm (1.6529 - 1.6535 in)
Rocker arm internal diameter	
- Intake	42.045 - 42.061 mm (1.655 - 1.656 in)
- Exhaust	59.000 - 59.019 mm (2.3228 - 2.3236 in)
Bushing outside diameter for rocker arms	
- Intake	Not applicable
- Exhaust	59.070 - 59.110 mm (2.326 - 2.327 in)
Bushing inside diameter for rocker arms	
- Intake	Not applicable
- Exhaust	59.000 - 56.049 mm (2.323 - 2.2067 in)
Clearance between bushings and housings	
- Intake	Not applicable

Engine - Engine and crankcase


- Exhaust	0.051 - 0.110 mm (0.002 - 0.004 in)
Clearance between rocker arm and shaft	
- Intake	0.045 - 0.077 mm (0.002 - 0.003 in)
- Exhaust	Not applicable

Engine - Overview




NHIL14ENG0794FA 1

Left-hand view




NHIL14ENG0993FA 2

Front view



NHIL14ENG0994FA 3

Right-hand view



NHIL14ENG0995FA 4


Rear view

Engine - Service instruction - Finding Top Dead Center (TDC)

1. Use the tool **380000137** to rotate the engine flywheel in the direction of normal rotation until you see the hole with three reference marks **(E)** through the inspection window at the bottom of the housing.


NOTE: **(E)** marks **30 °** before Top Dead Center (TDC).

2. Continue to turn the flywheel until the following hole with one reference mark **(B)** can be seen. This marks TDC of the number one cylinder.



NHIL14ENG1086FA 1

3. The exact position of piston number one at TDC is obtained when the tool **380000150 (1)** can be inserted through the hole **(4)** of the flywheel speed sensor and engage the hole **(3)** in the engine flywheel **(2)**.
4. Remove the tool **380000150 (1)**.




NHIL13ENG1231AA 2

Crankcase Liner - Remove

Prior operation:

Connecting rod and piston - Remove (10.105)

1. Use tool **380000366** (2) in conjunction with tool **380000116** (3) as shown in the figure.
2. Check to make sure the plate (3) rests on the cylinder liner correctly.
3. Tighten the nut of the screw (1) to extract the cylinder liner (4) from the crankcase.



NHIL13ENG1191AA 1

Next operation:

Crankcase Liner - Measure (10.001)

Crankcase Liner - Install


Prior operation:

Crankcase Liner - Remove (10.001)

1. Whenever the liners are removed, the water seals (3), (4) and (5) must be replaced before installing liners into the cylinder block.
2. Install the adjusting ring (2) on the cylinder liner (1).
3. Lubricate the seals.
4. Use the appropriate tool to install the liner into the cylinder block.


NOTE: The adjustment ring (2) is supplied as a spare part with the following thicknesses:

- 0.08 mm (0.0031 in)
- 0.10 mm (0.0039 in)
- 0.12 mm (0.0047 in)
- 0.14 mm (0.0055 in).



NHIL13ENG1252BA 1

5. After you complete the installation of all the cylinder liners, lock the cylinder liners (1) to the engine block (3) with the pins 380000363 (2).



NHIL13ENG1187AA 2

Next operation:


Crankcase Liner - Measure (10.001)

Crankcase Liner - Measure – Protrusion

Prior operation:

Crankcase Liner - Install (10.001)

1. Place the compression plate **380000115 (5)** on top of the cylinder liner.
2. Install the tool **380000140 (7)** with the spacers **380000142 (6)** and existing head bolts (1).
3. Tighten the screw (2) to a torque of **225 Nm (166 lb ft)**.
4. Use the dial gauge **380001004 (3)** and the dial gauge base **380000364 (4)** to check the protrusion of the cylinder liner over the block deck is **0.08 - 0.1400 mm (0.0031 - 0.0055 in)**.
5. If the protrusion is not within spec, remove the liner. Refer to **Crankcase Liner - Remove (10.001)** for specific instructions.
6. Replace the adjusting ring. Refer to **Crankcase Liner - Install (10.001)** Figure 1, callout (2). Choose the appropriate thickness to achieve the desired specification.



NHIL13ENG1217AA 1

Next operation:


Connecting rod and piston - Install (10.105)

Crankcase Under block - Remove

Prior operation:

Engine oil pan - Remove (10.102)

1. Remove the torx bolts (1).
2. Remove the M20 x 190 hex bolts (2).
3. Remove the M10 x 30 hex bolts (3).
4. Remove the under block (4) from the cylinder block.



NHIL14ENG0790AA 1

Next operation:

Crankcase Under block - Install (10.001)