

1188 Hydraulic Wheeled and Crawler Excavators

Product: 2001 Case 1188 Crawler Excavator Service Manual 7-79944

Full Download: <https://www.arepairmanual.com/downloads/2001-case-1188-crawler-excavator-service-manual-7-79944/>

[excavator service manual-7-79944/](https://www.arepairmanual.com/downloads/2001-case-1188-crawler-excavator-service-manual-7-79944/)

Table of Contents

DIVISION/SECTION	SECTION N°	REFERENCE N°
1 GENERAL INFORMATION		
Safety, general Information and torque specifications	1001	7-56942GB
Specifications (Crawler excavators).....	1002	7-79021GB
Specifications (Wheeled excavators).....	1002	7-79031GB
2 ENGINE		
Engine removal and installation	2002	7-79040GB
Engine specifications	2401	**
Cylinder head and valve assembly	2415	**
Engine block	2425	**
Lubrication system	2445	**
Cooling system	2455	**
Turbocharger.....	2465	**
Turbocharger failure analysis.....	2565	**
3 FUEL SYSTEM		
Fuel system and filter.....	3410	**
CAV injection pump.....	3411	**
BOSCH injection pump	3412	**
Fuel injector	3413	**
BOSCH ANEROID fuel injection pump.....	3416	**
4 ELECTRICAL SYSTEM		
Electrical schematic (Crawler excavators) - (before November 1999).....	4001	*
Electrical schematics (Wheeled excavators)	4001	*
Electrical schematic (Crawler excavators) - (November 1999 and after).....	4001	*
Electrical schematics (Wheeled excavators)	4001	*
Electronic system and troubleshooting (Crawler excavators).....	4002	*
Electronic system and troubleshooting (Wheeled excavators)	4002	*
Starter motor	4003	7-58691GB
Alternator	4004	7-58701GB
Powersensor diagnostic tool	4010	7-79991GB
Anti - start device tool	4020	7-29370GB
5 UNDERCARRIAGE		
Track group (Crawler excavators).....	5002	7-79070GB
6 DRIVE TRAIN		
Travel reduction gear and brake (Crawler excavators).....	6002	7-79080GB
Swing reduction gear and brake	6003	7-79091GB
Front axle and service brake (Wheeled excavators).....	6004	7-79100GB
Rear axle and service brake (Wheeled excavators)	6005	7-79110GB
Gearbox and parking brake (Wheeled excavators)	6008	7-80701GB
Twin wheels (Wheeled excavators)	6020	7-26170GB
7 UNDERCARRIAGE HYDRAULICS		
Hydraulic travel motor (Mono-speed crawler excavators).....	7002	7-80711GB
Hydraulic travel motor (Two-speed crawler excavators)	7003	7-80721GB
Hydraulic travel motor (Wheeled excavators)	7003	7-80731GB
Travel control valve (Crawler excavators).....	7030	7-80741GB
Travel, stabilizer and dozer blade control valve (wheeled excavators)	7031	7-79170GB
Steering, stabilizer, dozer blade and front axle locking cylinders (wheeled excavators)	7080	7-79180GB

* Consult the Schematic Set

** Consult the engine Service Manual.

Sample of manual. Download All 648 pages at:

<https://www.arepairmanual.com/downloads/2001-case-1188-crawler-excavator-service-manual-7-79944/>

Copyright © 2001 Case France

Printed in France

April 2001

Case

Cre 7-79014GB

DIVISION/SECTION	SECTION N°	REFERENCE N°
8 UPPERSTRUCTURE HYDRAULICS		
Hydraulic inspection, adjustment and schematics (Wheeled excavators).....	8001	*
Hydraulic inspection, adjustment and schematics (Crawler excavators)	8001	*
Hydraulic swivel (Crawler excavators)	8011	7-80791GB
Hydraulic swivel (Wheeled excavators)	8011	7-80801GB
High Pressure Hydraulic pumps	8020	7-58862GB
Swing Hydraulic pumps	8021	7-79220GB
Attachment control valve.....	8031	7-79230GB
Swing control valve	8033	7-79240GB
Rotary control valve (Orbitrol) (Wheeled excavators).....	8037	7-80841GB
Hydraulic swing motor and forced-feed safety block	8040	7-80851GB
Attachment and swing control block (Control lever).....	8050	7-80261GB
Travel and option control block (Foot pedal).....	8051	7-80270GB
Travel hand control block (Inching, wheeled excavators)	8052	7-80870GB
Direction of travel inverter control block (Inching, crawler excavators).....	8053	7-80290GB
Travel control block (wheeled excavators).....	8054	7-80301GB
Brake module	8060	7-80882GB
Parking brake electro-control valve.....	8061	7-80952GB
Electro-control valve block (Crawler excavators).....	8070	7-79331GB
Electro-control valve block (wheeled excavators).....	8071	7-79341GB
Attachment cylinders.....	8080	7-79351GB
9 UPPERSTRUCTURE		
Upperstructure and turntable bearing	9002	7-79361GB
Cab	9004	7-58191GB

* Consult the Schematic Set

NOTE: CASE Company reserves the right to make changes in the specification and design of the machine without prior notice and without incurring any obligation to modify units previously sold.

The description of the models shown in this manual has been made in accordance with the technical specifications known as of the date of design of this document.

Section 1001

**SAFETY, GENERAL INFORMATION
AND TORQUE SPECIFICATIONS**

TABLE OF CONTENTS

SAFETY.....	3
TWIN WHEELS	5
Safety rules	5
Safety instructions.....	5
GENERAL INFORMATION	6
CORRECT USE OF TORQUE WRENCHES	7
HARDWARE TIGHTENING ORDER	8
STANDARD SCREW A TORQUE SPECIFICATIONS.....	9
Correct screw identification	9
METAL CAP REFERENCES.....	10
PLASTIC PLUG AND CAP REFERENCE CHART	11

SAFETY



WARNING: This symbol means **WARNING ! BE VIGILANT ! YOUR SAFETY IS AT RISK**. The message that follows the symbol contains important safety information. Read it carefully. Be sure you understand the possible risks of injury or even death.

To avoid all risks, always follow the safety notes contained in this section and throughout this manual.

Put the warning tag shown below on the key for the keyswitch when servicing or repairing the machine. One warning tag is supplied with each machine. Additional tags, Part Number 321-4614, are available from your service parts supplier.



PDG0328



WARNING: Read the Operator's Manual carefully and make sure you understand how to operate the controls correctly.



WARNING: Never operate the machine and attachment controls unless you are seated in the operator's seat. If you are not in the operator's seat, you run the risk of serious injury.



WARNING: The machine is built to carry the operator only. Do not allow passengers to ride on the machine.



WARNING : Prior to starting up the engine read the safety messages contained in the operator's manual carefully. Read all safety stickers on the machine. Have people move back from the machine. Learn how to use the controls before starting up the machine. It is your responsibility to follow the manufacturer's instructions on how to operate and maintain the machine. It is your responsibility to follow applicable rules and regulations. Service and Operator's Manuals are available from your J.I. Case Dealer.



WARNING: If you wear loose clothing or if you omit to use safety equipment for your work, you risk injury. Always wear clothes that do not risk getting caught in the machine. Other safety equipment may be necessary, in particular : helmets, safety shoes, ear plugs, safety glasses, protection mask, thick gloves and reflecting clothes.



WARNING: When working close to the fan with the engine running, avoid wearing loose clothing and operate with extreme caution.



WARNING: When checking the hydraulic circuits, follow procedures to the letter. **DO NOT CHANGE** procedures.



WARNING: Prior to operating the hydraulic cylinders of this machine for setting or to bleed the circuit, have all people standing around the machine move away.



WARNING: Wear gloves or insulated mittens when working on hot parts.



WARNING: Lower all attachments to the ground or rest them on stands before carrying out maintenance jobs.



WARNING: Fine sprays of hydraulic oil under pressure can penetrate the skin and cause serious infection. If hydraulic oil under pressure penetrates the skin, see a doctor immediately. Maintain all hoses and pipes in good condition. Make sure that all connections are properly tightened. Change all hoses or pipes that have been damaged or that are suspect. **DO NOT CHECK** for leaks with bare hands. Use a piece of cardboard or wood.



WARNING: To remove a hardened pin such as a pivot pin, or a hardened shaft, use a soft head hammer (brass or bronze) or a brass or bronze strip and a steel head hammer.



WARNING: When using a hammer to remove or reassemble pivot pins, or when using compressed air, or when using a grinder make sure to wear safety glasses that protect the eyes from all sides.



WARNING: Use proper lifting/hoisting equipment to lift wheels or tracks and always work on safe ground. Prevent the machine from moving using correct safety chocks.



WARNING: When performing maintenance or repair operations on the machine, make sure that the work shop floor, the cab and the steps of the excavator are free from oil, water, grease, tools etc. Use oil absorbing material or rags as necessary. Always think safety.



WARNING: Certain components of this machine are very heavy. Use hoisting tools or additional assistance as recommended in this manual.



WARNING: Exhaust fumes can cause death. If it is necessary to start up the engine in a closed building, evacuate exhaust fumes using an exhaust pipe extension. Open the doors and let fresh air into the building.



WARNING: When battery liquid is frozen, the battery can explode if : (1) you try to charge the battery or (2) you try to start the engine by connecting an auxiliary power source. To prevent battery electrolyte from freezing keep the battery fully charged. If you do not follow these instructions, you or others nearby may be injured.



WARNING: Batteries contain acid and explosive gases. A spark, a flame or an improper cable connection may cause an explosion. For proper connection of cables to the battery of this machine see the Operator's Manual. If you do not follow these instructions, you risk severe injury.

TWIN WHEELS

Safety rules



WARNING: *In all cases, before removing twin wheels, always deflate both tyres completely.*



WARNING: *If a tyre bursts it can cause serious injury. Check tyres regularly to see that they are in good condition and always be sure to inflate them to the correct pressure.*



WARNING: *Never face a tyre when checking pressure or adding air. Always stand in front of the tread. Use an inflation cage if the wheel has been removed from the machine. Make sure all people standing in the area move well away.*



WARNING: *Never weld near a tyre. If this can not be avoided, it is mandatory to remove the tyre before performing any welding operations.*



WARNING: *Make sure that all decals on the machine are perfectly legible, clean them regularly and replace any decals which are damaged, missing or painted over, with new ones.*

Safety instructions

- Use appropriate, good quality tools to disassemble the various wheel components. Never use a hammer. Use a rubber, plastic or copper-faced mallet.

IMPORTANT: *Never remove the inner tyre valve extension, as this will be necessary afterwards for inflating and deflating the tyre.*

IMPORTANT: *If the valve or the valve extension are no longer accessible, take the necessary precautions and then, imperatively, puncture the tyre.*

- Use suitable grease to facilitate the installation and removal of the tyre.
- Never re-inflate a tyre on the machine which has been used at a pressure lower than 5.6 bar.
- Check the various components: tyre, rim, shoulder, retaining ring and replace any defective items.
- Never reuse a retaining ring which is distorted or rusty.

GENERAL INFORMATION

CLEANING

Clean all metal parts except bearings with white spirit or steam. Do not use caustic soda when steam cleaning. After cleaning, dry and lubricate all parts. Clean hydraulic lines with compressed air. Clean bearings with kerosene, then dry them and lubricate them.

INSPECTION

Check all parts when disassembled. Change all parts showing wear or damage. Scratches that are not too deep can be removed by honing or with a rag dipped into buffing compound. A full visual inspection to detect wear and pitting and subsequent changing of parts will prevent premature failure.

BEARINGS

Check that bearings rotate freely. If their adjustment is too loose or if they do not run regularly, change them. Wash bearings with a good solvent or kerosene and let them dry. **DO NOT DRY BEARINGS WITH COMPRESSED AIR.**

NEEDLE BEARINGS

Before inserting needle bearings into a bore, remove all metal particles from the edge of the bore. Prior to mounting bearings with a press, coat the inside and the outside of the bearing with vaseline.

GEARS

Check all the gears for wear or damage. Change worn or damaged gears.

SEAL RINGS, O-RINGS, GASKETS

Always use new seal rings. O-rings and gaskets. Coat sealing rings and O-rings with vaseline.

SHAFTS

Check all shafts showing signs of wear or damage. Check that the surface of a shaft running in a bearing is not damaged.



SPARE PARTS

Always use original CASE spare parts. To order spare parts, see the Spare Parts Catalogue to indicate the proper reference of original CASE spare parts. Failures caused by the use of parts that are not original CASE spare parts are not covered by the warranty.




LUBRICATION

Use only oils and lubricants specified in the Operator's and Service Manuals. Failures due to the use of oils and lubricants not specified are not covered by the warranty.

CORRECT USE OF TORQUE WRENCHES


<p>TORQUE WRENCHES</p>	 <p style="text-align: right;">PDG0315</p>
<p>CORRECT USE</p> <p>a - Hold the wrench by the handle provided.</p> <p>b - When tightening, always keep the wrench perpendicular to the screw.</p> <p>c - Keep one hand on the leverage point handle on the wrench.</p> <p>d - Tighten progressively in one movement.</p> <p>e - Position a correctly dimensioned socket or open-ended wrench on the flats of the screw head.</p>	 <p style="text-align: right;">PDG0316</p>

HARDWARE TIGHTENING ORDER




<p>TORQUE WRENCHES</p>	 <p style="text-align: right;">PDG0317</p>
<p>INITIAL TORQUE</p> <p>a - Torque wrench.</p> <p>- Follow the correct order of procedure when tightening.</p> <p>- Cross or diagonal pattern tightening.</p>	 <p style="text-align: right;">PDG0318</p>
<p>FINAL TORQUE</p> <p>Always tighten in clockwise order.</p>	 <p style="text-align: right;">PDG0319</p>

STANDARD SCREW A TORQUE SPECIFICATIONS

Correct screw identification



PDG0320

	Diameter x thread size Grade 8.8	Key  		Torque			
				Nm		lb.ft	
							
Two-part hydraulic connector (to SAE J518 specifications) 	M5 x 0.8	4	8	5.5	5.5	4.1	4.1
	M6 x 1	5	10	9	9	6.7	6.7
	M8 x 1.5	6	13	22.5	22.5	16.6	16.6
	M10 x 1.5	8	17	45	45	33.2	33.2
	M12 x 1.75	10	19	70	80	51.6	59
	M14 x 2	12	22	100	120	73.8	88.6
	M16 x 2	14	24	170	200	125.5	147.6
	M18 x 2.5	14	27	250	300	184.5	221.4
	M20 x 2.5	17	30	350	400	258.3	295.2
	M22 x 2.5	17	32	500	600	369	442.8
	M24 x 3	-	36	600	700	442.8	516.6
	M27 x 3	-	41	900	1000	664.2	738
M30 x 3.5	-	46	1200	1400	885.6	1033.2	
Components assembled by screws and bolts SCREW   BOLT	Grade 10.9						
	M5 x 0.8	4	8	75	75	5.6	5.6
	M6 x 1	5	10	12.5	12.5	9.3	9.3
	M8 x 1.5	6	13	35	35	25.8	25.8
	M10 x 1.5	8	17	60	70	44.3	51.6
	M12 x 1.75	10	19	100	120	73.8	88.6
	M14 x 2	12	22	170	200	125.5	147.6
	M16 x 2	14	24	250	300	184.5	221.4
	M18 x 2.5	14	27	350	400	258.3	295.2
	M20 x 2.5	17	30	500	600	369	442.8
	M22 x 2.5	17	32	700	800	516.6	442.8
	M24 x 3	-	36	900	1000	664.2	738
M27 x 3	-	41	1200	1400	885.6	1033.6	
M30 x 3.5	-	46	1700	1900	1254.6	1402.2	

PDG0321

PDG0322

-  Zinc bichromate
-  Phosphate





METAL CAP REFERENCES

To SAE J518 specifications

	NP 250 bar Ø ND	NP 400 bar Ø ND	Part number	
			A	B
<p style="text-align: center;">PDG0323</p>	13 mm	-	D5327838	E5327839
	19 mm	-	F5327840	G5327841
	25 mm	-	H5327842	J5327843
	32 mm	-	K5327844	L5327845
	38 mm	-	M5327846	N5327847
	-	13 mm	U5327830	V5327831
	-	19 mm	W5327832	X5327833
	-	25 mm	Z5327834	A5327835
	-	32 mm	B5327836	C5327837

NP = Nominal pressure
 NP = Nominal diameter

PLASTIC PLUG AND CAP REFERENCE CHART

	Dia. x pas	Part number	Dia. x pas	Part number
Tapped orifices and connectors with tightening nuts = screw-type plugs  PDG0324	M10 x 1.5 M12 x 1.5 M14 x 1.5 M16 x 1.5 M18 x 1.5	F3237416 G3237417 H3237418 J3237419 K3237420	M20 x 1.5 M22 x 1.5 M24 x 1.5 M27 x 2	L3237421 M3237422 N3237423 Q3237448
Unions = Screw-type plugs  PDG0325	M12 x 1.5 M14 x 1.5 M16 x 1.5 M18 x 1.5	X3237409 Z3237410 A3237411 B3237412	M20 x 1.5 M22 x 1.5 M30 x 1.5	C3237413 D3237414 E3237415
S.A.E tube or hose collars = external plugs  PDG0326	NP 250 bar 30.2 38.1 44.5 50.8 60.4	J2537460 K2537461 L2537462 M2537463 N2537464	NP 400 bar 31.8 41.3 47.6 54 63.6	P2537465 Q2537466 R2537467 S2537468 T2537469
S.A.E orifices = caps for installation into tapped fitting orifices  PDG0327	NP 250 bar L = 38.1 47.65 52.35 58.07 69.85	A2340480 B2340481 C2340482 D2340483 E2340484	NP 400 bar L = 40.5 50.8 57.15 66.7 79.4	K1640415 R1640421 S1640422 T1640423 Z1640479

NP = Nominal pressure
 ND = Nominal diameter

Section 1002


1002

SPECIFICATIONS 1188 *Plus* Crawler Excavators

TABLE OF CONTENTS

MACHINE OVERALL DIMENSIONS.....	3
TRANSPORTATION OVERALL DIMENSIONS	4
GENERAL MACHINE SPECIFICATIONS.....	5
Engine	5
Hydraulic system	5
Electrical system	6
Upperstructure	6
Cab.....	6
Operation	7
Undercarriage	7
Safety devices.....	7
Indicators.....	7
Warning and indicator lamps.....	7
Attachments	7
Noise level.....	8
Ground pressure	8
Travel	8
WEIGHTS.....	9
Machine.....	9
Attachments	11
Counterweight.....	11
Cab.....	11
Tools	12
Earthmoving buckets	12
Trench buckets with ejector	12
Ditch cleaning buckets equipped with teeth.....	12
Ditch cleaning buckets equipped with reversible blade (notched or smooth)	12
Buckets equipped with smooth blade	12
V-shaped bucket	12
Trench clamshell with ejector.....	12
Earthmoving clamshells	12
Rehandling clamshells	13
Boring clamshell.....	13
Sugar beet clamshell	13
5-tine stone grab with removable tine tips	13
Scrap metal 5 tine grab.....	13
FLUIDS AND LUBRICANTS	14
SUMMARY OF DETAILED SPECIFICATIONS PER COMPONENT	17
DETAILED SPECIFICATIONS PER COMPONENT	18


MACHINE OVERALL DIMENSIONS



	LC Type	CK Type
A (0.50 m track pads)	2.87 m	2.47 m
A (0.60 m track pads)	2.97 m	2.57 m
A (0.75 m track pads)	3.12 m	2.72 m
A (0.90 m track pads)	3.27 m	
B	2.37 m	1.97 m
C	0.50 m	0.50 m
D	3.11 m	3.11 m
E	2.44 m	2.44 m
F (radius)	2.67 m	2.67 m
G	1.15 m	1.15 m
H	2.50 m	2.50 m
J	3.59 m	3.25 m
K	4.41 m	4.07 m
L	4.48 m	4.72 m
M	3.00 m	2.61 m

PDH0253M

TRANSPORTATION OVERALL DIMENSIONS



PDH0256

NOTE: Cab height above ground: see section "Machine overall dimensions".

Boom	Dipper	A	B
One-piece 4.80 m	1.70 m	3.35	9.45
	2.20 m	3.20	9.10
	2.50 m *	3.25	8.80
	2.80 m	3.45	8.85
	3.40 m	3.95	8.60
One-piece 5.40 m	1.70 m	3.30	10.05
	2.20 m	3.05	9.05
	2.50 m *	3.10	9.50
	2.80 m	3.40	9.45
	3.40 m	3.75	9.40
Articulated	1.70 m	3.75	8.25
	2.20 m	3.75	7.30
	2.50 m *	3.75	8.55
	2.80 m	3.75	8.95
	3.40 m	3.75	9.70
Adjustable	1.70 m	3.60	7.55
	2.20 m	3.55	7.30
	2.50 m *	3.70	7.10
	2.80 m	4.10	6.80
	3.40 m	4.85	6.45
Handling	Handling	3.20	9.20

NOTE: These values are given in metres.

* Special for Germany

GENERAL MACHINE SPECIFICATIONS

Engine

Make and type	CASE 6TA 590
Total SAE horsepower at 2800 rpm	126.4 kW (172 hp)
4 stroke, 6 cylinder	turbo-charged diesel
Capacity	5880 cm ³
Bore	102 mm
Stroke	120 mm
Cooling	water-cooled
Starting:	2 x 12 volt batteries, 24 V, 120 A/h

Working specifications

Engine speed	2000 rpm
Power: SAE J1995	119 kW (160 hp)
DIN 70020 - DIN 6271	113 kW (152 hp)
EEC 80/1269 - ISO 9249	113 kW (152 hp)

Specifications maintained up to an altitude of 3000 m at a temperature of 25°C.

Capacities: Engine oil sump	14.3 L
Fuel tank	330 L

Fuel tank filler pump, electrical

Average hourly consumption

Engine and pump assembly mounted on rubber blocks.

Heavy-duty dust filtration.

Hydraulic system

Variable output system with independent and simultaneous operation of all functions.

Electronic regulation of hydraulic power ("Powersensor" system) for optimal use of engine power.

3 regulation modes:

"FINE": For work requiring extreme precision.

"ECO" (ECONOMICAL): For normal jobs.

"MAX" (MAXIMUM): In this position, the operator has the entire power of the machine available for use.

Automatic engine return to idle at operator's choice.

Working pressure

Capacity of hydraulic reservoir

Total system capacity

Pumps:

One double-body variable displacement pump for supplying travel motors and attachments.

Flow

One single body variable displacement pump supplying the upperstructure swing.

Flow

Installed hydraulic power

1002-6

Fixed flow pump for the pilot systems.
Parallel, closed centre type attachment and travel control valves.
Flow rates per function, independent of pressures.

Oil cooler with air cooling from engine.
Multispiral high pressure hoses
 minimum safety factor 2 to 4 times the working pressure
Self-lubricating hydraulic swivel.

Electrical system

Circuit voltage circuit 24 volt, negative earth
Batteries two low-maintenance 12 volt batteries
All electrical system safety functions are grouped in an electrical cabinet with a printed circuit.
Instrument panel with printed circuit.
Automatic instrument panel lamp testing.
Two-stage alarm system.
Upperstructure electrical power connection (24 V, 15 Amp.).
Battery master switch.

Upperstructure

All welded frame

Modular structure.
Transverse walkway giving access to the various components.
Sound-proofed, lockable cowling meeting all current regulations.
Tool box with tool set.

Swing

Hydraulic motor with reduction gear and automatic static brake.
Swing speed 8.5 rpm
Turntable alternating rollers and internal teeth
Bearing surface and tooth lubrication centralised

Cab

Removable, sound-proofed, on flexible mounting blocks.
Up and over windshield.
Tinted windshield.
Pre-fitted for radio installation.
Transparent roof hatch optional equipment
Sliding window on door optional equipment
Polycarbonate windows optional equipment
Cab safety guards available on request
Elevated cab available on request
Ant-vandal cab optional equipment

Operation

De-luxe seat with armrests and multi-position adjustment (vibration level III/ISO 7096).

Hydraulically assisted controls.

Attachment and swing 2 control levers

Travel..... 2 pedals

Single-speed windshield wiper, plus intermittent action, windshield washer, heating, de-frosting, two-speed ventilation, cab light, cigarette lighter, sun shield.

Working lights:

On upperstructure2 x 70 W

On attachment 70 W

Front and rear (on cab) optional equipment

Rear (on cab) 70 W

Air conditioning..... optional equipment

Cab sun-shield..... optional equipment

Cab blower optional equipment

Undercarriage

One-piece undercarriage chassis with welded components.

Lifetime lubricated rollers.

Tractor type tracks; grease cylinder type track tension; shock absorber for shock absorption.

Removable sprocket tooth rings.

Front and rear chain guide (central optional).

Safety devices

In the event of engine failure, the attachment can be lowered, under control, to the ground.

Cancellation of controls by lifting the left-hand control arm.

Tinted safety glass, horn.

Cab safety guardsavailable on request

Safety valves optional equipment

Overload indicator optional equipment

Roller type seat belt..... optional equipment

Fire extinguisher optional equipment

Rotary light special for certain countries

Indicators

Engine coolant solution temperature, hydraulic fluid temperature, fuel level and hourmeter.

Warning and indicator lamps

Engine oil pressure, battery charge, hydraulic and engine air filter start of restriction indicator.

Warning/indicator lamp test.

Attachments

Sealed linkages, all linkages greased from ground level or walkway.

Double acting cylinders with end-of-stroke shock absorbers.

Play take-up system on bucket linkage.

Noise level

Certified by the manufacturer.

In accordance with European directive 86/662/EEC.

Inside operator's compartment (LpA)	79 dB(A)
Outside machine (LWA)	105 dB(A)

Ground pressure

With attachment: 5.40 m boom, 2.20 m dipper and 970 L bucket

Machine equipped with 0.50 m track pads

LC Type	0.561 bar
CK Type	0.599 bar

Machine equipped with 0.60 m track pads

LC Type	0.474 bar
CK Type	0.505 bar

Machine equipped with 0.75 m track pads

LC Type	0.387 bar
CK Type	0.412 bar

Machine equipped with 0.90 m track pads

LC Type only	0.329 bar
---------------------------	-----------

Travel

Sprockets driven by hydraulic motors (Dual displacement optional).

Independent drive to each track.

Manual controlled travel block providing precise adjustment of travel speed regardless of pressure exerted on travel pedals.

Travel speeds:

(single speed machine), max. speed	from 0 to 3.1 kph
(2-speed machine), max. speed.....	First speed: from 0 to 3.1 kph Second speed: from 0 to 5.5 kph

Braked motors (automatic static brake).

Gradeability:

LC Type	90%
CK Type	80%

Tractive force:

LC Type	17850 daN
CK Type	17950 daN

Hydraulic speed limiter, automatic when descending slopes.

WEIGHTS

Machine (LC Type)

Boom	Dipper	LC Type			
		Track pads 0.50 m	Track pads 0.60 m	Track pads 0.75 m	Track pads 0.90 m
One-piece 4.80 m	1.70 m	21 990	22 295	22 745	23 205
	2.20 m	22 030	22 335	22 785	23 245
	2.50 m *	22 045	22 350	22 800	23 260
	2.80 m	22 120	22 420	22 870	23 335
	3.40 m	22 155	22 460	22 910	23 370
One-piece 5.40 m	1.70 m	22 125	22 430	22 880	23 340
	2.20 m	22 165	22 470	22 920	23 380
	2.50 m *	22 180	22 485	22 935	23 395
	2.80 m	22 255	22 555	23 005	23 470
	3.40 m	22 290	22 595	23 045	23 505
Articulated	1.70 m	23 000	23 305	23 755	24 215
	2.20 m	23 040	23 345	23 795	24 255
	2.50 m *	23 055	23 360	23 810	24 270
	2.80 m	23 125	23 430	23 880	24 340
	3.40 m	23 165	23 465	23 920	24 380
Adjustable	1.70 m	22 670	22 975	23 425	23 885
	2.20 m	22 710	23 015	23 465	23 925
	2.50 m *	22 725	23 030	23 480	23 940
	2.80 m	22 795	23 100	23 550	24 010
	3.40 m	22 835	23 135	23 590	24 050
Handling	Handling (without clamshell)	20 775	21 075	21 530	21 990

NOTE: These values are given in kg, with 970 L backhoe bucket.

* Special for Germany

(CK Type)

Boom	Dipper	CK Type		
		Track pads 0.50 m	Track pads 0.60 m	Track pads 0.75 m
One-piece 4.80 m	1.70 m	21 395	21 675	22 090
	2.20 m	21 435	21 715	22 130
	2.50 m *	21 450	21 730	22 145
	2.80 m	21 520	21 800	22 215
	3.40 m	21 560	21 840	22 250
One-piece 5.40 m	1.70 m	21 530	21 810	22 225
	2.20 m	21 570	21 850	22 265
	2.50 m *	21 585	21 865	22 280
	2.80 m	21 655	21 935	22 350
	3.40 m	21 695	21 975	22 385
Articulated	1.70 m	22 405	22 685	23 095
	2.20 m	22 445	22 725	23 140
	2.50 m *	22 460	22 740	23 155
	2.80 m	22 530	22 810	23 225
	3.40 m	22 570	22 845	23 260
Adjustable	1.70 m	22 075	22 355	22 765
	2.20 m	22 115	22 395	22 810
	2.50 m *	22 130	22 410	22 825
	2.80 m	22 200	22 480	22 895
	3.40 m	22 240	22 515	22 930
Handling	Handling (without clamshell)	20 180	20 455	20 870

NOTE: These values are given in kg, with 970 L backhoe bucket.

* Special for Germany

Attachments

Booms (with dipper cylinder)	
4.80 m	1575 kg
5.40 m	1710 kg
Adjustable boom	2255 kg
Adjustable boom	2520 kg
Dipper (with yoke, connecting link and bucket cylinder)	
1.70 m	980 kg
2.20 m	1020 kg
2.50 m (Special for Germany)	1025 kg
2.80 m	1105 kg
3.40 m	1140 kg
Handling boom 5.90 m (with dipper cylinder)	1530 kg
Handling dipper 4.30 m	580 kg

Counterweight

4500 kg

Cab

291 kg

Tools

NOTE: *The selection of bucket capacity depends on the density of the material (See "Density of various spoils and materials" in the operator's manual) and the attachment configuration in addition to the compactness and structure of the ground).*

Earthmoving buckets

Width	SAE heaped capacity	Weight
0.60 m.....	460 L	585 kg
0.75 m.....	590 L	615 kg
0.85 m.....	680 L	645 kg
0.90 m.....	730 L	690 kg
1.05 m.....	870 L	745 kg
1.15 m.....	970 L	775 kg
1.25 m.....	1060 L	845 kg
1.40 m.....	1200 L	890 kg

All earthmoving buckets are equipped with teeth with removable tooth tips and pins with side play take-up system. Heavy duty supplement optional (add 5% to the capacity shown). Side cutters optional (add 8 cm to the width shown).

Trench buckets with ejector

Width	SAE heaped capacity	Weight
0.45 m.....	310 L	755 kg

Ditch cleaning buckets equipped with teeth

Width	CECE capacity	Weight
2.00 m.....	900 L	780 kg

Ditch cleaning buckets equipped with reversible blade (notched or smooth)

Width	CECE capacity	Weight
2.00 m.....	900 L	825 kg

Buckets equipped with smooth blade

Width	CECE capacity	Weight
2.20 m.....	1000 L	815 kg

V-shaped bucket

Width	CECE capacity	Weight
0.50 - 3.00 m	670 L	615 kg

Trench clamshell with ejector

Width	Opening	Capacity	Weight
0.55 m.....	1.94 m.....	350 L	1180 kg

Earthmoving clamshells

Width	Opening	Capacity	Weight
0.92 m.....	1.72 m.....	500 L	1270 kg
1.02 m.....	1.83 m.....	650 L	1300 kg
1.27 m.....	1.83 m.....	850 L	1395 kg

Rehandling clamshells

Width	Opening	Capacity	Weight
1.03 m.....	2.14 m.....	1000 L	1240 kg

Boring clamshell

Width	Capacity	Weight
1.18 m.....	180 L	1025 kg
1.48 m.....	350 L	1175 kg

Sugar beet clamshell

Width	Opening	Capacity	Weight
1.81 m.....	2.50 m.....	2050 L	1440 kg
2.05 m.....	2.50 m.....	2350 L	1625 kg
2.29 m.....	2.50 m.....	2600 L	1703 kg

5-tine stone grab with removable tine tips

Opening diameter	Weight
2.12 m.....	1815 kg

Scrap metal 5 tine grab

Opening diameter	Weight
2.00 m.....	1300 kg

FLUIDS AND LUBRICANTS

Lubricants must have the correct properties for each application.



WARNING: *The conditions of use for individual fluids and lubricants must be respected.*

Hydraulic fluid

CASE hydraulic fluid is specially designed for high pressure applications and for the CASE hydraulic system. The type of fluid to be used depends on the ambient temperature.

Temperate climates

-20°C to +40°C
Fluid type ISO VG 46
CASE reference: POHYDR

Hot climates

0°C to +60°C
Fluid type ISO VG 100
CASE reference: POHYDC

Cold climates

-40°C to +20°C
Fluid type ISO VG 22
CASE reference: POHYPF

These various grades of fluid must be in conformity with CASE France specification P9903201Z.

Temperate climate biodegradable fluid:

This yellow fluid is compatible with standard fluid. If adopted, it is advisable to drain the circuit completely.
Fluid type ISO VG 46
CASE reference: CASYNTH 46

This grade of fluid must be in conformity with CASE France specification P9903203B

Transmission component oil

Extreme pressure oil used for transmission components inside sealed housings.
Extreme pressure oil type API GL5 grade 80W90 or ISO VG 150

Grease

The type of grease to use depends on ambient temperature.

Temperate and hot climates

-20°C to +60°C
Extreme pressure grease EP NLGI grade 2 with molybdenum disulphide.

Cold climates

-40°C to +20°C
Extreme pressure grease EP NLGI grade 0.

Engine oil

CASE engine oil No. 1 is recommended for your engine. This oil ensures correct lubrication of your engine in all working conditions.

If CASE No. 1 Multiperformance or Performance engine oil is not available, use oil corresponding to category API/CG/CF.

NOTE: Do not put any Performance Additive or other additive in the sump. Oil change intervals shown in this manual are based on tests carried out on CASE lubricants.




RD97F136



RB97F100

Oil viscosity/Oil range



CS98M561

(A) FAHRENHEIT TEMPERATURE

(B) CELSIUS TEMPERATURE

(1) ALL SEASONS

(2) WINTER

(3) TROPICAL

(4) ARCTIC

SHOWS THAT AN ENGINE OIL HEATER OR ENGINE COOLANT SOLUTION HEATER MUST BE USED.

Use fuel which is to ASTM (American Society for Testing and Materials) D975 standard.

Use Grade No. 2 fuel. The use of other types of fuel can result in a loss of power and may cause high fuel consumption.

In cold weather, the use of a mixture of fuels No. 1 and No. 2 is temporarily permitted. Consult your fuel supplier.

If the temperature falls below the fuel cloud point (point at which wax begins to form) the wax crystals will cause power loss or will prevent the engine from starting.

IMPORTANT: *In cold weather, fill the fuel tank at the end of the day's work, in order to prevent the formation of condensation.*

Fuel storage

Long storage can lead to the accumulation of impurities and condensation in the fuel. Engine trouble can often be traced to the presence of water in the fuel.

The storage tank must be placed outside and the temperature of the fuel should be kept as low as possible. Drain off water and impurities regularly.

Antifreeze/anti-corrosion

Use anti-freeze in all seasons to protect the cooling system from corrosion and all risk of freezing.

In environments with a temperature higher than -36°C, use a mixture of 50% ethylene-glycol based anti-freeze.

For areas where the temperature is below -36°C, it is advisable to use a blend of 40% water and 60% anti-freeze.

Environment

Before carrying out any servicing operation on this machine and before disposing of used fluids or lubricants, always think of the environment. Never throw fluid or oil on the ground and never keep them in leaking receptacles.

Consult your local ecological recycling centre to obtain information on the appropriate means of disposing of these substances.

Components made from plastic or resin

When cleaning polycarbonate windows, the console, the instrument panel, the gauges, etc., do not use petrol (gasoline), paraffin (kerosene), paint solvents, etc. Use only water, soap and a soft cloth.

The use of petrol (gasoline), de paraffin (kerosene), paint solvents, etc, will cause discoloration, cracking or deformation of these components.