

Product: 2013 Case Farmall 95U 105U 115U Efficient Power Tractor Service Repair Manual 84568025

Full Download: <https://www.arepairmanual.com/downloads/2013-case-farmall-95u-105u-115u-efficient-power-tractor-service-repair-manual-84568025>

568025/

Farmall 95U Efficient Power

Farmall 105U Efficient Power

Farmall 115U Efficient Power

Tractor

SERVICE MANUAL

Sample of manual. Download All 2155 pages at:
<https://www.arepairmanual.com/downloads/2013-case-farmall-95u-105u-115u-efficient-power-tractor-service-repair-manual-84568025>

Part number 84568025

English
March 2013

Copyright © 2013 CNH Europe Holding S.A. All Rights Reserved.




Product: 2013 Case Farmall 95U 105U 115U Efficient Power Tractor Service/Repair Manual 84568025

Full Download: <https://www.arepairmanual.com/downloads/2013-case-farmall-95u-105u-115u-efficient-power-tractor-service-repair-manual-84568025/>



SERVICE MANUAL



Farmall 105U EP

Farmall 115U EP

Farmall 95U EP

Sample of manual. Download All 2155 pages at:

<https://www.arepairmanual.com/downloads/2013-case-farmall-95u-105u-115u-efficient-power-tractor-service-repair-manual-84568025/>

84568025 22/03/2013

EN

Link Product / Engine

Product	Market Product	Engine
Farmall 105U EP	North America	F5DFL413B*A006
Farmall 105U EP	Europe	F5DFL413B*A006
Farmall 105U EP	International Region	F5DFL413B*A006
Farmall 115U EP	North America	F5DFL413A*A002
Farmall 115U EP	Europe	F5DFL413A*A002
Farmall 115U EP	International Region	F5DFL413A*A002
Farmall 95U EP	Europe	F5DFL413C*A003
Farmall 95U EP	International Region	F5DFL413C*A003

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
[10.414] Fan and drive	10.2
[10.501] Exhaust Gas Recirculation (EGR) - Diesel Particulate Filter (DPF) exhaust treatment	10.3
Clutch	18
[18.112] Slip clutch or flywheel damper	18.1
Transmission.....	21
[21.118] Transmission/Rear drive	21.1
[21.112] Power shuttle transmission.....	21.2
[21.104] Power shuttle transmission lubrication system.....	21.3
[21.134] Power shuttle transmission external controls	21.4
[21.148] Transmission/Rear drive internal components	21.5
[21.154] Power shuttle transmission internal components	21.6
[21.145] Gearbox internal components.....	21.7
[21.160] Creeper	21.8
[21.168] Hi-Lo unit	21.9
Four-Wheel Drive (4WD) system	23
[23.202] Electro-hydraulic control	23.1
[23.304] Four-Wheel Drive (4WD) gearbox	23.2
[23.314] Drive shaft.....	23.3
Front axle system	25
[25.100] Powered front axle	25.1
[25.102] Front bevel gear set and differential	25.2
[25.108] Final drive hub, steering knuckles, and shafts	25.3
Rear axle system.....	27

[27.100] Powered rear axle.....	27.1
[27.106] Rear bevel gear set and differential.....	27.2
[27.120] Planetary and final drives	27.3
Power Take-Off (PTO)	31
[31.104] Rear electro-hydraulic control.....	31.1
[31.116] Three-speed rear Power Take-Off (PTO)	31.2
[31.114] Two-speed rear Power Take-Off (PTO)	31.3
Brakes and controls	33
[33.202] Hydraulic service brakes	33.1
[33.204] Front axle brake.....	33.2
[33.110] Parking brake or parking lock	33.3
[33.220] Trailer brake hydraulic control.....	33.4
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.355] Hydraulic hand control	35.2
[35.204] Remote control valves	35.3
[35.114] Three-point hitch control valve	35.4
Hitches, drawbars, and implement couplings.....	37
[37.110] Rear three-point hitch	37.1
Steering.....	41
[41.200] Hydraulic control components.....	41.1
[41.206] Pump	41.2
[41.216] Cylinders	41.3
Wheels	44
[44.511] Front wheels.....	44.1
Electrical systems	55
[55.000] Electrical system	55.1

[55.100] Harnesses and connectors.....	55.2
[55.201] Engine starting system.....	55.3
[55.301] Alternator.....	55.4
[55.302] Battery.....	55.5
[55.640] Electronic modules.....	55.6
[55.024] Transmission control system.....	55.7
[55.523] Cab hitch controls.....	55.8
[55.130] Rear three-point hitch electronic control system.....	55.9
[55.408] Warning indicators, alarms, and instruments	55.10
[55.DTC] FAULT CODES.....	55.11
Platform, cab, bodywork, and decals	90
[90.150] Cab.....	90.1
[90.100] Engine hood and panels	90.2



INTRODUCTION

Contents

INTRODUCTION

Advice	3
Safety rules SAFETY REGULATIONS	4
Basic instructions	7
Basic instructions for arc-welding on tractors with electronic lift	9
Special tools NOTES FOR EQUIPMENT	10
Consumables	11
Part identification	12

Advice

IMPORTANT NOTICE

All maintenance and repair work described in this manual must be performed exclusively by CASE IH AGRICULTURE service technicians, in strict accordance with the instructions given and using any specific tools necessary. Anyone performing the operations described herein without strictly following the instructions is personally responsible for any eventual injury or damage to property.

Safety rules SAFETY REGULATIONS

TO PREVENT ACCIDENTS

Most accidents or injuries that occur in workshops are the result of non-observance of simple and fundamental safety regulations.

For this reason, IN MOST CASES THESE ACCIDENTS CAN BE AVOIDED: by foreseeing possible causes and consequently acting with the necessary caution and care.

Accidents may occur with all types of vehicle, regardless of how well it was designed and built.

A careful and judicious service technician is the best guarantee against accidents.

Precise observance of the most basic safety rule is normally sufficient to avoid many serious accidents.

DANGER: Never carry out any cleaning, lubrication or maintenance operations when the engine is running.

GENERAL

- Carefully follow specified repair and maintenance procedures.
- Do not wear rings, wristwatches, jewellery, unbuttoned or loose articles of clothing such as: ties, torn clothing, scarves, open jackets or shirts with open zips that may remain entangled in moving parts.
It is advised to wear approved safety clothing, e.g: non-slip footwear, gloves, safety goggles, helmets, etc.
- Do not carry out repair operations with someone sitting in the driver's seat, unless the person is a trained technician who is assisting with the operation in question.
- Operate the vehicle and use the implements exclusively from the driver's seat.
- Do not carry out operations on the vehicle with the engine running, unless specifically indicated.
- Stop the engine and ensure that all pressure is relieved from hydraulic circuits before removing caps, covers, valves, etc.
- All repair and maintenance operations must be carried out using extreme care and attention.
- Service steps and platforms used in a workshop or in the field should be built in compliance with the safety rules in force.
- Disconnect the batteries and label all controls to indicate that the vehicle is being serviced. Block the machine and all equipment which should be raised.
- Do not check or fill fuel tanks, accumulator batteries, nor use starting liquid when smoking or near naked flames, as these fluids are inflammable.
- Brakes are inoperative if manually released for repair or maintenance purposes.
In such cases, the machine should be kept constantly under control using blocks or similar devices.
- The fuel nozzle should always be in contact with the filling aperture. Maintain this position until filling operations are completed in order to avoid possible sparks caused by the accumulation of static electricity.
- Only use specified towing points for towing the tractor, connect parts carefully. Make sure that all pins and/or locks are secured in position before applying traction.
Never remain near the towing bars, cables or chains that are operating under load
- Transport vehicles that cannot be driven using a trailer or a low-loading platform trolley, if available.
- When loading or unloading the vehicle from the trailer (or other means of transport), select a flat area capable of sustaining the trailer or truck wheels, firmly secure the tractor to the truck or trailer and lock the wheels in the position.
- Electric heaters, battery-chargers and similar equipment must only be powered by auxiliary power supplies with efficient ground insulation to avoid electrical shock hazards.
- Always use suitable hoisting or lifting devices when raising or moving heavy parts.
- Take extra care if bystanders are present.
- Never pour gasoline or diesel oil into open, wide and low containers.
- Never use gasoline, diesel oil or other inflammable liquids as cleaning agents. Use non-flammable non-toxic proprietary solvents.
- Wear safety goggles with side guards when cleaning parts with compressed air.
- Limit the air pressure to a maximum of **2.1 bar (30.5 psi)**, according to local regulations.

- Do not run the engine in confined spaces without suitable ventilation.
- Do not smoke, use naked flames, or cause sparks in the area when fuel filling or handling highly inflammable liquids.
- Never use naked flames for lighting when working on the machine or checking for leaks.
- All movements must be carried out carefully when working under, on or near the vehicle and wear protective equipment: helmets, goggles and special footwear.
- When carrying out checks with the engine running, request the assistance of an operator in the driver's seat. The operator must maintain visual contact with the service technician at all times.
- If operating outside the workshop, position the vehicle on a flat surface and lock in position. If working on a slope, lock the vehicle in position and move to a flat area as soon as is safely possible.
- Damaged or bent chains or cables are unreliable. Do not use them for lifting or towing. Always use suitable protective gloves when handling chains or cables.
- Chains should always be safely secured. Ensure that fastening device is strong enough to hold the load foreseen. No persons should stop near the fastening point, trailing chains or cables.
- Maintenance and repair operations must be carried out in a CLEAN and DRY area, eliminate any water or oil spillage immediately.
- Do not create piles of oil or grease--soaked rags as they represent a serious fire hazard; store them in a closed metal container.
Before starting the vehicle or implements, make sure that the driver's seat is locked in position and always check that the area is free of persons or obstacles.
- Empty pockets of all objects that may fall unobserved into the vehicle parts when disassembled.
- In the presence of protruding metal parts, use protective goggles or goggles with side guards, helmets, special footwear and gloves.
- Handle all parts carefully, do not put your hands or fingers between moving parts, wear suitable safety clothing -- safety goggles, gloves and shoes.

WELDING OPERATIONS

- When welding, use protective safety devices: tinted safety goggles, helmets, special overalls, gloves and footwear. All persons present in the area where welding is taking place must wear tinted goggles.
NEVER LOOK AT THE WELDING ARC IF YOUR EYES ARE NOT SUITABLY PROTECTED.
- Where possible, remove the part or tool that requires arc welding from the tractor.
- Disconnect both battery leads. Isolate the cable ends to avoid contact with each other and the tractor.
- Position the welder ground clamp as near as possible to the area where welding is taking place.
- Remove the electronic control units located on the tractor if welding is to be carried out near these control units.
- Never allow welding cables to lay on, near or across any electrical wiring or electronic component while welding is in progress.
- Metal cables tend to fray with repeated use. Always use suitable protective devices (gloves, goggles, etc.) when handling cables.

START UP

- Never start the engine in confined spaces that are not equipped with adequate ventilation for exhaust gas extraction.
- Never place the head, body, limbs, feet, hands or fingers near fans or rotating belts.

ENGINE

- Always loosen the radiator cap slowly before removing it to allow any remaining pressure in the system to be discharged. Coolant should be topped up only when the engine is stopped or idle if hot.
- Never fill up with fuel when the engine is running, especially if hot, in order to prevent the outbreak of fire as a result of fuel spillage
- Never check or adjust fan belt tension when the engine is running.
Never adjust the fuel injection pump when the vehicle is moving.

- Never lubricate the vehicle when the engine is running.

ELECTRICAL SYSTEMS

- If it is necessary to use auxiliary batteries, remember that both ends of the cables must be connected as follows: (+) with (+) and (-) with (-).
- Avoid short-circuiting the terminals. GAS RELEASED FROM BATTERIES IS HIGHLY INFLAMMABLE.
- During charging, leave the battery compartment uncovered to improve ventilation.
- Never check the battery charge using "jumpers" (metal objects placed on the terminals).
- Avoid sparks or flames near the battery zone to prevent explosion hazards.
- Before servicing operations, check for fuel or current leaks. Eliminate any eventual leaks before starting work.
- Never charge batteries in confined spaces. Make sure that there is adequate ventilation in order to prevent accidental explosion hazards as a result of the accumulation of gases released during charging operations.
- Always disconnect the battery before performing any kind of servicing on the electrical system.

HYDRAULIC SYSTEMS

- Some fluid slowly coming out from a very small port can be almost invisible and be strong enough to penetrate the skin. Check for leaks using a piece of cardboard, NEVER USE HANDS.
- If any liquid penetrates skin tissue, call for medical aid immediately
- Serious skin infections may result if medical attention is not given.
- Use the specific tools when checking pressure values on the hydraulic system.

WHEELS AND TYRES

- Check that the tyres are correctly inflated at the pressure specified by the manufacturer. Periodically check possible damages to the rims and tyres.
- Stand away from (at the side of) the tire when checking inflation pressure.
- Only check pressure when the vehicle is unloaded and the tires are cold, to avoid incorrect readings as a result of over-pressure.
- Do not re-use parts of recovered wheels as incorrect welding or brazing may heat the material, causing it to weaken and eventually damage or break the wheel.
- Never cut, nor weld a rim with the inflated tyre assembled.
- When removing the wheels, lock both the front and rear vehicle wheels.
- Always position support stands when raising the vehicle, in order to conform to current safety regulations.
- Deflate the tyre before removing any object caught into the tyre tread.
- Never inflate tires using inflammable gases; this could cause an explosion and put operator safety at risk.

REMOVAL AND RE-FITTING

- Lift and handle all heavy parts using suitable lifting equipment and make sure that all slings and hooks are correctly secured.
- Handle all parts carefully during lifting operations, keep an eye on the personnel working near the load to be lifted. Never insert hands or fingers between parts, always wear approved accident prevention clothing (goggles, gloves and work boots).
- Avoid twisting chains or metal cables and always wear safety gloves when handling cables or chains.

Basic instructions

SHIMMING

For each adjustment operation, select adjusting shims and measure individually using a micrometer, then add up the measured values: Do not rely on measuring the entire shimming set, which may be incorrect, or the rated value indicated for each on shim.

ROTATING SHAFT SEALS

For correct rotating shaft seal installation, proceed as follows:

- thoroughly clean the shaft and check that the working surface on the shaft is not damaged;
- position the sealing lip facing the fluid; with hydrodynamic lips, take into consideration the shaft rotation direction and position the grooves so that they will deviate the fluid towards the inner side of the seal;
- coat the sealing lip with a thin layer of lubricant (use oil rather than grease) and fill the gap between the sealing lip and the dust lip on double lip seals with grease;
- insert the seal in its seat and press down using a seal installer; do not tap the seal with a hammer or mallet;
- whilst inserting the seal, check that it is perpendicular to the seat; once settled.
- to prevent damaging the seal lip on the shaft, position a protective guard during installation operations.

O--RING SEALS

Lubricate the O--RING seals before inserting them in the seats, this will prevent them from overturning and twisting, which would jeopardise sealing efficiency.

SEALING COMPOUNDS

Apply one of the following sealing compounds on the mating surfaces marked, on this manual, with an X: **RTV 1473, RHODORSIL® CAF 1 or LOCTITE PLASTIC GASKET.**

Before applying the sealing compound, prepare the surfaces as follows:

- remove any incrustations using a wire brush;

- **⚠ WARNING**

Chemical hazard!

Always wear protective clothing and goggles when cleaning with solvents, acids, or alkaline chemical agents. Always follow the chemical manufacturer's instructions.
Failure to comply could result in death or serious injury.

W0180A

thoroughly de-grease the surfaces using one of the following cleaning agents: trichlorethylene, Diesel fuel or a water and sodium hydroxide (**NaOH** , also known as caustic soda) solution.

BEARINGS

When installing bearings it is advised to:

- heat the bearings to 80 ÷ 90 °C before fitting on the shafts;
- allow the bearings to cool before installing them.

SPRING PINS

When fitting split socket elastic pins, ensure that the pin notch is positioned in the direction of the force required to stress the pin.

Spiral spring pins do not require special positioning.

IMPORTANT NOTES

Wear limit values indicated for certain parts are recommended, but not binding. The terms "front", "rear", "right--hand" and "left--hand" (when referred to different parts) are intended as seen from the driving position with the tractor in the normal direction of movement.

MOVING THE TRACTOR WITH THE BATTERY REMOVED

External power supply cables should only be connected to the respective positive and negative cable terminals, using efficient clamps that guarantee adequate and secure contact. Disconnect all services (lights, windshield wipers, etc.) before starting the vehicle. If the vehicle electrical system requires checking, carry out operations with the power supply connected; Once checking is completed, disconnect all services and switch off the power supply before disconnecting the cables.

Basic instructions for arc-welding on tractors with electronic lift

ATTENTION: Observe the following precautions when carrying out arc welding on a tractor fitted with an electronic lift.

- Where possible, remove the part or implement that requires arc welding from the tractor.
- Disconnect both battery leads. Isolate the cable ends to avoid contact with each other and the tractor.
- Position the welder ground clamp as near as possible to the area where welding is to take place.
- Remove the electronic control units located on the tractor if welding is to be carried out near these control units.
- Never allow welding cables to lay on, near or across any electrical wiring or electronic component while welding is in progress.

Special tools NOTES FOR EQUIPMENT

The tools that CASE IH AGRICULTURE propose and illustrate in this manual are:

- specifically researched and designed for use with CASE IH AGRICULTURE vehicles;
- necessary to make reliable repair;
- accurately built and strictly tested to offer efficient and long--lasting working means.

By using these tools, repair personnel will benefit from:

- operating in optimal technical conditions;
- obtaining the best results;
- saving time and effort;
- working in safe conditions.

Consumables

	QUANTITY	RECOMMENDED CASE IH AGRICULTURE PRODUCTS	SPECIFICATION CASE IH AGRICULTURE	INTERNATIONAL SPECIFICATION
Cooling system:	16 l (4.2 US gal)	Mixture of water and antifreeze CASE IH AKCELA PREMIUM ANTI-FREEZE at 50 % + 50 %	NH 900 A	-
Windscreen wash reservoir	2 l (0.5 US gal)	Water and Detergent liquid	-	-
Fuel tank:	155 l (40.9 US gal)	Decanted, filtered diesel fuel	-	-
Engine sump: Minimum	6.4 l (1.7 US gal)	CASE IH AKCELA UNITEK CJ-4 ENGINE OIL SAE 10W-40 or CASE IH AKCELA UNITEK CJ-4 ENGINE OIL SAE 0W-40	MAT3521	API CJ-4 ACEA E7/E9
Maximum	8.1 l (2.1 US gal)			
Brake control circuit	0.7 l (0.18 US gal)	CASE IH AKCELA LHM FLUID	NH 610 A	ISO 7308
Front axle:	4.5 l (1.2 US gal)	CASE IH AKCELA NEXPLORE™ FLUID	NH 410 B	API GL4 ISO 32/46 SAE 10W-30
Final drives (each)	1.0 l (0.3 US gal)			
Transmission bevel drive final drives and brakes gearbox hydraulic lift power take-off hydrostatic steering	63 l (16.6 US gal)			
Front hubs	-	CASE IH AKCELA 251H EP MULTI-PURPOSE GREASE	NH 710 A	NLGI 2
Grease fittings	-			
Air-conditioning refrigerant	650 g (22.9 oz)	-	-	R134A
Air-conditioning compressor oil	0.185 l (0.05 US gal)	-	-	SP10

Part identification

Use solely genuine parts, which guarantee the same quality, duration and safety as the original parts as they are identical to the ones fitted during production.

Only genuine parts can offer this guarantee.


When ordering spare parts, always provide the following information:

- tractor model (commercial name) and frame number;
- engine type and number;
- part number of the ordered part, which can be found in the "Microfiches" or the "Spare Parts Catalogue", used for order processing.



SERVICE MANUAL

Engine



**Farmall 105U EP
Farmall 115U EP
Farmall 95U EP**

Contents

Engine - 10

[10.001] Engine and crankcase	10.1
Farmall 105U EP , Farmall 115U EP , Farmall 95U EP	
[10.414] Fan and drive	10.2
Farmall 105U EP , Farmall 115U EP , Farmall 95U EP	
[10.501] Exhaust Gas Recirculation (EGR) - Diesel Particulate Filter (DPF) exhaust treatment	10.3
Farmall 105U EP , Farmall 115U EP , Farmall 95U EP	



Engine - 10

Engine and crankcase - 001

**Farmall 105U EP
Farmall 115U EP
Farmall 95U EP**

Contents

Engine - 10

Engine and crankcase - 001

TECHNICAL DATA

Engine	
General specification	3

SERVICE

Engine	
Remove	5
Install	16

Engine - General specification


GENERAL SPECIFICATIONS		4 Cylinders
Engine, technical type: Farmall 95U		F5DFL413C*A003
Farmall 105U		F5DFL413B*A006
Farmall 115U		F5DFL413B*A002
Engine rpm - high		2400 - 2500 RPM
- nominal		2300 RPM
- low		700 - 800 RPM
Cycle		diesel, 4-stroke
Fuel injection		Direct
Number of cylinders in line		4
Bore - All models - Piston diameter		99 mm (3.8976 in)
- Piston stroke		110 mm (4.3307 in)
Total displacement: - All models		3400 cm³
Compression ratio All models		17 ± 0.5 : 1
Maximum Power Output: - Farmall 95U		73 kW (99 Hp)
- Farmall 105U		79 kW (107 Hp)
- Farmall 115U		84 kW (114 Hp)
Maximum power speed		2300 RPM
Peak torque - Farmall 95U		407 N·m (300.19 lb ft)
- Farmall 105U		444 N·m (327.48 lb ft)
- Farmall 115U		461 N·m (340.02 lb ft)
Peak torque speed		1500 RPM
Torque increase - Farmall 95U		34 %
- Farmall 105U		35 %
- Farmall 115U		32 %
Power at the power take-off - Farmall 95U		62.7 kW (85.1 Hp)
- Farmall 105U		68.6 kW (93.3 Hp)
- Farmall 115U		73.9 kW (100.4 Hp)
Number of main bearings		5
Sump		structural, cast iron
Lubrication		forced, with lobe pump
Pump drive		from crankshaft
Oil filtration		mesh screen on oil intake and filter cartridge on delivery line
Engine oil pressure switch operating pressures: - contacts closing* with decreasing pressure. - contacts opening* with increasing pressure. * with the contacts closed the engine oil pressure warning light is on		0.2 bar (2.90 psi) 0.9 bar (13.05 psi)
Cooling		coolant circulation
closing		with five rows of vertical pipes
Capacity		16 l (4.23 US gal)
Fan with viscous joint, fixed to the specific pulley		Ø 520 mm (20.4724 in)
Coolant pump		intake, in plastic with 10 blades
Coolant thermometer		colored scale divided into three sections
Temperature ranges corresponding to each section: - initial dark blue sector		normal temperature
- final red sector		high temperature
dark blue area		via thermostat valve
- Start of opening		80 °C (176.00 °F)

GENERAL SPECIFICATIONS		4 Cylinders
Timing	overhead valves operated by tappets, rods and rocker arms via the camshaft located in the engine block; the camshaft is driven by the crankshaft using straight-tooth gears	
Intake: - start: before P.M.S. - end: after P.M.I.	19 ° 37 °	
Exhaust: - start: before P.M.I. - end: after P.M.S.	61 ° 21 °	
Clearance between valves and rocker arms with engine cold.	The valve clearance is hydraulically controlled. Therefore, manual adjustment is not necessary.	
Turbocharging	Turbocharged with intercooler	
Air cleaning	dual cartridge dry air cleaner, with clogged filter indicator with centrifugal pre-filter and automatic dust ejector	
Fuel filtration	by mesh prefilter on the supply pipe, suction line filter with water - fuel separator, low pressure filter and sensor.	
Priming pump	Manual mounted on the suction line filter	
Injection pump	BOSCH	
Type	High pressure Common Rail control unit HPCR - CP4.1	
Nozzles type	Electro-injectors	
Injection pressure	300 - 1400 bar (4350.00 - 20300.00 psi)	
Filling: Engine sump Fuel tank	6.4 - 8.1 l (1.69 - 2.14 US gal) 140 l (36.98 US gal)	
Anti-pollution system Type:	Exhaust gas recycling system EGR Particulate filter DPF*	
Recommended frequency for renewing filter	every 3000 hours	

NOTE: * - For filter maintenance please refer to: (*Diesel Particulate Filters (DPF) - Dynamic description manual regeneration of the diesel particulate filter (DPF) (55.408)*)


Engine - Remove

1. Remove the hood (1) as indicated in **Hood - Remove (90.100)**
2. Free the bottom steps of the ladder with the retainer (1), raise it with the knob (2), take off the battery cover, detach the battery negative cable.




WLAPL4S10C101A 1

3. Remove the split pins, retaining pin and front ballast assembly (1) from the support.



WLAPL4S10C102AA 2


4. Unscrew the fixing screws (1) and remove the front wheel mudguards (2) (if applicable) Do this on both sides.



MMR0070A


WLAPL4S10C104A 3

5. Remove the fixing bolts (1) and detach the engine left-hand side panel (2). Carry out the same operation for the right-hand side panel too. Remove the glove compartment.




WLAPL4S10C105A 4


6. Recover the refrigerant from the system via the connections (1) and (2) using the specific tool **380000315**. Detach the pipe (1), clear the section of brackets and clamps, move it onto the condenser (1, 6), detach the pipe (2), clear the section and take it to the cab.




7. Subsequently go onto the front detach the lower pipe (3) on the condenser (1) free it from any straps or clamps, disconnect the sensor (2) and take it to the cab.




8. Drain the fuel from the tank by removing the bottom drain plug.



9. Unscrew the fixing bolts (1) and remove the right-hand steps (2).




10. Raise the rear of the tractor with a hydraulic jack, put a mechanical stand under the reduction unit box, with a pneumatic gun remove the left-hand rear wheel retaining nuts, and subsequently take off the wheel.




WLAPL4S10C110A 9

11. Detach the tank retaining straps (1), mark and detach the fuel pipes (2) and extract the fuel tank (3). Remove also the bottom tank guard (4)




WLAPL4S10C111A 10

12. Unscrew the front central and rear retaining bolts on the front axle shaft guard, then remove the guard (1).




WLAPL4S10C112AA 11

13. Remove the circlip (2) and move the front sleeve (1) in the direction indicated by the arrow until it is released from the groove on the front axle.




WLAPL4S10C113AA 12

14. Remove the circlip (2) retaining the coupling sleeve of the propeller shaft (1) on the back, move the sleeve on the shaft.




WLAPL4S10C114AA 13

15. Take out the screws fixing the central support (1) of the propeller shaft and remove the shaft together with the support, remove also the shaft end float adjuster shim on the back.




WLAPL4S10C115AA 14

16. Loosen the union of the cab heater radiator coolant return pipe, drain and collect the engine coolant.




WLAPL4S10C116A 15

17. Take out the plug (1) and drain the oil from the gearbox-transmission casing.




WLAPL4S10C117A 16

18. Loosen the device joining the outlet on the filter **DPF**, free the outlet tube from any brackets fastening it to the cab and remove it.




WLAPL4S10C118A 17

19. Loosen the fixing clamps (1) and extract the pipe from the turbine to the radiator **intercooler** (2). Carry out the same operation for the pipe from the radiator **intercooler** to the engine (3).




WLAPL4S10C119A 18

20. Loosen the clamp (2) fastening the air intake pipe to the turbine, then free the air cleaner (4) together with the support bracket (3) from the screws fixing it. Disconnect the oil vapor pipe (1) on the left-hand side of the engine at the level of the fuel pump; remove it all.



WLAPL4S10C120A 19

21. Free the air cleaner bracket - casing support (1) from the fixing screws and remove it.



WLAPL4S10C121A 20

ATTENTION: The filter outlet union **DPF** (1) at its terminal (2) has a decoupler, that reacts, when the temperature changes, only lengthwise.

Sample of manual. Download All 2155 pages at:

<https://www.arepairmanual.com/downloads/2013-case-farmall-95u-105u-115u-efficient-power-tractor-service-repair-manual>