



1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4




1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4



1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4



1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4

## W4 LOADER AND FORKLIFT TABLE OF CONTENTS

DIVISION/SECTION	SECTION NO.	FORM NO.
<b>1 GENERAL</b>		
Safety Rules, Service Manual Introduction, and Torque Specifications .....	1001	8-33921
Maintenance and Lubrication .....	1002	8-33931
<b>2 ENGINE</b>		
1.8 Litre Diesel Engine Repair Operation Manual (Leyland) .....		AKM 3934 (2nd Edition)
Mitsubishi Diesel Engine 4DQ50 (2.1 litres) .....		99609-10111
Engine Removal and Installation, 1.8 Litre Diesel Engine .....	2020	8-33582
Engine Removal and Installation, 2.1 Litre Diesel Engine .....	2021	8-33650
Drive Plate, 1.8 Litre Diesel Engine .....	2042	8-33691
Air Cleaner System .....	2060	8-33590
Cooling System .....	2080	8-33601
<b>4 ELECTRICAL</b>		
Wiring Diagrams .....	4015	8-33631
Battery .....	4025	8-33641
Warning Lights, Heat Indicator, Neutral Start Switch .....	4060	8-33681
<b>5 STEERING</b>		
Steering System Description and Operation .....	5004	8-33710
Steering System Troubleshooting .....	5008	8-33721
Steering Control Valve .....	5018	8-33741
Steering Pump .....	5019	8-33751
Steering Cylinder .....	5020	8-33761
<b>6 POWER TRAIN</b>		
2 Speed Transmission .....	6020	8-33551
Hydrostatic Transmission Operation, Maintenance, and Start-Up Procedure .....	6050	8-33501
Hydrostatic Diagram, Troubleshooting, and Pressure Checks .....	6052	8-33511
Hydrostatic Pump .....	6054	8-33521
Hydrostatic Motor .....	6056	8-33531
Drive Shaft .....	6075	8-33570
Front Axle Removal and Installation .....	6088	8-33491
Rear Axle and Transmission Removal and Installation .....	6089	8-33702
Drive Axle .....	6090	8-33562
Wheels and Tires .....	6095	8-33481
<b>7 BRAKES</b>		
Brakes .....	7040	8-33650
<b>8 HYDRAULICS</b>		
Cleaning the Hydraulic System .....	8003	8-33650
Troubleshooting, Hydraulic Diagrams, and Pressure Checks .....	8008	8-33821
Loader and Forklift Control Valve .....	8041	8-33831
Cylinders .....	8090	8-33650
<b>9 MOUNTED EQUIPMENT</b>		
Loader .....	9010	8-33650
Forklift .....	9040	8-33650
Roll-Over Protective Structure .....	9075	8-34050

Reprinted

## NOTES

# Section 1001

## SAFETY RULES SERVICE MANUAL INTRODUCTION AND TORQUE SPECIFICATIONS

Written in *Clear  
And  
Simple  
English*

## SAFETY RULES


**This Symbol Shows Important Information About Safety In This Manual. When You See This Symbol, Carefully Read The Information That Follows and Understand The Possible Causes of Injury Or Death.** 1-1-A

**IMPORTANT:** *To prevent injury on job, follow the Warning, Caution, and Danger notes in this section and other sections throughout this manual. Follow the instructions carefully.*

The procedures recommended and shown in this manual are good, effective service methods. However, all possible procedures and service hazards may not be covered. Therefore, if you use a tool or procedure not recommended, you must make sure that the method you select is a safe method.



**DANGER:** *Engine exhaust fumes can cause death. If it is necessary to start the engine in a closed place, remove the exhaust fumes from the area with an exhaust pipe extension. If you do not have an exhaust pipe extension, open the doors and get outside air into the area.* 48-56


**WARNING:** *Read operator's manual to familiarize yourself with control lever functions.* 46-27


**WARNING:** *Operate tractor and equipment controls from the seat position only. Any other method could result in serious injury.* 48-55


**WARNING:** *This is a one man machine, no riders allowed.* 35-8


**WARNING:** *If you wear clothing that is too loose or do not use the correct safety equipment for your job, you can be injured. Always wear clothing that will not catch on objects. Extra safety equipment that can be required includes hard hat, safety shoes, ear protection, eye or face protection, heavy gloves and reflector clothing.* 45-3-A




**WARNING:** *When working in the area of the fan belt with the engine running, avoid loose clothing if possible, and use extreme caution.* 35-4


**WARNING:** *Whenever the bucket must be raised to aid in servicing, block the loader arms in place with lift cylinder support strut or a suitable safety stand.* 23-7-B


**WARNING:** *When doing checks and tests on the equipment hydraulics, follow the procedures as they are written. DO NOT change the procedure.* 47-44



**WARNING:** When putting the hydraulic cylinders on this machine through the necessary cycles to check operation or to remove air from a circuit, make sure all people are out of the way. 47-45



**WARNING:** Locate the machine on level ground and block the wheels securely before working under the machine. Failure to follow the above procedure can result in personal injury. 46-77



**WARNING:** Use insulated gloves or mittens when working with hot parts. 47-41A



**CAUTION:** Pin sized and smaller streams of hydraulic oil under pressure can penetrate the skin and result in serious infection. If hydraulic oil under pressure does penetrate the skin, seek medical treatment immediately. Maintain all hoses and tubes in good condition. Make sure all connections are tight. Make a replacement of any tube or hose that is damaged or thought to be damaged. DO NOT use your hand to check for leaks; use a piece of cardboard or wood. 40-6-A



**CAUTION:** When removing hardened pins such as a pivot pin, or a hardened shaft, use a soft head (brass or bronze) hammer or use a driver made from brass or bronze and a steel head hammer. 46-17



**CAUTION:** When using a hammer to remove and install pivot pins or separate parts, using compressed air or using a grinder, wear eye protection that completely encloses the eyes (approved goggles or other approved eye protectors). 46-13



**CAUTION:** When servicing or repairing the machine, keep the shop floor and operator's compartment and steps free of oil, water, grease, tools, etc. Use an oil absorbing material and/or shop cloths as required. Use safe practices at all times. 40-8



**CAUTION:** Use suitable floor (service) jacks or chain hoists to raise wheels or track off the floor. Always block machine in place with suitable safety stands. 40-7-A



**CAUTION:** Some components of this machine are very heavy. Use suitable lifting equipment or additional help as instructed in this service manual. 40-10

## SERVICE MANUAL INTRODUCTION

This service manual has been prepared with the latest service information available. Troubleshooting, removal, disassembly, inspection and installation procedures, and complete specifications and tightening references can be found in most sections. Some sections have drawings without a written procedure because the job is so easily done. This service manual is one of the most important tools available to the service technician.

### Right-Hand and Left-Hand

The terms right-hand and left-hand and front and rear as used in this manual indicate the right and left sides, and front and rear of the machine as seen from the operator's seat for correct operation of the machine or attachment.

### Text

If the service manual is for more than one machine or different models of components (planetary axles, gear boxes, control valves, etc.) the procedures have the steps necessary to service each model.

### Table of Contents

A Table of Contents is in the front of this manual. The Table of Contents shows the main divisions and the sections that are in each division. The individual sections, where necessary, have a Table of Contents on the second page of that section.

### Page Numbers

All page numbers are made of two numbers separated by a dash, such as 4002-9. The number before the dash is the section number. The number following the dash is the page number in that section. Page numbers will be found at the upper right or left of each page. -

### Illustrations

Illustrations are put as near as possible to the text and are to be used as part of the text.

### Torque Specifications

The most common grades of fasteners (bolts, nuts, and screws) used on Case machines are grade 5 and grade 8. See page 1001-6 for torque specifications and identification marks.

The specifications in this section are standard torque values and are to be used on all fasteners during assembly and installation unless special torque values are shown in a section.

Rev. May 1982

### P.I.N., Serial and Model Numbers

When replacement parts are needed, it is necessary to give the parts department one or all of the numbers. The model number is normally found on the Product Identification Number plate or Serial Number plate.

The Product Identification Number (P.I.N.) and serial numbers will be found in the following locations.

Machine - Product Identification Number plate fastened to the front frame above the parking brake.

1.8 Litre Diesel Engine - A serial number plate is on the left-hand side of the engine below the preheaters.

2.1 Litre Diesel Engine - A serial number is stamped on the left-hand side of the engine in front of the tachometer drive.

ROPS - Serial number plate fastened to the left-hand side of the ROPS.

Forklift - Serial number is stamped on the right-hand side of the outer frame assembly.

Components - A serial number plate is on many components such as starters, alternators, pumps, etc.

### Classification of Lubricants

The SAE number is the viscosity of engine oils; for example, SAE 30, a single viscosity oil. SAE 10W30 is a variable viscosity oil.

The API classification (SD, CD, etc.) is the oil performance in terms of engine usage. Only oil specified in Section 1002 can be used. These oils have the needed chemical additives to give maximum engine protection. Both the SAE grade and API classification must be found on the container.

### Gear Lubricant and Grease

Gear lubricant and grease for each application is specified in Section 1002.

## Decals and Painting

All decals about operation of the machine and/or attachments must be in a condition so that you can read the decals easily. Replace any decal that is damaged or cannot be read.

All decals that start with the words WARNING, CAUTION, or DANGER must be in a condition so that you can read the decals easily. Replace any decal that is damaged or cannot be read.

When you paint the machine or attachment, put covers over the good decals and remove the decals which have damage or cannot be read easily. Use enamel thinner to make the decal easier to remove.

Remove the old decal before you install a new decal. Use enamel thinner to make the old decal easier to remove.

## Special Tools

Special tools are needed to remove and install, disassemble and assemble, check and adjust some component parts of this machine. Some special tools can be easily made locally and the necessary information to make the tool is in this service manual. Other special tools are more difficult to make locally and are available from Service Tools in the U.S. and from Jobborn Manufacturing in Canada. Use these tools according to the instructions in this service manual for your personal safety and to do the job correctly.

Order special tools from either of the following companies:

Service Tools  
P.O. Box 314  
Owatonna, Minnesota 55060

Jobborn Manufacturing Co.  
97 Frid Street  
Hamilton, Ontario L8P 4M3  
Canada

**U.S. AND METRIC TORQUE SPECIFICATIONS**

Torque values for all situations unless special torque is specified

<b>Grade 5 Bolts, Nuts, and Studs</b>			
			
Thread Size	Pound-Feet	Newton metres	Kilogram metres
<b>1/4 - 20</b>	7-9	9-12	1.0-1.2
<b>1/4 - 28</b>	11-13	15-18	1.5-1.8
6.4 mm			
<b>5/16 - 18</b>	10-15	15-20	1.4-2.1
<b>5/16 - 24</b>	15-20	20-25	2.1-2.8
7.9 mm			
<b>3/8 - 16</b>	20-25	25-35	2.8-3.4
<b>3/8 - 24</b>	25-30	35-40	3.4-4.1
9.5 mm			
<b>7/16 - 14</b>	30-40	40-55	4.1-5.5
<b>7/16 - 20</b>	35-45	45-60	4.8-6.2
11.1 mm			
<b>1/2 - 13</b>	50-60	70-80	6.9-8.3
<b>1/2 - 20</b>	60-70	80-95	8.3-9.7
12.7 mm			
<b>9/16 - 12</b>	70-90	95-120	9.7-12.4
<b>9/16 - 18</b>	80-100	110-135	11.0-13.8
14.3 mm			
<b>5/8 - 11</b>	100-120	135-160	13.8-16.6
<b>5/8 - 18</b>	120-150	160-200	16.6-20.7
15.9 mm			
<b>3/4 - 10</b>	180-220	245-300	24.9-30.4
<b>3/4 - 16</b>	200-240	270-325	27.7-33.2
19.0 mm			
<b>7/8 - 9</b>	290-350	390-475	40.1-48.4
<b>7/8 - 14</b>	325-400	440-540	44.9-55.3
22.2 mm			
<b>1 - 8</b>	430-530	580-720	59.4-73.3
<b>1 - 12</b>	480-580	650-785	66.4-80.2
25.4 mm			
<b>1-1/8 - 7</b>	540-660	730-895	74.7-91.2
<b>1-1/8 - 12</b>	595-725	805-980	82.3-100.2
28.6 mm			
<b>1-1/4 - 7</b>	755-925	1025-1255	104.4-127.9
<b>1-1/4 - 12</b>	830-1010	1125-1370	114.8-139.6
31.8 mm			
<b>1-3/8 - 6</b>	990-1210	1340-1640	136.9-167.3
<b>1-3/8 - 12</b>	1135-1385	1540-1860	156.9-191.5
34.9 mm			
<b>1-1/2 - 6</b>	1315-1610	1780-2180	181.8-222.6
<b>1-1/2 - 12</b>	1475-1800	2000-2440	203.9-248.9
38.1 mm			

<b>Grade 8 Bolts, Nuts, and Studs</b>			
			
Thread Size	Pound-Feet	Newton metres	Kilogram metres
<b>1/4 - 20</b>	5-10	7-15	.7-1.4
<b>1/4 - 28</b>	10-15	15-20	1.4-2.1
6.4 mm			
<b>5/16 - 18</b>	15-20	20-30	2.1-2.8
<b>5/16 - 24</b>	20-25	30-35	2.8-3.4
7.9 mm			
<b>3/8 - 16</b>	30-40	40-50	4.1-5.5
<b>3/8 - 24</b>	35-40	40-55	4.8-5.5
9.5 mm			
<b>7/16 - 14</b>	40-60	55-80	5.5-8.3
<b>7/16 - 20</b>	55-65	75-90	7.6-9.0
11.1 mm			
<b>1/2 - 13</b>	70-90	95-120	9.7-12.4
<b>1/2 - 20</b>	80-100	110-135	11.1-13.8
12.7 mm			
<b>9/16 - 12</b>	100-120	135-160	13.8-16.6
<b>9/16 - 18</b>	120-140	160-190	16.6-19.4
14.3 mm			
<b>5/8 - 11</b>	150-190	200-260	20.7-26.3
<b>5/8 - 18</b>	160-200	220-270	22.1-27.7
15.9 mm			
<b>3/4 - 10</b>	250-310	340-420	34.6-42.9
<b>3/4 - 16</b>	290-350	390-475	40.1-48.4
19.0 mm			
<b>7/8 - 9</b>	415-505	560-685	57.4-69.8
<b>7/8 - 14</b>	450-550	610-745	62.2-76.0
22.2 mm			
<b>1 - 8</b>	610-750	870-1015	84.3-103.7
<b>1 - 12</b>	665-815	900-1105	91.9-112.7
25.4 mm			
<b>1-1/8 - 7</b>	865-1055	1170-1430	119.6-145.9
<b>1-1/8 - 12</b>	970-1190	1315-1610	134.1-164.5
28.6 mm			
<b>1-1/4 - 7</b>	1225-1495	1660-2025	169.4-206.7
<b>1-1/4 - 12</b>	1350-1650	1830-2235	186.6-228.1
31.8 mm			
<b>1-3/8 - 6</b>	1600-1960	2170-2655	221.2-271.0
<b>1-3/8 - 12</b>	1835-2245	2490-3045	253.8-310.4
34.9 mm			
<b>1-1/2 - 6</b>	2125-2595	2880-3520	293.8-358.8
<b>1-1/2 - 12</b>	2395-2925	3245-3965	331.1-404.4
38.1 mm			

## TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS

Tube OD Hose ID	Thread Size	Pound- Feet	Newton metres	Kilogram metres
<b>37 Degree Flare Fittings</b>				
<b>1/4 in</b> 6.4 mm	7/16-20	6-12	8-16	0.8-1.7
<b>5/16 in</b> 7.9 mm	1/2-20	8-16	11-21	1.1-2.2
<b>3/8 in</b> 9.5 mm	9/16-18	10-25	14-33	1.4-3.5
<b>1/2 in</b> 12.7 mm	3/4-16	15-42	20-56	2.1-5.8
<b>5/8 in</b> 15.9 mm	7/8-14	25-58	34-78	3.5-8.0
<b>3/4 in</b> 19.0 mm	1-1/16-12	40-80	54-108	5.5-11.1
<b>7/8 in</b> 22.2 mm	1-3/16-12	60-100	81-135	8.3-13.9
<b>1.0 in</b> 25.4 mm	1-5/16-12	75-117	102-158	10.4-16.2
<b>1-1/4 in</b> 31.8 mm	1-5/8-12	125-165	169-223	17.3-22.8
<b>1-1/2 in</b> 38.1 mm	1-7/8-12	210-250	285-338	29.0-34.6

Tube OD Hose ID	Thread Size	Pound- Feet	Newton metres	Kilogram metres
<b>Straight Threads with O-ring</b>				
<b>1/4 in</b> 6.4 mm	7/16-20	12-19	16-25	1.7-2.6
<b>5/16 in</b> 7.9 mm	1/2-20	16-25	22-33	2.2-3.5
<b>3/8 in</b> 9.5 mm	9/16-18	25-40	34-54	3.5-5.5
<b>1/2 in</b> 12.7 mm	3/4-16	42-67	57-90	5.8-9.3
<b>5/8 in</b> 15.9 mm	7/8-14	58-92	79-124	8.0-12.7
<b>3/4 in</b> 19.0 mm	1-1/16-12	80-128	108-174	11.1-17.8
<b>7/8 in</b> 22.2 mm	1-3/16-12	100-160	136-216	13.8-22.1
<b>1.0 in</b> 25.4 mm	1-5/16-12	117-187	159-253	16.2-25.9
<b>1-1/4 in</b> 31.8 mm	1-5/8-12	165-264	224-357	22.8-36.5
<b>1-1/2 in</b> 38.1 mm	1-7/8-12	250-400	339-542	34.6-55.3

<b>Split Flange Mounting Bolts</b>			
Size	Pound- Feet	Newton metres	Kilogram metres
5/16-18	15-20	20-27	2.1-2.8
3/8-16	20-25	26-33	2.8-3.5
7/16-14	35-45	47-61	4.7-6.2
1/2-13	55-65	74-88	7.6-9.0
5/8-11	140-150	190-203	19.4-20.7

811361A

## NOTES

# Section 1002

## MAINTENANCE AND LUBRICATION

Written In *Clear  
And  
Simple  
English*




REF NO. SERVICE POINT	SERVICE REQUIRED	FREQUENCY
1 Engine Oil Dipstick 2 Engine Air Cleaner 3 Radiator 4 Hydraulic Oil Reservoir 5 Steering Cylinder (both ends) 6 Center Pivot Grease Fitting (2 places) 7 Slide Grease Fitting (2 places if equipped) 8 Bucket Cylinder Pivots 9 Lift Cylinder Pivots 10 Lift Arm Pivots 11 Bucket Leveler Arm (3 places) 12 Bucket Pivots	*Check level - fill as required Check and service as required Check coolant level. Add coolant as required Check level - fill as required Lubricate with No. 2 Lithium Base Grease  Lubricate with No. 2 Lithium Base Grease  Lubricate with No. 2 Lithium Base Grease  Lubricate with No. 2 Lithium Base Grease Lubricate with No. 2 Lithium Base Grease	Daily or after every 10 hours of operation
13 Fuel Tank	Fill at the end of each day of operation	Daily
14 Engine Oil Drain	*Drain and fill with new oil	After every 50 hours of operation
15 Battery	Check and service as required	After every 50 hours of operation or weekly
16 Engine Oil Filter 17 Drive Shaft Grease Fitting 18 Front and rear U-Joint Grease Fitting 19 Front and rear Axles 20 2-Speed Transmission	*Replace with new filter Lubricate with No. 2 Lithium Base Grease Lubricate with No. 2 Lithium Base Grease  Check fluid level - fill as required Check fluid level - fill as required	After every 100 hours of operation
21 Hydraulic Oil Filters 22 Fuel Filter	**Replace with new filters Replace with new filter	After every 250 hours of operation
23 Hydraulic Oil Reservoir Drain 24 Front and Rear Axle Drain 25 2-Speed Transmission Drain	Drain and fill with new oil  Drain and fill with new oil Drain and fill with new oil	After every 100 hours of operation or yearly
26 Radiator Drain	Drain and flush cooling system. Fill with new coolant	After every 2000 hours or yearly

\*The engine oil and filter must be changed initially after the first 25 hours of operation. Check oil level at 3 hour intervals during this period.

\*\*The hydraulic oil filters must be changed initially after the first 25 hours of operation.

# FORKLIFT SERVICE POINTS



820078

REF NO. SERVICE POINT	SERVICE REQUIRED	FREQUENCY
1 Engine Oil Dipstick 2 Engine Air Cleaner 3 Radiator 4 Hydraulic Oil Reservoir 5 Steering Cylinder (both ends) 6 Center Pivot Grease Fitting (2 places) 7 Slide Grease Fitting (2 places if equipped) 8 Mast Tilt Pivots (2) 9 Forklift Chain 10 Mast Tilt Cylinders	*Check level - fill as required Check and service as required Check coolant level. Add coolant as required Check level - fill as required Lubricate with No. 2 Lithium Base Grease Lubricate with Case Chain and Cable Lubricant (Part No. B17082) Lubricate with Case Chain and Cable Lubricant (Part No. B17082)	Daily or after every 10 hours of operation
11 Fuel Tank	Fill at the end of each day of operation	Daily
12 Engine Oil Drain	*Drain and fill with new oil	After every 50 hours of operation
13 Battery	Check and service as required	After every 50 hours of operation or weekly
14 Engine Oil Filter 15 Drive Shaft Grease Fitting 16 Front and Rear U-Joint Grease Fitting 17 Front and Rear Axles 18 2-Speed Transmission	*Replace with new filter Lubricate with No. 2 Lithium Base Grease Lubricate with No. 2 Lithium Base Grease Check fluid level - fill as required Check fluid level - fill as required	After every 100 hours of operation
19 Hydraulic Oil Filters 20 Fuel Filter 21 Forklift Mast Slides	**Replace with new filters Replace with new filter Lubricate with No. 2 Lithium Base Grease	After every 250 hours of operation
22 Hydraulic Oil Reservoir Drain 23 Front and Rear Axle Drain 24 2-Speed Transmission Drain	Drain and fill with new oil Drain and fill with new oil Drain and fill with new oil	After every 1000 hours of operation or yearly
25 Radiator Drain	Drain and flush cooling system. Fill with new coolant	After every 2000 hours or yearly

\*The engine oil and filter must be changed initially after the first 25 hours of operation. Check oil level at 3 hour intervals during this period.

\*\*The hydraulic oil filters must be changed initially after the first 25 hours of operation.

## FLUIDS AND LUBRICANTS

Component	Capacity		Specifications
	U.S.	Metric	
Fuel tank	13.2 gallons	49.8 litres	Diesel Fuel, See Operators Manual
Engine crankcase, 1.8 litre diesel engine			Case HDM Oil Alternate engine oil: CD-Commercial class D
Without filter change	4.0 quarts	3.8 litres	Above 68° F (20° C) ..... SAE 30
With filter change	5.0 quarts	4.8 litres	15 to 85° F (-10 to 30° C) ..... SAE 20W
Below 32° F (0° C) ..... SAE 10W			
Engine crankcase, 2.1 litre diesel engine			Case HDM Oil Alternate engine oil: CD-Commercial class D
Without filter change	6.0 quarts	5.7 litres	Above 104° F (40° C) ..... SAE 40
With filter change	7.0 quarts	6.7 litres	25 to 104° F (-5 to 40° C) ..... SAE 30
Below 10° F (-15° C) ..... SAE 10W			
Hydraulic oil reservoir	10.0 gallons	38 litres	Automatic transmission fluid (ATF) type "F"
Hydraulic system	15.0 gallons	57 litres	
Transmission	2.7 pints	1.3 litres	Multipurpose Gear Lubricant (API-GL-5) SAE 80-90
Front and Rear Axles (each)	4.0 quarts	3.8 litres	Multipurpose Gear Lubricant (API-GL-5) SAE 80 - 90. <b>IMPORTANT:</b> <i>If the axle has a limited slip differential, the lubricant must have a limited slip additive.</i>
Engine cooling system			Mix an ethylene glycol coolant with water for the lowest outside temperature that is expected. The mixture must be at least 50/50.
1.8 litre diesel engine	8.0 quarts	7.6 litres	
2.1 litre diesel engine	10.0 quarts	9.5 litres	
Battery	As required		Add drinking water or distilled water
Grease fittings	As required		Number 2 Lithium base grease



# **1.8 Litre Diesel Engine**

## ***REPAIR OPERATION MANUAL***

Publication Part No. AKM 3934 (2nd Edition)

Published by Austin Morris Limited  
A subsidiary of BL Cars Limited

© BL CARS LIMITED 1979

## **SPECIFICATION**

Purchasers are advised that the specification details set out in this Manual apply to a range of engines and not to any particular engine. For the specification of any particular engine purchasers should consult their supplier.

The manufacturers reserve the right to vary their specifications with or without notice, and at such times and in such manner as they think fit. Major as well as minor changes may be involved in accordance with the manufacturer's policy of constant product improvement.

Whilst every effort is made to ensure the accuracy of the particulars contained in this Manual, neither the manufacturer nor the supplier, by whom this Manual is supplied, shall in any circumstances be held liable for any inaccuracy or the consequences thereof.

## **COPYRIGHT**

© BL Cars Limited 1979

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form, whether electronic, or mechanical, or by photocopying, recording or other means without prior written permission of BL Cars – Service and Parts, Cowley, Oxford.

## CONTENTS

	Operation No.	Page No.
General Specification Data . . . . .	04	7
Engine Tuning Data . . . . .	05	9
Torque Wrench Settings . . . . .	06	9
Service Lubricants, Fuel, Fluids and Capacities . . . . .	09	10

### MAINTENANCE 10

#### Routine Maintenance Operations

Engine . . . . .		10-1
Fuel System . . . . .		10-2
Electrical . . . . .		10-2
Service Operations . . . . .		10-2

### ENGINE

#### Camshaft

– bearings – remove and refit . . . . .	12.13.13	12-2
– locating plate – remove and refit (see 12.65.12) . . . . .	12.13.23	12-13
– remove and refit (see 12.29.57) . . . . .	12.13.02	12-1

#### Connecting rods and pistons

– overhaul . . . . .	12.17.10	12-5
– remove and refit . . . . .	12.17.01	12-4

#### Crankshaft

– end-float – check and adjust . . . . .	12.21.26	12-6
– front oil seal – remove and refit (see 12.65.05) . . . . .	12.21.14	12-13
– rear oil seal – remove and refit . . . . .	12.21.20	12-5
– remove and refit . . . . .	12.21.33	12-6
– spigot bush – remove and refit . . . . .	12.21.45	12-7

#### Cylinder head

– gasket – remove and refit . . . . .	12.29.02	12-9
– overhaul . . . . .	12.29.19	12-10
– rocker shaft – overhaul . . . . .	12.29.55	12-11
– rocker shaft – remove and refit . . . . .	12.29.54	12-11
– tappets – remove and refit . . . . .	12.29.57	12-1
– valve clearance – check and adjust . . . . .	12.29.48	12-11

#### Cylinder liners – remove and refit . . . . .

12-8

#### Engine

– front mounting plate gasket – remove and refit . . . . .	12.25.10	12-8
– governed speeds – check and adjust . . . . .	12.49.12	12-12

#### Flywheel

– gearbox adaptor plate – remove and refit (see 12.21.20) . . . . .	12.53.03	12-5
– remove and refit (see 12.21.20) . . . . .	12.53.07	12-5

#### Lubrication

– oil pick-up strainer – remove and refit (see 12.10.30) . . . . .	12.60.20	12-1
– oil pressure relief valve – remove and refit . . . . .	12.60.56	12-13
– oil pump drive shaft – remove and refit . . . . .	12.10.30	12-1
– oil pump – overhaul . . . . .	12.60.32	12-12
– oil pump – remove and refit (see 12.10.30) . . . . .	12.60.26	12-1

#### Timing gears, chains and tensioners

– cover oil seal – remove and refit . . . . .	12.65.05	12-13
– cover – remove and refit (see 12.65.05) . . . . .	12.65.01	12-13
– fuel injection pump gear – remove and refit . . . . .	12.10.25	12-1
– fuel injection pump hub – remove and refit . . . . .	12.10.26	12-1
– tensioner – remove and refit (see 12.65.12) . . . . .	12.65.28	12-13
– timing chain and gears – remove and refit . . . . .	12.65.12	12-13
– timing chain – remove and refit . . . . .	12.65.14	12-13

*continued*

## CONTENTS

	Operation No.	Page No.
<b>FUEL SYSTEM</b>		
Fuel filter element – remove and refit . . . . .	19.25.07	19–3
Fuel system – bleeding . . . . .	19.50.07	19–11
Injection pump		
– overhaul . . . . .	19.30.19	19–6
– remove and refit . . . . .	19.30.07	19–5
– timing – check and adjust . . . . .	19.30.01	19–5
Injectors		
– overhaul . . . . .	19.60.08	19–12
– remove and refit . . . . .	19.60.01	19–12
Lift pump		
– overhaul . . . . .	19.45.16	19–11
– remove and refit . . . . .	19.45.09	19–11
<b>COOLING SYSTEM</b>		
Coolant – drain and refill . . . . .	26.10.01	26–1
Fan		
– belt – remove and refit . . . . .	26.20.07	26–1
– blades – remove and refit . . . . .	26.25.01	26–1
– pulley – remove and refit . . . . .	26.25.01	26–1
Thermostat		
– remove and refit . . . . .	26.45.01	26–1
– test . . . . .	26.45.09	26–1
Water pump – remove and refit . . . . .	26.50.01	26–1
<b>CLUTCH</b>		
Clutch assembly		
– overhaul . . . . .	33.10.08	33–1
– remove and refit . . . . .	33.10.01	33–1
Clutch driven plate – remove and refit (see 33.10.01) . . . . .	33.10.02	33–1
Release bearing – remove and refit . . . . .	33.25.12	33–2
<b>ELECTRICAL</b>		
Alternator		
– overhaul . . . . .	86.10.08	86–2
– remove and refit . . . . .	86.10.02	86–2
Service precautions . . . . .	86.01.01	86–1
Starter motor		
– overhaul . . . . .	86.60.13	86–3
– remove and refit . . . . .	86.60.01	86–3
Starter solenoid		
– remove and refit . . . . .	86.60.08	86–3
Testing the charging circuit . . . . .	86.01.02	86–1
<b>SERVICE TOOLS</b> . . . . .		End of manual

## INTRODUCTION

The purpose of this Manual is to assist skilled mechanics in the efficient repair and maintenance of the range of engines given on the title-page. The procedures detailed, carried out in the sequence given and using the appropriate service tools, will enable the operations to be completed in the time stated in the Repair Operation Times.

### Indexing

The contents pages list the titles and reference numbers of the divisions in alphabetical order.

### Operation Numbering

Each operation is followed by the number allocated to it in a master index. The number consists of six digits arranged in three pairs.

The master index of operations has been compiled for universal application to engines manufactured by BL Cars Limited and therefore continuity of the numbering sequence is not maintained throughout this Manual.

Each instruction within an operation has a sequence number, and to complete the operation in the minimum time it is essential that these instructions are performed in the numerical sequence commencing at 1 unless otherwise stated. Where applicable, the sequence numbers identify the components in the appropriate illustration.

### Service Tools

Where performance of an operation requires the use of a service tool, the tool number is quoted under the operation heading and is repeated in the instruction involving its use.

An illustrated list of all service tools necessary to complete the operations described in the Manual is also included.

### Definitions

Remove and refit — the removing of an existing part, fitting of a new or replacement part.  
Overhaul — includes removing a component, fitting new parts, adjusting and its refitting.

### References

The water pump end of the engine is referred to as the front.

To reduce repetition, operations covered in this Manual do not include reference to testing the engine after repair. It is essential that work is inspected and tested after completion, particularly where safety-related items are concerned.

### Dimensions

The dimensions quoted are to design engineering specification. Alternative unit equivalents have been converted from the original specification.

During the period of running-in from new, certain adjustments may vary from the specification figures given in this Manual. These adjustments will be reset by the supplier after After Sales Service, and thereafter should be maintained at the figures specified in the Manual.

## REPAIRS AND REPLACEMENTS

When service parts are required it is essential that only genuine **BL** or **Unipart** replacements are used.

Attention is particularly drawn to the following points concerning repairs and the fitting of replacements parts and accessories:

The performance and durability of the engine may be impaired if other than genuine parts are fitted. In certain territories, legislation prohibits the fitting of parts not to the engine manufacturer's specification. Torque wrench setting figures given in this Manual must strictly adhered to. Locking devices, where specified, must be fitted. If the efficiency of a locking device is impaired during removal, it must be renewed. When purchasing accessories while travelling abroad ensure that the accessory and its fitted location conform to requirements existing in their country of origin. The engine warranty may be invalidated if the fitting of other than genuine **BL** or **Unipart** parts.

All **BL** and **Unipart** replacements have the full backing of the factory warranty.

## SERVICE PARTS

Genuine **BL** and **UNIPART** Service parts are designed and tested for your engine and have the full backing of the **BL** Factory Warranty. **ONLY WHEN GENUINE BL or UNIPART SERVICE PARTS ARE USED CAN RESPONSIBILITY BE CONSIDERED UNDER THE TERMS OF THE WARRANTY.**

Genuine parts are supplied in cartons bearing one or both of these symbols:



ABBREVIATIONS AND SYMBOLS IN THIS MANUAL

Across flats (bolt size)	A.F.	Gallons (Imperial)	gal	Miles per gallon		Revolutions per minute	rev/min
After bottom dead centre	A.B.D.C.	Gallons (U.S.)	U.S. gal	Miles per hour	m.p.h.	Right-hand	R.H.
After top dead centre	A.T.D.C.	Grammes (force)	gf	Millimetres	mm	Right-hand steering	R.H.Stg.
Alternating current	a.c.	Grammes (mass)	g	Millimetres of mercury	mmHg	"	"
Amperes	A	High compression	h.c.	Minimum	min.	Second (angle)	"
Amperè-hour	Ah	High tension (electrical)	h.t.	Minus (of tolerance)	-	Second (numerical order)	2nd
Atmospheres	Atm	Horse-power	hp	Minute (of angle)	-	Single carburetter	SC
Before bottom dead centre	B.B.D.C.	Hundredweight	cwt	Negative (electrical)	-	Society of Automobile Engineers	S.A.E.
Before top dead centre	B.T.D.C.	Inches	in	Newton metre	Nm	Specific gravity	sp. gr.
Bottom dead centre	B.D.C.	Inches of mercury	inHg	Number	No.	Square centimetres	cm <sup>2</sup>
Brake horse power	b.h.p.	Independent front suspension	i.f.s.	Ounces (force)	ozf	Square inches	in <sup>2</sup>
Brake mean effective pressure	b.m.e.p.	Internal diameter	i.dia.	Ounces (mass)	oz	Standard	std.
British Standards	B.S.	Kilogrammes (force)	kgf	Ounce inch (torque)	ozf in	Standard wire gauge	s.w.g.
Carbon monoxide	CO	Kilogrammes (mass)	kg	Outside diameter	o.dia	Synchronizer/synchromesh	synchro.
Centigrade (Celsius)	C	Kilogramme centimetre	kgf cm	Overdrive	O/D	Third	3rd
Centimetres	cm	Kilogramme metres	kgf m	Paragaphs	para.	Top dead centre	T.D.C.
Cubic centimetres	cm <sup>3</sup>	Kilogrammes per square centimetre	kgf/cm <sup>2</sup>	Part Number	Part No.	Twin carburetters	TC
Cubic inches	in <sup>3</sup>	Kilometres per hour	km/h	Percentage	%	United Kingdom	UK
Cycles per minute	c/min	Kilovolts	kV	Pints (Imperial)	pt	Volts	V
Degree (angle)	deg. or °	King pin inclination	k.p.i.	Pints (U.S.)	U.S. pt	Watts	W
Degree (temperature)	deg. or °	Left-hand	L.H.	Plus or minus	±	Screw threads	
Diameter	dia.	Left-hand steering	L.H.Stg.	Plus (tolerance)	+	American Standard Taper Pipe	N.P.T.F.
Direct current	d.c.	Left-hand thread	L.H.Thd.	Positive (electrical)	+	British Association	B.A.
Fahrenheit	F	Low compression	L.C.	Pounds (force)	lbf	British Standard Fine	B.S.F.
Feet	ft	Low tension	l.t.	Pounds (mass)	lb	British Standard Pipe	B.S.P.
Feet per minute	ft/min	Maximum	max.	Pounds feet (torque)	lbf ft	British Standard Whitworth	B.S.W.
Fifth	5th	Metres	m	Pounds per square inch	lbf/in <sup>2</sup>	Unified Coarse	U.N.C.
Figure (illustration)	Fig.	Mimature Edison Screw	MES	Radius	r	Unified Fine	U.N.F.
First	1st			Ratio	:		
Fourth	4th			Reference	ref.		



**Valves**

Seat angle: Inlet .....  
 Exhaust .....  
 Head diameter: Inlet .....  
 Exhaust .....  
 Stem diameter: Inlet .....  
 Exhaust .....  
 Stem to guide clearance: Inlet .....  
 Exhaust .....  
 Valve lift: Inlet and exhaust .....  
 Valve stand down:  \*\* .....  
 .....

**Valve guides**

Length: Inlet and exhaust .....  
 Outside diameter: Inlet and exhaust .....  
 Inside diameter (reamed after fitting):  
 Inlet and exhaust .....  
 Fitted height above spring seat: Inlet  
 and exhaust .....  
 Interference fit in head: Inlet and  
 exhaust .....

**Valve springs**

Free length .....  
 Fitted length .....  
 Load at fitted length .....  
 Load at top of lift .....  
 Number of working coils .....

**Valve timing**

Timing marks .....  
 Rocker clearance:  \*\*Running .....  
 Timing .....  
 Running .....  
 Timing .....

**Inlet valve:**

Opens .....  
 Closes .....  
**Exhaust valve:** Opens .....  
 Closes .....

**Lubrication**

System .....  
 System pressure: Running .....  
 Idling .....  
 Oil pump .....  
 Oil filter .....  
 Oil pressure relief valve .....  
 Relief valve springs: Free length .....  
 Fitted length .....

45° .....  
 45° .....  
 1.434 to 1.439 in (36.42 to 36.55 mm)  
 1.207 to 1.212 in (30.64 to 30.78 mm)  
 0.3428 to 0.3433 in (8.71 to 8.73 mm)  
 0.3422 to 0.3427 in (8.69 to 8.70 mm)  
 0.0008 to 0.0020 in (0.02 to 0.05 mm)  
 0.0014 to 0.0026 in (0.03 to 0.06 mm)  
 0.384 in (9.75 mm)  
 0.0445 to 0.0505 in (1.13 to 1.28 mm)  
 0.020 to 0.030 in (0.508 to 0.762 mm)  
 2.22 in (56.39 mm)  
 0.5635 to 0.5640 in (14.31 to 14.33 mm)  
 0.3441 to 0.3448 in (8.74 to 8.76 mm)  
 0.55 to 0.56 in (13.9 to 14.2 mm)  
 0.0005 to 0.00175 in (0.01 to 0.04 mm)

1.92 in (48.77 mm)  
 1.44 in (36.57 mm)  
 82 lbf, 37.19 kgf, 364 N  
 142 lbf, 64.4 kgf, 631 N  
 4 1/2

Dimples on timing wheels, marks on  
 flywheel

0.017 in (0.43 mm)  
 0.024 in (0.61 mm)  
 0.014 in (0.36 mm)  
 0.016 in (0.41 mm)

.....  
 .....  
 8° B.T.D.C. 8° B.T.D.C.  
 42° A.B.D.C. 44° A.B.D.C.  
 60° B.B.D.C. 50° B.B.D.C.  
 12° A.T.D.C. 10° A.T.D.C.

Wet sump, pressure fed  
 3.5 bar, 50 lbf/in<sup>2</sup>, 3.52 kgf/cm<sup>2</sup>  
 1.0 bar, 15 lbf/in<sup>2</sup>, 1.05 kgf/cm<sup>2</sup>  
 Rotor type  
 Full flow: disposable cartridge type  
 3.5 bar, 50 lbf/in<sup>2</sup>, 3.52 kgf/cm<sup>2</sup>  
 3 in (76 mm)  
 2.156 in (54.77 mm)  
 15.5 to 16.5 lbf, 7.0 to 7.4 kgf, 69 to 73 N

**FUEL SYSTEM**

Fuel injection pump .....  
 Type .....  
 Injection timing .....  
 Fuel lift pump .....  
 Fuel injectors .....  
 Nozzle type .....  
 Nozzle holder type .....  
 Opening pressure .....  
 Main fuel filter .....  
 Type .....  
 Heater plugs .....  
 Champion .....

C.A.V.  
 DPA.3247F180, DPA.3247F260,  
 DPA.3342F710 or DPA3342F720  
 18° B.T.D.C.  
 A.C. Mechanical  
 C.A.V. Pintaux  
 BDN.OSPC.6651  
 BKB.35SD.5188  
 135 Atm  
 C.A.V.  
 FSS83 6B130  
 AG32

**COOLING SYSTEM**

Thermostat:  
 Standard .....  
 Hot climates .....  
 Cold climates .....  
 Fan belt tension .....

82° C (180° F)  
 72° C (162° F)  
 88° C (190° F)  
 See 'Maintenance'

**CLUTCH**

Type .....  
 Clutch plate diameter .....

Single dry plate  
 9 in (228.6 mm)

**ELECTRICAL**

**Alternator**

Type: Lucas .....  
 Output at 14V and 6000 rev/min .....  
 Rotor winding resistance at 20°C  
 (68°F) .....  
 Maximum permissible rotor speed .....  
 Brush length new .....  
 Brush spring tension, brush face flush  
 with brush box .....

16ACR 18ACR  
 34 A 43 A  
 3.3 ohm ± 5% 3.2 ohm ± 5%  
 15 000 rev/min 15 000 rev/min  
 0.5 in (12.7 mm) 0.5 in (12.7 mm)  
 3 to 4 N, 3 to 4 N,  
 9 to 13 ozf, 9 to 13 ozf,  
 255 to 368 gf 255 to 368 gf

**Starter motor**

Type: Lucas .....  
 Light running current .....  
 Lock torque at 940 amp .....  
 Minimum brush length .....  
 Brush spring tension .....

M45G pre-engaged  
 100 amp at 5000 to 6000 rev/min  
 29 lbf ft (4.01 kgf m, 39 Nm)  
 0.31 in (8.0 mm)  
 42 ozf (1.2 kgf, 11 N)

\*\*   see page 7

## ENGINE TUNING DATA

### ENGINE — Diesel 1.8 litre

Type	18- /-----/D
Displacement	109.7 in <sup>3</sup> (1798 cm <sup>3</sup> )
Injection order	1, 3, 4, 2
Compression ratio	21.47 : 1
Valve rocker clearance (cold) <input type="checkbox"/> **	0.017 in (0.43 mm)
	<input checked="" type="checkbox"/> 0.014 in (0.36 mm)
Idle speed:	
Engines with hydraulic governor	650 rev/min minimum †
Engines with mechanical governor	800 rev/min minimum †
Maximum governed light running speed	4,900 rev/min †

### Fuel injection pump

Make and type	C.A.V. DPA.3247F180, DPA.3247F260, DPA.3342F710 or DPA.3342F720
Injection pump timing	18° B.T.D.C.

### Fuel injectors

Make and type	C.A.V. Pintaux
Nozzle type	BDN.OSPC.6651
Nozzle holder type	BKB.35SD.5188
Opening pressure	135 Atm

### Heater plugs

Make and type	Champion AG32
---------------	---------------

† For exact settings see injection pump code and/or Equipment manufacturers settings.

\*\*   see page 7

## TORQUE WRENCH SETTINGS

	lbf ft	kgf m	Nm
Cylinder head nuts	75	10.4	102
Rocker bracket nuts	25	3.5	34
Manifold nuts	15	2.1	20
Big-end nuts	35	4.8	47
Main bearing set screws	75	10.4	102
Flywheel bolts	40	5.5	54
Timing cover bolts: $\frac{1}{4}$ in	6	0.8	8
	$\frac{5}{16}$ in	2.8	27
	$\frac{3}{8}$ in	2.8	27
Rear plate bolts: $\frac{1}{2}$ in	20	2.8	27
	$\frac{5}{8}$ in	4.1	41
	$\frac{3}{4}$ in	9.0	88
Camshaft nut	65	9.0	88
Crankshaft bolt	115*	16	156
Idle gear hub bolt	30	4.1	41
Cylinder side cover set screws	4	0.5	5
Rocker cover nuts	4	0.5	5
Sump bolts	6	0.8	8
Oil filter adaptor	30	4.1	41
Oil pump nuts	16	2.2	22
Oil release valve — domed nut	45	6.2	61
Starter motor bolts	35	4.8	47
Clutch to flywheel	25	3.5	34
Fuel lift pump nuts	12	1.7	16
Injector nozzle nut	50	6.9	68
Injection pump nuts	18	2.5	24
Injector nuts	12	1.7	16
Injection pump driving flange set screws	10	1.4	14
Water pump bolts	17	2.3	23
Water pump pulley set screws	18	2.5	24
Alternator pulley nut	27	3.7	36
Thermal transmitter	16	2.2	22

\*Discard lock washer

## SERVICE LUBRICANTS, FUEL, FLUIDS AND CAPACITIES

### Lubricants

The lubrication system of your new engine is filled with high quality oil. You should always use a high quality oil of the correct viscosity range in the engine during subsequent maintenance operations or when topping up. The use of oils not to the correct specification can lead to high oil and fuel consumption and ultimately to damage to components.

Oil to the correct specification contains additives which disperse the corrosive acids formed by combustion and also prevent the formation of sludge which can block oilways. **Additional oil additives should not be used.** Service intervals must be adhered to.


### Engine

Use a well known brand of oil to B.L.S. OL.02 or MIL-L-2104B or MIL-L-46152 or A.P.I. SE/CC quality, with a viscosity band spanning the temperature range of your locality.

The use of monograde oils is permissible providing that it is of the correct viscosity for the ambient temperature of your locality. It should also be of the same quality MIL-L-46152, MIL-L-2104B or A.P.I. SE/CC as the preferred multigrade oils.

For sustained high speed operation or operation for long periods in a high ambient temperature, the use of a multigrade oil of the correct viscosity and quality is recommended.


Multigrade Oils Viscosity/Temperature Ranges



### S.A.E. Viscosity

8NA015A

Monograde Oils Viscosity/Temperature Ranges



### S.A.E. Viscosity

9NC004

### Fuel

Use fuel oils generally known as Diesel fuel oil, distillate Diesel fuel, automotive gas oil or Derv fuel conforming to British Standard 2869: 1967, Class A1 or A2.

### Anti-Freeze Solutions

Use UNIPART UNIVERSAL Anti-freeze to protect the cooling system.

If UNIPART Universal is not available any anti-freeze conforming to Specification B.S. 3151 or 3152 may be used. Anti-freezes to these specifications are compatible with UNIPART Universal and can be used with it. UNIPART Universal should not be mixed with other universal anti-freezes.

The overall anti-freeze concentration should not fall below 30% by volume, to ensure that the anti-corrosion properties of the coolant are maintained.

After filling with anti-freeze solution, attach a warning label in a prominent position stating the type of anti-freeze contained in the cooling system to ensure that the correct type is used for topping-up.

Solution	Commences to freeze		Frozen solid
	°C	°F	
33 1/2	-19	-2	-36
50	-36	-33	-48
			-33
			-53





### Capacities (approx.)

Engine sump (including filter) . . . . . 8 1/4 pt, 4.68 litres, 9.9 U.S. pt  
 Filter only . . . . . 1 1/4 pt, 0.71 litre, 1.5 U.S. pt

**LUBRICANTS**

		FORECOURT OILS				FLEET OIL	
		MIL-L-2104B A.P.I.-SE/CC or MIL-L-46152					
Minimum performance level	Temperatures above -10°C (10°F)	Temperatures -20°C (-5°F) to 10°C (50°F)	Temperatures below -10°C (10°F)	Temperatures above 10°C (10°F)	Temperatures -20°C (-5°F) to 10°C (50°F)	Temperatures below -10°C (10°F)	
<b>CLIMATIC CONDITIONS</b>							
<b>UNIPART</b>	Unipart Super Multigrade Motor Oil 15W/50						
<b>BP</b>	BP Super Visko-Static 20W/50 BP Vanellus C3 Multi-grade BP Visko 2000*	BP Super Visko-Static 10W/30 or 10W/40*	BP Super Visko-Static 5W/20*	BP Vanellus M 20-50 BP Vanellus C3 Multigrade	BP Vanellus M 10W/30 or 10W/40*	BP Super Visko-Static 5W/20*	
<b>CASTROL</b>	Castrol GTX 20W/50 Castrol GTX-2 15W/20	Castrolite 10W/30 or 10W/40 Castrol GTZ 10W/40 (Sweden)	Castrol Super GTX 5W/30 (Canada) Castrol GTZ 5W/40 (Finland)	Castrol Deusol RX Super 15W/40			
<b>DUCKHAMS</b>	Duckhams Q Motor Oil 20W/50						
<b>ESSO</b>	Esso Uniflo 15W/50	Esso Uniflo 10W/40	Esso Uniflo 5W/40	Esso Lubex HDX Plus 20W/50 Esso Uniflo 15W/50	Esso Lubex HDX Plus 10W/30 Esso Uniflo 10W/40	Esso Lubex MDX Plus 10W/30 Esso Uniflo 5W/40	
<b>MOBIL</b>	Mobil Super 15W/50	Mobil SHC 10W/50	Mobil 1 5W/20 Mobil 5W/20	Mobil Delvac Super 15W/40 Delvac Special 20W/50	Mobil Delvac Special 10W/30	Mobil 5W/20	
<b>PETROFINA</b>	Fina Supergrade Motor Oil 20W/50	Fina Supergrade Motor Oil 10W/40		Fina Delta Multigrade 20W/50	Fina Delta Multigrade 10W/30		
<b>SHELL</b>	Shell Super Motor Oil U.K. 20W/50 Europe 15W/50	Shell Super Motor Oil 10W/40 (Norway, Sweden, Canada) 10W/50 (Rest of Europe, U.S.A.)	Shell Super Motor Oil 5W/40 (Finland) 5W/30 (Canada)	Rotella SX Rotella TX 20W/40 Rotella SX 10W/20 SX 20W/30 (Sweden)	Rotella TX 10W/30 Rotella SX 10W/20 (Sweden)	Rotella TX 5W/20 (Finland, Canada)	
<b>TEXACO</b>	Texaco URSA Oil LA 15W/40			Eurotex Motor Oil HD 20W/50	Eurotex Motor Oil HD 10W/30		

\*Not available in the U.K.



## ENGINE

### Lubrication

#### Checking oil level


- 1 Maintain the level between the 'MIN' and 'MAX' mark on the dipstick.

#### Draining and refilling

- 2 Drain the oil while the engine is warm: check the drain plug copper washer before refitting.
- 3 Refill with the correct quantity and grade of oil. Run the engine for a short while, then allow it to stand for a few minutes before re-checking the level.

#### Disposable cartridge filter renewal

- 4 Unscrew the old cartridge with a tourniquet type wrench; a quantity of oil will be released. Discard the cartridge and seal (5).
- 5 Wet the new seal with engine oil and ensure that it is located correctly in its groove in the new cartridge.
- 6 Screw the new cartridge to the filter head, using hand force only.
- 7 Start the engine and check the filter for leaks. Stop the engine, and re-check the oil level after waiting for a few minutes.



#### Valve rocker adjustment

- 1 Remove the rocker cover.
- 2 Check the clearance between the valve rocker arms and valve stems with a feeler gauge.




Clearance: see 'ENGINE TUNING DATA'.

The gauge should be a sliding fit when the engine is cold.

Check the clearance of each valve in the following order:

Check No. 1 valve with No. 8 fully open.	3	3	3	6	3
"	5	2	3	4	3
"	2	3	3	7	3
"	8	3	3	1	3
"	6	3	3	3	3
"	4	3	3	5	3
"	7	3	3	2	3

- 3 Slacken the locknut.
- 4 Rotate screw, clockwise to decrease or anti-clockwise to increase the clearance.
- 5 Retighten the locknut when the clearance is correct, holding the screw against rotation.
- 6 Refit the rocker cover checking that the gasket is serviceable.



**DRIVE BELT TENSION**

**Checking**  
 1 Use one of the following methods of checking the belt tension:

- a Use a torque spanner and apply a load of 14.9 to 15.6 Nm (1.5 to 1.6 kgf m, 11.0 to 11.5 lbf ft) in a clockwise direction to the alternator pulley retaining nut. If the belt tension is correct the belt will slip at this torque loading.
- b Apply a load of 33.4 to 36.4 N (3.3 to 3.6 kgf, 7.5 to 8.2 lbf) at right angles to the belt midway between pulleys. The belt should deflect 6 mm (0.25 in). It is important that the belt tension is set correctly.

**NOTE:** Fit a new belt with a moderate degree of tension, run the engine for five minutes at 1000 rev/min, stop the engine then set the belt to the correct tension.

**Adjusting**

- 2 Slacken the alternator securing bolts.
- 3 Slacken the bolt securing the adjusting link to the alternator.
- 4 Slacken the adjusting link to engine securing nut.
- 5 Move the alternator to the required position: avoid over-tightening. Apply any leverage necessary to the alternator drive end bracket only, using a wood or soft metal lever.
- 6 Tighten the securing nuts and bolts.

**SERVICE OPERATIONS — Summary**

Every 150 hours  
 Change engine oil

Operation	Every 300 hours	Every 600 hours
Check/adjust drive belt tension.....	X	X
Check/adjust valve clearances.....	X	X
Renew main fuel filter element.....	X	X
Change engine oil and filter element.....	X	X
Test injectors for spray.....	X	X
Remove heater plugs and clean carbon from each plug orifice in cylinder head — check heater plug operation.....		X
Renew oil filler cap.....		X
Clean/renew air filter element.....	X	X
Check governor settings.....	X	X
Retorque cylinder head nuts.....	X	X

**NOTE:** More frequent air cleaner element servicing may be necessary in dirty/dusty conditions.

**FUEL SYSTEM**

**Air cleaner elements**

Renew the air cleaner element. In dusty operating conditions the element may require changing more frequently than recommended.

**Removing**

- 1 Unscrew the wing nut, remove the fibre washer and withdraw the cover.
- 2 Withdraw and discard the element.
- 3 Clean the interior of the container.

**Refitting**

- 4 Fit the element.
- 5 Check that the sealing ring is in good condition.
- 6 Refit the cover, fibre washer and nut.