

Product: Case 521E TIER 3 Wheel Loader Service Repair Manual 84243970  
Full Download: <https://www.arepairmanual.com/downloads/case-521e-tier-3-wheel-loader-service-repair-manual-84243970/>



**SERVICE MANUAL  
WHEEL LOADER  
521E  
TIER 3**


**84243970**  
(Replaces 87728450)

Sample of manual. Download All 896 pages at:  
<https://www.arepairmanual.com/downloads/case-521e-tier-3-wheel-loader-service-repair-manual-84243970/>  
Revised 2008  
Issued February 2008

Product: Case 521E TIER 3 Wheel Loader Service Repair Manual 84243970

Full Download: <https://www.arepairmanual.com/downloads/case-521e-tier-3-wheel-loader-service-repair-manual-84243970/>

**Please cut where indicated and place the label on the spine of the binder**



Sample of manual. Download All 896 pages at:

<https://www.arepairmanual.com/downloads/case-521e-tier-3-wheel-loader-service-repair-manual-84243970/>

**84243972**

**521E Wheel Loader  
Service Manual  
84243970 (Replaces 87728450)**

**Table of Contents**

Description	Section No.	Form No.
<b>General</b>		
Section Index - General	5-10830	
Standard Torque Specifications	1001	8-71603
Fluids and Lubricants	1002	5-10840
Metric Conversion Chart	1003	7-52950
<b>Engines</b>		
Section Index - Engines	5-10850	
Engine and Radiator Removal and Installation	2000	5-10860
Stall Tests	2002	5-10870
After Cooler	2003	6-49850
For Engine Repair, See the Engine Service Manual		87630273
<b>Fuel System</b>		
Section Index - Fuel System	5-11830	
For Fuel System Repair, See the Engine Service Manual		87630273
<b>Electrical</b>		
Section Index - Electrical	5-10880	
Removal and Installation of Starter and Alternator	4001	5-10890
Electrical Specifications and Troubleshooting	4002	5-11190
Batteries	4003	6-42331
Instrument Cluster	4005	5-10900
<b>Steering</b>		
Section Index - Steering	5-10911	
Removal and Installation of Steering Components	5001	5-10920
Steering Specifications, Pressure Checks, and Troubleshooting	5002	5-7410
Steering Cylinders	5005	5-10930
Center Pivot	5006	5-10940
Auxiliary Steering Motor and Pump	5008	5-10950
Joystick Steering	5009	5-17000

**521E Wheel Loader  
Service Manual  
84243970 (Replaces 87728450)**

**Table of Contents**

Description	Section No.	Form No.
<b>Power Train</b>		
Section Index - Power Train	<b>Tab 6</b>	5-10960
Removal and Installation of Power Train Components	6001	5-10970
Transmission Specifications, Pressure Checks, and Troubleshooting	6002	5-11840
Transmission	6003	5-11820
Front Axle	6004	5-10980
Rear Axle	6004	84243973 Replaces 5-10990
Drive Shafts, Center Bearing, and Universal Joints	6005	5-11000
Wheels and Tires	6006	5-11010
Transmission Control Valve	6007	6-81450
<b>Brakes</b>		
Section Index - Brakes	<b>Tab 7</b>	5-11020
Removal and Installation of Brake Components	7001	5-11030
Hydraulic Brake Troubleshooting	7002	5-11040
Brake Pump	7003	5-11050
Brake Accumulators	7004	5-11060
Parking Brake	7008	5-11070
<b>Hydraulics</b>		
Section Index - Hydraulics	<b>Tab 8</b>	5-11080
How to Read Hydraulic Schematics	8000	5-5670
Removal and Installation of Hydraulic Components	8001	5-11090
Hydraulic Specifications, Troubleshooting, and Pressure Checks	8002	5-11100
Cleaning the Hydraulic System	8003	7-49641
Loader Control Valve	8005	5-11110
Cylinders	8006	5-11610
Coupler Solenoid Locking Valve	8007	6-42600
Ride Control Accumulator	8013	5-11120
Ride Control Valve	8014	5-3010

**521E Wheel Loader  
Service Manual  
84243970 (Replaces 87728450)**

**Table of Contents**

Description	Section No.	Form No.
<b>Mounted Equipment</b>		<b>Tab 9</b>
Section Index - Mounted Equipment		5-11130
Air Conditioning Troubleshooting and System Checks	9002	5-4030
Air Conditioner System Service	9003	5-11140
Removal And Installation Of Air Conditioning And Heater Components	9004	5-11150
Loader	9006	5-11160
Roll Over Protective Structure (ROPS), Cab Structural Frame (CSF)	9007	5-11170
Cab Glass Installation	9010	6-42710
<b>Electrical Schematic Foldouts and Hydraulic Schematic Foldout</b>	<b>In Rear Pocket</b>	<b>5-11180</b>

**NOTE: CNH America LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.**

## **SECTION INDEX**

### **GENERAL**

<b>Section Title</b>	<b>Section Number</b>
Standard Torque Specifications.....	1001
Fluids and Lubricants .....	1002
Metric Conversion Chart .....	1003



# Section

# 1001

## GENERAL TORQUE SPECIFICATIONS

## TABLE OF CONTENTS

TORQUE SPECIFICATIONS - DECIMAL HARDWARE .....	3
TORQUE SPECIFICATIONS - METRIC HARDWARE .....	4
TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS .....	5
TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS .....	6

## TORQUE SPECIFICATIONS - DECIMAL HARDWARE

Use the torques in this chart when special torques are not given. These torques apply to fasteners with both UNC and UNF threads as received from suppliers dry, or when lubricated with engine oil. Not applicable if special graphitics, Molydisulfide greases, or other extreme pressure lubricants are used.

<b>Grade 5 Bolts, Nuts, and Studs</b>		
  		
Size	Pound-Inches	Newton metres
1/4 inch	108 to 132	12 to 15
5/16 inch	204 to 252	23 to 28
3/8 inch	420 to 504	48 to 57
Size	Pound-Feet	Newton metres
7/16 inch	54 to 64	73 to 87
1/2 inch	80 to 96	109 to 130
9/16 inch	110 to 132	149 to 179
5/8 inch	150 to 180	203 to 244
3/4 inch	270 to 324	366 to 439
7/8 inch	400 to 480	542 to 651
1 0 inch	580 to 696	787 to 944
1-1/8 inch	800 to 880	1085 to 1193
1-1/4 inch	1120 to 1240	1519 to 1681
1-3/8 inch	1460 to 1680	1980 to 2278
1-1/2 inch	1940 to 2200	2631 to 2983

<b>Grade 8 Bolts, Nuts, and Studs</b>		
  		
Size	Pound-Inches	Newton metres
1/4 inch	144 to 180	16 to 20
5/16 inch	288 to 348	33 to 39
3/8 inch	540 to 648	61 to 73
Size	Pound-Feet	Newton metres
7/16 inch	70 to 84	95 to 114
1/2 inch	110 to 132	149 to 179
9/16 inch	160 to 192	217 to 260
5/8 inch	220 to 264	298 to 358
3/4 inch	380 to 456	515 to 618
7/8 inch	600 to 720	814 to 976
1 0 inch	900 to 1080	1220 to 1465
1-1/8 inch	1280 to 1440	1736 to 1953
1-1/4 inch	1820 to 2000	2468 to 2712
1-3/8 inch	2380 to 2720	3227 to 3688
1-1/2 inch	3160 to 3560	4285 to 4827

**NOTE:** Use thick nuts with Grade 8 bolts.

## TORQUE SPECIFICATIONS - METRIC HARDWARE


Use the following torques when specifications are not given.

These values apply to fasteners with coarse threads as received from supplier, plated or unplated, or when lubricated with engine oil. These values do not apply if graphite or Molydisulfide grease or oil is used.

Grade 8.8 Bolts, Nuts, and Studs		
8.8		
Size	Pound-Inches	Newton metres
M4	24 to 36	3 to 4
M5	60 to 72	7 to 8
M6	96 to 108	11 to 12
M8	228 to 276	26 to 31
M10	456 to 540	52 to 61
Size	Pound-Feet	Newton metres
M12	66 to 79	90 to 107
M14	106 to 127	144 to 172
M16	160 to 200	217 to 271
M20	320 to 380	434 to 515
M24	500 to 600	675 to 815
M30	920 to 1100	1250 to 1500
M36	1600 to 1950	2175 to 2600

Grade 10.9 Bolts, Nuts, and Studs		
10.9		
Size	Pound-Inches	Newton metres
M4	36 to 48	4 to 5
M5	84 to 96	9 to 11
M6	132 to 156	15 to 18
M8	324 to 384	37 to 43
Size	Pound-Feet	Newton metres
M10	54 to 64	73 to 87
M12	93 to 112	125 to 150
M14	149 to 179	200 to 245
M16	230 to 280	310 to 380
M20	450 to 540	610 to 730
M24	780 to 940	1050 to 1275
M30	1470 to 1770	2000 to 2400
M36	2580 to 3090	3500 to 4200

### Grade 12.9 Bolts, Nuts, and Studs



Usually the torque values specified for grade 10.9 fasteners can be used satisfactorily on grade 12.9 fasteners.

## TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS

Tube OD Hose ID	Thread Size	Pound- Inches	Newton metres
<b>37 Degree Flare Fitting</b>			
1/4 inch 6.4 mm	7/16-20	72 to 144	8 to 16
5/16 inch 7.9 mm	1/2-20	96 to 192	11 to 22
3/8 inch 9.5 mm	9/16-18	120 to 300	14 to 34
1/2 inch 12.7 mm	3/4-16	180 to 504	20 to 57
5/8 inch 15.9 mm	7/8-14	300 to 696	34 to 79
Tube OD Hose ID	Thread Size	Pound- Feet	Newton metres
3/4 inch 19.0 mm	1-1/16-12	40 to 80	54 to 108
7/8 inch 22.2 mm	1-3/16-12	60 to 100	81 to 135
1.0 inch 25.4 mm	1-5/16-12	75 to 117	102 to 158
1-1/4 inch 31.8 mm	1-5/8-12	125 to 165	169 to 223
1-1/2 inch 38.1 mm	1-7/8-12	210 to 250	285 to 338

Tube OD Hose ID	Thread Size	Pound- Inches	Newton metres
<b>Straight Threads with O-ring</b>			
1/4 inch 6.4 mm	7/16-20	144 to 228	16 to 26
5/16 inch 7.9 mm	1/2-20	192 to 300	22 to 34
3/8 inch 9.5 mm	9/16-18	300 to 480	34 to 54
1/2 inch 12.7 mm	3/4-16	540 to 804	57 to 91
Tube OD Hose ID	Thread Size	Pound- Feet	Newton metres
5/8 inch 15.9 mm	7/8-14	58 to 92	79 to 124
3/4 inch 19.0 mm	1-1/16-12	80 to 128	108 to 174
7/8 inch 22.2 mm	1-3/16-12	100 to 160	136 to 216
1.0 inch 25.4 mm	1-5/16-12	117 to 187	159 to 253
1-1/4 inch 31.8 mm	1-5/8-12	165 to 264	224 to 357
1-1/2 inch 38.1 mm	1-7/8-12	250 to 400	339 to 542

### Split Flange Mounting Bolts

Size	Pound- Inches	Newton metres
5/16-18	180 to 240	20 to 27
3/8-16	240 to 300	27 to 34
7/16-14	420 to 540	47 to 61
Size	Pound- Feet	Newton metres
1/2-13	55 to 65	74 to 88
5/8-11	140 to 150	190 to 203

# TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS

Nom. SAE Dash Size	Tube OD	Thread Size	Pound- Inches	Newton metres	Thread Size	Pound- Inches	Newton metres
<b>O-ring Face Seal End</b>					<b>O-ring Boss End Fitting or Lock Nut</b>		
-4	1/4 inch 6.4 mm	9/16-18	120 to 144	14 to 16	7/16-20	204 to 240	23 to 27
-6	3/8 inch 9.5 mm	11/16-16	216 to 240	24 to 27	9/16-18	300 to 360	34 to 41
-8	1/2 inch 12.7 mm	13/16-16	384 to 480	43 to 54	3/4-16	540 to 600	61 to 68
					Thread Size	Pound- Feet	Newton metres
-10	5/8 inch 15.9 mm	1-14	552 to 672	62 to 76	7/8-14	60 to 65	81 to 88
Nom. SAE Dash Size	Tube OD	Thread Size	Pound- Feet	Newton metres	1-1/16-12	85 to 90	115 to 122
					1-3/16-12	95 to 100	129 to 136
-12	3/4 inch 19.0 mm	1-3/16-12	65 to 80	90 to 110	1-5/16-12	115 to 125	156 to 169
-14	7/8 inch 22.2 mm	1-3/16-12	65 to 80	90 to 110	1-5/8-12	150 to 160	203 to 217
-16	1.0 inch 25.4 mm	1-7/16-12	92 to 105	125 to 140	1-7/8-12	190 to 200	258 to 271
-20	1-1/4 inch 31.8 mm	1-11/16-12	125 to 140	170 to 190			
-24	1-1/2 inch 38.1 mm	2-12	150 to 180	200 to 254			

# Section

# 1002

1002

## FLUIDS AND LUBRICANTS

## TABLE OF CONTENTS

CAPACITIES AND LUBRICANTS .....	3
ENGINE OIL RECOMMENDATIONS .....	4
TRANSMISSION Temperature CHART .....	5
HYDRAULIC/BRAKE SYSTEM Temperature CHART .....	5
DIESEL FUEL SYSTEM .....	6
Fuel Storage .....	6
Specifications for Acceptable No. 2 Diesel Fuel .....	6
MAINTENANCE SCHEDULE .....	7
Model 521E .....	7
MAINTENANCE POINTS .....	8
Model 521E .....	8

## CAPACITIES AND LUBRICANTS

Engine Oil		
Capacity .....	10.9 liters (11.5 U.S. Quarts)	
Capacity with Filter Change .....	11.8 liters (12.5 U.S. Quarts)	
Type of oil .....	Case AKCELA (SAE 15W-40)	
Engine Cooling System		
Capacity.....	22 liters (23.2 U.S. Quarts)	
Type of Coolant .....	50% water and 50% Ethylene Glycol	
Fuel Tank		
Capacity .....	189.3 liters (50 U.S. Gallons)	
Type of Fuel.....	See Diesel fuel specifications on page 6	
Hydraulic System		
Hydraulic Reservoir Refill Capacity .....	56.8 liters (15.0 U.S. Gallons)	
Total System Capacity.....	113.6 liters (30.0 U.S. Gallons)	
Type of Oil .....	Case AKCELA Hy-Tran Ultra®	
Transmission		
Refill Capacity with Filter Change .....	18.9 liters (20 U.S. Quarts)	
Total System Capacity.....	26 liters (27.5 U.S. Quarts)	
Type of Oil .....	Case AKCELA (SAE 15W-40)	
Axles		
Capacity		
Front.....	22.0 liters (23.2 U.S. Quarts)	
Rear .....	22.0 liters (23.2 U.S. Quarts)	
Type of Lubricant.....	Case AKCELA Transaxle Fluid (SAE 80W-140)	
<b>NOTE: DO NOT use an alternate oil in the axles. The brake components in the axles could be damaged as a result of using an alternate oil. Machines are shipped from the factory with break-in oil.</b>		
Brake System		
Type of Fluid (Same as Hydraulic System).....	Case AKCELA Hy-Tran Ultra®	
Fittings		
Grease as required .....	Case AKCELA Molydisulfide	

## ENGINE OIL RECOMMENDATIONS

Case AKCELA No. 1 Engine oil is recommended for use in your Case engine. Case AKCELA No. 1 Engine Oil will lubricate your engine correctly under all operating conditions.


If Case AKCELA No. 1 Multi-Viscosity Oil is not available, use only oil meeting API engine oil service category CI-4.

See the chart below for recommended viscosity at ambient air temperature ranges.

**NOTE:** Do not put performance additives or other oil additive products in the engine crankcase. The oil change intervals given in this manual are according to tests with Case AKCELA lubricants.




BD03A102




BC02N250

## TRANSMISSION TEMPERATURE CHART



## HYDRAULIC/BRAKE SYSTEM TEMPERATURE CHART



## DIESEL FUEL SYSTEM

Use No. 2 diesel fuel in the engine of this machine. The use of other fuels can cause the loss of engine power and high fuel consumption.

In very cold temperatures, a mixture of No. 1 and No. 2 diesel fuels is temporarily permitted. See the following Note.

**NOTE:** *See your fuel dealer for winter fuel requirements in your area. If the temperature of the fuel lowers below the cloud point (wax appearance point), wax crystals in the fuel will restrict the fuel filter and cause the engine to lose power or not start.*

The diesel fuel used in this machine must meet the specifications as shown below in, "Specifications for Acceptable No. 2 Diesel Fuel", or Specification (ASTM-D-975) of the American Society for Testing and Materials.

### Specifications for Acceptable No. 2 Diesel Fuel

API gravity, minimum .....	34
Flash point, minimum .....	60°C (140°F)
Cloud point (wax appearance point), maximum .....	-20°C (-5°F) See Note above
Pour point, maximum .....	-26°C (-15°F) See Note above
Distillation temperature, 90% point .....	282 to 338°C (540 to 640°F)
Viscosity, at 38°C (100°F)	
Centistokes .....	2.0 to 4.3
Cetane number, minimum .....	43 (45 to 55 for winter or high altitudes)
Water and sediment, by volume, maximum .....	0.05%

### Fuel Storage

If you keep fuel in storage for a period of time, you can get foreign material or water in the fuel storage tank. Many engine problems are caused by water in the fuel.

Keep the fuel storage tank outside and keep the fuel as cool as possible. Remove water from the storage container at regular periods of time.

Fill the fuel tank at the end of the daily operating period to prevent condensation in the fuel tank.


# MAINTENANCE SCHEDULE

## Model 521E

SERVICE INTERVAL	ITEM NUMBER	SERVICE POINTS	Initial Service	FREQUENCY IN HOURS					
				CHECK	CLEAN	CHANGE	DRAIN	LUBRICATE	REPLACE
Variable Periodic (*)	29	Air cleaner	*		*				
	18	Bleed Fuel Filter of Condensation				*			
	19	Hydraulic Filter	*						
	22	Alternator, AC, Drive Belt	*						
	13	Radiator Coolant Level	*						
	XX	Fire extinguisher	*						
Every 10 Hours	14	Tires	*						
	1	Check Engine Oil Level	10						
Every 50 Hours	2	Check Engine Coolant Level	50						
	3	Check Transmission Oil Level	50						
	4	Check Hydraulic Oil Level	50						
	5 & 6	Grease Bucket Mounting Fittings					50		
	7	Grease Front Drive Shaft Support Bearing					100		
Every 100 Hours	8 & 9	Lubricate The Steering Cylinder Pivots - Rod And Closed End (4 Fittings)					100		
	10	Lubricate Loader Lift & Cylinder Pivots (10) Z-bar					100		
	11	Lubricate Loader Lift & Cylinder Pivots (18) XT					100		
	12	Check Cab Air Filter	250						
Every 250 Hours	13	Check Tire Pressure & Wheel Torque	100	250					
	14	Check Drive Belt		250					
	15	Check Battery Electrolyte Level	500						
Every 500 Hours	16	Check Axle Oil Level	500						
	17	Drain Fuel Tank Condensation & Water Separator					500		
	18	Change Engine Oil and Filter	100		500				
	18	Change Crankcase Filter			500				
	19 & 27	Replace Fuel Filter	100					500	
	XX	ROPS/CSF and seat belt torques		500					
	20	Change Front & Rear Axle Oil	100		1000				
Every 1000 Hours	21	Replace Hydraulic Oil filter	100					1000	
	22	Replace Cab Air Filter						1000	
	23	Replace Drive Belt						1000	
	24	Change Transmission Oil and Filter	100		1000				
	25	Grease Articulation Fittings					1000		
	26	Check Injector Calibration		1000					
	27	Fuel Pre-Filter			1000				
	XX	Drive Shaft Slip Joint					1000		
	XX	Check Valve Adjustment (Engine Manual)		1000					
	XX	Trans Clutch Calibration (See Section 6002)	250	1000					
Every 2000 Hours	28	Change Hydraulic Oil			2000				
	29	Change Coolant			2000				
	30	Replace Engine Air Cleaner						2000	
Every 4000 Hours	XX	Valve Clearance (Engine Manual)							4000

## MAINTENANCE POINTS

## Model 521E



BS08B289

See your Operators manual for maintenance of safety related items and for detailed information of the service items on this chart. Operators and service manuals are available for this machine from your dealer.

If you operate the machine in severe conditions, lubricate and service the machine more frequently.

# Section

# 1003

1003

## METRIC CONVERSION CHART

CNH AMERICA LLC  
700 State Street  
Racine, WI 53404 U.S.A.

Bur 7-52950

© 2005 CNH America LLC  
Printed in U.S.A.  
June, 1997

## TABLE OF CONTENTS

CONVERSION FACTORS .....	3
Metric to U.S. .....	3
U.S. to Metric .....	4

# CONVERSION FACTORS

## Metric to U.S.

	<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>
<b>Area:</b>	sq. meter hectare	10.763 91 2.471 05	square foot acre
<b>Force:</b>	newton newton	3.596 942 0.224 809	ounce force pound force
<b>Length:</b>	millimeter meter kilometer	0.039 370 3.280 840 0.621 371	inch foot mile
<b>Mass:</b>	kilogram	2.204 622	pound
<b>Mass/Area:</b>	kilogram/hectare	0.000 466	ton/acre
<b>Mass/Energy:</b>	gr/kW/hr.	0.001 644	lbs/hp/hr.
<b>Mass/Volume:</b>	kg/cubic meter	1.685 555	lb/cubic yd.
<b>Power:</b>	kilowatt	1.341 02	horsepower
<b>Pressure:</b>	kilopascal bar	0.145 038 14.50385	lb/sq. inch lb/sq. inch
<b>Temperature:</b>	degree C	1.8 x C +32	degree F
<b>Torque:</b>	newton meter newton meter	8.850 748 0.737 562	lb/inch lb/foot
<b>Velocity:</b>	kilometer/hr.	0.621 371	miles/hr.
<b>Volume:</b>	cubic centimeter cubic meter cubic meter milliliter litre litre litre litre	0.061 024 35.314 66 1.307 950 0.033 814 1.056 814 0.879 877 0.264 172 0.219 969	cubic inch cubic foot cubic yd. ounce (US fluid) quart (US liquid) quart (Imperial) gallon (US liquid) gallon (Imperial)
<b>Volume/Time:</b>	litre/min. litre/min.	0.264 172 0.219 969	gallon/min. (US liquid) gallon/min. (Imperial)

## U.S. to Metric

	<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>
<b>Area:</b>	square foot acre	0.092 903 0.404 686	square meter hectare
<b>Force:</b>	ounce force pound force	0.278 014 4.448 222	newton newton
<b>Length:</b>	inch foot mile	25.4 * 0.304 8 * 1.609 344 *	millimeter meter kilometer
<b>Mass:</b>	pound ounce	0.453 592 28.35	kilogram gram
<b>Mass/Area:</b>	ton/acre	2241 702	kilogram/hectare
<b>Mass/Energy:</b>	lb/hp/hr	608.277 4	gr/kW/hr
<b>Mass/Volume:</b>	lb/cubic yd.	0.593 276	kg/cubic meter
<b>Power:</b>	horsepower	0.745 700	kilowatt
<b>Pressure:</b>	lbs/sq. in. lbs/sq. in. lbs/sq. in.	6.894 757 0.069 0.070 303	kilopascal bar kg/sq. cm
<b>Temperature:</b>	degree F	1.8 F - 32	degree C
<b>Torque:</b>	pound/inch pound/foot	0.112 985 1.355 818	newton meter newton meter
<b>Velocity:</b>	miles/hr.	1.609 344 *	kilometer/hr.
<b>Volume:</b>	cubic inch cubic foot cubic yard ounce (US fluid) quart (US liquid) quart (Imperial) gallon (US) gallons (Imperial)	16.387 06 0.028 317 0.764.555 29.573 53 0.946 353 1.136 523 3.785 412 4.546 092	cubic centimeter cubic meter cubic meter milliliter litre litre litre litre
<b>Volume/Time:</b>	gallon/min.	3.785 412	litre/min.

\* = exact

## **SECTION INDEX**

### **ENGINES**

<b>Section Title</b>	<b>Section Number</b>
Engine and Radiator Removal and Installation . . . . .	2000
Stall Tests . . . . .	2002
After Cooler . . . . .	2003

**FOR ENGINE REPAIR, SEE THE ENGINE REPAIR MANUAL  
87630273**



# Section

# 2000

## ENGINE AND RADIATOR REMOVAL AND INSTALLATION


## TABLE OF CONTENTS

Engine .....	3
Removal .....	3
Installation .....	11
Radiator .....	20
Removal .....	20
Installation .....	23

## ENGINE

### Removal

#### STEP 1



Park machine on a level surface and lower bucket to ground. Put articulation lock in LOCKED position.

#### STEP 2

Stop engine. Actuate brake pedal several times to discharge brake accumulators. Put key switch in ON position and move loader control lever back and forth at least 30 times to release any pressure from hydraulic circuit. Put key switch in OFF position.

#### STEP 3


Slowly loosen the filler cap for hydraulic reservoir to release air pressure in hydraulic reservoir.

#### STEP 4




The master disconnect is located under the hood on the left rear side of the machine. Raise the hood put master disconnect switch in OFF position. Remove both battery covers and disconnect batteries from the machine.

#### STEP 5



Put a container capable of holding at least 22.7 liter (6.0 gallon) below radiator drain. Remove radiator cap. Remove cap and drain coolant into container. Install cap after coolant has drained. Install radiator cap.

#### STEP 6



Put a container capable of holding at least 12.3 liter (13 U.S. quarts) below engine oil drain. Remove cap and drain oil into container. Install cap after oil has drained.

**NOTE:** After draining oil disconnect drain hose from frame for removal with engine.