

Product: Case 921E Wheel Loader Service Repair Manual 84299249

Full Download: <https://www.arepairmanual.com/downloads/case-921e-wheel-loader-service-repair-manual-84299249/>



SERVICE MANUAL
WHEEL LOADER
921E
TIER 3

84299249

(Replaces 87624950)

Sample of manual. Download All 848 pages at:

https://www_arepairmanual.com/downloads/case-921e-wheel-loader-service-repair-manual-84299249/

Issued February 2007

Product: Case 921E Wheel Loader Service Repair Manual 84299249
Full Download: <https://www.arepairmanual.com/downloads/case-921e-wheel-loader-service-repair-manual-84299249/>

921E Wheel Loader Service Manual 84299249 (Replaces 87624950)

Table of Contents

| Description | Section No. | Form No. |
|---|-------------|-------------------------------|
| General | | |
| Section Index - General | | 5-5380 |
| Standard Torque Specifications | 1001 | 8-71603 |
| Fluids and Lubricants | 1002 | 5-5390 |
| Metric Conversion Chart | 1003 | 7-52950 |
| Engines | | |
| Section Index - Engines | | 5-5400 |
| Engine and Radiator Removal and Installation | 2000 | 5-5410 |
| Stall Tests | 2002 | 5-5420 |
| After Cooler | 2003 | 5-5430 |
| For Engine Repair See Your Cummins Dealer | | |
| Fuel System | | |
| Section Index - Fuel System | | 5-5440 |
| For Fuel System Repair, See Your Cummins Dealer | | |
| Electrical | | |
| Section Index - Electrical | | 5-5450 |
| Removal and Installation of Starter and Alternator | 4001 | 5-5460 |
| Electrical Specifications and Troubleshooting | 4002 | 5-5470 |
| Batteries | 4003 | 6-42331 |
| Instrument Cluster and Equipment Fault Codes | 4005 | 5-5480 |
| Steering | | |
| Section Index - Steering | | 84299252 (Replaces 5-5490) |
| Removal and Installation of Steering Components | 5001 | 5-5500 |
| Steering Specifications, Pressure Checks, and Troubleshooting | 5002 | 5-5510 |
| Steering Control Valve | 5003 | 5-5520 |
| Steering Cylinders | 5005 | 5-5530 |
| Center Pivot | 5006 | 5-5540 |
| Auxiliary Steering Motor and Pump | 5008 | 6-42430 |
| Joystick Steering | 5009 | 5-15970 |

**921E Wheel Loader
Service Manual 84299249
(Replaces 87624950)**

Table of Contents

| Description | Section No. | Form No. |
|--|--------------|----------|
| Power Train | Tab 6 | |
| Section Index - Power Train | | 5-5550 |
| Removal and Installation of Power Train Components | 6001 | 5-5560 |
| Transmission Specifications, Pressure Checks, and Troubleshooting | 6002 | 5-5570 |
| Transmission | 6003 | 5-5580 |
| Front and Rear Axle | 6004 | 5-5590 |
| Drive Shafts, Center Bearing, and Universal Joints | 6005 | 5-5600 |
| Wheels and Tires | 6006 | 5-5610 |
| Transmission Control Valve | 6007 | 6-42501 |
| Brakes | Tab 7 | |
| Section Index - Brakes | | 5-5620 |
| Removal and Installation of Brake Components | 7001 | 5-5630 |
| Hydraulic Brake Troubleshooting | 7002 | 5-5640 |
| Parking Brake | 7008 | 5-5650 |
| Hydraulics | Tab 8 | |
| Section Index - Hydraulics | | 5-5660 |
| How to Read Symbols in a Hydraulic Schematic | 8000 | 5-5670 |
| Removal and Installation of Hydraulic Components | 8001 | 5-5680 |
| Hydraulic Specifications, Troubleshooting, and Pressure Checks | 8002 | 5-5690 |
| Cleaning the Hydraulic System | 8003 | 5-5700 |
| Hydraulic Pump | 8004 | 5-5710 |
| Loader Control Valve | 8005 | 5-5720 |
| Cylinders | 8006 | 5-5730 |
| Mounted Equipment | Tab 9 | |
| Section Index - Mounted Equipment | | 5-5740 |
| Air Conditioning Troubleshooting and System Checks | 9002 | 5-5750 |
| Air Conditioner System Service | 9003 | 5-5760 |
| Removal and Installation of Air Conditioning and Heater Components | 9004 | 5-5770 |
| Loader | 9006 | 5-5780 |
| The Rollover Protective Structure (ROPS) or Cab Structural Frame (CSF) | 9007 | 5-5790 |
| Cab Glass Installation | 9010 | 6-42710 |

**921E Wheel Loader
Service Manual 84299249
(Replaces 87624950)**

Table of Contents

| Description | Section No. | Form No. |
|--|-----------------------|---------------|
| Electrical Schematic Foldouts and Hydraulic Schematic Foldout | In Rear Pocket | 5-5800 |

NOTE: CNH America LLC. reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

SECTION INDEX

GENERAL

| Section Title | Section Number |
|--------------------------------------|-----------------------|
| Standard Torque Specifications | 1001 |
| Fluids and Lubricants | 1002 |
| Metric Conversion Chart | 1003 |

Section

1001

GENERAL TORQUE SPECIFICATIONS

TABLE OF CONTENTS

| | |
|--|---|
| TORQUE SPECIFICATIONS - DECIMAL HARDWARE | 3 |
| TORQUE SPECIFICATIONS - METRIC HARDWARE | 4 |
| TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS | 5 |
| TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS | 6 |

TORQUE SPECIFICATIONS - DECIMAL HARDWARE

Use the torques in this chart when special torques are not given. These torques apply to fasteners with both UNC and UNF threads as received from suppliers dry, or when lubricated with engine oil. Not applicable if special graphites, Molydisulfide greases, or other extreme pressure lubricants are used.

| Grade 5 Bolts, Nuts, and Studs | | |
|---|--------------|---------------|
|    | | |
| Size | Pound-Inches | Newton metres |
| 1/4 inch | 108 to 132 | 12 to 15 |
| 5/16 inch | 204 to 252 | 23 to 28 |
| 3/8 inch | 420 to 504 | 48 to 57 |
| | | |
| Size | Pound-Feet | Newton metres |
| 7/16 inch | 54 to 64 | 73 to 87 |
| 1/2 inch | 80 to 96 | 109 to 130 |
| 9/16 inch | 110 to 132 | 149 to 179 |
| 5/8 inch | 150 to 180 | 203 to 244 |
| 3/4 inch | 270 to 324 | 366 to 439 |
| 7/8 inch | 400 to 480 | 542 to 651 |
| 1.0 inch | 580 to 696 | 787 to 944 |
| 1-1/8 inch | 800 to 880 | 1085 to 1193 |
| 1-1/4 inch | 1120 to 1240 | 1519 to 1681 |
| 1-3/8 inch | 1460 to 1680 | 1980 to 2278 |
| 1-1/2 inch | 1940 to 2200 | 2631 to 2983 |

| Grade 8 Bolts, Nuts, and Studs | | |
|---|--------------|---------------|
|    | | |
| Size | Pound-Inches | Newton metres |
| 1/4 inch | 144 to 180 | 16 to 20 |
| 5/16 inch | 288 to 348 | 33 to 39 |
| 3/8 inch | 540 to 648 | 61 to 73 |
| | | |
| Size | Pound-Feet | Newton metres |
| 7/16 inch | 70 to 84 | 95 to 114 |
| 1/2 inch | 110 to 132 | 149 to 179 |
| 9/16 inch | 160 to 192 | 217 to 260 |
| 5/8 inch | 220 to 264 | 298 to 358 |
| 3/4 inch | 380 to 456 | 515 to 618 |
| 7/8 inch | 600 to 720 | 814 to 976 |
| 1.0 inch | 900 to 1080 | 1220 to 1465 |
| 1-1/8 inch | 1280 to 1440 | 1736 to 1953 |
| 1-1/4 inch | 1820 to 2000 | 2468 to 2712 |
| 1-3/8 inch | 2380 to 2720 | 3227 to 3688 |
| 1-1/2 inch | 3160 to 3560 | 4285 to 4827 |

NOTE: Use thick nuts with Grade 8 bolts.

TORQUE SPECIFICATIONS - METRIC HARDWARE


Use the following torques when specifications are not given.

These values apply to fasteners with coarse threads as received from supplier, plated or unplated, or when lubricated with engine oil. These values do not apply if graphite or Molydisulfide grease or oil is used.

| Grade 8.8 Bolts, Nuts, and Studs | | |
|----------------------------------|--------------|---------------|
| 8.8 | | |
| Size | Pound-Inches | Newton metres |
| M4 | 24 to 36 | 3 to 4 |
| M5 | 60 to 72 | 7 to 8 |
| M6 | 96 to 108 | 11 to 12 |
| M8 | 228 to 276 | 26 to 31 |
| M10 | 456 to 540 | 52 to 61 |
| | | |
| Size | Pound-Feet | Newton metres |
| M12 | 66 to 79 | 90 to 107 |
| M14 | 106 to 127 | 144 to 172 |
| M16 | 160 to 200 | 217 to 271 |
| M20 | 320 to 380 | 434 to 515 |
| M24 | 500 to 600 | 675 to 815 |
| M30 | 920 to 1100 | 1250 to 1500 |
| M36 | 1600 to 1950 | 2175 to 2600 |

| Grade 10.9 Bolts, Nuts, and Studs | | |
|-----------------------------------|--------------|---------------|
| 10.9 | | |
| Size | Pound-Inches | Newton metres |
| M4 | 36 to 48 | 4 to 5 |
| M5 | 84 to 96 | 9 to 11 |
| M6 | 132 to 156 | 15 to 18 |
| M8 | 324 to 384 | 37 to 43 |
| | | |
| Size | Pound-Feet | Newton metres |
| M10 | 54 to 64 | 73 to 87 |
| M12 | 93 to 112 | 125 to 150 |
| M14 | 149 to 179 | 200 to 245 |
| M16 | 230 to 280 | 310 to 380 |
| M20 | 450 to 540 | 610 to 730 |
| M24 | 780 to 940 | 1050 to 1275 |
| M30 | 1470 to 1770 | 2000 to 2400 |
| M36 | 2580 to 3090 | 3500 to 4200 |

Grade 12.9 Bolts, Nuts, and Studs



Usually the torque values specified for grade 10.9 fasteners can be used satisfactorily on grade 12.9 fasteners.

TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS

| 37 Degree Flare Fitting | | | |
|-------------------------|----------------|------------------|------------------|
| Tube OD Hose ID | Thread Size | Pound- Inches | Newton metres |
| 1/4 inch 6.4 mm | 7/16-20 | 72 to 144 | 8 to 16 |
| 5/16 inch 7.9 mm | 1/2-20 | 96 to 192 | 11 to 22 |
| 3/8 inch 9.5 mm | 9/16-18 | 120 to 300 | 14 to 34 |
| 1/2 inch 12.7 mm | 3/4-16 | 180 to 504 | 20 to 57 |
| 5/8 inch 15.9 mm | 7/8-14 | 300 to 696 | 34 to 79 |
| | | | |
| Tube OD Hose ID | Thread Size | Pound- Feet | Newton metres |
| 3/4 inch 19.0 mm | 1-1/16-12 | 40 to 80 | 54 to 108 |
| 7/8 inch 22.2 mm | 1-3/16-12 | 60 to 100 | 81 to 135 |
| 1.0 inch 25.4 mm | 1-5/16-12 | 75 to 117 | 102 to 158 |
| 1-1/4 inch 31.8 mm | 1-5/8-12 | 125 to 165 | 169 to 223 |
| 1-1/2 inch 38.1 mm | 1-7/8-12 | 210 to 250 | 285 to 338 |

| Straight Threads with O-ring | | | |
|------------------------------|----------------|------------------|------------------|
| Tube OD Hose ID | Thread Size | Pound- Inches | Newton metres |
| 1/4 inch 6.4 mm | 7/16-20 | 144 to 228 | 16 to 26 |
| 5/16 inch 7.9 mm | 1/2-20 | 192 to 300 | 22 to 34 |
| 3/8 inch 9.5 mm | 9/16-18 | 300 to 480 | 34 to 54 |
| 1/2 inch 12.7 mm | 3/4-16 | 540 to 804 | 57 to 91 |
| | | | |
| Tube OD Hose ID | Thread Size | Pound- Feet | Newton metres |
| 5/8 inch 15.9 mm | 7/8-14 | 58 to 92 | 79 to 124 |
| 3/4 inch 19.0 mm | 1-1/16-12 | 80 to 128 | 108 to 174 |
| 7/8 inch 22.2 mm | 1-3/16-12 | 100 to 160 | 136 to 216 |
| 1.0 inch 25.4 mm | 1-5/16-12 | 117 to 187 | 159 to 253 |
| 1-1/4 inch 31.8 mm | 1-5/8-12 | 165 to 264 | 224 to 357 |
| 1-1/2 inch 38.1 mm | 1-7/8-12 | 250 to 400 | 339 to 542 |

| Split Flange Mounting Bolts | | |
|-----------------------------|------------------|------------------|
| Size | Pound- Inches | Newton metres |
| 5/16-18 | 180 to 240 | 20 to 27 |
| 3/8-16 | 240 to 300 | 27 to 34 |
| 7/16-14 | 420 to 540 | 47 to 61 |
| | | |
| Size | Pound- Feet | Newton metres |
| 1/2-13 | 55 to 65 | 74 to 88 |
| 5/8-11 | 140 to 150 | 190 to 203 |

TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS

| O-ring Face Seal End | | | | | O-ring Boss End Fitting or Lock Nut | | |
|-----------------------------|-----------------------|----------------|------------------|------------------|--|------------------|------------------|
| Nom. SAE Dash Size | Tube OD | Thread Size | Pound- Inches | Newton metres | Thread Size | Pound- Inches | Newton metres |
| -4 | 1/4 inch 6.4 mm | 9/16-18 | 120 to 144 | 14 to 16 | 7/16-20 | 204 to 240 | 23 to 27 |
| -6 | 3/8 inch 9.5 mm | 11/16-16 | 216 to 240 | 24 to 27 | 9/16-18 | 300 to 360 | 34 to 41 |
| -8 | 1/2 inch 12.7 mm | 13/16-16 | 384 to 480 | 43 to 54 | 3/4-16 | 540 to 600 | 61 to 68 |
| | | | | | | | |
| | | | | | Thread Size | Pound- Feet | Newton metres |
| -10 | 5/8 inch 15.9 mm | 1-14 | 552 to 672 | 62 to 76 | 7/8-14 | 60 to 65 | 81 to 88 |
| | | | | | | | |
| Nom. SAE Dash Size | Tube OD | Thread Size | Pound- Feet | Newton metres | 1-1/16-12 | 85 to 90 | 115 to 122 |
| | | | | | 1-3/16-12 | 95 to 100 | 129 to 136 |
| -12 | 3/4 inch 19.0 mm | 1-3/16-12 | 65 to 80 | 90 to 110 | 1-5/16-12 | 115 to 125 | 156 to 169 |
| -14 | 7/8 inch 22.2 mm | 1-3/16-12 | 65 to 80 | 90 to 110 | 1-5/8-12 | 150 to 160 | 203 to 217 |
| -16 | 1.0 inch 25.4 mm | 1-7/16-12 | 92 to 105 | 125 to 140 | 1-7/8-12 | 190 to 200 | 258 to 271 |
| -20 | 1-1/4 inch 31.8 mm | 1-11/16-12 | 125 to 140 | 170 to 190 | | | |
| -24 | 1-1/2 inch 38.1 mm | 2-12 | 150 to 180 | 200 to 254 | | | |

Section

1002

1002

FLUIDS AND LUBRICANTS

TABLE OF CONTENTS

| | |
|---|---|
| CAPACITIES AND LUBRICANTS | 3 |
| ENGINE OIL RECOMMENDATIONS | 4 |
| DIESEL FUEL SYSTEM | 5 |
| Fuel Storage | 5 |
| Specifications for Acceptable No. 2 Diesel Fuel | 5 |
| Biodiesel Information | 5 |
| MAINTENANCE SCHEDULE | 6 |
| Model 921E | 6 |

CAPACITIES AND LUBRICANTS

Engine Oil

| | |
|-----------------------------------|--|
| Capacity with Filter Change | 30.0 liters (32 U.S. quarts) |
| Type of oil | Case AKCELA No. 1 (SAE 15W-40) engine oil - see engine oil recommendations on page 4 |

Engine Cooling System

| | |
|-----------------------|-----------------------------------|
| Capacity..... | 56.8 liters (15.0 U.S. Gallons) |
| Type of Coolant | 50% water and 50% Ethylene Glycol |

Fuel Tank

| | |
|-------------------|--|
| Capacity | 393.7 liters (104 U.S. Gallons) |
| Type of Fuel..... | See Diesel fuel specifications on page 5 |

Hydraulic System

| | |
|--|----------------------------------|
| Hydraulic Reservoir Refill Capacity with Filter Change | 130 liters (34.0 U.S. Gallons) |
| Total System Capacity..... | 242.0 liters (64.0 U.S. Gallons) |
| Type of Oil | Case AKCELA Hy-Tran Ultra® |

Transmission

| | |
|--|---------------------------------|
| Refill Capacity with Filter Change | 28.4 liters (7.5 U.S. Gallons) |
| Total System Capacity..... | 44.5 liters (11.8 U.S. Gallons) |
| Type of Oil | Case AKCELA No. 1 (15W-40) |

Axles

Capacity

| | |
|-----------------------------------|---------------------------------|
| Front with out axle coolers | 51.0 liters (13.5 U.S. Gallons) |
| Rear with out axle coolers..... | 51.0 liters (13.5 U.S. Gallons) |

| | |
|-------------------------------|---|
| Front with axle coolers | 55.0 liters (14.5 U.S. Gallons) |
| Rear with axle coolers..... | 55.0 liters (14.5 U.S. Gallons) |
| Type of Lubricant..... | Case AKCELA (SAE 80W-140) Transaxle Fluid |

Brake System

| | |
|--|----------------------------|
| Type of Fluid (Same as Hydraulic System) | Case AKCELA Hy-Tran Ultra® |
|--|----------------------------|

NOTE: *DO NOT use an alternate oil in the axles. The brake components in the axles could be damaged as a result of using an alternate oil.*

ENGINE OIL RECOMMENDATIONS


Case AKCELA No. 1 Engine oil is recommended for use in your Case engine. Case AKCELA No. 1 Engine Oil will lubricate your engine correctly under all operating conditions.

If Case AKCELA No. 1 Multi-Viscosity Oil is not available, use only oil meeting API engine oil service category CH-4 (preferred) or CG-4.



See the chart below for recommended viscosity at ambient air temperature ranges.

NOTE: Do not put performance additives or other oil additive products in the engine crankcase. The oil change intervals given in this manual are according to tests with Case AKCELA lubricants.



DIESEL FUEL SYSTEM

Use No. 2 diesel fuel in the engine of this machine. The use of other fuels can cause the loss of engine power and high fuel consumption.

In very cold temperatures, a mixture of No. 1 and No. 2 diesel fuels is temporarily permitted. See the following Note.

NOTE: See your fuel dealer for winter fuel requirements in your area. If the temperature of the fuel lowers below the cloud point (wax appearance point), wax crystals in the fuel will restrict the fuel filter and cause the engine to lose power or not start.

The diesel fuel used in this machine must meet the specifications as shown below in, "Specifications for Acceptable No. 2 Diesel Fuel", or "Specification D975-81" of the American Society for Testing and Materials.

Specifications for Acceptable No. 2 Diesel Fuel

| | |
|---|--|
| API gravity, minimum | 34 |
| Flash point, minimum | 60°C (140°F) |
| Cloud point (wax appearance point), maximum | -20°C (-5°F) See Note above |
| Pour point, maximum | -26°C (-15°F) See Note above |
| Distillation temperature, 90% point | 282 to 338°C (540 to 640°F) |
| Viscosity, at 38°C (100°F) | |
| Centistokes | 2.0 to 4.3 |
| Cetane number, minimum | 43 (45 to 55 for winter or high altitudes) |
| Water and sediment, by volume, maximum | 0.05% |

Biodiesel Information

| General Fuel | Final Boiling | Cetane | Sulfur Content |
|------------------------|-------------------|--------|----------------|
| Classification | Point (Max) | (Min) | (Max) |
| B5 * (5% Biodiesel) | < 360° C (680° F) | 47 | 0.05% |
| B20 ** (20% Biodiesel) | < 360° C (680° F) | 47 | 0.05% |

*- Must meet the D 975 specification for diesel fuels.

**-Must meet the ASTM D6751-03A specification.

NOTE: B20 Biodiesel is not approved for common rail diesel engines at this time.

Fuel Storage

If you keep fuel in storage for a period of time, you can get foreign material or water in the fuel storage tank. Many engine problems are caused by water in the fuel.

Keep the fuel storage tank outside and keep the fuel as cool as possible. Remove water from the storage container at regular periods of time.

Fill the fuel tank at the end of the daily operating period to prevent condensation in the fuel tank.

MAINTENANCE SCHEDULE

Model 921E

AS REQUIRED

SERVICE THE AIR CLEANER IF THE AIR CLEANER WARNING LAMP ILLUMINATES SEE OPERATORS MANUAL
 REPLACE THE TRANSMISSION FILTER

IF THE TRANSMISSION FILTER RESTRICTION WARNING LAMP ILLUMINATES USE CASE FILTER
 CHECK THE RADIATOR COOLANT LEVEL IF THE WARNING LAMP ILLUMINATES SEE OPERATORS MANUAL
 REPLACE THE HYDRAULIC FILTER IF THE HYDRAULIC FILTER WARNING LAMP ILLUMINATES USE CASE FILTER

EVERY 10 HOURS OF OPERATION OR EACH DAY - WHICHEVER OCCURS FIRST

CHECK THE ENGINE OIL LEVEL SEE OPERATORS MANUAL
 DRAIN THE FUEL/WATER SEPARATOR SEE OPERATORS MANUAL
 CHECK THE ALTERNATOR, AC BELT SEE OPERATORS MANUAL

EVERY 50 HOURS OF OPERATION

CHECK THE TRANSMISSION OIL LEVEL (ENGINE RUNNING AND OIL WARM) SEE OPERATORS MANUAL
 CHECK THE HYDRAULIC RESERVOIR FLUID LEVEL SEE OPERATORS MANUAL
 CHECK THE ENGINE COOLANT SURGE TANK SEE OPERATORS MANUAL
 LUBRICATE THE BELLCRANK AND BUCKET PIVOTS (6 FITTINGS) Z-BAR CASE AKCELA MOLYDISULFIDE GREASE
 LUBRICATE REAR AXLE TRUNNION PINS (2 FITTINGS) CASE AKCELA MOLYDISULFIDE GREASE

EVERY 100 HOURS OF OPERATION

LUBRICATE THE STEERING CYLINDER PIVOTS - ROD AND CLOSED END (4 FITTINGS) CASE AKCELA MOLYDISULFIDE GREASE
 LUBRICATE THE LOADER LIFT ARM AND CYLINDER PIVOTS (7 FITTINGS) Z-BAR CASE AKCELA MOLYDISULFIDE GREASE
 LUBRICATE THE FRONT DRIVE SHAFT SUPPORT BEARING CASE AKCELA MOLYDISULFIDE GREASE

EVERY 250 HOURS OF OPERATION

CHANGE COOLANT FILTER SEE OPERATORS MANUAL
 CHECK THE TIRE CONDITION AND AIR PRESSURE SEE OPERATORS MANUAL
 CLEAN THE CAB AIR FILTERS SEE OPERATORS MANUAL
 REPLACE FUEL FILTER SEE OPERATORS MANUAL

EVERY 500 HOURS OF OPERATION

CHANGE THE ENGINE OIL AND REPLACE THE ENGINE OIL FILTER SEE OPERATORS MANUAL
 CHECK THE BATTERY FLUID LEVEL SEE OPERATORS MANUAL
 DRAIN WATER AND SEDIMENT FROM THE FUEL TANK SEE OPERATORS MANUAL
 CHECK THE AXLE OIL LEVEL FRONT AND REAR SEE OPERATORS MANUAL
 CHECK ROPS AND SEAT BELT MOUNTING BOLTS SEE OPERATORS MANUAL

EVERY 1000 HOURS OF OPERATION

REPLACE THE HYDRAULIC FILTERS (2) USE CASE FILTER
 REPLACE THE TRANSMISSION OIL FILTERS (2) USE CASE FILTER
 CHANGE THE TRANSMISSION OIL SEE OPERATORS MANUAL
 CHANGE CAB AIR FILTERS SEE OPERATORS MANUAL
 LUBRICATE THE UPPER AND LOWER CHASSIS PIVOTS (2 FITTINGS) CASE AKCELA MOLYDISULFIDE GREASE
 CHANGE THE FRONT/REAR AXLE OIL (AND FILTERS IF EQUIPPED) SEE OPERATORS MANUAL

EVERY 1500 HOURS OF OPERATION

ADJUST THE ENGINE VALVE CLEARANCES SEE YOUR CUMMINS DEALER

EVERY 2000 HOURS OF OPERATION OR EACH YEAR - WHICHEVER OCCURS FIRST

CHANGE THE HYDRAULIC OIL SEE OPERATORS MANUAL
 DRAIN, FLUSH AND REFILL THE ENGINE COOLING SYSTEM ETHYLENE GLYCOL AND WATER
 REPLACE THE AIR CLEANER ELEMENTS USE CASE FILTERS

If you operate the machine in severe conditions, lubricate and service the machine more frequently. It is recommended that you see your Case dealer for information on the Systemgard Lubrication Analysis System.

See your Operators manual for maintenance of safety related items and for detailed information of the service items on this chart. Operators and service manuals are available for this machine from your Case dealer.

Section

1003

1003

METRIC CONVERSION CHART

TABLE OF CONTENTS

| | |
|--------------------------|---|
| CONVERSION FACTORS | 3 |
| Metric to U.S. | 3 |
| U.S. to Metric | 4 |

CONVERSION FACTORS

Metric to U.S.

| | <u>MULTIPLY</u> | <u>BY</u> | <u>TO OBTAIN</u> |
|---------------------|--|--|---|
| Area: | sq. meter hectare | 10.763 91 2.471 05 | square foot acre |
| Force: | newton newton | 3.596 942 0.224 809 | ounce force pound force |
| Length: | millimeter meter kilometer | 0.039 370 3.280 840 0.621 371 | inch foot mile |
| Mass: | kilogram | 2.204 622 | pound |
| Mass/Area: | kilogram/hectare | 0.000 466 | ton/acre |
| Mass/Energy: | gr/kW/hr. | 0.001 644 | lbs/hp/hr. |
| Mass/Volume: | kg/cubic meter | 1.685 555 | lb/cubic yd. |
| Power: | kilowatt | 1.341 02 | horsepower |
| Pressure: | kilopascal bar | 0.145 038 14.50385 | lb/sq. inch lb/sq. inch |
| Temperature: | degree C | 1.8 x C +32 | degree F |
| Torque: | newton meter newton meter | 8.850 748 0.737 562 | lb/inch lb/foot |
| Velocity: | kilometer/hr. | 0.621 371 | miles/hr. |
| Volume: | cubic centimeter cubic meter cubic meter milliliter litre litre litre litre | 0.061 024 35.314 66 1.307 950 0.033 814 1.056 814 0.879 877 0.264 172 0.219 969 | cubic inch cubic foot cubic yd. ounce (US fluid) quart (US liquid) quart (Imperial) gallon (US liquid) gallon (Imperial) |
| Volume/Time: | litre/min. litre/min. | 0.264 172 0.219 969 | gallon/min. (US liquid) gallon/min. (Imperial) |

U.S. to Metric

| | <u>MULTIPLY</u> | <u>BY</u> | <u>TO OBTAIN</u> |
|---------------------|--|--|--|
| Area: | square foot acre | 0.092 903 0.404 686 | square meter hectare |
| Force: | ounce force pound force | 0.278 014 4.448 222 | newton newton |
| Length: | inch foot mile | 25.4 * 0.304 8 * 1.609 344 * | millimeter meter kilometer |
| Mass: | pound ounce | 0.453 592 28.35 | kilogram gram |
| Mass/Area: | ton/acre | 2241 702 | kilogram/hectare |
| Mass/Energy: | lb/hp/hr | 608.277 4 | gr/kW/hr |
| Mass/Volume: | lb/cubic yd. | 0.593 276 | kg/cubic meter |
| Power: | horsepower | 0.745 700 | kilowatt |
| Pressure: | lbs/sq. in. lbs/sq. in. lbs/sq. in. | 6.894 757 0.069 0.070 303 | kilopascal bar kg/sq. cm |
| Temperature: | degree F | 1.8 F - 32 | degree C |
| Torque: | pound/inch pound/foot | 0.112 985 1.355 818 | newton meter newton meter |
| Velocity: | miles/hr. | 1.609 344 * | kilometer/hr. |
| Volume: | cubic inch cubic foot cubic yard ounce (US fluid) quart (US liquid) quart (Imperial) gallon (US) gallons (Imperial) | 16.387 06 0.028 317 0.764.555 29.573 53 0.946 353 1.136 523 3.785 412 4.546 092 | cubic centimeter cubic meter cubic meter milliliter litre litre litre litre |
| Volume/Time: | gallon/min. | 3.785 412 | litre/min. |

* = exact

SECTION INDEX

ENGINES

| Section Title | Section Number |
|--|-----------------------|
| Engine and Radiator Removal and Installation | 2000 |
| Stall Tests | 2002 |
| After Cooler | 2003 |

FOR ENGINE REPAIR, SEE YOUR CUMMINS DEALER

Section

2000

ENGINE AND RADIATOR REMOVAL AND INSTALLATION

TABLE OF CONTENTS


| | |
|--------------------|----|
| Engine | 3 |
| Removal | 3 |
| Installation | 13 |
| Radiator | 24 |
| Removal | 24 |
| Installation | 25 |

ENGINE

Removal

IMPORTANT: When disconnecting fuel or hydraulics connections put caps on the fittings and plugs in the hoses to prevent foreign material from entering the system.

STEP 1



BD03A040

Park machine on a level surface and lower bucket to ground. Put articulation lock in LOCKED position.

STEP 2

Turn the ignition switch to the run position, place the pilot control switch in the normal operation position (right side of rocker switch depressed).

STEP 3

Move the loader hydraulic control handle to the raise and lower position in order to release any hydraulic pressure in the lift circuit.

STEP 4

Move the loader control handle in and out of the tilt position several times, this will relieve any pressure in the pilot accumulator.

STEP 5

Release the pressure in the ride control accumulator with the bleeder valve in the ride control valve, see ride control valve remove section 8001.

STEP 6

Actuate brake pedal several times to discharge brake accumulators.

STEP 7

Slowly loosen the filler cap for hydraulic reservoir to release air pressure in hydraulic reservoir.

STEP 8



BD07A219

Raise the hood with the hood lift motor. Put master disconnect switch in OFF position. Remove both battery covers and disconnect batteries from the machine.


STEP 9



BD07B106

Tag and disconnect hood wiring harness connector from rear chassis wiring harness connector.

STEP 10



BD07B107

Remove bolts securing harness.

STEP 11

BD07B108

Attach sling left side of the hood.

STEP 12

BD07B109

Attach sling right side of the hood.

STEP 13


BD07B110

Attach a sling to the rear of the hood. Raise and remove weight from the hood lifting motor.

STEP 14


BD07B111

Remove the pin from the top of the lifting motor.

STEP 15


BD07B112

Put punch in the hole to hold washer and bolt from turning while removing nut from inside.

STEP 16

BD07B113

Push bolt and washer away from hinge, do not remove at this time.


STEP 17

BD07B114

Mark wedge and hood for reposition during assembly, remove bolt, washer, and wedge.


STEP 18

Carefully raise and remove hood from loader. Lower hood onto suitable platform and disconnect lifting equipment.

STEP 19

BD07B115

Loosen clamp and remove inlet air hood.

STEP 20

BD07B116

Remove hand rail bolts.

STEP 21

BD07B117

Loosen hand rail bolts, turn the hand rail out away from the engine hood.

STEP 22

Repeat steps 20 and 21 for the other hand rail.


STEP 23

BD07B118

Remove hood mounting bolts, attach sling to exhaust stack.

STEP 24

Carefully raise and remove hood from loader. Lower hood onto suitable platform and disconnect lifting equipment.

STEP 25

BD07B214


Open the hydraulic reservoir cap. Attach a hose to the hydraulic reservoir drain valve, drain the reservoir.

STEP 26

BD07B176

Open the cooling system deaeration tank cap. Drain the engine oil and engine cooling system.

NOTE: *The oil cooler will not drain by draining the reservoir.*

STEP 27

BD07B296

Located behind the rear axle on the right side of the frame, disconnect the return line from the oil cooler, drain the oil cooler.

STEP 28

If loader is equipped with air conditioning, recover the freon. Refer to section 9003.

STEP 29

BD07B199

Release the latch on the fan shroud and open the shroud.

STEP 30


BD07B200

Tag and disconnect fan hoses.

STEP 31


BD07B204

Tag and disconnect four oil cooler hoses.

STEP 32


BD07B205

Disconnect the lower radiator hose and cooling pack grounding wire.

STEP 33


BD07B206

Tag and disconnect the fuel cooler hoses from the fuel cooler, remove brackets securing fuel hoses to cooler pack.

STEP 34

BD07B230

Disconnect the fuel tank vent hose.


STEP 35

BD07B221

Disconnect the top hose from the condenser.


STEP 36

<https://www.arepairmanual.com/downloads/case-921e-wheel-loader-service-repair-manual-84299249/>



Loosen clamps and remove upper radiator hose and tube. Loosen the clamps and remove the hoses from the after cooler. Loosen clamp and disconnect radiator vent hose, disconnect cooling level sensor.

STEP 37



Attach lifting equipment to the lifting points on cooler pack.

STEP 38




Remove the mounting bolts for the cooler pack.

STEP 39


Carefully raise and remove cooler pack from loader. Lower cooler pack onto suitable platform and disconnect lifting equipment.

STEP 40



Loosen the hose clamps, disconnect and remove the after cooler tubes from the machine.

STEP 41



Loosen the hose clamps, disconnect the turbo inlet hose. Loosen the clamp and disconnect the muffler flex pipe from the turbo.

Sample of manual. Download All 848 pages at:

<https://www.arepairmanual.com/downloads/case-921e-wheel-loader-service-repair-manual-84299249/>