




Product: Cummins ISB and QSB5.9 Engines Service Repair Manual

Full Download: <https://www.aresairmanual.com/downloads/cummins-isb-and-qs5-9-engines-service-repair-manual/>

Troubleshooting and Repair Manual ISB and QSB5.9 Engines

U.S.A., Canada, Australia, New Zealand, and Puerto Rico

Open front screen



Sample of manual. Download All 739 pages at:

<https://www.aresairmanual.com/downloads/cummins-isb-and-qs5-9-engines-service-repair-manual/>


Product: Cummins ISB and QSB5.9 Engines Service Repair Manual
Full Download: <https://www.arepairmanual.com/downloads/cummins-isb-and-qsb5-9-engines-service-repair-manual/>

Sample of manual. Download All 739 pages at:
<https://www.arepairmanual.com/downloads/cummins-isb-and-qsb5-9-engines-service-repair-manual/>



Troubleshooting and Repair Manual ISB and QSB5.9 Engines

U.S.A., Canada, Australia, New Zealand, and Puerto Rico



00900062

Copyright© 1999
Cummins Engine Company, Inc.
All rights reserved

Bulletin No. 3666193-01
Printed 2/99

Foreword

This manual provides instructions for troubleshooting and repairing this engine in the chassis. Component and assembly rebuild procedures are provided in the engine shop manual. Refer to Section i - Introduction for instructions on how to use this manual.

Read and follow all safety instructions. Refer to the WARNING in the General Safety Instructions in Section i - Introduction.

The manual is organized to guide a service technician through the logical steps of identifying and correcting problems related to the engine. This manual does not cover vehicle or equipment problems. Consult the vehicle or equipment manufacturer for repair procedures.

A series of specific service manuals (for example: Shop, Specifications, and Alternative Repair) are available and can be ordered by filling out and mailing the Literature Order Form located in Section L - Service Literature.

The repair procedures used in this manual are recommended by Cummins Engine Co., Inc. Some service procedures require the use of special service tools. Use the correct tools as described.

Cummins Engine Company, Inc. encourages the user of this manual to report errors, omissions, and recommendations for improvement. Please use the postage paid, pre-addressed Literature Survey Form in the back of this manual for communicating your comments.

The specifications and rebuild information in this manual are based on the information in effect at the time of printing. Cummins Engine Company, Inc. reserves the right to make any changes at any time without obligation. If differences are found between your engine and the information in this manual, contact a Cummins Authorized Repair Location or call 1-800-DIESELS (1-800-343-7357) toll free in the U.S. and Canada.

The latest technology and the highest quality components are used to manufacture Cummins engines. When replacement parts are needed, we recommend using only genuine Cummins or ReCon® exchange parts. These parts can be identified by the following trademarks:



Table of Contents

	Section	
Introduction	I	
Engine Identification	E	
Troubleshooting Symptoms	TS	
Complete Engine — Group 00	0	
Cylinder Block — Group 01	1	
Cylinder Head — Group 02	2	
Rocker Levers — Group 03	3	
Cam Followers/Tappets — Group 04	4	
Fuel System — Group 05	5	
Injectors and Fuel Lines — Group 06	6	
Lubricating Oil System — Group 07	7	
Cooling System — Group 08	8	
Drive Units — Group 09	9	
Air Intake System — Group 10	10	
Exhaust System — Group 11	11	
Compressed Air System — Group 12	12	
Electrical Equipment — Group 13	13	
Engine Testing — Group 14	14	
Mounting Adaptations — Group 16	16	
Miscellaneous — Group 17	17	
Vehicle Braking — Group 20	20	
Service Literature	L	
Component Manufacturers	M	
Specifications	V	
Index	X	



Section i - Introduction

Section Contents

	Page
About the Manual	i-1
Acronyms and Abbreviations	i-7
General Cleaning Instructions	i-6
Glass or Plastic Bead Cleaning	i-6
Solvent and Acid Cleaning	i-6
Steam Cleaning	i-6
General Repair Instructions	i-5
General Safety Instructions	i-4
Important Safety Notice	i-4
How to Use the Manual	i-1
Illustrations	i-3
Symbols	i-2

THIS PAGE LEFT INTENTIONALLY BLANK.

About the Manual

This ISB Engine Troubleshooting and Repair Manual is intended to aid in determining the cause of engine-related problems and to provide recommended repair procedures. The manual is divided into sections by system. Each section provides general information, specifications, diagrams, and service tools where applicable. The specific repair procedures are referenced in the Troubleshooting Symptoms Charts.

How to Use the Manual

The manual is organized to provide an easy flow from problem identification to problem correction. A list of troubleshooting symptoms containing the most common engine problems begins on Page T-a in Section TS - Troubleshooting Symptoms. Complete the following steps to locate and correct the problem.

- (Step 1.) Locate the symptom on the list.
Refer to the procedure number where the Troubleshooting Symptoms Chart is found.
- (Step 2.) The left column of the Troubleshooting Symptoms Chart indicates a problem cause, starting at the top with the simplest and easiest to repair, and continuing downward to the most difficult.
The right column provides a brief description of the corrective action, with the reference number, for the repair.
- (Step 3.) Locate the probable cause in the left column, and then turn to the procedure number in the right column.
The repair procedures are listed by system (Cooling, Lubricating Oil, Combustion Air, Compressed Air, Fuel, Electrical, and Base Engine Components).
- (Step 4.) The Troubleshooting Symptoms Charts are based on the following assumptions:
1. The engine has been installed according to the manufacturer's specifications.
 2. The easiest repairs are done first.
 3. "Generic" solutions cover problems with the most common applications and original equipment manufacturers (OEM).

Symbols

The following group of symbols have been used in this manual to help communicate the intent of the instructions. When one of the symbols appears, it conveys the meaning defined below.



WARNING - Provides a warning to take precaution to avoid bodily injury from electrical shock or electrocution. There is in the vicinity uninsulated high A.C. voltage.



WARNING - Serious personal injury or extensive property damage can result if the warning instructions are not followed.



CAUTION - Minor personal injury can result or a part, an assembly or the engine can be damaged if the caution instructions are not followed.



Indicates a **REMOVAL** or **DISASSEMBLY** step.



Indicates an **INSTALLATION** or **ASSEMBLY** step.



INSPECTION is required.



CLEAN the part or assembly.



PERFORM a mechanical or time **MEASUREMENT**.



LUBRICATE the part or assembly.



Indicates that a **WRENCH** or **TOOL SIZE** will be given.



TIGHTEN to a specific torque.



PERFORM an electrical **MEASUREMENT**.



Refer to another location in this manual or another publication for additional information.



The main circuit breaker is closed and normal power is being supplied to the equipment.



The main circuit breaker must be open so that normal power is not being supplied to the equipment.



The generator set is on and supplying power to the equipment.



The generator set must be off and not supplying power to the equipment.



The wiring harness disconnect plug must be disconnected.




The component weighs 23 kg [50 lb] or more. To avoid personal injury, use a hoist or get assistance to lift the component.


17800001

Illustrations

Some of the illustrations throughout this manual are generic and will **not** look exactly like the engine or parts used in your application. The illustrations can contain symbols to indicate an action required and an acceptable or **not** acceptable condition.



The illustrations are intended to show repair or replacement procedures. The procedure will be the same for all applications, although the illustration can differ.



General Safety Instructions

Important Safety Notice



Improper practices or carelessness can cause burns, cuts, mutilation, asphyxiation or other bodily injury or death.

Read and understand all of the safety precautions and warnings before performing any repair. This list contains the general safety precautions that **must** be followed to provide personal safety. Special safety precautions are included in the procedures when they apply.

- Make sure the work area surrounding the product is dry, well lit, ventilated, free from clutter, loose tools, parts, ignition sources and hazardous substances. Be aware of hazardous conditions that can exist.
- **Always** wear protective glasses and protective shoes when working.
- Rotating parts can cause cuts, mutilation or strangulation.
- Do **not** wear loose-fitting or torn clothing. Remove all jewelry when working.
- Disconnect the battery (negative [-] cable first) and discharge any capacitors before beginning any repair work. Disconnect the air starting motor if equipped to prevent accidental engine starting. Put a "Do Not Operate" tag in the operator's compartment or on the controls.
- Use **ONLY** the proper engine barring techniques for manually rotating the engine. Do **not** attempt to rotate the crankshaft by pulling or prying on the fan. This practice can cause serious personal injury, property damage, or damage to the fan blade(s) causing premature fan failure.
- If an engine has been operating and the coolant is hot, allow the engine to cool before you slowly loosen the filler cap and relieve the pressure from the cooling system.
- Do **not** work on anything that is supported **ONLY** by lifting jacks or a hoist. **Always** use blocks or proper stands to support the product before performing any service work.
- Relieve all pressure in the air, oil, fuel and the cooling systems before any lines, fittings, or related items are removed or disconnected. Be alert for possible pressure when disconnecting any device from a system that utilizes pressure. Do **not** check for pressure leaks with your hand. High pressure oil or fuel can cause personal injury.
- To prevent suffocation and frostbite, wear protective clothing and **ONLY** disconnect fuel and liquid refrigerant (freon) lines in a well ventilated area. To protect the environment, liquid refrigerant systems **must** be properly emptied and filled using equipment that prevents the release of refrigerant gas (fluorocarbons) into the atmosphere. Federal law requires capturing and recycling refrigerant.
- To avoid personal injury, use a hoist or get assistance when lifting components that weigh 23 kg [50 lb] or more. Make sure all lifting devices such as chains, hooks, or slings are in good condition and are of the correct capacity. Make sure hooks are positioned correctly. **Always** use a spreader bar when necessary. The lifting hooks **must not** be side-loaded.
- Corrosion inhibitor, a component of SCA and lubricating oil, contains alkali. Do **not** get the substance in your eyes. Avoid prolonged or repeated contact with skin. Do **not** swallow internally. In case of contact, immediately wash skin with soap and water. In case of contact, immediately flood eyes with large amounts of water for a minimum of 15 minutes. **IMMEDIATELY CALL A PHYSICIAN. KEEP OUT OF REACH OF CHILDREN.**
- Naptha and Methyl Ethyl Ketone (MEK) are flammable materials and **must** be used with caution. Follow the manufacturer's instructions to provide complete safety when using these materials. **KEEP OUT OF REACH OF CHILDREN.**
- To avoid burns, be alert for hot parts on products that have just been turned off, and hot fluids in lines, tubes, and compartments.
- **Always** use tools that are in good condition. Make sure you understand how to use them before performing any service work. Use **ONLY** genuine Cummins or Cummins ReCon® replacement parts.
- **Always** use the same fastener part number (or equivalent) when replacing fasteners. Do **not** use a fastener of lesser quality if replacements are necessary.
- Do **not** perform any repair when fatigued or after consuming alcohol or drugs that can impair your functioning.
- Some state and federal agencies in the United States of America have determined that used engine oil can be carcinogenic and can cause reproductive toxicity. Avoid inhalation of vapors, ingestion, and prolonged contact with used engine oil.

General Repair Instructions

This engine incorporates the latest technology at the time it was manufactured; yet, it is designed to be repaired using normal repair practices performed to quality standards.

- **Cummins Engine Company, Inc. does not recommend or authorize any modifications or repairs to engines or components except for those detailed in Cummins Service Information. In particular, unauthorized repair to safety-related components can cause personal injury or death. Below is a partial listing of components classified as safety-related:**

Air Compressor
Air Controls
Air Shutoff Assemblies
Balance Weights
Cooling Fan
Fan Hub Assembly
Fan Mounting Bracket(s)
Fan Mounting Capscrews
Fan Hub Spindle
Flywheel
Flywheel Crankshaft Adapter

Flywheel Mounting Capscrews
Fuel Shutoff Assemblies
Fuel Supply Tubes
Lifting Brackets
Throttle Controls
Turbocharger Compressor Casing
Turbocharger Oil Drain Line(s)
Turbocharger Oil Supply Line(s)
Turbocharger Turbine Casing
Vibration Damper Mounting Capscrews

- **Follow all safety instructions noted in the procedures**
 - Follow the manufacturer's recommendations for cleaning solvents and other substances used during the repair of the engine. Some solvents and used engine oil have been identified by government agencies as toxic or carcinogenic. Avoid excessive breathing, ingestion and contact with such substances. **Always** use good safety practices with tools and equipment.
- **Provide a clean environment and follow the cleaning instructions specified in the procedures**
 - The engine and its components **must** be kept clean during any repair. Contamination of the engine or components will cause premature wear.
- **Perform the inspections specified in the procedures**
- **Replace all components or assemblies which are damaged or worn beyond the specifications**
- **Use genuine Cummins new or ReCon® service parts and assemblies**
 - The assembly instructions have been written to use again as many components and assemblies as possible. When it is necessary to replace a component or assembly, the procedure is based on the use of new Cummins or Cummins ReCon® components. All of the repair services described in this manual are available from all Cummins Distributors and most Dealer locations.
- **Follow the specified disassembly and assembly procedures to avoid damage to the components**

Complete rebuild instructions are available in the shop manual which can be ordered or purchased from a Cummins Authorized Repair Location. Refer to Section L — Service Literature for ordering instructions.

General Cleaning Instructions

Solvent and Acid Cleaning

Several solvent and acid-type cleaners can be used to clean the engine parts. Experience has shown that the best results can be obtained using a cleaner that can be heated to 90 to 95 degrees Celsius [180 to 200 degrees Fahrenheit]. A cleaning tank that provides a constant mixing and filtering of the cleaning solution will give the best results. **Cummins Engine Company, Inc. does not recommend any specific cleaners. Always follow the cleaner manufacturer's instructions.**

Remove all the gasket material, o-rings, and the deposits of sludge, carbon, etc., with a wire brush or scraper before putting the parts in a cleaning tank. Be careful not to damage any gasket surfaces. When possible, steam clean the parts before putting them in the cleaning tank.

▲ WARNING ▲

Acid is extremely dangerous and can cause personal injury and damage the machinery. Always provide a tank of strong soda water as a neutralizing agent.

Rinse all of the parts in hot water after cleaning. Dry completely with compressed air. Blow the rinsed water from all of the capscrew holes and the oil drillings.

If the parts are not to be used immediately after cleaning, dip them in a suitable rustproofing compound. The rustproofing compound **must** be removed from the parts before installation on the engine.

Steam Cleaning

Steam cleaning can be used to remove all types of dirt that can contaminate the cleaning tank. It is a good way to clean the oil drillings.

▲ WARNING ▲

Wear protective clothing to prevent personal injury from the high pressure and extreme heat.

Do not steam clean the following parts:

- | | |
|--------------------------|--------------------|
| 1. Electrical Components | 4. Fuel Pump |
| 2. Wiring | 5. Belts and Hoses |
| 3. Injectors | 6. Bearings |

Glass or Plastic Bead Cleaning

Glass or plastic bead cleaning can be used on many engine components to remove carbon deposits. The cleaning process is controlled by the size of the glass or plastic beads, the operating pressure, and the cleaning time.

▲ CAUTION ▲

Do not use glass or plastic bead cleaning on aluminum piston skirts. Do not use glass bead cleaning on aluminum ring grooves. Small particles of glass or plastic will embed in the aluminum and result in premature wear. Valves, turbocharger shafts, etc., can also be damaged. Follow the cleaning directions listed in the procedures.

NOTE: Plastic bead blasting media, Part No. 3822735, can be used to clean aluminum ring grooves. Do not use any bead blasting media on pin bores or aluminum skirts.

Follow the equipment manufacturer's cleaning instructions. The following guidelines can be used to adapt to manufacturer's instructions:

1. Bead size:
 - a. Use U.S. size No. 16-20 for piston cleaning with plastic bead media, Part No. 3822735.
 - b. Use U.S. size No. 70 for piston domes with glass media.
 - c. Use U.S. size No. 60 for general purpose cleaning with glass media.
2. Operating Pressure:
 - a. Glass: Use 620 kPa [90 psi] for general purpose cleaning.
 - b. Plastic: Use 270 kPa [40 psi] for piston cleaning.
3. Steam clean or wash the parts with solvent to remove all of the foreign material and glass or plastic beads after cleaning. Rinse with hot water. Dry with compressed air.
4. Do not contaminate the wash tanks with glass or plastic beads.

Acronyms and Abbreviations

AFC	Air Fuel Control	kPa	Kilopascal
API	American Petroleum Institute	LNG	Liquid Natural Gas
ASA	Air Signal Attenuator	LTA	Low Temperature Aftercooling
ASTM	American Society of Testing and Materials	MIP	Mixer Inlet Pressure
°C	Celsius	MPa	Megapascal
CARB	California Air Resources Board	mph	Miles Per Hour
C.I.D.	Cubic Inch Displacement	mpq	Miles Per Quart
CNG	Compressed Natural Gas	N•m	Newton-meter
CPL	Control Parts List	NG	Natural Gas
cSt	Centistokes	OEM	Original Equipment Manufacturer
ECM	Electronic Control Module	ppm	Parts Per Million
ECS	Emission Control System	psi	Pounds Per Square Inch
EPA	Environmental Protection Agency	PTO	Power Takeoff
EPS	Engine Position Sensor	rpm	Revolutions Per Minute
°F	Fahrenheit	SAE	Society of Automotive Engineers
GVW	Gross Vehicle Weight	SCA	Supplemental Coolant Additive
Hg	Mercury	STC	Step Timing Control
hp	Horsepower	VS	Variable Speed
H₂O	Water	VSS	Vehicle Speed Sensor
ICM	Ignition Control Module		
km/l	Kilometers per Liter		

Section E - Engine Identification

Section Contents


	Page
Engine Diagrams	E-5
Engine Views	E-5
Engine Identification	E-1
Cummins Engine Nomenclature	E-2
ECM Dataplate	E-2
Engine Dataplate	E-1
Fuel Injection Pump Dataplate	E-2
Specifications	E-3
Air Intake System	E-4
Cooling System	E-4
Electrical System	E-4
Exhaust System	E-4
Fuel System	E-3
General Specifications	E-3
Lubricating Oil System	E-3

THIS PAGE LEFT INTENTIONALLY BLANK.

Engine Identification


Engine Dataplate

The engine dataplate shows specific facts about your engine. The engine serial number and CPL provide data for ordering parts and service. The engine dataplate **must not** be changed unless approved by Cummins Engine Company, Inc.





Have the following engine data available when communicating with a Cummins Authorized Repair Location. The information on the dataplate is **mandatory** when sourcing service parts.

1. Engine serial number
2. Control parts list (CPL)
3. Model
4. Horsepower and rpm rating.




NOTE: If the engine dataplate (1) is not readable, the engine serial number (2) can be identified on the engine block on top of the lubricating oil cooler housing. Additional engine information is available by reading the ECM dataplate.





Cummins Engine Nomenclature


The Cummins engine nomenclature provides the data as illustrated in the graphic.



Fuel Injection Pump Dataplate

The VP44 fuel injection pump dataplate is located on the side of the fuel pump. The dataplate contains the following information:

- Order number (A)
- Bosch® part number (B)
- Factory code (C)
- Cummins part number (D)
- Manufacture date (E)
- Pump serial number (F)
- Last three digits of the key part number (G).



ECM Dataplate

The ECM dataplate shows information about your ECM and how the ECM was programmed. The dataplate is located on the ECM, above the ECM connectors.

The following information is available on the ECM dataplate:

- ECM part number
- ECM serial number
- ECM date code
- Engine serial number
- ECM code: Software number.

NOTE: Have the ECM code for your engine available when communicating with a Cummins Authorized Repair Location.

Specifications

General Specifications

Horsepower (refer to engine dataplate)

Bore and Stroke 102 mm [4.02 in] X 120 mm [4.72 in]

Displacement 5.9 liters [359 C.I.D.]

Compression Ratio 16.5:1

Firing Order 1-5-3-6-2-4

Engine Weight (with standard accessories):

Dry Weight 458 kg [1010 lb]

Crankshaft Rotation (viewed from the front of the engine) **Clockwise**

Valve Clearance:

Intake 0.025 mm [0.010 in]

Exhaust 0.051 mm [0.020 in]

NOTE: The ISB engine features a no-adjust overhead. The ISB valve train is designed such that adjustment of the valve lash is **not** required for normal service during the first 241,402 km [150,000 mi]. The valve train operates acceptably within the limits of 0.152- to 0.381-mm [0.006- to 0.015-in] intake valve lash and 0.381- to 0.762-mm [0.015- to 0.030-in] exhaust valve lash.

Fuel System

For performance and fuel rate values, refer to the Engine Data Sheet or the fuel injection pump for the particular model involved.

Engine Idle Speed 700 to 1000 rpm

Maximum Fuel Inlet Restriction to Lift Pump 20 kPa [6 in Hg]

Maximum Fuel Pressure at Fuel Filter Outlet (engine cranking) 28 to 55 kPa [4 to 8 psi]

Minimum Fuel Pressure at Fuel Filter Inlet (engine running) 55 to 117 kPa [8 to 17 psi]

Maximum Pressure Drop Across Fuel Filter 34 kPa [5 psi]

Fuel Drain Line Maximum Restriction 69 kPa [10 psi]

Fuel Inlet Maximum Temperature 74°C [165°F]

Engine Minimum Cranking Speed 150 rpm

Lubricating Oil System

Oil Pressure:

Low Idle (minimum allowed) 103 kPa [15 psi]

At Rated Speed (minimum allowed) 310 kPa [45 psi]

Regulated Pressure 414 kPa [60 psi]

Oil Capacity of Standard Engine:

Standard

Pan Only 14.2 liters [15 qt]

Total System 16.4 liters [17 qt]

Deep Sump

Pan Only 16.1 liters [17 qt]

Total System 18.3 liters [19 qt]

Oil Pan High - Low

Standard Pan 12 to 14.2 liters [13 to 15 qt]

Deep Sump Pan 14.2 to 16.1 liters [15 to 17 qt]

NOTE: Some applications use a slightly different lubricating oil pan capacity. Contact your local Cummins Distributor if you have questions.

Cooling System

Coolant Capacity (engine only) 9.0 liters [9.5 qt]
 Standard Modulating Thermostat - Range 84 to 91°C [184 to 195°F]
 Maximum Allowed Operating Temperature 100°C [212°F]
 Minimum Recommended Operating Temperature 71°C [160°F]
 Minimum Recommended Pressure Cap 48 kPa [7 psi]

Air Intake System

Maximum Intake Restriction (clean air filter element) 254 mm H₂O [10.0 in H₂O]
 Maximum Intake Restriction (dirty air filter element) 635 mm H₂O [25.0 in H₂O]

Exhaust System

Maximum Back Pressure from Piping and Silencer (combined):
 Hg 76 mm Hg [3 in Hg]
 H₂O 1016 mm H₂O [40 in H₂O]
 Exhaust Pipe Size (normally acceptable inside diameter) 76 mm [3 in]

Electrical System

Minimum Recommended Battery Capacity

System Voltage	Ambient Temperature			
	-18°C [0°F]		0°C [32°F]	
	Cold Cranking Amperes	Reserve Capacity ¹ Amperes	Cold Cranking Amperes	Reserve Capacity ¹ Amperes
12 VDC	1800	640	1280	480
24 VDC ²	900	320	640	240


1. The number of plates within a given battery size determines reserve capacity. Reserve capacity determines the length of time in which sustained cranking can occur.
2. Cold cranking amps (CCA) ratings are based on two 12-VDC batteries in series.

Engine Diagrams

Engine Views

The following illustrations show the locations of the major external engine components, filters, and other service and maintenance points. Some external components will be at different locations for different engine models.

NOTE: The illustrations are **only** a reference showing a typical engine.




00900035

Front View

1. Fan pulley
2. Top dead center indication
3. Air compressor
4. Front gear cover
5. Vibration damper


6. Water pump
7. Turbocharger air inlet
8. Alternator
9. Turbocharger air outlet
10. Automatic belt tensioner
11. Coolant temperature sensor.



00900032

Air Intake Side View

- | | |
|---|-------------------------------------|
| 1. Engine air inlet | 11. Dipstick |
| 2. M10 (STOR) fuel pressure after filter | 12. Engine position sensor (EPS) |
| 3. M10 (STOR) fuel pressure before filter | 13. M10 (STOR) oil pressure |
| 4. Intake manifold pressure sensor | 14. Oil pressure sensor |
| 5. Intake manifold temperature sensor | 15. Electronic control module (ECM) |
| 6. Fuel filter/water separator | 16. Engine diagnostic sensor |
| 7. Magnetic pickup location (3/4-inch-16 UNF) | 17. Engine dataplate |
| 8. Fuel return connection | 18. High-pressure fuel lines |
| 9. Fuel inlet connection | 19. Fuel injection pump |
| 10. Fuel lift pump | 20. Intake air preheater. |




00900034

Exhaust Side View

- 1. Starter motor and solenoid
- 2. 1/2-inch (NPTF) coolant taps
- 3. Oil fill
- 4. Water outlet
- 5. Front engine lifting bracket
- 6. Lubricating oil filter


- 7. Water inlet
- 8. Lubricating oil cooler
- 9. Oil drain
- 10. Provision for coolant heater
- 11. Turbocharger wastegate actuator
- 12. Coolant vent fitting.



00900033

Rear View

1. Rear engine lifting bracket
2. Turbocharger exhaust outlet
3. Clutch mounting holes
4. Flywheel housing
5. Flywheel/flexplate.



19900841

Top View

1. Engine air inlet
2. Coolant temperature sensor
3. Exhaust manifold
4. Turbocharger
5. Coolant vent fitting.

Section TS - Troubleshooting Symptoms

Section Contents

	Page
Troubleshooting Procedures and Techniques	TS-1
Troubleshooting Symptoms Charts	TS-2
Air Compressor Air Pressure Rises Slowly	TS-3
Air Compressor Cycles Frequently	TS-4
Air Compressor Noise is Excessive	TS-6
Air Compressor Pumping Excess Lubricating Oil into the Air System	TS-8
Air Compressor Will Not Maintain Adequate Air Pressure (Not Pumping Continuously).....	TS-10
Air Compressor Will Not Pump Air.....	TS-11
Air Compressor Will Not Stop Pumping.....	TS-12
Alternator Not Charging or Insufficient Charging	TS-13
Alternator Overcharging	TS-14
Communication Error – Electronic Service Tool or Control Device	TS-15
Connecting Rod Bearing Noise	TS-117
Coolant in the Lubricating Oil.....	TS-26
Coolant Loss – External	TS-18
Coolant Loss – Internal	TS-19
Coolant Temperature Above Normal – Gradual Overheat.....	TS-20
Coolant Temperature is Above Normal – Sudden Overheat.....	TS-23
Coolant Temperature is Below Normal.....	TS-25
Crankcase Gases (Blowby) Excessive	TS-27
Cranking Fuel Pressure is Low.....	TS-28
Driveability – General Information	TS-118
Driveability/Low Power – Customer Complaint Form	TS-119
Driveability/Low Power/Excessive Fuel Consumption – Checklist	TS-120
Engine Acceleration or Response Poor.....	TS-29
Engine Decelerates Slowly	TS-34
Engine Difficult to Start or Will Not Start (Exhaust Smoke)	TS-35
Engine Difficult to Start or Will Not Start (No Exhaust Smoke).....	TS-39
Engine Noise Diagnostic Procedures – General Information	TS-117
Engine Noise Excessive	TS-42
Engine Noise Excessive – Combustion Knocks.....	TS-45
Engine Noise Excessive – Connecting Rod	TS-46
Engine Noise Excessive – Main Bearing.....	TS-47
Engine Noise Excessive – Piston.....	TS-48
Engine Noise Excessive – Turbocharger	TS-49
Engine Power Output Low.....	TS-50
Engine Runs Rough at Idle	TS-56
Engine Runs Rough or Misfires.....	TS-59
Engine Shuts Off Unexpectedly or Dies During Deceleration.....	TS-62
Engine Speed Surges at Low or High Idle.....	TS-64
Engine Speed Surges in PTO or Cruise Control	TS-72
Engine Speed Surges Under Load or in Operating Range.....	TS-68
Engine Starts But Will Not Keep Running.....	TS-74
Engine Vibration Excessive	TS-76
Engine Will Not Crank or Cranks Slowly (Air Starter).....	TS-78
Engine Will Not Crank or Cranks Slowly (Electric Starter).....	TS-80
Engine Will Not Reach Rated Speed (RPM)	TS-83
Engine Will Not Shut Off	TS-85
Fault Code Warning Lamps Do Not Illuminate	TS-87
Fault Code Warning Lamps Stay On (No Apparent Reason)	TS-86
Fuel Consumption - General Information	TS-121
Fuel Consumption Excessive.....	TS-88
Fuel Consumption – Customer Complaint Form	TS-122
Fuel in Coolant.....	TS-92
Fuel in the Lubricating Oil	TS-93
Intake Manifold Air Temperature Above Specification.....	TS-94
Intake Manifold Pressure (Boost) is Below Normal.....	TS-96
Low Idle Adjust Switch Does Not Work.....	TS-98
Lubricating Oil Consumption Excessive.....	TS-99
Lubricating Oil Contaminated.....	TS-101
Lubricating Oil Pressure High.....	TS-102
Lubricating Oil Pressure Low	TS-103
Lubricating Oil Sludge in the Crankcase Excessive.....	TS-105

	Page
Lubricating Oil Temperature Above Specification	TS-106
Lubricating or Transmission Oil in the Coolant	TS-107
Main Bearing Noise	TS-117
Oil Consumption	TS-123
Piston Noise	TS-117
PTO or Cruise Control Does Not Operate	TS-108
Smoke, Black — Excessive	TS-110
Smoke, White — Excessive	TS-113
Turbocharger Leaks Engine Oil or Fuel	TS-116