



# Service Manual

## ROBOT 150, 165

PUBLISHED BY THE  
TECHNICAL PUBLICATIONS DEPARTMENT  
OF JCB SERVICE; ©  
WATERLOO PARK, UTTOXETER,  
STAFFORDSHIRE, ST14 5PA, ENGLAND  
Tel. ROCESTER (01889) 590312  
PRINTED IN ENGLAND

Publication No. 9803/8500

Sample of manual. Download All 254 pages at:

<https://www.arepairmanual.com/downloads/jcb-robot-150165-skid-steer-loader-service-repair-manual/>

<b>General Information</b>	<b>1</b>
<b>Care &amp; Safety</b>	<b>2</b>
<b>Routine Maintenance</b>	<b>3</b>
<b>Attachments</b>	<b>A</b>
<b>Body &amp; Framework</b>	<b>B</b>
<b>Electrics</b>	<b>C</b>
<b>Controls</b>	<b>D</b>
<b>Hydraulics</b>	<b>E</b>
<b>Transmission</b>	<b>F</b>
<b>Brakes</b>	<b>G</b>
<b>Engine</b>	<b>K</b>

Product: JCB ROBOT 150,165 Skid Steer Loader Service Repair Manual  
Full Download: <https://www.arepairmanual.com/downloads/jcb-robot-150165-skid-steer-loader-service-repair-manual/>

Sample of manual. Download All 254 pages at:  
<https://www.arepairmanual.com/downloads/jcb-robot-150165-skid-steer-loader-service-repair-manual/>

---

## Introduction

This publication is designed for the benefit of JCB Distributor Service Engineers who are receiving, or have received, training by JCB Technical Training Department.

These personnel should have a sound knowledge of workshop practice, safety procedures, and general techniques associated with the maintenance and repair of hydraulic earthmoving equipment.

Renewal of oil seals, gaskets, etc., and any component showing obvious signs of wear or damage is expected as a matter of course. It is expected that components will be cleaned and lubricated where appropriate, and that any opened hose or pipe connections will be blanked to prevent excessive loss of hydraulic fluid and ingress of dirt. Finally, please remember above all else **SAFETY MUST COME FIRST!**

The manual is compiled in sections, the first three are numbered and contain information as follows:

<b>1</b>	=	<b>General Information</b> - includes torque settings and service tools.
<b>2</b>	=	<b>Care &amp; Safety</b> - includes warnings and cautions pertinent to aspects of workshop procedures etc.
<b>3</b>	=	<b>Routine Maintenance</b> - includes service schedules and recommended lubricants for all the machine.

The remaining sections are alphabetically coded and deal with Dismantling, Overhaul etc. of specific components, for example:

<b>A</b>	=	<b>Attachments</b>
<b>B</b>	=	<b>Body &amp; Framework</b> ...etc.

The page numbering in each alphabetically coded section is not continuous. This allows for the insertion of new items in later issues of the manual.

Section contents, technical data, circuit descriptions, operation descriptions etc are inserted at the beginning of each alphabetically coded section.

All sections are listed on the front cover; tabbed divider cards align directly with individual sections on the front cover for rapid reference.

Where a torque setting is given as a single figure it may be varied by plus or minus 3%. Torque figures indicated are for dry threads, hence for lubricated threads may be reduced by one third.


With the exception of slewing operations 'Left Hand' and 'Right Hand' are as viewed from the rear of the machine facing forwards.

<b>Contents</b>	<b>Page No.</b>
Identifying your Machine	1 - 1
Torque Settings	2 - 1
Service Tools	
- Numerical List	3 - 1
- Electrics	4 - 1
- Hydraulics	4 - 2
Sealing and Retaining Compounds	5 - 1

The serial number of the chassis, engine, lift arm and hydraulic pump unit positively identify the type of JCB Skid Steer Loader you have.

### Machine Identification Plate

The machine identification plate **A** is located as shown. It is stamped with the serial numbers of the major individual units.



### Typical Vehicle Identification Number (VIN)

SLP 165 S B V E 677001  
 ① ② ③ ④ ⑤ ⑥ ⑦

- ① World Manufacturer Identification
- ② Machine Model
- ③ Machine Type (S = Standard, H = High-flow)
- ④ Build Type (A = Canopy, B = Cab)
- ⑤ Year of Manufacture:  
 T = 1996                      1 = 2001  
 V = 1997                      2 = 2002  
 W = 1998                      3 = 2003  
 X = 1999                      4 = 2004  
 Y = 2000                      5 = 2005
- ⑥ Manufacturer Location (E = England)
- ⑦ Product Identification Number (PIN)

**J.C. BAMFORD EXCAVATORS LTD.**  
 ROCESTER, STAFFS, ENGLAND.

CONSTRUCTOR                      MADE IN UK

Vehicle Identification No.                      Product Identification No.

ENGINE SERIAL No.                      WEIGHT

PUMP SERIAL No.                      YEAR OF MANUFACTURE

MODEL	80/1269/EEC		MODEL	80/1269/EEC	
	POWER KW	R.P.M.		POWER KW	R.P.M.
150	35	2800	1CX	35	2800
165	35	2800	1CX HF	35	2800
165 HF	35	2800	185	52	2200
			185 HF	52	2200

817/04437

## Unit Identification






\* The engine serial number on XUD engines is stamped on a machined area **B** on the top of the cylinder block. On JCB Diesel engines the number is stamped on a label **G** on the left side of the cylinder block.

The chassis serial number is stamped on the front edge of the right hand mudguard as shown at **C**. On early machines the serial number is stamped on the right hand side of the machine as shown at **F**.

The lift arm serial number is stamped on the rear of the lift arm as shown at **D**.


The hydraulic pump unit serial number is stamped on a plate on the top of the pump at **E**.

If any of the above units are replaced with new ones, the relevant serial number on the Machine Identification Plate will be superseded. Either stamp the plate with the new number or stamp out the old number.



## Left Side, Right Side

In this manual, 'left' **X** and 'right' **Y** mean your left and right when you are seated correctly in the machine.



S173660

Use only where no torque setting is specified in the text. Values are for dry threads and may be within three per cent of the figures stated. For lubricated threads the values should be REDUCED by one third.

**UNF Grade 'S' Bolts**

Bolt Size in	(mm)	Hexagon (A/F) in	Torque Settings		
			Nm	kgf m	lbf ft
1/4	(6.3)	7/16	14	1.4	10
* 5/16	(7.9)	1/2	28	2.8	20
3/8	(9.5)	9/16	49	5.0	36
7/16	(11.1)	5/8	78	8.0	58
1/2	(12.7)	3/4	117	12.0	87
9/16	(14.3)	13/16	170	17.3	125
5/8	(15.9)	15/16	238	24.3	175
3/4	(19.0)	1 1/8	407	41.5	300
7/8	(22.2)	1 5/16	650	66.3	480
1	(25.4)	1 1/2	970	99.0	715
1 1/4	(31.7)	1 7/8	1940	198.0	1430
1 1/2	(38.1)	2 1/4	3390	345.0	2500

**Metric Grade 8.8 Bolts**


Bolt Size in	(mm)	Hexagon (A/F) in	Torque Settings		
			Nm	kgf m	lbf ft
M5	(5)	8	7	0.7	5
M6	(6)	10	12	1.2	9
M8	(8)	13	28	3.0	21
M10	(10)	17	56	5.7	42
M12	(12)	19	98	10	72
M16	(16)	24	244	25	180
M20	(20)	30	476	48	352
M24	(24)	36	822	84	607
M30	(30)	46	1633	166	1205
M36	(36)	55	2854	291	2105

**Note:** All bolts used on JCB machines are high tensile and must not be replaced by bolts of a lesser tensile specification.

## Numerical List

		Page No.			Page No.
1406/0011	Bonded Washer	4 - 3	892/00268	Flow Monitoring Unit	4 - 2
1406/0018	Bonded Washer	4 - 3	892/00269	Sensor Head	4 - 2
1406/0021	Bonded Washer	4 - 2/4 - 3	892/00270	Load Valve	4 - 2
1406/0029	Bonded Washer	4 - 3	892/00271	Adapter	4 - 2
1604/0003	Adapter	4 - 3	892/00272	Adapter	4 - 2
1604/0004	Adapter	4 - 3	892/00274	Adapter	4 - 3
1604/0006	Adapter	4 - 2/4 - 3	892/00275	Adapter	4 - 2
1606/0003	Adapter	4 - 3	892/00276	Adapter	4 - 2
1606/0004	Adapter	4 - 3	892/00277	Adapter	4 - 2
1606/0007	Adapter	4 - 3	892/00278	Gauge	4 - 3
1606/0008	Adapter	4 - 3	892/00279	Gauge	4 - 3
1606/0009	Adapter	4 - 3	892/00281	AVO Meter	4 - 1
1612/0006	Adapter	4 - 2	892/00282	Shunt	4 - 1
* 4101/0251	Threadlocker and Sealer	5 - 1	892/00283	Tool Kit Case	4 - 1
* 4101/0451	Threadlocker	5 - 1	892/00284	Tachometer	4 - 1
* 4101/0552	Threadlocker and Sealer (High Strength)	5 - 1	892/00285	Hydraulic Oil Temperature Probe	4 - 1
* 4101/0651	Retainer (High Strength)	5 - 1	892/00286	Surface Temperature Probe	4 - 1
* 4102/0551	High Strength Threadlocker	5 - 1	892/00706	Test Probe	4 - 3
4102/1201	Multi-Gasket	5 - 1	892/00858	Pump Support Bracket	4 - 3
* 4104/0251	Activator (Aerosol)	5 - 1	892/00923	A.R.V Test Block - Commercial Hyd.	4 - 3
* 4104/0253	Activator (Bottle)	5 - 1	992/09300	Spanner	4 - 3
* 4104/1557	JCB Cleaner/Degreaser	5 - 1	992/09400	Spanner	4 - 3
816/00189	Blanking Cap	4 - 4	992/09500	Spanner	4 - 3
816/00190	Blanking Cap	4 - 4	992/09600	Spanner	4 - 3
816/00193	Blanking Cap	4 - 4	993/68100	Slide Hammer	4 - 4
816/00196	Blanking Cap	4 - 4	993/85700	Battery Tester	4 - 1
816/00197	Blanking Cap	4 - 4	993/99510	Half Moon Spanner	4 - 4
816/00294	Blanking Cap	4 - 4			
816/15118	Pressure Test Adapter	4 - 2		The following parts are replacement items for kits and would normally be included in the kit numbers quoted above.	
816/20008	Adapter	4 - 2			
816/50043	'T' Adapter	4 - 4			
816/55038	Pressure Test 'T' Adapter	4 - 2		Replacement items for kit no. 892/00253	
816/55040	Pressure Test 'T' Adapter	4 - 2	892/00201	Replacement Gauge	4 - 2
816/60096	'T' Adapter	4 - 4	892/00202	Replacement Gauge	4 - 2
892/00047	'T' Adapter	4 - 4	892/00203	Replacement Gauge	4 - 2
892/00048	'T' Adapter	4 - 4	892/00254	Replacement Hose	4 - 2
892/00055	Blanking Plug	4 - 4			
892/00056	Blanking Plug	4 - 4			
892/00057	Blanking Plug	4 - 4			
892/00059	Blanking Plug	4 - 4			
892/00060	Blanking Plug	4 - 4			
892/00074	Female Connector	4 - 4			
892/00075	Female Connector	4 - 4			
892/00077	Female Connector	4 - 4			
892/00137	Hose	4 - 3			
892/00223	Hand Pump	4 - 3			
892/00252	A.R.V Test Block - Husco	4 - 3			
892/00253	Pressure Test Kit	4 - 2			
892/00255	Pressure Test Adapter	4 - 2			
892/00256	Pressure Test Adapter	4 - 2			
892/00257	Pressure Test Adapter	4 - 2			
892/00258	Pressure Test Adapter	4 - 2			
892/00259	Pressure Test Adapter	4 - 2			
892/00260	Pressure Test Adapter	4 - 2			
892/00261	Pressure Test Adapter	4 - 2			
892/00262	Pressure Test 'T' Adapter	4 - 2/4 - 3			
892/00263	Pressure Test 'T' Adapter	4 - 2			
892/00264	Pressure Test 'T' Adapter	4 - 2			
892/00265	Pressure Test 'T' Adapter	4 - 2			


Section C - Electrics



AVO Test Kit

1	892/00283	Tool Kit Case
2	892/00281	AVO Meter
3	892/00286	Surface Temperature Probe
4	892/00284	Microtach Digital Tachometer
5	892/00282	Shunt - open type
6	892/00285	Hydraulic Oil Temperature Probe


188230



\* 993/85700 Battery Tester

239510


Section E - Hydraulics



Hydraulic Circuit Pressure Test Kit

- 892/00253 Pressure Test Kit
- 892/00201 Replacement Gauge 0-20 bar (0-300 lbf/in<sup>2</sup>)
- 892/00202 Replacement Gauge 0-40 bar (0-600 lbf/in<sup>2</sup>)
- \* 892/00203 Replacement Gauge 0-400 bar (0-6000 lbf/in<sup>2</sup>)
- 892/00254 Replacement Hose


188120



Pressure Test 'T' Adapters

- 892/00262 1/4 in M BSP x 1/4 in F BSP x Test Point
- 816/55038 3/8 in M BSP x 3/8 in F BSP x Test Point
- 816/55040 1/2 in M BSP x 1/2 in F BSP x Test Point
- 892/00263 5/8 in M BSP x 5/8 in F BSP x Test Point
- 892/00264 3/4 in M BSP x 3/4 in F BSP x Test Point
- 892/00265 1 in M BSP x 1 in F BSPP x Test Point


188130



Pressure Test Adapters

- 892/00255 1/4 in BSP x Test Point
- 892/00256 3/8 in BSP x Test Point
- 892/00257 1/2 in BSP x Test Point
- 892/00258 5/8 in BSP x Test Point
- 816/15118 3/4 in BSP x Test Point
- 892/00259 1 in BSP x Test Point
- 892/00260 1.1/4 in BSP x Test Point
- 892/00261 5/8 in UNF x Test Point

200140




Flow Test Equipment

- 892/00268 Flow Monitoring Unit
- 892/00269 Sensor Head 0 - 100 l/min (0 - 22 UK gal/min)
- 892/00270 Load Valve
- 1406/0021 Bonded Washer
- 1604/0006 Adapter 3/4 in M x 3/4 in M BSP
- 1612/0006 Adapter 3/4 in F x 3/4 in M BSP
- 892/00271 Adapter 3/4 in F x 5/8 in M BSP
- 892/00272 Adapter 5/8 in F x 3/4 in M BSP
- 816/20008 Adapter 3/4 in F x 1/2 in M BSP
- 892/00275 Adapter 1/2 in F x 3/4 in M BSP
- 892/00276 Adapter 3/4 in F x 3/8 in M BSP
- 892/00277 Adapter 3/8 in F x 3/4 in M BSP


188150

**Section E - Hydraulics**



A215880


892/00858 Pump support bracket - for engine removal.



220840

S270650

\* 892/00252 Test Block for A. R. V. - Husco valves  
 \* 892/00923 Test Block for A. R. V. - Commercial Hydraulic valves



193850

Hand Pump Equipment


892/00223 Hand Pump  
 892/00137 Micro-bore Hose 1/4 in BSP x 5 metres  
 892/00274 Adapter 1/4 in M BSP x 3/8 in M BSP Taper  
 892/00262 1/4 in M BSP x 1/4 in F BSP x Test Point  
 892/00706 Test Probe  
 892/00278 Gauge 0 - 40 bar (0 - 600 lbf/in<sup>2</sup>)  
 892/00279 Gauge 0 - 400 bar (0 - 6000 lbf/in<sup>2</sup>)



188140

Bonded Washers


1406/0011 1/4 in BSP  
 1406/0018 1/2 in BSP  
 1406/0021 3/4 in BSP  
 1406/0029 1.1/4 in BSP



193860

Male Adapters - BSP x BSP

1606/0003 3/8 in x 1/4 in  
 1604/0003 3/8 in x 3/8 in  
 1606/0004 1/2 in x 1/4 in  
 1606/0007 1/2 in x 3/8 in  
 1604/0004 1/2 in x 1/2 in  
 1606/0008 3/4 in x 3/8 in  
 1606/0009 3/4 in x 1/2 in  
 1604/0006 3/4 in x 3/4 in




193930

Hexagon Spanners for Ram Pistons and End Caps

992/09300 55 mm A/F  
 992/09400 65 mm A/F  
 992/09500 75 mm A/F  
 992/09600 85 mm A/F


Section E - Hydraulics



193870

Female Cone Blanking Plug


892/00055	1/4 in BSP
892/00056	3/8 in BSP
892/00057	1/2 in BSP
892/00059	3/4 in BSP
892/00060	1 in BSP'T



193880

Male Cone Blanking Plug


816/00294	1/4 in BSP
816/00189	3/8 in BSP
816/00190	1/2 in BSP
816/00197	5/8 in BSP
816/00196	3/4 in BSP
816/00193	1 in BSP



193890

'T' Adapters


892/00047	3/8 in BSP (A) x 1/4 in BSP (B)
892/00048	1/2 in BSP (A) x 1/4 in BSP (B)
816/50043	3/4 in BSP (A) x 1/4 in BSP (B)
816/60096	3/4 in BSP (A) x 3/4 in BSP (B)



193900

Female Connectors

892/00074	3/8 in BSP x 3/8 in BSP
892/00075	1/2 in BSP x 1/2 in BSP
892/00077	3/4 in BSP x 3/4 in BSP



193910

193920

* 993/68100	Slide Hammer
993/99510	Half Moon Spanner

<b>JCB Multi-Gasket</b>	A medium strength sealant suitable for all sizes of gasket flanges, and for hydraulic fittings of 25-65 mm diameter.	4102/1201	
<b>JCB High Strength Threadlocker</b>	A high strength locking fluid for use with threaded components.	4102/0551	
<b>JCB Retainer (High Strength)</b>	For retaining parts which are unlikely to be dismantled.	4101/0651	
<b>JCB Threadlocker &amp; Sealer</b>	A medium strength locking fluid for sealing and retaining nuts, bolts, and screws up to 50 mm dia., and for hydraulic fittings up to 25 mm dia.	4101/0251	
<b>JCB Threadlocker &amp; Sealer (High Strength)</b>	A medium to high strength locking fluid for retention and sealing of ram piston heads.	4101/0552	
<b>JCB Threadlocker</b>	A locking fluid for use on threads larger than 50 mm dia.	4101/0451	
<b>JCB Activator</b>	A cleaning primer which speeds the curing rate of anaerobic products.	4104/0251 4104/0253	Aerosol Bottle
<b>JCB Cleaner/Degreaser</b>	For degreasing components prior to use of anaerobic adhesives and sealants.	4104/1557	Aerosol

The part numbers and descriptions of sealing and retaining compounds available from JCB Service have been revised with effect from January 1997 (see MI 563/H, 507/HA, 511/E). The list above has been changed accordingly.

References to these products on subsequent pages in this service manual will be progressively updated but for convenience a cross reference table is shown below.

Old Description	Old Part Number	New Description	New Part Number
<b>JCB High Strength Threadlocker</b>	4102/0502	<b>JCB High Strength Threadlocker</b>	4102/0551
<b>JCB High Strength Retainer</b>	4101/0602	<b>JCB Retainer (High Strength)</b>	4101/0651
<b>JCB Lock &amp; Seal</b>	4101/0202	<b>JCB Threadlocker &amp; Sealer</b>	4101/0251
<b>Loctite 243</b>	4101/1101	Use 4101/0251	
<b>Loctite 262</b>	4101/0502	<b>JCB Threadlocker &amp; Sealer (High Strength)</b>	4101/0552
<b>Loctite 932</b>	4101/0402	<b>JCB Threadlocker</b>	4101/0451
<b>Loctite Activator N</b>	4104/0101 Aerosol 4104/0102 Bottle	<b>JCB Activator</b>	4104/0251 4104/0253
<b>JCB Cleaner &amp; Degreaser</b>	4104/1538 Aerosol	<b>JCB Cleaner/Degreaser</b>	4104/1557

<b>Contents</b>	<b>Page No.</b>
Safety Notices	1 - 1
General Safety	2 - 1
Operating Safety	3 - 1
Maintenance Safety	4 - 1
Safety Decals	5 - 1

## Safety Notices

In this publication and on the machine there are safety notices. Each notice starts with a signal word. The signal word meanings are given below.

### **DANGER**

Denotes an extreme hazard exists. If proper precautions are not taken, it is highly probable that the operator (or others) could be killed or seriously injured.

INT-1-2-1

### **WARNING**

Denotes a hazard exists. If proper precautions are not taken, the operator (or others) could be killed or seriously injured.

INT-1-2-2

### **CAUTION**

Denotes a reminder of safety practices. Failure to follow these safety practices could result in injury to the operator (or others) and possible damage to the machine.

INT-1-2-3

All construction and agricultural equipment can be hazardous. When a JCB machine is correctly operated and properly maintained, it is a safe machine to work with. But when it is carelessly operated or poorly maintained it can become a danger to you (the operator) and others.

Do not work with the machine until you are sure that you can control it.

Do not start any job until you are sure that you and those around you will be safe.

If you are unsure of anything, about the machine or the job, ask someone who knows. Do not assume anything.

**Remember**  
**BE CAREFUL**  
**BE ALERT**  
**BE SAFE**

GEN-1-6

## General Safety

### **WARNING**

#### **Decals**

You can be injured if you do not obey the decal safety instructions. Keep decals clean. Replace unreadable or missing decals with new ones before operating the machine. Make sure replacement parts include warning decals where necessary.

INT-1-3-4

### **WARNING**

#### **Care and Alertness**

All the time you are working with or on the machine, take care and stay alert. Always be careful. Always be alert for hazards.

INT-1-3-5

### **WARNING**

#### **Clothing**

You can be injured if you do not wear the proper clothing. Loose clothing can get caught in the machinery. Wear protective clothing to suit the job. Examples of protective clothing are: a hard hat, safety shoes, safety glasses, a well fitting overall, ear-protectors and industrial gloves. Keep cuffs fastened. Do not wear a necktie or scarf. Keep long hair restrained.

INT-1-3-6

### **WARNING**

#### **Lifting Equipment**

You can be injured if you use faulty lifting equipment. Make sure that lifting equipment is in good condition. Make sure that lifting tackle complies with all local regulations and is suitable for the job. Make sure that lifting equipment is strong enough for the job.

INT-1-3-7

### **WARNING**

#### **Raised Attachments**

Raised attachments can fall and injure you. Do not walk or work under raised attachments unless they are safely blocked.

INT-1-3-8

## Operating Safety

### **WARNING**

#### Controls

You or others can be killed or seriously injured if you operate the control levers from outside the cab. Operate the control levers only when you are correctly seated inside the cab.

INT-2-1-3

### **WARNING**

#### Machine Limits

Operating the machine beyond its design limits can damage the machine, it can also be dangerous. Do not operate the machine outside its limits. Do not try to upgrade the machine performance with unapproved modifications.

INT-2-1-4

### **WARNING**

#### Entering/Leaving

When entering and leaving the cab, use the step and handrails. Make sure the step, handrails and your boot soles are clean and dry. Do not jump from the machine. Do not use the machine controls or Safety Restraint Bar as handholds, use only the handrails.

3-1-1-1

### **WARNING**

#### Engine

The engine has rotating parts. Do not open the engine cover while the engine is running. Do not use the machine with the cover open.

INT-2-1-6

### **WARNING**

#### ROPS/FOPS Structure

The machine is fitted with a Roll Over Protection Structure (ROPS) and a Falling Objects Protection Structure (FOPS). You could be killed or seriously injured if you operate the machine with a damaged or missing ROPS/FOPS. If the ROPS/FOPS has been in an accident, do not use the machine until the structure has been renewed. Modifications and repairs that are not approved by the manufacturer may be dangerous and will invalidate the ROPS/FOPS certification.

INT-2-1-9/3

### **WARNING**

#### Seat Belts

The ROPS/FOPS cab is designed to give you protection in an accident. If you do not wear your seat belt, you could be thrown around inside the cab or thrown out of the machine and crushed. You must wear a seat belt when using the machine. Fasten the seat belt before starting the engine.

2-2-1-9

### **WARNING**

#### Exhaust Gases

Breathing the machine exhaust gases can harm and possibly kill you. Do not operate the machine in closed spaces without making sure there is good ventilation. If possible, fit an exhaust extension. If you begin to feel drowsy, stop the machine at once. Get out of the cab into fresh air.

INT-2-1-10

### **WARNING**

#### Passengers

Passengers in or on the machine can cause accidents. The JCB Skid Steer Loader is a one man machine. Do not carry passengers.

INT-2-2-2

### **WARNING**

#### Communications

Bad communications can cause accidents. Keep people around you informed of what you will be doing. If you will be working with other people, make sure any hand signals that may be used are understood by everybody. Work sites can be noisy, do not rely on spoken commands.

INT-2-2-3

### **WARNING**

#### Ramps and Trailers

Water, mud, ice, grease and oil on ramp or trailers can cause serious accidents. Make sure ramps and trailers are clean before driving onto them. Use extreme caution when driving onto ramps and trailers. Always reverse up a ramp if unloaded, travel forwards if loaded.

3-1-1-3/1

### **DANGER**

#### Sparks

Explosions and fire can be caused by sparks from the exhaust or the electrical system. Do not use the machine in closed areas where there is flammable material, vapour or dust.

INT-2-2-10

### **WARNING**

#### Attachments

Use only JCB approved attachments. Non-approved attachments, modified to fit the Skid Steer Loader, could cause damage to the machine, and/or make it unsafe. The use of non-approved attachments could invalidate your warranty.

3-1-2-1

## Maintenance Safety

### WARNING

#### Repairs

Do not try to do repairs or any other type of maintenance work you do not understand. To avoid injury and/or damage get the work done by a specialist engineer.

GEN-1-5

### WARNING

#### Metal Splinters

You can be injured by flying metal splinters when driving metal pins in or out. Use a soft faced hammer or drift to remove and fit metal pins. Always wear safety glasses.

INT-3-1-3

### WARNING

#### Electrical Circuits

Understand the electrical circuit before connecting or disconnecting an electrical component. A wrong connection can cause injury or damage.

INT3-1-4

### WARNING

#### Communications

Bad communications can cause accidents. If two or more people are working on the machine, make sure each is aware of what the others are doing. Before starting the engine make sure the others are clear of the danger areas; examples of danger areas are: the rotating blades and belt on the engine, the attachments and linkages, and anywhere beneath or behind the machine. People can be killed or injured if these precautions are not taken.

INT-3-1-5

### WARNING

#### Petrol

Do not use petrol in this machine. Do not mix petrol with the diesel fuel; in storage tanks the petrol will rise to the top and form flammable vapours.

INT-3-1-6

### WARNING

#### Battery

A battery with frozen electrolyte can explode if it is used or charged. Do not use a machine with a frozen battery. To help prevent the battery from freezing, keep the battery fully charged.

INT-3-1-7

### WARNING

#### Battery Gases

Batteries give off explosive gases. Keep flames and sparks away from the battery. Do not smoke close to the battery. Make sure there is good ventilation in closed areas where batteries are being used or charged. Do not check the battery charge by shorting the terminals with metal; use a hydrometer or voltmeter.

INT-3-1-8

### WARNING

#### Battery Terminals

The machine is negatively earthed. Always connect the negative pole of the battery to earth.

When connecting the battery, connect the earth (-) lead last.

When disconnecting the battery, disconnect the earth (-) lead first.

INT-3-1-9

### WARNING

#### Hydraulic Fluid

Fine jets of hydraulic fluid at high pressure can penetrate the skin. Do not use your fingers to check for hydraulic fluid leaks. Do not put your face close to suspected leaks. Hold a piece of cardboard close to suspected leaks and then inspect the cardboard for signs of hydraulic fluid. If hydraulic fluid penetrates your skin, get medical help immediately.

INT-3-1-10/1

### WARNING

#### Hydraulic Pressure

It is not possible to vent all residual pressure. Loosen the connection one full turn and allow the pressure to dissipate. Keep face and hands well clear of pressurised hydraulic oil and wear protective glasses.

HYD 4-3

### DANGER

#### Electrolyte

Battery electrolyte is toxic and corrosive. Do not breathe the gases given off by the battery. Keep the electrolyte away from your clothes, skin, mouth and eyes. Wear safety glasses. See Battery in MAINTENANCE section for First Aid treatment.

INT-3-2-1/2

### WARNING

#### Diesel Fuel

Diesel fuel is flammable; keep naked flames away from the machine. Do not smoke while refuelling the machine or working on the engine. Do not refuel with the engine running. There could be a fire or injury if you do not follow these precautions.

INT-3-2-2

**Maintenance Safety (cont'd)****⚠ WARNING****Oil**

Oil is toxic. If you swallow any oil, do not induce vomiting, seek medical advice. Used engine oil contains harmful contaminants which can cause skin cancer. Do not handle used engine oil more than necessary. Always use barrier cream or wear gloves to prevent skin contact. Wash skin contaminated with oil thoroughly in warm soapy water. Do not use petrol, diesel fuel or paraffin to clean your skin.

INT-3-2-3

**⚠ WARNING****Soft Ground**

A machine can sink into soft ground. Never work under a machine on soft ground.

INT-3-2-4

**⚠ WARNING****Tyres and Rims**

Over-inflated or over-heated tyres can explode. Follow the instructions in this manual for inflating the tyres. Do not weld or cut rims. Get a tyre/wheel specialist to do any repair work.

INT-3-2-6

**⚠ WARNING****Fires**

If your machine is equipped with a fire extinguisher, make sure it is checked regularly. Keep it in the operator's cab until you need to use it. Do not use water to put out a machine fire, you could spread an oil fire or get a shock from an electrical fire. Use carbon dioxide, dry chemical or foam extinguishers. Contact your nearest fire department as quickly as possible. Firefighters should use self-contained breathing apparatus.

INT-3-2-7/1

**⚠ WARNING****Hot Coolant**

The cooling system is pressurised when the engine is hot. Hot coolant can spray out when you remove the radiator cap. Let the system cool before removing the radiator cap. To remove the cap; turn it to the first notch and let the steam pressure escape, then remove the cap.

INT-3-2-9

**⚠ CAUTION****Rams**

The efficiency of the rams will be affected if they are not kept free of solidified dirt. Clean dirt from around the rams regularly. When leaving or parking the machine, close all rams if possible to reduce the risk of weather corrosion.

INT-3-2-10

**⚠ CAUTION****Cleaning**

Cleaning metal parts with incorrect solvents can cause corrosion. Use only recommended cleaning agents and solvents.

INT-3-2-11

**⚠ CAUTION****'O' rings, Seals and Gaskets**

Badly fitted, damaged or rotted 'O' rings, seals and gaskets can cause leakages and possible accidents. Renew whenever disturbed unless otherwise instructed. Do not use Trichloroethane or paint thinners near 'O' rings and seals.

INT-3-2-12

**⚠ WARNING****Hydraulic Hoses**

Damaged hoses can cause fatal accidents. Inspect the hoses regularly for:

- Damaged end fittings
- Chafed outer covers
- Ballooned outer covers
- Kinked or crushed hoses
- Embedded armouring in outer covers
- Displaced end fittings.

INT-3-3-2

**⚠ WARNING**

Always wear safety glasses when dismantling assemblies containing components under pressure from springs. This will protect against eye injury from components accidentally flying out.

GEN-6-2

## Safety Decals

### **WARNING**

Decals on the machine warn you of particular hazards. Each decal is attached close to a part of the machine where there is a possible hazard. Read and make sure you understand the safety message before you work with or on that part of the machine.

Keep all decals clean and readable. Replace lost or damaged decals. The decals and their attachment points are shown on the following pages. Each decal has a part number printed on it, use this number to order a new decal from your JCB distributor.

INT-3-3-3

### **WARNING**

If you need eye-glasses for reading, make sure you wear them when reading the safety decals. Decals are strategically placed around the machine to remind you of possible hazards. Do not over-stretch or place yourself in dangerous positions to read the decals.

INT-3-3-4

**Safety Decals (cont'd)**

<b>Contents</b>	<b>Page No.</b>
Fluids, Capacities and Lubricants	1 - 1
Lubricants	
Health and Safety	1 - 2
Fuel System	2 - 1
Service Schedules	3 - 1
Loader Arm Safety Strut	4 - 1
Greasing	5 - 1
* Body and Framework	
Oiling	6 - 1
Cleaning Cab Interior	6 - 4
Checking Seat Belt Condition and Security	6 - 4
Electrical System	
Battery Safety	7 - 1
Checking the Electrolyte Level	7 - 2
Changing the Light Bulbs	7 - 3
Hydraulic System	
Checking the Fluid Level	8 - 1
Changing the Filter	8 - 1
* Transmission	
Drive Chain Lubrication up to machine number 677999	9 - 1
- Checking the Oil Levels	9 - 1
- Changing the Oil	9 - 1
Drive Chain Lubrication from machine number 678000	9 - 2
- Checking the Oil Levels	9 - 2
- Changing the Oil	9 - 2
Adjusting the Drive Chain Tension	9 - 3
Tyres and Wheels	9 - 4
- Inflating the Tyres	9 - 4
- Replacing Segments of Optional Non-Inflatable Tyres	9 - 4
- Checking the Wheelnut Torques	9 - 4
- Tyre Table	9 - 4

<b>Contents</b>	<b>Page No.</b>
Engine	
Air Filter up to machine number 677999	
- Changing the Elements	10 - 1
Air Filter from machine number 678000	
- Changing the Elements	10 - 1A
Checking the Oil Level - Peugeot engine	10 - 2
Changing the Oil and Filter - Peugeot engine	10 - 2
* Checking the Oil Level - JCB Diesel engine	10 - 4
* Changing the Oil and Filter - JCB Diesel engine	10 - 4
Draining the Fuel Filter - Peugeot engine	10 - 6
Changing the Fuel Filter Element - Peugeot engine	10 - 6
* Draining the Fuel Filter - JCB Diesel engine	10 - 7
* Changing the Fuel Filter Element - JCB Diesel engine	10 - 7
Cooling System	10 - 8
- Coolant Mixtures	10 - 8
- Checking the Coolant Level	10 - 8
- Changing the Coolant	10 - 9
- Cleaning the Coolant Radiator	10 - 9
Adjusting the Alternator Belt	10 - 10
Fitting a New Alternator Belt	10 - 10
Windscreen Washer	11 - 1

**Fluids, Capacities and Lubricants - except North America**

ITEM	CAPACITY	FLUID/LUBRICANT	SPECIFICATION
<b>Engine Oil</b> <b>Peugeot XUD</b> * <b>JCB Diesel</b>	5 litres 8.2 litres	JCB 15W/40 Multigrade JCB 10W/30 Multigrade	API CE 15W 40 API CC 10W 30
<b>Hydraulic System</b>	65 litres	JCB 15W/40 Multigrade JCB 10W/30 Multigrade	API CE 15W 40 API CC 10W 30
<b>Cooling System</b> <b>Peugeot XUD</b> Total coolant cap. Antifreeze * <b>JCB Diesel</b> Total coolant cap. Antifreeze	11 litres 5.5 litres 11 litres 5.5 litres	Water/Anti-freeze (see <b>Coolant Mixtures</b> )  JCB Universal Antifreeze/water (see <b>Coolant Mixtures</b> )	Inhibited Ethanediol AL - 39  ASTM D3306-74
<b>Fuel System</b>	60 litres	Diesel oil (see <b>Types of Fuel</b> )	ASTM D975-66T Nos. 1D, 2D
<b>Grease Points</b>	-	JCB Special HP Grease or JCB Special MPL Grease	Lithium based, No. 2 consistency
<b>Chain Case</b>	Fill to level plug	Engine Oil	API CE 15W 40 or API CC 10W 30

**Fluids, Capacities and Lubricants - North America**

ITEM	CAPACITY	FLUID/LUBRICANT	SPECIFICATION
<b>Engine Oil</b> <b>Peugeot XUD</b> * <b>JCB Diesel</b>	1.32 US gal 2.17 US gal	JCB 30W JCB 10W or JCB 15W/40	API CD/CE MIL-L-2104E
<b>Hydraulic System</b>	17.2 US gal	JCB 30W JCB 15W/40 (top up only)	API CD/CE MIL-L-2104E
<b>Cooling System</b> <b>Peugeot XUD</b> Total coolant cap. Antifreeze * <b>JCB Diesel</b> Total coolant cap. Antifreeze	2.9 US gal 1.45 US gal 2.9 US gal 1.45 US gal	Water/Anti-freeze (see <b>Coolant Mixtures</b> )  Permanent Antifreeze	Inhibited Ethanediol AL - 39  ASTM D3306-74
<b>Fuel System</b>	15.8 US gal	Diesel oil (see <b>Types of Fuel</b> )	ASTM D975-66T Nos. 1D, 2D
<b>Grease Points</b>	-	JCB Moly EP #2 Grease	Lithium based, No. 2
<b>Chain Case</b>	Fill to level plug	Engine Oil	API CE 15W 40 or API CC 10W 30

It is most important that you read and understand this information and the publications referred to. Make sure that all of your colleagues who are concerned with lubricants read it too.

## Lubricants - Health and Safety

### Hygiene

JCB lubricants are not a health risk when used properly for their intended purposes.

However, excessive or prolonged skin contact can remove the natural fats from your skin, causing dryness and irritation.

Low viscosity oils are more likely to do this, therefore particular care is necessary in handling used oils which can be diluted with fuel contamination.

Whenever you are handling oil products you should maintain good standards of care and personal and plant hygiene. For details of these precautions we advise you to read the relevant publications issued by your local health authority, and note the following:

### Storage

Always keep lubricants out of the reach of children.

Never store lubricants in open or unlabelled containers.

### Waste Disposal

All waste products should be disposed of in accordance with all the relevant regulations.

The collection and disposal of used engine oil should be in accordance with any local regulations. Never pour used engine oil into sewers, drains or on the ground.

### Handling

#### New Oil

There are no special precautions needed for the handling or use of new oil, beside normal care and hygiene practices.

#### Used Oil

Used engine crankcase lubricants contain harmful contaminants. In laboratory tests it was shown that used engine oils can cause skin cancer.

Here are precautions to protect your health when handling used engine oil:

- 1 Avoid prolonged, excessive or repeated skin contact with used engine oils.
- 2 Apply a barrier cream to the skin before handling used engine oil.

3 Note the following when removing engine oil from skin:

- a Wash your skin thoroughly with soap and water.
- b Using a nail brush will help.
- c Use special hand cleansers to help clean dirty hands.
- d Never use petrol, diesel fuel or paraffin for washing.
- e Avoid skin contact with oil soaked clothing.
- f Don't keep oily rags in pockets.
- g Wash dirty clothing before re-use.
- h Throw away oil-soaked shoes.

### First Aid - Oil

#### Swallowing.

If oil is swallowed you should not induce vomiting. Get medical advice.

#### Skin

In the case of excessive skin contact you should wash with soap and water.

#### Eyes

In the case of eye contact, flush with water for 15 minutes. If irritation persists, get medical attention.

#### Spillage

Absorb on sand or a locally approved brand of absorbent granules. Scrape up and remove to a chemical disposal area.

#### Fires

Extinguish with carbon dioxide, dry chemical or foam. Firefighters should use self contained breathing apparatus.

### WARNING

**Do not use water to put out an oil fire. This will only spread it because oil floats on water.**

**Extinguish oil and lubricant fires with carbon dioxide, dry chemical or foam. Fire fighters should use self contained breathing apparatus.**

7-3-1-3/1

## Fuel System

### Types of Fuel

Use good quality diesel fuel to get the correct power and performance from your engine. The recommended fuel specification for JCB engines is given below.

<b>Cetane Number:</b>	45 (minimum)
<b>Viscosity:</b>	2.5/4.5 Centistokes at 40 °C (104 °F)
<b>Density:</b>	0.835/0.855 kg/litre (0.872/0.904 lb/pint)
<b>Sulphur:</b>	0.5% of mass (maximum)
<b>Distillation:</b>	85% at 350 °C (662 °F)

### Cetane Number

Indicates ignition performance. Fuel with a low cetane number can cause cold start problems and affect combustion.

### Viscosity

Is the resistance to flow. If this is outside limits, the engine performance can be affected.

### Density

Lower density will reduce engine power. Higher density will increase both engine power and exhaust smoke.

### Sulphur

High sulphur content can cause engine wear. (High sulphur fuel is not normally found in North America, Europe or Australia.) If you have to use high sulphur fuel you must also use a highly alkaline engine lubricating oil; or change the normal oil more frequently.

### Distillation

This indicates the mixture of different hydrocarbons in the fuel. A high ratio of lightweight hydrocarbons can affect the combustion characteristics.

### Low Temperature Fuels

Special winter fuels may be available for engine operation at temperatures below 0 °C (32 °F). These fuels have a lower viscosity. They also limit wax formation in the fuel at low temperatures. (Wax forming in the fuel can stop the fuel flowing through the filter).

Flow improvers may also be available. These can be added to the fuel to reduce wax formation.

### Petrol

#### **WARNING**

**Do not use petrol in this engine. Do not mix petrol with the diesel fuel. In storage tanks the petrol could rise to the top and form flammable vapours.**

INT-3-1-6

### Filling the Tank

#### **WARNING**

**Diesel fuel is flammable; keep naked flames away from the machine. Do not smoke while refuelling the machine or working on the engine. Do not refuel with the engine running. There could be a fire and injury if you do not follow these precautions.**

INT-3-2-2

At the end of every working day, fill the tank with the correct type of fuel.

This will prevent condensation from developing in the fuel tank overnight.

We recommend that, if possible, you lock the fuel cap to prevent theft and tampering.

## Service Schedules

### EVERY 10 OPERATING HOURS OR DAILY

whichever occurs first, for the first 50 Operating Hours only

#### Check (engine stopped)

- 1 Tightness of wheel bolts

### EVERY 10 OPERATING HOURS OR DAILY

whichever occurs first

#### Clean

- 1 Machine generally, including cab interior

#### Check (engine stopped)

- 1 Generally for damage including ROPS/FOPS structure
- 2 Engine coolant level and condition
- 3 Fuel system for leaks and contamination
- 4 Hydraulic fluid level
- 5 Hydraulic system for leaks
- 6 Engine oil level and condition
- 7 Engine generally for leaks
- 8 Tyre pressures and condition
- \*9 Windscreen washer level (if fitted)
- 10 Alternator belt tension (JCB Diesel engine only)
- 11 Fuel filter - drain if necessary (Peugeot engine only)
- 12 Seat belt condition and security

#### Check (Engine Running)

- 1 Warning lights extinguished
- 2 Operation of all electrical equipment
- 3 Exhaust for excessive smoke
- 4 Operation of all hydraulic services

#### Grease

- 1 Quickhitch pivot pins

### AFTER THE FIRST 50 OPERATING HOURS ONLY

#### Change (Engine Stopped)

- 1 Engine oil and filter
- \*2 Hydraulic fluid filter
- 3 Fuel filter - drain if necessary (JCB Diesel engine only)

**Note:** The engine is supplied with "Running in" oil. This must be changed together with engine oil filter after the first 50 operating hours. Failure to complete this could damage the engine.

### EVERY 50 OPERATING HOURS OR WEEKLY

whichever occurs first

Do the Daily jobs plus:

#### Check (Engine Stopped)

- 1 Oil cooler connections
- 2 Radiator hoses and condition
- 3 Alternator belt tension (Peugeot engine only)
- 4 Fuel filter - drain if necessary

#### Grease

- 1 Loader arm pivot points
- 2 Lift and compensating ram pivots

### EVERY 100 OPERATING HOURS OR 2 WEEKLY

whichever occurs first

Do the Daily and 50 hour jobs plus:

#### Clean

- 1 Battery terminals
- 2 Quickhitch square locking peg housings

#### Check (Engine Stopped)

- 1 Condition of ram piston rods
- 2 Hoses and pipework for chafing and damage
- 3 Air cleaner hose security
- 4 Wiring for chafing

#### Change

- 1 Air filter outer element when operating in dusty conditions

#### Oil

- 1 All linkage points
- 2 Hand throttle lever
- 3 Throttle pedal hinge bolt (if fitted)

**Service Schedules (cont'd)****EVERY 250 OPERATING HOURS OR MONTHLY  
whichever occurs first**

Do the Daily to 100 hour jobs plus:

**Clean**

- 1 Air cleaner dust valve
- 2 Radiator matrix
- 3 Hydraulic tank breather

**Check (Engine stopped)**

- 1 Tightness of wheel bolts

**Check (Engine running)**

- 1 Exhaust system security
- 2 Exhaust for excessive smoke
- 3 Cooling system for leaks
- 4 Throttle system and control pedal
- 5 Transmission operation
- 6 Operation of all hydraulic services
- 7 Operation of control isolation
- 8 Parking brake operation
- 9 Operation of electrical system
- 10 Operation of attachments

**Change (Engine Stopped)**

- \* 1 Engine oil and filter
- 2 Fuel filter element (JCB Diesel engine only)

**EVERY 500 OPERATING HOURS OR 6 MONTHLY  
whichever occurs first**

Do the Daily to 250 hour jobs plus:

**Check (Engine Stopped)**

- 1 Engine and pump mounting bolts for tightness
- 2 Pivot pins and bushes
- 3 Drive chain case oil levels
- \* 4 Hydraulic motor mounting bolts
- 5 Battery charge and condition
- 6 Valve clearances (JCB Diesel engine only)

**Change**

- 1 Hydraulic fluid filter(s)
- 2 Fuel filter element (Peugeot engine only)
- 3 Air filter outer element

**EVERY 1000 OPERATING HOURS OR YEARLY  
whichever occurs first**

Do the Daily to 500 hour jobs plus:

**\* Check (Engine Stopped)**

- 1 Tighten cylinder head bolts (JCB Diesel engine only)
- 2 Engine cam belt - condition (Peugeot engine only)
- 3 Drive chain tension

**Check (Engine Running)**

- 1 Idling speed
- 2 Maximum governed speed
- 3 Pulled down speed
- 4 Compression
- 5 M.R.V. pressure
- 6 A.R.V. pressure
- 7 Drive pump pressure
- 8 Transmission stall pressure

**EVERY 2000 OPERATING HOURS OR 2 YEARLY  
whichever occurs first**

Do the Daily to 1000 hour jobs plus:

**Clean**

- 1 Engine injectors (and test)

**Check (Engine Stopped)**

- 1 Valve clearances (Peugeot engine only)
- 2 Wheel hub and hydraulic motor bearing clearance, replace as necessary

**Change**

- 1 Air filter inner element
- 2 Hydraulic fluid - sample/change (clean suction strainer)
- 3 Engine coolant
- 4 Engine cam belt (Peugeot engine only)
- 5 Drive chain case oil

## Loader Arm Safety Strut

### Installing

#### **⚠ WARNING**

Raised loader arms can drop suddenly and cause serious injury. Before working under raised loader arms, fit the loader arm safety strut.

2-1-1-6

#### **⚠ WARNING**

You could be killed or seriously injured if the loader control is accidentally operated. Make sure that no-one goes near the machine whilst you fit the safety strut.

16-3-1-5

- 1 Empty the shovel or attachment, if appropriate, and raise the loader arm enough to fit the safety strut.
- 2 Stop the engine.
- 3 Fit the strut:
  - a Remove the strut from its stowage position on the right hand mudguard **C**.
  - \* b Place the strut around the lift ram.
  - c Secure the strut **A** into position using strap **B**.
- 4 Start the engine.
- 5 Slowly lower the loader arm onto the safety strut. Stop the movement immediately the weight of the arm is supported by the strut.

**Note:** Extreme care must be taken when lowering the loader arm onto the safety strut. 'Feather' the lever to lower the loader arm slowly.

### Removing



#### **⚠ WARNING**

You could be killed or injured if the loader control is accidentally operated. Make sure no-one comes near the machine while you remove the safety strut.

2-3-1-3

- 1 Make sure that the drive control lever is in the neutral (rest) position.
- 2 Raise the loader arm to take the weight off the safety strut **A**. Stop the engine.
- 3 Remove the strut:
  - a Release securing strap **B**.
  - b Remove the safety strut from the lift ram.
  - \* c Return the safety strut to its stowage position on the right hand mudguard **C**.

193490



174170

## Greasing

The machine must be greased regularly to keep it working efficiently. Regular greasing will also increase the machine's working life.

Grease should be applied with a grease gun, normally two strokes of the gun should be sufficient. Stop the greasing procedure when fresh grease appears at the joint. Use the recommended grease.

In the following illustrations, the grease points are numbered. Count off the grease points as you apply grease to each one. Refit the dust caps after greasing.

**Quickhitch Pivot Pins** - for interval see Service Schedule


**Total of 9 grease points.**

### **⚠ WARNING**

#### **Safety Strut**

**If it is necessary to work with the loader arm raised, you must fit the loader arm safety strut first.** (See Loader Arm Safety Strut).

2-1-1-6



174210