



Service Manual

406
407
408
409

JCB SERVICE ©
ROCESTER, STAFFORDSHIRE,
ST14 5LS, ENGLAND.
TEL. ROCESTER (01889) 590312

Contents

This Service Manual covers the following machines:

406
407
408
409
* 409 Telemaster

407 and 409 Machines commence from Serial Number 632700.

Unless otherwise stated, information for 406 also applies to 407 and information for 408 also applies to 409 and the 409 Telemaster.

General	1
Hydraulics	2
Attachments	3
Body and Framework	4
Engine	5
Transmission	6
Axles	7
Brakes	8
Hydraulic Steering	9
Electrics	10
Service Tools	11

Introduction

This publication is designed for the benefit of JCB Distributor Service Engineers who are receiving or have received training by the JCB Technical Training Department.

It is assumed that such personnel have a sound knowledge of good workshop practice, safety procedures and general techniques associated with the maintenance and repair of hydraulic earthmoving equipment. Details of such may therefore be omitted from this manual, the primary intention being to convey the more specialised information concerning particular aspects of the machine or component in question.

Renewal of oil seals, gaskets, etc. and any component showing obvious wear or damage is expected. It is also expected that components will be thoroughly cleaned and lubricated where appropriate, also that any opened hose or pipe connections will be blanked to prevent entry of dirt and excessive loss of hydraulic fluid.

For convenience the manual is compiled in sections, e.g. "Hydraulics", "Electrics" etc., but to find details of a specific component or its application, reference should be made to the alphabetical index at the back of the manual.

Except where a maximum and minimum figure is given, torque settings quoted in the text are intended as 'mean' figures which may be varied by + or - 3%. Where no figure is quoted in the text, refer to page 1/1 - 3.

'Left Hand' and 'Right Hand' are as viewed from the rear of the machine looking forward.

WARNING

Fluoroelastomeric Materials

Certain seals and gaskets (e.g. crankshaft oil seal) on JCB machines contain fluoroelastomeric materials such as Viton, Fluorel and Technoflon. Fluoroelastomeric materials subjected to high temperatures can produce highly corrosive hydrofluoric acid. **THIS ACID CAN SEVERELY BURN.**

New fluoroelastomeric components at ambient temperature require no special safety precautions.

Used fluoroelastomeric components whose temperatures have not exceeded 300°C require no special safety precautions. If evidence of decomposition (e.g. charring) is found, refer to the next paragraph for safety instructions **DO NOT TOUCH COMPONENT OR SURROUNDING AREA.**

Used fluoroelastomeric components subjected to temperatures greater than 300°C (e.g. engine fire) must be treated using the following safety procedure. Make sure that heavy duty gloves and special safety glasses are worn:

- 1 Ensure that components have cooled then remove and place material into plastic bags.
- 2 Thoroughly wash contaminated area with 10% calcium hydroxide or other suitable alkali solution, if necessary use wire wool to remove burnt remains.
- 3 Thoroughly wash contaminated area with detergent and water.
- 4 Contain all removed material, gloves etc. used in this operation in sealed plastic bags and dispose of in accordance with Local Authority Regulations.

DO NOT BURN FLUOROELASTOMERIC MATERIALS.

If contamination of skin or eyes occurs, wash the affected area with a continuous supply of clean water or with calcium hydroxide solution for 15-60 minutes. Get medical attention immediately.

INT-3-3-5/1

WARNING

Asbestos

Asbestos dust can damage your lungs. Some engine joints and gaskets may contain asbestos. Take the following precautions when working on them.

- 1 Wear a face mask and gloves.
- 2 Work in a well ventilated area and do not smoke.
- 3 Do not use a rotary wire brush, use a hand scraper.
- 4 Make sure the material to be removed is wet with oil or water to contain loose particles.
- 5 Place all material into plastic bags and dispose of in accordance with local regulations.

GEN-1-8

Contents	Page No.
Fluids, Lubricants, Capacities & Specifications	
- 406/408	1 - 1
- 407/409	1 - 2
* - 409 Telemaster	1 - 3
* - Torque Settings	1 - 10
Service Schedules	2 - 1
Greasing	
- Shovel Pivot Pins	3 - 1
- Loader End	3 - 2
- Central Pivot and Steering Ram	3 - 3
- Intermediate Propshaft	3 - 3
- Propshafts (except Intermediate)	3 - 4
Greasing (409 Telemaster)	
- Boom Wear Pad Runways	4 - 1
- Boom Pivot Pins	4 - 2

Note: New engines DO NOT require a running-in period. The engine/machine should be used in a normal work cycle immediately; glazing of the piston cylinder bores, resulting in excessive oil consumption, could occur if the engine is gently run-in. Under no circumstances should the engine be allowed to idle for extended periods; (e.g. warming up without load). Engines of new machines are filled at the factory with JCB 10W/30 Multigrade oil. This oil should be drained after the first 100 hours operation and the engine filled with the appropriate recommended grade as shown in the lubrication chart. JCB 10W/30 Multigrade should also be used for the first 100 hours operation whenever a new or reconditioned engine is fitted to the machine. After the first 100 hours operation, it is essential that the 10W/30 oil is replaced by the lubricant recommended below.

ITEM	CAPACITY	FLUID/LUBRICANT	SPECIFICATION
Engine Oil -18 to 0° C -10 to 50° C	406 7.2 litres (1.6 UK gal) 408 10.7 litres (2.4 UK gal)	JCB Torque Converter Fluid JCB 15W/40 Multigrade	API CD MIL-L-2104C
Gearbox	Syncro Shuttle †19 litres (4.2 UK gal) Powershift †19 litres (4.2 UK gal)	JCB Special Transmission Fluid JCB Special Transmission Fluid	Ford ESN-M2C 33G Ford ESN-M2C 33G
Transfer box	1.3 litres (0.3 UK gal)	JCB HD 90 Gear Oil	API-GL-5, MIL-L-2105C
Axles - Hurth (406) Differential Housing Hubs (Individual)	5.0 litres (1.1 UK gal) 0.2 litres (0.04 UK gal)	JCB Special Gear Oil JCB Special Gear Oil	Ford ESE-M2C 86B Ford ESE-M2C 86B
Axles - JCB	406 5.0 litres (1.1 UK gal) 408 16 litres (3.6 UK gal)	JCB Special Gear Oil JCB Special Gear Oil	Ford ESE-M2C 86B Ford ESE-M2C 86B
Hydraulic System Up to 38° C Above 38° C	406 59 litres (13.2 UK gal) 408 63 litres (14.1 UK gal)	JCB Special Hydraulic Fluid JCB High Performance Hydraulic Fluid	ISO 32 ISO 46
Brake System	1.2 litres (0.27 UK gal)	JCB Light Hydraulic Fluid CAUTION: DO NOT USE ORDINARY BRAKE FLUID	ISO 15
Cooling System	406 12.5 litres (2.8 UK gal) 408 15.5 litres (3.5 UK gal)	Water/Anti-freeze (see Coolant mixture)	ASTM D3306-74
Fuel System	406 65 litres (14.5 UK gal) 408 90 litres (20.2 UK gal)	Diesel Oil (see Types of Fuel)	ASTM D975-66T Nos. 1D, 2D.
Grease Points		JCB Special MPL Grease	Lithium based, No. 2 consistency

Note: The total hydraulic system capacity depends on the equipment being used. Fill the system with all rams closed and watch the level indicator.

† The figure quoted is TOTAL system capacity. Use the 'MAX' and 'MIN' marks on the dipstick when refilling the system.

FLUIDS, CAPACITIES AND LUBRICANTS

Note: New engines DO NOT require a running-in period. The engine/machine should be used in a normal work cycle immediately; glazing of the piston cylinder bores, resulting in excessive oil consumption, could occur if the engine is gently run-in. Under no circumstances should the engine be allowed to idle for extended periods; (e.g. warming up without load). Engines of new machines are filled at the factory with JCB 10W/30 Multigrade oil. This oil should be drained after the first 100 hours operation and the engine filled with the appropriate recommended grade as shown in the lubrication chart. JCB 10W/30 Multigrade should also be used for the first 100 hours operation whenever a new or reconditioned engine is fitted to the machine. After the first 100 hours operation, it is essential that the 10W/30 oil is replaced by the lubricant recommended below.

ITEM	CAPACITY	FLUID/LUBRICANT	SPECIFICATION
Engine Oil -18 to 0° C -10 to 50° C	10.7 litres (2.4 UK gal)	JCB Torque Converter Fluid JCB 15W/40 Multigrade	API CD MIL-L-2104C
Gearbox	Syncro Shuttle †19 litres (4.2 UK gal)	JCB Special Transmission Fluid	Ford ESN-M2C 33G
	Powershift †13 litres (2.9 UK gal)	JCB Special Transmission Fluid	Ford ESN-M2C 33G
Transfer box	1.3 litres (0.3 UK gal)	JCB HD 90 Gear Oil	API-GL-5, MIL-L-2105C
Axles	407 5.0 litres (1.1 UK gal)	JCB Special Gear Oil	Ford ESE-M2C 86B
	409 16 litres (3.6 UK gal)	JCB Special Gear Oil	Ford ESE-M2C 86B
Hydraulic System Up to 38° C Above 38° C	63 litres (14.1 UK gal)	JCB Special Hydraulic Fluid JCB High Performance Hydraulic Fluid	ISO 32 ISO 46
Brake System	1.2 litres (0.27 UK gal)	JCB Light Hydraulic Fluid	ISO 15 CAUTION: DO NOT USE ORDINARY BRAKE FLUID
Cooling System	15.5 litres (3.5 UK gal)	Water/Anti-freeze (see Coolant mixture)	ASTM D3306-74
Fuel System	90 litres (20.2 UK gal)	Diesel Oil (see Types of Fuel)	ASTM D975-66T Nos. 1D, 2D.
Grease Points		JCB Special MPL Grease	Lithium based, No. 2 consistency

Note: The total hydraulic system capacity depends on the equipment being used. Fill the system with all rams closed and watch the level indicator.

† The figure quoted is TOTAL system capacity. Use the '**MAX**' and '**MIN**' marks on the dipstick when refilling the system.

FLUIDS, CAPACITIES AND LUBRICANTS

Note: New engines DO NOT require a running-in period. The engine/machine should be used in a normal work cycle immediately; glazing of the piston cylinder bores, resulting in excessive oil consumption, could occur if the engine is gently run-in. Under no circumstances should the engine be allowed to idle for extended periods; (e.g. warming up without load). Engines of new machines are filled at the factory with JCB 10W/30 Multigrade oil. This oil should be drained after the first 100 hours operation and the engine filled with the appropriate recommended grade as shown in the lubrication chart. JCB 10W/30 Multigrade should also be used for the first 100 hours operation whenever a new or reconditioned engine is fitted to the machine. After the first 100 hours operation, it is essential that the 10W/30 oil is replaced by the lubricant recommended below.

ITEM	CAPACITY	FLUID/LUBRICANT	SPECIFICATION
Engine Oil -18 to 0° C -10 to 50° C	10.7 litres (2.4 UK gal)	JCB Torque Converter Fluid JCB 15W/40 Multigrade	API CD MIL-L-2104C
Gearbox	Syncro Shuttle †19 litres (4.2 UK gal) Powershift 13 litres (2.9 UK gal)	JCB Special Transmission Fluid JCB Special Transmission Fluid	Ford ESN-M2C 33G Ford ESN-M2C 33G
Transfer box	1.3 litres (0.3 UK gal)	JCB HD 90 Gear Oil	API-GL-5, MIL-L-2105C
Axles	16 litres (3.6 UK gal)	JCB Special Gear Oil	Ford ESE-M2C 86B
Hydraulic System Up to 38° C Above 38° C	63 litres (14.1 UK gal)	JCB Special Hydraulic Fluid JCB High Performance Hydraulic Fluid	ISO 32 ISO 46
Cooling System	15.5 litres (3.5 UK gal)	Water/Anti-freeze (see Coolant mixture)	ASTM D3306-74
Fuel System	90 litres (20.2 UK gal)	Diesel Oil (see Types of Fuel)	ASTM D975-66T Nos. 1D, 2D.
Grease Points		JCB Special MPL Grease	Lithium based, No. 2 consistency
Wear Pad Runways		JCB Waxoyl	

Note: The total hydraulic system capacity depends on the equipment being used. Fill the system with all rams closed and watch the level indicator.

† The figure quoted is TOTAL system capacity. Use the '**MAX**' and '**MIN**' marks on the dipstick when refilling the system.

TORQUE SETTINGS

Use only where no torque setting is specified in the text. Values are for dry threads and may be within three per cent of the figures stated. For lubricated threads the values should be REDUCED by one third.

UNF Grade 'S' Bolts

Bolt Size in	Hexagon (A/F) (mm)	Hexagon (A/F) in	Torque Settings		
			Nm	kgf m	lbf ft
1/4	(6.3)	7/16	14	1.4	10
5/16	(7.9)	1/2	28	2.8	20
3/8	(9.5)	9/16	49	5.0	36
7/16	(11.1)	5/8	78	8.0	58
1/2	(12.7)	3/4	117	12.0	87
9/16	(14.3)	1/16	170	17.3	125
5/8	(15.9)	15/16	238	24.3	175
3/4	(19.0)	1 1/8	407	41.5	300
7/8	(22.2)	15/16	650	66.3	480
1	(25.4)	1 1/2	970	99.0	715
1 1/4	(31.7)	1 7/8	1940	198.0	1430
1 1/2	(38.1)	2 1/4	3390	345.0	2500

Metric Grade 8.8 Bolts

Bolt Size	(mm)	Hexagon (A/F) mm	Torque Settings		
			Nm	kgf m	lbf ft
M5	(5)	8	7	0.7	5
M6	(6)	10	12	1.2	9
M8	(8)	13	28	3.0	21
M10	(10)	17	56	5.7	42
M12	(12)	19	98	10	72
M16	(16)	24	244	25	180
M20	(20)	30	476	48	352
M24	(24)	36	822	84	607
M30	(30)	46	1633	166	1205
M36	(36)	55	2854	291	2105

Note: All bolts used on JCB machines are high tensile and must not be replaced by bolts of a lesser tensile specification.

A badly maintained machine is a danger to the operator and the people working around him. Make sure that the regular maintenance and lubrication jobs listed in the schedules are done to keep the machine in a safe and efficient working condition. A badly maintained machine is a danger to the operator and the people working around him. Make sure that the regular maintenance and lubrication jobs listed in the schedules are done to keep the machine in a safe and efficient working condition.

The schedules are based on machine running hours. Keep a regular check on the hourmeter readings. Do not use a machine which is due for a service. Make sure any defects found during the regular maintenance checks are rectified immediately.

Pre-start Cold Checks Service Points and Fluid Levels		Operation	10 Hr	50 Hr	First 100 Hr	500 Hr	1000 Hr	2000 Hr
ENGINE								
Generally for Leaks		- Check	<input type="checkbox"/>					
Oil level		- Check	<input type="checkbox"/>		<input type="checkbox"/>			
Oil and Filter		† - Change			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Fuel Filter		- Drain		<input type="checkbox"/>				
Fuel Filter		† - Change			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Coolant Level and Antifreeze Strength		- Check	<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Air Cleaner Dust Valve		- Clean					<input type="checkbox"/>	<input type="checkbox"/>
Air Cleaner Outer Element		- Change					<input type="checkbox"/>	<input type="checkbox"/>
Air Cleaner Inner Element		- Change						<input type="checkbox"/>
Coolant		- Change						<input type="checkbox"/>
Fuel Lift Pump		- Clean			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Fuel Sedimenter		- Drain		<input type="checkbox"/>	<input type="checkbox"/>			
Fan Belt Tension/Condition		- Check		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Valve Clearances		- Check and Adjust						<input type="checkbox"/>
Engine Mount Security		- Check			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Fuel System for Leaks and Contamination		- Check	<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
TRANSMISSION AND AXLES								
Hub Oil Levels		- Check			<input type="checkbox"/>			
Hub Oil		†† - Change					<input type="checkbox"/>	<input type="checkbox"/>
Oil Filter		- Change			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Drive Axle(s) Oil Level		- Check			<input type="checkbox"/>			
Drive Axle(s) Oil		†† - Change					<input type="checkbox"/>	<input type="checkbox"/>
Transmission Oil Level		- Check			<input type="checkbox"/>	<input type="checkbox"/>		
Transmission Oil		- Change					<input type="checkbox"/>	<input type="checkbox"/>
Transmission Strainer		- Clean					<input type="checkbox"/>	<input type="checkbox"/>
Transfer Gearbox Oil Level		- Check				<input type="checkbox"/>		
Transfer Gearbox Oil		- Change			<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>
Axle Breather(s)		- Clean			<input type="checkbox"/>			
Drive shaft/Prop. Shaft Security		- Check			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Drive Shaft/Prop. Shaft		- Lubricate			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Axle Mount Security		- Check			<input type="checkbox"/>			
Transmission Mount Security		- Check			<input type="checkbox"/>			
HYDRAULICS								
* Oil Filter		- Change			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Oil		- Sample/Change						<input type="checkbox"/>
Suction Strainer		- Clean						<input type="checkbox"/>
Oil Level		- Check	<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Hoses - Damage or Leaks		- Check		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Rams - Condition		- Check			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Pipework - Damage or Leaks		- Check		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Pre-start Cold Checks Service Points and Fluid Levels		10 Hr	50 Hr	First 100 Hr	500 Hr	1000 Hr	2000 Hr
BRAKES							
Parking Brake	- Check and Adjust	<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Brake System Fluid Level	- Check	<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Brake System Fluid	- Change						<input type="checkbox"/>
ELECTRICS							
Battery Electrolyte Level	- Check			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Wiring for Chaffing	- Check		<input type="checkbox"/>				
Battery Terminals for Condition and Tightness	- Check		<input type="checkbox"/>				
BODY AND FRAMEWORK							
All Articulation and Steer Pivots	- Grease		<input type="checkbox"/>	<input type="checkbox"/>			
All Loader Pivots	- Grease		<input type="checkbox"/>	<input type="checkbox"/>			
All Pivot Pins	- Check and Grease		<input type="checkbox"/>				
Windscreen Washer Fluid Level	- Check	<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
* ROPS/FOPS Structures	- Check				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Boom Wear Pads	* - Check and Inspect				<input type="checkbox"/>		
ATTACHMENTS							
Optional Equipment (as required)	- Check			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Functional Test and Final Inspection		10 Hr	50 Hr	First 100 Hr	500 Hr	1000 Hr	2000 Hr
ENGINE							
Idle Speed	- Check and Adjust			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Maximum Governed speed	- Check and Adjust			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Torque Converter Stall Speed	- Check			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Exhaust Smoke	- Check		<input type="checkbox"/>	<input type="checkbox"/>			
Exhaust System Security	- Check			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Air Inlet System Security	- Check			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Coolant System for Leaks	- Check		<input type="checkbox"/>	<input type="checkbox"/>			
Throttle System and Control Cable	- Check		<input type="checkbox"/>	<input type="checkbox"/>			
Operation of Stop Control/E.S.O.S.	- Check		<input type="checkbox"/>	<input type="checkbox"/>			
TRANSMISSION AND AXLES							
Torque Converter Mainline Pressure	- Check			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Clutch Pack Pressures	- Check			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Tyre pressure and condition	- Check			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Wheel Nut Torque	- Check			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Steering Operation	- Check		<input type="checkbox"/>				
Neutral Start Operation	- Check			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Forward/Reverse Selection/Operation	- Check			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Gear Change and Selection	- Check			<input type="checkbox"/>			
Clutch Disconnect	- Check			<input type="checkbox"/>			
Reverse Alarm (if fitted)	- Check			<input type="checkbox"/>			
Oil Cooler and Pipework	- Check			<input type="checkbox"/>			

Functional Test and Final Inspection	Operation	10 Hr	50 Hr	First 100 Hr	500 Hr	1000 Hr	2000 Hr
HYDRAULICS							
MRV Pressure	* - Check and Adjust			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
All ARV's	* - Check and Adjust			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Auxiliary Circuit	* - Check and Adjust			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Steer Circuit MRV	* - Check and Adjust			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Operation of All Services	- Check		<input type="checkbox"/>				
Loader Valve and Controls	- Check		<input type="checkbox"/>	<input type="checkbox"/>			
BRAKES							
Foot Brake Operation	- Check		<input type="checkbox"/>				
ELECTRICS							
All Electrics	- Operate		<input type="checkbox"/>				
Starter Motor	- Check			<input type="checkbox"/>			
Alternator	- Check			<input type="checkbox"/>			
Warning Lights	- Check			<input type="checkbox"/>			
Lights and Instruments	- Check			<input type="checkbox"/>			
Wipers	- Check			<input type="checkbox"/>			
Heater	- Check			<input type="checkbox"/>			
Other (give details)	- Check			<input type="checkbox"/>			
PAINTWORK							
Condition	- Check			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
CAB							
Glazing for Correct Fit	- Check			<input type="checkbox"/>			
Doors and Hinges	- Check			<input type="checkbox"/>			
Locks and Keys	- Check			<input type="checkbox"/>			
Seat/Seat Belts	- Check	<input type="checkbox"/>		<input type="checkbox"/>			
ATTACHMENTS							
Attachment Circuit Pressures	- Check			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Operation	- Check		<input type="checkbox"/>	<input type="checkbox"/>			
REGISTRATION/CERTIFICATION							
Form 2530 (F91) (UK Requirement) - Lift	- Check			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Form 2531 (F96/F97) (UK Requirement)	- Check			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
SWL Stickers (UK)	- Renew as Required			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Note: Operation must be carried out at the end of each set period, ie. The 10 Hour operations must be carried out after **every** 10 Hours.

Note: The First 100 Hour Operations are carried out after the initial 100 hours only.

Note ††: When operating in regions where ambient temperatures exceed 32° C (90° F), change at 500 Hours.

Note †: When operating in extreme conditions, change at 250 Hours.


Note: We recommend that the services marked with an * are carried out by a recognised JCB Distributor.

GREASING

Shovel Pivot Pins

Total of 2 grease points.

Normally two strokes of the gun should be sufficient. Stop greasing when fresh grease appears at the joint.




S132230

GREASING

Loader End

Total of 9 grease points.


Normally two strokes of the gun should be sufficient. Stop greasing when fresh grease appears at the joint.



GREASING

Centre Pivot and Steering Ram


Total of 5 grease points.



S101340

Intermediate Propshaft

Total of 3 grease points.




S132240

GREASING

Propshafts (Except Intermediate)

Total of 7 grease points.



S132250

GREASING (409 Telemaster)**Boom Wear Pad Runways**

Extend the boom fully. Spray Waxoyl evenly over the swept surfaces; internally to the outer boom and externally to the inner boom. Ensure that all surfaces have complete and even cover. Allow 2-3 hours drying time before re-assembling or retracting the boom.

- * **Note:** Waxoyl to be applied internally to inner boom rear end for 300 mm length.

 CAUTION

Waxoyl contains turpentine substitute, which is flammable. Keep flames away when applying Waxoyl. Waxoyl can take a few weeks to dry completely. Keep flames away during the drying period.

Do not weld near the affected area during the drying period. Take the same precautions as for oil to keep Waxoyl off your skin. Do not breathe the fumes. Apply in a well-ventilated area.

5-3-1-9


GREASING (409 Telemaster)**⚠ WARNING**

Make the machine safe before working underneath it. Park the machine on level ground and lower the attachments, (if it is necessary to work with the boom raised, the boom safety strut must be fitted). See Boom Safety Strut in MAINTENANCE section. Engage the parking brake, put the transmission in neutral and stop the engine. Chock both sides of all four wheels. If you are working near the articulation danger zone, fit the articulation safety lock. See Articulation Lock in MAINTENANCE section.

4-3-2-6

Boom Pivot Points

Total of 13 grease points.



Contents	Page No.
Technical Data	
- 406 and 407	1 - 1
- 408 and 409	1 - 2
- 409 Telemaster	1 - 3
Fluid Level and Filter	
- 406	2 - 1
- 408	2 - 2
Tank and Suction Strainer	2 - 3
Pump	
- Operation	3 - 1
- Removal, Replacement and Inspection	
- 406	3 - 3
- 407 and 409	3 - 5
System Neutral Circuit	4 - 1
* System Neutral Circuit (409 Telemaster)	4 - 2
Loader Valve	
- Neutral Circuit	6 - 1
- Load Hold Check Valve - Op 1	7 - 1
- Load Hold Check Valve - Op 2	7 - 2
- Float Operation	7 - 3
- M.R.V. Operation	8 - 1
- A.R.V. Operation	9 - 1
- Removal and Replacement	
- 406	10 - 1
- 408	10 - 2
- Dismantling and Assembly	
- Relief Valve/inter-section Sealing	11 - 1
- Standard Spools	11 - 2
- Float (Lift) Spool	11 - 3
- Pressure Testing	
- Main Relief Valve	12 - 1
Loader Valve (409 Telemaster)	
- Neutral Circuit	13 - 1
- Boom Lift Operation	13 - 2
- Boom Lower Operation	13 - 4
- Hose Burst Operation	13 - 6
- Boom Extend Operation	13 - 8
- Removal and Replacement	13 - 10
- Dismantling and Assembly	
- Relief Valve Inter-section Sealing	13 - 11
- Solenoid Operated Spool	13 - 12
- Pilot Pressure Operated Spool	13 - 13
- Pressure Testing	
- Main and Auxiliary Relief Valves	13 - 14
* - Servo	13 - 15

Contents No.	P a g e
Typical Ram	
- Cutaway Illustration	14 - 1
- Removal and Replacement	
- 406	15 - 1
- 408	15 - 3
- Metric Ram	15 - 5
Schematic Circuit (Cetops)	
- 406	16 - 1
- 408	16 - 2
- 409 Telemaster	16 - 3

* **TECHNICAL DATA (406 and 407 Machines)****Pump**

Type Sundstrand AFGP 28L-30442 (gear type)
 Flow at 2000 rev/min and 186 bar (2700 lbf/in²) 56 litres/min 12.3 UK gal/min 14.8 US gal/min

Main Relief Valve Operating Pressure	bar	kgf/cm ²	lbf/in ²
	186	190	2700

Auxiliary Relief Valves Operating Pressures

Shovel Ram Rod Side	158	160	2300
Shovel Ram Head Side	227	230	3300

Filter

By-pass pressure	1.05	1.07	15.0
------------------	------	------	------

Ram Torque Settings

	Nm	kgf m	lbf ft
Piston Head (all rams except steer ram)	405	41.3	300
End Cap (all rams except steer ram)	678	69.2	500
Piston Head (steer ram)	300	30.6	221
End Cap (steer ram)	450	45.9	332

Ram Dimensions [mm (in.)]	Bore	Stroke	Rod Dia.	Piston Head A/F	Cap A/F
* Steering Ram (to m/c 631796)	60 (2.36)	245.5 (9.67)	30 (1.18)	40	50
* Steering Ram (from m/c 631797)	60 (2.36)	245.5 (9.67)	30 (1.18)	45	55
* Shovel Ram (to m/c 631796)	100 (3.94)	387.5 (15.26)	60 (2.36)	75	95
* Shovel Ram (from m/c 631797)	100 (3.94)	387.5 (15.26)	60 (2.36)	75	85
* Lift Ram (to m/c 631796)	100 (3.94)	715.0 (28.15)	60 (2.36)	75	95
* Lift Ram (from m/c 631797)	100 (3.94)	715.0 (28.15)	60 (2.36)	75	85
Quick Hitch (Twin piston cylinder)	60 (2.36)	54.0 (2.13)	44.4 (1.75)	-	73

* **TECHNICAL DATA (408 and 409 Machines)****Pump**

Type	Sundstrand AFGP 36L-31805 (gear type)		
Flow at 2000 rev/min and 207 bar (3000lbf/in ²)	72 litres/min	15.8 UK gal/min	19 US gal/min

Main Relief Valve Operating Pressure	bar	kgf/cm ²	lbf/in ²
	207	211	3000

Auxiliary Relief Valves Operating Pressures

Shovel Ram Rod Side	172	175	2494
Shovel Ram Head Side	228	233	3306

Filter

By-pass pressure	1.05	1.07	15.0
------------------	------	------	------

Ram Torque Settings

	Nm	kgf m	lbf ft
Piston Head (all rams)	405	41.3	300
End Cap (all rams)	678	69.2	500

Ram Dimensions [mm (in.)]	Bore	Stroke	Rod Dia.	Piston Head A/F	Cap A/F
Steering Ram	70 (2.76)	246 (9.69)	40 (1.58)	55	65
* Shovel Ram (to m/c 631870)	100 (3.94)	397 (1563)	60 (2.36)	75	95
* Shovel Ram (from m/c 631871)	100 (3.94)	397 (1563)	60 (2.36)	75	85
* Lift Ram (to m/c 631870)	110 (4.33)	708 (27.87)	60 (2.36)	75	95
* Lift Ram (from m/c 631871)	110 (4.33)	708 (27.87)	60 (2.36)	85	95
Quick Hitch (Twin piston cylinder)	60 (2.36)	54 (2.13)	44.4 (1.75)	-	73

TECHNICAL DATA (409 Telemaster)**Pump**

Type	Sundstrand AFGP 36L-31805 (gear type)		
Flow at 2250 rev/min and 207 bar (3000 lbf/in ²)	81 litres/min	17.8 UK gal/min	21.4 US gal/min

Main Relief Valve Operating Pressure	bar	kgf/cm ²	lbf/in ²
	207	211	3000

Auxiliary Relief Valves Operating Pressures

* Forward Tilt (G)	280	286	4060
* Backward Tilt (F)	280	286	4060
* Servo Pressure (at PRV)	30	30	435

Filter

By-pass pressure	1.05	1.07	15.0
------------------	------	------	------

Ram Torque Settings

	Nm	kgf m	lbf ft
Piston Head (all rams)	405	41.3	300
End Cap (all rams)	678	69.2	500

Ram Dimensions [mm (in.)]	Bore	Stroke	Rod Dia.	Piston Head A/F	Cap A/F
Steering Ram	70 (2.76)	246 (9.69)	40 (1.58)	55	65
Tilt Ram	120 (4.73)	285 (11.23)	70 (2.76)	95	105
Compensating Ram	70 (2.76)	630 (24.82)	40 (1.58)	55	65
Lift Ram	110 (4.33)	842 (33.18)	60 (2.36)	85	95
Extending Ram	70 (2.76)	1,200 (47.28)	40 (1.58)	55	65
Quickhitch (Twin piston cylinder)	40 (1.58)	40 (1.58)	30 (1.18)	-	-

FLUID LEVEL & FILTER (406 Machine)*** Check Level** for interval see *Service Schedule*

Before checking level place the machine on firm level ground with loader arms lowered and shovel resting on the ground, transmission in neutral, parking brake applied, and engine switched off.

Examine sight gauge at **A** to ensure that fluid is visible between the upper and lower marks.


Top up at **B** as required.

 **CAUTION**

Do not run engine with filler cap removed.
HYD 3-1

*** Renew Element** for interval see *Service Schedule*

1. Follow precautions above, except place the shovel in the fully dumped position to inhibit syphoning when the filter element is removed.
2. Remove filler cap; unscrew and discard element **C**.
3. Clean all metal parts in JCB Hydraulic Fluid.
4. Lubricate seal **D**; fit new element hand tight only.
5. Top up system at **B**.
6. Run engine for a few minutes, then recheck level at **A**.



FLUID LEVEL & FILTER (406 Machine)*** Check Level** for interval see Service Schedule

Before checking level place the machine on firm level ground with loader arms lowered and shovel resting on the ground, transmission in neutral, parking brake applied, and engine switched off.

Examine sight gauge at **A** to ensure that fluid is visible between the upper and lower marks.


Top up at **B** as required.


 **CAUTION**

Do not run engine with filler cap removed.
HYD 3-1

*** Renew Element** for interval see Service Schedule

1. Follow precautions above, except place the shovel in the fully dumped position to inhibit syphoning when the filter element is removed.
2. Remove filler cap; unscrew and discard element **C**.
3. Clean all metal parts in JCB Hydraulic Fluid.
4. Lubricate seal **D**; fit new element hand tight only.
5. Top up system at **B**.
6. Run engine for a few minutes, then recheck level at **A**.





S102110

HYDRAULIC TANK & SUCTION STRAINER**Drain and Refill** *for interval see Service Schedule*

Place the machine on firm level ground with loader arms lowered and shovel resting on the ground, transmission in neutral, parking brake applied, and engine switched off. Fit articulation safety link and chock wheels.

- 1 To drain tank remove filler cap and drain plug.
- 2 Before replacing drain plug, apply JCB Lock and Seal to thread.
- 3 Refill tank to sight gauge markings.
- 4 Run engine for a few minutes, then recheck level.


Clean Suction Strainer *for interval see Service Schedule*

- 1 After draining tank, unscrew nuts **A** and remove battery mounting plate **B**.
- 2 Unscrew nuts **C**, remove cover plate **D** and gasket **E**.
- 3 Unscrew nut **F**, remove strainer and wash in petrol or carbon tetrachloride.

Note: If a new strainer is fitted it should be washed in the same way to remove any protective coating.

- 4 Reassemble in reverse order, using a new gasket **E**.
- 5 After refilling to the correct level check the sight gauge to ensure that the hydraulic fluid remains clear during machine operation. Cloudiness indicates that water or air has entered the system which could cause serious damage.

PUMP OPERATION



9808/4801



9808/4801

PUMP OPERATION

The pump is a gear type, mounted at the rear of the machine and driven by the engine.

The working principle of a gear pump depends upon the meshing of two spur gears **A**. Oil is picked up on the suction side of the pump by the gears and carried round between the gear teeth and the pump body. As the gears come into mesh the oil is forced out through the outlet port.

Some oil is allowed to circulate behind the bearings **C** to hold them against the gears and minimise oil slippage. Lubrication oil is drawn through the recess **B** and around the counterbore. The oil then flows along scrolled grooves in the bearing bushes, induced by the viscous drag of the rotating shaft.



PUMP (Sundstrand)

Note: Before removing and dismantling the pump, check flow and pressure. If either of these is low and cannot be corrected at the relief valve, the appropriate pump section must be renewed completely. Renewal of components such as gears, bearings and housings will not effect a permanent cure. If the pump output is satisfactory but there is external leakage, the pump should be removed and dismantled for re-sealing only.

Removal and Replacement

Remove number plate carrier to gain access to pump. Disconnect and plug inlet and outlet hoses. Unscrew coupling bolts **1** then remove bolt **2** and withdraw pump from machine.

Replace by reversing the removal sequence.

When renewing resilient bush **23**, coat with concentrated soap solution and press into the boss so that it protrudes a nominal 2 mm (0.080 in) either side. When pump is mounted on machine there must be nil clearance between bush and sleeve **5** in order to avoid loading bracket **22**. Incorrect assembly will cause premature pump shaft failure.

Assemble sleeve **5** with chamfered end toward bracket **22**.

CAUTION

Because the pump inlet connection is above the maximum fluid level in the hydraulic tank it is essential that, after installation, the pump and the inlet hose are primed with JCB Hydraulic Fluid prior to running the engine.

HYD 3-2

Priming the Pump

Before connecting the outlet hose from the pump, fill the pump with clean hydraulic fluid and allow to drain partially.

Make sure that the engine cannot start (Remove the engine stop fuse on later machines - pull the engine stop handle on earlier machines).

Motor the engine until there is a positive flow of hydraulic fluid from the pump outlet.

Connect the outlet hose.

Dismantling and Assembly

When Dismantling

The numerical sequence shown on the illustration is intended as a guide to dismantling.

Remove sharp edges and burrs from shaft to avoid seal damage.

Mark covers **11** and **13** and housing **19** to ensure correct replacement. Do not damage machined faces by prising them apart - use a soft faced hammer.

Withdraw the gears **15** and bearings **16** and **17** from the body bore as an assembly, carefully noting their original

positions of manual. Download All 457 pages at:

<https://www.arepairmanual.com/downloads/jcb-406407408409-wheel-loader-service-repair-manual/>

* Inspection

It is normal for the gears to have cut a slight track in the body bore on the inlet side. The gear track wear cannot be measured accurately but will be related to bearing wear. Examine the bores of the bearing blocks **16**, and **17**, which are coated during manufacture with PTFE. If the grey PTFE is worn through so that the bronze base is visible, the complete pump must be renewed.

Renew pump if faces of bearing blocks are scored or if side faces of gears are chipped or damaged. DO NOT use any abrasives on the bearing blocks or gears as this would destroy critical manufacturing dimensions.

When Assembling

Wash all components, then apply hydraulic oil immediately afterwards to prevent moisture from collecting.

Renew all seals and 'O' rings. Grease the lips of seals **18**.

Install bearings **16** and **17** with recesses **K** positioned on the inlet side facing the gears, and the relieved radii on the outlet side of the pump.

Align housing and covers using marks previously made, after checking that protrusion of dowels **13A** is 3.5 mm (0.138 in).

Locate bolts **1** in drive flange before fitting flange to shaft. Ensure that tab washer **7** is located in the keyway, and bend up tabs after torque tightening nut **6**.

Apply Loctite 577 to threads of inlet and outlet adaptors L. Fit and tighten adaptors **L** to 45 - 50 Nm (4.6 - 5.1 kgf m; 33 - 37 lbf ft).

Refit and prime the pump.

Torque Settings

Item	Nm	kgf m	lbf ft
1	77	7.9	57
2	118	12.0	87
6	95-100	9.7-10.2	70-74
10	85-95	8.7-9.7	63-70
20	117	11.9	86