



# Service Manual

## FASTRAC 1115, 1115S, 1125 & 1135

PUBLISHED BY THE  
TECHNICAL PUBLICATIONS DEPARTMENT  
OF JCB SERVICE: ©  
ROCESTER, STAFFORDSHIRE, ST14 5LS,  
ENGLAND  
Tel. ROCESTER (01889) 590312  
PRINTED IN ENGLAND

Publication No. 9803/0010

Sample of manual. Download all 962 pages at:

<https://www.arepairmanual.com/downloads/jcb-11151115s11251135-fastrac-service-repair-manual/>

<b>General Information</b>	<b>1</b>
<b>Care &amp; Safety</b>	<b>2</b>
<b>Routine Maintenance</b>	<b>3</b>
<b>Optional Equipment</b>	<b>A</b>
<b>Body &amp; Framework</b>	<b>B</b>
<b>Electrics</b>	<b>C</b>
<b>Controls</b>	<b>D</b>
<b>Hydraulics</b>	<b>E</b>
<b>Transmission</b>	<b>F</b>
<b>Brakes</b>	<b>G</b>
<b>Steering</b>	<b>H</b>
<b>Suspension</b>	<b>S</b>
<b>Engine</b>	<b>T</b>

## Introduction

This publication is designed for the benefit of JCB Distributor Service Engineers who are receiving, or have received, training by JCB Technical Training Department.

These personnel should have a sound knowledge of workshop practice, safety procedures, and general techniques associated with the maintenance and repair of hydraulic earthmoving equipment.

Renewal of oil seals, gaskets, etc., and any component showing obvious signs of wear or damage is expected as a matter of course. It is expected that components will be cleaned and lubricated where appropriate, and that any opened hose or pipe connections will be blanked to prevent excessive loss of hydraulic fluid and ingress of dirt. Finally, please remember above all else

### SAFETY MUST COME FIRST!

The manual is compiled in sections, the first three are numbered and contain information as follows:

- 1 = **General Information** - includes torque settings and service tools.
- 2 = **Care & Safety** - includes warnings and cautions pertinent to aspects of workshop procedures etc.
- 3 = **Routine Maintenance** - includes service schedules and recommended lubricants for the whole machine.

The remaining sections are alphabetically coded and deal with Dismantling, Overhaul etc. of specific components, for example:

- A = **Optional Equipment**
- B = **Body & Framework** ...etc

The page numbering in each alphabetically coded section is not continuous. This allows for the insertion of new items in later issues of the manual.

Section contents, technical data, circuit descriptions, operation descriptions etc. are inserted at the beginning of each alphabetically coded section.

All sections are listed on the front cover; tabbed divider cards align directly with individual sections on the front cover for rapid reference.

Page cross references are generally made by presenting the subject title printed in bold, followed by the title of the section containing the subject. For example:

"24 If the axle is still on the machine, fit the brake calipers (see **Brake Caliper Removal and Replacement**, Section G)."

**Note:** If only the subject title in bold is given, i.e. no section title, the cross reference is to another part of the same section.

Use the contents list at the beginning of each section to find the exact page number.

Where a torque setting is given as a single figure it may be varied by plus or minus 3%. Torque figures indicated are for dry threads, hence for lubricated threads may be reduced by one third.

'Left Hand' and 'Right Hand' are as viewed from the rear of the machine facing forwards.

## Colour Coding

The following colour coding, used on illustrations to denote various conditions of oil pressure and flow, is standardised throughout JCB Service Publications.



**Blue:** Neutral Circuit Pressure.



**Light Green:** Oil subjected to a partial vacuum due to a drop in pressure (cavitation).



**Red:** Pressure generated by the operation of a service. Depending on application this may be anything between Neutral Circuit Pressure and M.R.V. Operating Pressure.

**Yellow:** Oil trapped within a chamber or line, preventing movement of components (lock-up).



**Pink:** Pressure that is above Neutral Circuit Pressure but lower than that denoted by Red.



**Orange:** Oil pressure used in a controlling device (servo).




**Green:** Exhaust.


## Black/White Coding



Neutral Circuit Pressure




Oil subjected to a partial vacuum due to a drop in pressure (cavitation).



Pressure generated by the operation of a service. Depending on application this may be anything between Neutral Circuit Pressure and M.R.V. Operating Pressure.




Oil trapped within a chamber or line, preventing movement of components (lock-up).



Pressure that is above Neutral Circuit Pressure but lower than that denoted above.



Oil pressure used in a controlling device (servo).




Exhaust.

Contents	Page No.
Serial Number Plate	1 - 1
Typical Vehicle Identification Number (VIN)	1 - 1
Typical Engine Identification Number	1 - 1
Unit Identification	1 - 1
Torque Settings	2 - 1
Sealing and Retaining Compounds	3 - 1
Service Tools Numerical List	4 - 1
Service Tools	
Body and Framework	5 - 1
Electrics	6 - 1
Hydraulics	7 - 1
Transmission	8 - 1
* Brakes	8 - 4
Steering	8 - 5
Suspension	8 - 5
Engine	8 - 5
Moving a Disabled Machine	10 - 1
Preparation for Towing	10 - 1
Transporting the Machine	10 - 2

**\* Machine Identification Plate**

Each machine has an identification plate located on the front of the seat base. Vehicle Identification Number (VIN), and the serial numbers of the engine, gearboxes and axles are stamped on the plate.

**Typical Vehicle Identification No. (VIN)**



**A** = Manufacturing Code

**B** = Machine Range

**\* C = Engine Code:**

- 11 = 1000 Series 1006-6LR (1115)
- 12 = 1000 Series, Rating 1815/2400 (Earlier 1135)
- 13 = New 1000 Series, Rating 1941/2300 (1115S)
- 14 = New 1000 Series, Rating 1929/2300 (1125)
- 15 = New 1000 Series, Rating 1947/2300 (Later 1135)

**D = Transmission Speed Code:**


- 3 = 30 km/h
- 4 = 40 km/h
- 5 = 50 km/h

**E = Vehicle Max. Speed Code:**

- 30 = 30 km/h
- 40 = 40 km/h
- 50 = 50 km/h

**F** = Sequential Serial Number

**Typical Engine Identification Number**



**\* G = Engine Type:-**

- YA = Normally Aspirated 1000 Series 6 cylinder
- YB = Turbocharged 1000 Series, 6 cylinder
- YH = Turbocharged New 1000 Series, 6 cylinder

**H** = Build List Number

(see **Engine Technical Data** for details)

**J** = Country of Origin


**K** = Engine Serial Number

**L** = Year of Manufacture

**Unit Identification**

The serial number of each major unit is also stamped on the unit itself as shown below. If a major unit is replaced by a new one, the serial number on the plate will be wrong. Either stamp the new number of the unit on the identification plate, or simply stamp out the old number. This will prevent the wrong unit number being quoted when replacement parts are ordered.

- Engine **M**
- Transmission (Assembly of all three gearboxes) **N**
- Speed Gearbox **P**
- Front Axle **R**
- Rear Axle **S**



227090

## Torque Settings

Use only where no torque setting is specified in the text. Values are for dry threads and may be within three per cent of the figures stated. For lubricated threads the values should be REDUCED by one third.

**Note:** All bolts used on JCB machines are high tensile and must not be replaced by bolts of a lesser tensile specification.

### Metric Grade 8.8 Bolts

Dia.	Bolt size		Torque Settings		
	(mm)	Hexagon (A/F) mm	Nm	kgf m	lbf ft
M5	(5)	8	7	0.7	5
M6	(6)	10	12	1.2	9
M8	(8)	13	28	3.0	21
M10	(10)	17	56	5.7	42
M12	(12)	19	98	10	72
M16	(16)	24	244	25	180
M18	(18)	27	350	36	258
M20	(20)	30	476	48	352
M24	(24)	36	822	84	607
M30	(30)	46	1633	166	1205
M36	(36)	55	2854	291	2105

### Metric - All Internal Hexagon Headed Cap Screws

Diameter mm	Torque		
	Nm	kgf m	lbf ft
M3	2	0.2	1.5
M4	6	0.6	4.5
M5	11	1.1	8
M6	19	1.9	14
M8	46	4.7	34
M10	91	9.3	67
M12	159	16.2	117
M16	395	40	292
M18	550	56	406
M20	770	79	568
M24	1332	136	983

### Hydraulic Hose to Adapter Connections

BSP Size (inches)	Torque Settings		
	Nm	kgf m	lbf ft
1/8	14	1.4	10
1/4	24	2.5	18
3/8	33	3.3	24
1/2	44	4.8	35
5/8	58	6.0	43
3/4	84	8.6	62
1	115	11.8	85
1 1/2	244	24.9	180

### Hydraulic Adapter into Component Connections with bonded washers

BSP Size (inches)	Torque Settings		
	Nm	kgf m	lbf ft
1/8	20	2.1	15
1/4	34	3.4	25
3/8	75	7.6	55
1/2	102	10.3	75
5/8	122	12.4	90
3/4	183	18.7	135
1	203	20.7	150
1 1/2	305	31	225


## Sealing and Retaining Compounds

<b>JCB Multigasket</b>	A medium strength sealant suitable for all sizes of gasket flanges, and for hydraulic fittings of 25-65 mm diameter.	4102/1212	50ml
<b>JCB Threadlocker</b>	For threads of 50mm diameter upwards, eg. suction strainer.	4101/0451	50ml
<b>JCB Threadlocker (High Strength)</b>	A high strength locking fluid for use with threaded components. Gasketing for all sizes of flange where the strength of the joint is important.	4102/0551	50ml
<b>JCB Retainer (High Strength)</b>	For all retaining parts which are unlikely to be dismantled.	4101/0651	50ml
<b>JCB Threadlocker And Sealer</b>	A medium strength locking fluid for sealing and retaining nuts, bolts, and screws up to 50 mm diameter, and for hydraulic fittings up to 25 mm diameter.	4101/0250 4101/0251	10ml 50ml
<b>JCB Threadlocker And Sealer (High Strength)</b>	A high strength locking fluid for sealing and retaining nuts, bolts, and screws up to 50 mm diameter, and for hydraulic fittings up to 25 mm diameter.	4101/0550 4101/0552	10ml 200ml
<b>JCB Threadseal</b>	A medium strength thread sealing compound.	4102/1951	50ml
<b>JCB Activator</b>	A cleaning primer which speeds the curing rate of anaerobic products.	4104/0251 4104/0253	Aerosol (1 ltr) Bottle (200 ml)
<b>JCB Cleaner/Degreaser</b>	For degreasing components prior to use of anaerobic adhesives and sealants.	4104/1557	Aerosol (400ml)
<b>Direct Glazing Kit</b>	For one pane of glass; comprises items marked † below plus applicator nozzle etc.		
† <b>Ultra Fast Adhesive</b>	For direct glazing	4103/2109	310 ml
† <b>Active Wipe 205</b>	For direct glazing	4104/1203	250 g
† <b>Black Primer 206J</b>	For direct glazing	4201/4906	30 ml
<b>Clear Silicone Sealant</b>	To seal butt jointed glass.	4102/0901	



## Service Tools


### Section B - Body and Framework



S186240

**Hand Cleaner** - special blend for the removal of polyurethane adhesives.


JCB part number - 4104/1310 (454g; 1lb tub)



S186270

**Cartridge Gun** - hand operated - essential for the application of sealants, polyurethane materials etc.


JCB part number - 892/00845



S186250

**12V Mobile Oven** - 1 cartridge capacity - required to pre-heat adhesive prior to use. It is fitted with a male plug (703/23201) which fits into a female socket (715/04300).


JCB part number - 992/12300



S186280

**Folding Stand for Holding Glass** - essential for preparing new glass prior to installation.

JCB part number - 892/00843




S186260

**240V Static Oven** - available with 2 or 6 cartridge capacity - required to pre-heat adhesive prior to use. No plug supplied. Note: 110V models available upon request - contact JCB Technical Service

JCB part number:

992/12400 - 2 cartridge x 240V

992/12600 - 6 cartridge x 240V



S186300

**Glass Lifter** - minimum 2 off - essential for glass installation, 2 required to handle large panes of glass. Ensure suction cups are protected from damage during storage.

JCB part number - 892/00842

Service Tools

Section C - Electrics

1 892/00283 Tool Kit Case  
 2 892/00281 AVO Meter  
 3 892/00286 Surface Temperature Probe  
 4 892/00284 Microtach Digital Tachometer  
 5 892/00282 100 Amp Shunt - open type  
 6 892/00285 Hydraulic Oil Temperature Probe  
 7 892/00298 Fluke 85 Multimeter

188230

993/85700 Battery Tester


239510

892/00882 Socket for Pulley Nut on Magneti Marelli Alternator.

S216770

**Service Tools**


**Section E - Hydraulics**



**Hydraulic Circuit Pressure Test Kit**

892/00253	Pressure Test Kit
892/00201	Replacement Gauge 0-20 bar (0-300 lbf/in <sup>2</sup> )
892/00202	Replacement Gauge 0-40 bar (0-600 lbf/in <sup>2</sup> )
892/00203	Replacement Gauge 0-400 bar (0-6000 lbf/in <sup>2</sup> )
892/00254	Replacement Hose
:993/69800	Seal Kit for 892/00254 (can also be used with probe 892/00706)


S188120



**Pressure Test T Adapters**

892/00262	1/4 in M BSP x 1/4 in F BSP x Test Point
816/55038	3/8 in M BSP x 3/8 in F BSP x Test Point
816/55040	1/2 in M BSP x 1/2 in F BSP x Test Point
892/00263	5/8 in M BSP x 5/8 in F BSP x Test Point
892/00264	3/4 in M BSP x 3/4 in F BSP x Test Point
892/00265	1 in M BSP x 1 in F BSP x Test Point

S188130




**Pressure Test Adapters**

892/00255	1/4 in BSP x Test Point
892/00256	3/8 in BSP x Test Point
892/00257	1/2 in BSP x Test Point
892/00258	5/8 in BSP x Test Point
816/15118	3/4 in BSP x Test Point
892/00259	1 in BSP x Test Point
892/00260	1.1/4 in BSP x Test Point
892/00261	5/8 in UNF x Test Point

S200140

**Flow Test Equipment**


892/00268	Flow Monitoring Unit
892/00269	Sensor Head 0 - 100 l/min (0 - 22 UK gal/min)
892/00293	Connector Pipe
892/00270	Load Valve
1406/0021	Bonded Washer
1604/0006	Adapter 3/4 in M x 3/4 in M BSP
1612/0006	Adapter 3/4 in F x 3/4 in M BSP
892/00271	Adapter 3/4 in F x 5/8 in M BSP
892/00272	Adapter 5/8 in F x 3/4 in M BSP
816/20008	Adapter 3/4 in F x 1/2 in M BSP
892/00275	Adapter 1/2 in F x 3/4 in M BSP
892/00276	Adapter 3/4 in F x 3/8 in M BSP
892/00277	Adapter 3/8 in F x 3/4 in M BSP
892/00273	Sensor Head 0 - 380 l/min
892/00294	Connector Pipe
1606/0015	Adapter 1.1/4 in M BSP x 1 in M BSP
892/00078	Connector 1 in F x 1 in F BSP
1604/0008	Adapter 1 in M x 1 in M BSP
1606/0012	Adapter 1 in M x 3/4 in M BSP
816/20013	Adapter 3/4 in F x 1 in M BSP



S188150

Service Tools (continued)


Section E - Hydraulics (continued)



S193850


Hand Pump Equipment

- 892/00223 Hand Pump
- 892/00137 Micro-bore Hose 1/4 in BSP x 5 metres
- 892/00274 Adapter 1/4 in BSP male x 3/8 BSPT male
- 892/00262 Test Point on 1/4 in BSP male x 1/4 BSP female adapter
- 892/00706 Test Probe
- 892/00278 Gauge 0-40 bar (0-600 lbf/in<sup>2</sup>)
- 892/00279 Gauge 0-400 bar (0-6000 lbf/in<sup>2</sup>)





197210

892/00318 Hose And Adapter Kit  
To enable flow and pressure test equipment to be connected to adapters fitted with 'O' ring face seals.



197220

892/00334 Gland Seal Fitting Tool










A234740

\*Extractor Tool - Pump P1 Line Filter Retainer.  
Manufacture locally.


Service Tools

Section F - Transmission



**Service Tools (continued)**

**Section F - Transmission (continued)**



993/45400 Torque Multiplier  
(use in conjunction with a torque wrench to give a 5 : 1 multiplication)


S197030



Heavy Duty Sockets


892/00817	17 mm A/F x 3/4in. square drive
892/00818	22 mm A/F x 3/4in. square drive
892/00819	15 mm A/F x 1/2in. square drive
892/00333	19 mm A/F x 3/4in. square drive

197250




892/00174 Measuring Cup - Pinion Head Bearing

S190770




892/00224 Impulse Extractor Set for Hub Bearing Seals

S197070




892/00312 Dummy End Plate for Range Gearbox

S197240



477/00437 Gearbox Lifting Adapter

197200







110  
25 25  
15  
40

A197180

Rear Differential Setting Key  
Cut from 5 mm plate to dimensions shown. Fabricate handle to suit.


Service Tools (continued)

Section F - Transmission (continued)




## Service Tools (continued)

## Section F - Transmission (continued)




## Section G - Brakes




## Service Tools (continued)


### Section H - Steering



### Section S - Suspension



### Section T - Engine



## General

Do not tow a machine unless there is no alternative. Remember that more damage might be caused to the machine by towing it. If at all possible repair the machine where it stands.

**Note:** It is not possible to tow-start a machine fitted with JCB Powersplit.

Make sure you will be obeying all pertinent laws and regulations before towing the machine on public roads.

### **⚠ DANGER**

If the engine is not running, there will not be enough pressure to apply the service brakes. Carefully follow the precautions on this page before moving the machine or there may be a serious accident.

13-2-4-4


### **⚠ CAUTION**

Towing a machine too far or too fast can damage the transmission. Do not tow the machine further than one mile. Use a trailer for greater distances. When towing do not travel faster than 25 km/h (15 mph).

Use a rigid drawbar. If you must use towing chains, then use two towing vehicles. One towing vehicle should be coupled to the front of the disabled machine. The other towing vehicle should be coupled to the rear of the disabled machine, to provide braking power.

The towing vehicle(s) must have enough pulling and braking power to move and stop the machine.

2-2-7-3



## \* Preparation for Towing

- 1 **Connect the towing vehicle.**
  - a Apply the parking brakes on the towing vehicle and securely chock the wheels on the Fastrac.
  - b Fit the drawbar between towing vehicle and Fastrac.
- 2 **Prepare the machine.**
  - a Make sure that the range and speed gearboxes are both in neutral.
  - b If the gearbox has failed, disconnect both propshafts (see Section F).
  - c If an axle has failed, remove the sun gears (see Section F).
- 3 **Release the Fastrac parking brake.**
  - a Machines to Serial No. 737000  
Release the machine parking brake by means of the hand lever.
  - b Machines from Serial No. 737001  
If there is not enough air pressure to release the brake, start the engine to charge up the air system. If the engine cannot be run but the brake air system is serviceable, charge the system to 120 psi (8 bar) through Schrader valve X. This job must be done by a qualified mechanic, using the correct equipment.

### **⚠ DANGER**

Ensure that the chocks and towing vehicle will prevent the Fastrac from moving as it is necessary to work under the machine to release the parking brake. When the parking brake has been manually released as described below, it will be impossible to apply the brake until plate A has been removed.


13-2-2-11

Alternatively, position plate A (if provided with the machine) as shown. Keeping nut B tight against clevis C, turn nut D against the plate so that rod E is drawn out of the actuator body and the parking brake is released.

**Note:** If the parking brake cannot be released, remove both propshafts (see Section F).

The machine is now ready for towing. If you will be steering the Fastrac, make sure you understand what the towing driver will be doing. Obey his instructions and all relevant regulations.

Remember that the steering will be much heavier if the engine is not running.



## \* Transporting the Machine

The safe transit of the load is the responsibility of the transport contractor and driver. Any machine, attachments or parts that may move during transit must be adequately secured.

5-2-5-9

**Note:** Before transporting the machine make sure you will be obeying the rules and laws of all the areas that the machine will be carried through.

Make sure that the transporting vehicle is suitable. See **Static Dimensions** (SPECIFICATIONS section in the machine handbook) for the dimensions of the machine.


### WARNING

Before moving the machine onto the trailer, make sure that the trailer and ramp are free from oil, grease and ice. Remove oil, grease and ice from the machine tyres. Make sure the machine will not foul on the ramp angle. See Static Dimensions in SPECIFICATIONS section for the minimum ground clearance of your machine.

2-2-7-5/1

- 1 Place blocks at the front and rear of the trailer wheels.
- 2 Move the machine on to the trailer as follows:
  - a Make sure the ramps are correctly in place and secure.
  - b Carefully drive the machine onto the trailer.
  - c Set the drive to neutral and engage the parking brake.
  - d Switch off the engine.
  - e Ensure that the overall height of the load is within regulations.
  - f Secure the cab.

- 3 Anchor the machine to the trailer with chains or suitable webbing straps. The preferred fixing is to use webbing straps individually fixing all four wheels to the deck of the trailer as at **A**. If chains are used they should be connected to a suitable part of the drawbar at the rear of the machine. At the front, use the tie down points. Avoid chaining any part of the machine where the chains may damage critical componentry. For example, chaining around either axle provides the possibility of damaging the steel brake pipes running along their length.
- 4 Measure the maximum height of the machine from the ground. Try to make sure the truck driver knows the clearance height before he drives away.



<b>Contents</b>	<b>Page No.</b>
Safety Notices	1 - 1
General Safety	2 - 1
Operating Safety	3 - 1
Maintenance Safety	4 - 1

In this publication and on the machine, there are safety notices. Each notice starts with a signal word. The signal word meanings are given below.

### **DANGER**

Denotes an extreme hazard exists. If proper precautions are not taken, it is highly probable that the operator (or others) could be killed or seriously injured.

INT-1-2-1

### **WARNING**

Denotes a hazard exists. If proper precautions are not taken, the operator (or others) could be killed or seriously injured.

INT-1-2-2

### **CAUTION**

Denotes a reminder of safety practices. Failure to follow these safety practices could result in injury to the operator (or others) and possible damage to the machine.

INT-1-2-3

All construction and agricultural equipment can be hazardous. When a JCB Fastrac is correctly operated and properly maintained, it is a safe machine to work with. But when it is carelessly operated or poorly maintained it can become a danger to you (the operator) and others.

Do not work with the machine until you are sure that you can control it.

Do not start any job until you are sure that you and those around you will be safe.

If you are unsure of anything, about the machine or the job, ask someone who knows. Do not assume anything.

**Remember**

**BE CAREFUL  
BE ALERT  
BE SAFE**

GEN-1-6

As well as the warnings in the following pages, specific warnings are given throughout the book. This section is designed to give a safety code for use of the machine generally and for operation and maintenance practices.

## General Safety

**⚠ WARNING**  
**Lifting Equipment**

You can be injured if you use faulty lifting equipment. Make sure that lifting equipment is in good condition. Make sure that lifting tackle complies with all local regulations and is suitable for the job. Make sure that lifting equipment is strong enough for the job.

INT-1-3-7

**⚠ WARNING**  
**Clothing**

You can be injured if you do not wear the proper clothing. Loose clothing can get caught in the machinery. Wear protective clothing to suit the job. Examples of protective clothing are: a hard hat, safety shoes, safety glasses, a well fitting overall, ear-protectors and industrial gloves. Keep cuffs fastened. Do not wear a necktie or scarf. Keep long hair restrained.

INT-1-3-6

**⚠ WARNING**  
**Alcohol and Drugs**

It is extremely dangerous to operate machinery when under the influence of alcohol or drugs. Do not consume alcoholic drinks or take drugs before or whilst operating the machine or attachments. Be aware of medicines which can cause drowsiness.

INT-1-3-9

**⚠ WARNING**  
**Care and Alertness**

All the time you are working with or on the machine, take care and stay alert. Always be careful. Always be alert for hazards.

INT-1-3-5

**⚠ WARNING**  
**Raised Equipment**

Raised equipment can fall and injure you. Do not walk or work under raised equipment unless safely supported.

13-1-1-6

**⚠ WARNING**  
**Machine Modifications**

This machine is manufactured in compliance with legislative and other requirements. It should not be altered in any way which could affect or invalidate any of these requirements. For advice consult your JCB Distributor.

Reference should also be made to Optional Attachments section where appropriate.

INT-1-3-10

## Operating Safety

### **DANGER**

#### Parking

Leaving the machine in gear will not prevent it running away. Do not leave the driving seat under any circumstances unless the parking brake is on.

13-2-1-10

### **WARNING**

#### Roll Over Protection Structure (ROPS)

The machine is fitted with a Roll Over Protection Structure (ROPS). You could be killed or seriously injured if you operate the machine with a damaged or missing ROPS. If the ROPS has been in an accident, do not use the machine until the structure has been renewed. Modifications and repairs that are not approved by the manufacturer may be dangerous and will invalidate the ROPS certification.

13-1-1-8/1

### **WARNING**

#### Entering/Leaving

Always face the machine when entering and leaving the cab. Use the step(s) and handrails. Make sure the step(s), handrails and your boot soles are clean and dry. Do not jump from the machine. Do not use the machine controls as handholds, use the handrails.

INT-2-1-7

### **WARNING**

#### Seat

Position the seat so that you can comfortably reach the machine controls. You could have an accident if you operate the machine with the seat in the wrong position.

INT-3-3-5

### **WARNING**

#### Seat Belt

Operating the machine without a seat belt can be dangerous. Before starting the engine, make sure your seat belt is fastened. Check the tightness and condition of the seat belt securing bolts regularly (see maintenance schedules).

INT 2-1-8/1

### **WARNING**

#### Passengers

Ensure that passengers use the seat provided in the cab. Passengers must not be carried on the rear deck of the vehicle under any circumstances.

13-1-1-1/1

### **WARNING**

#### Reversing

Reversing at high speeds can cause accidents. Always drive at a safe speed to suit working conditions

13-1-1-3

### **WARNING**

#### Visibility

Accidents can be caused by working in poor visibility. Keep windows clean and use your lights to improve visibility. Do not operate the machine if you cannot see properly.

INT-2-1-11

### **WARNING**

#### Practice

You or others can be killed or seriously injured if you do unfamiliar operations without first practising them. Practise away from the work site on a clear area. Keep other people away. Do not perform new operations until you are sure you can do them safely.

INT-2-1-1

### **WARNING**

#### Machine Limits

Operating the machine beyond its design limits can damage the machine, it can also be dangerous. Do not operate the machine outside its limits. Do not try to upgrade the machine performance with unapproved modifications.

INT-2-1-4

### **WARNING**

#### Brakes

Do not coast the machine with the engine stopped as the main brakes will only operate for a limited number of applications and hydraulic trailer brakes will not function at all. Also the steering will become very heavy.

13-1-1-5/2

### **CAUTION**

#### Hydraulic Traller Brakes

Trailers with single line hydraulic brakes used in the United Kingdom are subject to a maximum speed of 20 mph (32 kph).

13-2-2-8

### **CAUTION**

#### Trailer Brakes

Trailers with single line air brakes used in the Republic of Germany are subject to a maximum speed of 25 km/h (15 mph).

13-2-2-13

### **WARNING**

#### Engine

The engine has rotating parts. Do not open the engine cover while the engine is running. Do not use the machine with the cover open.

INT-2-1-6

## Operating Safety (cont'd)

### **WARNING**

#### **Banks and Trenches**

Banked material and trenches can collapse. Do not work or drive too close to banks and trenches where there is danger of collapse.

INT-2-2-5

### **WARNING**

#### **Ramps and Trailers**

Water, mud, ice, grease and oil on ramps or trailers can cause serious accidents. Make sure ramps and trailers are clean before driving onto them. Use extreme caution when driving onto ramps and trailers.

INT-2-2-6

### **WARNING**

#### **Communications**

Bad communications can cause accidents. Keep people around you informed of what you will be doing. If you will be working with other people, make sure any hand signals that may be used are understood by everybody. Work sites can be noisy, do not rely on spoken commands.

INT-2-2-3

### **WARNING**

#### **Engine/Steering Failure**

If the engine or steering fails, stop the machine as quickly as possible. Do not operate the machine until the fault has been corrected.

INT-2-1-5

### **DANGER**

#### **Sparks**

Explosions and fire can be caused by sparks from the exhaust or the electrical system. Do not use the machine in closed areas where there is flammable material, vapour or dust.

INT-2-2-10

### **WARNING**

#### **Controls**

Keep the machine controls clean and dry. Your hands and feet could slide off slippery controls. If that happens you will lose control of the machine.

2-2-3-6

### **WARNING**

#### **Exhaust Gases**

Breathing the machine exhaust gases can harm and possibly kill you. Do not operate the machine in closed spaces without making sure there is good ventilation. If possible, fit an exhaust extension. If you begin to feel drowsy, stop the machine at once. Get out of the cab into fresh air.

INT-2-1-10

### **WARNING**

#### **Connecting the Power Take-off**

Rotating equipment is dangerous. Always disengage the PTO and stop the engine before attempting to attach or detach an implement to or from a PTO shaft or before making adjustments to an implement connected to the machine via a PTO shaft.

13-2-1-5

### **WARNING**

#### **Power Take-off Operation**

When operating PTO equipment, always observe the following safety precautions:

Follow the instructions in the implement operator's handbook.

Rotating equipment is dangerous. Do not wear loose fitting clothing when working close to rotating shafts.

Always disengage the PTO, stop the engine and wait until the equipment stops, before:

- 1 Leaving the cab
- 2 Attempting to attach or detach an implement to or from a PTO shaft or
- 3 Working on or cleaning an implement connected to the machine via a PTO shaft.

Always ensure that the PTO shaft and driveline are fully guarded before use.

When using stationary PTO equipment, ensure that the parking brake is applied.

13-2-1-6

### **WARNING**

#### **Power Take-off Jamming**

If the PTO becomes jammed, disengage the PTO, stop the engine and clear the blockage. Wait until the PTO shaft stops before working on the equipment. If the PTO clutch slips, immediately disengage the PTO and stop the engine.

13-2-2-2

### **WARNING**

#### **Hitching Trailers and Equipment**

When the vehicle is approaching a trailer or equipment to be hitched, make sure that no persons are present between vehicle and trailer or equipment. When mounting equipment at the rear of the vehicle, you must ensure that proper steering control is maintained. The reduction of front axle loading must not exceed 80%.

13-1-1-13

## Operating Safety (cont'd)

### **WARNING**

#### **Tyres - General**

You could be killed or injured if a machine tyre bursts. Do not use the machine with damaged, incorrectly inflated or excessively worn tyres. Recognize the speed limitation of the tyres fitted and do not operate at more than their recommended maximum speed.

13-2-1-2

### **WARNING**

Certain tyres fitted as after-market equipment may have maximum permitted speeds below the maximum speed of the vehicle. Brake efficiency is slightly reduced and stopping distance is increased when these tyres are fitted. They will suffer damage if operated at speeds higher than those recommended and may endanger life.

13-3-2-5

### **WARNING**

#### **Tyre Speed Limitations**

Running tyres outside recommended guidelines may result in failure of the tyres which at high speeds may endanger life. **BE WARNED.**

13-3-1-6

### **WARNING**

#### **Rear Deck**

Passengers must not be carried on the rear deck of the vehicle. Ensure that loads carried on the rear deck are secured adequately to prevent them rolling about, falling off or toppling over.

13-1-1-12/1

### **WARNING**

#### **Weight Distribution**

The machine must never be loaded such that less than 20% of the unladen vehicle weight is carried on the front axle.

13-1-1-11

### **CAUTION**

#### **Weight Distribution**

The Fastrac has to comply with certain braking regulations which in some countries control weight distribution between front and rear axles. Travelling on the road with implements or weights carried on the front when no implement is on the rear may break the law. In this case you should transfer the front mounted equipment to the rear linkage. It is the operator's responsibility to know and observe the laws in the country concerned.

13-2-2-5

### **WARNING**

#### **Travel Speed**

Be aware of the load the machine is carrying or towing and the speed at which you are travelling. Do not corner fast when carrying heavy mounted implements or towing trailers. Reduce speed when towing non-suspended implements on rough ground.

13-2-2-1

### **WARNING**

#### **Stability**

In the event of the machine becoming unstable, keep firm hold of the steering wheel and do not try to leave the cab.

13-2-2-10

### **WARNING**

#### **Audible Warnings**

When you hear an audible warning, stop the machine as soon as possible. Get the fault put right before using the machine again.

13-2-1-9

### **WARNING**

#### **Controls**

When driving the machine on the road, use the accelerator pedal and not the hand throttle to control the engine speed.

13-2-1-8

## Maintenance Safety

### WARNING

#### Working Under the Machine

Make the machine safe before getting beneath it. Do the following: Park on level ground. Engage the parking brake. Lower any mounted implements to the ground. Stop the engine, remove the starter key, disconnect the battery. Chock the wheels.

13-3-1-1

### WARNING

#### Soft Ground

A machine can sink into soft ground. Never work under a machine on soft ground.

INT-3-2-4

### WARNING

#### Jacking

A machine can roll off jacks and crush you unless the wheels have been chocked. Always chock the wheels at the opposite end of the machine to that which is to be jacked. Do not work underneath a machine supported only by jacks. Always support a jacked-up machine on axle stands before working underneath it.

INT-3-2-8

### WARNING

#### Transmission Testing

The transmission is in 4 wheel drive until de-selected by hydraulic pressure to 2 wheel drive. If the machine is to be raised and the engine/transmission run, make sure all four wheels are off the ground and supported by axle stands as if only the rear wheels were raised, the machine could still drive through the front axle. Note that when a NoSpin differential is fitted, both front wheels will be driven even if one is jacked up and the other is on the ground.

TRAN 8-1/2

### WARNING

#### Diesel Fuel

Diesel fuel is flammable; keep naked flames away from the machine. Do not smoke while refuelling the machine or working on the engine. Do not refuel with the engine running. There could be a fire and injury if you do not follow these precautions.

INT-3-2-2

### WARNING

#### Petrol

Do not use petrol in this machine. Do not mix petrol with the diesel fuel; in storage tanks the petrol will rise to the top and form flammable vapours.

INT-3-1-6

### WARNING

#### Battery

A battery with frozen electrolyte can explode if it is used or charged. Do not use a machine with a frozen battery. To help prevent the battery from freezing, keep the battery fully charged.

INT-3-1-7

### WARNING

#### Battery Gases

Batteries give off explosive gases. Keep flames and sparks away from the battery. Do not smoke close to the battery. Make sure there is good ventilation in closed areas where batteries are being used or charged. Do not check the battery charge by shorting the terminals with metal; use a hydrometer or voltmeter.

INT-3-1-8

### WARNING

#### Battery Terminals

The machine is negatively earthed. Always connect the negative pole of the battery to earth.

When connecting the battery, connect the earth (-) lead last.

When disconnecting the battery, disconnect the earth (-) lead first.

INT-3-1-9

### WARNING

#### Electrical Circuits

Understand the electrical circuit before connecting or disconnecting an electrical component. A wrong connection can cause injury and/or damage.

INT-3-1-4

### WARNING

#### Hydraulic Hoses

Damaged hoses can cause fatal accidents. Inspect the hoses regularly for:

- Damaged end fittings
- Chafed outer covers
- Ballooned outer covers
- Kinked or crushed hoses
- Embedded armouring in outer covers
- Displaced end fittings.

INT-3-3-2

### WARNING

#### Rams

The efficiency of the rams will be affected if they are not kept free of solidified dirt. Clean dirt from around the rams regularly. When leaving or parking the machine, close all rams if possible to reduce the risk of weather corrosion.

INT-3-2-10

**Maintenance Safety (cont'd)****⚠ WARNING****Hydraulic Pressure**

Hydraulic fluid at system pressure can injure you. Before disconnecting or connecting hydraulic hoses, stop the engine and operate the controls to release pressure trapped in the hoses. Make sure the engine cannot be started while the hoses are open.

INT-3-1-11/1

**⚠ WARNING****Hydraulic Fluid**

Fine jets of hydraulic fluid at high pressure can penetrate the skin. Do not use your fingers to check for hydraulic fluid leaks. Do not put your face close to suspected leaks. Hold a piece of cardboard close to suspected leaks and then inspect the cardboard for signs of hydraulic fluid. If hydraulic fluid penetrates your skin, get medical help immediately.

INT-3-1-10/1

**⚠ WARNING****Oil**

Oil is toxic. If you swallow any oil, do not induce vomiting, seek medical advice. Used engine oil contains harmful contaminants which can cause skin cancer. Do not handle used engine oil more than necessary. Always use barrier cream or wear gloves to prevent skin contact. Wash skin contaminated with oil thoroughly in warm soapy water. Do not use petrol, diesel fuel or paraffin to clean your skin.

INT-3-2-3

**⚠ WARNING****Hot Coolant**

The cooling system is pressurised when the engine is hot. Hot coolant can spray out when you remove the radiator cap. Let the system cool before removing the radiator cap. To remove the cap; turn it to the first notch and let the system pressure escape, then remove the cap.

INT-3-2-9

**⚠ WARNING****Wheels**

Wheels are heavy. Handle and store with care to ensure that they cannot fall and cause injury.

13-3-1-7

**⚠ WARNING****Metal Splinters**

You can be injured by flying metal splinters when driving metal pins in or out. Use a soft faced hammer or drift to remove and fit metal pins. Always wear safety glasses.

INT-3-1-3

**⚠ WARNING**

Always wear safety glasses when dismantling assemblies containing components under pressure from springs. This will protect against eye injury from components accidentally flying out.

GEN 6-2

**⚠ WARNING****Communications**

Bad communications can cause accidents. If two or more people are working on the machine, make sure each is aware of what the others are doing. Before starting the engine make sure the others are clear of the danger areas; examples of danger areas are: the rotating blades and belt on the engine, the attachments and linkages, and anywhere beneath or behind the machine. People can be killed or injured if these precautions are not taken.

INT-3-1-5

**⚠ WARNING****Cleaning**

Cleaning metal parts with incorrect solvents can cause corrosion. Use only recommended cleaning agents and solvents.

INT-3-2-11

**⚠ WARNING****'O' rings, Seals and Gaskets**

Badly fitted, damaged or rotted 'O' rings, seals and gaskets can cause leakages and possible accidents. Renew whenever disturbed unless otherwise instructed. Do not use Trichloroethane or paint thinners near 'O' rings and seals.

INT-3-2-12

**⚠ WARNING****Clutch Fluid**

Do not use ordinary hydraulic fluid in the clutch system.

13-3-2-4

**⚠ WARNING****Welding and Modifications**

To prevent the possibility of damage to electronic components, disconnect the battery and withdraw the plug from the electronic draft control unit before arc-welding on the machine or attached implements.

Parts of the machine are made from cast iron; welds on cast iron can weaken the structure and break. Do not weld cast iron. On no account weld or drill the chassis structure. Non-approved modifications can cause injury and damage. Contact JCB before modifying the machine.

GEN 8-1

**Maintenance Safety (cont'd)****⚠ WARNING****Fluoroelastomeric Materials**

Certain seals and gaskets (e.g. crankshaft oil seal) on JCB machines contain fluoroelastomeric materials such as Viton, Fluorel and Technoflon. Fluoroelastomeric materials subjected to high temperatures can produce highly corrosive hydrofluoric acid. **THIS ACID CAN SEVERELY BURN.**

New fluoroelastomeric components at ambient temperature require no special safety precautions.

Used fluoroelastomeric components whose temperatures have not exceeded 300°C require no special safety precautions. If evidence of decomposition (e.g. charring) is found, refer to the next paragraph for safety instructions **DO NOT TOUCH COMPONENT OR SURROUNDING AREA.**

Used fluoroelastomeric components subjected to temperatures greater than 300°C (e.g. engine fire) must be treated using the following safety procedure. Make sure that heavy duty gloves and special safety glasses are worn:

- 1 Ensure that components have cooled then remove and place material in plastic bags.
- 2 Thoroughly wash contaminated area with 10% calcium hydroxide or other suitable alkali solution, if necessary use wire wool to remove burnt remains.
- 3 Thoroughly wash contaminated area with detergent and water.
- 4 Contain all removed material, gloves etc used in this operation in sealed plastic bags and dispose of in accordance with Local Authority Regulations.

**DO NOT BURN FLUOROELASTOMERIC MATERIALS.**

If contamination of skin or eyes occurs, wash the affected area with a continuous supply of clean water or with calcium hydroxide solution for 16-60 minutes. Get medical attention immediately.

INT - 3 - 3 - 5/1

**⚠ WARNING****Brake Pads**

Always renew brake pads and locating pins in complete axle sets, using genuine JCB parts, otherwise braking will be unsafe.

13-3-1-10

**⚠ WARNING****Cleaning Agents**

When using cleaning agents, solvents or other chemicals, you must adhere to the manufacturer's instructions and safety precautions.

GEN-1-9

<b>Contents</b>	<b>Page No.</b>
Lubricants & Capacities	1 - 1
Lubricants - Health and Safety	1 - 2
Service Schedules	2 - 1
Checking for Damage	2 - 4
Opening/Closing the Bonnet	2 - 4
Checking Seat Belt Condition and Security	2 - 4
Greasing	
Propshafts and PTO Driveshafts	3 - 1
Steering Swivels	3 - 2
Hydraulic Lift & 3 point Linkage	3 - 3
Rear PTO Driveshaft Bearings	3 - 3
Rear Suspension Cylinder Pivots	3 - 3
Clutch Operating Mechanism	3 - 4
Rear Anti-roll Bar Ball Joints	3 - 4
Automatic Trailer Coupling	3 - 5
Cab	
Checking the ROPS Structure	4 - 1
Checking the Windscreen washer Fluid Level	4 - 2
Air Conditioning	
Cleaning the Filter	5 - 1
Adjusting the Compressor Belt	5 - 1
Checking the Sight Glass	5 - 2
Electrics	
Checking the Battery Electrolyte Level	6 - 1
First Aid - Electrolyte	6 - 1
Checking the Beam Alignment	6 - 2
Fuses	See Section C
Hydraulics	
Checking the Fluid Level	7 - 1
Changing the Filter Element	7 - 1
Changing the Hydraulic Fluid	7 - 2
Cleaning the Suction Strainer	7 - 2
Clutch	
Checking the Fluid Level	8 - 1
PTO, Speed and Range Gearboxes	
Checking the Oil Level	9 - 1
Changing the Oil and Cleaning the Strainer	9 - 2
Changing the Transmission Oil Filter	9 - 3
Checking the Oil in the Front PTO Transfer Gearbox	9 - 4
Front Axle	
Checking the Differential Oil Level	10 - 1
Changing the Differential Oil	10 - 1
Checking the Hub Oil Levels	10 - 2
Changing the Hub Oil	10 - 2

<b>Contents</b>	<b>Page No.</b>
Rear Axle (2WS)	
Checking the Oil Level	11 - 1
Changing the Oil	11 - 2
Rear Axle (4WS)	
Checking the Differential Oil Level	11 - 3
Changing the Differential Oil	11 - 3
Checking the Hub Oil Levels	11 - 4
Changing the Hub Oil	11 - 4
Front and Rear Axle Steering Swivels (4WS)	
Checking 4WS Right Side Trunnion Seals	11 - 5
Tyres and Wheels	
General	12 - 1
Tyre Inflation	12 - 1
Pressures, Speeds and Loads	12 - 2
Checking Wheel Nut Torques	12 - 2
Adjusting the Track Width	12 - 2
Lock Stops	12 - 2
Checking and Adjusting Wheel Alignment	12 - 3
Brakes	
Checking and Renewing Foot Brake Pads	13 - 1
* Testing the Parking Brake (Machines to Serial No. 737000)	13 - 1A
Testing the Parking Brake (Machines from Serial No. 737001)	13 - 1B
* Checking and Renewing Parking Brake Pads	See Caliper Removal and Replacement - Section G
Checking the Foot Brake Fluid Level (Machines from Serial No. 737001)	13 - 2
Checking and Renewing the Parking Brake Pads (Machines from Serial No. 737001)	13 - 3
Air System	
Draining the Air System Tank	13 - 4
Antifreeze Pump	13 - 5
Engine	
Checking the Oil Level	14 - 1
Changing the Oil and Filter	14 - 2
Draining/Cleaning the Fuel Sediment Bowl	15 - 1
Draining the Fuel Filters	15 - 1
Changing the Fuel Filter Elements	15 - 2
Cleaning the Fuel Lift Pump	15 - 3
Bleeding the Fuel System	15 - 4
Checking the Coolant Level	16 - 1
Draining the Coolant	16 - 2
Filling the Cooling System	16 - 3
Coolant Mixtures	16 - 3
Cleaning the Radiator	16 - 4
Adjusting the Fan Belts	17 - 1
Cleaning the Pre-Cleaner	17 - 1
Changing the Air Filter Element	18 - 1

Sample of manual. Download All 562 pages at:

<https://www.arepairmanual.com/downloads/jcb-11151115s11251135-fastrac-service-repair-manual/>