


# VIBROMAX

---

## 1103 SINGLE DRUM ROLLER

*SERVICE MANUAL SM90001*

July 1998



Product: Vibromax 1103 Sigle Drum Roller?Service Repair Workshop Manual SM90001

Full Download: <https://www.arepairmanual.com/downloads/vibromax-1103-sigle-drum-roller-service-repair-workshop-manual-sm90001/>

**CALIFORNIA**

**Proposition 65 Warning**

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Sample of manual. Download All 222 pages at:

<https://www.arepairmanual.com/downloads/vibromax-1103-sigle-drum-roller-service-repair-workshop-manual-sm90001/>

# TABLE OF CONTENTS

---

## SECTION ONE

### GENERAL INFORMATION

MACHINE DESCRIPTION .....	1 - 3
SERIAL NUMBERS .....	1 - 5
IDENTIFYING MACHINE COMPONENTS .....	1 - 6
SAFETY, GENERAL .....	1 - 7
SPARK ARRESTER .....	1 - 7
SAFETY, PERSONAL.....	1 - 7
SAFETY, MACHINE OPERATION.....	1 - 8
SAFETY, MAINTENANCE .....	1 - 9
GENERAL INFORMATION .....	1 - 12
CLEANING .....	1 - 12
INSPECTION .....	1 - 12
BEARINGS .....	1 - 12
NEEDLE BEARINGS .....	1 - 12
GEARS .....	1 - 12
OIL SEALS, O-RINGS, & GASKETS .....	1 - 12
SHAFTS .....	1 - 12
SERVICE PARTS .....	1 - 12
LUBRICATION .....	1 - 12
STANDARD TORQUE DATA .....	1 - 13
MACHINE SPECIFICATIONS .....	1 - 15
FLUID SPECIFICATIONS .....	1 - 17
DIESEL FUEL SPECIFICATION.....	1 - 18
ENGINE OIL SPECIFICATION .....	1 - 19
TIRE BALLAST .....	1 - 20

## SECTION TWO

### ENGINE

CUMMINS ENGINE WARRANTY .....	2 - 3
ENGINE REMOVAL .....	2 - 4

## SECTION THREE

### ELECTRICAL

GENERAL INFORMATION .....	3 - 2
INSTRUMENT PANEL.....	3 - 4
UNDERSTANDING ELECTRICAL SCHEMATICS .....	3 - 7
UNDERSTANDING RELAYS .....	3 - 9
VIBROMAX RELAYS .....	3 - 11
STARTER/CHARGING CIRCUIT (before JKC8302000) .....	3 - 13
STARTER/CHARGING CIRCUIT (AFTER JKC8302000) .....	3 - 15
UNDERSTANDING BATTERIES .....	3 - 15
BATTERY DIAGNOSTICS .....	3 - 16

## TABLE OF CONTENTS

---

UNDERSTANDING ALTERNATORS .....	3 - 17
CHARGING SYSTEM DIAGNOSTICS .....	3 - 18
VOLTAGE CHECKS AT ALTERNATOR .....	3 - 19
SYSTEM LEAKAGE .....	3 - 19
CIRCUIT WIRING TEST .....	3 - 19
MEASURING ALTERNATOR OUTPUT .....	3 - 20
UNDERSTANDING STARTERS .....	3 - 20
STARTER SOLENOID .....	3 - 21
STARTER SYSTEM DIAGNOSTICS .....	3 - 21
SOLENOID CIRCUIT TEST .....	3 - 21
STARTER CIRCUIT WIRING TEST .....	3 - 22
STARTER MOTOR TEST .....	3 - 23
INSTRUMENTATION PANEL .....	3 - 25
EMERGENCY STOP SWITCH/ BRAKE SWITCH .....	3 - 27
VIBRATION CIRCUIT .....	3 - 29
VIBRATION AFTER JKC8300700 .....	3 - 31
LIGHTING CIRCUIT .....	3 - 33
WORK LIGHTS, ACCESSORY PLUG, HEATER AND WIPERS .....	3 - 35
CAB WIRING .....	3 - 46
WIRE HARNESS 7250/16315 .....	3 - 47
WIRE CHART 7250/16315 .....	3 - 52
WIRE HARNESS 7250/16110 .....	3 - 56
WIRE CHART 7250/16110 .....	3 - 59

## SECTION FOUR HYDRAULIC

PUMP SUCTION LINES .....	4 - 2
HYDRAULIC COOLING SYSTEM.....	4 - 4
HYDRAULIC DRAIN LINES .....	4 - 6
HYDRAULIC TEST SYSTEM .....	4 - 8
HYDRAULIC TEST STATION .....	4 - 9
CHARGE SYSTEM .....	4 - 11
PROPULSION SYSTEM .....	4 - 13
MULTIFUNCTION VALVES .....	4 - 17
PROPULSION SYSTEM DIAGNOSTICS.....	4 - 18
INTERNAL LEAKAGE .....	4 - 18
PUMP SERVO CONTROL .....	4 - 19
VIBRATION SYSTEM .....	4 - 21
VIBRATION FREQUENCY .....	4 - 23
VIBRATION AMPLITUDE .....	4 - 25
VIBRATORY SYSTEM DIAGNOSTICS .....	4 - 26
STEERING SYSTEM.....	4 - 27
PARKING BRAKE SYSTEM .....	4 - 30
TOWING YOUR MACHINE .....	4 - 31
PARKING BRAKE DIAGNOSTICS .....	4 - 31

## TABLE OF CONTENTS

---

DIFFERENTIAL LOCK SYSTEM .....	4 - 35
HYDRAULIC SCHEMATIC .....	4 - 38

### SECTION FIVE FINAL DRIVES

GENERAL INFORMATION .....	5 - 2
OPERATION .....	5 - 3
KESSLER AXLE.....	5 - 4
SPETH STANDARD AXLE .....	5 - 5
REAR AXLE REMOVAL .....	5 - 6
AXLE INSTALLATION .....	5 - 7
AXLE TUBE DISASSEMBLY .....	5 - 8
PLANETARY DISSASSEMBLY .....	5 - 10
DIFFERENTIAL LOCK REMOVAL .....	5 - 12
DIFFERENTIAL LOCK ASSEMBLY .....	5 - 13
AXLE TUBE AND PLANETARY ASSEMBLY .....	5 - 14
INTERMEDIATE GEARBOX DISASSEMBLY .....	5 - 18
INTERMEDIATE GEARBOX ASSEMBLY .....	5 - 20
DIFFERENTIAL DISASSEMBLY .....	5 - 22
DIFFERENTIAL ASSEMBLY .....	5 - 24
DRUM REMOVAL .....	5 - 29
DRUM INSTALLATION .....	5 - 29
DRUM DRIVE .....	5 - 30
DRUM DRIVE BEARING REMOVAL.....	5 - 34
DRUM DRIVE BEARING INSTALLATION .....	5 - 36
DRUM DRIVE MOTOR REPAIRS .....	5 - 36

### SECTION SIX PARKING BRAKE SYSTEM

DESCRIPTION .....	6 - 2
RELEASE AND TOWING .....	6 - 4
DRUM MOTOR BRAKE .....	6 - 5
DISASSEMBLY OF MOTOR BRAKE.....	6 - 6
ASSEMBLY OF MOTOR BRAKE .....	6 - 6
STANDARD AXLE BRAKE .....	6 - 8
BAND BRAKE ADJUSTMENT .....	6 - 9
BAND BRAKE CYLINDER.....	6 - 10
HEAVY DUTY AXLE BRAKE .....	6 - 11

## TABLE OF CONTENTS

---

### SECTION SEVEN

#### VIBRATION SYSTEM

VIBRATION SYSTEM .....	7 - 2
VIBRATION FREQUENCY .....	7 - 3
VIBRATION AMPLITUDE .....	7 - 5
VIBRATORY SYSTEM DIAGNOSTICS .....	7 - 6
LIFTING DEVICE .....	7 - 7
DRUM REMOVAL .....	7 - 8
DRUM INSTALLATION .....	7 - 8
EXCITER BEARING REMOVAL .....	7 - 9
EXCITER BEARING ASSEMBLY.....	7 - 14
SMOOTH DRUM SHAFT .....	7 - 15
PADFOOT DRUM SHAFT .....	7 - 16

### SECTION EIGHT

#### STEERING SYSTEM

SPECIAL TOOLS .....	8 - 2
ARTICULATION JOINTS .....	8 - 3
JOINT DISASSEMBLY .....	8 - 5
JOINT ASSEMBLY .....	8 - 9
STEERING CYLINDER .....	8 - 12

### SECTION NINE

#### CHASSIS

DRUM FRAME .....	9 - 2
REAR FRAME .....	9 - 3
SIDE FRAME .....	9 - 4
ENGINE COMPARTMENT PANELS.....	9 - 5
OPERATOR PLATFORM .....	9 - 6
ROLLOVER PROTECTION STRUCTURE .....	9 - 7

### SECTION TEN

#### ATTACHMENTS

LEVELING BLADE .....	10 - 2
BLADE CONTROL .....	10 - 3
BLADE HYDRAULIC LINES .....	10 - 4

# SECTION ONE

## GENERAL INFORMATION


### **CALIFORNIA**

#### **Proposition 65 Warning**

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.



## MACHINE DESCRIPTION



The 1103 Vibratory Roller is the replacement for the 1102. Like the 1102, the 1103 is available in smooth drum or pad foot drum configuration. The 1103 however, is also offered with a standard Speth axle or a heavy duty Speth axle for high gradeability applications.

The 1103 uses the Cummins 5.9 liter 6 cylinder turbocharged engine at 130 gross horsepower. Changes in the drive pump and

the addition of a heavy duty axle drive motor result in improved machine performance. The vibratory drum diameter remains the same and drum width is two inches narrower. The drum's centrifugal force has been increased 22%.

A Sauer Sundstrand Series 90 variable displacement, axial piston hydrostatic pump, used for machine propulsion, is mounted to the flywheel end of the engine. It provides oil to a Poclain MS25 drum drive motor and a Sauer Sundstrand 2 speed axle drive motor in a parallel path. The Poclain motor is mounted on the left side of the drum and is isolated from the drum by rubber buffers. The axle drive motor on the standard axle has a displacement of 80 cc while the motor on the heavy duty axle displaces 110cc.

The vibration system uses a Sauer Sundstrand Series 90 hydrostatic pump similar to the propulsion pump and mounted directly behind the propulsion pump. The vibratory pump supplies oil to a Sauer Sundstrand hydrostatic motor mounted at the right side of the drum. Like the 1102, the 1103 smooth drum operates at frequencies of 1680 or 2160 vibrations per minute,


while the pad foot version operates only at the lower frequency.

A steering pump, mounted to the rear of the vibration pump, provides the oil needed for steering. The steering pump is also a second charge pump in the propulsion/vibration circuit. The steering pump draws oil from the reservoir, passes it through the steering control valve, through the inline hydraulic filter, and into the charge circuit. The charge pump draws oil from reservoir, joins the steering oil at the filter, passes it through the filter and into the charge circuit.

The 1103 has brakes at both the front drum and the rear axle. A spring applied-hydraulically released multi disc brake is part of the drum drive motor. The standard axle machine uses a spring applied-hydraulically released band brake at the intermediate gearbox while the heavy duty axle incorporates multiple disc brakes at the intermediate gearbox.


Pressure testing of the 1103 has been made easier by placing all the test ports at a centrally located test station under the operators platform on the right side of the machine.

The electrical system of the 1103 consists of a 12 volt battery, starter, alternator system, optional lighting and standard instrumentation.



**SERIAL NUMBERS**

1	Model / Serial Number	
2	Front Drum Drive Motor S/N	
3	Steering Unit S/N	
4	Axle S/N	
5	Vibratory Motor S/N	
6	Hydraulic Pumps S/N	
7	Axle Drive Motor S/N	
8	Engine S/N	



**IDENTIFYING MACHINE COMPONENTS**

1	Articulation joint	13	Lifting and towing eyes
2	Smooth drum	14	Fuel tank
3	Lifting eye	15	Air filter system
4	Operator's stand	16	Hydraulic oil cooler
5	Battery	17	Roll over protective structure
6	Hydraulic tank	18	Vibration motor
7	Engine	19	Steering cylinder
8	Planetary gear	20	Hydraulic pumps
9	Differential	21	Parking brake cylinder
10	Drum drive motor	22	Intermediate gear box
11	Isolation buffer	23	Axle drive motor
12	Scraper	24	Radiator

## SAFETY, GENERAL

The information in this manual does not replace any safety rules and laws used in your area. Before you operate this machine, learn the rules and laws for your area and make sure your machine has the correct equipment according to these rules and regulations.

*Your safety and the safety of other persons in the work area are dependent on your correct operation of this machine.*

- Know the location and function of all machine controls.
- Clear the area of other persons before you start the engine.
- Check all controls in a safe area before you operate the machine.
- Understand the limits of the machine.
- Do not try to do too much too fast.
- Keep the machine under control at all times.

## SPARK ARRESTER

**NOTE:** *Rules or laws in some areas can make it necessary for this machine to be equipped with a spark arrester or spark arrester muffler. Check the rules or laws in your area.*

## SAFETY, PERSONAL

**⚠ WARNING** *Loose clothing and jewelry can cause an accident. Do not wear loose clothing or jewelry that can catch on controls, etc. Do wear safety shoes, hard hat, heavy gloves, etc. when required for your protection.*

**⚠ WARNING** *A fire can cause injury or death. Always have a fire extinguisher on the job site near the machine. Make sure the fire extinguisher is serviced according to the manufacturer's instructions.*

**⚠ WARNING** *Foreign materials and loose objects on the steps, hand rails, and in the operator's compartment can cause accidents and injury. Keep the steps, hand rails, and operator's compartment clear at all times.*

**⚠ WARNING** *Always use the seat belt when operating the machine. Make sure the buckle for the seat is fastened correctly.*

**⚠ WARNING** *Make sure cab windows are clean and unobstructed.*

**⚠ WARNING** *Know and understand the arrangements for movement of trucks, machines, and persons on your job site. Understand and follow the instructions of flagmen, road signs, or signals.*

**⚠ WARNING** *Always wear the proper ear protection when operating this machine. Permanent hearing loss can result from extended exposure to loud noises.*

**⚠ WARNING** *Check machine controls for proper operation prior to starting the machine.*

**⚠ WARNING** Holes, obstructions, debris, and other work area hazards can cause injury or death. Always walk around and look for these and other hazards before you operate your machine in a new work area.

**⚠ WARNING** Electrical cables, gas pipes, water pipes, sewers, or other underground objects can cause injury or death. Know the location of underground hazards before you operate your machine in a new work area.

**⚠ WARNING** Not doing, or wrong machine inspection and maintenance can cause accidents. Always follow the instructions in this manual for machine inspection and maintenance.

## SAFETY, MACHINE OPERATION

**⚠ WARNING** Dust, smoke, fog, etc. can decrease your vision and cause an accident. Always stop or slow the machine until you can see your work area and the surrounding traffic

**⚠ WARNING** Operate the controls from the operator's seat only, and keep your hands on the controls during operation.

**⚠ WARNING** Do not permit other persons to ride on the machine.

**⚠ WARNING** Look at the instruments and gauges frequently when you operate. Make sure all systems are in the proper operating range.

**⚠ WARNING** This machine uses an articulating joint. Keep all persons clear of this pinch area when the engine is running. Machine movement can cause personal injury.

**⚠ WARNING** A machine out of control can cause injury or death. You must make a judgement if weather and earth conditions will permit safe operation on a hill, ramp, or rough ground. Adjust machine operation accordingly.

**⚠ WARNING** Operating your machine in, on, or near a trench, high bank, or overhang is extra dangerous and can cause injury or death. You must make a judgement if your machine can be safely operated near any of these areas. Use wall supports if necessary.

**⚠ WARNING** Sparks from the electrical system or engine exhaust can cause a fire or explosion. Before you operate this machine in an area with flammable dust or vapors, use good ventilation to remove the flammable dust or vapors.

**⚠ WARNING** Engine exhaust fumes can cause injury or death. If you operate this machine in an enclosed area, use good ventilation to replace the exhaust fumes with fresh air.

**⚠ WARNING** *The vibrations from this machine can cause the walls of a trench or high bank to collapse. If you must operate this machine close to a trench or high bank, make sure the walls of the trench or bank are braced. If you do not follow these instructions, you can cause personal injury or death to persons working in these areas.*

**⚠ WARNING** *Operating this machine too close to High Voltage electrical lines can cause injury or death. Follow the guide lines listed below.*

**NOTE:** *IF THE CLEARANCES IN THE SPECIFICATIONS BELOW ARE LESS THAN THE CLEARANCES GIVEN IN THE RULES AND LAWS OF YOUR AREA, YOU MUST FOLLOW THE RULES AND LAWS OF YOUR AREA!*

### Electrical Safety Rules

Cable Voltage	Minimum Clearance From Cable When Machine is Working	Minimum Clearance From Cable When Transporting Machine
50,000 volts or less	10 feet (3 meters)	4 feet (1.2 meters)
50,000 volts to 345,000 volts	10 feet (3m) plus 1/2 inch (13mm) for every 1000 volts over 50,000 volts	10 feet (3 meters)
345,000 volts to 750,000 volts	10 feet (3m) plus 1/2 inch (13mm) for every 1000 volts over 50,000 volts	16 feet (5 meters)

## SAFETY, MAINTENANCE

**⚠ WARNING** *Engine fuel is flammable and can cause a fire or an explosion. Do not fill the fuel tank or service the fuel system while the machine is running, or near an open flame, welding, burning cigars and cigarettes, etc.*

**⚠ WARNING** *Flammable cleaning solvents can cause injury or death. Use nonflammable cleaning solvents for cleaning purposes.*

**⚠ WARNING** *Machine movement without an operator can cause injury or death. If you must service this machine with the engine running, have another person help you and follow the instructions in the machine manuals. Lock the articulation joint and do not leave the machine when the engine is running.*

**⚠ WARNING** *Improper service or repair can cause injury or death. If you do not understand the service procedures for this machine, see your Vibromax dealer.*

**⚠ WARNING** *Missing shields, guards, or access panels can cause injury or death. Always install all shields, guards, or access panels before you start the engine.*

**⚠ WARNING** *Do not make any modifications or repairs to the machine ROPS. If your ROPS is damaged, replace with new parts. Welding, drilling, etc. can weaken the ROPS structure.*

**⚠ WARNING** *Unauthorized modifications to this machine can cause injury or death. Never make modifications to this machine without prior written approval from Vibromax.*

**⚠ WARNING** *Metal chips or debris can cause eye injury. Wear eye protection when you service this machine. If you use a hammer to drive hardened pins or for other service, use a hammer with a soft face (brass, plastic, etc.).*

**⚠ WARNING** *Unauthorized modifications to cast iron parts can cause injury or death. Welding can cause cast iron parts to break. Do not use welding to repair or attach items to cast iron parts on this machine.*

**⚠ WARNING** *Batteries produce explosive gases. Keep sparks and flame away. Ventilate when charging. Always wear eye protection when working near batteries. Do not wear jewelry or watch bands when working on batteries.*

**⚠ WARNING** *When you install a battery or use a booster battery, connect the negative ground cable last. When you remove a battery or booster battery, disconnect the negative ground cable first.*

**⚠ WARNING** *Never charge or jump a battery when the electrolyte is frozen. If you do not follow this instruction the battery can explode.*

**⚠ WARNING** *Never wear rings or other jewelry when working on machine maintenance. Severe burns can result when jewelry is shorted on an electrical system.*

**⚠ WARNING** *Never wear loose clothing which can catch on objects or be tangled in moving parts.*

**⚠ WARNING** *Use suitable floor (service) jacks and safety stands when lifting the machine off the ground.*

**⚠ WARNING** *Hydraulic oil under pressure can penetrate the skin. If hydraulic oil has penetrated the skin, seek medical treatment immediately. Do not use your hands to check for hydraulic leaks, use a piece of cardboard or wood.*

**⚠ WARNING** *Keep your work area clean and free of spilled oil and grease to avoid accidentally slipping.*

**GENERAL INFORMATION****CLEANING**

Clean all metal parts, except bearings, in mineral spirits or by steam cleaning. Do not use caustic soda for steam cleaning. After cleaning, dry and put oil on all parts. Clean oil passages with compressed air. Clean bearings in kerosene, dry the bearings completely and put oil on the bearings.

**INSPECTION**

Check all parts when the parts are disassembled. Replace all parts that have wear or damage. Small scoring or grooves can be removed with a hone or crocus cloth. Complete visual inspection for indications of wear and pitting. Replacement of bad parts will prevent early failure.

**BEARINGS**

Check bearings for easy movement. If bearings have a loose fit or rough action replace the bearing. Wash bearings in kerosene and allow to air dry. **DO NOT USE COMPRESSED AIR TO DRY BEARINGS.**

**NEEDLE BEARINGS**

Before pressing needle bearings into a bore always remove any metal protrusions in the bore or edge of the bore. Before pressing bearing lubricate the inner and outer diameters as needed.

**GEARS**

Check all gears for wear and damage. Replace gears that have wear or damage.

**OIL SEALS, O-RINGS, & GASKETS**

Always install new oil seals, o-rings and gaskets. Put petroleum jelly or the specified oil on seals and o-rings.

**SHAFTS**

Check all shafts that have wear damage. Check the surfaces where bearings and oil seals operate for signs of wear.

**SERVICE PARTS**

Always install genuine Vibromax service parts. When ordering refer to the parts manual for the correct part numbers. Failure to use genuine Vibromax replacement parts can void your warranty.

**LUBRICATION**

Use the oils and lubricants specified in the Operator's or Service Manual. Failures due to the use of non specified lubricants are not covered by warranty.

**STANDARD TORQUE DATA**

Where no special torque data is specified, the following torque figures should be applied.  
Threads should be lubricated with engine oil or grease.

**STANDARD TORQUE SPECIFICATIONS +/- 10%**

SIZE	GRADE 8.8		GRADE 10.9		GRADE 12.9	
	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm
5mm	4	5.5	5.5	7.5	6.6	9
6mm	6.6	9	9.2	12.5	11	15
8mm	16.5	22.5	23	31.5	26.5	36
10mm	32	44	45	62	55	75
12mm	57	77.5	81	110	95	130
14mm	88	120	125	170	155	210
16mm	140	190	195	265	236	320
18mm	192	260	269	365	320	435
20mm	273	370	383	520	457	620
22mm	369	500	516	700	619	840
24mm	471	640	665	900	796	1080
27mm	702	950	996	1350	1195	1620
30mm	955	1300	1328	1800	1593	2160

**NUTS FOR TUBES AND HOSES**

DIAMETER & PITCH	NEWTONS/METER	POUNDS/FOOT
16MM X 1.5	20	14.5
18MM X 1.5	35	26
20MMX1.45	45	33.2
24MM X 1.5	60	44


**FITTINGS, CONNECTIONS AND PLUGS**

DIAMETER & PITCH	NEWTONS/METER	POUNDS/FOOT
10MM X 1	20	14.5
12MM X 1.5	35	26
14MM X 1.5	45	33.2
16MM X 1.5	60	44
18MM X 1.5	70	51
22MM X 1.5	100	73
27MM X 2	200	147
33MM X 2	280	207
42MM X 2	380	281

**FLANGES**

DIAMETER & PITCH	NEWTONS/METER	POUNDS/FOOT
8MM X 1.5	28	21
10MM X 1.5	55	41
12MM X 1.75	90	67
14MM X 2	145	107
16MM X 2	230	170

MACHINE SPECIFICATIONS



## ENGINE DATA

Make / Model / Type	Cummins 6BT5.9C, 6 cylinder, turbo diesel
Cooling	Water
Displacement - cu.in. (cc)	359 (5880)
HP, SAE net (kW) @ 2500 rpm	122 (91)
Air Cleaner	Dual replacement elements
Fuel filter	Spin-on Cartridge
Fuel consumption gal/hr (l/hr)	5.3 (19.5)
Fuel Capacity - gal (liter)	74 (280)
Electrical system	12 volt

## DRIVE SYSTEM DATA

	1103D/1103HD	1103PD/1103HPD
Propulsion - front and rear	Infinitely variable hydrostatic	Infinitely variable hydrostatic
Travel speed 1st. - mph (km/hr)	0 - 3.1 (0-5)	0 - 3.3 (0-5.5)
Travel speed 2nd. - mph (km/hr)	0 - 6 (0-9)	0 - 6.6 (0-11)
Theoretical gradeability, forward -%	45/65	45/65
Brakes, front drum	hydraulic disc	hydraulic disc
Brakes, rear 1103	hydraulic drum, intermediate shaft	hydraulic drum, intermediate shaft
Brakes, rear 1103H	hydraulic disc, intermediate shaft	hydraulic disc, intermediate shaft
Steering	Articulated, hydraulic powered	Articulated, hydraulic powered
Tire size	23.1x26 8PR diamond tread	23.1x26 8PR tractor tread

## OPERATING DATA

	1103D/1103HD		1103PD/1103HPD
Operating Weight - lbs (kg)	24475 (11100)/25740 (11700)		25300 (11500) / 26620 (12100)
Weight, front - lbs (kg)	12789 (5813)		13668 (6212)
Static linear drum load - lb/in (kg/cm)	155 (27.6)		-----
Drum wt, unsprung - lbs (kg)	7055 (3206)		7934 (3606)
Articulation/oscillation - degrees	37/15		37/15
Turning radius, inside - ft (m)	12 (3.7)		12 (3.7)
Drum shell thickness - in. (mm)	1.0 (25)		1.0 (25)
Number of pad feet/height of foot - in (mm)	-----		144/4.0 (100)
Contact area of foot - sq. in (sq. cm)	-----		14.8 (95)
	1st stage	2nd stage	1st stage
Max compaction depth - in (cm)	39 (100)	23.6 (60)	39 (100)
Frequency - vpm (Hz)	1680 (28)	2160 (36)	1680 (28)
Nominal Amplitude - in. (mm)	.063 (1.6)	.023 (0.6)	.063 (1.6)
Centrifugal force - lbf (kN)	47211 (210)	24053 (107)	47211 (210)
Centrifugal force/drum width - lb/in (N/cm)	570 (1000)	291 (510)	570 (1000)
Total applied force - lb/in (N/cm)	60000 (267)	36842 (164)	60879 (271)
Total applied linear force	725 (1271)	445 (781)	736 (1290)

## FLUID SPECIFICATIONS

MACHINE PART	CAPACITY USA (metric)	SPECIFICATIONS
Fuel tank	74 gal (280 l)	see diesel fuel
Engine crankcase	15 qts(14.2 l)	engine oil API classification API-CD MIL-L-2104C multigrade engine oil (see oil chart) single grade engine oil (see oil chart)
Hydraulic system  Reservoir only	29.1 gal (110 l)  18.5 gal (70 l)	cold weather HLP 46 DIN 51524/2 hot weather HLP 68 DIN 51524/2 Mobil DTE 25,26 Shell Tellus OL 46,68 Amoco Rykon HD 46,68 Texaco Rando HD 46,68
Vibration system	12.7 qts. (12 l)	CLP DIN 51517/3 Mobil Gear 629 Shell Omala 150 Texaco Meropa 150
Battery	as required	Distilled water
Grease	as required	KP3K DIN 51502 Mobil Oil - Mobilux 3 Shell Oil - Alvania 3 Texaco Oil - Starplex 3
Engine coolant	20 qts (19 l)	50% ethylene glycol and 50% water
Tire ballast	see chart	Calcium Chloride (77%CaCl <sup>2</sup> )
Intermediate gear standard duty heavy duty  Axle gear standard duty heavy duty  Planetary gear standard duty heavy duty	1.1 qts (1 ltr) 1.6 qts (1.5 ltr)  5.3 qts (5 ltr) 14.8 qts (14 ltr)  2.2 qts (2 ltr) 1.9 qts (1.8 ltr)	SAE 90 API GL-5 gear lubricant

**DIESEL FUEL SPECIFICATION**

If fuel is stored for a long time, foreign particles or water can collect in the fuel storage tank. Many engine problems are caused by contaminated fuel. Store fuel outside and keep the fuel as cool as possible. Drain water from the fuel storage tank at regular intervals.

**NOTE:** Paraffin crystals will start to form in fuel when the fuel temperature falls below the fuel's cloud point. These paraffin crystals will clog the fuel filter and cause the engine to stop or lose power. At ambient temperatures above 32°F (0°C) use #2 diesel fuel. At temperature below 32°F (0°C) use #1 diesel fuel.

Different brands of fuel can exhibit different properties. Make sure that the number 2 diesel fuel you use meets the following minimum requirements.

**MINIMUM REQUIREMENTS FOR NO.2 DIESEL FUEL:**

Maximum cloud point	-10°F (-23°C)
Maximum pour point	42°F (6°C) below the lowest ambient air temperature at which the engine must start
Cetane number, min	40 (45 to 55 in winter or at high altitude)
Max. sulphur content, by weight	0.50%
Max. water content & sediment by volume	0.05%
Max. ash content, by weight	0.01%
Max. carbon residue (10% point)	0.20%
Distillation temperature @ 90% point	540 to 625°F (282-329°C)
Distillation temperature @ end point	675°F (357°C)
Minimum flash point	125°F (52°C)
Viscosity at 100°F (38°C)	
Centistokes	2.0 to 4.3
Saybolt Universal Seconds (SUS)	32 to 40
Copper strip test, 3 hours @ 212°F (100°C)	No 3 ASTM
Minimum API gravity	30


**ENGINE OIL SPECIFICATION**

Use multigrade or single grade engine oil with API engine oil service classification "CD".

**NOTE:** DO NOT use performance additives or other oil additives in your engine crankcase.

See the chart below for recommended oil viscosity at the various ambient air temperature range

**Engine Oil Viscosity Chart**  
**Ambient Air Temperature Ranges**



**TIRE BALLAST**

Refer to the weight chart below for the maximum weight of tire ballast that you can add to the machine. The Calcium chloride will prevent freezing of the ballast to -30° F (-34° C). Tire pressure is set at 13 to 20 PSI (0.9 to 1.40 bar). See your Vibromax dealer for more information.

**NOTE:** *The following information is for one tire only and for a tire size of 23.1-26 AW 8PR.*

Water		Calcium Chloride		Total Mixture Weight	
Liters	US Gal.	kg	Lbs	kg	Lbs
484.5	128			481.7	1062
412.6	109	173.3	382	585.2	1291
389.9	103	233.6	515	623.3	1374

# SECTION TWO

## ENGINE

### **CALIFORNIA**

#### **Proposition 65 Warning**

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.



## CUMMINS ENGINE WARRANTY

All Cummins Engines manufactured by Cummins Diesel and installed in Vibromax products are covered by Cummins warranty and are to be serviced by an Authorized Cummins Servicing Dealer and/or Distributor. The engines used in Vibromax equipment have a two (2) year warranty period.

Warranty on Cummins engines begins when any of the following conditions are met:

- \* a claim is submitted to Cummins
- \* engine has accumulated 50 running hours
- \* unit is rented, leased, or retailed
- \* Cummins representatives perform a start-up service

Cummins engine warranty is transferable throughout its term. Terms are not adjustable nor reversible.

Start up Service is not required at the start of warranty on the engine. Warranty service is provided by your local Cummins Service Outlet. If you require assistance with locating a Service Outlet, call the Cummins Customer Relations Department, 1-800-343-7357.


### ENGINE DATA

Make / Model / Type	Cummins 6BT5.9C, 6 cylinder, turbo diesel
Cooling	Water
Displacement - cu.in. (cc)	359 (5880)
HP, SAE net (kW) @ 2500 rpm	122 (91)
Air Cleaner	Dual replacement elements
Fuel filter	Spin-on Cartridge
Fuel consumption gal/hr (l/hr)	5.3 (19.5)
Fuel Capacity - gal (liter)	74 (280)
Electrical system	12 volt

It is not the intent or purpose of this manual to supersede the manufacturers technical instruction for repair or overhaul of this engine. After the expiration of warranty, those wishing to do their own engine service work should obtain the Cummins Shop Manual for the "B" series engine from their local Cummins distributor.

## ENGINE REMOVAL

1. Disconnect the negative battery cable. The battery is located on the operator platform to the right side of the seat.
2. Remove the engine compartment hood and side panels.



3. Drain the engine cooling system. A drain valve is provided and is located to the rear side of the radiator overflow tank on the left side of the machine.
4. Drain the engine oil using the fitting provided in the left rear frame behind the tire. After the oil has been drained disconnect the drain hose from the engine oil pan.