

# Service Manual

## JS130

from machine no. 758000

## JS160

from machine no. 702000

PUBLISHED BY THE  
TECHNICAL PUBLICATIONS DEPARTMENT  
OF JCB SERVICE: ©  
WORLD PARTS CENTRE  
UTTOXETER, STAFFORDSHIRE, ST14 7BS,  
ENGLAND  
Tel. ROCESTER (01889) 590312  
PRINTED IN ENGLAND

Publication No. 9803/6410

Issue 1

<b>General Information</b>	<b>1</b>
<b>Care &amp; Safety</b>	<b>2</b>
<b>Routine Maintenance</b>	<b>3</b>
<b>Attachments</b>	<b>A</b>
<b>Body &amp; Framework</b>	<b>B</b>
<b>Electrics</b>	<b>C</b>
<b>Hydraulics</b>	<b>E</b>
<b>Transmission</b>	<b>F</b>
<b>Brakes</b>	<b>G</b>
<b>Track &amp; Running Gear</b>	<b>J</b>
<b>Engine</b>	<b>K</b>

## Introduction

This publication is designed for the benefit of JCB Distributor Service Engineers who are receiving, or have received, training by JCB Technical Training Department.

These personnel should have a sound knowledge of workshop practice, safety procedures, and general techniques associated with the maintenance and repair of hydraulic earthmoving equipment.

Renewal of oil seals, gaskets, etc., and any component showing obvious signs of wear or damage is expected as a matter of course. It is expected that components will be cleaned and lubricated where appropriate, and that any opened hose or pipe connections will be blanked to prevent excessive loss of hydraulic fluid and ingress of dirt. Finally, please remember above all else **SAFETY MUST COME FIRST!**

The manual is compiled in sections, the first three are numbered and contain information as follows:

- 1 = General Information** - includes torque settings and service tools.
- 2 = Care & Safety** - includes warnings and cautions pertinent to aspects of workshop procedures etc.
- 3 = Routine Maintenance** - includes service schedules and recommended lubricants for the whole machine.

The remaining sections are alphabetically coded and deal with Dismantling, Overhaul etc. of specific components, for example:

- A = Attachments**
- B = Body & Framework** ...etc

The page numbering in each alphabetically coded section is not continuous. This allows for the insertion of new items in later issues of the manual.

Section contents, technical data, circuit descriptions, operation descriptions etc. are inserted at the beginning of each alphabetically coded section.

All sections are listed on the front cover; tabbed divider cards align directly with individual sections on the front cover for rapid reference.

Where a torque setting is given as a single figure it may be varied by plus or minus 3%. Torque figures indicated are for dry threads, hence for lubricated threads may be reduced by one third.

'Left Hand' and 'Right Hand' are as viewed from the rear of the machine facing forwards.

**Note:** In this manual the term 'swing' may sometimes be used in place of 'slew' and the term 'arm' may sometimes be used in place of 'dipper'.

<b>Contents</b>	<b>Page No.</b>
Bolt and Nut Torque Specifications	1 - 1
Torque Settings	1 - 2
Service Tools	
* Section B - Body and framework	3 - 1
Section C - Electrics	4 - 1
Section E - Hydraulics	5 - 1
* Section F - Transmission	6 - 1
*Sealing and Retaining Compounds	7 - 1

## JS130/JS160 and Variants

Tighten the bolts and nuts according to the table. Before and after daily work, check the bolts and nuts for looseness and for those missing. Tighten if loose and renew if missing.

Tighten the bolts and nuts after the first 50 hours of the running-in stage and every 250 hours thereafter.

### Tightening Torque Table

No	Tightening Point	Bolt Diameter	Wrench mm	JS130/JS160		
				Tightening Torque		
				Nm	kgf m	lbf ft
1†	Travel Motor	M16	24	270~310	27.6~31.8	200~230
2†	Drive Sprocket	M16	24	220~310	27.6~31.8	200~230
3†	Idler Wheel	M16	24	270~310	27.6~31.8	200~230
4†	Upper (Carrier) Roller	M16/M20	24/30	270~310/520~608	27.6~31.8/53.2~62.2	200~230/385~450
5†	Lower (Track) Roller	M16	24	270~310	27.6~31.8	200~230
6†	Track Guard	M16	24	270~310	27.6~31.8	200~230
* 7	Shoe Bolt	M16	24	310~360/640~750	32~37/65~76.5	229~266/472~553
8	Counter weight	M27	41	845~980	86~100	622~723
9†	Turntable Bearing (Undercarriage)	M16/M20	24	280~310/475~550	28.4~31.8/48.4~55.3	205~230/350~400
10†	Turntable Bearing (Slew Frame)	M16/M20	24	280~310/475~550	28.4~31.8/48.4~55.3	205~230/350~400
11†	Slew Equipment	M16/M20	24	280~310/475~550	28.4~31.8/48.4~55.3	205~230/350~440
12†	Engine (Engine Mount)	M16	24	265~310	27~32	195~230
13†	Engine Bracket	M10	17	65~75	6.5~7.6	47~55
14	Radiator	M12	19	60~70	6.2~7.2	45~52
15†	Hydraulic Pump	M10	17	65~75	6.5~7.6	47~55
16†	Hydraulic Oil Tank	M16	24	205~285	21~29	152~210
17†	Fuel Tank	M16	24	225~285	22.4~29	162~210
18†	Control Valve	M16	24	270~310	27.6~31.8	200~230
19†	Rotary Coupling	M12	19	110~125	11.1~13.0	80~94
20	Cab	M16	24	127~137	13~14	94~101
21	Battery	M10	17	20~30	2.1~2.9	15~21

\* **Note:** Use JCB Threadlocker and Sealer (High Strength) (adhesive) on those marked † and tighten to the torque listed in the above table.

The tightening torques for the bolts and nuts not listed above are as follows:

Bolt Diameter (size)			M6	M8	M10	M12	M14	M16	M18	M20
Hex. bolt	Wrench	mm	10	13	17	19	22	24	27	30
	Tightening Torque	Nm	6.9	15.7	32.3	58.8	98.0	137.2	196.0	274.4
		kgf m	0.7	1.6	3.2	5.9	9.8	13.7	19.6	27.4
		lbf ft	5	12	24	43	72	101	145	202
Hex. socket head bolt	Wrench	mm	5	6	8	10	12	14	14	17
	Tightening Torque	Nm	8.8	21.6	42.1	78.4	117.6	176.4	245.0	343.0
		kgf m	0.88	2.2	4.2	7.8	11.8	17.6	24.5	34.3
		lbf ft	6.5	16	31	58	87	130	181	253

## Torque Settings


**Note 1:** The figures quoted are for non-plated fasteners and are to be used only when there is no torque setting specified in the relevant procedure in this service manual.

**Note 2:** The 4T grade settings DO NOT APPLY to fasteners used on the engine. If any 4T specification fasteners are found on the engine, these must be tightened to the figure quoted in the relevant engine manual.

Bolt Size	Strength Grade of Bolt or Stud								
	4T			8.8			10.9		
	Nm	kgf m	lbf ft	Nm	kgf m	lbf ft	Nm	kgf m	lbf ft
<b>M3</b>	0.39	0.04	0.28	-	-	-	-	-	-
<b>M4</b>	0.78	0.08	0.57	-	-	-	-	-	-
<b>M5</b>	1.67	0.17	1.2	-	-	-	-	-	-
<b>M6</b>	2.84	0.29	2.1	8.04	0.82	5.9	11.3	1.15	8.3
<b>M8</b>	7.06	0.72	5.2	19.6	2.00	14.5	27.7	2.82	20.4
<b>M10</b>	14.0	1.43	10.3	39.1	3.99	28.8	55.0	5.61	40.6
<b>M12</b>	24.6	2.51	18.1	68.5	6.98	50.5	96.2	9.81	71
<b>M16</b>	61.9	6.31	45.7	173	17.6	127.6	242	24.7	178.5
<b>M20</b>	122	12.4	90	337	34.4	249	475	48.4	350
<b>M22</b>	167	17.0	123	464	47.3	342	652	66.5	481
<b>M24</b>	210	21.4	155	584	59.5	431	821	83.7	606
<b>M27</b>	311	31.7	229	864	88.1	637	1220	124	900
<b>M30</b>	420	42.8	310	1170	119	863	1650	168	1217
<b>M33</b>	576	58.7	425	1600	163	1180	2260	230	1667
<b>M36</b>	736	75.1	543	2050	209	1512	2880	294	2124
<b>M39</b>	961	98.0	709	2680	273	1977	3760	383	2773
<b>M42</b>	1190	121	878	3300	336	2434	4640	473	3422
<b>M45</b>	1490	152	1099	4140	422	3054	5820	593	4293
<b>M48</b>	1780	182	1312	4960	506	3659	6970	711	5141

## Service Tools


### (SECTION B) BODY AND FRAMEWORK



S186240

**Hand Cleaner** - special blend for the removal of polyurethane adhesives.


4104/1310 (454g; 1lb tub)



S186270

**Cartridge Gun** - hand operated - essential for the application of sealants, polyurethane materials etc.


892/00845



S186250

**12V Mobile Oven** - 1 cartridge capacity - required to pre-heat adhesive prior to use. It is fitted with a male plug (703/23201) which fits into a female socket (715/04300).


992/12300



S186280

**Folding Stand for Holding Glass** - essential for preparing new glass prior to installation.

892/00843




S186260

**240V Static Oven** - available with 2 or 6 cartridge capacity - required to pre-heat adhesive prior to use. No plug supplied. Note: 110V models available upon request - contact JCB Technical Service

992/12400 - 2 cartridge x 240V

992/12600 - 6 cartridge x 240V




S186300

**Glass Lifter** - minimum 2 off - essential for glass installation, 2 required to handle large panes of glass. Ensure suction cups are protected from damage during storage.

892/00842

**Service Tools (cont'd)**


**(SECTION B) BODY AND FRAMEWORK**



S186310

**Wire Starter** - used to access braided cutting wire (below) through original polyurethane seal.


892/00848



S186340

**Cut-out Knife** - used to remove broken glass.


992/12800



S186320

**Glass Extractor (Handles)** - used with braided cutting wire (below) to cut out broken glass.


892/00846



S186350

**'L' Blades** - 25mm (1in.) cut - replacement blades for cut-out knife (above).


992/12801 (unit quantity = 5 off)



S186330

**Braided Cutting Wire** - consumable heavy duty cut-out wire used with the glass extraction tool (above).


892/00849 (approx 25m length)



S186360

**Long Knife** - used to give extended reach for normally inaccessible areas.


892/00844

**Service Tools (cont'd)****(SECTION B) BODY AND FRAMEWORK**

S186470

**Nylon Spatula** - general tool used for smoothing sealants - also used to re-install glass in rubber glazing because metal tools will chip the glass edge.

892/00847




S186550

**Rubber Spacer Blocks** - used to provide the correct set clearance between glass edge and cab frame.

926/15500  
(unit quantity = 500 off)


**Service Tools**

**SECTION C - ELECTRICS**



**Electrical Test Equipment**

1	892/00283	Tool Kit Case
2	892/00281	AVO Meter
3	892/00286	Surface Temperature Probe
4	892/00284	Microtach Digital Tachometer
5	892/00282	Shunt - open type
6	892/00285	Hydraulic Oil Temperature Probe
7	892/00298	Fluke 85 Multimeter






993/85700      Battery Tester

**Service Tools (continued)**

**SECTION E - HYDRAULICS**


**Hydraulic Pressure Test Gauges and Connections**

- 1 892/00279 Pressure Gauge 0-400 bar (0-6000 lbf/in<sup>2</sup>)
- 2 892/00346 Pressure Gauge 0-70 bar (0-1000 lbf/in<sup>2</sup>)
- 3 892/00347 Connector
- 4 892/00254 Hose
- 5 892/00280 Pressure Gauge 0-600 bar (0-9000 lbf/in<sup>2</sup>)




**Pressure Test 'T' Adapters**

- 892/00262 1/4 in BSP x 1/4 in F BSP x Test Point
- 816/55038 3/8 in BSP x 3/8 in F BSP x Test Point
- 816/55040 1/2 in BSP x 1/2 in F BSP x Test Point
- 892/00263 5/8 in BSP x 5/8 in F BSP x Test Point
- 892/00264 3/4 in BSP x 3/4 in F BSP x Test Point
- 892/00265 1 in M BSP x 1 in F BSP x Test Point
- 892/00266 1,1/4 in M BSP x 1,1/4 in F BSP x Test Point
- 892/00267 1,1/2 in M BSP x 1,1/2 in F BSP x Test Point




**Pressure Test Adapters**


- 892/00255 1/4 in BSP x Test Point
- 892/00256 3/8 in BSP x Test Point
- 892/00257 1/2 in BSP x Test Point
- 892/00258 5/8 in BSP x Test Point
- 816/15118 3/4 in BSP x Test Point
- 892/00259 1 in BSP x Test Point
- 892/00260 1,1/4 in BSP x Test Point
- 892/00261 5/8 in UNF x Test Point

**Service Tools (continued)****SECTION E - HYDRAULICS****Hand Pump Equipment**


892/00223	Hand Pump
892/00137	Micro-bore Hose 1/4 in BSP x 5 metres
892/00274	Adapter 1/4 in M BSP x 3/8 in M BSP Taper
892/00262	1/4 in M BSP x 1/4 in F BSP x Test Point
892/00706	Test Probe
892/00278	Gauge 0 - 40 bar (0 - 600 lb/in <sup>2</sup> )
892/00279	Gauge 0 - 400 bar (0 - 6000 lb/in <sup>2</sup> )
892/00280	Gauge 0 - 600 bar (0 - 8500 lb/in <sup>2</sup> )



816/50005	1/2 in BSP (A) x 1/2 in BSP (B)
816/60096	3/4 in BSP (A) x 3/4 in BSP (B)
816/00018	1 in BSP (A) x 1 in BSP (B)

**Female Cone Blanking Plug**


892/00055	1/4 in BSP
892/00056	3/8 in BSP
892/00057	1/2 in BSP
892/00058	5/8 in BSP
892/00059	3/4 in BSP
892/00060	1 in BSP

**Male Cone Blanking Plug**

816/00294	1/4 in BSP
816/00189	3/8 in BSP
816/00190	1/2 in BSP
816/00197	5/8 in BSP
816/00196	3/4 in BSP
816/00193	1 in BSP


**Service Tools (continued)**

**SECTION E - HYDRAULICS**



Ram Piston Nut Removal/Fitting Rig

- 993/99525 Rig Assembly (not including spanners and ram)
- 993/99522 Anchor Side Plate (supplied loose unwelded)
- 993/99523 Anchor Cross Member (supplied loose unwelded)
- 993/99524 Ram Eye End Modification Plate Assembly
- 556/43400 Lift Ram
- 545/18000 Lynch Pin
- 811/50232 1,1/4" Pivot Pin







Ram Piston Nut Removal/Fitting Spanner

- 993/99512 Spanner 55 mm A/F
- 993/99513 Spanner 60 mm A/F
- 993/99514 Spanner 65 mm A/F
- 993/99515 Spanner 70 mm A/F
- 993/99516 Spanner 75 mm A/F
- 993/99517 Spanner 85 mm A/F
- 993/99518 Spanner 90 mm A/F
- 993/99519 Spanner 100 mm A/F
- 993/99520 Spanner 110 mm A/F
- 993/99521 Spanner 115 mm A/F
- SSP0046 Spanner 80 mm A/F
- SSP0047 Spanner 95 mm A/F

Service Tools (continued)

SECTION E - HYDRAULICS


Slew Motor Unit - JS130



Service Tools (continued)

SECTION E - HYDRAULICS

Slew Motor Unit - JS160



JS07 00

Puller for Brake Piston


Stud is threaded M10 on both ends for 20 mm (0.8 in) and fitted with two M10 nuts.

**Service Tools (continued)**

**SECTION E - HYDRAULICS**

**Hydraulic Tank - JS130, JS160**

A	Dia. 40 mm (1.57 in)	
B	Dia. 26 mm (1.02 in)	
C	40 mm (1.47 in)	
D	50 mm (1.97 in)	
E	Dia. 10 mm (0.39 in)	
F	550 mm (21.7 in)	
G	9 mm (0.35 in)	
H	24 mm (0.94 in)	+0 -0.1     +0 -0.004
I	Dia. 81 mm (3.91 in)	
J	Dia. 76 mm (2.99 in)	
K	24 mm (0.94 in)	
L	95 mm (3.74 in)	
M	Radius 0.7 mm (0.028 in)	
N	120 mm (16.5 in)	
O	4.0 mm (0.157 in)	
P	3.0 mm (0.118 in)	
Q	15°	
O-ring	G75	




Blank for Suction Strainer






Service Tools (continued)

SECTION E - HYDRAULICS

Hydraulic Pump




Guide Rods




Rear Shaft Protection Tool

Swash Plate Levelling Tool



Oil Seal Insertion Tool

Front Shaft Protection Tool





Bearing Insertion Tool

**Service Tools (continued)**

**SECTION E - HYDRAULICS**



**Hydraulic Rams**

**Reconditioning**





**Bush Removal/Assembly Jig**

**Seal Ring Insertion Jig (Inner)**




**Bush Removal/Assembly Jig**

**Seal Ring Bedding Jig**



**Cylinder Head Insertion Jig**

**Wiper Ring Installation Jig**





**Seal Ring Insertion Jig (Outer)**



\* Service Tools (continued)

SECTION F - TRANSMISSION

Slew Gearbox - JS130






Slew Gearbox - JS160



Service Tools (continued)

SECTION F - TRANSMISSION

Slew Gearbox - JS160 (continued)



## Sealing and Retaining Compounds

<b>JCB Multi-Gasket</b>	A medium strength sealant suitable for all sizes of gasket flanges, and for hydraulic fittings 25-65 mm diameter.	4102/1212	
<b>JCB High Strength Threadlocker</b>	A high strength locking fluid for use with threaded components.	4102/0551	
<b>JCB Retainer (High Strength)</b>	For retaining parts which are unlikely to be dismantled.	4101/0651	
<b>JCB Threadlocker and Sealer</b>	A medium strength locking fluid for sealing and retaining nuts, bolts, and screws up to 50 mm diameter, and for hydraulic fittings up to 25 mm diameter.	4101/0251	
<b>JCB Threadlocker</b>	A locking fluid for use on threads larger than 50 mm diameter.	4101/0451	50ml
<b>JCB Threadlocker and Sealer (High Strength)</b>	A medium to high strength locking fluid for retention and sealing of ram piston heads.	4101/0552	
<b>JCB Activator</b>	A cleaning primer which speeds the curing rate of anaerobic products.	4104/0251 4104/0253	Aerosol Bottle
<b>JCB Cleaner/Degreaser</b>	For degreasing components prior to use of anaerobic adhesives and sealants.	4104/1557	Aerosol
<b>Anti-Seize Paste</b>	A compound used for assembly and prevention of parts seizure.	4003/0211	
<b>Direct Glazing Kit</b>	For one pane of glass; comprises items marked † below plus applicator nozzle etc.		
<b>† Ultra Fast Adhesive</b>	For direct glazing	4103/2109	310 ml
<b>† Active Wipe 205</b>	For direct glazing	4104/1203	250 g
<b>† Black Primer 206J</b>	For direct glazing	4201/4906	30 ml
<b>Clear Silicone Sealant</b>	To seal butt jointed glass.	4102/0901	

The part numbers and descriptions of sealing and retaining compounds available from JCB Service have been revised with effect from January 1997 (see MI 563/H, 507/HA, 511/E).

References to these products on subsequent pages in this service manual will be progressively updated, but for convenience a cross reference table is shown below.

Old Description	Old Part Number	New Description	New Part Number
<b>JCB High Strength Threadlocker</b>	4102/0502	<b>JCB High Strength Threadlocker</b>	4102/0551
<b>JCB High Strength Retainer</b>	4101/0602	<b>JCB Retainer (High Strength)</b>	4101/0651
<b>JCB Lock &amp; Seal</b>	4101/0202	<b>JCB Threadlocker &amp; Sealer</b>	4101/0251
<b>Loctite 243</b>	4101/1101	Use 4101/0251	
<b>JCB Multi-Gasket</b>	4102/1204	<b>JCB Multi-Gasket</b>	4102/1212
<b>High Strength Lock and Seal</b>	4104/0502	<b>JCB Threadlocker &amp; Sealer (High Strength)</b>	4101/0552
<b>JCB Threadlocker</b>	4101/0402	<b>JCB Threadlocker</b>	4102/0451
<b>Loctite Activator N</b>	4104/0101 Aerosol 4104/0102 Bottle	<b>JCB Activator</b>	4104/0251 4104/0253
Super Clean Safety Solvent	4104/0601 Aerosol	No longer available, Replaced by	4104/1557
<b>JCB Cleaner &amp; Degreaser</b>	4104/1538 Aerosol	<b>JCB Cleaner/Degreaser</b>	4104/1557

**Note:** High Strength Threadlocker was previously called High Strength Gasketing (4102/0502).

<b>Contents</b>	<b>Page No.</b>
Safety Notices	1 - 1
General Safety	2 - 1
Operating Safety	3 - 1
Maintenance Safety	4 - 1

In this publication and on the machine, there are safety notices. Each notice starts with a signal word. The signal word meanings are given below.

 **DANGER**

**Denotes an extreme hazard exists. If proper precautions are not taken, it is highly probable that the operator (or others) could be killed or seriously injured.**

INT-1-2-1

 **WARNING**

**Denotes a hazard exists. If proper precautions are not taken, the operator (or others) could be killed or seriously injured.**

INT-1-2-3

 **CAUTION**

**Denotes a reminder of safety practices. Failure to follow these safety practices could result in injury to the operator (or others) and possible damage to the machine.**

INT-1-2-3

All construction and agricultural equipment can be hazardous. When a JCB Excavator is correctly operated and properly maintained, it is a safe machine to work with. But when it is carelessly operated or poorly maintained it can become a danger to you (the operator) and others.

Do not work with the machine until you are sure that you can control it.

Do not start any job until you are sure that you and those around you will be safe.

If you are unsure of anything, about the machine or the job, ask someone who knows. Do not assume anything.

### **Remember**

**BE CAREFUL  
BE ALERT  
BE SAFE**

GEN-1-6

As well as the warnings in the following pages, specific warnings are given throughout the book. This section is designed to give a safety code for use of the machine generally and for operation and maintenance practices.

## **General Safety**



### **WARNING**

#### **Lifting Equipment**

You can be injured if you use faulty lifting equipment. Make sure that lifting equipment is in good condition. Make sure that lifting tackle complies with all local regulations and is suitable for the job. Make sure that lifting equipment is strong enough for the job.

INT-1-3-7



### **WARNING**

#### **Clothing**

You can be injured if you do not wear the proper clothing. Loose clothing can get caught in the machinery. Wear protective clothing to suit the job. Examples of protective clothing are: a hard hat, safety shoes, safety glasses, a well fitting overall, ear-protectors and industrial gloves. Keep cuffs fastened. Do not wear a necktie or scarf. Keep long hair restrained.

INT-1-3-6



### **WARNING**

#### **Care and Alertness**

All the time you are working with or on the machine, take care and stay alert. Always be careful. Always be alert for hazards.

INT-1-3-5



### **WARNING**

#### **Raised Equipment**

Raised equipment can fall and injure you. Do not walk or work under raised equipment unless safely supported.

13-1-1-6



### **DANGER**

Before removing the boom from the machine, ensure that the counterweight is adequately supported as in certain ground conditions the machine could tip backwards. Never travel or transport the machine with the boom removed.

BF6-3

## Operating Safety

### **WARNING**

#### Engine

The engine has rotating parts. Do not open the engine cover while the engine is running. Do not use the machine with the cover open.

INT-2-1-6

### **WARNING**

#### Entering/Leaving

Always face the machine when entering and leaving the cab. Use the step(s) and handrails. Make sure the step(s), handrails and your boot soles are clean and dry. Do not jump from the machine. Do not use the machine controls as handholds, use the handrails.

INT-2-1-7

### **WARNING**

#### Controls

You or others can be killed or seriously injured if you operate the control levers from outside the cab. Operate the control levers only when you are correctly seated inside the cab.

INT-2-1-3

### **WARNING**

#### Visibility

Accidents can be caused by working in poor visibility. Keep windows clean and use your lights to improve visibility. Do not operate the machine if you cannot see properly.

INT-2-1-11

### **WARNING**

#### Machine Limits

Operating the machine beyond its design limits can damage the machine, it can also be dangerous. Do not operate the machine outside its limits. Do not try to upgrade the machine performance with unapproved modifications.

INT-2-1-4

### **WARNING**

#### Exhaust Gases

Breathing the machine exhaust gases can harm and possibly kill you. Do not operate the machine in closed spaces without making sure there is good ventilation. If possible, fit an exhaust extension. If you begin to feel drowsy, stop the machine at once. Get out of the cab into fresh air.

INT-2-1-10

### **WARNING**

#### Hazardous Atmospheres

This machine is designed for use in normal outdoor atmospheric conditions. It should not be used in an enclosed area without adequate ventilation. Do not use the machine in a potentially explosive atmosphere, i.e. combustible vapours, gas or dust, without first consulting your JCB Distributor.

INT-2-1-14

### **WARNING**

#### Ramps and Trailers

Water, mud, ice, grease and oil on ramps or trailers can cause serious accidents. Make sure ramps and trailers are clean before driving onto them. Use extreme caution when driving onto ramps and trailers.

INT-2-2-6

### **WARNING**

#### Communications

Bad communications can cause accidents. Keep people around you informed of what you will be doing. If you will be working with other people, make sure any hand signals that may be used are understood by everybody. Work sites can be noisy, do not rely on spoken commands.

INT-2-2-3

### **DANGER**

#### Sparks

Explosions and fire can be caused by sparks from the exhaust or the electrical system. Do not use the machine in closed areas where there is flammable material, vapour or dust.

INT-2-2-10

### **WARNING**

#### Controls

Keep the machine controls clean and dry. Your hands and feet could slide off slippery controls. If that happens, you will lose control of the machine.

2-2-3-6

## Maintenance Safety

### **WARNING**

#### **Soft Ground**

A machine can sink into soft ground. Never work under a machine on soft ground.

INT-3-2-4

### **WARNING**

#### **Metal Splinters**

You can be injured by flying metal splinters when driving metal pins in or out. Use a soft faced hammer or drift to remove and fit metal pins. Always wear safety glasses.

INT-3-1-3

### **WARNING**

#### **Communications**

Bad communications can cause accidents. If two or more people are working on the machine, make sure each is aware of what the others are doing. Before starting the engine, make sure the others are clear of the danger areas; examples of danger areas are: the rotating blades and belt on the engine, the attachments and linkages, and anywhere beneath or behind the machine. People can be killed or injured if these precautions are not taken.

INT-3-1-5

### **WARNING**

#### **Diesel Fuel**

Diesel fuel is flammable; keep naked flames away from the machine. Do not smoke while refuelling the machine or working on the engine. Do not refuel with the engine running. There could be a fire and injury if you do not follow these precautions.

INT-3-2-2

### **WARNING**

#### **Petrol**

Do not use petrol in this machine. Do not mix petrol with the diesel fuel; in storage tanks the petrol will rise to the top and form flammable vapours.

INT-3-1-6

### **WARNING**

#### **Oil**

Oil is toxic. If you swallow any oil, do not induce vomiting, seek medical advice. Used engine oil contains harmful contaminants which can cause skin cancer. Do not handle used engine oil more than necessary. Always use barrier cream or wear gloves to prevent skin contact. Wash skin contaminated with oil thoroughly in warm soapy water. Do not use petrol, diesel fuel or paraffin to clean your skin.

INT-3-2-3

### **WARNING**

#### **Fires**

If your machine is equipped with a fire extinguisher, make sure it is checked regularly. Keep it in the operator's cab until you need to use it.

Do not use water to put out a machine fire, you could spread an oil fire or get a shock from an electrical fire. Use carbondioxide, dry chemical or foam extinguishers. Contact your nearest fire department as quickly as possible. Fire fighters should use self-contained breathing apparatus.

INT-3-2-7/1

### **WARNING**

#### **Battery**

A battery with frozen electrolyte can explode if it is used or charged. Do not use a machine with a frozen battery. To help prevent the battery from freezing, keep the battery fully charged.

INT-3-1-7

### **WARNING**

#### **Battery Gases**

Batteries give off explosive gases. Keep flames and sparks away from the battery. Do not smoke close to the battery. Make sure there is good ventilation in closed areas where batteries are being used or charged. Do not check the battery charge by shorting the terminals with metal; use a hydrometer or voltmeter.

INT-3-1-8

### **WARNING**

#### **Battery Terminals**

The machine is negatively earthed. Always connect the negative pole of the battery to earth.

When connecting the battery, connect the earth (-) lead last.

When disconnecting the battery, disconnect the earth (-) lead first.

INT-3-1-9

### **WARNING**

#### **Electrical Circuits**

Understand the electrical circuit before connecting or disconnecting an electrical component. A wrong connection can cause injury and/or damage.

INT-3-1-4

### **CAUTION**

Do not disconnect the alternator, the battery, or any part of the charging circuit with the engine running.

8-3-4-1

**Maintenance Safety (cont'd)****⚠ CAUTION**

Never use water or steam to clean inside the cab. The use of water or steam could damage the on-board computer and render the machine inoperable. Remove dirt using a brush or damp cloth.

8-3-4-8

**⚠ CAUTION**  
**Arc Welding**

Before carrying out any arc welding on the machine, completely remove the Control Computer to avoid damage to the circuits; also disconnect the alternator plug and battery leads.

When welding items to the mainframe make sure that the earth clamp is positioned on the mainframe and when welding to the undercarriage make sure that the earth clamp is positioned on the undercarriage. If you earth one and weld the other, you may cause severe damage to the slew ring.

Always connect the earth clamp to any other component being welded, i.e. boom or dipper, to avoid damage to pivot pins and bushes.

8-1-2-6/1

**⚠ WARNING**  
**Hydraulic Hoses**

Damaged hoses can cause fatal accidents. Inspect the hoses regularly for:

- Damaged end fittings
- Chafed outer covers
- Ballooned outer covers
- Kinked or crushed hoses
- Embedded armouring in outer covers
- Displaced end fittings.

INT-3-3-2

**⚠ WARNING**

DO NOT remove the hydraulic tank filler cap or cover plate when the engine is running. The hydraulic system is under pressure. You or others could be injured. First stop the engine and then release the pressure.

8-3-4-4/1

**⚠ WARNING**  
**Hydraulic Pressure**

Hydraulic fluid at system pressure can injure you. Before disconnecting or connecting hydraulic hoses, stop the engine and operate the controls to release pressure trapped in the hoses. Make sure the engine cannot be started while the hoses are open.

INT-3-1-11/1

**⚠ WARNING****Hydraulic Fluid**

Fine jets of hydraulic fluid at high pressure can penetrate the skin. Do not use your fingers to check for hydraulic fluid leaks. Do not put your face close to suspected leaks. Hold a piece of cardboard close to suspected leaks and then inspect the cardboard for signs of hydraulic fluid. If hydraulic fluid penetrates your skin, get medical help immediately.

INT-3-1-10/1

**⚠ CAUTION****Rams**

The efficiency of the rams will be affected if they are not kept free of solidified dirt. Clean dirt from around the rams regularly. When leaving or parking the machine, close all rams if possible to reduce the risk of weather corrosion.

INT-3-2-10

**⚠ CAUTION****Cleaning**

Cleaning metal parts with incorrect solvents can cause corrosion. Use only recommended cleaning agents and solvents.

INT-3-2-11

**⚠ CAUTION****'O'-rings, Seals and Gaskets**

Badly fitted, damaged or rotted 'O'-rings, seals and gaskets can cause leakages and possible accidents. Renew whenever disturbed unless otherwise instructed. Do not use Trichloroethane or paint thinners near 'O' rings and seals.

INT-3-2-12

**⚠ WARNING****Hot Coolant**

The cooling system is pressurised when the engine is hot. Hot coolant can spray out when you remove the radiator cap. Let the system cool before removing the radiator cap. To remove the cap; turn it to the first notch and let the system pressure escape, then remove the cap.

INT-3-2-9

**⚠ CAUTION**

If the machine is operated at full load, before its initial run-in procedure is complete, it may cause scuffing and seizing which can adversely effect the service life of the machine.

8-3-1-5

**⚠ WARNING****Compressed Air**

When using compressed air, wear safety glasses and gloves. Do not direct compressed air at your skin.

8-3-4-2


<b>Contents</b>	<b>Page No.</b>
<b>Fluids and Lubricants</b>	1 - 1
Lubricants - Health and Safety	1 - 2
<b>Service Schedules</b>	
Service Intervals for Hydraulic Oil and Filters when using a Breaker or Crusher	2 - 1
Initial Precautions For New Machine Usage	2 - 2
Operating Hours Schedule	2 - 3
<b>Greasing</b>	
Slew Ring Bearing	3 - 1
Slew Ring Teeth and Slew Pinion	3 - 1
Excavator End	3 - 2
<b>Battery</b>	4 - 1
<b>Fuses</b>	See Section C
<b>Hydraulics</b>	
Air bleeding procedures	5 - 1
Releasing tank pressure	5 - 1
Air bleeding from hydraulic pump	5 - 2
Air bleeding from ram	5 - 2
Air bleeding from the slew motor	5 - 3
Checking the fluid level	5 - 4
Topping up fluid level	5 - 4
Changing the hydraulic oil	5 - 5
Changing the Return Filter Element	5 - 6
Flushing Filters	5 - 6
Cleaning/Changing the Suction Strainer	5 - 7
Changing the Air Breather Element	5 - 8
Draining Tank Impurities	5 - 9
Changing the Pilot Oil Filter	5 - 9
Changing the Breaker In-line Filter	5 - 10
Changing the Drain Line Filter	5 - 10
Changing the Nephron Filter	5 - 11
<b>Transmission</b>	
Checking Track Gearbox Oil Level	6 - 1
Changing the Track Gearbox Oil	6 - 1
Checking the Slew Gearbox Oil Level	6 - 2
Changing the Slew Gearbox Oil	6 - 2
Replenishing Slew Gearbox Grease	6 - 2
<b>Tracks and Running Gear</b>	
Cleaning the Tracks	7 - 1
Checking/Adjusting the Track Tension	7 - 2
Checking the Shoe Plate	7 - 3
Checking the Rollers and Idler Wheels for Oil Leaks	7 - 3

<b>Contents</b>	<b>Page No.</b>
<b>Engine</b>	
Changing the Air Filter Elements	8 - 1
Checking the Oil Level	8 - 2
Changing the Oil and Filter(s)	8 - 2
Checking the Coolant Level	8 - 3
Coolant Mixtures	8 - 3
Changing the Coolant	8 - 4
Adjusting the Fan Belt	8 - 5
Fitting a New Fan Belt	8 - 5
Cleaning the Radiator and Oil Cooler	8 - 6
Draining Fuel Tank Impurities	8 - 7
Draining the Water Separator	8 - 7
Changing the Fuel Filter Element	8 - 7
Bleeding the Fuel System	8 - 8
<b>Component Location Diagrams</b>	9 - 1
<b>Performance Evaluation</b>	10 - 1
* <b>Falling Objects Protection Structure (FOPS)</b>	
Checking the FOPS structure	12 - 1


**CAPACITIES AND SPECIFICATIONS**

Item	Lubricant	International Specification	Capacity	
			JS130	JS160
ENGINE	(see separate chart)		12.1 litres (2.7 UK gal) (3.2 US gal)	12.1 litres (2.7 UK gal) (3.2 US gal)
TRACK GEARBOX	JCB HD90 Gear Oil	API-GL-5, MIL-L-2105	2 x 3.0 litres (2 x 0.66 UK gal) (2 x 0.79 US gal)	2 x 3.0 litres (2 x 0.66 UK gal) (2 x 0.79 US gal)
SLEW GEARBOX	JCB HD90 Gear Oil	API-GL-5, MIL-L-2105	5 litres (1.09 UK gal) (1.31 US gal)	5 litres (1.09 UK gal) (1.31 US gal)
	JCB Special HP Grease	Lithium based No. 2 consistency	1 litre (0.22 UK gal) (0.26 US gal)	1 litre (0.22 UK gal) (0.26 US gal)
TRACK ROLLERS IDLER WHEEL	JCB HD 90 Gear Oil	API-GL-5, MIL-L-2105	-	-
RECOIL SPRING CYLINDER	JCB Special HP Grease	Lithium based, No. 2 consistency	-	-
HYDRAULIC SYSTEM	JCB Hydraulic Fluid 46	ISO VG46	124 litres (27.3 UK gal) (32.8 US gal)	124 litres (27.3 UK gal) (32.8 US gal)
SLEW RING - BEARING - GEAR TEETH	JCB Special HP Grease	Lithium based No. 2 consistency	-	-
	JCB Special HP Grease	Lithium based No. 2 consistency	11kg (24.25 lb)	17kg (37.48 lb)
ALL OTHER GREASE POINTS	JCB Special HP Grease	Lithium based No. 2 consistency	-	-
COOLING SYSTEM	see <b>Coolant Mixtures</b>	-	16.4 litres (3.6 UK gal) (4.3 US gal)	17.2 litres (3.78 UK gal) (4.5 US gal)
FUEL TANK	see <b>Type of Fuel</b>	-	240 litres (52.8 UK gal) (63.4 US gal)	240 litres (52.8 UK gal) (63.4 US gal)

**\*ENGINE LUBRICATION CHART - ALL COUNTRIES EXCEPT NORTH AMERICAN**



**\*ENGINE LUBRICATION CHART - NORTH AMERICAN**



Sample of manual. Download All Pages at:

<https://www.arepairmanual.com/downloads/jcb-js130js160-tracked-excavators-service-repair-manual/>