

WORKSHOP MANUAL

Engine D900 - series

Product: KOMATSU D900 Series Diesel Engine Service Repair Workshop Manual(2974770M1)
Full Download: <https://www.arepairmanual.com/downloads/komatsu-d900-series-diesel-engine-service-repair-workshop-manual2974770m1/>

Product: KOMATSU D900 Series Diesel Engine Service Repair Workshop Manual(2974770M1)
Full Download: <https://www.arepairmanual.com/downloads/komatsu-d900-series-diesel-engine-service-repair-workshop-manual2974770m1/>

Sample of manual. Download All 316 pages at:
<https://www.arepairmanual.com/downloads/komatsu-d900-series-diesel-engine-service-repair-workshop-manual2974770m1/>

PREFACE and EXPLANATIONS


This hand book should assist the skilled construction machine mechanic when carrying out repairs and adjustments on MF construction machines. The work operations are written in such a style that the dismantling and assembling of the components can be carried out successfully and without difficulty.

To assist in the locating of specific test-repair operations, working descriptions etc. this hand book is divided into main and sub-groups. This also applies to all types of repair hand book publications.

At the top right hand corner of every page next to the section heading a series of numbers (orientation number) are to be found. These numbers follow in numerical sequence throughout the book.

The section heading applies either to the construction machine type, assembly or component for which the text and illustrations are valid.

Orientation number :



The main group numbers refer to either main assemblies, groups of main assemblies, sub-assemblies or components.

Example : Group 1700 - Steering (mechanical steering, assisted steering, hydro-steering, steering unit)

The sub-group numbers classify the descriptions and details as follows :

- 0 - General
- 1 - Functional descriptions
- 2 - Fault finding and possible preventive measures
- 3 - Test and adjustments
- 4 - Repairs
- 5 - Technical details

The instructions for dismantling and assembling of components have been coordinated with the picture tables, sectional views and parts lists so that all numbers in brackets refer to the identical part, i. e. (24).

CONTENTS

Page

ENGINE, general

Description	5000 - 101
Engine D 943 B, Injection pump side	5000 - 103
D 943 B, Camshaft side	5000 - 104
D 962 B, Injection pump side	5000 - 105
D 962 B, Camshaft side	5000 - 106
D 962 K, Injection pump side	5000 - 107
D 962 K, Camshaft side	5000 - 108
D 963 B, Injection pump side	5000 - 109
D 963 B, Camshaft side	5000 - 110
D 963 K, Injection pump side	5000 - 111
D 963 K, Camshaft side	5000 - 112
D 963 A 1, Injection pump side	5000 - 113
D 963 A 1, Camshaft side	5000 - 114
D 963 A 2, Injection pump side	5000 - 115
D 963 A 2, Camshaft side	5000 - 116
Fault finding chart	5000 - 201
Engine speed, testing and adjusting	5000 - 301
Engine mountings, replacing, D 962 K Dozer	5000 - 401
Engine mountings, replacing, D 963 B, D 963 A 1, D 963 A 2	5000 - 405
General technical data, repair values D 943 B	5000 - 501
	D 962 B 5000 - 511
	D 962 K 5000 - 521
Page 5000 - 500 shows from which engine number important amendments have taken place to the repair values.	D 963 B 5000 - 531
	D 963 K 5000 - 541
	D 963 A 1 5000 - 551
	D 963 A 2 5000 - 561
 <u>Cylinder block</u>	
Cylinder liners, removing	5100 - 401
Cylinder liners, refitting	5100 - 402
Rear crankshaft oil seal, replacing	5100 - 404
Side covers and gaskets, replacing	5100 - 406

CONTENTS	Page
<u>Cylinder head, complete</u>	
* Compression pressure test	5200 - 301
Adjusting valve clearances	5200 - 304
Air intake pipes and hoses, removing and refitting D 963 A 1, D 963 A 2	5200 - 401
Exhaust silencer, supports and gaskets, removing and refitting D 962 B / D 962 K / D 963 B / D 963 K	5200 - 406
Air intake manifolds and hoses, removing and refitting	5200 - 408
Cylinder head water pipes, removing and refitting D 943 B / D 962 B / D 962 K / D 963 K	5200 - 410
Heat exchanger water pipes, replacing D 943 B/D 962 B/D 962 K/D 963 K	5200 - 412
Cylinder head water pipes and hoses replacing D 963 B / D 963 A 1 / D 963 A 2	5200 - 413
Cab heater shut-off valve, removing, refitting and replacing	5200 - 415
Rocker arms, rocker shafts and push rods, removing	5200 - 416
Rocker arms, rocker shafts and push rods, refitting	5200 - 418
Cylinder head complete, removing and refitting	5200 - 419
Cylinder head, dismantling	5200 - 421
Valve seat inserts, refitting	5200 - 423
* Valve seat inserts, machining (in situ)	5200 - 426
* Valves and seats, regrinding	5200 - 427
* Valve guides, refitting	5200 - 429
Cylinder head, assembling	5200 - 430
<u>Pistons / connecting rods, complete</u>	
Pistons / connecting rods, removing	5300 - 401
Fitting piston to connecting rod	5300 - 403
Pistons / connecting rods, refitting	5300 - 405
<u>Crankshaft, complete</u>	
Crankshaft, removing	5400 - 401
Crankshaft, refitting	5400 - 404

* Please note the repair value amendments on page 5000 - 500

CONTENTS

Page

<u>Engine timing gear</u>	5500 - 401
Front crankshaft oil seal, replacing	5500 - 402
Push rods, tappets and camshaft, removing	5500 - 404
Fuel injection pump drive, removing	5500 - 407
Fuel injection pump drive, dismantling and assembling	5500 - 408
Fuel injection pump drive, dismantling and assembling D 963 A 2	5500 - 410
Camshaft bearings, replacing	5500 - 413
Tappets, push rods and camshaft refitting	5500 - 415
Injection pump drive, refitting	5500 - 417
Timing gear, setting	5500 - 418
Timing case cover, sump, pulley and push rods, refitting	5500 - 419
Checking the backlash and end float	5500 - 421
<u>Engine lubrication system</u>	
Oil circuit diagram D 943 B	5600 - 101
D 962 B / D 962 K	5600 - 103
D 963 K	5600 - 105
D 963 B	5600 - 107
D 963 A 1 / D 963 A 2	5600 - 109
Oil pump, pressure relief valve and piston cooling nozzle, removing	5600 - 401
Oil pump dismantling	5600 - 406
Oil pump assembling	5600 - 407
Oil pump dismantled	5600 - 408
Oil pump, pressure relief valve and piston cooling nozzle, refitting	5600 - 409
Oil filter complete and filter support removing and refitting D 963 B / D 963 K / D 963 A 1 / D 963 A 2	5600 - 412
Oil filter base and support, dismantled D 963 B / D 963 K / D 963 A 1 / D 963 A 2	5600 - 414
Oil filter complete, removing and refitting D 943 B / D 962 B / D 962 K	5600 - 416
Oil pipes and connections, repairing and replacing	5600 - 417
Turbo supercharger oil feed pipes, removing and refitting	5600 - 419
Oil sump and gasket, removing and refitting	5600 - 421

CONTENTS

Page

Fuel injection system

Circuit diagrams of the fuel injection and cold-start systems	5700 - 101
	to 5700 - 105
Changes to the fuel injection system	5700 - 106
Function of the cold-start device installed in the fuel injection pump	5700 - 107
Checking the commencement of injection	5700 - 301
Setting the commencement of injection	5700 - 304
Engine control, adjusting D 962 K	5700 - 306
Accelerator cable, to adjust D 943 B / D 962 B / D 963 B / D 963 A 1 / D 963 A 2	5700 - 308
Fuel injection pump, removing	5700 - 401
★ Fuel injection pump, refitting	5700 - 403
★ Fuel injectors removing and refitting	5700 - 406
★ Fuel injectors, testing and repairing	5700 - 408
Injection pipes and fuel leak-off hoses, replacing	5700 - 411
Glow plug, removing and refitting D 963 A 1 / D 963 A 2	5700 - 412
Fuel feed pump, testing and replacing	5700 - 413
Hand priming pump, testing and replacing	5700 - 414
 <u>Engine accessory equipment</u>	
Cooling fan, removing and refitting D 963 A 1 / D 963 A 2	5800 - 401
Fan pulley, removing and refitting D 963 A 1 / D 963 A 2	5800 - 401
Fan spindle bearing, removing and refitting D 963 A 1 / D 963 A 2	5800 - 403
Fan pulley, replacing D 962 K	5800 - 404
Fan spindle bearing, removing and refitting D 962 K	5800 - 404
Fan spindle bearing, dismantling and assembling D 962 K	5800 - 405
Water pump pulley, replacing D 962 K	5800 - 407
Water pump pulley, removing and refitting D 963 B / D 963 A 1 / D 963 A 2	5800 - 408
V-belt tensioner, removing, refitting and reconditioning D 963 K / D 963 B / D 963 A 1 / D 963 A 2	5800 - 411
Water pump, removing and refitting D 943 B / D 962 K	5800 - 415
Water pump, removing and refitting D 963 B / D 963 A 1 / D 963 A 2	5800 - 416
Water pump, dismantling and assembling D 943 B / D 962 K	5800 - 420

★ Please note the repair value amendments on page 5000 - 500

CONTENTS	Page
Thermostat removing and refitting D 943 B / D 962 B / D 962 K / D 963 K	5800 – 423/1
Thermostats, removing and refitting D 963 B / D 963 A 1 / D 963 A 2	5800 – 426
Hints for the operation of turbo supercharged diesel engines	5800 – 428
Turbo supercharger removing and refitting D 963 A 1 / D 963 A 2	5800 – 429
Turbo supercharger, sectional view	5800 – 432
Turbo supercharger, dismantling	5800 – 434
Turbo supercharger, assembling	5800 – 436
Air compressor, removing and refitting D 943 B / D 962 B / D 963 B / D 963 A 1 / D 963 A 2	5800 – 438
Air compressor pulley, removing and refitting D 943 B / D 962 B / D 963 B / D 963 A 1 / D 963 A 2	5800 – 441
Flywheel / ring gear, removing, refitting and replacing	5800 – 442
Starter motor, removing and refitting	5800 – 444
Alternator, removing and refitting	5800 – 445
Alternator pulley, removing and refitting	5800 – 447
Special tools	3419 – 001

<u>Machine type</u>	<u>Engine type</u>
44 C	D 943 B
55 C	D 962 B
66 C	D 963 B
77 C	D 963 A2
C 44 C	D 943 B
C 55 C	D 962 B
C 66 C	D 963 A1
D 66 C	D 963 A1
600 C	D 962 K
D 600 C	D 962 K
D 600 D	D 962 K
700 C	D 963 K
700 D	D 963 A1
D 700 C	D 963 K
D 700 D	D 963 A1

ENGINE DESCRIPTION

The crankcase is manufactured from cast iron and with the below centre crankshaft and re-inforced side walls produces a distortion free construction.

The renewable wet cylinder liners are manufactured from a centrifugally cast alloy and are sealed with a silicon sealing compound and two "O" ring seals.

Water tubes in the cylinder block guarantee an exceptional cooling of the cylinder liners.

The cylinder head is of a high quality cast iron and fitted to the crankcase with safety collar headed bolts.

The cylinder head gasket is a steel sheet coated on both sides with asbestos. The gasket bore hole rims are re-inforced with steel sheeting. When fitting the cylinder head gasket, on no account use sealing compound.

The valves operate in cast iron guides pressed into the cylinder head. In engines D 943, D 963, D 963 A 1, and D 963 A 2 the exhaust valve seat facings are stellite plated. In these engines a high heat resisting material is used for the inlet and exhaust valve seat inserts. (In the D 962 engine for the exhaust valve only).

The valve springs are of a special spring steel and are secured by spring caps and two piece split cones.

The induction hardened valve rocker shafts are mounted in light metal support brackets bolted onto the top face of the cylinder head. The inlet and exhaust valve rocker arms are manufactured from heat treated steel and are lubricated via an external oil pipe tapped into a camshaft bearing bush. They are operated by case hardened tappets and push rods.

The valve rocker gear is covered with a light metal cover.

The crankshaft is mounted in seven main bearings (the D 943 engine in five bearings) and is of cast chrome steel and hardened. The main and connecting rod journals are induction hardened, thereby guaranteeing a long life.

The precision finished bearing shells are white bearing metal lined. The bearing caps are of cast iron and secured with hexagon headed set screws.

At the front and rear of the crankshaft dust protected radial oil seals are fitted.

ENGINE DESCRIPTION (continued)

The seven journal camshaft (D 943 engine, five journals) is of cast and hardened steel. The cams and bearing surfaces are induction hardened. The camshaft is mounted in renewable precision finished bearings.

The light metal pistons have an eccentric positioned combustion chamber in the piston crowns, three compression rings and one oil control ring. The upper compression ring is chromed. In engines D 963 A 1, and D 963 A 2 the upper compression ring is fitted into a ring carrier cast in the piston.

The floating piston pins are secured with circlips.

The cast chrome alloy steel connecting rods have oblique fitting bearings caps and are located by serrations on the big end faces at right angles to the rod axis.

The piston pin bushes and connecting rod bearings are renewable. The piston complete with connecting rod can be removed from above.

The double geared oil pump guarantees all lubricating requirements of the engine even by extreme working angles of the machine.


The helical timing gears are of bath nitrated cast steel. The camshaft and injection pump timing gears are interchangeable.

The oil sump and timing gear housings are of thick walled cast iron and have the effect of dampening the engine gear mechanism noise.


The BOSCH injection pump is mechanical and variable speed regulated. It is lubricated independent from the engine. The overflow of leak-off fuel is directed into the pump crankcase.

The BOSCH injectors with multi-holed nozzles are fitted into the cylinder head with union type retaining nuts.

On the D 900 series engines the engine number is located on the camshaft side of the engine near the engine oil filter. (Fig. D 494)




INJECTION PUMP SIDE (Fig. D 464)



- | | |
|---|--|
| 1 Silencer | 9 Engine oil drain plug |
| 2 Engine suspending point | 10 Injection pump oil filler opening and breather filter |
| 3 Pressure regulator with tyre inflator bottle (brake system) | 11 Engine suspending point |
| 4 Engine bearer, rear | 12 Attachment point for angle drive for measuring engine speed |
| 5 Injection pump | 13 Fuel filter |
| 6 Coolant drain plug | 14 Air compressor |
| 7 Fuel feed pump | 15 Transmitter for coolant temperature gauge |
| 8 Engine bearer, front | |

CAMSHAFT SIDE (Fig. D 463)




D 463

- 1 Thermostat
- 2 Engine suspending point
- 3 Water pump
- 4 Alternator
- 5 Fan intermediate drive
- 6 Oil pressure transmitter
- 7 Engine oil drain plug
- 8 Engine bearer, front
- 9 Oil sump


- 10 Oil level dip stick
- 11 Oil filter
- 12 Engine bearer, rear
- 13 Starter
- 14 Access plug for injection timing marks
- 15 Breather filter and oil filler neck
- 16 Engine suspending point
- 17 Inlet manifold

INJECTION PUMP SIDE (Fig. D 458)



- | | |
|---------------------------|--|
| 1 Silencer | 9 Fuel filter |
| 2 Engine suspending point | 10 Attachment point for angle drive for measuring engine speed |
| 3 Engine bearer, rear | 11 Engine suspending point |
| 4 Injection pump | 12 Air compressor |
| 5 Fuel feed pump | 13 Transmitter for coolant temperature gauge |
| 6 Coolant drain plug | |
| 7 Engine bearer, front | |
| 8 Oil sump | |


CAMSHAFT SIDE (Fig. D 457)



D 457


- | | |
|----------------------------|---|
| 1 Thermostat | 10 Oil filler neck and dip stick |
| 2 Water pump | 11 Oil filter |
| 3 Engine suspending point | 12 Breather filter |
| 4 Alternator | 13 Engine bearer, rear |
| 5 Fan intermediate drive | 14 Starter |
| 6 Oil pressure transmitter | 15 Access plug for injection timing marks |
| 7 Engine bearer, front | 16 Engine suspending point |
| 8 Engine oil drain plug | 17 Inlet manifold |
| 9 Oil sump | |

INJECTION PUMP SIDE (Fig. B 227)




- | | |
|--|--|
| 1 Silencer | 11 Engine oil drain plug, rear |
| 2 Fuel filter | 12 Injection pump oil filler neck and breather filter |
| 3 Dip stick for converter transmission | 13 Engine oil drain plug front |
| 4 Oil filler neck | 14 Engine bearer, front |
| 5 Converter transmission | 15 Attachment point for angle drive for measuring engine speed |
| 6 Engine bearer, rear | 16 Tensioner pulley for water pump V-belts |
| 7 Heat exchanger | 17 Thermostat |
| 8 Injection pump | 18 Transmitter for coolant temperature gauge |
| 9 Fuel feed pump | |
| 10 Coolant drain plug | |

CAMSHAFT SIDE (Fig. B 228)




- | | |
|----------------------------|---|
| 1 Water pump | 10 Oil filler neck and breather |
| 2 Engine suspending point | 11 Starter |
| 3 Fan intermediate drive | 12 Engine bearer, rear |
| 4 Alternator | 13 Access plug for injection timing marks |
| 5 Engine bearer, front | 14 Working hydraulics pump |
| 6 Oil filter | 15 Breather valve for converter |
| 7 Oil pressure transmitter | 16 Inlet manifold |
| 8 Oil dip stick | |
| 9 Engine number | |

INJECTION PUMP SIDE (Fig. D 462)




- | | |
|---------------------------|--|
| 1 Silencer | 9 Fuel filter |
| 2 Engine suspending point | 10 Attachment point for angle drive for measuring engine speed |
| 3 Engine bearer, rear | 11 Engine suspending point |
| 4 Injection pump | 12 Air compressor |
| 5 Coolant drain plug | 13 Transmitter for coolant temperature gauge |
| 6 Fuel feed pump | |
| 7 Engine bearer, front | |
| 8 Oil sump | |

INJECTION PUMP SIDE (Fig. D 459)




- | | |
|---------------------------|---|
| 1 Silencer | 9 Oil sump |
| 2 Engine suspending point | 10 Vibration damper |
| 3 Fuel filter | 11 Attachment point for angle drive
for measuring engine speed |
| 4 Engine bearer, rear | 12 Engine suspending point |
| 5 Injection pump | 13 Injection pump oil filler and
breather |
| 6 Fuel feed pump | 14 Coolant outlet to radiator |
| 7 Coolant drain plug | |
| 8 Engine bearer, front | |

CAMSHAFT SIDE (Fig. D 460)




- | | |
|---|---|
| 1 Transmitter for coolant temperature gauge | 10 Oil sump |
| 2 Water pump | 11 Oil dip stick |
| 3 Engine suspending point | 12 Oil filter |
| 4 Alternator | 13 Engine bearer, rear |
| 5 Tensioner pulley for water pump and fan belts | 14 Starter |
| 6 Oil pressure transmitter | 15 Access plug for injection timing marks |
| 7 Vibration damper | 16 Engine suspending point |
| 8 Engine oil drain plug | 17 Breather filter and oil filler neck |
| 9 Engine bearer, front | 18 Inlet manifold |

INJECTION PUMP SIDE (Fig. C 259)




- | | |
|---|--|
| 1 Transmitter for coolant temperature gauge | 11 Coolant drain plug |
| 2 Air compressor | 12 Powershift transmission heat exchanger |
| 3 Exhaust pipe | 13 Engine oil drain plug |
| 4 Turbo charger | 14 Oil sump |
| 5 Injector | 15 Fuel filter |
| 6 Shut-off valve for heating system | 16 Fuel primary filter |
| 7 Engine suspending point | 17 Attachment point for angle drive for measuring engine speed |
| 8 Coolant drain plug | 18 Vibration damper |
| 9 Air pipe to pressure regulator (brakes) | 19 Fan |
| 10 Injection pump | |

CAMSHAFT SIDE (Fig. C 258)




- | | |
|------------------------------|---|
| 1 Air pipe to air compressor | 12 Oil sump |
| 2 Glow plug | 13 Coolant drain plug |
| 3 Solenoid | 14 Engine oil heat exchanger |
| 4 Coolant outlet to radiator | 15 Starter |
| 5 Thermostat housing | 16 Access plug for injection timing marks |
| 6 Water pump | 17 Engine suspending point |
| 7 Alternator | 18 Breather filter and oil filler neck |
| 8 Oil filter | 19 Breather filter and oil filler neck |
| 9 Oil level dip stick | |
| 10 Oil pressure transmitter | |
| 11 Engine oil drain plug | |

INJECTION PUMP SIDE (Fig. D 493)



- | | |
|--|---|
| 1 Exhaust pipe | 9 Injection pump oil filler neck
and breather filter |
| 2 Turbo charger | 10 Fuel filter |
| 3 Shut-off valve for heating
system | 11 Oil sump |
| 4 Engine suspending point | 12 Vibration damper |
| 5 Fuel primary filter | 13 Attachment point for angle drive
for measuring engine speed |
| 6 Injection pump | 14 Fan |
| 7 Fuel feed pump | 15 Servo pump |
| 8 Engine oil drain plug | 16 Air compressor |

CAMSHAFT SIDE (Fig. C 258)



- | | |
|------------------------------|---|
| 1 Air pipe to air compressor | 12 Oil sump |
| 2 Glow plug | 13 Coolant drain plug |
| 3 Solenoid | 14 Engine oil heat exchanger |
| 4 Coolant outlet to radiator | 15 Starter |
| 5 Thermostat housing | 16 Access plug for injection timing marks |
| 6 Water pump | 17 Engine suspending point |
| 7 Alternator | 18 Breather filter and oil filler neck |
| 8 Oil filter | 19 Breather filter and oil filler neck |
| 9 Oil level dip stick | |
| 10 Oil pressure transmitter | |
| 11 Engine oil drain plug | |

ENGINE, general

Turbo-supercharger, fault diagnosis

Although troubles on the engine may at first seem to be due to a faulty turbo-supercharger, it is advisable to study the engine fault diagnosis chart, especially in respect of the fuel injection system, before referring to the fault diagnosis chart set out below.

Fault	Possible Cause	Remedy
Abnormal density of exhaust gas and power loss	<p>As a rule caused by lack of air if charging pressure is too low.</p> <p>Dirt in air filter system, deformations at suction piping (too high vacuum in front of compressor, possibility of oil leakages on the compressor side.</p> <p>Silencer or exhaust gas piping behind the charger contaminated or damaged (pressure behind the charger too high).</p>	<p>Clean air filter and/or replace filter insert. Check suction pipe.</p> <p>Clean and/or repair parts.</p>
Unusual density of exhaust gas, power loss, but accompanied by abnormal noises	<p>Leakages at joints and flanges of air and exhaust gas pipings</p> <p>Rotor contacting housing</p>	<p>Check joints and flange connections, possibly replace seals.</p> <p>Remove piping on turbine and compressor sides and inspect housings for scoring. If necessary, check bearing clearances as specified.</p>
Rotor contacting housing	<p>As a rule, too large bearing clearance, caused by temporary interruption of oil supply, too low oil pressure, foreign matter or remnants in oil pipings and channels, defective or clogged oil filter system, poor oil quality due to too long intervals between oil changes, leakages at pressure oil piping to the charger, extreme rapid-start with very cold engine (avoid fast loading after start)</p>	<p>Replace charger. To avoid more damage until the charger can be replaced, run engine on part load only. Observe exhaust gas density.</p>

Prior to mounting the turbo-charger, check the suction piping in front of the compressor, the exhaust gas piping from the engine to the turbine and the oil piping to the charger very thoroughly for foreign matter or other types of contamination, thus avoiding untimely damages to the charger. Before connecting the oil feed piping, top up the bearing housing with clean oil.


ENGINE, complete

Fault Finding Chart

Fault	Possible Cause
Low cranking speed	1, 2, 3, 4
Will not start	5, 6, 8, 9, 10, 12, 13, 14, 15, 16, 17, 18, 19, 20, 22, 31, 32, 33, 60, 61, 62, 63, 64, 65
Difficult starting	5, 8, 9, 10, 11, 12, 13, 14, 15, 16, 18, 19, 20, 21, 22, 29, 31, 32, 33, 61, 62, 63, 64, 65
Lack of power	8, 9, 10, 11, 12, 13, 14, 18, 19, 20, 21, 22, 23, 25, 26, 27, 31, 32, 33, 61, 62, 63, 64, 66, 67, 68
Misfiring	8, 9, 10, 12, 13, 14, 18, 19, 20, 25, 26, 28, 29, 30, 32
Excessive fuel consumption	11, 13, 14, 18, 19, 20, 22, 23, 25, 27, 28, 29, 31, 32, 33
Black exhaust	11, 13, 14, 18, 19, 20, 22, 25, 27, 28, 29, 31, 32, 33, 66, 67, 68
Blue/white exhaust	4, 16, 18, 19, 20, 25, 27, 31, 33, 34, 45
Low oil pressure	36, 37, 38, 39, 40, 42, 43, 44, 58, 70
Knocking	9, 14, 18, 19, 22, 26, 28, 29, 31, 33, 36, 45, 46, 59
Erratic running	8, 9, 10, 11, 12, 13, 14, 20, 21, 23, 26, 28, 29, 30, 33, 45, 59
Vibration	13, 14, 20, 23, 25, 26, 29, 30, 33, 45, 47, 48, 49
High oil pressure	4, 38, 41
Overheating	11, 13, 14, 18, 19, 24, 25, 45, 50, 51, 52, 53, 54, 57, 69
Excessive crankcase pressure	25, 31, 33, 34, 45, 55
Poor compression	11, 19, 25, 28, 29, 31, 32, 33, 34, 46, 59
Starts and stops	10, 11, 12, 60

ENGINE**Fault Finding Chart****Key to fault finding chart**

- | | |
|---|---|
| 1 Battery capacity low | 38 Inaccurate oil pressure gauge |
| 2 Bad electrical connections | 39 Inaccurate oil gauge transmitter |
| 3 Faulty starter motor | 40 Pressure relief valve
sticking open |
| 4 Incorrect grade of lubricating oil | 41 Pressure relief valve
sticking closed |
| 5 Low cranking speed | 42 Broken relief valve spring |
| 6 Fuel tank empty | 43 Faulty oil suction pipe |
| 8 Blocked fuel feed pipe | 44 Choked oil filter |
| 9 Faulty fuel lift pump | 45 Piston seizure/pick up |
| 10 Choked fuel filter | 46 Incorrect piston height |
| 11 Restriction in air cleaner | 47 Damaged fan |
| 12 Air in fuel system | 48 Faulty engine mounting |
| 13 Faulty fuel injection pump | 49 Incorrectly aligned flywheel
housing or flywheel |
| 14 Faulty injectors or incorrect type | 50 Faulty thermostat |
| 15 Incorrect use of the cold start equipment on the D 963 A 1/A 2 engine | 51 Restriction in water jacket |
| 16 Heating element of the cold start equipment on the D 963 A 1/A 2 engine faulty | 52 Loose fan belt |
| 17 Broken fuel injection pump drive | 53 Choked radiator |
| 18 Incorrect fuel pump timing | 54 Faulty water pump |
| 19 Incorrect valve timing | 55 Choked breather pipe/filter |
| 20 Poor compression | 57 Coolant level too low |
| 21 Blocked fuel tank vent | 58 Blocked sump strainer |
| 22 Incorrect type or grade of fuel | 59 Broken valve spring |
| 23 Sticking throttle or restricted movement | 60 Fuel shut-off cock closed |
| 24 Exhaust pipe restriction | 61 Primary fuel filter choked |
| 25 Cylinder head gasket leaking | 62 Primary fuel filter leaking |
| 26 Overheating | 63 Fuel lift pump gauze choked |
| 27 Cold running | 64 Fuel overflow valve faulty |
| 28 Incorrect tappet adjustment | 65 Cold start equipment solenoid on the D 963 A 1/A 2 engine faulty |
| 29 Sticking valves | |
| 30 Incorrect high pressure pipes | |
| 31 Worn cylinder bores | |
| 32 Pitted valves and seats | 66 Exhaust pipe from engine to turbocharger leaking |
| 33 Broken, worn or sticking piston ring/s. | 67 Suction pipe from turbocharger to engine leaking |
| 34 Worn valve stems and guides | 68 Turbocharger faulty |
| 36 Worn or damaged bearings | 69 Cooling fan reversed |
| 37 Insufficient oil in sump | 70 Worn oil pumps |



ENGINE, general


Engine speed, testing and adjusting

Tools :

Angle drive with flexible drive shaft
 Tachometer
 Sealing pliers

Wilbär 5159
 Wilbär 2386

Warm up engine (approx. 85° C) (185° F).



1. Using a straight ring spanner unscrew and remove the plug. (1, Fig. C 272)

2. Connect up the angle drive with flexible drive shaft. (1, Fig. C 273)

3. On the other end of the flexible drive shaft, connect the contact piece (2, Fig. C 273) with the appropriate counter part (3, Fig. C 273) in the tachometer.

4. With the engine stopped, push the accelerator control rod towards maximum speed position and check to ensure that the governor lever (6, Fig. C 274) abuts the adjusting screw. (2, Fig. C 274)

If necessary adjust.

5. Reposition the accelerator control rod to idling position.

6. Start the engine and check engine speed.

For upper and lower speed figures see "Technical Data".

Adjusting on D 962 K and D 963 K engines (Fig. C 274) :

Lower idling speed :

Loosen the lock nut (3), adjust the control rod (1) until the correct idling speed is reached. Tighten the lock nut (3).

