

Shop Manual

DUMP TRUCK

HD465-7E0
HD605-7E0

SERIAL NUMBERS

HD465- 10001-10037
HD465- 10101 and up
HD605- 8001-8032
HD605- 10101 and up

ecot3

KOMATSU

05-7e0-rigid-dump-truck-service-repair-workshop-manualsen01081-17

DUMP TRUCK

HD465-7E0 HD605-7E0

Machine model	Serial number
HD465-7E0	10001 – 10037
HD465-7E0	10101 and up
HD605-7E0	8001 – 8032
HD605-7E0	10101 and up

00 Index and foreword

Index

Composition of shop manual	2
Table of contents	4

Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Note 1: Always keep the latest version of this manual in accordance with this list and utilize accordingly.

The marks shown to the right of Form No. denote the following:

○: New issue (to be filed additionally) ●: Revision (to be replaced for each Form No.)

Note 2: This shop manual can be supplied for each Form No.

Note 3: To file this shop manual in the special binder for management, handle it as follows:

- Place a divider on the top of each section in the file after matching the Tub No. with No. indicated next to each Section Name shown in the table below:
- File overview and other materials in sections in the order shown below and utilize them accordingly.

Section Title	Form Number
Shop Manual, contents binder, binder label and tabs	SEN01081-17
00 Index and foreword	SEN01082-17
Index	SEN01083-17 ●
Foreword and general information	SEN01084-06
01 Specification	SEN01085-03
Specification and technical data	SEN01086-03
10 Structure, function and maintenance standard	SEN01087-10
Engine and cooling system	SEN01088-02
Power train, Part 1	SEN01089-04 ●
Power train, Part 2	SEN01090-01
Steering system	SEN01091-01
Brake system	SEN01092-02
Undercarriage and frame	SEN01093-03
Hydraulic system	SEN01094-03
Work equipment (Body)	SEN04679-00
Cab and its attachments	SEN01095-02
Electrical system, Part 1	SEN01096-04
Electrical system, Part 2	SEN01097-04
Electrical system, Part 3	SEN01098-02
Electrical system, Part 4	SEN01099-05
20 Standard value table	SEN01100-03
Standard service value table	SEN01649-03
30 Testing and adjusting	SEN01101-06
Testing and adjusting, Part 1	SEN01650-05
Testing and adjusting, Part 2	SEN01651-05
Testing and adjusting, Part 3	SEN01652-04
Testing and adjusting, Part 4	SEN01653-02
Testing and adjusting, Part 5	SEN01654-04
40 Troubleshooting	SEN01102-07
Failure code table and fuse locations	SEN01660-04

General information on troubleshooting	SEN01661-05
Troubleshooting by failure code, Part 1	SEN01662-03
Troubleshooting by failure code, Part 2	SEN01663-04
Troubleshooting by failure code, Part 3	SEN01664-04
Troubleshooting by failure code, Part 4	SEN01665-04
Troubleshooting by failure code, Part 5	SEN01666-05
Troubleshooting by failure code, Part 6	SEN01667-05
Troubleshooting by failure code, Part 7	SEN01668-03
Troubleshooting by failure code, Part 8	SEN01669-02
Troubleshooting by failure code, Part 9	SEN01670-03
Troubleshooting of electrical system (E-mode)	SEN01671-03
Troubleshooting of hydraulic and mechanical system (H-mode)	SEN01672-01
Troubleshooting of engine (S-mode)	SEN01673-03
50 Disassembly and assembly	SEN01103-04
General information on disassembly and assembly	SEN02483-03
Engine and cooling system	SEN02484-03
Power train, Part 1	SEN02485-01
Power train, Part 2	SEN02486-01
Steering system	SEN02487-01
Brake system	SEN02488-01
Undercarriage and frame	SEN02489-02
Hydraulic system	SEN02490-01
Body	SEN02491-02
Cab and its attachments	SEN02492-03
Electrical system	SEN02493-01
90 Diagrams and drawings	SEN01104-10
Hydraulic diagrams and drawings	SEN01105-03
Electrical diagrams and drawings	SEN01106-08

Table of contents

00 Index and foreword	
Index	SEN01083-17
Composition of shop manual	2
Table of contents	4
Foreword and general information	SEN01084-06
Safety notice	2
How to read the shop manual	7
Explanation of terms for maintenance standard	9
Handling of electric equipment and hydraulic component	11
Handling of connectors newly used for engines	20
How to read electric wire code	23
Precautions when carrying out operation	26
Method of disassembling and connecting push-pull type coupler	29
Standard tightening torque table	32
Conversion table	36
01 Specification	
Specification and technical data	SEN01086-03
Specification drawing	2
Specifications	4
Weight table	12
Fuel, coolant and lubricants	13
10 Structure, function and maintenance standard	
Engine and cooling system	SEN01088-02
Radiator, torque converter oil cooler, after cooler, work equipment oil cooler, fuel cooler	2
Fuel system	4
Brake oil cooler	5
Output shaft	6
Power train, Part 1	SEN01089-04
Power train skeleton	2
Drive shaft	4
Torque converter and transmission hydraulic piping	6
Brake cooling oil control valve (BCV)	8
Torque converter	10
Torque converter valve	17
Transmission	19
Transmission control valve	35
ECMV	36
Power train, Part 2	SEN01090-01
Axle	2
Differential	4
Final drive	5
Wheels	6
Steering system	SEN01091-01
Steering column	2
Steering linkage	3
Brake system	SEN01092-02
Brake piping	2
Brake valve	4
Secondary brake valve	7
Relay valve	8

Front brake off valve	9
Accumulator charge valve	10
Accumulator	14
Slack adjuster.....	15
Brake.....	17
Parking brake solenoid valve	21
Undercarriage and frame	SEN01093-03
Suspension	2
Suspension cylinder	4
Rear axle support.....	12
Hydraulic system	SEN01094-03
Steering and hoist hydraulic piping	2
Dump body control	4
Hydraulic tank	5
Steering valve.....	6
Crossover relief valve.....	10
Steering cylinder.....	11
Steering control valve.....	12
Hoist valve.....	18
Dump control valve (EPC valve)	24
Hoist cylinder.....	28
Hydraulic pump	29
Work equipment (Body)	SEN04679-00
Auto greasing system.....	2
Cab and its attachments	SEN01095-02
ROPS cab	2
Air conditioner	3
Rear view monitor	9
Electrical system, Part 1	SEN01096-04
Machine monitor system	2
Electrical system, Part 2	SEN01097-04
Automatic shift control system	2
Transmission controller	6
External power supply heater.....	20
Automatic emergency steering system	22
Automatic suspension system.....	26
Retarder control system	29
Battery disconnecter switch	40
Dump control lever	46
Electrical system, Part 3	SEN01098-02
Payload meter II (Card type)	2
Electrical system, Part 4	SEN01099-05
VHMS controller related	2
ASR system (If equipped)	26
Sensors, switches	32
20 Standard value table	
Standard service value table	SEN01649-03
Standard value table for engine	2
Standard value table for machine.....	4
30 Testing and adjusting	
Testing and adjusting, Part 1	SEN01650-05
Tools for testing, adjusting, and troubleshooting	3
Sketch of special tool	9

Testing engine speed	10
Testing air supply pressure (boost pressure)	11
Testing exhaust temperature	12
Testing exhaust gas color	14
Adjustment of valve clearance	16
Testing of compression pressure	18
Testing blow-by pressure	21
Testing engine oil pressure	22
Testing EGR valve and bypass valve drive oil pressure	23
Handling of fuel system devices	25
Releasing residual pressure from fuel system	25
Testing of fuel pressure	26
Reduced cylinder mode operation	27
No-injection cranking	27
Testing of fuel return rate and fuel leakage	28
Bleeding air from fuel circuit	30
Testing the fuel circuit for leakage	31
Replacement and adjustment of fan belt	32
Replacement and adjustment of alternator and air conditioner compressor belt	33
Testing and adjusting, Part 2	SEN01651-05
Testing torque converter stall speed	3
Testing power train oil pressure	4
Adjusting transmission speed sensor	11
Testing and adjusting brake oil pressure	12
Testing of accumulator nitrogen gas pressure and procedure for charging accumulator with nitrogen gas	15
Testing brake performance	21
Bleeding air from brake circuit	23
Testing wear of front brake pad	24
Testing wear of rear brake disc	25
Method of releasing parking brake in an emergency	26
Testing and adjusting front suspension cylinder	27
Testing and adjusting rear suspension cylinder	31
Testing and adjusting front suspension cylinder (Automatic suspension specification)	35
Testing and adjusting hydraulic pressure in steering, hoist circuit	36
Testing and adjusting oil pressure in dump EPC circuit	39
Air bleeding from steering cylinder	40
Procedure for raising dump body in emergency	41
Procedure for lowering dump body in emergency	42
Adjusting body positioner sensor	44
Handling of voltage circuit of engine controller	45
Adjusting transmission controller	45
Method for emergency escape at electrical system failure	46
Testing and adjusting, Part 3	SEN01652-04
Setting and adjusting of devices	2
Special functions of machine monitor (EMMS)	14
Testing and adjusting, Part 4	SEN01653-02
Special functions of machine monitor (EMMS)	2
Testing and adjusting, Part 5	SEN01654-04
Request for opening ORBCOMM terminal	2
VHMS controller initial setting procedure	4
Using method of KOMTRAX functions of ORBCOMM terminal	24
Precautions for replacing VHMS controller	27
Pm Clinic check sheet	33
Initial setting of payload meter	37
Setting of payload meter built in VHMS	38
Setting of card-type payload meter (PLM-II) after installation or replacement	46

40 Troubleshooting	
General information on troubleshooting	SEN01661-05
Points to remember when troubleshooting.....	2
Sequence of events in troubleshooting	3
Check before troubleshooting	4
Classification and procedures for troubleshooting	5
Contents of troubleshooting table.....	6
Connection table for connector pin numbers	8
T-branch box and T-branch adapter table	44
Failure code table and fuse locations	SEN01660-04
Failure codes table	2
Fuse locations	13
Troubleshooting by failure code, Part 1	SEN01662-03
Failure code [1500L0] (Dual engagement).....	3
Failure code [15B0NX] (Transmission oil filter: Clogging).....	4
Failure code [15F0KM] (R → F shifting abuse 1: Mistake in operation)	6
Failure code [15F0MB] (R → F shifting abuse 2: Mistake in operation)	6
Failure code [15F7KM] (Forward clutch disk abuse: Mistake in operation or setting).....	7
Failure code [15G0MW] (R clutch: Slipping)	8
Failure code [15G7KM] (Reverse clutch disk abuse: Mistake in operation or setting)	10
Failure code [15H0MW] (Hi clutch: Slipping)	12
Failure code [15J0MW] (Lo clutch: Slipping).....	14
Failure code [15K0MW] (1st clutch: Slipping)	16
Failure code [15L0MW] (2nd clutch: Slipping)	18
Failure code [15M0MW] (3rd clutch: Slipping)	20
Failure code [15N0MW] (4th clutch: Slipping).....	22
Failure code [15SBL1] (R clutch solenoid: Fill signal is ON when command current is OFF).....	24
Failure code [15SBMA] (R clutch solenoid: Malfunction)	26
Failure code [15SCL1] (Hi clutch solenoid: Fill signal is ON when command current is OFF).....	27
Failure code [15SCMA] (Hi clutch solenoid: Malfunction)	30
Failure code [15SDL1] (Lo clutch solenoid: Fill signal is ON when command current is OFF)	31
Failure code [15SDMA] (Lo clutch solenoid: Malfunction)	34
Failure code [15SEL1] (1st clutch solenoid: Fill signal is ON when command current is OFF).....	35
Failure code [15SEMA] (1st clutch solenoid: Malfunction).....	38
Troubleshooting by failure code, Part 2	SEN01663-04
Failure code [15SFL1] 2nd clutch solenoid: Fill signal is ON when command current is OFF....	4
Failure code [15SFMMA] 2nd clutch solenoid: Malfunction	7
Failure code [15SGL1] 3rd clutch solenoid: Fill signal is ON when command current is OFF	8
Failure code [15SGMA] 3rd clutch solenoid: Malfunction	11
Failure code [15SHL1] 4th clutch solenoid: Fill signal is ON when command current is OFF	12
Failure code [15SHMA] 4th clutch solenoid: Malfunction	15
Failure code [15SJMA] Lockup clutch solenoid: Malfunction	16
Failure code [2C4MNX] Retarder cooling oil filter: Clogging.....	18
Failure code [2F00KM] Parking brake: Mistake in operation or setting.....	20
Failure code [2G42ZG] Accumulator: Oil pressure reduction (Front).....	23
Failure code [2G43ZG] Accumulator: Oil pressure reduction (Rear)	23
Failure code [6014NX] Hydraulic oil filter: Clogging.....	24
Failure code [989A00] Engine over run prevention command signal: Operating.....	26
Failure code [989D00] Rear section tipping over alarm: Alarm is activated.....	26
Failure code [A570NX] Engine oil filter: Clogging	27
Failure code [AA10NX] Air cleaner element: Clogging	28
Failure code [AB00MA] Alternator: Malfunction	30
Failure code [B@BAZG] Abnormal lowering of engine oil pressure: Lowering of oil pressure ...	32
Failure code [B@BAZK] Engine oil: Level too low	33
Failure code [B@BCNS] Engine: Overheat	34
Failure code [B@BCZK] Lowering of radiator coolant: Lowering of level	36
Failure code [B@BFZK] Lowering of fuel level	38

Failure code [B@C7NS] Brake cooling oil: Overheating (Rear).....	40
Failure code [B@CENS] Overheating of torque converter oil	42
Failure code [B@GAZK] Battery electrolyte level: Lowering of level.....	43
Failure code [B@JANS] Steering oil temperature: Overheat	44
Troubleshooting by failure code, Part 3	SEN01664-04
Failure code [CA111] Abnormality in engine controller.....	4
Failure code [CA115] Engine Ne or Bkup speed sensor error	6
Failure code [CA122] Charge pressure sensor high error.....	8
Failure code [CA123] Charge pressure sensor low error	10
Failure code [CA131] Throttle sensor high error	12
Failure code [CA132] Throttle sensor low error.....	15
Failure code [CA135] Engine oil pressure sensor high error.....	16
Failure code [CA141] Engine oil pressure sensor low error	18
Failure code [CA144] Coolant temperature sensor high error.....	20
Failure code [CA145] Coolant temperature sensor low error	22
Failure code [CA153] Charge temperature sensor high error	24
Failure code [CA154] Charge temperature sensor low error.....	26
Failure code [CA187] Sensor power supply 2 low error.....	26
Failure code [CA212] Engine oil temperature sensor high error	28
Failure code [CA213] Engine oil temperature sensor low error.....	30
Failure code [CA221] Atmospheric pressure sensor high error	32
Failure code [CA222] Atmospheric pressure sensor low error.....	34
Failure code [CA227] Sensor power supply 2 high error.....	36
Failure code [CA234] Engine overspeed.....	38
Failure code [CA238] Ne speed sensor power supply error.....	40
Failure code [CA263] Fuel temperature sensor high error	42
Failure code [CA265] Fuel temperature sensor low error	44
Failure code [CA271] PCV1 short circuit.....	46
Failure code [CA272] PCV1 disconnection	48
Failure code [CA273] PCV2 short circuit.....	50
Failure code [CA274] PCV2 disconnection	52
Failure code [CA322] Injector #1 system disconnection or short circuit.....	54
Failure code [CA323] Injector #5 system disconnection or short circuit.....	56
Failure code [CA324] Injector #3 system disconnection or short circuit.....	58
Failure code [CA325] Injector #6 system disconnection or short circuit.....	60
Failure code [CA331] Injector #2 system disconnection or short circuit.....	62
Failure code [CA332] Injector #4 system disconnection or short circuit.....	64
Failure code [CA342] Engine controller data inconsistency	66
Failure code [CA351] Injectors drive circuit error	66
Failure code [CA352] Sensor power supply 1 low error.....	67
Failure code [CA386] Sensor power supply 1 high error.....	68
Troubleshooting by failure code, Part 4	SEN01665-04
Failure code [CA431] Idle validation switch error	4
Failure code [CA432] Idle validation action error	8
Failure code [CA441] Battery voltage low error.....	8
Failure code [CA442] Battery voltage high error	9
Failure code [CA449] Common rail pressure high error 2.....	9
Failure code [CA451] Common rail pressure sensor high error	10
Failure code [CA452] Common rail pressure sensor low error	12
Failure code [CA553] Common rail pressure high error 1	13
Failure code [CA554] Common rail pressure sensor: In-range error	14
Failure code [CA559] Supply pump no-pressure feed error 1	15
Failure code [CA689] Engine Ne speed sensor error.....	18
Failure code [CA731] Engine Bkup speed sensor phase error	20
Failure code [CA757] All engine controller data lost error.....	21
Failure code [CA778] Engine Bkup speed sensor error	22
Failure code [CA1228] EGR valve servo error 1	24

Failure code [CA1625] EGR valve servo error 2	25
Failure code [CA1626] Short circuit in bypass valve solenoid drive system	26
Failure code [CA1627] Disconnection in bypass valve solenoid drive system	28
Failure code [CA1628] Bypass valve servo error 1	29
Failure code [CA1629] Bypass valve servo error 2	30
Failure code [CA1631] Bypass valve lift sensor high error	32
Failure code [CA1632] Bypass valve lift sensor low error	34
Failure code [CA1633] KOMNET (datalink timeout) error	35
Failure code [CA2185] Throttle sensor supply voltage high error	36
Failure code [CA2186] Throttle sensor power supply low error	38
Failure code [CA2249] Supply pump no-pressure feed error 2	39
Failure code [CA2271] EGR valve lift sensor high error	40
Failure code [CA2272] EGR valve lift sensor low error	42
Failure code [CA2351] Short circuit in EGR valve solenoid drive system	44
Failure code [CA2352] Disconnection in EGR valve solenoid drive system	46
Failure code [CA2555] Intake heater relay voltage low error	47
Failure code [CA2556] Intake heater relay voltage high error	48
Troubleshooting by failure code, Part 5	SEN01666-05
Failure code [D19HKB] Stop lamp relay output system: Short circuit	3
Failure code [D5ZKKZ] Front brake cut-off solenoid valve: Disconnection, short circuit or short circuit to power supply line	4
Failure code [DAF9KM] Wrong connection of connector	6
Failure code [DAFRKR] Abnormal CAN communication (machine monitor): Abnormal communication	7
Failure code [DAQ0KK] Transmission controller direct power supply: Lowering of supply voltage	8
Failure code [DAQ0KT] Transmission controller nonvolatile memory: Abnormality in controller	10
Failure code [DAQ2KK] Transmission controller solenoid power supply: Power supply voltage too low	12
Failure code [DAQ9KQ] Transmission controller: Disagreement of model selection	14
Failure code [DAQRKR] Abnormality in CAN communication (Transmission)	15
Failure code [DAQRMA] Transmission controller option setting: Malfunction	20
Failure code [DB10KT] Retarder controller nonvolatile memory: Abnormality in controller	20
Failure code [DB12KK] Retarder controller solenoid power supply: Power supply system trouble	21
Failure code [DB13KK] Retarder controller battery direct power supply: Power supply voltage too low	23
Failure code [DB19KQ] Disagreement of model selection (Retarder controller)	25
Failure code [DB1RKR] CAN communication (retarder controller): Communication disabled	27
Failure code [DB1RMA] Disagreement of option setting (Retarder controller)	31
Failure code [DB2RKR] CAN communication (engine controller): Communication disabled	32
Failure code [DBB0KK] or VHMS_LED display: "n9" → "01" VHMS controller: Low power supply voltage (input)	38
Failure code [DBB0KQ] or VHMS_LED display: "nF" → "11" VHMS controller: Disagreement of model selection signals	40
Failure code [DBB3KK] or VHMS_LED display: "n9" → "05" VHMS controller battery power supply: Low power supply voltage (input)	42
Failure code [DBB5KP] or VHMS_LED display: "n9" → "04" VHMS controller 5 V power supply output: Low output voltage	44
Failure code [DBB6KP] or VHMS_LED display: "n9" → "02" VHMS controller 24 V power supply output: Low output voltage	46
Failure code [DBB7KP] or VHMS_LED display: "n9" → "03" VHMS controller 12 V power supply output: Low output voltage	48
Failure code [DBQRKR] or VHMS_LED display: "n8" → "02" VHMS controller CAN communication: Defective communication (Abnormality in target component system)	49
Failure code [DBBRKR] Abnormality in CAN communication (VHMS)	49
Failure code [DBC2KK] ABS controller solenoid power supply: Power supply system trouble ..	50

Failure code [DBC3KK] ABS controller battery direct power supply: Power supply voltage too low.....	52
Failure code [DBC9KQ] Disagreement of model selection (ABS controller)	54
Failure code [DBCRRK] Abnormality in CAN communication (ABS)	55
Failure code [DBCRRMA] Disagreement of option setting (ABS controller).....	59
Failure code [DDD7KX] Trouble in travel speed setting switch system: Out of input signal range	60
Failure code [DDD8KA] ARSC system switch system: Disconnection (If equipped)	62
Failure code [DDD8KB] ARSC system switch system: Short circuit (If equipped)	64
Failure code [DDD9KA] ABS system switch system: Disconnection	66
Failure code [DDD9KB] ABS system switch system: Short circuit	68
Failure code [DDDAKA] ASR system switch: Disconnection	70
Failure code [DDDAKB] ASR system switch: Short circuit.....	72
Failure code [DDP6L4] Service brake pressure switch trouble (Rear).....	74
Failure code [DDTHKA] Hi clutch fill switch: Disconnection	76
Failure code [DDTJKA] Lo clutch fill switch: Disconnection	78
Failure code [DDTKKA] 1st clutch fill switch: Disconnection	80
Failure code [DDTLKA] 2nd clutch fill switch: Disconnection	82
Failure code [DDTMKA] 3rd clutch fill switch: Disconnection.....	84
Failure code [DDTNKA] R clutch fill switch: Disconnection.....	86
Failure code [DDTPKA] 4th clutch fill switch: Disconnection.....	88
Failure code [DF10KA] Gear shift lever: Disconnection	90
Failure code [DF10KB] Gear shift lever: Short circuit.....	93
Failure code [DGE5KX] or VHMS_LED display: "n4" → "01" Atmospheric temperature sensor: Out of input signal range	98
Failure code [DGF1KX] Transmission oil temperature sensor: Out of input signal range	100
Failure code [DGR2KZ] Retarder oil temperature sensor system trouble : Ground fault (Rear wheel).....	102
Failure code [DGR6KX] Steering oil temperature sensor: Input signal out of range	104
Failure code [DGT1KX] Torque converter oil temperature sensor: Out of input signal range	106
Troubleshooting by failure code, Part 6	SEN01667-05
Failure code [DGT4KA] or VHMS_LED display: "n3" → "12" Exhaust gas temperature sensor (F): Disconnection	3
Failure code [DGT4KB] or VHMS_LED display: "n3" → "11" Exhaust gas temperature sensor (F): Short circuit.....	6
Failure code [DGT5KA] or VHMS_LED display: "n3" → "22" Exhaust gas temperature sensor (R): Disconnection.....	9
Failure code [DGT5KB] or VHMS_LED display: "n3" → "21" Exhaust gas temperature sensor (R): Short circuit	12
Failure code [DHE5KB] or VHMS_LED display: "n3" → "32" Blow-by pressure sensor: Short circuit	15
Failure code [DHE5KY] or VHMS_LED display: "n3" → "31" Blow-by pressure sensor: Short circuit with power supply line	18
Failure code [DHP4KY] or VHMS_LED display: "n5" → "44" Short circuit in suspension pressure sensor system (Front right)	20
Failure code [DHP4KZ] or VHMS_LED display: "n5" → "43" Disconnection or ground fault in suspension pressure sensor system (Front right)	22
Failure code [DHP5KY] or VHMS_LED display: "n5" → "54" Short circuit in suspension pressure sensor system (Front left)	24
Failure code [DHP5KZ] or VHMS_LED display: "n5" → "53" Disconnection or ground fault in suspension pressure sensor system (Front left).....	26
Failure code [DHP6KA] Suspension pressure sensor system: Disconnection (Right rear)	28
Failure code [DHP6KX] Failure in suspension pressure sensor system trouble: Out of input signal range (Right rear).....	29
Failure code [DHP6KY] or VHMS_LED display: "n5" → "64" Suspension pressure sensor system: Short circuit (Right rear)	32
Failure code [DHP6KZ] or VHMS_LED display: "n5" → "63" Suspension pressure sensor system: Disconnection or ground fault (Right rear)	34

Failure code [DHP7KA] Suspension pressure sensor system: Disconnection (Left rear).....	36
Failure code [DHP7KX] Failure in suspension pressure sensor system trouble:	
Out of input signal range (Left rear)	38
Failure code [DHP7KY] or VHMS_LED display: "n5" → "74" Suspension pressure sensor system: Short circuit (Left rear)	40
Failure code [DHP7KZ] or VHMS_LED display: "n5" → "73" Suspension pressure sensor system: Disconnection or ground fault (Left rear)	42
Failure code [DHT5KX] Torque converter oil pressure sensor: Out of input signal range.....	44
Failure code [DHT5L6] Torque converter oil pressure sensor: Disagreement of run and stop condition with signal	46
Failure code [DHU2KX] Front accumulator oil pressure sensor: Out of input signal range	48
Failure code [DHU3KX] Rear accumulator oil pressure sensor: Out of input signal range.....	50
Failure code [DHU6KX] Trouble in ABS control valve pressure sensor (Front right)	52
Failure code [DHU7KX] Trouble in ABS control valve pressure sensor (Front left)	54
Failure code [DHU8KX] Trouble in ABS control valve pressure sensor (Front right)	56
Failure code [DHU9KX] Trouble in ABS control valve pressure sensor (Front right)	58
Failure code [DJF1KA] Fuel level sensor: Disconnection	60
Failure code [DK30KX] Steering angle potentiometer: Trouble (Disconnection).....	62
Failure code [DK51L5] Retarder lever potentiometer: Potentiometer signal is inconsistent with switch signal	63
Failure code [DK52KX] Failure in hoist lever potentiometer 1: Out of input signal range	66
Failure code [DK53L8] Failure in hoist lever potentiometer 2: Disagreement of analog signal...	68
Failure code [DK54KX] Body positioner sensor: Out of input signal range	70
Failure code [DKD0L6] Failure in steering speed sensor.....	72
Failure code [DKH0KX] Clinometer sensor signal out of range	74
Failure code [DKH1KX] or VHMS_LED display: "n4"→"33" Abnormality in clinometer sensor...	76
Failure code [DLF1KA] Transmission input shaft speed sensor: Disconnection.....	78
Failure code [DLF1LC] Transmission input shaft speed sensor: Disagreement of revolution speed signal.....	80
Failure code [DLF2KA] Transmission intermediate shaft speed sensor: Disconnection.....	82
Failure code [DLF2LC] Transmission intermediate shaft speed sensor: Disagreement of revolution speed signal	84
Troubleshooting by failure code, Part 7	SEN01668-03
Failure code [DLF6KA] Disconnection in wheel speed sensor (Front right).....	3
Failure code [DLF6L3] Trouble in wheel speed sensor (Front right)	4
Failure code [DLF7KA] Disconnection in wheel speed sensor (Front left)	5
Failure code [DLF7L3] Trouble in wheel speed sensor (Front left)	6
Failure code [DLF8KA] Disconnection in wheel speed sensor (Right rear)	8
Failure code [DLF8L3] Trouble in wheel speed sensor (Right rear).....	10
Failure code [DLF8LC] Trouble in wheel speed sensor system (Right rear).....	12
Failure code [DLF8MA] Disconnection in wheel speed sensor (Right rear).....	13
Failure code [DLF9KA] Disconnection in wheel speed sensor (Left rear).....	14
Failure code [DLF9L3] Trouble in wheel speed sensor (Left rear)	16
Failure code [DLF9LC] Trouble in wheel speed sensor system (Left rear)	18
Failure code [DLF9MA] Disconnection in wheel speed sensor (Left rear)	19
Failure code [DLT3KA] Disconnection in transmission output shaft speed sensor system.....	20
Failure code [DLT3LC] Trouble in transmission output shaft speed sensor	22
Failure code [DLT4KA] Disconnection in transmission output shaft speed sensor	24
Failure code [DLT4MA] Disconnection in transmission output shaft speed sensor.....	26
Failure code [DV00KB] Short circuit in buzzer output	28
Failure code [DW2AKA] Disconnection in main pressure variable valve output	30
Failure code [DW2AKB] Ground fault in main pressure variable valve output circuit	32
Failure code [DW2AKY] Hot short in main pressure variable valve output circuit.....	34
Failure code [DW2AL1] Defective reset of main pressure variable valve	36
Failure code [DW2ALH] Malfunction of main pressure variable valve	38
Failure code [DW35KZ] Trouble in output system of auto suspension solenoid 1 (Disconnection or short circuit)	40

Failure code [DW36KZ] Trouble in output system of auto suspension solenoid 2 (Disconnection or short circuit).....	42
Failure code [DW72KZ] Trouble in kick-out solenoid output system (Disconnection or short circuit).....	44
Failure code [DW73KZ] Trouble in hoist select valve output system (Disconnection or short circuit).....	46
Failure code [DW78KZ] Trouble in brake cooling valve (BCV) (rear wheel) output system (Disconnection or short circuit).....	48
Failure code [DWNBK4] Trouble in ASR shut-off valve (Valve keeps operating)	50
Failure code [DWNBKA] Disconnection in ASR shut-off valve output circuit	52
Failure code [DWNBKB] Ground fault in ASR shut-off valve output circuit	54
Failure code [DWNBKY] Short circuit in ASR shut-off valve output circuit.....	56
Failure code [DWNBMA] Trouble in ASR shut-off valve (Valve does not operate)	57
Failure code [DWNDKZ] Trouble in ABS cut-off valve (Front) system	58
Failure code [DWNDMA] Defective ABS cut-off valve (Front).....	60
Failure code [DWNEKZ] Trouble in ABS cut-off valve (Rear) system	62
Failure code [DWNEMA] Defective ABS cut-off valve (Rear)	64
Troubleshooting by failure code, Part 8	SEN01669-02
Failure code [DX11K4] Trouble in rear brake proportional pressure reducing solenoid valve (Valve keeps operating).....	4
Failure code [DX11KA] Disconnection in rear brake proportional pressure reducing solenoid valve output circuit	6
Failure code [DX11KB] Short circuit in rear brake proportional pressure reducing solenoid valve	7
Failure code [DX11KY] Short circuit in rear wheel proportional pressure reducing solenoid valve output circuit	8
Failure code [DX11MA] Trouble in rear wheel proportional pressure reducing solenoid valve (Valve does not operate)	9
Failure code [DX13KA] Disconnection in hoist EPC valve output circuit.....	10
Failure code [DX13KB] Short circuit in hoist EPC valve output circuit	12
Failure code [DX13KY] Short circuit in hoist EPC valve output circuit	14
Failure code [DX17K4] Trouble in ASR proportional pressure reducing solenoid valve (right) (Valve keeps operating)	16
Failure code [DX17KA] Disconnection in ASR proportional pressure reducing solenoid valve (right) output circuit	18
Failure code [DX17KB] Ground fault in ASR proportional pressure reducing solenoid valve (right) output circuit	20
Failure code [DX17KY] Short circuit in ASR proportional pressure reducing solenoid valve (right) output circuit	22
Failure code [DX17MA] Trouble in ASR proportional pressure reducing solenoid valve (right) (Valve does not operate).....	22
Failure code [DX18K4] Trouble in ASR proportional pressure reducing solenoid valve (left) (Valve keeps operating)	24
Failure code [DX18KA] Disconnection in ASR proportional pressure reducing solenoid valve (left) output circuit.....	26
Failure code [DX18KB] Ground fault in ASR proportional pressure reducing solenoid valve (left) output circuit.....	28
Failure code [DX18KY] Short circuit in ASR proportional pressure reducing solenoid valve (left) output circuit.....	30
Failure code [DX18MA] Trouble in ASR proportional pressure reducing solenoid valve (left) (Valve does not operate).....	30
Failure code [DX21KA] Disconnection in ABS control valve output circuit (Front right).....	31
Failure code [DX21KB] Ground fault in ABS control valve output circuit (Front right).....	32
Failure code [DX21KY] Hot short in ABS control valve output circuit (Front right).....	33
Failure code [DX21MA] Defective ABS control valve (Front right)	34
Failure code [DX22KA] Disconnection in ABS control valve output circuit (Front left)	35
Failure code [DX22KB] Ground fault in ABS control valve output circuit (Front left).....	36
Failure code [DX22KY] Hot short in ABS control valve output circuit (Front left)	37

Failure code [DX22MA] Defective ABS control valve (Front left)	38
Failure code [DX23KA] Disconnection in ABS control valve output circuit (Rear right)	39
Failure code [DX23KB] Ground fault in ABS control valve output circuit (Rear right)	40
Failure code [DX23KY] Hot short in ABS control valve output circuit (Rear right)	41
Failure code [DX23MA] Defective ABS control valve (Rear right)	42
Failure code [DX24KA] Disconnection in ABS control valve output circuit (Rear left).....	43
Failure code [DX24KB] Ground fault in ABS control valve output circuit (Rear left)	44
Failure code [DX24KY] Hot short in ABS control valve output circuit (Rear left).....	45
Failure code [DX24MA] Defective ABS control valve (Rear left).....	46
Failure code [DX25MA] Defective ABS front wheel system control valve.....	47
Failure code [DX26MA] Defective ABS rear wheel system control valve	47
Troubleshooting by failure code, Part 9	SEN01670-03
Failure code [DXH1KA] Lockup clutch solenoid output circuit: Disconnection.....	4
Failure code [DXH1KB] Lockup clutch solenoid output circuit: Short circuit	6
Failure code [DXH1KY] Lockup clutch solenoid output circuit: Short circuit to power supply line	8
Failure code [DXH2KA] Hi clutch solenoid output circuit: Disconnection.....	10
Failure code [DXH2KB] Hi clutch solenoid output circuit: Short circuit	12
Failure code [DXH2KY] Hi clutch solenoid output circuit: Short circuit to power supply line.....	14
Failure code [DXH3KA] Lo clutch solenoid output circuit: Disconnection	18
Failure code [DXH3KB] Lo clutch solenoid output circuit: Short circuit.....	20
Failure code [DXH3KY] Lo clutch solenoid output circuit: Short circuit in power supply line	22
Failure code [DXH4KA] 1st clutch solenoid output circuit: Disconnection	26
Failure code [DXH4KB] 1st clutch solenoid output circuit: Short circuit	28
Failure code [DXH4KY] 1st clutch solenoid output circuit: Short circuit to power supply line	30
Failure code [DXH5KA] 2nd clutch solenoid output circuit: Disconnection	34
Failure code [DXH5KB] 2nd clutch solenoid output circuit: Short circuit.....	36
Failure code [DXH5KY] 2nd clutch solenoid output circuit: Short circuit in power supply line	38
Failure code [DXH6KA] 3rd clutch solenoid output circuit: Disconnection	42
Failure code [DXH6KB] 3rd clutch solenoid output circuit: Short circuit.....	44
Failure code [DXH6KY] 3rd clutch solenoid output circuit: Short circuit to power supply line.....	46
Failure code [DXH7KA] R clutch solenoid output circuit: Disconnection.....	50
Failure code [DXH7KB] R clutch solenoid output circuit: Short circuit	52
Failure code [DXH7KY] R clutch solenoid output circuit: Short circuit to power supply line	54
Failure code [DXHHKA] 4th clutch solenoid output circuit: Disconnection.....	56
Failure code [DXHHKB] 4th clutch solenoid output circuit: Short circuit	58
Failure code [DXHHKY] 4th clutch solenoid output circuit: Short circuit to power supply line	60
Failure code [F@BBZL] or VHMS_LED display: "n3"→"38" Blow-by pressure: High error.....	63
Failure code [F@BYNR] or VHMS_LED display: "n3"→"62" Exhaust gas temperature (F): Abnormal heat.....	64
Failure code [F@BYNS] or VHMS_LED display: "n3"→"61" Exhaust gas temperature (F): Overheat	66
Failure code [F@BZNR] or VHMS_LED display: "n3"→"72" Exhaust gas temperature (R): Abnormal heat.....	68
Failure code [F@BZNS] or VHMS_LED display: "n3"→"71" Exhaust gas temperature (R): Overheat	70
Troubleshooting of electrical system (E-mode)	SEN01671-03
Before troubleshooting of electric system	3
Contents of troubleshooting table.....	4
E-1 Engine does not start.....	5
E-2 Automatic preheating does not operate.....	8
E-3 Machine monitor does not display all, when starting switch is turned ON.....	12
E-4 Machine monitor does not operate when starting switch is OFF	14
E-5 Alarm buzzer does not sound.....	16

E-6 Alarm buzzer does not stop sounding	18
E-7 Gauges of machine monitor, caution lamps or character display section do not display properly.....	20
E-8 A selection of the display in character display section cannot be changed	21
E-9 Power mode selecting function does not operate properly.....	24
E-10 AISS function does not operate properly	25
E-11 Seat belt caution lamp does not display properly	26
E-12 Turn signal lamp or turning lamp (hazard lamp) do not work properly.....	27
E-13 Night illumination (lighting) does not work properly	30
E-14 Emergency steering does not operate	42
E-15 Hoist lever does not operate normally	48
E-16 Electric priming pump does not operate or does not stop automatically	50
Troubleshooting of hydraulic and mechanical system (H-mode)	SEN01672-01
Contents of troubleshooting table.....	3
H-1 Machine does not start	4
H-2 Machine does not travel smoothly (hunting).....	6
H-3 Lockup cannot be cancelled	6
H-4 Excessive shock when starting or shifting excessive	7
H-5 Transmission does not shift up	8
H-6 Machine lacks power or speed when traveling.....	10
H-7 Time lag is excessive when starting or shifting gear	14
H-8 Torque converter oil temperature is high	16
H-9 Torque converter oil pressure is low	17
H-10 Front brake is ineffective	18
H-11 Rear brake is ineffective	19
H-12 Steering wheel is heavy.....	20
H-13 Steering wheel does not work.....	21
H-14 Steering wheel vibrates	22
H-15 Dump body lifting speed is slow	23
H-16 Dump body does not work.....	24
H-17 Excessive hydraulic drift of dump body	25
Troubleshooting of engine (S-mode)	SEN01673-03
Method of using troubleshooting chart	4
S-1 Starting performance of engine is poor.....	8
S-2 Engine does not start.....	10
S-3 Engine does not pick up smoothly	14
S-4 Engine stops during operation	15
S-5 Engine does not rotate smoothly	16
S-6 Engine lack output (or lacks power).....	17
S-7 Exhaust gas is black (incomplete combustion).....	18
S-8 Oil consumption is excessive (or exhaust gas is blue)	20
S-9 Oil becomes dirty quickly	21
S-10 Fuel consumption is excessive	22
S-11 Oil is in coolant (or coolant spurts back or coolant level goes down).....	23
S-12 Oil pressure drops	24
S-13 Oil level rises (Entry of coolant or fuel)	26
S-14 Coolant temperature becomes too high (Overheating).....	28
S-15 Abnormal noise is made	29
S-16 Vibration is excessive	30
S-17 Air cannot be bled from fuel circuit	32
50 Disassembly and assembly	
General information on disassembly and assembly	SEN02483-03
How to read this manual.....	2
Coating materials list.....	4
Special tool list.....	7
Sketches of special tools.....	10

Engine and cooling system	SEN02484-03
Removal and installation of fuel supply pump assembly	2
Removal and installation of fuel injector assembly	5
Removal and installation of cylinder head assembly	9
Removal and installation of engine front seal	21
Removal and installation of engine rear seal	24
Removal and installation of engine assembly	28
Removal and installation of radiator assembly	35
Removal and installation of output shaft assembly	39
Disassembly and assembly of output shaft assembly	40
Removal and installation of brake and power train oil cooler assembly	43
Power train, Part 1	SEN02485-01
Removal and installation of torque converter and transmission assembly	2
Separation and coupling of transmission assembly and torque converter assembly	5
Disassembly and assembly of transmission assembly and torque converter assembly	6
Disassembly and assembly of torque converter assembly	8
Disassembly and assembly of transmission assembly	18
Removal and installation of transmission control valve assembly (ECMV assembly)	49
Disassembly and assembly of transmission control valve assembly (ECMV assembly)	50
Power train, Part 2	SEN02486-01
Removal and installation of differential assembly	2
Disassembly and assembly of differential assembly	4
Removal and installation of final drive carrier assembly	16
Disassembly and assembly of final drive carrier assembly	17
Disassembly and assembly of front wheel hub assembly	18
Steering system	SEN02487-01
Disassembly and assembly of steering cylinder assembly	2
Brake system	SEN02488-01
Removal and installation of front brake caliper pads	2
Removal and installation of front brake calipers assembly	3
Disassembly and assembly of front brake calipers assembly	4
Removal and installation of final drive and rear brake assembly	6
Removal and installation of final drive, rear brake, and parking brake assembly	9
Disassembly and assembly of final drive, rear brake, and parking brake assembly	10
Undercarriage and frame	SEN02489-02
Removal and installation of front wheel assembly	2
Removal and installation of rear wheel assembly	4
Removal and installation of front suspension cylinder assembly	6
Disassembly and assembly of front suspension cylinder assembly (Cylinder with buffer ring)	8
Removal and installation of rear suspension cylinder assembly	11
Disassembly and assembly of rear suspension cylinder assembly (Cylinder with buffer ring)	12
Hydraulic system	SEN02490-01
Disassembly and assembly of hoist cylinder assembly	2
Body	SEN02491-02
Removal and installation of body assembly	2
Cab and its attachments	SEN02492-03
Disassembly and assembly of operator's seat assembly	2
Removal and installation of air conditioner unit assembly	11
Electrical system	SEN02493-01
Removal and installation of engine controller assembly	2
Removal and installation of transmission controller assembly	3
Removal and installation of retarder controller assembly	4

90 Diagrams and drawings	
Hydraulic diagrams and drawings	SEN01105-03
Power train hydraulic circuit diagram	2
Steering and hoist hydraulic circuit diagram	3
Brake hydraulic circuit diagram	7
Electrical diagrams and drawings	SEN01106-08
Electrical circuit diagram inside cab (1/3)	3
Electrical circuit diagram inside cab (2/3)	5
Electrical circuit diagram inside cab (3/3)	7
Electrical circuit diagram outside cab (1/3)	9
Electrical circuit diagram outside cab (2/3)	11
Electrical circuit diagram outside cab (3/3)	13
Electrical circuit diagram for VHMS	15
Electrical circuit diagram for ASR (If equipped)	17
Air conditioner electrical circuit diagram	19
Electrical circuit diagram for auto greasing (If equipped)	21
Electrical circuit diagram of external power supply heater	22
Connectors table and arrangement drawing	23

HD465-7E0, HD605-7E0 Dump truck

Form No. SEN01083-17

© 2011 KOMATSU
All Rights Reserved
Printed in Japan 06-11

DUMP TRUCK

HD465-7E0

HD605-7E0

Machine model	Serial number
HD465-7E0	10001 – 10037
HD465-7E0	10101 and up
HD605-7E0	8001 – 8032
HD605-7E0	10101 and up

00 Index and foreword

Foreword and general information

Safety notice	2
How to read the shop manual	7
Explanation of terms for maintenance standard	9
Handling of electric equipment and hydraulic component	11
Handling of connectors newly used for engines	20
How to read electric wire code	23
Precautions when carrying out operation	26
Method of disassembling and connecting push-pull type coupler	29
Standard tightening torque table	32
Conversion table	36

Safety notice

(Rev. 2008/08)

Important safety notice

Proper service and repair are extremely important for safe machine operation. The service and repair techniques recommended by Komatsu and described in this manual are both effective and safe. Some of these techniques require the use of tools specially designed by Komatsu for the specific purpose.

To prevent injury to workers, the symbol  is used to mark safety precautions in this manual. The cautions accompanying these symbols should always be followed carefully. If any dangerous situation arises or may possibly arise, first consider safety, and take the necessary actions to deal with the situation.

1. General precautions

 **Mistakes in operation are extremely dangerous. Read the Operation and Maintenance Manual carefully before operating the machine. In addition, read this manual and understand its contents before starting the work.**

- 1) Before carrying out any greasing or repairs, read all the safety labels stuck to the machine. For the locations of the safety labels and detailed explanation of precautions, see the Operation and Maintenance Manual.
- 2) Decide a place in the repair workshop to keep tools and removed parts. Always keep the tools and parts in their correct places. Always keep the work area clean and make sure that there is no dirt, water, or oil on the floor. Smoke only in the areas provided for smoking. Never smoke while working.
- 3) When carrying out any operation, always wear safety shoes and helmet. Do not wear loose work clothes, or clothes with buttons missing.
 - Always wear safety glasses when hitting parts with a hammer.
 - Always wear safety glasses when grinding parts with a grinder, etc.
- 4) When carrying out any operation with 2 or more workers, always agree on the operating procedure before starting. Always inform your fellow workers before starting any step of the operation. Before starting work, hang UNDER REPAIR warning signs in the operator's compartment.
- 5) Only qualified workers must carry out work and operation which require license or qualification.
- 6) Keep all tools in good condition, learn the correct way to use them, and use the proper ones of them. Before starting work, thoroughly check the tools, machine, forklift, service car, etc.
- 7) If welding repairs are needed, always have a trained and experienced welder carry out the work. When carrying out welding work, always wear welding gloves, apron, shielding goggles, cap and other clothes suited for welding work.
- 8) Before starting work, warm up your body thoroughly to start work under good condition.
- 9) Avoid continuing work for long hours and take rests at proper intervals to keep your body in good condition. Take rests in specified safe places.

Safety points

1	Good arrangement
2	Correct work clothes
3	Following work standard
4	Making and checking signs
5	Prohibition of operation and handling by unlicensed workers
6	Safety check before starting work
7	Wearing protective goggles (for cleaning or grinding work)
8	Wearing shielding goggles and protectors (for welding work)
9	Good physical condition and preparation
10	Precautions against work which you are not used to or you are used to too much

2. Preparations for work

- 1) Before adding oil or making any repairs, park the machine on a hard and level ground, and apply the parking brake and block the wheels or tracks to prevent the machine from moving.
- 2) Before starting work, lower the work equipment (blade, ripper, bucket, etc.) to the ground. If this is not possible, insert the lock pin or use blocks to prevent the work equipment from falling. In addition, be sure to lock all the control levers and hang warning signs on them.
- 3) When disassembling or assembling, support the machine with blocks, jacks, or stands before starting work.
- 4) Remove all mud and oil from the steps or other places used to get on and off the machine. Always use the handrails, ladders or steps when getting on or off the machine. Never jump on or off the machine. If it is impossible to use the handrails, ladders or steps, use a stand to provide safe footing.

3. Precautions during work

- 1) Before disconnecting or removing components of the oil, water, or air circuits, first release the pressure completely from the circuit. When removing the oil filler cap, a drain plug, or an oil pressure pickup plug, loosen it slowly to prevent the oil from spurting out.
- 2) The coolant and oil in the circuits are hot when the engine is stopped, so be careful not to get scalded. Wait for the oil and coolant to cool before carrying out any work on the oil or water circuits.
- 3) Before starting work, stop the engine. When working on or around a rotating part, in particular, stop the engine. When checking the machine without stopping the engine (measuring oil pressure, revolving speed, temperature, etc.), take extreme care not to get rolled or caught in rotating parts or moving parts.
- 4) Before starting work, remove the leads from the battery. Always remove the lead from the negative (-) terminal first.
- 5) When raising a heavy component (heavier than 25 kg), use a hoist or crane. Before starting work, check that the slings (wire ropes, chains, and hooks) are free from damage. Always use slings which have ample capacity and install them to proper places. Operate the hoist or crane slowly to prevent the component from hitting any other part. Do not work with any part still raised by the hoist or crane.
- 6) When removing a cover which is under internal pressure or under pressure from a spring, always leave 2 bolts in diagonal positions. Loosen those bolts gradually and alternately to release the pressure, and then remove the cover.
- 7) When removing components, be careful not to break or damage the electrical wiring. Damaged wiring may cause electrical fires.
- 8) When removing piping, stop the fuel or oil from spilling out. If any fuel or oil drips onto the floor, wipe it up immediately. Fuel or oil on the floor can cause you to slip and can even start fires.
- 9) As a general rule, do not use gasoline to wash parts. Do not use it to clean electrical parts, in particular.
- 10) Be sure to assemble all parts again in their original places. Replace any damaged parts and parts which must not be reused with new parts. When installing hoses and wires, be sure that they will not be damaged by contact with other parts when the machine is operated.
- 11) When installing high pressure hoses, make sure that they are not twisted. Damaged tubes are dangerous, so be extremely careful when installing tubes for high pressure circuits. In addition, check that connecting parts are correctly installed.
- 12) When assembling or installing parts, always tighten them to the specified torques. When installing protective parts such as guards, or parts which vibrate violently or rotate at high speed, be particularly careful to check that they are installed correctly.
- 13) When aligning 2 holes, never insert your fingers or hand. Be careful not to get your fingers caught in a hole.
- 14) When measuring hydraulic pressure, check that the measuring tools are correctly assembled.
- 15) Take care when removing or installing the tracks of track-type machines. When removing the track, the track separates suddenly, so never let anyone stand at either end of the track.
- 16) If the engine is operated for a long time in a place which is not ventilated well, you may suffer from gas poisoning. Accordingly, open the windows and doors to ventilate well.

4. Precautions for sling work and making signs

1) Only one appointed worker must make signs and co-workers must communicate with each other frequently. The appointed sign maker must make specified signs clearly at a place where he is well seen from the operator's seat and where he can see the working condition easily. The sign maker must always stand in front of the load and guide the operator safely.

- Do not stand under the load.
- Do not step on the load.

2) Check the slings before starting sling work.

3) Keep putting on gloves during sling work. (Put on leather gloves, if available.)


4) Measure the weight of the load by the eye and check its center of gravity.

5) Use proper sling according to the weight of the load and method of slinging. If too thick wire ropes are used to sling a light load, the load may slip and fall.

6) Do not sling a load with 1 wire rope alone. If it is slung so, it may rotate and may slip out of the rope. Install 2 or more wire ropes symmetrically.

⚠ Slinging with 1 rope may cause turning of the load during hoisting, untwisting of the rope, or slipping of the rope from its original winding position on the load, which can result in a dangerous accident.

7) Limit the hanging angle to 60°, as a rule. Do not sling a heavy load with ropes forming a wide hanging angle from the hook. When hoisting a load with 2 or more ropes, the force subjected to each rope will increase with the hanging angle. The table below shows the variation of allowable load in kN {kg} when hoisting is made with 2 ropes, each of which is allowed to sling up to 9.8 kN {1,000 kg} vertically, at various hanging angles. When the 2 ropes sling a load vertically, up to 19.6 kN {2,000 kg} of total weight can be suspended. This weight is reduced to 9.8 kN {1,000 kg} when the 2 ropes make a hanging angle of 120°. If the 2 ropes sling a 19.6 kN {2,000 kg} load at a lifting angle of 150°, each of them is subjected to a force as large as 39.2 kN {4,000 kg}.




8) When installing wire ropes to an angular load, apply pads to protect the wire ropes. If the load is slippery, apply proper material to prevent the wire rope from slipping.

9) Use the specified eyebolts and fix wire ropes, chains, etc. to them with shackles, etc.

10) Apply wire ropes to the middle portion of the hook.

- Slinging near the tip of the hook may cause the rope to slip off the hook during hoisting. The hook has the maximum strength at the middle portion.



11) Do not use twisted or kinked wire ropes.

12) When lifting up a load, observe the following.

- Wind in the crane slowly until wire ropes are stretched. When settling the wire ropes with the hand, do not grasp them but press them from above. If you grasp them, your fingers may be caught.
- After the wire ropes are stretched, stop the crane and check the condition of the slung load, wire ropes, and pads.

- If the load is unstable or the wire rope or chains are twisted, lower the load and lift it up again.
 - Do not lift up the load slantingly.
- 13) When lifting down a load, observe the following.
- When lifting down a load, stop it temporarily at 30 cm above the floor, and then lower it slowly.
 - Check that the load is stable, and then remove the sling.
 - Remove kinks and dirt from the wire ropes and chains used for the sling work, and put them in the specified place.

5. Precautions for using mobile crane

- ★ Read the Operation and Maintenance Manual of the crane carefully in advance and operate the crane safely.

6. Precautions for using overhead hoist crane

▲ When raising a heavy part (heavier than 25 kg), use a hoist, etc. In Disassembly and assembly, the weight of a part heavier than 25 kg is indicated after the mark of .

- 1) Before starting work, inspect the wire ropes, brake, clutch, controller, rails, over wind stop device, electric shock prevention earth leakage breaker, crane collision prevention device, and power application warning lamp, and check safety.
- 2) Observe the signs for sling work.
- 3) Operate the hoist at a safe place.
- 4) Check the direction indicator plates (east, west, south, and north) and the directions of the control buttons without fail.
- 5) Do not sling a load slantingly. Do not move the crane while the slung load is swinging.
- 6) Do not raise or lower a load while the crane is moving longitudinally or laterally.
- 7) Do not drag a sling.
- 8) When lifting up a load, stop it just after it leaves the ground and check safety, and then lift it up.
- 9) Consider the travel route in advance and lift up a load to a safe height.
- 10) Place the control switch on a position where it will not be an obstacle to work and passage.
- 11) After operating the hoist, do not swing the control switch.
- 12) Remember the position of the main switch so that you can turn off the power immediately in an emergency.

- 13) If the hoist stops because of a power failure, turn the power switch OFF. When turning on a switch which was turned OFF by the electric shock prevention earth leakage breaker, check that the devices related to that switch are not in operation state.
- 14) If you find an obstacle around the hoist, stop the operation.
- 15) After finishing the work, stop the hoist at the specified position and raise the hook to at least 2 m above the floor. Do not leave the sling installed to the hook.

7. Selecting wire ropes

- 1) Select adequate ropes depending on the weight of parts to be hoisted, referring to the table below.

Wire ropes
(Standard "Z" twist ropes without galvanizing)
(JIS G3525, No. 6, Type 6X37-A)

Nominal diameter of rope mm	Allowable load	
	kN	ton
10	8.8	0.9
12	12.7	1.3
14	17.3	1.7
16	22.6	2.3
18	28.6	2.9
20	35.3	3.6
25	55.3	5.6
30	79.6	8.1
40	141.6	14.4
50	221.6	22.6
60	318.3	32.4

- ★ The allowable load is one-sixth of the breaking strength of the rope used (Safety coefficient: 6).

8. Precautions for disconnecting and connecting hoses and tubes in air conditioner circuit

1) Disconnection

⚠ For the environment, the air conditioner of this machine uses the refrigerant (air conditioner gas: R134a) which has fewer factors of the depletion of the ozone layer. However, it does not mean that you may discharge the refrigerant into the atmosphere as it is. Be sure to recover the refrigerant when disconnecting the refrigerant gas circuit and then reuse it.

★ Ask professional traders for collecting and filling operation of refrigerant (R134a).


★ Never release the refrigerant (R134a) to the atmosphere.

⚠ If the refrigerant gas gets in your eyes or contacts your skin, you may lose your sight and your skin may be frozen. Accordingly, put on safety glasses, safety gloves and safety clothes when recovering or adding the refrigerant. Refrigerant gas must be recovered and added by a qualified person.

2) Connection

- 1] When installing the air conditioner circuit hoses and tubes, take care that dirt, dust, water, etc. will not enter them.
- 2] When connecting the air conditioner hoses and tubes, check that O-rings (1) are fitted to their joints.
- 3] Check that each O-ring is not damaged or deteriorated.
- 4] When connecting the refrigerant piping, apply compressor oil for refrigerant (R134a) (**DENSO: ND-OIL8, VALEO THERMAL SYSTEMS: ZXL100PG (equivalent to PAG46)**) to its O-rings.

★ Example of O-ring (Fitted to every joint of hoses and tubes)



★ For tightening torque, see the precautions for installation in each section of "Disassembly and assembly".

How to read the shop manual

- Some attachments and optional parts in this shop manual may not be delivered to certain areas. If one of them is required, consult KOMATSU distributors.
- Materials and specifications are subject to change without notice.
- Shop manuals are divided into the “Chassis volume” and “Engine volume”. For the engine unit, see the engine volume of the engine model mounted on the machine.

1. Composition of shop manual

This shop manual contains the necessary technical information for services performed in a workshop. For ease of understanding, the manual is divided into the following sections.

00. Index and foreword

This section explains the shop manuals list, table of contents, safety, and basic information.

01. Specification

This section explains the specifications of the machine.

10. Structure, function and maintenance standard

This section explains the structure, function, and maintenance standard values of each component. The structure and function sub-section explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting. The maintenance standard sub-section explains the criteria and remedies for disassembly and service.

20. Standard value table

This section explains the standard values for new machine and judgement criteria for testing, adjusting, and troubleshooting. This standard value table is used to check the standard values in testing and adjusting and to judge parts in troubleshooting.

30. Testing and adjusting

This section explains measuring instruments and measuring methods for testing and adjusting, and method of adjusting each part. The standard values and judgement criteria for testing and adjusting are explained in Testing and adjusting.

40. Troubleshooting

This section explains how to find out failed parts and how to repair them. The troubleshooting is divided by failure modes. The “S mode” of the troubleshooting related to the engine may be also explained in the Chassis volume and Engine volume. In this case, see the Chassis volume.

50. Disassembly and assembly

This section explains the special tools and procedures for removing, installing, disassembling, and assembling each component, as well as precautions for them. In addition, tightening torque and quantity and weight of coating material, oil, grease, and coolant necessary for the work are also explained.

90. Diagrams and drawings (chassis volume)/Repair and replacement of parts (engine volume)

- Chassis volume
This section gives hydraulic circuit diagrams and electrical circuit diagrams.
- Engine volume
This section explains the method of reproducing, repairing, and replacing parts.

2. Revision and distribution

Any additions, revisions, or other change of notices will be sent to KOMATSU distributors. Get the most up-to-date information before you start any work.

3. Filing method

File by the brochures in the correct order of the form number printed in the shop manual composition table.

- **Revised edition mark**

When a manual is revised, the ones and tens digits of the form number of each brochure is increased by 1. (Example: 00, 01, 02 ...)

- **Revisions**

Revised brochures are shown in the shop manual composition table.

4. Symbols

Important safety and quality portions are marked with the following symbols so that the shop manual will be used practically.

Symbol	Item	Remarks
	Safety	Special safety precautions are necessary when performing work.
	Caution	Special technical precautions or other precautions for preserving standards are necessary when performing work.
	Weight	Weight of parts of component or parts. Caution necessary when selecting hoisting wire, or when working posture is important, etc.
	Tightening torque	Places that require special attention for tightening torque during assembly.
	Coat	Places to be coated with adhesives, etc. during assembly.
	Oil, coolant	Places where oil, etc. must be added, and capacity.
	Drain	Places where oil, etc. must be drained, and quantity to be drained.

5. Units

In this shop manual, the units are indicated with International System of units (SI). For reference, conventionally used Gravitational System of units is indicated in parentheses { }.

Explanation of terms for maintenance standard

The maintenance standard chapter explains the criteria for replacing or reusing products and parts in the machine maintenance work. The following terms are used to explain the criteria.

1. Standard size and tolerance

- To be accurate, the finishing size of parts is a little different from one to another.
- To specify a finishing size of a part, a temporary standard size is set and an allowable difference from that size is indicated.
- The above size set temporarily is called the “standard size” and the range of difference from the standard size is called the “tolerance”.
- The tolerance with the symbols of + or – is indicated on the right side of the standard size.


Example:

Standard size	Tolerance
120	–0.022 –0.126

- ★ The tolerance may be indicated in the text and a table as [standard size (upper limit of tolerance/lower limit of tolerance)].
Example) 120 (–0.022/–0.126)
- Usually, the size of a hole and the size of the shaft to be fitted to that hole are indicated by the same standard size and different tolerances of the hole and shaft. The tightness of fit is decided by the tolerance.
- Indication of size of rotating shaft and hole and relationship drawing of them

Example:

Standard size	Tolerance	
	Shaft	Hole
60	–0.030 –0.076	+0.046 0



2. Standard clearance and standard value

- The clearance made when new parts are assembled is called the “standard clearance”, which is indicated by the range from the minimum clearance to the maximum clearance.
- When some parts are repaired, the clearance is generally adjusted to the standard clearance.
- A value of performance and function of new products or equivalent is called the “standard value”, which is indicated by a range or a target value.
- When some parts are repaired, the value of performance/function is set to the standard value.

3. Standard interference

- When the diameter of a hole of a part shown in the given standard size and tolerance table is smaller than that of the mating shaft, the difference between those diameters is called the “interference”.
- The range (A – B) from the difference (A) between the minimum size of the shaft and the maximum size of the hole to the difference (B) between the maximum size of the shaft and the minimum size of the hole is the “standard interference”.
- After repairing or replacing some parts, measure the size of their hole and shaft and check that the interference is in the standard range.

4. Repair limit and allowable value or allowable dimension

- The size of a part changes because of wear and deformation while it is used. The limit of changed size is called the “repair limit”.
- If a part is worn to the repair limit, it must be replaced or repaired.
- The performance and function of a product lowers while it is used. A value which the product can be used without causing a problem is called the “allowable value” or “allowable dimension”.
- If a product is worn to the allowable value, it must be checked or repaired. Since the permissible value is estimated from various tests or experiences in most cases, however, it must be judged after considering the operating condition and customer's requirement.

5. Clearance limit

- Parts can be used until the clearance between them is increased to a certain limit. The limit at which those parts cannot be used is called the “clearance limit”.
- If the clearance between the parts exceeds the clearance limit, they must be replaced or repaired.

6. Interference limit

- The allowable maximum interference between the hole of a part and the shaft of another part to be assembled is called the “interference limit”.
- The interference limit shows the repair limit of the part of smaller tolerance.
- If the interference between the parts exceeds the interference limit, they must be replaced or repaired.

Handling of electric equipment and hydraulic component


To maintain the performance of the machine over a long period, and to prevent failures or other troubles before they occur, correct “operation“, “maintenance and inspection“, “troubleshooting“, and “repairs” must be carried out. This section deals particularly with correct repair procedures for mechatronics and is aimed at improving the quality of repairs. For this purpose, it gives sections on “Handling electric equipment” and “Handling hydraulic equipment” (particularly gear oil and hydraulic oil).

Points to remember when handling electric equipment

1. Handling wiring harnesses and connectors

Wiring harnesses consist of wiring connecting one component to another component, connectors used for connecting and disconnecting one wire from another wire, and protectors or tubes used for protecting the wiring.


Compared with other electrical components fitted in boxes or cases, wiring harnesses are more likely to be affected by the direct effects of rain, water, heat, or vibration. Furthermore, during inspection and repair operations, they are frequently removed and installed again, so they are likely to suffer deformation or damage. For this reason, it is necessary to be extremely careful when handling wiring harnesses.



2. Main failures occurring in wiring harness

1) Defective contact of connectors (defective contact between male and female)

Problems with defective contact are likely to occur because the male connector is not properly inserted into the female connector, or because one or both of the connectors is deformed or the position is not correctly aligned, or because there is corrosion or oxidization of the contact surfaces. The corroded or oxidized contact surfaces may become shiny again (and contact may become normal) by connecting and disconnecting the connector about 10 times.



2) Defective crimping or soldering of connectors

The pins of the male and female connectors are in contact at the crimped terminal or soldered portion, but if there is excessive force brought to bear on the wiring, the plating at the joint will peel and cause improper connection or breakage.

