

# SHOP MANUAL

# KOMATSU D155AX-5

MACHINE MODEL      SERIAL NUMBER

**D155AX-5**                      **70001 and up**

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- D155AX-5 mounts the SA6D140E-2 or SA6D140E-3 engine.  
For details of the engine, see the 6D140-2 or 140-3 Series Engine Shop Manual.

# CONTENTS

	No. of page
<b>01 GENERAL .....</b>	<b>01-1</b>
<b>10 STRUCTURE AND FUNCTION .....</b>	<b>10-1</b>
<b>20 TESTING AND ADJUSTING .....</b>	<b>20-1</b>
<b>30 DISASSEMBLY AND ASSEMBLY .....</b>	<b>30-1</b>
<b>40 MAINTENANCE STANDARD .....</b>	<b>40-1</b>
<b>90 OTHERS .....</b>	<b>90-1</b>

The affected pages are indicated by the use of the following marks. It is requested that necessary actions must be taken to these pages according to the list below.

Mark	Indication	Action required
○	Page to be newly added	Add
●	Page to be replaced	Replace
( )	Page to be deleted	Discard

Pages having no marks are not revised at this time.

### LIST OF REVISED PAGES

Mark	Pages	Revision number	Mark	Pages	Revision number	Mark	Pages	Revision number	Mark	Pages	Revision number	Mark	Pages	Revision number
●	00- 1	④		10- 5	③		10-52			10- 96			10-140	
	00- 2	①		10- 6	③		10-53			10- 97			10-141	
●	00- 2-1	④		10- 7			10-54	③		10- 98			10-142	
●	00- 2-2	④		10- 8	③		10-56			10- 99			10-143	
●	00- 2-3	④		10- 9	③		10-57			10-100			10-144	
●	00- 2-4	④		10-10	③		10-58	③		10-101			10-145	
○	00- 2-5	④		10-11			10-59			10-102			10-146	
	00- 3			10-12			10-60	③		10-103			10-147	
	00- 4			10-13			10-61			10-104			10-148	
	00- 5			10-14			10-62			10-105	③		10-149	
	00- 6			10-15			10-63			10-106	③		10-150	
	00- 7			10-16	③		10-64			10-107			10-151	
	00- 8			10-17			10-65			10-108			10-152	
	00- 9			10-19			10-66	③		10-109			10-153	
	00-10			10-20			10-67			10-110			10-154	
	00-11			10-21			10-68			10-111			10-156	
	00-12			10-22			10-69	③		10-112			10-157	
	00-13			10-24			10-70			10-113			10-158	
	00-14			10-25			10-71	③		10-114			10-159	
	00-15			10-26			10-72			10-116			10-160	
	00-16			10-27			10-73			10-117			10-161	
	00-17			10-28			10-74			10-118			10-162	
	00-18			10-29			10-75			10-119			10-163	
	00-19			10-30			10-76			10-120			10-164	
	00-20			10-31			10-77			10-121	③		10-165	
	00-21			10-32			10-78			10-122			10-166	
	01- 1			10-34			10-79			10-124			10-167	
	01- 2			10-35			10-80			10-125			10-168	
	01- 3			10-36			10-81			10-126			10-169	
	01- 4	③		10-37			10-82			10-127			10-170	
	01- 5	③		10-38			10-83			10-128			10-171	
	01- 6	③		10-39			10-84			10-129			10-172	
	01- 7	③		10-40			10-85	③		10-130			10-173	
	01- 8	③		10-41			10-86			10-131			10-174	
	01- 9	③		10-42			10-87			10-132			10-175	
	01-10	③		10-43			10-88			10-133			10-176	
	01-11	③		10-44			10-89			10-134			10-177	
	01-12	③		10-46			10-91			10-135			10-178	
	10- 1			10-47			10-92			10-136			10-179	
	10- 2	③		10-48			10-93	③		10-137			10-180	
	10- 3	③		10-49			10-94			10-138			10-181	
	10- 4	③		10-50	③		10-95			10-139			10-182	

Mark	Pages	Revision number	Mark	Pages	Revision number	Mark	Pages	Revision number	Mark	Pages	Revision number	Mark	Pages	Revision number
	10-183			20- 9			20-126		○	20-219-1	④	○	20-258	④
	10-184			20- 10			20-127		○	20-219-2	④	○	20-259	④
	10-185			20- 11			20-128		○	20-219-3	④	○	20-260	④
	10-186	③		20- 12			20-129		○	20-219-4	④	○	20-261	④
	10-187			20- 13			20-130		○	20-219-5	④	○	20-262	④
	10-188			20- 14			20-131		○	20-219-6	④	●	20-301	④
	10-189			20- 15			20-132			20-220			20-302	
	10-189-1	③	○	20- 16	④		20-133			20-221			20-303	
	10-189-2	③	○	20- 17	④		20-134			20-222			20-304	
	10-189-3	③	○	20- 18	④	●	20-135	④		20-223			20-305	
	10-189-4	③	○	20- 19	④	●	20-136	④		20-224			20-306	
	10-190		○	20- 20	④		20-137			20-225			20-307	
	10-191		○	20- 21	④		20-138			20-226			20-308	
	10-192		○	20- 22	④	○	20-138-1	④		20-227			20-309	
	10-193	③	●	20-101	④	○	20-138-2	④		20-228			20-310	
	10-193-1	③	●	20-102	④	○	20-138-3	④		20-229			20-311	
	10-194	③	●	20-103	④	●	20-139	④	○	20-229-1	④		20-312	
	10-195	③	○	20-103-1	④		20-140		○	20-229-2	④		20-313	
	10-196	③	○	20-103-2	④	○	20-140-1	④	○	20-229-3	④		20-314	
	10-196-1	③	●	20-104	④	○	20-140-2	④	○	20-229-4	④		20-315	
	10-196-2	③	○	20-104-1	④	○	20-140-3	④	○	20-229-5	④		20-316	
	10-196-3	③	●	20-105	④	○	20-140-4	④	○	20-229-6	④		20-317	
	10-197		○	20-105-1	④		20-141		○	20-229-7	④		20-318	
	10-198		●	20-106	④		20-142		○	20-229-8	④		20-319	
	10-199		●	20-107	④		20-143		○	20-229-9	④		20-320	
	10-200		○	20-107-1	④		20-144		●	20-230	④		20-321	
	10-201	③	●	20-108	④		20-145			20-231			20-322	
	10-202		●	20-109	④	●	20-146	④	○	20-231-1	④	●	20-401	④
	10-203	③	○	20-109-1	④		20-147		○	20-231-2	④		20-402	
	10-203-1	③	●	20-110	④		20-148		●	20-232	④		20-403	
	10-204	③	○	20-110-1	④		20-149			20-233			20-404	
	10-205	③	●	20-111	④		20-150			20-234			20-405	
	10-205-1	③	○	20-111-1	④		20-151			20-235			20-406	
	10-205-2	③	○	20-111-2	④		20-152		○	20-235-1	④		20-407	
	10-206		○	20-111-3	④		20-153		○	20-235-2	④		20-408	
	10-207		○	20-111-4	④		20-154		○	20-235-3	④		20-409	
	10-208		○	20-111-5	④		20-155		○	20-235-4	④		20-410	
	10-209		○	20-111-6	④		20-156		○	20-235-5	④		20-411	
	10-210	③	●	20-112	④		20-157		○	20-235-6	④		20-412	
	10-211	③	○	20-112-1	④	●	20-201	④	○	20-235-7	④		20-413	
	10-211-1	③	○	20-112-2	④		20-202		○	20-235-8	④		20-414	
	10-212	③		20-113			20-203		○	20-235-9	④		20-415	
	10-213	③	○	20-113-1	④		20-204		○	20-235-10	④		20-416	
	10-214	③	●	20-114	④		20-205		○	20-235-11	④		20-417	
	10-215	③	●	20-115	④		20-206		○	20-235-12	④		20-418	
	10-215-1	③	●	20-116	④		20-207			20-236			20-419	
	10-216		●	20-117	④		20-208		●	20-238	④		20-420	
	10-217		○	20-117-1	④		20-209		●	20-239	④		20-421	
	20- 1		●	20-118	④		20-210		●	20-240	④		20-422	
●	20- 2	④	○	20-118-1	④		20-211			20-241			20-423	
○	20- 2-1	④		20-119			20-212		○	20-251	④		20-424	
●	20- 3	④		20-120		●	20-214	④	○	20-252	④		20-425	
	20- 4			20-121			20-215		○	20-253	④		20-426	
	20- 5			20-122			20-216		○	20-254	④		20-427	
	20- 6			20-123			20-217		○	20-255	④		20-428	
	20- 7			20-124			20-218		○	20-256	④		20-429	
●	20- 8	④		20-125			20-219		○	20-257	④		20-430	

Mark	Pages	Revision number												
	20-431			20-620		○	20-742	④	○	20-902	④		30- 8	①
	20-432			20-621		○	20-743	④	○	20-903	④		30- 9	①
	20-433			20-622		○	20-744	④	○	20-904	④		30- 10	①
	20-434			20-623		○	20-745	④	○	20-905	④		30- 11	①
	20-435			20-624		○	20-746	④	○	20-906	④		30- 12	②
	20-436			20-625		○	20-801	④	○	20-907	④		30- 13	②
	20-437			20-626		○	20-802	④	○	20-908	④		30- 14	②
	20-438			20-627		○	20-803	④	○	20-909	④		30- 15	②
	20-439			20-628		○	20-804	④	○	20-910	④		30- 16	②
	20-440			20-629		○	20-805	④	○	20-911	④		30- 17	①
	20-441			20-630		○	20-806	④	○	20-912	④		30- 18	①
	20-442			20-632		○	20-807	④	○	20-913	④		30- 19	①
	20-443			20-633		○	20-808	④	○	20-914	④		30- 20	①
	20-444			20-634		○	20-809	④	○	20-915	④		30- 21	①
	20-445			20-635		○	20-810	④	○	20-916	④		30- 22	①
	20-446			20-636		○	20-811	④	○	20-917	④		30- 23	①
	20-447		○	20-701	④	○	20-812	④	○	20-918	④		30- 24	①
	20-448		○	20-702	④	○	20-813	④	○	20-919	④		30- 25	①
	20-501		○	20-703	④	○	20-814	④	○	20-920	④		30- 26	①
	20-502		○	20-704	④	○	20-815	④	○	20-921	④		30- 27	①
	20-503		○	20-705	④	○	20-816	④	○	20-922	④		30- 28	①
	20-504		○	20-706	④	○	20-817	④	○	20-923	④		30- 29	①
	20-505		○	20-707	④	○	20-818	④	○	20-924	④		30- 30	①
	20-506		○	20-708	④	○	20-819	④	○	20-925	④		30- 31	①
	20-507		○	20-709	④	○	20-820	④	○	20-926	④		30- 32	①
	20-508		○	20-710	④	○	20-821	④	○	20-927	④		30- 33	①
	20-509		○	20-711	④	○	20-822	④	○	20-928	④		30- 34	①
	20-510		○	20-712	④	○	20-823	④	○	20-929	④		30- 35	①
	20-511		○	20-713	④	○	20-824	④	○	20-930	④		30- 36	①
	20-512		○	20-714	④	○	20-825	④	○	20-931	④		30- 37	①
	20-513		○	20-715	④	○	20-826	④	○	20-932	④		30- 38	①
	20-514		○	20-716	④	○	20-827	④	○	20-933	④		30- 39	①
	20-515		○	20-717	④	○	20-828	④	○	20-934	④		30- 40	①
	20-516		○	20-718	④	○	20-829	④	○	20-935	④		30- 41	①
	20-517		○	20-719	④	○	20-830	④	○	20-936	④		30- 42	①
	20-518		○	20-720	④	○	20-831	④	○	20-937	④		30- 43	①
	20-519		○	20-721	④	○	20-832	④	○	20-938	④		30- 44	①
	20-520		○	20-722	④	○	20-833	④	○	20-939	④		30- 45	①
●	20-601	④	○	20-723	④	○	20-834	④	○	20-940	④		30- 46	①
	20-602		○	20-724	④	○	20-835	④	○	20-941	④		30- 47	①
	20-603		○	20-725	④	○	20-836	④	○	20-942	④		30- 48	①
	20-604		○	20-726	④	○	20-837	④	○	20-943	④		30- 49	①
	20-605		○	20-727	④	○	20-838	④	○	20-944	④		30- 50	①
	20-606		○	20-728	④	○	20-839	④	○	20-945	④		30- 51	①
	20-607		○	20-729	④	○	20-840	④	○	20-946	④		30- 52	①
	20-608		○	20-730	④	○	20-841	④	○	20-947	④		30- 53	①
	20-609		○	20-731	④	○	20-842	④	○	20-948	④		30- 54	①
	20-610		○	20-732	④	○	20-843	④	○	20-949	④		30- 55	①
	20-611		○	20-733	④	○	20-844	④	○	20-950	④		30- 56	①
	20-612		○	20-734	④	○	20-845	④	○	20-951	④		30- 57	①
	20-613		○	20-735	④	○	20-846	④		30- 1	②		30- 58	①
	20-614		○	20-736	④	○	20-847	④		30- 2	①		30- 59	①
	20-615		○	20-737	④	○	20-848	④		30- 3	①		30- 60	①
	20-616		○	20-738	④	○	20-849	④		30- 4	①		30- 61	①
	20-617		○	20-739	④	○	20-850	④		30- 5	①		30- 62	①
	20-618		○	20-740	④	○	20-851	④		30- 6	①		30- 63	①
	20-619		○	20-741	④	○	20-901	④		30- 7	①		30- 64	①

Mark	Pages	Revision number	Mark	Pages	Revision number	Mark	Pages	Revision number	Mark	Pages	Revision number	Mark	Pages	Revision number
30- 65		①	30-122		①	30-162		①	30-220		①	30-277		①
30- 66		①	30-123		①	30-163		①	30-221		①	30-278		①
30- 67		①	30-124		①	30-164		①	30-222		①	30-279		①
30- 68		①	30-125		①	30-165		①	30-223		①	30-280		①
30- 69		①	30-126		①	30-166		①	30-224		①	30-281		①
30- 70		①	30-127		①	30-167		①	30-225		①	30-282		①
30- 71		①	30-128		①	30-168		①	30-226		①	30-283		①
30- 72		①	30-129		①	30-169		①	30-227		①	30-284		①
30- 73		①	30-130		①	30-170		①	30-228		①	30-285		①
30- 74		①	30-131		①	30-171		①	30-229		①	30-286		①
30- 75		①	30-132		①	30-172		①	30-230		①	30-287		①
30- 76		①	30-133		①	30-173		①	30-231		①	30-288		①
30- 77		①	30-134		①	30-174		①	30-232		①	30-289		①
30- 78		①	30-135		①	30-175		①	30-233		①	30-290		①
30- 79		①	30-136		①	30-176		①	30-234		①	30-291		①
30- 80		①	30-137		①	30-177		①	30-235		①	30-292		①
30- 81		①	30-138		①	30-178		①	30-236		①	30-293		①
30- 82		①	30-139		①	30-179		①	30-237		①	30-294		①
30- 83		①	30-140		①	30-180		①	30-238		①	30-295		①
30- 84		①	30-141		①	30-181		①	30-239		①	30-296		①
30- 85		①	30-142		①	30-182		①	30-240		①	30-297		①
30- 86		①	30-143		①	30-183		①	30-241		①	30-298		①
30- 87		①	30-144		①	30-184		①	30-242		①	30-299		①
30- 88		①	30-145		①	30-185		①	30-243		①	30-300		①
30- 89		①	30-146		①	30-186		①	30-244		①	30-301		①
30- 90		①	30-146-1		②	30-187		①	30-245		①	30-302		①
30- 91		①	30-146-2		②	30-188		①	30-246		①	30-303		①
30- 92		①	30-146-3		②	30-189		①	30-247		①	30-304		①
30- 93		①	30-146-4		②	30-190		①	30-248		①	30-305		①
30- 94		①	30-146-5		②	30-191		①	30-249		①	30-306		①
30- 95		①	30-146-6		②	30-192		①	30-250		①	30-307		①
30- 96		①	30-146-7		②	30-193		①	30-251		①	30-308		①
30- 97		①	30-146-8		②	30-194		①	30-252		①	40- 1		③
30- 98		①	30-146-9		②	30-195		①	30-253		①	40- 2		
30- 99		①	30-146-10		②	30-196		①	30-254		①	40- 3		
30-100		①	30-146-11		②	30-197		①	30-255		①	40- 4		
30-101		①	30-146-12		②	30-198		①	30-256		①	40- 6		
30-102		①	30-146-13		②	30-199		①	30-257		①	40- 7		
30-103		①	30-146-14		②	30-200		①	30-258		①	40- 8		
30-104		①	30-146-15		②	30-201		①	30-259		①	40- 10		
30-105		①	30-146-16		②	30-202		①	30-260		①	40- 11		
30-106		①	30-146-17		②	30-203		①	30-261		①	40- 12		
30-107		①	30-147		①	30-204		①	30-262		①	40- 13		
30-108		①	30-148		①	30-205		①	30-263		①	40- 14		
30-109		①	30-149		①	30-207		①	30-264		①	40- 16		③
30-110		①	30-150		①	30-208		①	30-265		①	40- 17		
30-111		①	30-151		①	30-209		①	30-266		①	40- 18		
30-112		①	30-152		①	30-210		①	30-267		①	40- 19		
30-113		①	30-153		①	30-211		①	30-268		①	40- 20		
30-114		①	30-154		①	30-212		①	30-269		①	40- 21		
30-115		①	30-155		①	30-213		①	30-270		①	40- 22		
30-116		①	30-156		①	30-214		①	30-271		①	40- 24		
30-117		①	30-157		①	30-215		①	30-272		①	40- 25		
30-118		①	30-158		①	30-216		①	30-273		①	40- 26		
30-119		①	30-159		①	30-217		①	30-274		①	40- 28		③
30-120		①	30-160		①	30-218		①	30-275		①	40- 29		③
30-121		①	30-161		①	30-219		①	30-276		①	40- 29-1		③

Mark	Pages	Revision number	Mark	Pages	Revision number	Mark	Pages	Revision number	Mark	Pages	Revision number	Mark	Pages	Revision number
	40-29-2	③												
	40-30													
	40-31													
	40-32													
	40-33													
	40-34													
	40-35													
	40-36													
	40-37													
	40-38	③												
	40-39													
	40-40	③												
	40-42	③												
	40-43													
	40-44	③												
	40-46	③												
	40-47													
	40-48	③												
	40-49													
	40-50													
	40-51													
	40-52													
	40-53													
	40-54													
	40-56													
	40-57													
	40-58													
	40-59													
	40-60													
	40-61													
	40-62													
	40-63													
	40-64													
	40-66													
	40-67													
	40-68													
	40-69													
	40-70													
	40-71													
	40-72													
	40-73	③												
	40-74													
	40-75	③												
	40-76													
	40-78													
	40-79													
	90- 1	③												
	90- 3													
	90- 5													
	90- 7	③												
	90- 9	③												
	90-11	③												
	90-13	③												
	90-15	③												
	90-17	③												
	90-19	③												



---

# 20 TESTING AND ADJUSTING

---

## STANDARD VALUE TABLES

Standard value table for engine .....	20- 2
Standard value table for chassis .....	20- 3
Standard value table for electrical parts .....	20- 8
TESTING AND ADJUSTING .....	20-101
TROUBLESHOOTING .....	20-201

★ The following precautions are necessary, when using the standard value tables for testing and adjusting, or for troubleshooting .

1. The values in the table are for new machines, and are obtained from reference to values when shipping from the factory. Therefore, they should be used as target values for judging the progress of wear, or when repairing the machine.
2. The standard values for judging failures are based on the results of various tests when shipping the machine from the factory. These values should be used as reference together with the repair condition and operating record of the machine to make judgements on failures.
3. The values in the table should not be used for judging claims.

 **When carrying out testing, adjusting, or troubleshooting, stop the machine on level ground, install the safety pins and block the tracks.**

 **When carrying out work together with other workers, use agreed signals and do not allow unauthorized persons near the machine.**

 **When checking the water level, always wait for the water to cool down. If the radiator cap is removed when the water is still hot, the water will spurt out and cause burns.**

 **Be careful not to get caught in the fan or other rotating parts.**

## STANDARD VALUE TABLE FOR ENGINE

Serial No. 70001 – 75000

Machine model			D155AX-5	
Engine			SA6D140E-2	
Item	Measurement conditions	Unit	Standard value for new machine	Service limit value
Engine speed	High idling	rpm	2,050 ± 50	—
	Low idling		700 $^{+25}_0$	—
	Rated speed		1,900	—
Air supply pressure	At rated output	kPa {mmHg}	Min. 85.3 {Min. 640}	67.9 {510}
Exhaust temperature	Whole speed range (Ambient temperature: 20°C)	°C	Max. 680	700
Exhaust gas color	At sudden acceleration	Bosch index	Max. 6.0	8.0
	At high idling		Max. 1.0	2.0
Valve clearance (at normal temperature)	Intake valve	mm	0.43	—
	Exhaust valve		0.80	—
Compression pressure (SAE15W-40 or SAE30)	Oil temperature: 40 – 60°C (Engine speed)	MPa {kg/cm <sup>2</sup> } (rpm)	Min. 3.14 {Min.32} (200 – 250)	2.16 {22} (200 – 250)
Blow-by pressure (SAE15W-40 or SAE30)	At rated output (Water temperature: Operating range)	kPa {mmH <sub>2</sub> O}	Max. 0.98 {Max. 100}	1.96 {200}
Oil pressure (Oil temperature: Min. 80°C)	At high idling SAE15W-40 or SAE30 SAE10W	MPa {kg/cm <sup>2</sup> }	0.29 – 0.49 {3.0 – 5.0} 0.25 – 0.44 {2.5 – 4.5}	0.20 {2.0} 0.18 {1.8}
	At low idling SAE15W-40 or SAE30 SAE10W		Min. 0.1 {Min. 1.0} Min. 0.1 {Min. 1.0}	0.07 {0.7} 0.07 {0.7}
Oil temperature	Whole speed range (inside oil pan)	°C	80 – 110	120
Fuel injection timing	Before top dead center	°	15 ± 0.5	15 ± 0.5
Alternator belt tension	Deflection when pressed with finger force of approx. 59 N {6 kg}	mm	15	15
Air conditioner compressor belt tension			10	10

## Serial No. 75001 and up

Machine model			D155AX-5	
Engine			SA6D140E-3	
Item	Measurement conditions	Unit	Standard value for new machine	Service limit value
Engine speed	High idling	rpm	2,100 ± 50	—
	Low idling		740 <sup>+25</sup> <sub>0</sub>	—
	Rated speed		1,900	—
Air supply pressure	At rated output	kPa {mmHg}	Min. 85.3 {Min. 640}	67.9 {510}
Exhaust temperature	Whole speed range (Ambient temperature: 20°C)	°C	Max. 680	700
Exhaust gas color	At sudden acceleration	Bosch index	Max. 4.0	8.0
	At high idling		Max. 1.0	2.0
Valve clearance (at normal temperature)	Intake valve	mm	0.43	—
	Exhaust valve		0.80	—
Compression pressure (SAE15W-40 or SAE30)	Oil temperature: 40 – 60°C (Engine speed)	MPa {kg/cm <sup>2</sup> } (rpm)	Min. 3.14 {Min.32} (200 – 250)	2.16 {22} (200 – 250)
Blow-by pressure (SAE15W-40 or SAE30)	At rated output (Water temperature: Operating range)	kPa {mmH <sub>2</sub> O}	Max. 0.98 {Max. 100}	1.96 {200}
Oil pressure (Oil temperature: Min. 80°C)	At high idling SAE15W-40 or SAE30 SAE10W	MPa {kg/cm <sup>2</sup> }	0.29 – 0.49 {3.0 – 5.0} 0.25 – 0.44 {2.5 – 4.5}	0.20 {2.0} 0.18 {1.8}
	At low idling SAE15W-40 or SAE30 SAE10W		Min. 0.1 {Min. 1.0} Min. 0.1 {Min. 1.0}	0.07 {0.7} 0.07 {0.7}
Oil temperature	Whole speed range (inside oil pan)	°C	80 – 110	120
Fuel injection timing	Before top dead center	°	15 ± 0.5	15 ± 0.5
Alternator belt tension	Deflection when pressed with finger force of approx. 59 N {6 kg}	mm	15	15
Air conditioner compressor belt tension			10	10





## STANDARD VALUE TABLE FOR CHASSIS

Machine model				D155AX-5			
Category	Item	Measurement conditions	Unit	Standard value for new machine	Service limit value		
Engine stall speed	Torque converter stall speed	<ul style="list-style-type: none"> <li>Engine oil pressure: Within operating range</li> <li>Engine oil temperature: Within operating range</li> <li>Hydraulic oil temperature: 45 – 55 °C</li> </ul>	rpm	1,580 ± 100	1,420		
	Steering relief + work equipment raise stall speed ※ 1	<ul style="list-style-type: none"> <li>F3</li> <li>Ripper RAISE stall</li> </ul>		1,410 ± 100	1,250		
Control lever travel, pedal travel	Fuel control lever	Center of lever knob	Engine low idling → High idling	mm	105 ± 20	105 ± 20	
			Engine low idling → Stop		60 ± 20	60 ± 20	
	Decelerator pedal		Center of pedal		56 ± 15	56 ± 15	
	Joystick	Gear shift	<ul style="list-style-type: none"> <li>Engine stopped</li> <li>Center of lever knob</li> </ul>	1st ↔ 2nd	deg.	13 ± 5	13 ± 5
				2nd ↔ 3rd		13 ± 5	13 ± 5
		Directional		N ↔ FORWARD	45 ± 15	45 ± 15	
				N ↔ REVERSE	45 ± 15	45 ± 15	
				N → Right turn	57 ± 15	63 ± 15	
	Steering	N → Left turn	57 ± 15	63 ± 15			
	Brake pedal		<ul style="list-style-type: none"> <li>Engine at low idling</li> <li>Center of pedal</li> </ul>	Total travel	mm	79 ± 10	79 ± 10
	Blade lever		<ul style="list-style-type: none"> <li>Engine at low idling</li> <li>Center of lever knob</li> <li>Hydraulic oil temperature: 45 – 55°C</li> </ul>	Position until brake oil pressure becomes 0		61	61
	Ripper lever		<ul style="list-style-type: none"> <li>Engine at low idling</li> <li>Center of lever knob</li> <li>Hydraulic oil temperature: 45 – 55°C</li> </ul>	HOLD ↔ RAISE, FLOAT	mm	80 ± 15	80 ± 15
				HOLD ↔ LEFT, RIGHT TILT		60 ± 10	60 ± 10
Ripper lever		<ul style="list-style-type: none"> <li>Engine at low idling</li> <li>Center of lever knob</li> <li>Hydraulic oil temperature: 45 – 55°C</li> </ul>	HOLD ↔ RAISE, LOWER	mm	85 ± 15	85 ± 15	
			HOLD ↔ Digging angle decrease, increase		85 ± 15	85 ± 15	
Operating force of control lever, pedal	Fuel control lever ※ 1		Center of lever knob	N {kg}	98 – 157 {10 – 16}	177 {18}	
			Engine low idling ↔ High idling		98 – 177 {10 – 18}	196 {20}	
	Decelerator pedal		<ul style="list-style-type: none"> <li>Engine stopped</li> <li>Center of pedal</li> </ul>		78 ± 29 {8 ± 3}	147 {15}	
	Joystick	Gear shift	<ul style="list-style-type: none"> <li>Engine stopped</li> <li>Center of lever knob</li> </ul>	1st → 2nd	Nm {kgm}	216 ± 78 {22 ± 8}	216 ± 78 {22 ± 8}
				2nd → 3rd		372 ± 78 {38 ± 8}	372 ± 78 {38 ± 8}
				2nd → 1st		284 ± 78 {29 ± 8}	284 ± 78 {29 ± 8}
				3rd → 2nd		186 ± 78 {19 ± 8}	186 ± 78 {19 ± 8}

※ 1: Serial No. 70001 – 75000

Machine model				D155AX-5	
Category	Item	Measurement conditions	Unit	Standard value for new machine	Service limit value
Operating effort of control lever, pedal	Joystick	Directional	• Engine stopped N ↔ FORWARD	53.9 ± 19.1 {5.5 ± 2.0}	78.4 {8.0}
			• Center of lever knob N ↔ REVERSE	53.9 ± 19.1 {5.5 ± 2.0}	78.4 {8.0}
	Steering	• Engine stopped N ↔ Left turn	• Center of lever knob	17.6 ± 19.1 {1.8 ± 2.0}	44.1 {4.5}
			N ↔ Right turn	17.6 ± 19.1 {1.8 ± 2.0}	44.1 {4.5}
	Brake pedal		• Engine at low idling	461 ± 98 {47 ± 10}	608 {62}
	Blade lever	• Engine at low idling HOLD ↔ RAISE, FLOAT	• Hydraulic oil temperature: 45 – 55°C	29.4 ± 9.8 {3.0 ± 1.0}	49.0 {5.0}
			• Center of lever knob HOLD ↔ LEFT, RIGHT TILT	29.4 ± 9.8 {2.5 ± 1.0}	44.1 {4.5}
	Ripper lever	• Engine at low idling HOLD ↔ RAISE, LOWER	• Hydraulic oil temperature: 45 – 55°C	29.4 ± 9.8 {2.5 ± 1.0}	44.1 {4.5}
• Center of lever knob HOLD ↔ Digging angle decrease, increase			29.4 ± 9.8 {2.5 ± 1.0}	44.1 {4.5}	
Power train oil pressure	Torque converter inlet port pressure	• Power train oil temperature: Operating range	Engine at low idling	0.1 <sup>+0.1</sup> <sub>-0.09</sub> {1.0 <sup>+1.0</sup> <sub>-0.9</sub> }	0.1 <sup>+0.1</sup> <sub>-0.09</sub> {1.0 <sup>+1.0</sup> <sub>-0.9</sub> }
			Engine at high idling	0.83 ± 0.15 {8.5 ± 1.5}	0.83 ± 0.15 {8.5 ± 1.5}
	Torque converter outlet port pressure	Engine at low idling	0.1 <sup>+0.1</sup> <sub>-0.09</sub> {1.0 <sup>+1.0</sup> <sub>-0.9</sub> }	0.1 <sup>+0.1</sup> <sub>-0.09</sub> {1.0 <sup>+1.0</sup> <sub>-0.9</sub> }	
			Engine at high idling	0.44 ± 0.15 {4.5 ± 1.5}	0.44 ± 0.15 {4.5 ± 1.5}
	Transmission main relief pressure	Engine at high idling	2.94 <sup>+0.29</sup> <sub>0</sub> {30 <sup>+3</sup> <sub>0</sub> }	2.74 {28}	
	Transmission modulating pressure	Engine at high idling	2.94 <sup>+0.29</sup> <sub>0</sub> {30 <sup>+3</sup> <sub>0</sub> }	2.74 {28}	
	Brake actuating pressure	Engine at low idling	2.75 ± 0.29 {28 ± 3}	2.16 {22}	
Engine at high idling		2.75 ± 0.29 {28 ± 3}	2.16 {22}		
HSS circuit oil pressure	HSS main pressure	• Engine at high idling	38.2 – 41.7 {390 – 425}	38.2 – 41.7 {390 – 425}	
	HSS charge pressure		• Oil temperature: 45 – 55°C	3.72 ± 0.29 {38 ± 3}	3.24 {33}
	HSS servo charge pressure, PPC relief pressure		4.12 ± 0.29 {42 ± 3}	3.53 {36}	
Power train	Travel speed	• Level road surface • Engine water temperature: Within operating range • Run-up distance: 10–30 m • Measurement distance: 20 m	FORWARD 1st	3.5 ± 0.2	3.5 ± 0.2
			FORWARD 2nd	6.2 ± 0.3	6.2 ± 0.3
			FORWARD 3rd	10.8 ± 0.6	10.8 ± 0.6
			REVERSE 1st	4.8 ± 0.2	4.8 ± 0.2
			REVERSE 2nd	8.4 ± 0.3	8.4 ± 0.3
			REVERSE 3rd	13.9 ± 0.6	13.9 ± 0.6

Machine model				D155AX-5		
Category	Item	Measurement conditions	Unit	Standard value of new machine	Service limit value	
Work equipment	Work equipment speed	Work equipment posture  TYD00007 • Engine at high idling • Hydraulic oil temperature: 45 – 55°C • Lowest shank hole	LIFT	sec.	2.5 ± 0.5	4.0
		• Engine at high idling • Hydraulic oil temperature: 45 – 55°C • Lowest shank hole	LOWER		3.0 ± 1.0	5.0
		Work equipment posture  TYD00008 • Engine at high idling • Hydraulic oil temperature: 45 – 55°C • Lowest shank hole • Digging angle decrease ↔ increase	Decrease		3.0 ± 0.5	4.5
		• Engine at high idling • Hydraulic oil temperature: 45 – 55°C • Lowest shank hole • Digging angle decrease ↔ increase	Increase		2.5 ± 0.5	4.0
	Time lag	Blade	• Engine at high idling • Hydraulic oil temperature: 45 – 55°C • Raise blade to maximum height, then lower blade and measure time taken from point where blade contacts ground to point where idler comes off ground		1.5 ± 0.5	2.5
		Ripper	• Engine at high idling • Hydraulic oil temperature: 45 – 55°C • Raise ripper to maximum height, then lower ripper and measure time taken from point where ripper contacts ground to point where sprocket comes off ground		0 – 1.0	1.5
	Oil leakage	Cylinder	Blade tilt	• Hydraulic oil temperature: 45 – 55°C • Extend piston rod fully and disconnect hose at head end • Engine at high idling • Measure oil leakage during one minute of relief	cc/min	Max. 3.0
Ripper lift			Max. 2.7			11
Ripper tilt			Max. 2.7			11

# STANDARD VALUE TABLE FOR ELECTRICAL PARTS

Serial No. 70001 – 75000

System	Component	Connector No.	Inspection method	Judgement table	Measurement condition																	
HSS system	Engine speed sensor	CN-ENG (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table border="1" style="margin-left: 20px;"> <tr> <td>Between (1) – (2)</td> <td>500 – 1000 Ω</td> </tr> <tr> <td>Between (1), (2) – chassis</td> <td>Min.1 MΩ</td> </tr> </table>	Between (1) – (2)	500 – 1000 Ω	Between (1), (2) – chassis	Min.1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector.													
	Between (1) – (2)	500 – 1000 Ω																				
	Between (1), (2) – chassis	Min.1 MΩ																				
			Measure voltage	If the condition is as shown in the table below, it is normal <table border="1" style="margin-left: 20px;"> <tr> <td>Between (1) – (2)</td> <td>0.5 – 3.0 V</td> </tr> </table> ★ When using circuit tester, select AC voltage range.	Between (1) – (2)	0.5 – 3.0 V	1) Disconnect connectors. 2) Engine running															
	Between (1) – (2)	0.5 – 3.0 V																				
Steering potentiometer	CN-STR	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1" style="margin-left: 20px;"> <tr> <td colspan="2">Between (4) – (1)</td> <td>5.0 ± 0.25 V</td> </tr> <tr> <td rowspan="2">Lever fully at left</td> <td>Between (3) – (1)</td> <td>4.15 ± 0.25 V</td> </tr> <tr> <td>Between (2) – (1)</td> <td>0.85 ± 0.25 V</td> </tr> <tr> <td rowspan="2">Lever at N</td> <td>Between (3) – (1)</td> <td>2.5 ± 0.25 V</td> </tr> <tr> <td>Between (2) – (1)</td> <td>2.5 ± 0.25 V</td> </tr> <tr> <td rowspan="2">Lever fully at right</td> <td>Between (3) – (1)</td> <td>0.85 ± 0.25 V</td> </tr> <tr> <td>Between (2) – (1)</td> <td>4.15 ± 0.25 V</td> </tr> </table>	Between (4) – (1)		5.0 ± 0.25 V	Lever fully at left	Between (3) – (1)	4.15 ± 0.25 V	Between (2) – (1)	0.85 ± 0.25 V	Lever at N	Between (3) – (1)	2.5 ± 0.25 V	Between (2) – (1)	2.5 ± 0.25 V	Lever fully at right	Between (3) – (1)	0.85 ± 0.25 V	Between (2) – (1)	4.15 ± 0.25 V	1) Turn starting switch ON. 2) Insert T-adaptor. 3) Turn joystick to steering position.
Between (4) – (1)		5.0 ± 0.25 V																				
Lever fully at left	Between (3) – (1)	4.15 ± 0.25 V																				
	Between (2) – (1)	0.85 ± 0.25 V																				
Lever at N	Between (3) – (1)	2.5 ± 0.25 V																				
	Between (2) – (1)	2.5 ± 0.25 V																				
Lever fully at right	Between (3) – (1)	0.85 ± 0.25 V																				
	Between (2) – (1)	4.15 ± 0.25 V																				
REVERSE sensing potentiometer	CN-RSS	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1" style="margin-left: 20px;"> <tr> <td colspan="2">Between (1) – (3)</td> <td>5.0 ± 0.25 V</td> </tr> <tr> <td>Lever at N</td> <td rowspan="2">Between (2) – (3)</td> <td>Max. 3.5 V</td> </tr> <tr> <td>Lever at REVERSE</td> <td>3.5 – 4.4 V</td> </tr> </table>	Between (1) – (3)		5.0 ± 0.25 V	Lever at N	Between (2) – (3)	Max. 3.5 V	Lever at REVERSE	3.5 – 4.4 V	1) Turn starting switch ON. 2) Insert T-adaptor. 3) Turn joystick to directional position.										
Between (1) – (3)		5.0 ± 0.25 V																				
Lever at N	Between (2) – (3)	Max. 3.5 V																				
Lever at REVERSE		3.5 – 4.4 V																				
Steering circuit oil pressure sensor A	CN-STHP1	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1" style="margin-left: 20px;"> <tr> <td colspan="2">Between (2) – (1)</td> <td>20 – 30 V</td> </tr> <tr> <td rowspan="2">Between (3) – (1)</td> <td>Engine stopped</td> <td>0.8 – 1.2 V</td> </tr> <tr> <td>Engine running + Steering relief</td> <td>4.0 – 4.6 V</td> </tr> </table>	Between (2) – (1)		20 – 30 V	Between (3) – (1)	Engine stopped	0.8 – 1.2 V	Engine running + Steering relief	4.0 – 4.6 V	1) Turn starting switch ON. 2) Insert T-adaptor.										
Between (2) – (1)		20 – 30 V																				
Between (3) – (1)	Engine stopped	0.8 – 1.2 V																				
	Engine running + Steering relief	4.0 – 4.6 V																				
Steering circuit oil pressure sensor B	CN-STHP2	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1" style="margin-left: 20px;"> <tr> <td colspan="2">Between (2) – (1)</td> <td>20 – 30 V</td> </tr> <tr> <td rowspan="2">Between (3) – (1)</td> <td>Engine stopped</td> <td>0.8 – 1.2 V</td> </tr> <tr> <td>Engine running + Steering relief</td> <td>4.0 – 4.6 V</td> </tr> </table>	Between (2) – (1)		20 – 30 V	Between (3) – (1)	Engine stopped	0.8 – 1.2 V	Engine running + Steering relief	4.0 – 4.6 V	1) Turn starting switch ON. 2) Insert T-adaptor.										
Between (2) – (1)		20 – 30 V																				
Between (3) – (1)	Engine stopped	0.8 – 1.2 V																				
	Engine running + Steering relief	4.0 – 4.6 V																				

System	Component	Connector No.	Inspection method	Judgement table	Measurement condition					
Monitor system	Engine oil pressure switch	CN-403 (male)	Measure resistance	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between terminal – body</td> <td>Oil pressure is above 0.05 MPa {0.5 kg/cm<sup>2</sup>}</td> <td>Min. 1 MΩ</td> </tr> <tr> <td>Oil pressure is below 0.05 MPa {0.5 kg/cm<sup>2</sup>}</td> <td>Max. 1 Ω</td> </tr> </table>	Between terminal – body	Oil pressure is above 0.05 MPa {0.5 kg/cm <sup>2</sup> }	Min. 1 MΩ	Oil pressure is below 0.05 MPa {0.5 kg/cm <sup>2</sup> }	Max. 1 Ω	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connectors.</li> </ol>
	Between terminal – body	Oil pressure is above 0.05 MPa {0.5 kg/cm <sup>2</sup> }	Min. 1 MΩ							
Oil pressure is below 0.05 MPa {0.5 kg/cm <sup>2</sup> }		Max. 1 Ω								
	Alternator	CN-112	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between terminal R – chassis</td> <td>27.5 – 29.5 V</td> </tr> </table> <p>★ If the battery is old, or after starting in cold area, the voltage may not rise for some time.</p>	Between terminal R – chassis	27.5 – 29.5 V	<ol style="list-style-type: none"> <li>1) Run engine. (half throttle or above)</li> </ol>			
Between terminal R – chassis	27.5 – 29.5 V									
Others	Neutral safety switch	CN-152 (male)	Measure resistance	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between (1) – (3)</td> <td>Lever at N or FORWARD</td> <td>Min. 1M Ω</td> </tr> <tr> <td>Lever at REVERSE</td> <td>Max. 1 Ω</td> </tr> </table>	Between (1) – (3)	Lever at N or FORWARD	Min. 1M Ω	Lever at REVERSE	Max. 1 Ω	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connectors.</li> <li>3) Turn joystick to directional position</li> </ol>
	Between (1) – (3)	Lever at N or FORWARD	Min. 1M Ω							
		Lever at REVERSE	Max. 1 Ω							
	Blade pitch solenoid	CN-454 (male)	Measure resistance	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (1) – (2)</td> <td>40 – 80 Ω</td> </tr> <tr> <td>Between (1), (2) – chassis</td> <td>Min. 1MΩ</td> </tr> </table>	Between (1) – (2)	40 – 80 Ω	Between (1), (2) – chassis	Min. 1MΩ	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connectors.</li> </ol>	
Between (1) – (2)	40 – 80 Ω									
Between (1), (2) – chassis	Min. 1MΩ									
	Pin puller solenoid	CN-246 (male)	Measure resistance	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (1) – (2)</td> <td>40 – 80 Ω</td> </tr> <tr> <td>Between (1), (2) – chassis</td> <td>Min. 1 MΩ</td> </tr> </table>	Between (1) – (2)	40 – 80 Ω	Between (1), (2) – chassis	Min. 1 MΩ	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connectors.</li> </ol>	
Between (1) – (2)	40 – 80 Ω									
Between (1), (2) – chassis	Min. 1 MΩ									

Serial No. 75001 and up

System	Component	Connector No.	Inspection method	Judgement table	Measurement condition																
HSS system	Engine speed sensor	CN-E07 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td>Between (1) – (2)</td> <td>500 – 1000 Ω</td> </tr> <tr> <td>Between (1), (2) – chassis</td> <td>Min.1 MΩ</td> </tr> </table>	Between (1) – (2)	500 – 1000 Ω	Between (1), (2) – chassis	Min.1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector.												
			Between (1) – (2)	500 – 1000 Ω																	
	Between (1), (2) – chassis	Min.1 MΩ																			
	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td>Between (1) – (2)</td> <td>0.5 – 3.0 V</td> </tr> </table> ★ When using circuit tester, select AC voltage range.	Between (1) – (2)	0.5 – 3.0 V	1) Engine running 2) Insert T-adapter.																
	Between (1) – (2)	0.5 – 3.0 V																			
	Steering potentiometer	CN-STR	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td>Between (4) – (1)</td> <td>5.0 ± 0.25 V</td> </tr> <tr> <td rowspan="2">Lever fully at left</td> <td>Between (3) – (1)</td> <td>4.15 ± 0.25 V</td> </tr> <tr> <td>Between (2) – (1)</td> <td>0.85 ± 0.25 V</td> </tr> <tr> <td rowspan="2">Lever at N</td> <td>Between (3) – (1)</td> <td>2.5 ± 0.25 V</td> </tr> <tr> <td>Between (2) – (1)</td> <td>2.5 ± 0.25 V</td> </tr> <tr> <td rowspan="2">Lever fully at right</td> <td>Between (3) – (1)</td> <td>0.85 ± 0.25 V</td> </tr> <tr> <td>Between (2) – (1)</td> <td>4.15 ± 0.25 V</td> </tr> </table>	Between (4) – (1)	5.0 ± 0.25 V	Lever fully at left	Between (3) – (1)	4.15 ± 0.25 V	Between (2) – (1)	0.85 ± 0.25 V	Lever at N	Between (3) – (1)	2.5 ± 0.25 V	Between (2) – (1)	2.5 ± 0.25 V	Lever fully at right	Between (3) – (1)	0.85 ± 0.25 V	Between (2) – (1)	4.15 ± 0.25 V
Between (4) – (1)				5.0 ± 0.25 V																	
Lever fully at left				Between (3) – (1)	4.15 ± 0.25 V																
				Between (2) – (1)	0.85 ± 0.25 V																
Lever at N	Between (3) – (1)	2.5 ± 0.25 V																			
	Between (2) – (1)	2.5 ± 0.25 V																			
Lever fully at right	Between (3) – (1)	0.85 ± 0.25 V																			
	Between (2) – (1)	4.15 ± 0.25 V																			
REVERSE sensing potentiometer	CN-RSS	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td>Between (1) – (3)</td> <td>5.0 ± 0.25 V</td> </tr> <tr> <td rowspan="2">Lever at N</td> <td rowspan="2">Between (2) – (3)</td> <td>Max. 3.5 V</td> </tr> <tr> <td>3.5 – 4.4 V</td> </tr> </table>	Between (1) – (3)	5.0 ± 0.25 V	Lever at N	Between (2) – (3)	Max. 3.5 V	3.5 – 4.4 V	1) Turn starting switch ON. 2) Insert T-adapter. 3) Turn joystick to directional position.											
			Between (1) – (3)	5.0 ± 0.25 V																	
Lever at N	Between (2) – (3)	Max. 3.5 V																			
		3.5 – 4.4 V																			
Steering circuit oil pressure sensor A	CN-ST1	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td>Between (2) – (1)</td> <td>20 – 30 V</td> </tr> <tr> <td rowspan="2">Between (3) – (1)</td> <td>Engine stopped</td> <td>0.8 – 1.2 V</td> </tr> <tr> <td>Engine running + Steering relief</td> <td>4.0 – 4.6 V</td> </tr> </table>	Between (2) – (1)	20 – 30 V	Between (3) – (1)	Engine stopped	0.8 – 1.2 V	Engine running + Steering relief	4.0 – 4.6 V	1) Turn starting switch ON. 2) Insert T-adapter.										
			Between (2) – (1)	20 – 30 V																	
Between (3) – (1)	Engine stopped	0.8 – 1.2 V																			
	Engine running + Steering relief	4.0 – 4.6 V																			
Steering circuit oil pressure sensor B	CN-ST2	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td>Between (2) – (1)</td> <td>20 – 30 V</td> </tr> <tr> <td rowspan="2">Between (3) – (1)</td> <td>Engine stopped</td> <td>0.8 – 1.2 V</td> </tr> <tr> <td>Engine running + Steering relief</td> <td>4.0 – 4.6 V</td> </tr> </table>	Between (2) – (1)	20 – 30 V	Between (3) – (1)	Engine stopped	0.8 – 1.2 V	Engine running + Steering relief	4.0 – 4.6 V	1) Turn starting switch ON. 2) Insert T-adapter.										
			Between (2) – (1)	20 – 30 V																	
Between (3) – (1)	Engine stopped	0.8 – 1.2 V																			
	Engine running + Steering relief	4.0 – 4.6 V																			
HSS charge circuit oil pressure sensor	CN-406 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td rowspan="2">Between (1) – (2)</td> <td>Engine stopped</td> <td>Min. 1 MΩ</td> </tr> <tr> <td>Engine running</td> <td>Max. 1 Ω</td> </tr> <tr> <td colspan="2">Between (1), (2) – chassis</td> <td>Min. 1 MΩ</td> </tr> </table>	Between (1) – (2)	Engine stopped	Min. 1 MΩ	Engine running	Max. 1 Ω	Between (1), (2) – chassis		Min. 1 MΩ	1) Turn starting switch ON. 2) Disconnect connector.									
Between (1) – (2)	Engine stopped	Min. 1 MΩ																			
	Engine running	Max. 1 Ω																			
Between (1), (2) – chassis		Min. 1 MΩ																			

System	Component	Connector No.	Inspection method	Judgement table	Measurement condition								
HSS system	Work equipment circuit oil pressure sensor	CN-HHP	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td colspan="2">Between (2) – (1)</td> <td>20 – 30 V</td> </tr> <tr> <td rowspan="2">Between (3) – (1)</td> <td>Engine stopped</td> <td>0.8 – 1.2 V</td> </tr> <tr> <td>Engine started + work equipment relief</td> <td>2.4 – 3.0 V</td> </tr> </table>	Between (2) – (1)		20 – 30 V	Between (3) – (1)	Engine stopped	0.8 – 1.2 V	Engine started + work equipment relief	2.4 – 3.0 V	<ol style="list-style-type: none"> <li>1) Turn starting switch ON.</li> <li>2) Insert T-adapter.</li> </ol>
	Between (2) – (1)		20 – 30 V										
	Between (3) – (1)	Engine stopped	0.8 – 1.2 V										
		Engine started + work equipment relief	2.4 – 3.0 V										
	Backup alarm switch	CN-251 (male)	Measure resistance	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between (1) – (3)</td> <td>Lever at N or FORWARD</td> <td>Min. 1 MΩ</td> </tr> <tr> <td>Lever at REVERSE</td> <td>Max. 1 Ω</td> </tr> </table>	Between (1) – (3)	Lever at N or FORWARD	Min. 1 MΩ	Lever at REVERSE	Max. 1 Ω	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connectors.</li> <li>3) Turn joystick to directional position.</li> </ol>			
	Between (1) – (3)	Lever at N or FORWARD	Min. 1 MΩ										
		Lever at REVERSE	Max. 1 Ω										
	HSS pump solenoid A	CN-PUPA	Measure resistance	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (1) – (2)</td> <td>10 – 20 Ω</td> </tr> <tr> <td>Between (1), (2) – chassis</td> <td>Min. 1 MΩ</td> </tr> </table>	Between (1) – (2)	10 – 20 Ω	Between (1), (2) – chassis	Min. 1 MΩ	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connectors.</li> </ol>				
	Between (1) – (2)	10 – 20 Ω											
	Between (1), (2) – chassis	Min. 1 MΩ											
HSS pump solenoid B	CN-PUPB	Measure resistance	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (1) – (2)</td> <td>10 – 20 Ω</td> </tr> <tr> <td>Between (1), (2) – chassis</td> <td>Min. 1 MΩ</td> </tr> </table>	Between (1) – (2)	10 – 20 Ω	Between (1), (2) – chassis	Min. 1 MΩ	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connectors.</li> </ol>					
Between (1) – (2)	10 – 20 Ω												
Between (1), (2) – chassis	Min. 1 MΩ												
Backup alarm relay	CN-014 (male)	Measure resistance	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (1) – (2)</td> <td>200 – 400 Ω</td> </tr> <tr> <td>Between (3) – (5)</td> <td>Min. 1 MΩ</td> </tr> <tr> <td>Between (3) – (6)</td> <td>Max. 1 Ω</td> </tr> </table>	Between (1) – (2)	200 – 400 Ω	Between (3) – (5)	Min. 1 MΩ	Between (3) – (6)	Max. 1 Ω	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connectors.</li> </ol>			
Between (1) – (2)	200 – 400 Ω												
Between (3) – (5)	Min. 1 MΩ												
Between (3) – (6)	Max. 1 Ω												
HSS controller	Power supply for controller	CN-ST1	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (8),(18) – chassis</td> <td rowspan="2">20 – 30 V</td> </tr> <tr> <td>Between (8),(18) – (9),(19)</td> </tr> </table>	Between (8),(18) – chassis	20 – 30 V	Between (8),(18) – (9),(19)	<ol style="list-style-type: none"> <li>1) Turn starting switch ON.</li> <li>2) Insert T-adapter.</li> </ol>					
	Between (8),(18) – chassis	20 – 30 V											
	Between (8),(18) – (9),(19)												
	Power supply for solenoid	CN-ST1	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (17) – chassis</td> <td rowspan="2">20 – 30 V</td> </tr> <tr> <td>Between (17) – (9),(19)</td> </tr> </table>	Between (17) – chassis	20 – 30 V	Between (17) – (9),(19)	<ol style="list-style-type: none"> <li>1) Turn starting switch ON.</li> <li>2) Insert T-adapter.</li> </ol>					
Between (17) – chassis	20 – 30 V												
Between (17) – (9),(19)													
Net work (S-NET)	CN-ST1	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (1),(12) – (9),(19)</td> <td>4 – 8 V</td> </tr> </table>	Between (1),(12) – (9),(19)	4 – 8 V	<ol style="list-style-type: none"> <li>1) Turn starting switch ON.</li> <li>2) Insert T-adapter.</li> </ol>							
Between (1),(12) – (9),(19)	4 – 8 V												
Engine speed sensor	CN-ST3	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (4) – (12)</td> <td>0.5 – 3.0 V</td> </tr> </table> <p>★ When using circuit tester, select AC voltage range.</p>	Between (4) – (12)	0.5 – 3.0 V	<ol style="list-style-type: none"> <li>1) Engine running</li> <li>2) Insert T-adapter.</li> </ol>							
Between (4) – (12)	0.5 – 3.0 V												

System	Component	Connector No.	Inspection method	Judgement table	Measurement condition																
HSS system	HSS controller	5-V power supply for potentiometer	CN-ST2	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td>Between (10) – (9)</td> <td>5.0 ± 0.25 V</td> </tr> </table>	Between (10) – (9)	5.0 ± 0.25 V	1) Turn starting switch ON. 2) Insert T-adaper.													
		Between (10) – (9)	5.0 ± 0.25 V																		
		Steering potentiometer	CN-ST2	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td rowspan="2">Lever fully at right</td> <td>Between (19) – (9)</td> <td>4.15 ± 0.25 V</td> </tr> <tr> <td>Between (20) – (9)</td> <td>0.85 ± 0.25 V</td> </tr> <tr> <td rowspan="2">Lever at N</td> <td>Between (19) – (9)</td> <td>2.5 ± 0.25 V</td> </tr> <tr> <td>Between (20) – (9)</td> <td>2.5 ± 0.25 V</td> </tr> <tr> <td rowspan="2">Lever fully at left</td> <td>Between (19) – (9)</td> <td>0.85 ± 0.25 V</td> </tr> <tr> <td>Between (20) – (9)</td> <td>4.15 ± 0.25 V</td> </tr> </table>	Lever fully at right	Between (19) – (9)	4.15 ± 0.25 V	Between (20) – (9)	0.85 ± 0.25 V	Lever at N	Between (19) – (9)	2.5 ± 0.25 V	Between (20) – (9)	2.5 ± 0.25 V	Lever fully at left	Between (19) – (9)	0.85 ± 0.25 V	Between (20) – (9)	4.15 ± 0.25 V	1) Turn starting switch ON. 2) Insert T-adapter. 3) Turn joystick to steering position.
		Lever fully at right	Between (19) – (9)	4.15 ± 0.25 V																	
			Between (20) – (9)	0.85 ± 0.25 V																	
		Lever at N	Between (19) – (9)	2.5 ± 0.25 V																	
			Between (20) – (9)	2.5 ± 0.25 V																	
		Lever fully at left	Between (19) – (9)	0.85 ± 0.25 V																	
Between (20) – (9)	4.15 ± 0.25 V																				
Travel REVERSE sensing potentiometer	CN-ST2 CN-ST3	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td rowspan="2">Between CN-ST3(10) – CN-ST2(9)</td> <td>Lever at N</td> <td>Max. 3.5 V</td> </tr> <tr> <td>Lever at REVERSE</td> <td>3.5 – 4.4 V</td> </tr> </table>	Between CN-ST3(10) – CN-ST2(9)	Lever at N	Max. 3.5 V	Lever at REVERSE	3.5 – 4.4 V	1) Turn starting switch ON. 2) Insert T-adapter. 3) Turn joystick to directional position												
Between CN-ST3(10) – CN-ST2(9)	Lever at N	Max. 3.5 V																			
	Lever at REVERSE	3.5 – 4.4 V																			
Steering circuit oil pressure sensor A	CN-ST2 CN-ST3	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td rowspan="2">Between CN-ST3(1) – CN-ST2(9)</td> <td>Engine stopped</td> <td>0.8 – 1.2 V</td> </tr> <tr> <td>Engine running + Steering relief</td> <td>4.0 – 4.6 V</td> </tr> </table>	Between CN-ST3(1) – CN-ST2(9)	Engine stopped	0.8 – 1.2 V	Engine running + Steering relief	4.0 – 4.6 V	1) Turn starting switch ON. 2) Insert T-adapter.												
Between CN-ST3(1) – CN-ST2(9)	Engine stopped	0.8 – 1.2 V																			
	Engine running + Steering relief	4.0 – 4.6 V																			
Steering circuit oil pressure sensor B	CN-ST2 CN-ST3	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td rowspan="2">Between CN-ST3(9) – CN-ST2(9)</td> <td>Engine stopped</td> <td>0.8 – 1.2 V</td> </tr> <tr> <td>Engine running + Steering relief</td> <td>4.0 – 4.6 V</td> </tr> </table>	Between CN-ST3(9) – CN-ST2(9)	Engine stopped	0.8 – 1.2 V	Engine running + Steering relief	4.0 – 4.6 V	1) Turn starting switch ON. 2) Insert T-adapter.												
Between CN-ST3(9) – CN-ST2(9)	Engine stopped	0.8 – 1.2 V																			
	Engine running + Steering relief	4.0 – 4.6 V																			
HSS charge oil pressure sensor	CN-ST2	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td rowspan="2">Between (8) – chassis</td> <td>Engine stopped</td> <td>20 – 30 V</td> </tr> <tr> <td>Engine running</td> <td>Max. 1 V</td> </tr> </table>	Between (8) – chassis	Engine stopped	20 – 30 V	Engine running	Max. 1 V	1) Turn starting switch ON. 2) Insert T-adapter.												
Between (8) – chassis	Engine stopped	20 – 30 V																			
	Engine running	Max. 1 V																			
Work equipment circuit oil pressure sensor	CN-ST2 CN-ST3	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td rowspan="2">Between CN-CH2(2) – CN-CH1(9)</td> <td>Engine stopped</td> <td>0.8 – 1.2 V</td> </tr> <tr> <td>Engine running + Work equipment relief</td> <td>2.4 – 3.0 V</td> </tr> </table>	Between CN-CH2(2) – CN-CH1(9)	Engine stopped	0.8 – 1.2 V	Engine running + Work equipment relief	2.4 – 3.0 V	1) Turn starting switch ON. 2) Insert T-adapter.												
Between CN-CH2(2) – CN-CH1(9)	Engine stopped	0.8 – 1.2 V																			
	Engine running + Work equipment relief	2.4 – 3.0 V																			
Backup alarm switch	CN-ST2	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td rowspan="2">Between (7) – chassis</td> <td>Lever at N or FORWARD</td> <td>20 – 30 V</td> </tr> <tr> <td>Lever at REVERSE</td> <td>Max. 1 V</td> </tr> </table>	Between (7) – chassis	Lever at N or FORWARD	20 – 30 V	Lever at REVERSE	Max. 1 V	1) Turn starting switch ON. 2) Insert T-adapter. 3) Turn joystick to directional position.												
Between (7) – chassis	Lever at N or FORWARD	20 – 30 V																			
	Lever at REVERSE	Max. 1 V																			

System	Component	Connector No.	Inspection method	Judgement table	Measurement condition						
HSS system	HSS controller	Backup alarm relay	CN-ST1	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between (11) – chassis</td> <td>Lever at N or FORWARD</td> <td>Max. 1 V</td> </tr> <tr> <td>Lever at REVERSE</td> <td>20 – 30 V(※)</td> </tr> </table> <p>※ Voltage changes 20 – 30 V to below 1V alternatively every one second.</p>	Between (11) – chassis	Lever at N or FORWARD	Max. 1 V	Lever at REVERSE	20 – 30 V(※)	<ol style="list-style-type: none"> <li>1) Turn starting switch ON.</li> <li>2) Insert T-adapter.</li> <li>3) Turn joystick to directional position.</li> </ol>
		Between (11) – chassis	Lever at N or FORWARD	Max. 1 V							
			Lever at REVERSE	20 – 30 V(※)							
		Buzzer cancel switch 1	CN-ST2	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between ST2(6) – chassis</td> <td>Switch ON</td> <td>20 – 30 V</td> </tr> <tr> <td>Switch OFF</td> <td>Max. 1 V</td> </tr> </table>	Between ST2(6) – chassis	Switch ON	20 – 30 V	Switch OFF	Max. 1 V	<ol style="list-style-type: none"> <li>1) Turn starting switch ON.</li> <li>2) Insert T-adapter.</li> </ol>
		Between ST2(6) – chassis	Switch ON	20 – 30 V							
			Switch OFF	Max. 1 V							
		Buzzer cancel switch 2	CN-ST2	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between ST2(5) – chassis</td> <td>Switch ON</td> <td>20 – 30 V</td> </tr> <tr> <td>Switch OFF</td> <td>Max. 1 V</td> </tr> </table>	Between ST2(5) – chassis	Switch ON	20 – 30 V	Switch OFF	Max. 1 V	<ol style="list-style-type: none"> <li>1) Turn starting switch ON.</li> <li>2) Insert T-adapter.</li> </ol>
		Between ST2(5) – chassis	Switch ON	20 – 30 V							
Switch OFF	Max. 1 V										
Mode selection switch 1	CN-ST2	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between ST2(18) – chassis</td> <td>Switch ON</td> <td>20 – 30 V</td> </tr> <tr> <td>Switch OFF</td> <td>Max. 1 V</td> </tr> </table>	Between ST2(18) – chassis	Switch ON	20 – 30 V	Switch OFF	Max. 1 V	<ol style="list-style-type: none"> <li>1) Turn starting switch ON.</li> <li>2) Insert T-adapter.</li> </ol>		
Between ST2(18) – chassis	Switch ON	20 – 30 V									
	Switch OFF	Max. 1 V									
Mode selection switch 2	CN-ST2	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between ST2(17) – chassis</td> <td>Switch ON</td> <td>20 – 30 V</td> </tr> <tr> <td>Switch OFF</td> <td>Max. 1 V</td> </tr> </table>	Between ST2(17) – chassis	Switch ON	20 – 30 V	Switch OFF	Max. 1 V	<ol style="list-style-type: none"> <li>1) Turn starting switch ON.</li> <li>2) Insert T-adapter.</li> </ol>		
Between ST2(17) – chassis	Switch ON	20 – 30 V									
	Switch OFF	Max. 1 V									
Servise switch	CN-ST2	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between ST2(4) – chassis</td> <td>Switch ON</td> <td>20 – 30 V</td> </tr> <tr> <td>Switch OFF</td> <td>Max. 1 V</td> </tr> </table>	Between ST2(4) – chassis	Switch ON	20 – 30 V	Switch OFF	Max. 1 V	<ol style="list-style-type: none"> <li>1) Turn starting switch ON.</li> <li>2) Insert T-adapter.</li> </ol>		
Between ST2(4) – chassis	Switch ON	20 – 30 V									
	Switch OFF	Max. 1 V									
1st switch	CN-ST2	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between ST2(13) – chassis</td> <td>Lever at 3rd or 2nd</td> <td>20 – 30 V</td> </tr> <tr> <td>Lever at 1st</td> <td>Max. 1 V</td> </tr> </table>	Between ST2(13) – chassis	Lever at 3rd or 2nd	20 – 30 V	Lever at 1st	Max. 1 V	<ol style="list-style-type: none"> <li>1) Turn starting switch ON.</li> <li>2) Insert T-adapter.</li> <li>3) Turn joystick to 3rd or 2nd position.</li> </ol>		
Between ST2(13) – chassis	Lever at 3rd or 2nd	20 – 30 V									
	Lever at 1st	Max. 1 V									
2nd switch	CN-ST2	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between ST2(14) – chassis</td> <td>Lever at 1st or 2nd</td> <td>20 – 30 V</td> </tr> <tr> <td>Lever at 3rd</td> <td>Max. 1 V</td> </tr> </table>	Between ST2(14) – chassis	Lever at 1st or 2nd	20 – 30 V	Lever at 3rd	Max. 1 V	<ol style="list-style-type: none"> <li>1) Turn starting switch ON.</li> <li>2) Insert T-adapter.</li> <li>3) Turn joystick to 2nd or 1st position.</li> </ol>		
Between ST2(14) – chassis	Lever at 1st or 2nd	20 – 30 V									
	Lever at 3rd	Max. 1 V									

System	Component	Connector No.	Inspection method	Judgement table	Measurement condition												
Monitor panel system	Power train (Torque converter) oil temperature sensor	453 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td rowspan="5">Between (1) – (2)</td> <td>When water temperature is 100°C</td> <td>Approx. 3.8 kΩ</td> </tr> <tr> <td>When water temperature is 90°C</td> <td>Approx. 4.9 kΩ</td> </tr> <tr> <td>When water temperature is 35°C</td> <td>Approx. 29 kΩ</td> </tr> <tr> <td>When water temperature is 20°C</td> <td>Approx. 52 kΩ</td> </tr> <tr> <td>When water temperature is 10°C</td> <td>Approx. 80 kΩ</td> </tr> </table>	Between (1) – (2)	When water temperature is 100°C	Approx. 3.8 kΩ	When water temperature is 90°C	Approx. 4.9 kΩ	When water temperature is 35°C	Approx. 29 kΩ	When water temperature is 20°C	Approx. 52 kΩ	When water temperature is 10°C	Approx. 80 kΩ	1) Turn starting switch OFF. 2) Disconnect connectors.	
	Between (1) – (2)	When water temperature is 100°C	Approx. 3.8 kΩ														
		When water temperature is 90°C	Approx. 4.9 kΩ														
		When water temperature is 35°C	Approx. 29 kΩ														
		When water temperature is 20°C	Approx. 52 kΩ														
		When water temperature is 10°C	Approx. 80 kΩ														
	Fuel level sensor	423 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td rowspan="2">Between (1) – (2)</td> <td>At full</td> <td>Max. approx. 12 Ω</td> </tr> <tr> <td>At empty</td> <td>Approx. 85 – 110 Ω</td> </tr> </table>	Between (1) – (2)	At full	Max. approx. 12 Ω	At empty	Approx. 85 – 110 Ω	1) Turn starting switch OFF. 2) Disconnect connectors.							
	Between (1) – (2)	At full	Max. approx. 12 Ω														
		At empty	Approx. 85 – 110 Ω														
	Alternator	ANB	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td>Between terminal R – chassis</td> <td>27.5 – 29.5 V</td> </tr> </table> ★ If the battery is old, or after starting in cold area, the voltage may not rise for some time.	Between terminal R – chassis	27.5 – 29.5 V	1) Run engine. (half throttle or above)										
Between terminal R – chassis	27.5 – 29.5 V																
Monitor panel (Caution module)	Hydraulic oil temperature sensor	CN1	Measure resistance	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td rowspan="2">Between (5) – (2)</td> <td>When oil temperature is below 105°C</td> <td>Max. 1 V</td> </tr> <tr> <td>When oil temperature is above 105°C</td> <td>20 – 30 V</td> </tr> </table>	Between (5) – (2)	When oil temperature is below 105°C	Max. 1 V	When oil temperature is above 105°C	20 – 30 V	1) Insert T-adaptor. 2) Turn starting switch ON.							
	Between (5) – (2)	When oil temperature is below 105°C	Max. 1 V														
		When oil temperature is above 105°C	20 – 30 V														
	S-NET	CN1	Measure voltage	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td>Between (11) (12) – (10)</td> <td>4.0 – 10.0 V</td> </tr> </table>	Between (11) (12) – (10)	4.0 – 10.0 V	1) Insert T-adaptor. 2) Turn starting switch ON.										
Between (11) (12) – (10)	4.0 – 10.0 V																
Power train (Torque converter) oil temperature sensor	CN1 (female) CN2 (female)	Measure resistance	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td rowspan="6">Between CN2 (2) – CN1 (2)</td> <td>Oil temperature: 50°C (Level 1)</td> <td>Approx. 17 kΩ</td> </tr> <tr> <td>Oil temperature: 90°C (Level 2)</td> <td>Approx. 5 kΩ</td> </tr> <tr> <td>Oil temperature: 110°C (Level 3)</td> <td>Approx. 2.9 kΩ</td> </tr> <tr> <td>Oil temperature: 116°C (Level 4)</td> <td>Approx. 2.5 kΩ</td> </tr> <tr> <td>Oil temperature: 120°C (Level 5)</td> <td>Approx. 2.3 kΩ</td> </tr> <tr> <td>Oil temperature: 130°C (Level 6)</td> <td>Approx. 2.3 kΩ</td> </tr> </table>	Between CN2 (2) – CN1 (2)	Oil temperature: 50°C (Level 1)	Approx. 17 kΩ	Oil temperature: 90°C (Level 2)	Approx. 5 kΩ	Oil temperature: 110°C (Level 3)	Approx. 2.9 kΩ	Oil temperature: 116°C (Level 4)	Approx. 2.5 kΩ	Oil temperature: 120°C (Level 5)	Approx. 2.3 kΩ	Oil temperature: 130°C (Level 6)	Approx. 2.3 kΩ	1) Turn starting switch OFF. 2) Disconnect connectors.
Between CN2 (2) – CN1 (2)	Oil temperature: 50°C (Level 1)	Approx. 17 kΩ															
	Oil temperature: 90°C (Level 2)	Approx. 5 kΩ															
	Oil temperature: 110°C (Level 3)	Approx. 2.9 kΩ															
	Oil temperature: 116°C (Level 4)	Approx. 2.5 kΩ															
	Oil temperature: 120°C (Level 5)	Approx. 2.3 kΩ															
	Oil temperature: 130°C (Level 6)	Approx. 2.3 kΩ															
Fuel level sensor	CN1 (female) CN2 (female)	Measure resistance	If the condition is as shown in the table below, it is normal <table border="1"> <tr> <td rowspan="4">Between CN2 (3) – CN1 (2)</td> <td>E</td> <td>Approx. 75 kΩ</td> </tr> <tr> <td>Level 3/7</td> <td>Approx. 50 kΩ</td> </tr> <tr> <td>Level 5/7</td> <td>Approx. 35 kΩ</td> </tr> <tr> <td>F</td> <td>Approx. 14 kΩ</td> </tr> </table>	Between CN2 (3) – CN1 (2)	E	Approx. 75 kΩ	Level 3/7	Approx. 50 kΩ	Level 5/7	Approx. 35 kΩ	F	Approx. 14 kΩ	1) Turn starting switch OFF. 2) Disconnect connectors.				
Between CN2 (3) – CN1 (2)	E	Approx. 75 kΩ															
	Level 3/7	Approx. 50 kΩ															
	Level 5/7	Approx. 35 kΩ															
	F	Approx. 14 kΩ															

System	Component	Connector No.	Inspection method	Judgement table	Measurement condition						
Monitor pannel system	Monitor panel (Caution module)	Preheating signal	CN1 CN2	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between CN2 (5) – CN1 (2)</td> <td>When preheater is turned ON</td> <td>20 – 30 V</td> </tr> <tr> <td>When preheater is turned OFF</td> <td>Max. 1 V</td> </tr> </table>	Between CN2 (5) – CN1 (2)	When preheater is turned ON	20 – 30 V	When preheater is turned OFF	Max. 1 V	1) Insert T-adapter. 2) Turn starting switch ON.
		Between CN2 (5) – CN1 (2)	When preheater is turned ON	20 – 30 V							
			When preheater is turned OFF	Max. 1 V							
		Caution lamp	CN1 CN2	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between CN2 (7) – CN1 (2)</td> <td>When lamp is turned ON</td> <td>Max. 6 V</td> </tr> <tr> <td>When lamp is turned OFF</td> <td>20 – 30 V</td> </tr> </table>	Between CN2 (7) – CN1 (2)	When lamp is turned ON	Max. 6 V	When lamp is turned OFF	20 – 30 V	1) Insert T-adapter. 2) Turn starting switch ON.
	Between CN2 (7) – CN1 (2)	When lamp is turned ON	Max. 6 V								
		When lamp is turned OFF	20 – 30 V								
	Caution Buzzer	CN1 CN2	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between CN2 (8) – CN1 (2)</td> <td>When buzzer is turned ON</td> <td>Max. 3 V</td> </tr> <tr> <td>When buzzer is turned OFF</td> <td>20 – 30 V</td> </tr> </table>	Between CN2 (8) – CN1 (2)	When buzzer is turned ON	Max. 3 V	When buzzer is turned OFF	20 – 30 V	1) Insert T-adapter. 2) Turn starting switch ON.	
	Between CN2 (8) – CN1 (2)	When buzzer is turned ON	Max. 3 V								
		When buzzer is turned OFF	20 – 30 V								
	Lighting signal	CN4	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between (1) – (2)</td> <td>When lamp switch is turned OFF</td> <td>Max. 1 V</td> </tr> <tr> <td>When lamp switch is turned ON</td> <td>20 – 30 V</td> </tr> </table>	Between (1) – (2)	When lamp switch is turned OFF	Max. 1 V	When lamp switch is turned ON	20 – 30 V	1) Insert T-adapter. 2) Turn starting switch ON.	
	Between (1) – (2)	When lamp switch is turned OFF	Max. 1 V								
		When lamp switch is turned ON	20 – 30 V								
	Monitor panel (Tachometer module)	Backup power source	T01	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (7) – (2)</td> <td>20 – 30 V</td> </tr> </table>	Between (7) – (2)	20 – 30 V	1) Insert T-adapter. 2) Turn starting switch OFF.			
Between (7) – (2)		20 – 30 V									
Starting switch ON signal		T01	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (1) – (2)</td> <td>20 – 30 V</td> </tr> </table>	Between (1) – (2)	20 – 30 V	1) Insert T-adapter. 2) Turn starting switch ON.				
Between (1) – (2)		20 – 30 V									
Starting switch STAR signal		T01	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between (3) – (2)</td> <td>When starting switch is at ON position</td> <td>Max. 1 V</td> </tr> <tr> <td>When starting switch is at START position</td> <td>20 – 30 V</td> </tr> </table>	Between (3) – (2)	When starting switch is at ON position	Max. 1 V	When starting switch is at START position	20 – 30 V	1) Insert T-adapter.	
Between (3) – (2)		When starting switch is at ON position	Max. 1 V								
		When starting switch is at START position	20 – 30 V								
Alternator	T01	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between (4) – (2)</td> <td>While engine is stopped</td> <td>Max. 1 V</td> </tr> <tr> <td>While engine is running</td> <td>27.5 – 29.5 V</td> </tr> </table>	Between (4) – (2)	While engine is stopped	Max. 1 V	While engine is running	27.5 – 29.5 V	1) Insert T-adapter.		
Between (4) – (2)	While engine is stopped	Max. 1 V									
	While engine is running	27.5 – 29.5 V									
Service switch	T01	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between (5) – (2)</td> <td>When switch is turned OFF</td> <td>20 – 30 V</td> </tr> <tr> <td>When switch is turned ON</td> <td>Max. 1 V</td> </tr> </table>	Between (5) – (2)	When switch is turned OFF	20 – 30 V	When switch is turned ON	Max. 1 V	1) Insert T-adapter. 2) Turn starting switch ON.		
Between (5) – (2)	When switch is turned OFF	20 – 30 V									
	When switch is turned ON	Max. 1 V									
S-NET	T01	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (9) (10) – (8)</td> <td>4.0 – 10.0 V</td> </tr> </table>	Between (9) (10) – (8)	4.0 – 10.0 V	1) Insert T-adapter. 2) Turn starting switch ON.					
Between (9) (10) – (8)	4.0 – 10.0 V										

System	Component	Connector No.	Inspection method	Judgement table	Measurement condition															
Monitor panel system	Monitor panel (switch module)	Power source	S01	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (1) – (2)</td> <td>20 – 30 V</td> </tr> </table> <p>★ If the battery is old, or after starting in cold area, the voltage may not rise for some time.</p>	Between (1) – (2)	20 – 30 V	<ol style="list-style-type: none"> <li>1) Insert T-adapter.</li> <li>2) Turn starting switch ON.</li> </ol>												
	Between (1) – (2)	20 – 30 V																		
		Hydraulic oil temperature sensor	452 (male)	Measure resistance	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between (1) – chassis</td> <td>When oil temperature is below 105°C</td> <td>Max. 1 Ω</td> </tr> <tr> <td>When oil temperature is above 105°C</td> <td>Min. 1 MΩ</td> </tr> </table>	Between (1) – chassis	When oil temperature is below 105°C	Max. 1 Ω	When oil temperature is above 105°C	Min. 1 MΩ	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connectors.</li> </ol>									
	Between (1) – chassis	When oil temperature is below 105°C	Max. 1 Ω																	
		When oil temperature is above 105°C	Min. 1 MΩ																	
		Service switch	X1	Measure resistance	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (1) – (2)</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>Between (2) – (3)</td> <td>Max.1 Ω</td> <td>Min.1 MΩ</td> </tr> <tr> <td>Between (3) – (4)</td> <td>Min.1 MΩ</td> <td>Max.1 Ω</td> </tr> <tr> <td>Between (4) – (5)</td> <td>Max.1 Ω</td> <td>Min.1 MΩ</td> </tr> <tr> <td>Between (5) – (6)</td> <td>Min.1 MΩ</td> <td>Max.1 Ω</td> </tr> </table>	Between (1) – (2)	OFF	ON	Between (2) – (3)	Max.1 Ω	Min.1 MΩ	Between (3) – (4)	Min.1 MΩ	Max.1 Ω	Between (4) – (5)	Max.1 Ω	Min.1 MΩ	Between (5) – (6)	Min.1 MΩ	Max.1 Ω
Between (1) – (2)	OFF	ON																		
Between (2) – (3)	Max.1 Ω	Min.1 MΩ																		
Between (3) – (4)	Min.1 MΩ	Max.1 Ω																		
Between (4) – (5)	Max.1 Ω	Min.1 MΩ																		
Between (5) – (6)	Min.1 MΩ	Max.1 Ω																		
	Ribbon heater relay	HET (male)	Measure resistance	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (1) – (2)</td> <td>200 – 400 Ω</td> </tr> <tr> <td>Between (3) – (5)</td> <td>Min.1 MΩ</td> </tr> <tr> <td>Between (3) – (6)</td> <td>Max.1 Ω</td> </tr> </table>	Between (1) – (2)	200 – 400 Ω	Between (3) – (5)	Min.1 MΩ	Between (3) – (6)	Max.1 Ω	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connectors.</li> </ol>									
Between (1) – (2)	200 – 400 Ω																			
Between (3) – (5)	Min.1 MΩ																			
Between (3) – (6)	Max.1 Ω																			
	Monitor panel (caution module)	Power source	CN1	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td>Between (1) – (2)</td> <td>4.0 – 10.0 V</td> </tr> </table>	Between (1) – (2)	4.0 – 10.0 V	<ol style="list-style-type: none"> <li>1) Insert T-adapter.</li> <li>2) Turn starting switch ON.</li> </ol>												
Between (1) – (2)	4.0 – 10.0 V																			
		Starting switch START signal	CN1	Measure resistance	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between (3) – (2)</td> <td>When starting switch is at ON position</td> <td>Max. 1 Ω</td> </tr> <tr> <td>When starting switch is at START position</td> <td>20 – 30 V</td> </tr> </table>	Between (3) – (2)	When starting switch is at ON position	Max. 1 Ω	When starting switch is at START position	20 – 30 V	<ol style="list-style-type: none"> <li>1) Insert T-adapter.</li> </ol>									
Between (3) – (2)	When starting switch is at ON position	Max. 1 Ω																		
	When starting switch is at START position	20 – 30 V																		
		Alternator	CN1	Measure voltage	<p>If the condition is as shown in the table below, it is normal</p> <table border="1"> <tr> <td rowspan="2">Between (4) – (2)</td> <td>While engine is stopped</td> <td>Max. 1 V</td> </tr> <tr> <td>While engine is running</td> <td>27.5 – 29.5 V</td> </tr> </table>	Between (4) – (2)	While engine is stopped	Max. 1 V	While engine is running	27.5 – 29.5 V	<ol style="list-style-type: none"> <li>1) Insert T-adapter.</li> </ol>									
Between (4) – (2)	While engine is stopped	Max. 1 V																		
	While engine is running	27.5 – 29.5 V																		

# TESTING AND ADJUSTING

Tools for testing, adjusting, and troubleshooting .....	20-102
Measuring engine speed .....	20-103
Measuring intake air pressure (boost pressure) .....	20-104
Measuring exhaust temperature .....	20-105
Measuring exhaust color .....	20-106
Adjusting valve clearance .....	20-107
Measuring compression pressure .....	20-108
Measuring blow-by pressure .....	20-109
Measuring engine oil pressure .....	20-110
Testing and adjusting fuel injection timing .....	20-111
Handling equipment in fuel circuit .....	20-111-1
Rereasing remaining pressure in fuel system .....	20-111-1
Measuring fuel pressure .....	20-111-2
Reduced cylinder mode operation .....	20-111-3
Bleeding air from fuel system .....	20-111-5
Check for leakage in fuel system .....	20-111-6
Testing and adjusting alternator belt tension .....	20-112
Testing and adjusting air conditioner compressor belt tension .....	20-112-1
Testing and adjusting fun belt tension .....	20-112-2
Adjusting engine speed sensor .....	20-113
Handling controller high voltage circuit .....	20-113-1
Adjusting fuel control lever and decelerator pedal .....	20-114
Measuring torque converter stall speed .....	20-117
Measuring full stall speed .....	20-118
Measuring power train oil pressure .....	20-119
Testing and adjusting HSS main oil pressure .....	20-122
Testing and adjusting HSS charge oil pressure .....	20-124
Testing and adjusting HSS servo charge pressure and PPC relief pressure .....	20-126
Bleeding air from HSS pump .....	20-128
Simple procedure for testing brake performance .....	20-129
Adjusting joystick and parking lever .....	20-130
Testing and adjusting travel reverse sensing potentiometer .....	20-133
Adjusting travel reverse limit switch .....	20-134
Adjusting steering neutral position .....	20-135
Procedure for operating emergency steering switch .....	20-139
Adjusting initial current in HSS steering system .....	20-140-3
Adjusting brake pedal .....	20-141
Adjusting clearance of idler .....	20-143
Testing wear of sprocket .....	20-144
Testing and adjusting track shoe tension .....	20-145
Testing and adjusting hydraulic pressure .....	20-146
Measuring PPC valve output pressure .....	20-148
Adjusting play of PPC valve .....	20-150
Measuring solenoid valve output pressure .....	20-151
Testing location causing hydraulic drift of blade and ripper .....	20-152
Measuring leakage inside hydraulic cylinder .....	20-153
Releasing remaining oil pressure in hydraulic cylinder .....	20-154
Bleeding air from hydraulic cylinder .....	20-154
Adjusting work equipment safety lever .....	20-155
Adjusting semi-U tiltdozer .....	20-156

## TOOLS FOR TESTING, ADJUSTING, AND TROUBLESHOOTING

Check or measurement item	Symbol	Part No.	Part Name	Remarks	
Engine speed ※1	A	799-203-8001	Multi-tachometer	Digital display L : 60 – 2,000rpm H : 60 – 19,999rpm	
Air supply pressure (boost pressure)	B	799-201-2202	Boost gauge kit	-101 – 199.9kPa{-750 – 1,500mmHg}	
Temperature of water, oil , and exhaust gas	C	799-101-1502	Digital thermometer	- 99.9 – 1299°C	
Exhaust color	D	1	799-201-9000	Handy smoke checker	
		2	Commercially available	Smoke meter	
Valve clearance	E	795-125-1210	Feeler gauge	SA6D140E-2 Intake valve: 0.43mm, Exhaust valve: 0.80mm	
		Commercially available		SA6D140E-3 Intake valve: 0.35mm, Exhaust valve: 0.57mm	
Compression pressure ※1	F	795-502-1205	Compression gauge	0 – 6.9MPa {0 – 70kg/cm <sup>2</sup> }	
		• 795-502-1510	• Adapter		
		• 795-502-1520	• Plate		
Blow-by pressure	G	799-201-1504	Blow by checker	0 – 4.9MPa {0 – 500mmH <sub>2</sub> O}	
Oil pressure	H	1	799-101-5002	Hydraulic tester	Pressure gauge: 2.5,5.9,39.2,58.8MPa {25,60,400,600kg/cm <sup>2</sup> }
			790-261-1203	Digital hydraulic tester	Pressure gauge: 58.8MPa{600kg/cm <sup>2</sup> }
			799-101-5220	Nipple	10 x 1.25
			07002-11023	O-ring	
	2	799-401-2320	Hydraulic gauge	0.98MPa {10kg/cm <sup>2</sup> }	
Wear of sprocket	J	791-627-1160	Wear gauge		
Operating effort	K	79A-264-0021	Push-pull scale	0 – 294N {0 – 30kg}	
		79A-264-0091	Push-pull scale	0 – 490N {0 – 50kg}	
Stroke, hydraulic drift	L	Commercially available	Scale		
Work equipment speed	M	Commercially available	Stop watch		
Measuring voltage and resistance	N	79A-264-0211	Tester		
Troubleshooting of wiring harnesses	P	799-601-8000	T-adapter		
		799-601-7360	Adapter	For 5 pins relay	

※1: SA6D140E-2 engine

## MEASURING ENGINE SPEED




Serial No. 70001 – 75000

**⚠** Be careful not to touch any hot parts when removing or installing the measuring tools.

★ Measure the engine speed under the following conditions.

- Coolant temperature: Within operating range
- Transmission oil temperature: Within operating range
- Hydraulic temperature: 45 – 55°C

1. Remove cap (1) of the speed pickup port.
  2. Install sensor ① of multi-tachometer **A** to the speed pickup port, then connect to multi-tachometer **A**.
  3. Start the engine and measure the engine speed under the following conditions.
    - 1) Measurement at low idling:
      - i) Set the joystick and work equipment control lever to the neutral position.
      - ii) Set the fuel control lever to the low idling position, then measure the engine speed.
    - 2) Measurement at high idling
      - i) Set the joystick and work equipment control lever to the neutral position.
      - ii) Set the fuel control lever to the high idling position, then measure the engine speed.
- ★ When measuring the “stall speed of torque converter” and “speed to stall the torque converter and relieve the work equipment pump”, see the measurement procedure for them.




**Serial No. 75001 and up**


★ Measure the engine speed in the monitoring mode and adjusting mode of the monitor panel. For the general explanation of the monitoring mode and adjusting mode, see DISPLAY AND SPECIAL FUNCTIONS OF MONITOR PANEL in TROUBLESHOOTING.

1. Measuring low idling speed and high idling speed

- 1) Remove cover (1).
- 2) Turn starting switch ON.
- 3) Turn service switch (2) ON.
  - ★ The service switch is installed inside the cover.
- 4) Turn and hold buzzer cancel switch (3) to the right for at least 7 seconds to display the service mode in upper display unit (4).
- 5) Turn up mode selector switch (5) to display the monitoring mode.
  - ★ The mode selector switch is installed inside the cover.
  - ★ Each time the mode selector switch is turned up, the mode changes.
  - ★ If the monitoring mode is selected, round mark (6) on the left side lights up.
- 6) Turn buzzer cancel switch (3) to the right to display "99".
- 7) Start the engine and read its speed under the following conditions indicated in lower display unit (7) of the panel.
  - ★ The engine speed is indicated by the unit of rpm.
  - i) Measuring low idling speed:
    - Set the joystick and work equipment control lever in neutral and set the fuel control dial in the low idling position.



BWD10001



BWD10002

- ii) Measuring high idling speed:  
Set the joystick and work equipment control lever in neutral and set the fuel control dial in the high idling position.
- 8) After measuring the engine speed, turn OFF service switch (2) and set the panel to the ordinary mode.
- 9) Install cover (1).

## MEASURING INTAKE AIR PRESSURE (BOOST PRESSURE)

Serial No. 70001 – 75000

**⚠** Be careful not to touch any hot parts when removing or installing the measuring tools.

★ Measure the intake air pressure under the following conditions.

- Coolant temperature: Within operating range
- Transmission oil temperature: Within operating range
- Hydraulic temperature: 45 – 55 °C

1. Remove intake air pressure pickup plug (1) (PT1/8).

2. Install nipple ① of oil pressure gauge **H1**, then connect to boost gauge **B**.

3. Start and run the engine at a middle or higher speed to drain oil from the hoses.

- ★ Insert the connecting part of the hose in the pressure gauge halfway and open the self-sealing part on the hose side repeatedly to drain the oil.
- ★ If Pm kit (A) is available, the air bleeding coupling (790-261-113) in it may be used.
- ★ If any oil remains in the hoses, the gauge does not operate. Accordingly, drain the oil without fail.

4. Run the engine at high idling and stall the torque converter, and measure the intake air pressure (boost pressure) at this time.

- ★ For the procedure to stall the torque converter, see **MEASURING TORQUE CONVERTER STALL SPEED**.
- ★ The normal intake air pressure (boost pressure) must be measured while the machine is operating at the rated output. An approximate value can be obtained in the field, however, by measuring when the torque converter stalls.

