

SHOP MANUAL

WA380-6

MACHINE MODEL

WA380-6

SERIAL NUMBER

H60051 and up

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- WA380-6 mounts the SAA6D107E-1 engine.

Product: KOMATSU WA380-6 Wheel Loader Service Repair Workshop Manual

Full Download: <https://www.arepairmanual.com/downloads/komatsu-wa380-6-wheel-loader-service-repair-workshop-manual/>

Sample of manual. Download All 1303 pages at:

<https://www.arepairmanual.com/downloads/komatsu-wa380-6-wheel-loader-service-repair-workshop-manual/>

WHEEL LOADER**WA380-6****Machine model Serial number**

WA380-6 H60051 and up

00 Index and foreword**Index**

Composition of shop manual.....	2
Table of contents	4

Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Note 1: Always keep the latest version of this manual in accordance with this list and utilize accordingly.

The marks shown to the right of Form No. denote the following:

○: New issue (to be filed additionally) ●: Revision (to be replaced for each Form No.)

Note 2: This shop manual can be supplied for each Form No.

Note 3: To file this shop manual in the special binder for management, handle it as follows:

- Place a divider on the top of each section in the file after matching the Tub No. with No. indicated next to each Section Name shown in the table below:
- File overview and other materials in sections in the order shown below and utilize them accordingly.

Section Title	Form Number
Shop Manual, contents binder, binder label and tabs	VEBM440101
00 Index and foreword	SEN01011-04
Index	SEN01019-04 ●
Foreword and general information	SEN01020-01 ●
01 Specification	SEN01012-00
Specification and technical data	SEN01021-00
10 Structure, function and maintenance standard	SEN01013-01
Engine and cooling system	SEN01040-00
Power train	SEN01041-00
Steering system	SEN01042-00
Brake system	SEN01043-00
Undercarriage and frame	SEN01044-00
Hydraulic system, Part 1	SEN01045-00
Hydraulic system, Part 2	SEN01046-00
Work equipment	SEN01047-00
Cab and its attachments	SEN01048-00
Electrical system, Part 1	SEN01049-00
Electrical system, Part 2	SEN01050-00
Electrical system, Part 3	SEN01051-00
20 Standard value table	SEN01014-01
Standard service value table	SEN01024-01
30 Testing and adjusting	SEN01015-01
Testing and adjusting, Part 1	SEN01025-01
Testing and adjusting, Part 2	SEN01026-01
Testing and adjusting, Part 3	SEN01027-01
40 Troubleshooting	SEN01016-00
General information on troubleshooting	SEN01212-00
Troubleshooting by failure code (Display of code), Part 1	SEN01213-00
Troubleshooting by failure code (Display of code), Part 2	SEN01214-00
Troubleshooting by failure code (Display of code), Part 3	SEN01215-00
Troubleshooting by failure code (Display of code), Part 4	SEN01216-00

Troubleshooting by failure code (Display of code), Part 5	SEN01217-00
Troubleshooting by failure code (Display of code), Part 6	SEN01218-00
Troubleshooting by failure code (Display of code), Part 7	SEN01219-00
Troubleshooting by failure code (Display of code), Part 8	SEN01220-00
Troubleshooting by failure code (Display of code), Part 9	SEN01221-00
Troubleshooting by failure code (Display of code), Part 10	SEN01222-00
Troubleshooting of electrical system (E-mode)	SEN01223-00
Troubleshooting of hydraulic and mechanical system (H-mode)	SEN01224-00
Troubleshooting of engine (S-mode)	SEN01225-00
50 Disassembly and assembly	SEN01017-00
General information on disassembly and assembly	SEN01461-00
Engine and cooling system	SEN01462-00
Power train	SEN01463-00
Steering system	SEN01464-00
Brake system	SEN01465-00
Undercarriage and frame	SEN01466-00
Hydraulic system	SEN01467-00
Work equipment	SEN01468-00
Cab and its attachments	SEN01469-00
Electrical system	SEN01470-00
90 Diagrams and drawings	SEN01018-02
Hydraulic diagrams and drawings	SEN01022-00
Electrical diagrams and drawings	SEN01023-01 ●

Table of contents

00 Index and foreword	
Index	SEN01019-04
Composition of shop manual	2
Table of contents.....	4
Foreword and general information	SEN01020-01
Safety notice	2
How to read the shop manual.....	7
Explanation of terms for maintenance standard	9
Handling electric equipment and hydraulic component	11
How to read electric wire code.....	23
Precautions when carrying out operation	26
Method of disassembling and connecting push-pull type coupler	29
Standard tightening torque table	32
Conversion table.....	36
01 Specification	
Specification and technical data	SEN01021-00
Specification and technical data	3
Specification dimension drawing.....	3
Specifications.....	4
Weight table	8
Table of fuel, coolant and lubricants	10
10 Structure, function and maintenance standard	
Engine and cooling system	SEN01040-00
Engine and cooling system	2
Engine mount and transmission mount	2
Cooling system	3
Cooling fan pump.....	4
Cooling fan motor	12
Power train	SEN01041-00
Power train	3
Power train.....	3
Power train system diagram	4
Drive shaft.....	6
Power train piping diagram	7
Torque converter.....	8
Transmission.....	16
Flow control valve.....	33
Valve assembly.....	34
ECMV	35
Main relief valve and torque converter relief valve	42
Axe.....	44
Front axle.....	44
Rear axle	45
Differential.....	46
Front differential	46
Rear differential	47
Limited slip differential	51
Final drive	58

Steering system	SEN01042-00
Steering system.....	2
Steering piping diagram.....	2
Steering column.....	3
Steering pump	4
Steering valve	15
Orbit-roll valve	30
Stop valve	34
Steering relief valve	35
Steering cylinder	36
Emergency steering motor	38
Emergency steering pump.....	39
Brake system	SEN01043-00
Brake system	2
Brake piping diagram.....	2
Charge valve	3
Brake valve.....	10
Accumulator (for brake)	15
Brake	16
Parking brake control.....	21
Parking brake	22
Parking brake solenoid valve.....	24
Emergency parking brake release valve	26
Undercarriage and frame	SEN01044-00
Undercarriage and frame	2
Axe mount and center hinge pin	2
Tires.....	6
Hydraulic system, Part 1	SEN01045-00
Hydraulic system, Part 1	2
Hydraulic piping diagram	2
Work equipment control lever linkage	5
Hydraulic tank.....	6
Breather.....	7
Power train pump	8
Work equipment pump	9
Work equipment control valve	20
CLSS	34
Outline of CLSS.....	34
Basic principle	35
Each function and operation of each valve.....	38
Hydraulic circuit diagram and names of valves	38
Area ratio of pressure compensation valve	48
Hydraulic system, Part 2	SEN01046-00
Hydraulic system, Part 2	2
PPC valve.....	2
Stabilizer valve.....	8
Accumulator (for PPC circuit)	13
Accumulator (for ECSS)	14
Work equipment	SEN01047-00
Work equipment	2
Work equipment linkage	2
Bucket.....	4
Bucket positioner and boom kick-out.....	5
Work equipment cylinder	11

Cab and its attachments	SEN01048-00
Cab and its attachments.....	3
Cab	3
Air conditioner	4
Air conditioner piping diagram	4
Air conditioner unit	7
Blower and intake unit	9
Compressor	10
Condenser	11
Receiver.....	12
Air conditioner panel	14
Electrical system, Part 1	SEN01049-00
Electrical system, Part 1	2
Machine monitor system.....	2
Machine monitor	7
Electrical system, Part 2	SEN01050-00
Electrical system, Part 2	2
Electrical system (Transmission controller system).....	2
Transmission controller.....	36
Electrical system, Part 3	SEN01051-00
Electrical system, Part 3	2
Electric transmission control	2
Kickdown switch and hold switch.....	6
KOMTRAX terminal system.....	8
Engine starting circuit	10
Engine stopping circuit.....	12
Preheating circuit.....	13
Engine power mode selector circuit.....	14
Engine output derating function	15
Automatic warm-up function	15
Parking brake circuit	16
Sensor	18
20 Standard value table	
Standard service value table	SEN01024-01
Standard service value table	2
Standard service value table for engine.....	2
Standard service value table for chassis	3
30 Testing and adjusting	
Testing and adjusting, Part 1	SEN01025-01
Testing and adjusting, Part 1	3
Tools for testing, adjusting, and troubleshooting.....	3
Measuring engine speed	6
Measuring exhaust gas color.....	8
Adjusting valve clearance	10
Measuring compression pressure.....	12
Measuring blow-by pressure.....	15
Measuring engine oil pressure.....	16
Measuring intake air (boost) pressure	17
Handling fuel system equipment.....	18
Releasing residual pressure in fuel system	18
Measuring fuel pressure	19
Measuring fuel return rate and leakage	21
Bleeding air from fuel circuit	24
Testing leakage in fuel system.....	26

Handling reduced cylinder mode operation	27
Handling no-injection cranking operation	27
Handling controller voltage circuit.....	28
Testing and adjusting air conditioner compressor belt tension	29
Adjusting transmission speed sensor	30
Measuring directional lever.....	31
Measuring and adjusting power train oil pressure	32
Procedure for flushing torque converter and transmission hydraulic circuit	47
Method of moving machine when transmission valve is broken.....	48
Testing and adjusting steering stop valve	50
Testing and adjusting steering wheel.....	52
Testing steering oil pressure	54
Bleeding air from steering circuit	57
Testing and adjusting, Part 2	SEN01026-01
Testing and adjusting, Part 2	3
Testing hydraulic drive fan	3
Bleeding air from hydraulic drive fan circuit.....	5
Measuring brake pedal	7
Measuring brake performance.....	8
Testing and adjusting accumulator charge pressure	9
Testing wheel brake oil pressure	10
Measuring wear of wheel brake disc	12
Bleeding air from wheel brake circuit.....	13
Releasing residual pressure in brake accumulator circuit	14
Testing parking brake performance	15
Measuring parking brake oil pressure	16
Testing wear of parking brake disc	18
Method of releasing parking brake manually	19
Measuring and adjusting work equipment control lever	20
Measuring and adjusting work equipment PPC oil pressure	21
Measuring and adjusting work equipment oil pressure	24
Bleeding air from work equipment circuit.....	28
Releasing residual pressure in work equipment circuit	29
Testing and adjusting bucket positioner.....	30
Testing and adjusting boom kick-out	32
Checking proximity switch operation pilot lamp	33
Procedure for testing diodes.....	34
Preparation work for troubleshooting for electric system.....	35
How to start operation of KOMTRAX terminal	40
Lamp display of KOMTRAX terminal.....	45
Adjusting machine monitor	48
Adjusting replaced, reassembled or added sensor, controller, etc. with machine monitor	49
Testing and adjusting, Part 3	SEN01027-01
Testing and adjusting, Part 3	2
Special functions of machine monitor (EMMS).....	2
Pm-click inspection table	61
40 Troubleshooting	
General information on troubleshooting	SEN01212-00
General information on troubleshooting	2
Points to remember when troubleshooting	2
Sequence of events in troubleshooting	3
Testing before troubleshooting	4
Classification and procedures of troubleshooting.....	5
Connection table for connector pin numbers.....	8
T-branch box and T-branch adapter table	31

Troubleshooting by failure code (Display of code), Part 1	SEN01213-00
Troubleshooting by failure code (Display of code), Part 1.....	3
Failure codes list.....	3
Before carrying out troubleshooting for electrical system.....	10
Information contained troubleshooting table.....	13
Failure code [1500L0] (TORQFLOW transmission: Double meshing).....	15
Failure code [15SAL1] (ECMV F clutch: When command current is OFF, fill signal is ON)	16
Failure code [15SALH] (ECMV F clutch: When command current is ON, fill signal is OFF) ...	18
Failure code [15SBL1] (ECMV R clutch: When command current is OFF, fill signal is ON)....	20
Failure code [15SBLH] (ECMV R clutch: When command current is ON, fill signal is OFF)...	22
Failure code [15SEL1] (ECMV 1st clutch: When command current is OFF, fill signal is ON)..	24
Failure code [15SELH] (ECMV 1st clutch: When command current is ON, fill signal is OFF).	26
Failure code [15SFL1] (ECMV 2nd clutch: When command current is OFF, fill signal is ON). Failure code [15SFLH] (ECMV 2nd clutch: When command current is ON, fill signal is OFF)	28
Failure code [15SGL1] (ECMV 3rd clutch: When command current is OFF, fill signal is ON).	30
Failure code [15SGLH] (ECMV 3rd clutch: When command current is ON, fill signal is OFF)	32
Failure code [15SHL1] (ECMV 4th clutch: When command current is OFF, fill signal is ON) .	34
Failure code [15SHLH] (ECMV 4th clutch: When command current is ON, fill signal is OFF)	36
Failure code [2F00MA] (Parking brake: Malfunction)	38
Troubleshooting by failure code (Display of code), Part 2	SEN01214-00
Troubleshooting by failure code (Display of code), Part 2.....	4
Failure code [2G43ZG] (Accumulator: Low oil pressure).....	4
Failure code [AA1ANX] (Air cleaner: Clogging).....	6
Failure code [AB00L6] (Alternator: Signal disagrees with operating state of engine).....	8
Failure code [AB00MA] (Alternator: Malfunction)	10
Failure code [B@BAZG] (Rotation derating by low engine oil pressure).....	12
Failure code [B@BAZK] (Engine oil: Low level)	13
Failure code [B@BCNS] (Coolant: Overheating).....	14
Failure code [B@BCZK] (Coolant: Low level).....	16
Failure code [B@C7NS] (Brake oil: Overheating)	18
Failure code [b@CENS] (Torque converter oil: Overheating).....	20
Failure code [B@CENS] (Torque converter oil: Overheating)	22
Failure code [B@HANS] (Hydraulic oil: Overheating)	24
Failure code [CA111] (Abnormality in engine controller).....	26
Failure code [CA115] (Engine Ne or Bkup speed sensor error)	27
Failure code [CA122] (Charge pressure sensor high error).....	28
Failure code [CA123] (Charge pressure sensor low error)	30
Failure code [CA131] (Throttle sensor high error)	32
Failure code [CA132] (Throttle sensor low error).....	34
Failure code [CA144] (Coolant sensor high error)	36
Failure code [CA145] (Coolant sensor low error)	38
Failure code [CA153] (Charge temperature sensor high error)	40
Failure code [CA154] (Charge temperature sensor low error).....	42
Failure code [CA155] (Derating of speed by abnormally high charge temperature).....	44
Failure code [CA187] (Sensor power supply 2 low error).....	46
Failure code [CA221] (Atmospheric pressure sensor high error)	48
Failure code [CA222] (Atmospheric sensor low error).....	50
Failure code [CA227] (Sensor power supply 2 high error).....	52
Troubleshooting by failure code (Display of code), Part 3	SEN01215-00
Troubleshooting by failure code (Display of code), Part 3.....	3
Failure code [CA234] (Engine overspeed).....	3
Failure code [CA238] (Ne speed sensor power supply error).....	4
Failure code [CA271] (PCV1 Short circuit)	5
Failure code [CA272] (PCV1 Disconnection).....	6
Failure code [CA322] (Injector #1 (L/B #1) open/short error)	8
Failure code [CA323] (Injector #5 (L/B #5) open/short error)	10
Failure code [CA324] (Injector #3 (L/B #3) open/short error)	12

Failure code [CA325] (Injector #6 (L/B #6) open/short error)	14
Failure code [CA331] (Injector #2 (L/B #2) open/short error)	16
Failure code [CA332] (Injector #4 (L/B #4) open/short error)	18
Failure code [CA342] (Calibration code inconsistency)	20
Failure code [CA351] (Injectors drive circuit error)	21
Failure code [CA352] (Sensor power supply 1 low error)	23
Failure code [CA386] (Sensor power supply 1 high error)	25
Failure code [CA428] (Abnormally high level in water sensor)	26
Failure code [CA429] (Abnormally low level in water sensor)	28
Failure code [CA431] (Idle validation switch error)	30
Failure code [CA432] (Idle validation action error)	32
Failure code [CA435] (Engine oil pressure switch error)	34
Failure code [CA441] (Battery voltage low error)	35
Failure code [CA442] (Battery voltage high error)	38
Failure code [CA449] Common rail pressure high error 2	40
Failure code [CA451] (Common rail pressure sensor high error)	41
Failure code [CA452] (Common rail pressure sensor low error)	43
Failure code [CA488] (Derating of torque by abnormally high charge temperature)	45
Failure code [CA553] (Common rail pressure high error 1)	46
Failure code [CA559] (Supply pump pressure very low error)	47
Failure code [CA689] (Engine Ne speed sensor error)	48
Failure code [CA731] (Engine Bkup speed sensor phase error)	50
Failure code [CA757] (All continuous data lost error)	51
Failure code [CA778] (Engine Bkup speed sensor error)	54
Failure code [CA1117] (Partial engine controller data loss error)	56
Failure code [CA1633] (KOMNET datalink timeout error)	59
Troubleshooting by failure code (Display of code), Part 4	SEN01216-00
Troubleshooting by failure code (Display of code), Part 4	3
Failure code [CA2185] (Throttle sensor supply voltage high error)	3
Failure code [CA2186] (Throttle sensor power supply low error)	4
Failure code [CA2249] (Supply pump pressure very low error 2)	5
Failure code [CA2311] (Abnormality in IMV solenoid)	6
Failure code [CA2555] (Intake heater relay disconnection error)	8
Failure code [CA2556] (Intake heater relay short circuit error)	10
Failure code [D150KA] (Emergency steering relay: Disconnection)	12
Failure code [D150KB] (Emergency steering relay: Short circuit)	14
Failure code [D150KY] (Emergency steering relay: Short circuit with power supply line)	16
Failure code [D160KA] (Backup lamp relay: Disconnection)	18
Failure code [D160KB] (Backup lamp relay: Short circuit)	20
Failure code [D191KA] (Joystick steering neutral safety relay: Disconnection)	22
Failure code [D191KB] (Joystick steering neutral safety relay: Short circuit)	24
Failure code [D191KY] (Joystick steering neutral safety relay: Short circuit with power supply line)	26
Failure code [D192KA] (ECSS solenoid: Disconnection)	28
Failure code [D192KB] (ECSS solenoid: Short circuit)	29
Failure code [D192KY] (ECSS solenoid: Short circuit with power supply line)	30
Failure code [D5ZHKA] (Terminal C signal: Disconnection)	31
Failure code [D5ZHKB] (Terminal C signal: Short circuit)	35
Failure code [D5ZHL6] (Terminal C signal: Signal does not match engine running or stopped state)	39
Failure code [DA80L4] (Auto grease controller: ON/OFF signals disagree)	42
Failure code [DAF3KK] (Machine monitor: Low source voltage (input))	44
Failure code [DAF5KP] (Machine monitor: Low output voltage)	46
Failure code [DAFRKR] (CAN communication with machine monitor: Defective communication (Abnormality in target component system))	49
Failure code [DAQ0KK] (Transmission controller: Low source voltage)	51
Failure code [DAQ0KT] (Transmission controller: Abnormality in controller)	53

Failure code [DAQ2KK] (Transmission controller load power supply line: Low source voltage (input))	54
Failure code [DAQ9KQ] (Transmission controller model selection: Disagreement of model selection signals)	56
Troubleshooting by failure code (Display of code), Part 5	SEN01217-00
Troubleshooting by failure code (Display of code), Part 5	3
Failure code [DAQRKR] (CAN communication with transmission controller: Defective communication (Abnormality in target component system))	3
Failure code [DAQRMA] (Transmission controller option setting: Malfunction)	5
Failure code [DB2RKR] (CAN communication with engine controller: Defective communication (Abnormality in target component system))	6
Failure code [DB99KQ] (Work equipment controller model selection: Disagreement in model selection signals)	9
Failure code [DB9RKR] CAN communication with work equipment controller: Defective communication (Abnormality in target component system))	10
Failure code [DB9RMA] (Work equipment controller option setting: Malfunction)	12
Failure code [DD15LD] ■ switch (Panel switch 1): Switch is kept pressed for long time	14
Failure code [DD16LD] ◇ switch (Panel switch 2): Switch is kept pressed for long time	16
Failure code [DD17LD] < switch (Panel switch 3): Switch is kept pressed for long time	18
Failure code [DD18LD] > switch (Panel switch 4): Switch is kept pressed for long time	20
Failure code [DD1CLD] Load meter subtotal switch: Switch is kept pressed for long time	22
Failure code [DD1FLD] Load meter mode selector switch (A/B): Switch is kept pressed for long time	24
Failure code [DD1GLD] Load meter mode selector switch (+/-): Switch is kept pressed for long time	26
Failure code [DD1HLD] (Load meter display selector switch: Switch is kept pressed for long time)	28
Failure code [DD1NLD] (Fan reverse switch: Switch is kept pressed for long time)	30
Failure code [DD1NL4] (Fan automatic reverse switch: Switch is kept pressed for long time)	32
Failure code [DDB6L4] (Parking brake switch (Neutralizer): ON/OFF signals disagree)	34
Troubleshooting by failure code (Display of code), Part 6	SEN01218-00
Troubleshooting by failure code (Display of code), Part 6	4
Failure code [DDK3KA] (Right FNR switch: Disconnection)	4
Failure code [DDK6KA] (FNR lever switch: Disconnection)	7
Failure code [DDK6KB] (FNR lever switch: Short circuit)	10
Failure code [DDT0L4] (Shift mode selector switch: ON/OFF signals disagree)	12
Failure code [DDT4LD] (Transmission cut-off set switch: Switch is kept pressed for long time)	14
Failure code [DDW9LD] (Kick-down switch: Switch is kept pressed for long time)	16
Failure code [DDWLLD] (Hold switch: Switch is kept pressed for long time)	18
Failure code [DDY0LD] (Load meter cancel switch: Switch is kept pressed for long time)	20
Failure code [DF10KA] (Transmission shift lever switch: Disconnected)	22
Failure code [DF10KB] (Transmission shift lever switch: Short circuit)	26
Failure code [DGF1KA] (Transmission oil temperature sensor: Disconnected)	28
Failure code [DGF1KB] (Transmission oil temperature sensor: Short circuit)	30
Failure code [DGH2KX] (Hydraulic oil temperature sensor: Out of input signal range)	32
Failure code [DGR2KA] (Rear brake oil temperature sensor: Disconnected)	34
Failure code [DGR2KX] (Rear brake oil temperature sensor: Out of input signal range)	36
Failure code [DGT1KX] (Torque converter oil temperature sensor: Out of input signal range)	38
Troubleshooting by failure code (Display of code), Part 7	SEN01219-00
Troubleshooting by failure code (Display of code), Part 7	2
Failure code [DHPCKX] (Lift arm cylinder bottom pressure sensor: Out of input signal range)	2
Failure code [DHPDKX] (Lift arm cylinder head pressure sensor: Out of input signal range)	4
Failure code [DHT1KX] (Transmission cut-off pressure sensor: Out of input signal range)	6
Failure code [DHT8KA] (Steering pump pressure sensor: Disconnection)	8
Failure code [DHT8KB] (Steering pump pressure sensor: Short circuit)	10

Troubleshooting by failure code (Display of code), Part 8	SEN01220-00
Troubleshooting by failure code (Display of code), Part 8.....	2
Failure code [DLT3KA] (Transmission output shaft speed sensor: Disconnection).....	2
Failure code [DLT3LC] (Transmission output shaft speed sensor: Out of input signal range).....	4
Failure code [DT20KB] (Transmission cut-off indicator lamp: Short circuit)	6
Failure code [DV00KB] (Alarm buzzer: Short circuit)	8
Troubleshooting by failure code (Display of code), Part 9	SEN01221-00
Troubleshooting by failure code (Display of code), Part 9.....	2
Failure code [DW7BKA] (Fan reverse solenoid: Disconnection).....	2
Failure code [DW7BKB] (Fan reverse solenoid: Short circuit).....	3
Failure code [DW7BKY] (Fan reverse solenoid: Short circuit with power supply line)	4
Failure code [DX16KA] (Fan pump EPC solenoid: Disconnection)	6
Failure code [DX16KB] (Fan pump EPC solenoid: Short circuit).....	7
Failure code [DX16KY] (Fan pump EPC solenoid: Short circuit with power supply line)	8
Failure code [DXH1KA] (Lockup ECMV solenoid: Disconnection)	10
Failure code [DXH1KB] (Lockup ECMV solenoid: Short circuit).....	12
Failure code [DXH1KY] (Lockup ECMV solenoid: Short circuit with power supply line)	14
Failure code [DXH4KA] (1st clutch ECMV solenoid: Disconnection)	16
Failure code [DXH4KB] (1st clutch ECMV solenoid: Short circuit)	18
Troubleshooting by failure code (Display of code), Part 10	SEN01222-00
Troubleshooting by failure code (Display of code), Part 10.....	4
Failure code [DXH4KY] (1st clutch ECMV solenoid: Short circuit with power supply line).....	4
Failure code [DXH5KA] (2nd clutch ECMV solenoid: Disconnection)	6
Failure code [DXH5KB] (2nd clutch ECMV solenoid: Short circuit)	8
Failure code [DXH5KY] (2nd clutch ECMV solenoid: Short circuit with power supply line).....	10
Failure code [DXH6KA] (3rd clutch ECMV solenoid: Disconnection)	12
Failure code [DXH6KB] (3rd clutch ECMV solenoid: Short circuit).....	14
Failure code [DXH6KY] (3rd clutch ECMV solenoid: Short circuit with power supply line)	16
Failure code [DXH7KA] (R clutch ECMV solenoid: Disconnection).....	18
Failure code [DXH7KB] (R clutch ECMV solenoid: Short circuit)	20
Failure code [DXH7KY] (R clutch ECMV solenoid: Short circuit with power supply line)	22
Failure code [DXH8KA] (F clutch ECMV solenoid: Disconnection)	24
Failure code [DXH8KB] (F clutch ECMV solenoid: Short circuit).....	26
Failure code [DXH8KY] (F clutch ECMV solenoid: Short circuit with power supply line)	28
Failure code [DXHHKA] (4th clutch ECMV solenoid: Disconnection).....	30
Failure code [DXHHKB] (4th clutch ECMV solenoid: Short circuit)	32
Failure code [DXHHKY] (4th clutch ECMV solenoid: Short circuit with power supply line)	34
Troubleshooting of electrical system (E-mode)	SEN01223-00
Troubleshooting of electrical system (E-mode).....	3
Before carrying out troubleshooting for electrical system.....	3
Information in troubleshooting table	6
E-1 Engine does not start	7
E-2 Wiper does not operate.....	14
E-3 Windshield washer does not operate	18
E-4 Headlamp, clearance lamp, tail lamp, and license lamp do not light up or go off	22
E-5 Working lamp does not light up or go off.....	30
E-6 Turn signal lamp and hazard lamp do not light up or go off	35
E-7 Brake lamp does not light or it keeps lighting up	41
E-8 Backup lamp does not light or it keeps lighting up	43
E-9 Backup buzzer does not sound or it keeps sounding	45
E-10 Horn does not sound or it keeps sounding	47
E-11 Alarm buzzer does not sound or it keeps sounding	50
E-12 Air conditioner does not operate or stop	52
E-13 The KOMTRAX system does not work properly	55
Troubleshooting of hydraulic and mechanical system (H-mode)	SEN01224-00
Troubleshooting of hydraulic and mechanical system (H-mode)	3
Method of using troubleshooting chart	3

Table of failure modes and causes	6
H-1 The machine does not start	10
H-2 Torque converter lockup is not switched off (engine stalls) [Machine with lockup clutch (if equipped)]	12
H-3 Torque converter lockup is not switched on [Machine with lockup clutch (if equipped)]	13
H-4 The travel speed is slow, the thrusting force is weak, the uphill traveling power is weak, and the gear is not shifted	14
H-5 Shocks are large at the times of starting and shifting gear	16
H-6 Time lag is large at the times of starting and shifting gear	18
H-7 The torque converter oil temperature is high	20
H-8 Steering does not turn	21
H-9 Steering does not turn [Machine with joystick steering (if equipped)]	22
H-10 Steering response is low	23
H-11 Turning, response of steering is poor [machine with joystick steering (if equipped)]	24
H-12 Steering is heavy	25
H-13 When machine turns, it shakes or makes large shocks	26
H-14 When machine turns, it shakes or makes large shocks [machine with joystick steering (if equipped)]	27
H-15 The wheel brake does not work or does not work well	28
H-16 The wheel brake is not released or it drags	29
H-17 The parking brake does not work or does not work well	30
H-18 The parking brake is not released or it drags (including emergency release system)	31
H-19 Lift arm does not rise	32
H-20 Lift arm speed is low or rising force of lift arm is insufficient	33
H-21 When rising, the lift arm comes to move slowly at specific height	34
H-22 The lift arm cylinder cannot hold down the bucket (Bucket floats)	34
H-23 Hydraulic drifts of the lift arm is large	34
H-24 The lift arm wobbles during operation	34
H-25 Bucket does not tilt back	35
H-26 Bucket speed is low or tilting back force is insufficient	36
H-27 The bucket comes to operate slowly in the midst of tilting-back	37
H-28 The bucket cylinder cannot hold down the bucket	37
H-29 Hydraulic drifts of the bucket is large	37
H-30 The bucket wobbles during travel with cargo (The work equipment valve is set to "HOLD")	37
H-31 Lift arm and bucket control levers do not move smoothly and are heavy	38
H-32 During operation of the machine, engine speed lowers remarkably or engine stalls	39
H-33 Large shock is made when work equipment starts and stops	39
H-34 When work equipment circuit is relieved singly, other work equipment moves	39
H-35 ECSS does not operate, and pitching, bouncing occur	40
Troubleshooting of engine (S-mode)	SEN01225-00
Troubleshooting of engine (S-mode)	3
Method of using troubleshooting chart	3
S-1 Engine does not start easily	6
S-2 Engine does not start	7
S-3 Engine does not pick up smoothly	10
S-4 Engine stops during operations	11
S-5 Engine does not rotate smoothly	12
S-6 Engine lacks output (or lacks power)	13
S-7 Exhaust smoke is black (Incomplete combustion)	14
S-8 Oil consumption is excessive (or exhaust smoke is blue)	15
S-9 Engine oil becomes contaminated quickly	16
S-10 Fuel consumption is excessive	17
S-11 Coolant contains oil (blows back or reduces)	18
S-12 Oil pressure drops	19
S-13 Oil level rises (Water, fuel in oil)	20
S-14 Coolant temperature rises too high (Overheating)	21
S-15 Abnormal noise is made	22

S-16 Vibration is excessive	23
50 Disassembly and assembly	
General information on disassembly and assembly	SEN01461-00
General information on disassembly and assembly.....	2
How to read this manual	2
Coating materials list	4
Special tools list	7
Engine and cooling system	SEN01462-00
Engine and cooling system	2
Removal and installation of fuel supply pump assembly	2
Removal and installation of fuel injector assembly	4
Removal and installation of cylinder head assembly	9
Removal and installation of engine hood.....	18
Removal and installation of radiator assembly	20
Removal and installation of air aftercooler.....	22
Removal and installation of hydraulic oil cooler assembly	24
Removal and installation of engine assembly	26
Removal and installation of cooling fan and fan motor assembly.....	31
Removal and installation of fuel tank assembly.....	34
Power train	SEN01463-00
Power train	2
Removal and installation of torque converter and transmission assembly	2
Disassembly and assembly of torque converter assembly (Standard specification)	8
Disassembly and assembly of torque converter assembly (Lockup specification).....	12
Disassembly and assembly of transmission assembly.....	18
Disassembly and assembly of transmission clutch pack assembly.....	33
Disassembly and assembly of parking brake assembly	49
Removal and installation of front axle assembly	54
Removal and installation of rear axle assembly	56
Disassembly and assembly of axle housing	59
Disassembly and assembly of differential assembly	68
Steering system	SEN01464-00
Steering system.....	2
Removal and installation of steering demand valve assembly	2
Brake system	SEN01465-00
Brake system	2
Removal and installation of parking brake discs and plates	2
Undercarriage and frame	SEN01466-00
Undercarriage and frame	2
Removal and installation of center hinge pin.....	2
Removal and installation of counterweight	10
Hydraulic system	SEN01467-00
Hydraulic system.....	2
Removal and installation of work equipment control valve assembly.....	2
Removal and installation of power train pump and work equipment pump assembly	4
Removal and installation of steering pump and cooling fan pump assembly	5
Removal and installation of hydraulic tank assembly	6
Work equipment	SEN01468-00
Work equipment	2
Removal and installation of work equipment assembly	2
Disassembly and assembly of hydraulic cylinder assembly	6
Cab and its attachments	SEN01469-00
Cab and its attachments.....	2
Removal and installation of operator's cab and floor frame assembly	2

Removal and installation of operator's cab glass (stuck glass)	5
Removal and installation of air conditioner unit assembly	13
Electrical system	SEN01470-00
Electrical system	2
Removal and installation of engine controller assembly.....	2
90 Diagrams and drawings	
Hydraulic diagrams and drawings	SEN01022-00
Hydraulic diagrams and drawings	2
Power train hydraulic circuit diagram.....	2
Hydraulic circuit diagram	5
Electrical diagrams and drawings	SEN01023-01
Electrical diagrams and drawings.....	3
Electrical circuit diagram (1/2)	3
Electrical circuit diagram (2/2)	5
Connector arrangement diagram.....	7

WHEEL LOADER**WA380-6****Machine model Serial number**

WA380-6 H60051 and up

00 Index and foreword
Foreword and general information

Safety notice	2
How to read the shop manual	7
Explanation of terms for maintenance standard	9
Handling electric equipment and hydraulic component	11
How to read electric wire code	23
Precautions when carrying out operation	26
Method of disassembling and connecting push-pull type coupler	29
Standard tightening torque table	32
Conversion table	36

Safety notice

(Rev. 2006/09)

Important safety notice

Proper service and repair are extremely important for safe machine operation. The service and repair techniques recommended by Komatsu and described in this manual are both effective and safe. Some of these techniques require the use of tools specially designed by Komatsu for the specific purpose.

To prevent injury to workers, the symbol  is used to mark safety precautions in this manual. The cautions accompanying these symbols should always be followed carefully. If any dangerous situation arises or may possibly arise, first consider safety, and take the necessary actions to deal with the situation.

1. General precautions

 **Mistakes in operation are extremely dangerous. Read the Operation and Maintenance Manual carefully before operating the machine.**

- 1) Before carrying out any greasing or repairs, read all the safety plates stuck to the machine. For the locations of the safety plates and detailed explanation of precautions, see the Operation and Maintenance Manual.
- 2) Decide a place in the repair workshop to keep tools and removed parts. Always keep the tools and parts in their correct places. Always keep the work area clean and make sure that there is no dirt, water, or oil on the floor. Smoke only in the areas provided for smoking. Never smoke while working.
- 3) When carrying out any operation, always wear safety shoes and helmet. Do not wear loose work clothes, or clothes with buttons missing.
 - Always wear safety glasses when hitting parts with a hammer.
 - Always wear safety glasses when grinding parts with a grinder, etc.
- 4) When carrying out any operation with 2 or more workers, always agree on the operating procedure before starting. Always inform your fellow workers before starting any step of the operation. Before starting work, hang UNDER REPAIR warning signs in the operator's compartment.
- 5) Only qualified workers must carry out work and operation which require license or qualification.
- 6) Keep all tools in good condition, learn the correct way to use them, and use the proper ones of them. Before starting work, thoroughly check the tools, machine, forklift, service car, etc.

- 7) If welding repairs are needed, always have a trained and experienced welder carry out the work. When carrying out welding work, always wear welding gloves, apron, shielding goggles, cap and other clothes suited for welding work.
- 8) Before starting work, warm up your body thoroughly to start work under good condition.

Safety points

1	Good arrangement
2	Correct work clothes
3	Following work standard
4	Making and checking signs
5	Prohibition of operation and handling by unlicensed workers
6	Safety check before starting work
7	Wearing protective goggles (for cleaning or grinding work)
8	Wearing shielding goggles and protectors (for welding work)
9	Good physical condition and preparation
10	Precautions against work which you are not used to or you are used to too much

2. Preparations for work

- 1) Before adding oil or making any repairs, park the machine on hard and level ground, and apply the parking brake and block the wheels or tracks to prevent the machine from moving.
- 2) Before starting work, lower the work equipment (blade, ripper, bucket, etc.) to the ground. If this is not possible, insert the lock pin or use blocks to prevent the work equipment from falling. In addition, be sure to lock all the control levers and hang warning signs on them.


- 3) When disassembling or assembling, support the machine with blocks, jacks, or stands before starting work.
- 4) Remove all mud and oil from the steps or other places used to get on and off the machine. Always use the handrails, ladders or steps when getting on or off the machine. Never jump on or off the machine. If it is impossible to use the handrails, ladders or steps, use a stand to provide safe footing.
- 3. Precautions during work**
 - 1) Before disconnecting or removing components of the oil, water, or air circuits, first release the pressure completely from the circuit. When removing the oil filler cap, a drain plug, or an oil pressure pickup plug, loosen it slowly to prevent the oil from spurting out.
 - 2) The coolant and oil in the circuits are hot when the engine is stopped, so be careful not to get scalded. Wait for the oil and coolant to cool before carrying out any work on the oil or water circuits.
 - 3) Before starting work, stop the engine. When working on or around a rotating part, in particular, stop the engine. When checking the machine without stopping the engine (measuring oil pressure, revolving speed, temperature, etc.), take extreme care not to get rolled or caught in rotating parts or moving parts.
 - 4) Before starting work, remove the leads from the battery. Always remove the lead from the negative (-) terminal first.
 - 5) When raising a heavy component (heavier than 25 kg), use a hoist or crane. Before starting work, check that the slings (wire ropes, chains, and hooks) are free from damage. Always use slings which have ample capacity and install them to proper places. Operate the hoist or crane slowly to prevent the component from hitting any other part. Do not work with any part still raised by the hoist or crane.
 - 6) When removing a cover which is under internal pressure or under pressure from a spring, always leave 2 bolts in diagonal positions. Loosen those bolts gradually and alternately to release the pressure, and then remove the cover.
 - 7) When removing components, be careful not to break or damage the electrical wiring. Damaged wiring may cause electrical fires.
 - 8) When removing piping, stop the fuel or oil from spilling out. If any fuel or oil drips onto the floor, wipe it up immediately. Fuel or oil on the floor can cause you to slip and can even start fires.
 - 9) As a general rule, do not use gasoline to wash parts. Do not use it to clean electrical parts, in particular.
 - 10) Be sure to assemble all parts again in their original places. Replace any damaged parts and parts which must not be reused with new parts. When installing hoses and wires, be sure that they will not be damaged by contact with other parts when the machine is operated.
 - 11) When installing high pressure hoses, make sure that they are not twisted. Damaged tubes are dangerous, so be extremely careful when installing tubes for high pressure circuits. In addition, check that connecting parts are correctly installed.
 - 12) When assembling or installing parts, always tighten them to the specified torques. When installing protective parts such as guards, or parts which vibrate violently or rotate at high speed, be particularly careful to check that they are installed correctly.
 - 13) When aligning 2 holes, never insert your fingers or hand. Be careful not to get your fingers caught in a hole.
 - 14) When measuring hydraulic pressure, check that the measuring tools are correctly assembled.
 - 15) Take care when removing or installing the tracks of track-type machines. When removing the track, the track separates suddenly, so never let anyone stand at either end of the track.
 - 16) If the engine is operated for a long time in a place which is not ventilated well, you may suffer from gas poisoning. Accordingly, open the windows and doors to ventilate well.

4. Precautions for sling work and making signs


- 1) Only one appointed worker must make signs and co-workers must communicate with each other frequently. The appointed sign maker must make specified signs clearly at a place where he is seen well from the operator's seat and where he can see the working condition easily. The sign maker must always stand in front of the load and guide the operator safely.
 - Do not stand under the load.
 - Do not step on the load.
- 2) Check the slings before starting sling work.
- 3) Keep putting on gloves during sling work. (Put on leather gloves, if available.)
- 4) Measure the weight of the load by the eye and check its center of gravity.
- 5) Use proper sling according to the weight of the load and method of slinging. If too thick wire ropes are used to sling a light load, the load may slip and fall.
- 6) Do not sling a load with 1 wire rope alone. If it is slung so, it may rotate and may slip out of the rope. Install 2 or more wire ropes symmetrically.

⚠ Slinging with 1 rope may cause turning of the load during hoisting, untwisting of the rope, or slipping of the rope from its original winding position on the load, which can result in a dangerous accident.

- 7) Limit the hanging angle to 60°, as a rule. Do not sling a heavy load with ropes forming a wide hanging angle from the hook. When hoisting a load with 2 or more ropes, the force subjected to each rope will increase with the hanging angle. The table below shows the variation of allowable load in kN {kg} when hoisting is made with 2 ropes, each of which is allowed to sling up to 9.8 kN {1,000 kg} vertically, at various hanging angles. When the 2 ropes sling a load vertically, up to 19.6 kN {2,000 kg} of total weight can be suspended. This weight is reduced to 9.8 kN {1,000 kg} when the 2 ropes make a hanging angle of 120°. If the 2 ropes sling a 19.6 kN {2,000 kg} load at a lifting angle of 150°, each of them is subjected to a force as large as 39.2 kN {4,000 kg}.



- 8) When installing wire ropes to an angular load, apply pads to protect the wire ropes. If the load is slippery, apply proper material to prevent the wire rope from slipping.
- 9) Use the specified eyebolts and fix wire ropes, chains, etc. to them with shackles, etc.
- 10) Apply wire ropes to the middle portion of the hook.
 - Slinging near the tip of the hook may cause the rope to slip off the hook during hoisting. The hook has the maximum strength at the middle portion.



- 11) Do not use twisted or kinked wire ropes.
- 12) When lifting up a load, observe the following.
 - Wind in the crane slowly until wire ropes are stretched. When settling the wire ropes with the hand, do not grasp them but press them from above. If you grasp them, your fingers may be caught.
 - After the wire ropes are stretched, stop the crane and check the condition of the slung load, wire ropes, and pads.

- If the load is unstable or the wire rope or chains are twisted, lower the load and lift it up again.
- Do not lift up the load slantly.

13) When lifting down a load, observe the following.

- When lifting down a load, stop it temporarily at 30 cm above the floor, and then lower it slowly.
- Check that the load is stable, and then remove the sling.
- Remove kinks and dirt from the wire ropes and chains used for the sling work, and put them in the specified place.

5. **Precautions for using mobile crane**

★ Read the Operation and Maintenance Manual of the crane carefully in advance and operate the crane safely.

6. **Precautions for using overhead hoist crane**

⚠ When raising a heavy part (heavier than 25 kg), use a hoist, etc. In Disassembly and assembly, the weight of a part heavier than 25 kg is indicated after the mark of .

- 1) Before starting work, inspect the wire ropes, brake, clutch, controller, rails, over wind stop device, electric shock prevention earth leakage breaker, crane collision prevention device, and power application warning lamp, and check safety.
- 2) Observe the signs for sling work.
- 3) Operate the hoist at a safe place.
- 4) Check the direction indicator plates (east, west, south, and north) and the directions of the control buttons without fail.
- 5) Do not sling a load slantly. Do not move the crane while the slung load is swinging.
- 6) Do not raise or lower a load while the crane is moving longitudinally or laterally.
- 7) Do not drag a sling.
- 8) When lifting up a load, stop it just after it leaves the ground and check safety, and then lift it up.
- 9) Consider the travel route in advance and lift up a load to a safe height.
- 10) Place the control switch on a position where it will not be an obstacle to work and passage.
- 11) After operating the hoist, do not swing the control switch.
- 12) Remember the position of the main switch so that you can turn off the power immediately in an emergency.

13) If the hoist stops because of a power failure, turn the power switch OFF. When turning on a switch which was turned OFF by the electric shock prevention earth leakage breaker, check that the devices related to that switch are not in operation state.

14) If you find an obstacle around the hoist, stop the operation.

15) After finishing the work, stop the hoist at the specified position and raise the hook to at least 2 m above the floor. Do not leave the sling installed to the hook.

7. **Selecting wire ropes**

1) Select adequate ropes depending on the weight of parts to be hoisted, referring to the table below.

Wire ropes
(Standard "Z" twist ropes without galvanizing)
(JIS G3525, No. 6, Type 6X37-A)

Nominal diameter of rope	Allowable load	
mm	kN	ton
10	8.8	0.9
12	12.7	1.3
14	17.3	1.7
16	22.6	2.3
18	28.6	2.9
20	35.3	3.6
25	55.3	5.6
30	79.6	8.1
40	141.6	14.4
50	221.6	22.6
60	318.3	32.4

★ The allowable load is one-sixth of the breaking strength of the rope used (Safety coefficient: 6).

8. Precautions for disconnecting and connecting hoses and tubes in air conditioner circuit

1) Disconnection


⚠ Collect the air conditioner refrigerant gas (R134a).

⚠ If the refrigerant gas (R134a) gets in your eyes, you may lose your sight. Accordingly, when collecting or adding it, you must be qualified for handling the refrigerant and put on protective goggles.

2) Connection

- 1] When installing the air conditioner circuit hoses and tubes, take care that dirt, dust, water, etc. will not enter them.
- 2] When connecting the air conditioner hoses and tubes, check that O-rings (1) are fitted to their joints.
- 3] Check that each O-ring is not damaged or deteriorated.
- 4] When connecting the refrigerant piping, apply compressor oil for refrigerant (R134a) (**DENSO: ND-OIL8, ZEXEL: ZXL100PG (equivalent to PAG46)**) to its O-rings.

★ Example of O-ring (Fitted to every joint of hoses and tubes)



★ For tightening torque, see the precautions for installation in each section of "Disassembly and assembly".

How to read the shop manual

- Some attachments and optional parts in this shop manual may not be delivered to certain areas. If one of them is required, consult KOMATSU distributors.
- Materials and specifications are subject to change without notice.
- Shop manuals are divided into the “Chassis volume” and “Engine volume”. For the engine unit, see the engine volume of the engine model mounted on the machine.

1. Composition of shop manual

This shop manual contains the necessary technical information for services performed in a workshop. For ease of understanding, the manual is divided into the following sections.

00. Index and foreword

This section explains the shop manuals list, table of contents, safety, and basic information.

01. Specification

This section explains the specifications of the machine.

10. Structure, function and maintenance standard

This section explains the structure, function, and maintenance standard values of each component. The structure and function sub-section explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting. The maintenance standard sub-section explains the criteria and remedies for disassembly and service.

20. Standard value table

This section explains the standard values for new machine and judgement criteria for testing, adjusting, and troubleshooting. This standard value table is used to check the standard values in testing and adjusting and to judge parts in troubleshooting.

30. Testing and adjusting

This section explains measuring instruments and measuring methods for testing and adjusting, and method of adjusting each part. The standard values and judgement criteria for testing and adjusting are explained in Testing and adjusting.

40. Troubleshooting

This section explains how to find out failed parts and how to repair them. The troubleshooting is divided by failure modes. The “S mode” of the troubleshooting related to the engine may be also explained in the Chassis volume and Engine volume. In this case, see the Chassis volume.

50. Disassembly and assembly

This section explains the special tools and procedures for removing, installing, disassembling, and assembling each component, as well as precautions for them. In addition, tightening torque and quantity and weight of coating material, oil, grease, and coolant necessary for the work are also explained.

90. Diagrams and drawings (chassis volume)/Repair and replacement of parts (engine volume)

- Chassis volume
This section gives hydraulic circuit diagrams and electrical circuit diagrams.
- Engine volume
This section explains the method of reproducing, repairing, and replacing parts.

2. Revision and distribution

Any additions, revisions, or other change of notices will be sent to KOMATSU distributors. Get the most up-to-date information before you start any work.

3. Filing method

File by the brochures in the correct order of the form number printed in the shop manual composition table.

- **Revised edition mark**

When a manual is revised, the ones and tens digits of the form number of each brochure is increased by 1. (Example: 00, 01, 02 ...)

- **Revisions**

Revised brochures are shown in the shop manual composition table.

4. Symbols

Important safety and quality portions are marked with the following symbols so that the shop manual will be used practically.

Symbol	Item	Remarks
	Safety	Special safety precautions are necessary when performing work.
	Caution	Special technical precautions or other precautions for preserving standards are necessary when performing work.
	Weight	Weight of parts of component or parts. Caution necessary when selecting hoisting wire, or when working posture is important, etc.
	Tightening torque	Places that require special attention for tightening torque during assembly.
	Coat	Places to be coated with adhesives, etc. during assembly.
	Oil, coolant	Places where oil, etc. must be added, and capacity.
	Drain	Places where oil, etc. must be drained, and quantity to be drained.

5. Units

In this shop manual, the units are indicated with International System of units (SI). For reference, conventionally used Gravitational System of units is indicated in parentheses { }.

Explanation of terms for maintenance standard

The maintenance standard values necessary for judgment of products and parts are described by the following terms.

1. Standard size and tolerance

- To be accurate, the finishing size of parts is a little different from one to another.
- To specify a finishing size of a part, a temporary standard size is set and an allowable difference from that size is indicated.
- The above size set temporarily is called the “standard size” and the range of difference from the standard size is called the “tolerance”.
- The tolerance with the symbols of + or – is indicated on the right side of the standard size.

Example:

Standard size	Tolerance
120	-0.022
	-0.126


- ★ The tolerance may be indicated in the text and a table as [standard size (upper limit of tolerance/lower limit of tolerance)].

Example) 120 (-0.022/-0.126)

- Usually, the size of a hole and the size of the shaft to be fitted to that hole are indicated by the same standard size and different tolerances of the hole and shaft. The tightness of fit is decided by the tolerance.
- Indication of size of rotating shaft and hole and relationship drawing of them

Example:

Standard size	Tolerance	
	Shaft	Hole
60	-0.030	+0.046
	-0.076	0



2. Standard clearance and standard value

- The clearance made when new parts are assembled is called the “standard clearance”, which is indicated by the range from the minimum clearance to the maximum clearance.
- When some parts are repaired, the clearance is generally adjusted to the standard clearance.
- A value of performance and function of new products or equivalent is called the “standard value”, which is indicated by a range or a target value.
- When some parts are repaired, the value of performance/function is set to the standard value.

3. Standard interference

- When the diameter of a hole of a part shown in the given standard size and tolerance table is smaller than that of the mating shaft, the difference between those diameters is called the “interference”.
- The range (A – B) from the difference (A) between the minimum size of the shaft and the maximum size of the hole to the difference (B) between the maximum size of the shaft and the minimum size of the hole is the “standard interference”.
- After repairing or replacing some parts, measure the size of their hole and shaft and check that the interference is in the standard range.

4. Repair limit and allowable value

- The size of a part changes because of wear and deformation while it is used. The limit of changed size is called the “repair limit”.
- If a part is worn to the repair limit must be replaced or repaired.
- The performance and function of a product lowers while it is used. A value below which the product can be used without causing a problem is called the “allowable value”.
- If a product is worn to the allowable value, it must be checked or repaired. Since the permissible value is estimated from various tests or experiences in most cases, however, it must be judged after considering the operating condition and customer's requirement.

5. Clearance limit

- Parts can be used until the clearance between them is increased to a certain limit. The limit at which those parts cannot be used is called the “clearance limit”.
- If the clearance between the parts exceeds the clearance limit, they must be replaced or repaired.

6. Interference limit

- The allowable maximum interference between the hole of a part and the shaft of another part to be assembled is called the “interference limit”.
- The interference limit shows the repair limit of the part of smaller tolerance.
- If the interference between the parts exceeds the interference limit, they must be replaced or repaired.

Handling electric equipment and hydraulic component


To maintain the performance of the machine over a long period, and to prevent failures or other troubles before they occur, correct “operation”, “maintenance and inspection”, “troubleshooting”, and “repairs” must be carried out. This section deals particularly with correct repair procedures for mechatronics and is aimed at improving the quality of repairs. For this purpose, it gives sections on “Handling electric equipment” and “Handling hydraulic equipment” (particularly gear oil and hydraulic oil).

Points to remember when handling electric equipment

1. Handling wiring harnesses and connectors

Wiring harnesses consist of wiring connecting one component to another component, connectors used for connecting and disconnecting one wire from another wire, and protectors or tubes used for protecting the wiring.


Compared with other electrical components fitted in boxes or cases, wiring harnesses are more likely to be affected by the direct effects of rain, water, heat, or vibration. Furthermore, during inspection and repair operations, they are frequently removed and installed again, so they are likely to suffer deformation or damage. For this reason, it is necessary to be extremely careful when handling wiring harnesses.



2. Main failures occurring in wiring harness


1) Defective contact of connectors (defective contact between male and female)

Problems with defective contact are likely to occur because the male connector is not properly inserted into the female connector, or because one or both of the connectors is deformed or the position is not correctly aligned, or because there is corrosion or oxidization of the contact surfaces. The corroded or oxidized contact surfaces may become shiny again (and contact may become normal) by connecting and disconnecting the connector about 10 times.




2) Defective crimping or soldering of connectors

The pins of the male and female connectors are in contact at the crimped terminal or soldered portion, but if there is excessive force brought to bear on the wiring, the plating at the joint will peel and cause improper connection or breakage.




3) Disconnections in wiring

If the wiring is held and the connectors are pulled apart, or components are lifted with a crane with the wiring still connected, or a heavy object hits the wiring, the crimping of the connector may separate, or the soldering may be damaged, or the wiring may be broken.



4) High-pressure water entering connector


The connector is designed to make it difficult for water to enter (drip-proof structure), but if high-pressure water is sprayed directly on the connector, water may enter the connector, depending on the direction of the water jet. Accordingly, take care not to splash water over the connector. The connector is designed to prevent water from entering, but at the same time, if water does enter, it is difficult for it to be drained. Therefore, if water should get into the connector, the pins will be short-circuited by the water, so if any water gets in, immediately dry the connector or take other appropriate action before passing electricity through it.



5) Oil or dirt stuck to connector

If oil or grease are stuck to the connector and an oil film is formed on the mating surface between the male and female pins, the oil will not let the electricity pass, so there will be defective contact. If there is oil or grease stuck to the connector, wipe it off with a dry cloth or blow it dry with compressed air and spray it with a contact restorer.

- ★ When wiping the mating portion of the connector, be careful not to use excessive force or deform the pins.
- ★ If there is oil or water in the compressed air, the contacts will become even dirtier, so remove the oil and water from the compressed air completely before cleaning with compressed air.




3. Removing, installing, and drying connectors and wiring harnesses

1) Disconnecting connectors

1] Hold the connectors when disconnecting.

When disconnecting the connectors, hold the connectors. For connectors held by a screw, loosen the screw fully, then hold the male and female connectors in each hand and pull apart. For connectors which have a lock stopper, press down the stopper with your thumb and pull the connectors apart.


★ Never pull with one hand.



9JS03904

2] When removing from clips


- Both of the connector and clip have stoppers, which are engaged with each other when the connector is installed.



9JS03905

- When removing a connector from a clip, pull the connector in a parallel direction to the clip for removing stoppers.

★ If the connector is twisted up and down or to the left or right, the housing may break.




9JS02120

3] Action to take after removing connectors

After removing any connector, cover it with a vinyl bag to prevent any dust, dirt, oil, or water from getting in the connector portion.

★ If the machine is left disassembled for a long time, it is particularly easy for improper contact to occur, so always cover the connector.



9JS02122

2) Connecting connectors

1] Check the connector visually.

Check that there is no oil, dirt, or water stuck to the connector pins (mating portion).

Check that there is no deformation, defective contact, corrosion, or damage to the connector pins.

Check that there is no damage or breakage to the outside of the connector.

- ★ If there is any oil, water, or dirt stuck to the connector, wipe it off with a dry cloth. If any water has got inside the connector, warm the inside of the wiring with a dryer, but be careful not to make it too hot as this will cause short circuits.

- ★ If there is any damage or breakage, replace the connector.

2] Fix the connector securely.

Align the position of the connector correctly, and then insert it securely.


For connectors with the lock stopper, push in the connector until the stopper clicks into position.

3] Correct any protrusion of the boot and any misalignment of the wiring harness.


For connectors fitted with boots, correct any protrusion of the boot. In addition, if the wiring harness is misaligned, or the clamp is out of position, adjust it to its correct position.

- ★ If the connector cannot be corrected easily, remove the clamp and adjust the position.


- If the connector clamp has been removed, be sure to return it to its original position. Check also that there are no loose clamps.



9JS03906



9JS02124



9JS02125