



**HONDA**

Product: 1989-1990 Honda CBR600F(M) Motorcycle Service Repair Workshop Manual

Full Download: <https://www.arepairmanual.com/downloads/1989-1990-honda-cbr600fm-motorcycle-service-repair-workshop-manual/>

**SHOP MANUAL**



**HONDA**

**ADV**



**CBR600F<sub>M</sub>**

© HONDA MOTOR CO., LTD. 1990

Sample of manual. Download All 220 pages at:

<https://www.arepairmanual.com/downloads/1989-1990-honda-cbr600fm-motorcycle-service-repair-workshop-manual/>

## Important Safety Notice

**WARNING** Indicates a strong possibility of severe personal injury or death if instructions are not followed.

**CAUTION:** Indicates a possibility of equipment damage if instructions are not followed.

**NOTE:** Gives helpful information.

Detailed descriptions of standard workshop procedures, safety principles and service operations are not included. It is important to note that this manual contains *some* warnings and cautions against some specific service methods which could cause **PERSONAL INJURY** to service personnel or could damage a vehicle or render it unsafe. Please understand that those warnings could not cover all conceivable ways in which service, whether or not recommended by Honda, might be done or of the possibly hazardous consequences of each conceivable way, nor could Honda investigate all such ways. Anyone using service procedures or tools, whether or not recommended by Honda, *must satisfy himself thoroughly* that neither personal safety nor vehicle safety will be jeopardized by the service methods or tools selected.

### Type Codes

- Throughout this addendum, the following abbreviations are used to identify individual model.
- The asterisk (\*) indicates that this addendum is applicable for the corresponding area type.

Code	Available	Area Type
ED	*	European direct sales
E	*	U. K.
F	*	France
G (GI/GII)	*	Germany (Full power/Limited power)
U	*	Australia
SA		South Africa
ND		North Europe
SW	*	Switzerland
SD	*	Sweden
FI	*	Finland
N		Norway
IT	*	Italy
B		Belgium
H		Netherland
AR	*	Austria
D (DK, DM)		General export (km/h, mph)
SP	*	Spain

# Introduction

This service manual describes the service procedures of the CBR600F.

This Model Specific Manual includes every service procedure that is of a specific nature to this particular model. Basic service procedures that are common to other Honda Motorcycle/Motor Scooter/ATV Common Service Manual. This Model Specific Service Manual should be used together with the Common Service Manual in order to provide complete service information on all aspects this motorcycle.

Performing the first scheduled maintenance is very important.

It compensates for the initial wear that occurs during the break-in period.

Section 1 and 3 apply to the whole motorcycle, section 2 illustrates procedures for removal/installation of components that may be required to perform service describe parts of the motorcycle, grouped according locations.

Find the section you want on this page, then turn the table of contents on the first page of the section.

Most sections describe the service procedure through system illustration. Refer to the next page for details on how to use this manual.

If you don't know the source of the trouble, go to section 20 Troubleshooting.

**ALL INFORMATION, ILLUSTRATION, DIRECTIONS AND SPECIFICATIONS INCLUDED IN THIS PUBLICATION ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF APPROVAL FOR PRINTING. HONDA MOTOR CO., LTD. RESERVES THE RIGHT TO MAKE CHANGES AT ANY TIME WITHOUT INCURRING ANY OBLIGATION WHATEVER. NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT WRITTEN PERMISSION. THIS MANUAL IS WRITTEN FOR PERSONS WHO HAVE ACQUIRED BASIC KNOWLEDGE OF MAINTENANCE ON HONDA MOTORCYCLES, MOTOR SCOOTERS OR ATVS.**

**HONDA MOTOR CO., LTD.  
SERVICE PUBLICATION OFFICE**


# Contents

General Information	1
Frame/Body Panels/Exhaust System	2
Maintenance	3
Lubrication System	4
Cooling System	5
Fuel System	6
Engine Removal/Installation	7
Cylinder Head	8
Clutch/Gearshift Linkage	9
Crankcase/Cylinder/Piston	10
Crankshaft/Transmission	11
Chassis	
Front Wheel/Suspension/Steering	12
Rear Wheel/Suspension	13
Brake System	14
Electrical	
Charging System/Alternator	15
Ignition System	16
Electric Starter/Starter Clutch	17
Lights/Meters/Switches	18
Wiring Diagram	19
Troubleshooting	20

## How to Use This Manual


## **Finding The Information You Need**

- This manual is divided into sections which cover each of the major components of the motorcycle. To quickly find the section you are interested in, the first page of each section is marked with a black tab that lines up with one of the thumb index tabs before this page. The first page of each section lists the table of contents within the section. Read the service information and troubleshooting related to the section before you begin working.
- An index of the entire book is provided in the last chapter to directly locate the information you need.



## Understanding The Instructions

- The removal and installation of parts are for the most part illustrated by large and clear illustrations that should provide the reader with visual aid in understanding the major point for servicing.
- The system illustrations are augmented by callouts whose numbers or letters indicate the order in which the parts should be removed or installed.
- The sequence of steps represented numerically are differentiated from the ones represented alphabetically to notify the reader that they must perform these steps separately.  
For example, if the steps prior and up to camshaft removal are performed with the engine installed, but the subsequent steps like cylinder head removal require engine removal, the callouts are grouped in numerical and alphabetical orders.
- The illustrations may contain symbols to indicate necessary service procedures and precautions that need to be taken. Refer to the next page for the meaning of each symbol mark.
- Also in the illustration is a chart that lists information such as the order in which the part is removed/installed, the name of the part, and some extra notes that may be needed.
- Step by step instructions are provided to supplement the illustrations when detailed explanation of the procedure is necessary or illustrations alone would not suffice.
- Service procedures required before or after the procedure described on that particular page, or inspection/adjustment procedures required following the installation of parts, are described under the title Requisite Service.
- Standard workshop procedures and knowledge covered in the Common Service Manual are abbreviated in this manual.

Part name	Number of parts	Extra notes or precautions related to the service procedure
Symbols		<p><b>System illustration</b></p> 
		<p><b>CYLINDER HEAD/CYLINDER/PISTON</b></p> <p><b>CYLINDER HEAD REMOVAL/INSTALLATION</b></p> 
		<p><b>REQUISITE SERVICE</b></p> <p>Engine removal/installation (page 2-1)</p> <p><b>PROCEDURE</b></p> <p><b>01:</b></p> <ul style="list-style-type: none"> <li>REMOVAL ORDER           <ul style="list-style-type: none"> <li>1: Cylinder head special nut</li> <li>2: Cylinder head mounting Bolt</li> <li>3: Cylinder head assembly</li> <li>4: Gasket</li> <li>5: Dowel pin</li> <li>6: Camshaft idle gear case bolt</li> <li>7: Camshaft idle gear case downpin</li> <li>8: Sealing washer</li> <li>9: Camshaft idle gear case</li> <li>10: Camshaft idle gear case downpin</li> <li>11: Carburetor insulator</li> </ul> </li> </ul> <p><b>02:</b></p> <ul style="list-style-type: none"> <li>Installation is in the reverse order of removal</li> <li>Installation: page 8-51</li> </ul> <p><b>03:</b></p> <ul style="list-style-type: none"> <li>Install with the UP marks facing up and rearward</li> <li>Installation: page 8-51</li> </ul> <p><b>04:</b></p> <ul style="list-style-type: none"> <li>At installation, align the insulator groove with the engine lug with the UP marks facing towards carburetor side!</li> </ul>
		<p><b>CAMSHAFT IDLE GEAR CASE INSTALLATION</b></p> <p>Install the camshaft idle gear case downpins properly</p> <p><b>NOTE</b></p> <ul style="list-style-type: none"> <li>If the downpins are not installed properly, the camshaft idle gear may not be able to be installed onto the crank shaft timing gear.</li> </ul> <p>Install the camshaft idle gear case onto the cylinder. While moving the idle gear tightly with the gear case held, the gear case should be fitted up tightly from the cylinder.</p> <p>Install a new sealing washer and mounting bolts. Tighten bolts in a clockwise sequence, as shown.</p>
		
		<p><b>CYLINDER HEAD NUT/BOLT INSTALLATION</b></p> <p>Install the cylinder head special nuts as shown. Do not tighten them yet.</p> <p>Install the cylinder head mounting bolts. Tighten the special nuts and mounting bolts in a gradual crosswise pattern.</p> <p><b>TORQUE</b></p> <p>Special nut: 30 N·m (3.0 kg·m, 22 ft·lb)</p> <p>Mounting bolt: 12 N·m (1.2 kg·m, 9 ft·lb)</p> 
8-4		<p><b>Detailed description of the procedure</b></p>

## Symbols

The symbols used throughout this manual show specific service procedures. If supplementary information is required pertaining to these symbols, it would be explained specifically in the text without the use of the symbols.

	Replace the part(s) with new one(s) before assembly.
	Use special tool.
	Use optional tool. Use the same procedure you use to order parts.
	Torque specification 10 N·m (1.0 kg-m, 7.2 ft-lb).
	Use recommended engine oil, unless otherwise specified.
	Use molybdenum oil solution (mixture of engine oil and molybdenum grease in a ratio of 1 : 1).
	Use multi-purpose grease (Lithium based multi-purpose grease NLGI #2 or equivalent).
	Use molybdenum disulfide grease (containing more than 3% molybdenum disulfide, NLGI #2 or equivalent). Example: Molykote® BR-2 plus manufactured by Dow Corning, U.S.A. Multi-purpose M-2 manufactured by Mitsubishi Oil Japan
	Use molybdenum disulfide paste (containing more than 40% molybdenum disulfide, NLGI #2 or equivalent). Example: Molykote® G-n Paste manufactured by Dow Corning, U.S.A. Honda Moly 60 (U.S.A. only) Rocol ASP manufactured by Rocol Limited, U.K. Rocol Paste manufactured by Sumico Lubricant, Japan
	Use silicone grease.
	Apply a locking agent. Use a middle strength locking agent unless otherwise specified.
	Apply sealant.
	Use brake fluid, DOT 4. Use the recommended brake fluid, unless otherwise specified.
	Use Fork or Suspension Fluid.

# 1. General Information

1

General Safety	1-1	Tools	1-17
Model Identification	1-3	Lubrication & Seal Points	1-18
Specifications	1-4	Cable & Harness Routing	1-20
Torque Values	1-14		

## General Safety

### Carbon Monoxide

If the engine must be running to do some work, make sure the area is well ventilated. Never run the engine in an enclosed area.

**WARNING**

- The exhaust contains poisonous carbon monoxide gas that can cause loss of consciousness and may lead to death.**

Run the engine in an open area or with an exhaust evacuation system in an enclosed area.

### Gasoline

Work in a well ventilated area. Keep cigarettes, flames or sparks away from the work area or where gasoline is stored.

**WARNING**

- Gasoline is extremely flammable and is explosive under certain conditions. KEEP OUT OF REACH OF CHILDREN.**

### Hot Components

**WARNING**

- Engine and exhaust system parts become very hot and remain hot for some time after the engine is run. Wear insulated gloves or wait until the engine and exhaust system have cooled before handling these parts.**

### Used Engine/Transmission Oil

**WARNING**

- Used engine oil (or transmission oil in two-strokes) may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil.**

**KEEP OUT OF REACH OF CHILDREN**

### Brake Dust

Never use an air hose or dry brush to clean brake assemblies.

**WARNING**

- Inhaled asbestos fibers have been found to cause respiratory disease and cancer.**

### Brake Fluid

**WARNING**

- Spilling fluid on painted, plastic or rubber parts will damage them. Place a clean shop towel over these parts whenever the system is serviced. KEEP OUT OF REACH OF CHILDREN.**

### Coolant

Under some conditions, the ethylene glycol in engine coolant is combustible and its flame is not visible. If the ethylene glycol does ignite, you will not see any flame, but you can be burned.

#### WARNING

- Avoid spilling engine coolant on the exhaust system or engine parts. They may be hot enough to cause the coolant to ignite and burn without visible flame.
- Coolant (ethylene glycol) can cause some skin irritation and is poisonous if swallowed. **KEEP OUT OF REACH OF CHILDREN.**
- Do not remove the radiator cap when the engine is hot. The coolant is under pressure and could scald you.
- Keep hands and clothing away from the cooling fan, as it starts automatically.

If it contacts your skin, wash the affected areas immediately with soap and water. If it contacts your eyes, flush them thoroughly with fresh water and get immediate medical attention. If it is swallowed, the victim must be forced to vomit then rinse mouth and throat with fresh water before obtaining medical attention. Because of these dangers, always store coolant in a safe place, away from the reach of children.

### Nitrogen Pressure

For shock absorbers with a gas-filled reservoir.

#### WARNING



- The shock absorber contains nitrogen under high pressure. Allowing fire or heat near the shock absorber could lead to an explosion that could result in serious injury.
- Failure to release the pressure from a shock absorber before disposing of it may lead to a possible explosion and serious injury if it is heated or pierced.

### Battery Hydrogen Gas & Electrolyte

#### WARNING

- The battery gives off explosive gases; keep sparks, flames and cigarettes away. Provide adequate ventilation when charging.
- The battery contains sulfuric acid (electrolyte). Contact with skin or eyes may cause severe burns. Wear protective clothing and a face shield.
- If electrolyte gets on your skin, flush with water.
- If electrolyte gets in your eyes, flush with water for at least 15 minutes and call a physician.
- Electrolyte is poisonous.
- If swallowed, drink large quantities of water or milk and follow with milk of magnesia or vegetable oil and call a physician. **KEEP OUT OF REACH OF CHILDREN.**


## Model Identification



(1) FRAME SERIAL NUMBER

**(1) FRAME SERIAL NUMBER**


The frame serial number is stamped on the right side of the steering head.



(2) ENGINE SERIAL NUMBER

**(2) ENGINE SERIAL NUMBER**


The engine serial number is stamped on the upper crankcase.



(3) CARBURETOR IDENTIFICATION NUMBERS

**(3) CARBURETOR IDENTIFICATION NUMBER**

The carburetor identification numbers are on the carburetor body intake sides.



(4) COLOR CODE LABEL

**(4) COLOR CODE LABEL**

The color code label is attached on the frame under the right side cover. When ordering color-coded part, always specify its deginated color.

## Specifications

General		Item	Specifications
Dimentions	Overall length G I, GII, GIII, SW, AR type	2,010 mm (79.1 in) 2,130 mm (83.9 in)	
	Overall width	695 mm (27.4 in)	
	Overall height	1,130 mm (44.5 in)	
	Wheelbase	1,405 mm (55.3 in)	
	Seat height	810 mm (31.9 in)	
	Footpeg height	370 mm (14.6 in)	
	Ground clearance	145 mm (5.7 in)	
	Dry weight	185 kg (407.9 lb)	
	Curb weight	205 kg (452 lb)	
	Maximum weight capacity	190 kg (419 lb)	
Frame	Frame type Front suspension Front wheel travel Rear suspension Rear wheel travel Rear damper Front tire size (Bridgestone) (Michelin) Rear tire size (Bridgestone) (Michelin) Tire brand (Bridgestone) FR/RR Tire brand (Dunlop) FR/RR Tire brand (Yokohama) FR/RR Tire brand (Michelin) FR/RR Front brake Rear brake Caster angle Trail length Fuel tank capacity Fuel tank reserve capacity	Diamond Telescopic fork 130 mm (5.1 in) Swingarm 110 mm (4.3 in) Decarbon type 120/60 VR17 V260 120/60 ZR17 160/60 VR17 V260 160/60 ZR17 CY16G/CY20B  A59X/M59X Hydraulic disc brake (Double) Hydraulic disc brake 25° 10' 94 mm (3.7 in) 16.0 ℥ (4.23 US gal, 3.52 Imp gal) 3.0 ℥ (0.8 US gal, 0.7 Imp gal)	
Engine	Bore and stroke Displacement Compression ratio Valve train Intake valve open at (1mm lift) Intake valve close at (1mm lift) Exhaust valve open at (1mm lift) Exhaust valve close at (1mm lift) Lubrication system Oil pump type Cooling system Air filtration Crankshaft type Engine dry weight SW, AR type Firing order Cylinder arrengement	65.0×45.2 mm (2.56×1.78 in) 599 cc (36.5 cu-in) 11.6 : 1 Overhead camshaft chain drive 15° BTDC 35° ABDC 38° BBDC 7° ATDC Forced pressure and wet sump Trochoid Liquid cooled Paper filter Unit type, 5 main journals 60.7 kg (133.8 lb) 61.6 kg (135.8 lb) 1-2-4-3 4 cylinders inline	
		↑ Front 	

## General (cont'd)

Item		Specifications
Carburetor	Carburetor type Throttle bore	Constant Velocity 34 mm (1.3 in)
Drive train	Clutch system	Wet multi-plate
	Clutch operation system	Cable operating
	Transmission	6-speed constant mesh
	Primary reduction	1.864 (82/44)
	Secondary reduction	—
	Third reduction	—
	Final reduction	2.867 (43/15)
	Gear ratio 1st	2.929 (41/14)
	Gear ratio 2nd	2.063 (33/16)
	Gear ratio 3rd	1.588 (27/17)
	Gear ratio 4th	1.368 (26/19)
	Gear ratio 5th	1.200 (24/20)
	Gear ratio 6th	1.087 (25/23)
	Gear ratio reverse	—
	Gear shift pattern	1-N-2-3-4-5-6
Electrical	Ignition system Starting system Charging system Regulator/rectifier type Lighting system AC regulator type	Full transistor ignition Starter motor Triple phase out put alternator SCR shorted/triple phase full-wave rectification Battery



Unit : mm (in)

Lubrication	Item	Standard	Service Limit
Engine oil capacity at draining at disassembly at oil filter change		3.2 ℥ (3.38 US qt, 2.82 Imp qt) 4.0 ℥ (4.23 US qt, 3.52 Imp qt) 3.5 ℥ (3.70 US qt, 3.08 Imp qt)	_____
Recommended engine oil		Use Honda 4-stroke Oil or equivalent API Service Classification : SE, SF or SG. Viscosity : SAE 10W-40	_____
	OIL VISCOSITIES	Other viscosity shown in the chart may be used when the average temperature in your riding area is within the indicated range.	_____
Oil pressure at oil pressure switch		14.7 kPa (0.15 kg/cm², 2.1 psi)	_____
Oil pump rotor tip clearance	body clearance	0.15-0.22 (0.006-0.009)	0.20 (0.008)
	end clearance	0.15-0.22 (0.006-0.009)	0.35 (0.014)
		0.02-0.07 (0.001-0.003)	0.10 (0.004)


### Fuel System

Carburetor identification number	SW type AR type	VP40A VP43A VP44A # 135	_____
Main jet		_____	_____
(High altitude) (2,3) (1,4) (Front) (Rear)		_____	_____
Slow jet		# 38	_____
Jet needle clip position		2-1/4 turns out	_____
Pilot screw initial opening	SW type AR type	3 turns out 2-5/8 turns out	_____
high altitude adjustment final opening		1/2 turn out	_____
Air screw initial opening		_____	_____
Air screw high altitude adjustment		_____	_____
Float level		13.7 (0.54)	_____
Idle speed	SW, AR type	1,200 $\pm$ 100 min <sup>-1</sup> (rpm) 1,400 $\pm$ 50 min <sup>-1</sup> (rpm)	_____
Trottle grip free play		2-6 mm	_____
Accelerator pump clearance		_____	_____


## Cylinder Head

Item	Standard	Service Limit
Cylinder compression	1,261-1,287kPa (12.6-12.9 kg/cm <sup>2</sup> , 179-183 psi)	—
Valve clearance at cold temperature (below 35°C/95°F) IN EX	0.13-0.19 (0.005-0.007) 0.19-0.25 (0.007-0.010)	—
Cylinder head warpage	—	0.1 (0.04)
Cam lobe height ① IN EX	36.140-36.380 (1.4228-1.4323) 35.300-35.540 (1.3898-1.3992)	36.11 (1.422) 35.27 (1.389)
		
Camshaft runout ②	—	0.05 (0.002)
Camshaft oil clearance	0.020-0.062 (0.0008-0.0024)	0.1 (0.004)
Camshaft journal O.D. ③	23.959-23.980 (0.9433-0.9441)	24.955 (0.9825)
Camshaft holder I.D.	24.000-24.021 (0.9449-0.9457)	—
Valve stem O.D. IN EX	3.975-3.990 (0.1565-0.1571) 3.965-3.980 (0.1561-0.1567)	3.965 (0.1561) 3.955 (0.1557)
Valve guide I.D. IN EX	4.000-4.012 (0.1575-0.1580) 4.000-4.012 (0.1575-0.1580)	4.04 (0.159) 4.04 (0.159)
Stem-to-guide clearance IN EX	0.005-0.042 (0.0002-0.0017) 0.015-0.052 (0.0006-0.0020)	—
Valve guide projection above cylinder head (h) IN EX	31.27-31.87 (1.2311-1.2547) 31.31-31.91 (1.2327-1.2563)	—
	Before guide installation: 1. Chill the valve guides in the freezer section of a refrigerator for about one hour. 2. Heat the cylinder head to 100-150°C (212-300°F).	
Valve seat width	0.9-1.1 (0.035-0.043)	1.5 (0.06)
Valve spring free length Inner	31.92 (1.257)	30.62 (1.206)
Outer	35.36 (1.392)	33.86 (1.333)
Inner IN	—	—
Inner EX	—	—
Outer IN	—	—
Outer EX	—	—
Rocker arm I.D. IN EX	—	—
Rocker arm shaft O.D. IN EX	—	—
Rocker arm-to-rocker arm shaft clearance	—	—
Valve lifter O.D.	25.978-25.993 (1.0228-1.0233)	25.968 (1.0224)
Valve lifter bore I.D.	26.010-26.026 (1.0240-1.0246)	26.040 (1.0252)
Hydraulic lash adjuster assist spring free length	—	—
Hydraulic lash adjuster compression stroke with kerosene	—	—

**Cylinder/Piston**

Item	Standard	Service Limit
Cylinder I.D. out of round taper warpage	65.000-65.015 (2.5591-2.5596) _____ _____	65.10 (2.563) 0.10 (0.004) 0.10 (0.004) 0.10 (0.004)
Piston mark direction	"IN" mark facing the intake side	
Piston O.D. (D)	64.970-64.990 (2.5579-2.5587)	64.90 (2.555)
Piston O.D. measurement point (H)	11 (0.4) from the bottom	
Piston pin hole I.D. (d)	17.002-17.008 (0.6694-0.6696)	17.02 (0.670)
		
Cylinder-to-piston clearance	0.010-0.045 (0.0004-0.0018)	
Piston pin O.D.	16.993-17.000 (0.6690-0.6693)	16.98 (0.669)
Piston-to-piston pin clearance	0.002-0.015 (0.0001-0.0006)	
Connecting rod-to-piston pin clearance	0.016-0.041 (0.0006-0.0016)	
Top ring-to-ring groove clearance	0.025-0.060 (0.0010-0.0024)	0.08 (0.003)
Second ring-to-ring groove clearance	0.015-0.050 (0.0006-0.0020)	0.08 (0.003)
Top ring end gap	0.20-0.35 (0.008-0.014)	0.5 (0.02)
Second ring end gap	0.35-0.50 (0.014-0.020)	0.7 (0.03)
Oil ring (side rail) end gap	0.2-0.7 (0.01-0.03)	1.0 (0.04)
Top ring mark	"T" or "R"	
Second ring mark	"T" or "RN"	

**Crankshaft**

Connecting rod small end I.D.	17.016-17.034 (0.6699-0.6706)	17.04 (0.671)
Connecting rod big end side clearance radial clearance	0.05-0.20 (0.002-0.008)	0.30 (0.012)
Crankshaft runout ①	_____	0.05 (0.002)
		
Crankpin oil clearance	0.028-0.052 (0.0011-0.0020)	0.06 (0.002)
Crankpin bearing selection	See page 11-4.	
Main journal oil clearance	0.023-0.047 (0.0009-0.0019)	0.05 (0.002)
Main journal bearing selection	See page 11-4.	

**Kickstarter**

Kickstarter pinion gear I.D.	_____	_____
Kickstarter spindle O.D.	_____	_____
Countershaft O.D. at kickstarter idle gear	_____	_____
Kickstarter idle gear bushing O.D. I.D.	_____	_____

Unit : mm (in)

**Clutch System**

Item	Standard	Service Limit
Clutch lever free play	10-20 (0.4-0.8)	—
Clutch outer I.D.	—	—
Clutch outer guide O.D.	34.975-34.991 (1.3770-1.3776)	34.965 (1.3766)
I.D.	21.994-22.007 (0.8659-0.8664)	22.017 (0.8668)
Mainshaft O.D. at clutch outer guide	21.980-21.993 (0.8654-0.8659)	21.95 (0.864)
Clutch spring free height	—	—
Clutch spring free length	48.9 (1.93)	47.5 (1.87)
Clutch disc thickness	2.92-3.08 (0.115-0.121)	2.60 (0.102)
Clutch disc thickness A	—	—
B	—	—
Clutch plate warpage	—	0.30 (0.012)
Centrifugal clutch drum I.D.	—	—
bushing O.D.	—	—
Centrifugal clutch center guide I.D.	—	—
O.D.	—	—
Centrifugal clutch center guide collar height	—	—
Centrifugal clutch weight lining thickness	—	—
Clutch lining thickness	—	—
Crankshaft O.D. at clutch center	—	—

**Cooling System**

Coolant capacity (Radiator and engine) (Reserve tank)	2.4 ℥ (0.63 US gal, 0.53 Imp gal) 0.35 ℥ (0.09 US gal, 0.08 Imp gal)	—
Radiator cap relief pressure	110-140 kPa (1.1-1.4 kg/cm <sup>2</sup> , 15.6-19.9 psi)	—
Thermostat cap relief pressure	80-84°C (176-183°F)	—
Thermostat fully open	95°C (203°F)	—
Thermostat valve lift	8 (0.3) min	—



**Drive Train**

Final drive gear oil capacity at disassembly at draining	—	—
Recommended final drive oil	—	—
Final drive gear backlash	—	—
Ring gear-to-stop pin clearance (A)	—	—
Stop pin shim	—	—
Ring gear spacer	—	—
Pinion spacer	—	—
Output gear backlash	—	—
Output gear I.D.	—	—
Output gear bushing O.D. I.D.	—	—
Output drive shaft O.D.	—	—
Output gear damper spring free length	—	—
Output shaft adjustment shim	—	—
Countershaft drive shaft adjustment shim	—	—

## General Information

Unit : mm (in)

### Transmission

Item	Standard	Service Limit
Transmission gear I.D. M5, M6 C2, C3, C4	28.000-28.021 (1.1024-1.1032) 31.000-31.025 (1.2205-1.2215)	28.04 (1.104) 31.04 (1.222)
Transmission gear bushing O.D. M5, M6 C3, C4 C2	27.959-27.980 (1.1007-1.1016) 30.950-30.975 (1.2185-1.2195) 30.959-30.980 (1.2189-1.2197)	27.94 (1.100) 30.93 (1.218) 30.94 (1.218)
Transmission gear bushing I.D. M5 C2	24.985-25.006 (0.9837-0.9845) 27.985-28.006 (1.1018-1.1026)	24.016 (0.9455) 28.021 (1.1032)
Gear-to-bushing clearance at M5, M6 gear C2, C3, C4 gear	0.020-0.062 (0.0008-0.0024) 0.020-0.070 (0.0008-0.0028)	— —
Mainshaft O.D. at M5 gear bushing ① at clutch outer guide ②	24.967-24.980 (0.9830-0.9835) 21.980-21.993 (0.8654-0.8659)	24.960 (0.9827) 21.95 (0.864)
		
Countershaft O.D. at C2 gear bushing ①	27.967-27.980 (1.0904-1.1016)	27.96 (1.101)
		
Gear bushing-to-shaft clearance at M5 gear C2 gear	0.005-0.039 (0.0002-0.0015) 0.005-0.039 (0.0002-0.0015)	— —
Shift fork claw thickness R C L	5.93-6.00 (0.233-0.236) 5.93-6.00 (0.233-0.236) 5.93-6.00 (0.233-0.236)	5.90 (0.232) 5.90 (0.232) 5.90 (0.232)
Shift fork I.D. R C L	12.000-12.021 (0.4724-0.4733) 12.000-12.021 (0.4724-0.4733) 12.000-12.021 (0.4724-0.4733)	12.030 (0.4736) 12.030 (0.4736) 12.030 (0.4736)
Shift fork shaft O.D. at R shift fork C shift fork L shift fork	11.957-11.968 (0.4707-0.4712) 11.957-11.968 (0.4707-0.4712) 11.957-11.968 (0.4707-0.4712)	11.95 (0.470) 11.95 (0.470) 11.95 (0.470)


**Wheels/Tires**

Item	Standard	Service Limit
Minimum tire thread depth (FR) (RR)	—	1.5 (0.06) 2.0 (0.08)
Cold tire pressure Up to 90 kg (200 lb) load (FR) Up to 90 kg (200 lb) load (RR) Up to maximum weight capacity (FR) Up to maximum weight capacity (RR)	250 kPa (2.50 kg/cm <sup>2</sup> , 36 psi) 290 kPa (2.90 kg/cm <sup>2</sup> , 42 psi) 250 kPa (2.50 kg/cm <sup>2</sup> , 36 psi) 290 kPa (2.90 kg/cm <sup>2</sup> , 42 psi)	— — — —
Rear and front axle runout	—	0.2 (0.01)
Front and rear wheel rim runout (Radial) (Axial)	— —	2.0 (0.08) 2.0 (0.08)
Front wheel hub-to-rim distance	—	—
Front wheel hub standard surface	—	—
Rear wheel hub-to-rim distance	—	—
Rear wheel hub standard surface	—	—
Wheel balance weight Front/Rear	—	60 g (0.13 lb)
Drive chain slack	15-25 (0.6-1.0)	—
Drive chain size/link (DID) (RK)	DID50V4/108 RK50MFO/108	— —



**Front Suspension**

Fork spring free length	443.2 (17.45)	434.3 (17.10)
Fork spring free length (A) (B)	— —	— —
Fork spring direction	With tightly wound coil facing down	—
Fork tube runout	—	0.20 (0.01)
Recommended fork oil	—	—
Fork oil level	—	—
Fork oil level (R) (L)	118 (4.65)	— —
Fork oil capacity	508 cc (17.1 US oz, 17.9 Imp oz)	—
Fork oil capacity (R) (L)	— —	— —
Fork air pressure	—	—
Steering bearing preload	0.10-0.15 kg-m (0.73-1.09 ft-lb)	—

**Rear Suspension**

Shock absorber spring free length	139.2 (5.48)	136.4 (5.37)
Shock absorber spring free length (A) (B)	— —	— —
Damper gas pressure	10 kg/cm <sup>2</sup> (980 kPa)	—
Damper compression gas	Nitrogen	—
Damper rod compressed force at (0.4 in) 10 mm compressed	15.4 kg(111.39 ft-lb)	—
Damper drilling point	10 (0.4) mm from the top surface	—
		
Shock absorber spring installed length (Standard) (Adjustable range)	— —	— —
Shock absorber spring direction	Tightly wound coil facing upward	—
Recommended shock absorber oil	—	—
Shock absorber oil capacity air pressure	— —	— —

## Brakes

Item	Standard	Service Limit
Front brake fluid	DOT 4	
brake lever free play	To the groove ①	
brake pad wear indicator		
		
brake disc thickness	4.8-5.2 (0.19-0.20)	4.0 (0.20)
brake disc runout		0.30 (0.012)
master cylinder I.D.	12.700-12.743 (0.5000-0.5017)	12.76 (0.502)
master piston O.D.	12.657-12.684 (0.4983-0.4994)	12.65 (0.498)
caliper cylinder I.D.	25.400-25.450 (1.0000-1.0020)	25.46 (1.002)
caliper cylinder I.D. (Upper)		
(Lower)		
caliper piston O.D.	25.335-25.368 (0.9974-0.9987)	25.33 (0.997)
caliper piston O.D. (Upper)		
(Lower)		
brake drum I.D.		
brake lining thickness		
Rear	DOT 4	
brake fluid	To the groove ②	
brake pedal height		
brake pedal free play		
brake pad wear indicator		
		
brake disc thickness	4.8-5.2 (0.19-0.20)	4.0 (0.20)
brake disc runout		0.30 (0.012)
master cylinder I.D.	12.700-12.743 (0.5000-0.5017)	12.76 (0.502)
master piston O.D.	12.657-12.684 (0.4983-0.4994)	12.65 (0.498)
caliper cylinder I.D.	38.180-38.230 (1.5031-1.5051)	38.24 (1.506)
caliper piston O.D.	38.098-38.148 (1.4999-1.5019)	38.09 (1.500)
brake drum I.D.		
brake lining thickness		

## Battery/Charging System

Alternator chaging coil resistance (At 20° C/68° F)	0.1-1.0Ω	
Regulator regurated voltage/amperage	13.0-15.5V/1A MAX at 5,000 rpm	
Battery capacity	12V-8AH	
Battery specific gravity (Fully charging) (Needs charging)		
Battery charging rate (Normal) (Quick)	0.9A (5-10 hours)	
Battery voltage (Fully charged at 20° C/68° F) (Needs charging at 20° C/68° F)	4.0A (1 hour)	
Alternator lighting coil resistance (At 20° C/68° F)	Over 13.0V	
AC regulator regulated voltage (with analogue type) (with digital type)	Below 12.3V	

Unit : mm (in)

**Ignition System**

Item	H Standard	Service Limit
Spark plug (Standard NGK) (Standard ND) (For cold climate/below 5°C/41°F NGK) (For cold climate/below 5°C/41°F ND) (For extended high speed riding NGK) (For extended high speed riding ND)	CR9EX9 U27FER9 _____	_____
Spark plug gap	0.8-0.9 (0.03-0.04)	_____
Ignition timing "F" mark	Except SW type SW type	15° BTDC/1,200 ± 100 min⁻¹(rpm) 5° BTDC/1,400 ± 50 min⁻¹(rpm)
Advance start stop	_____	_____
Full advance	42° BTDC/5,500 ± 100 min⁻¹(rpm)	_____
Alternator exciter coil resistance (At 20°C/68°F)	0.1-1.0Ω	_____
Ignition coil resistance (Primary at 20°C/68°F) (Secondary with plug cap) (Secondary without plug cap)	2.5-3.1Ω 21-25kΩ 11-15kΩ	_____
Pulse generator resistance (At 20°C/68°F)	460-580Ω	_____

**Starting System**

Starter driven gear O.D. Starter clutch outer I.D. Starter motor brush spring tension brush length	51.699-51.718 (2.0354-2.0361) _____	51.684 (2.0348) _____
	12.0-13.0 (0.47-0.51)	4.5 (0.18)

**Lights/Meters/Switches**

Main fuse	30A	_____
Fuse	10A × 3 + 15A × 1	_____
Headlight (high/low beam)	12V 60/55W	_____
Tail/brakelight	12V 21/5W × 2	_____
Position light	12V 4W	_____
Front turn signal light	12V 21W × 2	_____
Rear turn signal light	12V 21W × 2	_____
Instrument light	12V 1.7W × 4	_____
Oil pressure warning indicator	12V 3.4W	_____
Side stand indicator	12V 1.7W	_____
Low fuel indicator	_____	_____
Coolant temperature indicator	_____	_____
Oil temperature indicator	_____	_____
High beam indicator	12V 3.4W	_____
Turn signal indicator	12V 3.4W × 2	_____
Neutral indicator	12V 3.4W	_____
Reverse indicator	_____	_____
Overdrive indicator	_____	_____
Oil temperature sensor resistance (At 20°C/68°F)	_____	_____
Fuel unit resistance (At full level) (At low level)	_____	_____
Fuel pump flow capacity (Min./minute)	_____	_____
Coolant temperature sensor resistance (At 80°C/176°F) (At 120°C/248°F)	45-60Ω 10-20Ω	_____
Fan motor switch Starts to close (ON) Stop to open (OFF)	98-102°C (208-216°F) 93-97°C (199-207°F)	_____

## Torque Values

### Standard

Fastners type	Torque		Fastners type	Torque	
	N · m (kg-m, ft-lb)	N · m (kg-m, ft-lb)		N · m (kg-m, ft-lb)	N · m (kg-m, ft-lb)
5mm hex bolt and nut	5 (0.5, 3.5)		5mm screw	4 (0.4, 3)	
6mm bolt and nut	10 (1.0, 7)		6mm screw	9 (0.9, 7)	
8mm bolt and nut	22 (2.2, 16)		6mm flange bolt (8mm head)	9 (0.9, 7)	
10mm hex bolt and nut	35 (3.5, 25)		6mm flange bolt (10mm head)	12 (1.2, 9)	
12mm hex bolt and nut	55 (5.5, 40)		and nut		
			8mm flange bolt and nut	27 (2.7, 20)	
			10mm flange bolt and nut	40 (4.0, 29)	

- Torque specifications listed below are for important fasteners.
- All others sholud be tightened to standard torque values listed above.

NOTES : 1. Apply sealant to the threads.

2. Apply a locking agent to the threads.

3. Apply molybdenum disulfide oil to the threads and seating surface.

4. Left hand threads.

5. Stake.

6. Apply oil to the threads and seating surface.

7. Apply clean engine oil to the O-ring.

8. Torque wrench scale reading using a special tool.

9. Apply grease to the threads and seating surface.

10. UBS bolt.

11. Do not apply molybdenum disulfide oil to the threads and seating surface.

### Engine

Item	Q'ty	Thread dia. (mm)	Torque		Remarks
			N · m (kg-m, ft-lb)	N · m (kg-m, ft-lb)	
<b>Lubrication System :</b>					
Oil drain bolt	1	12	38 (3.8, 27)		
Oil filter cartridge	1	20	10 (1.0, 7)		
Oil filter boss	1	20	18 (1.8, 13)		
Oil pump driven sprocket bolt	1	6	15 (1.5, 11)		
Special bolt	1	—	50 (5.0, 36)		
<b>Cooling System :</b>					
Thermosensor	1	—	10 (1.0, 7)		NOTE 1
Fanmotor switch	1	—	10 (1.0, 7)		NOTE 1
<b>Fuel System :</b>					
Fuel valve joint bolt	2	10	25 (2.5, 18)		
<b>Cylinder Head :</b>					
Cylinder head bolt	10	9	48 (4.8, 35)		NOTE 3
Spark plug	4	10	12 (1.2, 9)		
Cylinder head cover bolt	6	6	10 (1.0, 7)		
Camshaft holder bolt	20	6	12 (1.2, 9)		
Cylinder head cover breather plate bolt	2	6	12 (1.2, 9)		NOTE 2
Cylinder head stud bolt	8	8	26 (2.6, 19)		
Cam sprocket bolt	4	7	20 (2.0, 14)		NOTE 2
Cylinder head sealing bolt	2	18	33 (3.3, 24)		NOTE 1
<b>Clutch/Gearshift Linkage :</b>					
Clutch center lock nut	1	20	85 (8.5, 61)		NOTE 5
Gearshift spindle return spring pin	1	8	23 (2.3, 17)		NOTE 2
Shift drum center bolt	1	8	23 (2.3, 17)		NOTE 2
Right crankcase cover bolt	10	6	12 (1.2, 9)		

## Engine (cont'd)

Item	Q'ty	Thread dia. (mm)	Torque		Remarks
			N · m (kg-m, ft-lb)		
<b>Crankcase/Cylinder/Piston :</b>					
Upper crankcase bolt	7	6	12 (1.2, 9)		
Lower crankcase bolt	14	6	12 (1.2, 9)		
	10	8	24 (2.4, 17)		
	1	10	40 (4.0, 29)		
Connecting rod bearing cap nut	8	7	26 (2.6, 19)		NOTE 6, 11
Neutral switch	1	10	12 (1.2, 9)		NOTE 1
Oil pressure switch	1	—	12 (1.2, 9)		NOTE 1
Sealing bolt	1	20	30 (3.0, 22)		NOTE 1
	1	14	25 (2.5, 18)		NOTE 1
<b>Charging System/Alternator :</b>					
Flywheel bolt	1	10	105 (10.5, 76)		
Starter clutch bolt	1	6	16 (1.6, 12)		NOTE 2
Stator bolt	4	6	12 (1.2, 9)		NOTE 2
<b>Ignition System :</b>					
Pulse generator rotor cover cap	1	45	18 (1.8, 13)		NOTE 3
Pulse generator rotor cover bolt	8	6	12 (1.2, 9)		
Pulse generator rotor bolt	1	10	60 (6.0, 43)		

## Frame

Item	Q'ty	Thread dia. (mm)	Torque		Remarks
			N · m (kg-m, ft-lb)		
<b>Frame/Body Panels/Exhaust System :</b>					
Exhaust pipe joint nut	6	7	20 (2.0, 14)		
Exhaust pipe band bolt	2	8	21 (2.1, 15)		
Side stand pivot bolt	1	10	10 (1.0, 7)		
Side stand pivot lock nut	1	10	30 (3.0, 22)		
Side stand bracket bolt	2	10	55 (5.5, 40)		
<b>Engine Mount :</b>					
Front engine hanger nut	2	10	65 (6.5, 47)		
Engine hanger adjust bolt	1	20	15 (1.5, 11)		
Engine hanger lock nut	1	20	65 (6.5, 47)		
Drive sprocket bolt	1	10	55 (5.5, 40)		
Gearshift pedal pinch bolt (pedal side)	1	8	27 (2.7, 20)		
(arm side)	1	6	16 (1.6, 12)		
<b>Front Wheel/Suspension/Steering :</b>					
Ignition switch bolt	2	8	25 (2.5, 18)		NOTE 2
Handlebar pinch bolt	2	8	27 (2.7, 20)		
Fork cap bolt	2	37	23 (2.3, 17)		
Fork socket bolt	2	8	23 (2.3, 17)		
Steering stem nut	1	24	105 (10.5, 76)		

**Frame (cont'd)**


Item	Q'ty	Thread dia.(mm)	Torque		Remarks
			N · m (kg-m, ft-lb)		
Steering adjustment nut	1	24	25 (2.5, 18)		NOTE 6 See page 12-15.
Fork pinch bolt (upper)	2	8	23 (2.3, 17)		
(lower)	2	10	40 (4.0, 29)		
Front axle bolt	1	14	60 (6.0, 43)		
Front axle pinch bolt	4	8	22 (2.2, 16)		NOTE 2
Front brake disc bolt	12	8	43 (4.3, 31)		
<b>Rear Wheel/Rear Suspension:</b>					
Drive chain adjuster lock nut	2	6	22 (2.2, 16)		
Rear axle nut	1	18	95 (9.5, 69)		
Shock absorber mounting nut	2	10	45 (4.5, 33)		
Shock link nut (frame side)	1	10	45 (4.5, 33)		
Shock link nut (shock arm side)	1	10	45 (4.5, 33)		NOTE 9
Shock arm bolt	1	10	45 (4.5, 33)		NOTE 9
Swingarm pivot nut	1	14	110 (11.0, 80)		
Drive chain adjuster lock nut	2	8	22 (2.2, 16)		NOTE 2
Rear brake disc bolt	4	8	43 (4.3, 31)		NOTE 6
Driven sprocket nut	4	12	90 (9.0, 65)		
<b>Brake System :</b>					
Rear master cylinder mounting bolt	2	6	12 (1.2, 9)		
Rear brake master cylinder reservoir bolt	1	6	9 (0.9, 7)		
Front brake caliper bracket bolt	4	8	27 (2.7, 20)		NOTE 2
Brake hose bolt	6	10	35 (3.5, 25)		
Front master cylinder holder bolt	2	6	12 (1.2, 9)		
Brake lever pivot nut	1	6	6 (0.6, 4)		
Breeder screw	3	8	6 (0.6, 4.3)		
Brake pipe three way joint bolt	1	6	10 (1.0, 7)		
Brake pad pin	5	8	18 (1.8, 13)		
Brake pad pin plug	5	8	3 (0.3, 2.2)		NOTE 6
Brake pipe flare nut	2	10	17 (1.7, 12)		NOTE 2
Caliper bracket pin bolt	3	5	13 (1.3, 9)		NOTE 2
Front brake caliper pin bolt	2	8	23 (2.3, 17)		
Rear brake caliper bracket bolt	1	10	23 (2.3, 17)		
Rear brake caliper pin bolt	1	10	28 (2.8, 20)		

## Tools

- The newly designed tools are indicated with \* mark in the list.


Description	Tool Number	Applicability	Refer to Section(s)
Oil pressure gauge	07506-3000000	Choke case, mainline pipe	4
Oil pressure gauge attachment	07510-4220100	4	4
Oil filter wrench	07HAA-PJ70100	Cylinder top cap	4
Float level gauge	07401-0010000	Valve filter	5
Pilot screw wrench	07908-4730001	Valve stem (Valve guide surface)	5
Valve spring compressor	07757-0010000	Connecting rod sleeve (inner surface)	8
Valve compressor attachment	07959-KM30101	Wash-out tool (outer surface)	8
*Tappet hole protector	07HMG-MR70002	Connecting rod sleeve	8
Valve guide driver	07GMD-KT70100	Wash-out tool (outer surface)	8
*Valve guide reamer, 4 mm	07MMH-MV90100	Connecting rod sleeve	8
Valve seat cutter 24.5 mm(EX 45°)	07780-0010100	Oil pressure gauge	8
Valve seat cutter 27.5 mm(IN 45°)	07780-0010200	8	8
Valve seat cutter 24 mm(EX 32°)	07780-0012500	8	8
*Valve seat cutter 27 mm(IN 32°)	07780-0013300	8	8
Valve seat cutter 22 mm(EX 60°)	07780-0014202	8	8
Valve seat cutter 26 mm(IN 60°)	07780-0014502	8	8
Cutter holder, 4.0 mm	07781-0010500	8	8
Clutch center holder	07JMB-MN50300	Alternator bolt	9
Lock nut wrench, 17×27 mm	07716-0020300	Pulse detector bolt	9
Extension bar	07716-0020500	Pulse detector bolt sleeve	9, 12
Pilot, 12 mm	07746-0040200	Pulse detector bolt sleeve	9
Attachment, 32×35 mm	07746-0010100	(Shaken by)	9, 13
Attachment, 28×30 mm	07949-1870100	Thermosensor	9, 13
Inner driver C	07746-0030100	Cylinder base cap	11
Attachment, 25mm I.D.	07746-0030200	Cylinder base cap sleeve	11
Bearing remover shaft	07746-0050100	Cylinder base cap sleeve	12, 13
Bearing remover head, 20 mm	07746-0050600	Oil pump drive	12, 13
Attachment, 42×47 mm	07746-0010300	Shift drum	12, 13
Attachment, 52×55 mm	07746-0010400	Shift drum	12, 13
Pilot, 15 mm	07746-0040300	Shift base plate	12, 13
Pilot, 20 mm	07746-0040500	Shift base plate	12, 13
Fork seal driver	07947-KA50100	Cylinder base cap sleeve	12
Fork seal driver attachment	07947-KF00100	Shift base plate	12
Lock nut wrench, 30×32 mm	07716-0020400	Shift base plate	12
Steering stem socket	07916-3710100	Shift base plate	12
Ball race remover	07953-MJ10000	Ball pin sleeve	12
-driver attachment	07953-MJ10100	Ball pin sleeve	12
-driver handle	07953-MJ10200	Lower cylinder sleeve	12
Ball race remover	07946-3710500	Lower cylinder sleeve	12
Driver attachment	07945-3330300	Lower cylinder sleeve	13
Pilot, 22 mm	07746-0041000	Connecting rod sleeve	13
Attachment, 24 x 26mm	07746-0010700	Cylinder base cap sleeve	13
Pilot, 17mm	07746-0040400	Cylinder base cap sleeve	13
Oil seal driver attachment	07965-KE80200	Cylinder base cap sleeve	13
Driver shaft	07946-MJ00100	Oil seal lip (without oil)	13
Needle bearing remover	07GMD-KT70200	Oil seal lip	13
Pin driver	07GMD-KT80100	Oil seal lip	13
Snap ring pliers(IN)	07914-3230001	Base ring	14
Bearing remover set	07936-KC10000	Cylinder base cap sleeve	14
-bearing remover head, 15mm	07936-KC10200	Cylinder base cap sleeve	14
-bearing handle	07936-KC10100	Cylinder base cap sleeve	14
-remover sliding weight	07741-0010201	Cylinder base cap sleeve	14
Digital multimeter(KOWA)	07411-0020000	Cylinder base cap sleeve	15, 16, 17, 18
Peak voltage adaptor	07HGJ-0020100	Model 625	16
or Imrie diagnostic tester	Model 625		15, 16, 17, 18
Analogue multimeter(SANWA)	07308-0020001		15, 16, 17, 18
Analogue multimeter(KOWA)	TH-5H		
Flywheel holder	07925-ME90000		
Rotor puller	07733-0020001		
Flywheel holder	07725-0040000		
Torx bit (T30)	07703-0010200		
Torx bit (T40)	07703-0010100		



## Lubrication & Seal Points

Engine	Location	Material	Remarks
	Cylinder head semicircular cut-out Crankcase mating surface	Liquid sealant	Wipe the excess of sealant
	Camshaft lobes/journals Valve lifter sliding surfaces Valve stem (valve guide sliding surface) Connecting rod small end inner surface Main journal bearings Connecting rod bearings M3/4, C5, C6 gear shift fork grooves	Molybdenum disulfide oil	
	Oil pressure switch threads	Sealant	
	Alternator grommet Pulse generator grommet Pulse generator rotor cover bolt threads (Marked by "Δ" mark) Thermosensor threads		
	Cylinder head cover breather plate bolt threads Cam sprocket bolt threads Oil pump driven sprocket bolt threads Shift drum bearing set plate bolt threads Starter clutch outer bolt threads Countershaft bearing set plate threads	Locking agent	Clean and apply to the threads
	Cylinder head bolt threads and seating surface Clutch outer inner surface Starter clutch sliding surface Piston sliding surface, piston ring grooves, pin bore Piston pin surface Piston rings Lower crankcase bolt threads and seating surface (main journal tightening) Connecting rod cap nut threads and seating surface Cam chain tensioner collar sliding surface Cam chain tensioner and slipper surface Gear teeth and rotating surface Oil seal lip (without dust lip) O-rings Bearings	Engine oil	
	Clutch lifter piece Oil seal lip (with dust lip)	Multipurpose grease	


Frame	Location	Material	Remarks
Side stand pivot bolt sliding surface Main stand pivot bolt sliding surface Gearshift pedal pivot Brake pedal pivot Throttle grip sliding surface Wheel dust seal lips Swingarm pivot radial ball bearing Swingarm pivot distance collar outer surface Throttle cable end	Multipurpose grease		
Swingarm pivot dust seal lips Swingarm pivot needle bearing Shock arm pivot dust seal lips Shock arm pivot needle bearing Shock link pivot dust seal lips Shock link pivot needle bearing Rear shock absorber lower mount dust seal lips Rear shock absorber lower mount needle bearing	Molybdenum disulfide grease		
Driven sprocket nut threads and seating surface	Engine oil		
Handlebar grip rubber inner surface	Honda Bond A or an equivalent		
Brake reservoir Master piston/piston seals Caliper piston Caliper piston seals	DOT 4 brake fluid		
Brake caliper boots inside Master cylinder rubber boots inside Rear master cylinder push rod top Rear brake caliper pin bolt sliding surface	Silicone grease		
Fuel valve lever boss Caliper bracket/caliper pin bolt/socket bolt threads Caliper bracket bolt threads Ignition switch bolt threads Fork socket bolt threads Handlebar weight screw threads Drive chain slider screw threads	Locking agent	Clean and apply to the threads	
Air cleaner case inlet tube joint	Sealant		

## Wiring Diagram





## General Information



## 2. Frame/Body Panels/Exhaust System

<b>Service Information</b>	<b>2-1</b>	<b>Front Cowl Disassembly/Assembly</b>	<b>2-6</b>
<b>Troubleshooting</b>	<b>2-1</b>	<b>Rear Fender B Removal/Installation</b>	<b>2-7</b>
<b>Side Cover Removal/Installation</b>	<b>2-2</b>	<b>Tail Cowl Removal/Installation</b>	<b>2-7</b>
<b>Seat Removal/Installation</b>	<b>2-2</b>	<b>Rear Fender A Removal/Installation</b>	<b>2-8</b>
<b>Side Fairing Removal/Installation</b>	<b>2-3</b>	<b>Exhaust System Removal/Installation</b>	<b>2-10</b>
<b>Front Cowl Removal/Installation</b>	<b>2-4</b>	<b>Fuel Tank Removal/Installation</b>	<b>2-11</b>

### Service Information

**WARNING**

- **Gasoline is extremely flammable and explosive under certain condition.**
- **Serious burns may result if the exhaust system is not allowed to cool before components are removed or serviced.**

- Work in a well ventilated area. Smoking or allowing flames or sparks in the working area or where gasoline is stored can cause a fire or explosion.
- This section covers removal and installation of the frame body panels, fuel tank and exhaust system.
- Frame body panel installation is in the reverse order of removal, unless noted otherwise.  
When removing the cover, be careful not to damage any tab or groove of a cover.
- Always replace the exhaust pipe gaskets when removing the exhaust pipe from the engine.
- When installing the exhaust pipe, install all the fasteners loosely. Always tighten the exhaust clamps first, then tighten the mounting fasteners. If you tighten the mounting fasteners first, the exhaust pipe may not seat properly.
- Always inspect the exhaust system for leaks after installation.

### Troubleshooting

#### Excessive Exhaust Noise


- Broken exhaust system
- Exhaust gas leak

#### Poor Performance

- Deformed exhaust system
- Exhaust gas leak
- Clogged muffler

## Side Cover Removal/Installation


Unlock the clips by aligning the long slit with the punch mark.



Remove the side cover by releasing the bosses on the cover from the grommets.


### CAUTION

- Be careful not to break the pins, tabs and slits of the side cover and tail cowl when removing the side cover.



Install the side cover aligning its bosses with the grommets and engage the tabs with the slits, and pins with the holes securely as shown.

Lock the clip by aligning the "△" mark with the punch mark. Do the same on the other side.




## Seat Removal/Installation

Remove the side covers.

Remove the seat by removing the bolts and sliding the seat back.

Install the seat in the reverse order of removal and install the side covers.




Product: 1989-1990 Honda CBR600F(M) Motocycle Service Repair Workshop Manual

Full Download: <https://www.arepairmanual.com/downloads/1989-1990-honda-cbr600fm-motocycle-service-repair-workshop-manual/>

## Side Fairing Removal/Installation

00fm-motocycle-service-repair-workshop-manual/



### Requisite Service

- Side cover removal/installation(page 2-2)

Procedure		Q'ty	Remarks
(1)	<b>Removal Order</b>		Installation is in the reverse order of removal.
(1)	Maintenance lid	2	
(2)	Tapping screw	2	
(3)	Headlight under lid	1	Release the claws from the front cowl stay. Be careful not to break off the claws.
(4)	Retaining plug	2	
(5)	Hex bolt(long)	2	
(6)	Hex bolt(short)	10	
(7)	Left side fairing	1	<p><b>NOTE</b></p> <ul style="list-style-type: none"> <li>Separate the left side fairing from the right one by disengaging the hooks on the bottoms of the fairings.</li> <li>When assembling the side fairings, align the boss on the left side fairing with the hole in the right one.</li> <li>Left and right side fairings can be removed without removing the side fairing inner covers.</li> </ul>
(8)	Right side fairing	1	Replace the speedometer cable from the cable holder on the inner cover.
(9)	Tapping screw	6	
(10)	Side fairing inner cover(right/left)	1/1	