

HOW TO USE THIS MANUAL

Follow the Maintenance Schedule (Section 3) recommendations to ensure that the scooter is in peak operating condition and the emission levels are within the standards set by the U.S. Environmental Protection Agency and the California Air Resources Board. Performing the first scheduled maintenance is very important. It compensates for the initial wear that occurs during the break-in period.

Sections 1 through 3 apply to the whole scooter, while sections 4 through 17 describe parts of the scooter, grouped according to location.

Find the section you want on this page, then turn to the table of contents on page 1 of that section.

Most sections start with an assembly or system illustration, service information and troubleshooting for the section. The subsequent pages give detailed procedures.

If you don't know the source of the trouble, go to section 18, TROUBLESHOOTING.

All information, illustration, directions and specifications included in this publication are based on the latest product information available at the time of approval for printing. HONDA MOTOR CO., LTD. reserves the right to make changes at any time without notice and without incurring any obligation whatever. No part of this publication may be reproduced without written permission.

HONDA MOTOR CO., LTD.
 Service Publications Office

CONTENTS

	GENERAL INFORMATION	1	
	LUBRICATION	2	
	MAINTENANCE	3	
ENGINE	FUEL SYSTEM	4	
	ENGINE REMOVAL/INSTALLATION	5	
	CYLINDER HEAD/VALVES	6	
	CYLINDER/PISTON	7	
	DRIVE PULLEY/CLUTCH/DRIVEN PULLEY	8	
	FINAL REDUCTION	9	
	ALTERNATOR/STARTER CLUTCH	10	
	CRANKCASE/CRANKSHAFT	11	
	COOLING SYSTEM	12	
	CHASSIS	FRAME COVERS	13
		STEERING/FRONT WHEEL/BRAKE/SUSPENSION	14
		REAR WHEEL/BRAKE/SUSPENSION	15
ELECTRICAL	ELECTRICAL EQUIPMENT	16	
	WIRING DIAGRAM	17	
	TRUBLESHOOTING	18	
	TECHNICAL FEATURES	19	
	INDEX	20	

I. GENERAL INFORMATION

GENERAL SAFETY	1-1	TOOLS	1-6
SERVICE RULES	1-1	CABLE & HARNESS ROUTING	1-7
MODEL IDENTIFICATION	1-2	EMISSION CONTROL SYSTEM	1-12
SPECIFICATIONS	1-3	EMISSION CONTROL INFORMATION LABEL	1-14
TORQUE VALUES	1-5		

GENERAL SAFETY

WARNING

If the engine must be running to do some work, make sure the area is well-ventilated. Never run the engine in a closed area. The exhaust contains poisonous carbon monoxide gas.

WARNING

Gasoline is extremely flammable and is explosive under certain conditions. Do not smoke or allow flames or sparks in your working area.

WARNING

The battery electrolyte contains sulfuric acid. Protect your eyes, skin and clothing. In case of contact, flush thoroughly with water and call a doctor if electrolyte gets in your eyes.


WARNING

The battery generates hydrogen gas which can be highly explosive. Do not smoke or allow flames or sparks near the battery, especially while charging it.


SERVICE RULES

1. Use genuine Honda or Honda-recommended parts and lubricants or their equivalents. Parts that do not meet Honda' design specifications may damage the scooter.
2. Use the special tools designed for this product.
3. Use only metric tools when servicing this scooter. Metric bolts, nuts, and screws are not interchangeable with English fasteners. The use of incorrect tools and fasteners may damage the scooter.
4. Install new gaskets, O-rings, cotter pins, lock plates, etc. when reassembling.
5. When tightening bolts or nuts, begin with larger-diameter or inner bolts first, and tighten to the specified torque diagonally, unless a particular sequence is specified.
6. Clean parts in cleaning solvent upon disassembly. Lubricate any sliding surfaces before reassembly.
7. After reassembly, check all parts for proper installation and operation.
8. Route all electrical wires as shown beginning on page 1-7, Cable & Harness Routing.

MODEL IDENTIFICATION




The VIN (Vehicle Identification Number) is attached to the left side of the inner box.




The frame serial number is stamped on the right side of the frame body.



The engine serial number is stamped on the back of the crankcase near the rear wheel.



The carburetor identification number is stamped on the right side of the carburetor.



The color label is attached to the fuel tank below the seat.

SPECIFICATIONS

< >: CH150D

	ITEM	SPECIFICATION
DIMENSIONS	Overall length Overall width Overall height Wheel base Ground clearance Dry weight	1,925 mm (75.8 in) 645 mm (25.4 in) < 655 mm (25.79 in)> 1,125 mm (44.3 in) <1,165 mm (45.87 in)> 1,200 mm (47.2 in) 125 mm (4.9 in) 105 kg (232 lb) <107 kg (236 lb)>
FRAME	Type Front suspension, travel Rear suspension, travel Vehicle capacity load Front tire size Rear tire size Front tire pressure Rear tire pressure Front brake Rear brake Fuel capacity Caster angle Trail length	Back bone Bottom link 76 mm (3.0 in) Power unit swing arm 96 mm (3.8 in) 149 kg (330 lb) 3.50—10 (-4PR), tubeless 3.50—10 (-4PR), tubeless 150 kPa (1.5 kg/cm ² , 21 psi) 200 kPa (2.0 kg/cm ² , 29 psi) Up to 90 kg (200 lbs) load 250 kPa (2.5 kg/cm ² , 36 psi) Up to vehicle capacity load Internal expanding shoes Internal expanding shoes 8.0 liters (2.1 Us gal, 1.8 Imp gal) 27° 00' 79 mm (3.1 in)
ENGINE	Type Cylinder arrangement Bore and stroke Displacement Compression ratio Engine oil capacity Lubrication system Coolant capacity Air filtration Cylinder compression Intake valve Opens Closes Exhaust valve Opens closes Valve clearance (Cold) Engine weight Idle speed	Water cooled 4-stroke, OHC engine Single cylinder 58.0 x 57.8 mm (2.283 x 2.275 in) 153 cm ³ (9.3 cu in) 10.0 : 1 1.0 liter (1.1 Us qt, 0.9 Imp qt) at disassembly 0.8 liter (0.8 US qt, 0.7 Imp qt) at draining Forced pressure and wet sump 1.0 liters (1.1 US qt, 0.9 Imp qt) Paper filter 1,300 kPa (13.0 kg/cm ² , 184 psi) 0° (BTDC) } 30° (ABDC) } at 1.1 mm lift 35° (BBDC) } 0° (ATDC) } IN/EX: 0.1 mm (0.004 in) 26.5 kg (58 lb) 1,500 ± 100 rpm

GENERAL INFORMATION

	ITEM	SPECIFICATION
CARBURETION	Identification number '85 After '85 Float level Pilot screw initial opening Main jet Slow jet	VE03A (VE04A, California model) VE03B (VE04B, California model) 18.5 mm (0.73 in) See page 4-11 #100 (#95, High altitude type) #35
DRIVE TRAIN	Clutch type Primary reduction Final reduction	Automatic centrifugal clutch, dry type 2.2–0.9 7.318 : 1
ELECTRICAL	Ignition Starting system Alternator Spark plug Spark plug gap Ignition timing "F" mark full advance Battery capacity Fuse capacity	Condenser capacitive discharge ignition (CDI) Starting motor 12V–203 W/ 5,000 rpm (ND) X22EPR-U9, X20EPR-U9 (NGK) DPR7EA-9, DPR6EA-9 0.8–0.9 mm (0.032–0.035 mm) 10° BTDC/ 1500 rpm 27° BTDC/ 4000 rpm 12 V 9 AH 20 A (Main) 10 A (Turn signal light, Brake light) 10 A (Headlight, Instruments light) 10 A (Horn, license plate light, position light)
LIGHTS	Headlight, Low/High Brake/Tail light Turn signal/Position light (front) (rear) Instrument light Turn signal indicator light High beam indicator License plate light	12 V–55/60 W 12 V–27/8 W (32/3 cp) SEA No. 1157 12 V–23/8 W (32/3 cp) SEA No. 1034 12 V–23 W (32 cp) SAE No. 1073 12 V–3.4 W x 3 (2 cp) SAE No. 158 12 V–3.4 W x 2 (2 cp) SAE No. 158 12 V–3.4 W x 2 (2 cp) SAE No. 158 12 V–8 W (4 cp)

TORQUE VALUES

ENGINE

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kg-m, ft-lb)	REMARKS
Oil bolt	1	12	18-22 (1.8-2.2, 13-16)	Left hand threads
Oil bolt	2	8	8-12 (0.8-1.2, 6-9)	
Cylinder head cap nut	4	8	20-24 (2.0-2.4, 14-17)	
Water pump impeller	1	8	10-14 (1.0-1.4, 7-10)	
Cylinder head cover bolt	5	6	8-12 (0.8-1.2, 6-9)	
Oil filter screen cap	1	36	15-30 (1.5-3.0, 11-22)	
Cam chain tensioner sealing bolt	1	8	4-6 (0.4-0.6, 2.8-4.3)	
Cam chain tensioner bolt	2	8	6-10 (0.6-1.0, 4.3-7.2)	
Clutch drive plate nut	1	28	50-60 (5.0-6.0, 36-43)	
Flywheel nut	1	14	50-60 (5.0-6.0, 36-43)	
Crankcase bolt	7	6	8-12 (0.8-1.2, 6-9)	
Drive face seal cover bolt	3	4	3-5 (0.3-0.5, 2.2-3.6)	
Drive face nut	1	12	50-60 (5.0-6.0, 36-43)	
Clutch outer nut	1	10	35-40 (3.5-4.0, 25-29)	
Transmission case cover bolt	7	6	11-14 (1.1-1.4, 8-10)	
Starter clutch socket bolt	3	6	10-14 (1.0-1.4, 7-10)	Apply a locking agent
Transmission oil level check bolt	1	10	10-15 (1.0-1.5, 7-11)	

FRAME

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kg-m, ft-lb)	REMARKS
Engine hanger stopper bolt	1	8	24-30 (2.4-3.0, 17-22)	Apply locking agent
Engine hanger bracket bolt	1	10	35-45 (3.5-4.5, 25-32)	
Engine hanger bolt	1	10	35-45 (3.5-4.5, 25-32)	
Engine mounting bolt	1	10	35-45 (3.5-4.5, 25-32)	
Front axle nut	1	12	50-70 (5.0-7.0, 36-51)	
Rear axle nut	1	14	80-100 (8.0-10.0, 58-72)	
Rear shock absorber mount bolt	4	8	24-30 (2.4-3.0, 17-22)	
Rear shock absorber damper lock nut	2	8	15-25 (1.5-2.5, 11-18)	
Top cone race	1	25.4	2-3 (0.2-0.3, 1.4-2.2)	
Steering stem nut	1	25.4	130-150 (13.0-15.0, 74-108)	
Steering stem lock nut	1	25.4	10-20 (1.0-2.0, 7-14)	
Front shock absorber:				
-lower bolt	2	8	0.8-1.2 (0.08-0.12, 0.6-0.9)	
-lower nut	2	8	15-20 (1.5-2.0, 11-14)	
-upper mount bolt	2	8	30-36 (3.0-3.6, 22-26)	
-damper lock nut	2	8	15-25 (1.5-2.5, 11-18)	Apply oil Apply locking agent
Brake arm bolt	2	6	8-12 (0.8-1.2, 6-9)	
Pivot arm bolt	2	8	20-24 (2.0-2.4, 14-17)	Apply oil
Wheel hub nut	6	8	28-32 (2.8-3.2, 20-23)	
Rear brake pedal stay	2	6	8-12 (0.8-1.2, 6-9)	
Speedometer cable set screw	1	5	1.5-3 (0.15-0.3, 1.1-2.2)	
Headlight motor attaching nut	1	8	10-12 (1.0-1.2, 7-9)	
Link arm pinch bolt	1	6	10-12 (1.0-1.2, 7-9)	
Headlight motor set nut	1	8	8-12 (0.8-1.2, 6-9)	
Exhaust muffler bolt	3	8	32-38 (3.2-3.8, 23-27)	
Exhaust pipe joint nut	2	7	27-33 (2.7-3.3, 20-24)	

Torque specifications listed above are for most of the tightening points. If a specification is not listed, follow the standard torque values below.

STANDARD TORQUE VALUES

TYPE	TORQUE N·m (kg-m, ft-lb)	TYPE	TORQUE N·m (kg-m, ft-lb)
5 mm bolt, nut	4.5-6.0 (0.45-0.6, 3.3-4.3)	5 mm screw	3.5-5 (0.35-0.5, 2.5-3.6)
6 mm bolt, nut	8-12 (0.8-1.2, 6-9)	6 mm screw, and 6 mm bolt with 8 mm head	7-11 (0.7-1.1, 5-8)
8 mm bolt, nut	18-25 (1.8-2.5, 13-18)	6 mm flange bolt, nut	10-14 (1.0-1.4, 7-10)
10 mm bolt, nut	30-40 (3.0-4.0, 22-29)	8 mm flange bolt, nut	24-30 (2.4-3.0, 17-22)
12 mm bolt, nut	50-60 (5.0-6.0, 36-43)	10 mm flange bolt, nut	35-45 (3.5-4.5, 25-32)

GENERAL INFORMATION

TOOLS

SPECIAL

DESCRIPTION	TOOL NUMBER	ALTERNATE TOOL	TOOL NUMBER	REF. SECT.
Vacuum/pressure pump	A937X-041-XXXXX	Vacuum pump (U.S.A. only) Pressure pump (U.S.A. only)	ST-AH-260-MC7 ST-AH-255-MC7	4 4
Universal bearing puller	07631-0010000	Equivalent commercially available in U.S.A.		9
Lock nut wrench, 39 mm	07916-1870002	Lock nut wrench, 39 mm	07916-1870001	8
Steering stem lock nut wrench	07916-1870101	Equivalent commercially available in U.S.A.		14
Steering stem wrench	07916-GK00000	Adjustable pin spanner	07702-0020001	14
Shaft protector	07931-1870000			9
Flywheel puller	07933-KG20000			10
Bearing remover, 12 mm (Spindle assy, 12 mm)	07936-1660001 (07936-1660100)			9, 12
(Remover weight)	(07741-0010201)	Remover weight	07936-3710200	9, 12
Bearing remover handle	07936-3710100			9
Bearing remover, 17 mm	07936-3710300			9
Remover weight	07741-0010201	Remover weight	07936-3710200	9
Valve guide driver, 5.0 mm Attachment	07942-MA60000 07945-3330300			6 14
Water seal driver	07945-4150400	Water seal driver (U.S.A. only)	GN-AH-065-415	12
Bearing driver	07946-GC80000			8, 12
Ball race remover	07946-GA70000	Race remover	07946-3710400	14
Clutch spring compressor	07960-KM10000	Spring compressor attachment Spring compressor (bolt)	07960-KM10100 07960-KJ90000	8 8
Seal and case assembly tool (Assembly collar)	07965-1480010 (07965-1480100)			9
(Assembly shaft)	(07965-1480200)			9
Spring holder attachment	07967-1180100			15
Rear shock absorber attachment	07967-GA70001	Shock absorber attachment	07967-GA70001	14, 15
Shock absorber attachment	07967-KM10100			14
Engine hanger setting tool	07973-KJ90000	Not available in U.S.A.		5
Valve guide reamer, 5.0 mm	07984-MA60000			6


COMMON

DESCRIPTION	TOOL NUMBER	ALTERNATE TOOL	TOOL NUMBER	REF. SECT.
Float level gauge	07401-0010000			4
Lock nut wrench, 30 x 32 mm	07716-0020400	Equivalent commercially available in U.S.A.		14
Extension	07716-0020500	Equivalent commercially available in U.S.A.		14
Universal holder	07725-0030000			8
Flywheel holder	07725-0040000	Band strap wrench (commercially available in U.S.A.)		10
Attachment, 32 x 35 mm	07746-0010100			8, 9, 14
Attachment, 37 x 40 mm	07746-0010200			9
Attachment, 42 x 47 mm	07746-0010300			9, 14
Attachment, 52 x 55 mm	07746-0010400			14
Pilot, 12 mm	07746-0040200			9, 14
Pilot, 15 mm	07746-0040300			15
Pilot, 20 mm	07746-0040500			8, 9
Bearing remover shaft	07746-0050100	Equivalent commercially available in U.S.A.		14
Bearing remover head, 12 mm	07746-0050300			14
Driver	07749-0010000			
Valve guide driver	07743-0020000			6
Valve spring compressor	07757-0010000			6
Shock absorber compressor	07959-3290001			14, 15

CABLE & HARNESS ROUTING



Note the following when routing cables and wire harnesses:



- A loose wire, harness or cable can be safety hazard. After clamping, check each wire to be sure it is secure.
- Do not squeeze wires against the weld or its clamp.
- Secure wires and wire harnesses to the frame with their respective wire bands at the designated locations. Tighten the bands so that only the insulated surfaces contact the wires or wire harnesses.
- Route harnesses so they are neither pulled tight nor have excessive slack.
- Protect wires and harnesses with electrical tape or tube if they contact a sharp edge or corner. Clean the attaching surface thoroughly before applying tape.
- Do not use a wire or harness with a broken insulator. Repair by wrapping them with protective tape or replace them.
- Route wire harnesses to avoid sharp edges or corners.
- Avoid the projected ends of bolts and screws.
- Keep wire harnesses away from the exhaust pipes and other hot parts.
- Be sure grommets are seated in their grooves properly.
- After clamping, check each harness to be certain that it is not interfering with any moving or sliding parts.
- After routing, check that the wire harnesses are not twisted or kinked.
- Wire harnesses routed along the handlebars should not be pulled taut, have excessive slack, be pinched by or interfere with adjacent or surrounding parts in all steering positions.
- After routing, check that the wire harnesses are not twisted or kinked.
- Do not bend or twist control cables. Damaged control cables will not operate smoothly and may stick or bind.





O: CORRECT
X: INCORRECT

GENERAL INFORMATION







GENERAL INFORMATION



CH150D:



EMISSION CONTROL SYSTEMS

The U.S. Environmental Protection Agency and California Air Resources Board (CARB) require manufactures to certify that their motor scooters comply with applicable exhaust emissions standards during their useful life, when operated and maintained according to the instructions provided, and that motor scooters built after January 1, 1983 comply with applicable noise emission standards for one year or 6,000 km (3,730 miles) after the time of sale to the ultimate purchaser, when operated and maintained according to the instructions provided. Compliance with the terms of the Distributor's Warranty for Honda Motor Scooter Emission Control Systems is necessary in order to keep the emissions system warranty in effect.

SOURCE OF EMISSIONS

The combustion process produces carbon monoxide and hydrocarbons. Control of hydrocarbons is very important because, under certain conditions, they react to form photochemical smog when subjected to sunlight. Carbon monoxide does not react in the same way, but it is toxic.


Honda Motor Co., Ltd. utilizes lean carburetor settings as well as other systems, to reduce carbon monoxide and hydrocarbons.

EXHAUST EMISSION CONTROL SYSTEM

The exhaust emission control system is composed of a lean carburetor setting, and no adjustments should be made except the idle speed adjustment with the throttle stop screw.


CRANKCASE EMISSION CONTROL SYSTEM

The engine is equipped with a closed crankcase system which routes crankcase emissions through the air cleaner and into the combustion chamber. Condensed crankcase vapors are accumulated in a storage tank which must be emptied periodically. See the Maintenance Schedule in section 3.



EVAPORATIVE EMISSION CONTROL SYSTEM (California model only)

This model complies with California Air Resources Board requirements for evaporative emission regulations. Fuel vapor from the fuel tank is routed into a charcoal canister where it is adsorbed and stored while the engine is stopped. When the engine is running and the purge control diaphragm valve is open, fuel vapor in the charcoal canister is drawn into the engine through the carburetor.



NOISE EMISSION CONTROL SYSTEM

TAMPERING WITH THE NOISE CONTROL SYSTEM IS PROHIBITED: Federal law prohibits the following acts or the causing thereof: (1) The removal or rendering inoperative by any person, other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use; or (2) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.


AMONG THOSE ACTS PRESUMED TO CONSTITUTE TAMPERING ARE THE ACTS LISTED BELOW:

1. Removal of, or puncturing the muffler, baffles, header pipes or any other component which conducts exhaust gases.
2. Removal of, or puncturing of any part of the intake system.
3. Lack of proper maintenance.
4. Replacing any moving parts of the vehicle, or parts of the exhaust or intake system, with parts other than those specified by the manufacturer.

GENERAL INFORMATION

EMISSION CONTROL INFORMATION LABEL

An Emission Control Information Label is located on the fuel tank as shown. It contains basic tune-up specifications.





EMISSION CONTROL INFORMATION UPDATE LABEL


After making a high altitude carburetor adjustment (Page 4-12), attach a vehicle emission control information update label on the fuel tank as shown.

Instructions for obtaining the update label are given in Service Letter No. 132.

VACUUM HOSE ROUTING DIAGRAM LABEL (California model only)

The Vacuum Hose Routing Diagram Label is attached to the fuel tank. Route the vacuum hoses as shown on this label.





2. LUBRICATION

SERVICE INFORMATION	2-1	OIL PUMP INSPECTION	2-3
TROUBLESHOOTING	2-1	OIL PUMP ASSEMBLY	2-4
ENGINE OIL	2-2	OIL PUMP INSTALLATION	2-5
ENGINE OIL FILTER SCREEN CLEANING	2-2	TRANSMISSION OIL	2-6
OIL PUMP REMOVAL	2-2	LUBRICATION POINTS	2-7
OIL PUMP DISASSEMBLY	2-3		

SERVICE INFORMATION

GENERAL

- This section covers maintenance of the oil pump, engine oil and transmission oil.


SPECIFICATIONS

Engine oil capacity 1.0 liter (1.1 US qt, 0.9 Imp qt) at disassembly
 0.8 liter (0.8 US qt, 0.7 Imp qt) at change

Transmission oil 0.18 liter (0.19 US qt, 0.16 Imp qt) at disassembly
 0.15 liter (0.16 US qt, 0.13 Imp qt) at change

Recommended oil Use Honda 4-Stroke Oil or equivalent.
 API Service Classification: SE or SF
 VISCOSITY: SAE 10W-40

Other viscosities shown in the chart may be used when the average temperature in your riding area is within the indicated range.



ITEM		STANDARD mm (in)	SERVICE LIMIT mm (in)
Oil pump	Rotor tip clearance	0.15 (0.006)	0.20 (0.008)
	Body clearance	0.15-0.20 (0.006-0.008)	0.25 (0.010)
	Rotor end clearance	0.04-0.09 (0.002-0.004)	0.12 (0.005)

TORQUE VALUES

Oil filter screen cap 15-30 N·m (1.5-3.0 kg-m, 11-22 ft-lb)
 Transmission oil drain bolt 11-14 N·m (1.1-1.4 kg-m, 8-10 ft-lb)
 Transmission oil level check bolt 10-15 N·m (1.0-1.5 kg-m, 7-11 ft-lb)
 Oil pump mounting bolt 8-12 N·m (0.8-1.2 kg-m, 6-9 ft-lb)

TROUBLESHOOTING

Oil Level Too Low

- External oil leaks.
- Worn valve guide or seal.
- Worn piston rings.

Poor Lubrication Pressure

- Oil level too low.
- Clogged oil filter, oil passage, and/or oil pipe.
- Faulty oil pump.

Oil Contamination

- Oil not changed often enough.
- Head gasket faulty.
- Worn piston rings.

LUBRICATION

ENGINE OIL

OIL LEVEL

Stop the engine and support the scooter upright on level ground.

Check the oil level with the filler cap/dipstick

Do not screw in the dipstick when making this check
If the level is near the lower level, fill to the upper level with the recommended engine oil (page 2-1).

OIL CHANGE

NOTE

- Drain the oil from the crankcase while the engine is warm.
This ensures complete and rapid draining.

Place an oil pan under the engine, and remove the oil filter screen cap.

After the oil has been completely drained, be sure the O-ring is in good condition and install the filter, spring and cap.

TORQUE: 15–30 N·m (1.5–3.0 kg·m, 11–22 ft·lb)

Pour the recommended oil (page 2-1) through the oil filler hole.

ENGINE OIL CAPACITY:

0.8 liter (0.8 US qt, 0.7 Imp qt) at oil change

Reset the indicator by inserting the key in the indicator slot below the instrument panel.

Reinstall the oil filler cap. Start the engine and let it idle for few minutes.

Stop the engine and recheck the oil level.
Check that there are no oil leaks.

ENGINE OIL FILTER SCREN CLEANING





Drain the engine oil.
Remove the oil filter scren and spring.
Clean the oil filter scren.
Make sure that the O-ring is in good condition.
Install the oil filter scren and spring.
Install the filter scren cap.

TORQUE: 15–30 N·m (1.5–3.0 kg·m, 11–22 ft·lb)


Fill the crankcase with the recommended oil (page 2-1) and check the oil level.

OIL PUMP REMOVAL


Remove the alternator and starter drive gear (section 10).
Remove the attaching bolt and oil separator cover.



Pry the circlip off, then remove the oil pump drive chain and driven sprocket.




Remove the two oil pump mounting bolts, and remove the oil separator and oil pump.



OIL PUMP DISASSEMBLY


Unscrew the pump cover attaching screw and disassemble the oil pump as shown.



OIL PUMP INSPECTION

Measure the pump body-to-outer rotor clearance.


SERVICE LIMIT : 0.25 mm (0.010 in)



LUBRICATION


Measure the outer rotor-to-inner rotor tip clearance.

SERVICE LIMIT : 0.20 mm (0.008 in)




Check the rotor-to-pump body clearance.

SERVICE LIMIT : 0.12 mm (0.005 in)




OIL PUMP ASSEMBLY


Install the outer and inner rotor into the pump body.
Insert the pump shaft by aligning the flat on the shaft with the flat in the inner rotor.
Install the dowel pin.



Install the pump cover by aligning the hole in the cover with the dowel pin.



Tighten the screw.
 Make sure that the pump shaft rotates freely without binding.




OIL PUMP INSTALLATION


Install the oil pump and oil separator and tighten the bolts.

TORQUE: 8–12 N·m (0.8–1.2 kg·m, 6–9 ft·lb)

Make sure that the pump shaft rotates freely.




Install the pump driven sprocket and drive chain, then set the circlip securely on the pump shaft.



Install the oil separator cover by fitting the tab of the separator cover into the slit in the separator.

Install the starter gear and alternator (section 10).




LUBRICATION

TRANSMISSION OIL


OIL LEVEL CHECK

Place the scooter on its center stand on level ground.
Stop the engine and remove the transmission oil check bolt.



The oil level should be at the oil check bolt hole.
If the level is low, fill the final reduction with the recommended oil (Page 2-1).
Install the oil check bolt.

TORQUE: 10 – 15 N·m (1.0 – 1.5 kg·m, 7 – 11 ft·lb)



OIL CHANGE

Remove the oil check bolt.
Remove the oil drain bolt and drain the oil thoroughly.
Reinstall the drain bolt.

TORQUE: 11 – 14 N·m (1.1 – 1.4 kg·m, 8 – 10 ft·lb)

Make sure that the drain-bolt sealing washer is in good condition.
Fill the final reduction with the recommended oil (Page 2-1) through the oil check bolt hole up to the bolt hole.


CAPACITY: 0.15 liter (0.16 US qt, 0.13 Imp qt) at change

Make sure that the oil check bolt sealing washer is in good condition and reinstall the oil check bolt.
Start the engine and test ride for 2 – 3 minutes.
Stop the engine and make sure that the oil level is correct.
Make sure that there are no oil leaks.

LUBRICATION POINTS

CONTROL CABLES

Periodically, disconnect the throttle and brake cables at their upper ends. Thoroughly lubricate the cables and their pivot points with a commercially available cable lubricant or a light weight oil.



3. MAINTENANCE

SERVICE INFORMATION	3-1	CYLINDER COMPRESSION	3-9
MAINTENANCE SCHEDULES	3-2	DRIVE BELT	3-9
FUEL LINE	3-4	DRIVE BELT AIR CLEANER	3-9
THROTTLE OPERATION	3-4	BATTERY	3-10
AIR CLEANER	3-5	BRAKE SHOE WEAR	3-10
CRANKCASE BREATHER	3-5	BRAKE SYSTEM	3-10
SPARK PLUG	3-5	BRAKE LOCK LEVER	3-11
VALVE CLEARANCE	3-6	BRAKE LIGHT SWITCH/STARTER	
CARBURETOR-IDLE SPEED	3-7	LIMITER SWITCH	3-12
RADIATOR COOLANT	3-7	HEADLIGHT AIM	3-12
RADIATOR CORE	3-7	CLUTCH SHOE WEAR	3-12
COOLING SYSTEM HOSES & CONNECTIONS	3-7	SIDE STAND	3-13
EVAPORATIVE EMISSION CONTROL SYSTEM	3-8	SUSPENSION	3-13
IGNITION TIMING	3-8	NUT, BOLT, FASTENER	3-14
		WHEEL	3-14
		STEERING HEAD BEARING	3-14

SERVICE INFORMATION

GENERAL

Engine oil See page 2-2
 Engine oil strainer screen See page 2-2
 Transmission (final reduction) oil See Page 2-6

SPECIFICATIONS

ENGINE

Throttle grip free play: 2–6 mm (1/8–1/4 in)
 Spark plug: Standard: DPR7EA–9 (NGK), X22EPR–U9 (ND)
 For cold climate: DPR6EA–9 (NGK), X20EPR–U9 (ND)
 (below 5°C, 41°F)
 Plug gap: 0.8–0.9 mm (0.03–0.04 in)
 Ignition timing:
 "F" mark 10° ± 3° BTDC at 1,500 rpm
 Advance starts: 10° BTDC at 2,100 rpm
 Full advance: 27° BTDC at 4,000 rpm
 Idle speed: 1,500 ± 100 rpm
 Cylinder compression: 1,300 ± 200 kPa (13 ± 2 kg/cm², 184 ± 28 psi)
 Valve clearance: IN/EX 0.1 mm (0.004 in)

CHASSIS

Front brake free play: 10–20 mm (3/8–3/4 in)
 Rear brake free play: 20–30 mm (3/4–1-1/8 in)
 Tire:

		FRONT	REAR
Tire size		3.50–10–4PR	3.50–10–4PR
Cold tire pressure kPa (kg/cm ² , psi)	Up to 90 kg (200 lbs) load	150 (1.5, 21)	200 (2.0, 28)
	Up to vehicle capacity load	150 (1.5, 21)	250 (2.5, 36)
Tire brand (Tubeless only)			
	BRIDGESTONE	ML9	ML12
	DUNLOP	F11	'85 model: K627 After '85 model: K627B

MAINTENANCE

MAINTENANCE SCHEDULES

'85:

Perform the pre-ride inspection at each scheduled maintenance period.

I: Inspect, and Clean, Adjust, Lubricate or Replace if necessary.

C: Clean R: Replace A: Adjust L: Lubricate

ITEM	FREQUENCY	WHICHEVER COMES FIRST → ↓	ODOMETER READING [NOTE (4)]				Refer to
			600 mi (1,000 km)	2,500 mi (4,000 km)	5,000 mi (8,000 km)	7,500 mi (12,000 km)	
EMISSION RELATED ITEMS	* FUEL LINE		I	I	I		3-4
	* THROTTLE OPERATION		I	I	I		3-4
	AIR CLEANER	NOTE (1)	Replace every 12,500 mi (20,000 km)				3-5
	CRANKCASE BREATHER	NOTE (2)	C	C	C		3-5
	SPARK PLUG		R	R	R		3-5
	* VALVE CLEARANCE		A	A	A	A	3-6
	ENGINE OIL	YEAR	R	Replace every 1,250 mi (2,000 km)			2-2
	ENGINE OIL FILTER SCREEN			Clean every 1,250 mi (2,000 km)			2-2
	RADIATOR COOLANT			I	Replace every 10,000 mi (16,000 km)		3-7
	* RADIATOR CORE			I			3-7
	* COOLING SYSTEM HOSE & CONNECTIONS			I			3-7
	* CARBURETOR- IDLE SPEED		I	I	I	I	3-7
	NON-EMISSION RELATED ITEMS	* EVAPORATIVE EMISSION CONTROL SYSTEM	NOTE (3)			I	
* TRANSMISSION OIL		2 YEAR R*					2-6
* DRIVE BELT				Replace every 15,000 mi (24,000 km)			3-9
BATTERY		MONTH		I	I	I	3-10
BRAKE SHOE WEAR				I	I	I	3-10
BRAKE SYSTEM			I	I	I	I	3-10
* BRAKE LOCK LEVER			I	I	I	I	3-11
* BRAKE LIGHT SWITCH				I	I	I	3-12
* STARTER LIMITER SWITCH				I	I	I	3-12
* HEADLIGHT AIM				I	I	I	3-12
** CLUTCH SHOE WEAR				I	I	I	3-12
SIDE STAND				I	I	I	3-13
* SUSPENSION				I	I	I	3-13
* NUT, BOLT, FASTENER		I	I	I	I	3-14	
** WHEEL			I	I	I	3-14	
** STEERING HEAD BERARING		I			I	3-14	

* Should be serviced by an authorized HONDA Scooter Dealer, unless the owner has proper tools and service data and is mechanically qualified.

** In the interest of safety, we recommend these items be serviced ONLY by an authorized HONDA Scooter Dealer.

NOTE: 1 Service more frequently when riding in dusty areas.

2 Service more frequently when riding in rain or at full throttle.

3 California type only.

4 For higher odometer readings, repeat at the frequency interval established here.

AFTER '85:

Perform the pre-ride inspection at each scheduled maintenance period.

I: Inspect, and Clean, Adjust, Lubricate or Replace if necessary.

C: Clean R: Replace A: Adjust L: Lubricate

ITEM	FREQUENCY	WHICHEVER COMES FIRST ↓	ODOMETER READING (NOTE (4))				Refer to page
			600 mi (1,000 km)	2,500 mi (4,000 km)	5,000 mi (8,000 km)	7,500 mi (12,000 km)	
EMISSION RELATED ITEMS	* FUEL LINE			I	I	I	3-4
	* THROTTLE OPERATION			I	I	I	3-4
	AIR CLEANER	NOTE (1)				R	3-5
	CRANKCASE BREATHER	NOTE (2)		C	C	C	3-5
	SPARK PLUG			R	R	R	3-5
	* VALVE CLEARANCE		I	I	I	I	3-6
	ENGINE OIL	YEAR	R	Replace every 1,250 mi (2,000 km)			2-2
	* ENGINE OIL FILTER SCREEN					C	2-2
	* CARBURETOR- IDLE SPEED		I	I	I	I	3-7
	RADIATOR-COOLANT	2 YEARS * R			I		3-7
NON-EMISSION RELATED ITEMS	* COOLING SYSTEM				I		3-7
	* EVAPORATIVE EMISSION CONTROL SYSTEM	NOTE (3)				I	3-8
	TRANSMISSION OIL					R	2-6
	* DRIVE BELT		I: EVERY 5,000 mi (8,000 km) R: EVERY 15,000 mi (24,000 km)				3-9
	BELT CASE AIR CLEANER	NOTE 1		C	C	C	3-9
	BATTERY			I	I	I	3-10
	BRAKE SHOE WEAR			I	I	I	3-10
	BRAKE SYSTEM		I	I	I	I	3-10
	* BRAKE LIGHT SWITCH			I	I	I	3-12
	* STARTER LIMIT SWITCH			I	I	I	3-12
* BRAKE LOCK LEVER		I	I	I	I	3-11	
* HEADLIGHT AIM			I	I	I	3-12	
** CLUTCH SHOE WEAR				I		3-12	
SIDE STAND			I	I	I	3-13	
* SUSPENSION			I	I	I	3-13	
* NOT, BOLT, FASTENER		I		I		3-14	
** WHEEL			I	I	I	3-14	
** STEERING HEAD BEARING		I			I	3-14	

* Should be serviced by an authorized HONDA Scooter Dealer, unless the owner has proper tools and service data and is mechanically qualified.

** In the interest of safety, we recommend these items be serviced ONLY by an authorized HONDA Scooter Dealer.

NOTE: 1 Service more frequently when riding in dusty areas.

2 Service more frequently when riding in rain or at full throttle.

3 California type only.

4 For higher odometer readings, repeat at the frequency interval established here.

MAINTENANCE


FUEL LINE

Remove the right rear cover (page 13-2).
Remove the fuel valve cover (page 4-13).

Check the fuel lines and replace any parts which show signs of deterioration, damage or leakage.

WARNING

- *Gasoline is flammable and is explosive under certain conditions. Do not smoke or allow flames or sparks in your working area.*




THROTTLE OPERATION

Check for smooth throttle grip movement, full opening and automatic full closing in all steering positions.
Check the throttle cable and replace it, if it is deteriorated, kinked or damaged.


Lubricate the throttle cable (Page 2-7), if throttle operation is not smooth.

Measure the throttle grip free play at the throttle grip flange.

FREE PLAY : 2 – 6 mm (1/8 – 1/4 in)




Adjustment can be made at either end of the throttle cable.
Minor adjustments are made with the upper adjuster.
Slide the rubber cover out and adjust by loosening the lock nut and turning the adjuster.



Major adjustments are made with the lower adjusting nut.
Remove the right and left rear covers and the frame center cover (page 13-2) and then adjust by loosening the lock nut and turning the adjusting nut.

Tighten the lock nut and recheck throttle operation.



AIR CLEANER



Remove the left rear cover (page 13-2).
Remove the three air cleaner case cover screws and the cover.

Remove the air cleaner element and discard it in accordance with the maintenance schedule.
Also, replace the element any time it is excessively dirty or damaged.

NOTE

- The air cleaner element has a viscous type paper element. do not try to clean.

Install the element and air cleaner case cover, and tighten the three screws.
Install the left rear cover.




CRANKCASE BREATHER

Remove the plug from the drain tube to empty any deposits.

NOTE

- Service more frequently when ridden in rain or at full throttle or if the deposit level can be seen in the transparent section of the drain tube.



SPARK PLUG


RECOMMENDED SPARK PLUGS:

	NGK	ND
Standard	DPR7EA-9	X22EPR-U9
For cold climate (below 5°C, 41°F)	DPR6EA-9	X20EPR-U9

Remove the left rear cover (page 13-2).
Disconnect the spark plug cap.
Clean any dirt from around the spark plug base.
Remove the spark plug.
Measure the new spark plug gap using a wire-type feeler gauge.

SPARK PLUG GAP: 0.8–0.9 mm (0.03–0.04 in)

Adjust by bending the side electrode carefully.
With the plug washer attached, thread the spark plug in by hand to prevent cross-threading. Tighten the spark plug another 1/2 turn with a spark plug wrench to compress the plug washer.
Then connect the spark plug cap.



MAINTENANCE


VALVE CLEARANCE

NOTE


- Inspect and adjust valve clearance while the engine is cold (below 35°C/ 95°F).

Remove the right and left rear covers and frame center cover (page 13-2).


Remove the timing hole cap from the right side of the cylinder head cover.



Remove the four screws attaching the drive belt air cleaner cover to the left crankcase cover.



Rotate the drive pulley counterclockwise so that the index mark on the cam sprocket is aligned with the cylinder head mating surface as shown to bring the piston to TDC (Top Dead Center) on the compression stroke.



Loosen fully the valve adjuster lock bolts, located on the left side of the cylinder head.


Move the intake and exhaust adjusters outward (away from each other) fully, until resistance is felt.

Then move them inwards (towards each other) the equivalent of one graduation. Tighten the adjuster lock bolts.

NOTE

- One graduation on the adjusters equals 0.10 mm (0.004 in), which is the specified clearance.


Install the removed parts in the reverse order of removal.



[cycle-service-repair-workshop-manual/](https://www.arepairmanual.com/downloads/1986-honda-ch150-mot-cycle-service-repair-workshop-manual/)


RADIATOR COOLANT

Place the scooter on its center stand.
Remove the radiator grille (Section 13).
Check the coolant level of the reserve tank with the engine running at normal operating temperature. The level should be between the "F" and "L" level lines.
If necessary, remove the reserve tank cap and fill to the "F" level line with a 50/50 mixture of distilled water and anti-freeze.
Reinstall the cap.




RADIATOR CORE

Remove the radiator grille (Section 13).
Remove the air duct.
Check the air passages for clogging or damage.
Straighten bent fins and collapsed core tubes.
Remove insects, mud or any obstruction with compressed air or low pressure water.
Replace the radiator if the air flow is restricted over more than 20% of the radiating surface.



COOLING SYSTEM HOSES & CONNECTIONS

Inspect the hoses for cracks or deterioration, and replace if necessary.
Check the tightness of all hose clamps.




CARBURETOR—IDLE SPEED

NOTE

- Inspect and adjust idle speed after all other engine adjustments are within specifications.
- The engine must be warm for accurate idle inspection and adjustment. Ten minutes of stop and go riding is sufficient.

Remove the inspection cover from the center cover.
Warm up the engine and place the motorcycle on its center stand. Connect a tachometer.
Turn the throttle stop screw to obtain the specified idle speed.



Idle speed: 1,500 ± 100 rpm

Sample manual. Download All 223 pages at: <https://www.arepairmanual.com/downloads/1986-honda-ch150-motorcycle-service-repair-workshop-manual/>