

Product: 1998-1999 Kawasaki ZX6R Motorcycle Service Repair Workshop Manual  
Full Download: <https://www.arepairmanual.com/downloads/1998-1999-kawasaki-zx6r-motocycle-service-repair-workshop-manual/>

# KAWASAKI ZX6R-1999



## SERVICE MANUAL + PARTS MICROFICHE

Sample of manual. Download All 370 pages at:  
<https://www.arepairmanual.com/downloads/1998-1999-kawasaki-zx6r-motocycle-service-repair-workshop-manual/>

Product: 1998-1999 Kawasaki ZX6R Motorcycle Service  
Full Download: <https://www.arepairmanual.com/download/1998-1999-kawasaki-zx6r-motorcycle-service-repair-workshop-manual/>

**Kawasaki**

**Ninja ZX-6R**

# Motorcycle Service Manual

---

All rights reserved. No parts of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic mechanical photocopying, recording or otherwise, without the prior written permission of Quality Assurance Department/Consumer Products Group/Kawasaki Heavy Industries, Ltd., Japan.

No liability can be accepted for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible.

The right is reserved to make improvements to this manual periodically and without notice, or to make such changes to products manufactured previously. See your dealer for the latest information on product improvements and to obtain the latest manual.

All information contained in this publication is based on the latest product information available at the time of publication. Illustrations and photographs in this publication are intended for reference use only and may not depict actual model component parts.

## LIST OF ABBREVIATIONS

A	ampere(s)	lb	pounds(s)
ABDC	after bottom dead center	m	meter(s)
AC	alternating current	min	minute(s)
ATDC	after top dead center	N	newton(s)
BBDC	before bottom dead center	Pa	pascal(s)
BDC	bottom dead center	PS	horsepower
BTDC	before top dead center	psi	pound(s) per square inch
°C	degree(s) Celsius	r	revolution
DC	direct current	rpm	revolution(s) per minute
F	farad(s)	TDC	top dead center
°F	degree(s) Fahrenheit	TIR	total indicator reading
ft	foot, feet	V	volt(s)
g	gram(s)	W	watt(s)
h	hour(s)	Ω	ohm(s)
L	liter(s)		

**Read OWNER'S MANUAL before operating.**

## EMISSION CONTROL INFORMATION

To protect the environment in which we all live, Kawasaki has incorporated crankcase emission (1) and exhaust emission (2) control systems in compliance with applicable regulations of the United States Environmental Protection Agency and California Air Resources Board. Additionally, Kawasaki has incorporated an evaporative emission control system (3) in compliance with applicable regulations of the California Air Resources Board on vehicles sold in California only.

### 1. Crankcase Emission Control System

This system eliminates the release of crankcase vapors into the atmosphere. Instead, the vapors are routed through an oil separator to the intake side of the engine. While the engine is operating, the vapors are drawn into combustion chamber, where they are burned along with the fuel and air supplied by the carburetion system.

### 2. Exhaust Emission Control System

This system reduces the amount of pollutants discharged into the atmosphere by the exhaust of this motorcycle. The fuel, ignition and exhaust systems of this motorcycle have been carefully designed and constructed to ensure an efficient engine with low exhaust pollutant levels. The exhaust system of this model motorcycle manufactured primarily for sale in California includes a catalytic converter system.

### 3. Evaporative Emission Control System

Vapors caused by fuel evaporation in the fuel system are not vented into the atmosphere. Instead, fuel vapors are routed into the running engine to be burned, or stored in a canister when the engine is stopped. Liquid fuel is caught by a vapor separator and returned to the fuel tank.

The Clean Air Act, which is the Federal law covering motor vehicle pollution, contains what is commonly referred to as the Act's "tampering provisions."

"Sec. 203(a) The following acts and the causing thereof are prohibited...

- (3)(A) for any person to remove or render inoperative any device or element of design installed on or in a motor vehicle or motor vehicle engine in compliance with regulations under this title prior to its sale and delivery to the ultimate purchaser, or for any manufacturer or dealer knowingly to remove or render inoperative any such device or element of design after such sale and delivery to the ultimate purchaser.
- (3)(B) for any person engaged in the business of repairing, servicing, selling, leasing, or trading motor vehicles or motor vehicle engines, or who operates a fleet of motor vehicles knowingly to remove or render inoperative any device or element of design installed on or in a motor vehicle or motor vehicle engine in compliance with regulations under this title following its sale and delivery to the ultimate purchaser..."

(Continued on next page.)

#### NOTE

- o *The phrase "remove or render inoperative any device or element of design" has been generally interpreted as follows:*
- 1. Tampering does not include the temporary removal or rendering inoperative of devices or elements of design in order to perform maintenance.*
  - 2. Tampering could include:*
    - a. Maladjustment of vehicle components such that the emission standards are exceeded.*
    - b. Use of replacement parts or accessories which adversely affect the performance or durability of the motorcycle.*
    - c. Addition of components or accessories that result in the vehicle exceeding the standards.*
    - d. Permanently removing, disconnecting, or rendering inoperative any component or element of design of the emission control systems.*

**WE RECOMMEND THAT ALL DEALERS OBSERVE THESE PROVISIONS OF FEDERAL LAW, THE VIOLATION OF WHICH IS PUNISHABLE BY CIVIL PENALTIES NOT EXCEEDING \$10,000 PER VIOLATION.**

#### TAMPERING WITH NOISE CONTROL SYSTEM PROHIBITED

Federal law prohibits the following acts or the causing thereof: (1) The removal or rendering inoperative by any person other than for purposes of maintenance, repair, or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or (2) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Among those acts presumed to constitute tampering are the acts listed below:

- Replacement of the original exhaust system or muffler with a component not in compliance with Federal regulations.
- Removal of the muffler(s) or any internal portion of the muffler(s).
- Removal of the air box or air box cover.
- Modifications to the muffler(s) or air intake system by cutting, drilling, or other means if such modifications result in increased noise levels.

# Foreword

This manual is designed primarily for use by trained mechanics in a properly equipped shop. However, it contains enough detail and basic information to make it useful to the owner who desires to perform his own basic maintenance and repair work. A basic knowledge of mechanics, the proper use of tools, and workshop procedures must be understood in order to carry out maintenance and repair satisfactorily. Whenever the owner has insufficient experience or doubts his ability to do the work, all adjustments, maintenance, and repair should be carried out only by qualified mechanics.

In order to perform the work efficiently and to avoid costly mistakes, read the text, thoroughly familiarize yourself with the procedures before starting work, and then do the work carefully in a clean area. Whenever special tools or equipment are specified, do not use makeshift tools or equipment. Precision measurements can only be made if the proper instruments are used, and the use of substitute tools may adversely affect safe operation.

**For the duration of the warranty period,** we recommend that all repairs and scheduled maintenance be performed in accordance with this service manual. Any owner maintenance or repair procedure not performed in accordance with this manual may void the warranty.

To get the longest life out of your motorcycle:

- Follow the Periodic Maintenance Chart in the Service Manual.
- Be alert for problems and non-scheduled maintenance.
- Use proper tools and genuine Kawasaki Motorcycle parts. Special tools, gauges, and testers that are necessary when servicing Kawasaki motorcycles are introduced by the Special Tool Manual. Genuine parts provided as spare parts are listed in the Parts Catalog.
- Follow the procedures in this manual carefully. Don't take shortcuts.
- Remember to keep complete records of maintenance and repair with dates and any new parts installed.

---

## How to Use This Manual

---

In preparing this manual, we divided the product into its major systems. These systems became the manual's chapters. All information for a particular system from adjustment through disassembly and inspection is located in a single chapter.

The Quick Reference Guide shows you all of the product's system and assists in locating their chapters. Each chapter in turn has its own comprehensive Table of Contents.

The Periodic Maintenance Chart is located in the General Information chapter. The chart gives a time schedule for required maintenance operations.

If you want spark plug information, for example, go to the Periodic Maintenance Chart first. The chart tells you how frequently to clean and gap the plug. Next, use the Quick Reference Guide to locate the Electrical System chapter. Then, use the Table of Contents on the first page of the chapter to find the Spark Plug section.

Whenever you see these WARNING and CAUTION symbols, heed their instructions! Always follow safe operating and maintenance practices.

### **▲WARNING**

This warning symbol identifies special instructions or procedures which, if not correctly followed, could result in personal injury, or loss of life.

### **CAUTION**

This caution symbol identifies special instructions or procedures which, if not strictly observed, could result in damage to or destruction of equipment.

This manual contains four more symbols (in addition to WARNING and CAUTION) which will help you distinguish different types of information.

#### NOTE

- *This note symbol indicates points of particular interest for more efficient and convenient operation.*
- Indicates a procedural step or work to be done.
- Indicates a procedural sub-step or how to do the work of the procedural step it follows. It also precedes the text of a NOTE.
- ★ Indicates a conditional step or what action to take based on the results of the test or inspection in the procedural step or sub-step it follows.

In most chapters an exploded view illustration of the system components follows the Table of Contents. In these illustrations you will find the instructions indicating which parts require specified tightening torque, oil, grease or a locking agent during assembly.

# General Information

## Table of Contents

Before Servicing .....	1-2
Model Identification .....	1-4
General Specifications .....	1-6
Periodic Maintenance Chart .....	1-8
Technical Information – KLEEN (KAWASAKI LOW EXHAUST EMISSION) .....	1-10
Technical Information – Non-Contact Hall IC-Type Speed Sensor .....	1-17
Details:.....	1-17
Construction & Operation:.....	1-17
Speed Sensor Inspection .....	1-18
Technical Information – Alternator made from Rare Magnet .....	1-18
Rare Magnet Material:.....	1-18
Main Characters:.....	1-18
Torque and Locking Agent .....	1-19
Special Tools and Sealant .....	1-23
Cable, Wire, and Hose Routing .....	1-29

## 1-2 GENERAL INFORMATION

### Before Servicing

Before starting to service a motorcycle, careful reading of the applicable section is recommended to eliminate unnecessary work. Photographs, diagrams, notes, cautions, warnings, and detailed descriptions have been included wherever necessary. Nevertheless, even a detailed account has limitations, a certain amount of basic knowledge is also required for successful work.

#### Especially note the following:

- (1) **Dirt**

Before removal and disassembly, clean the motorcycle. Any dirt entering the engine or other parts will work as an abrasive and shorten the life of the motorcycle. For the same reason, before installing a new part, clean off any dust or metal filings.
- (2) **Battery Ground**

Remove the ground (-) lead from the battery before performing any disassembly operations on the motorcycle. This prevents: (a) the possibility of accidentally turning the engine over while partially disassembled. (b) sparks at electrical connections which will occur when they are disconnected. (c) damage to electrical parts.
- (3) **Installation, Assembly**

Generally, installation or assembly is the reverse of removal or disassembly. But if this Service Manual has installation or assembly procedures, follow them. Note parts locations and cable, wire, and hose routing during removal or disassembly so they can be installed or assembled in the same way. It is preferable to mark and record the locations and routing as much as possible.
- (4) **Tightening Sequence**

Generally, when installing a part with several bolts, nuts, or screws, start them all in their holes and tighten them to a snug fit. Then tighten them evenly in a cross pattern. This is to avoid distortion of the part and/or causing gas or oil leakage. Conversely when loosening the bolts, nuts, or screws, first loosen all of them by about a quarter turn and then remove them. Where there is a tightening sequence indication in this Service Manual, the bolts, nuts, or screws must be tightened in the order and method indicated.
- (5) **Torque**

When torque values are given in this Service Manual, use them. Either too little or too much torque may lead to serious damage. Use a good quality, reliable torque wrench.
- (6) **Force**

Common sense should dictate how much force is necessary in assembly and disassembly. If a part seems especially difficult to remove or install, stop and examine what may be causing the problem. Whenever tapping is necessary, tap lightly using a wooden or plastic-faced mallet. Use an impact driver for screws (particularly for the removal of screws held by a locking agent) in order to avoid damaging the screw heads.
- (7) **Edges**

Watch for sharp edges, especially during major engine disassembly and assembly. Protect your hands with gloves or a piece of thick cloth when lifting the engine or turning it over.
- (8) **High-Flash Point Solvent**

A high-flash point solvent is recommended to reduce fire danger. A commercial solvent commonly available in North America is Stoddard solvent (generic name). Always follow manufacturer and container directions regarding the use of any solvent.
- (9) **Gasket, O-Ring**

Do not reuse a gasket or O-ring once it has been in service. The mating surfaces around the gasket should be free of foreign matter and perfectly smooth to avoid oil or compression leaks.
- (10) **Liquid Gasket, Non-Permanent Locking Agent**

Follow manufacturer's directions for cleaning and preparing surfaces where these compounds will be used. Apply sparingly. Excessive amounts may block engine oil passages and cause serious damage. An example of a non-permanent locking agent commonly available in North America is Loctite Lock'n Seal (Blue).
- (11) **Press**

A part installed using a press or driver, such as a wheel bearing, should first be coated with oil on its outer or inner circumference so that it will go into place smoothly.
- (12) **Ball Bearing and Needle Bearing**

Do not remove a ball bearing or a needle bearing unless it is absolutely necessary. Replace any ball or needle bearings that were removed with new ones, as removal generally damages bearings. Install bearings with the marked side facing out applying pressure evenly with a suitable driver. Only press on the race that forms the press fit with the base component to avoid damaging the bearings. This prevents severe stress on the balls or needles and races, and prevent races and balls or needles from being dented. Press a ball bearing until it stops at the stops in the hole or on the shaft.

## (13) Oil Seal and Grease Seal

Replace any oil or grease seals that were removed with new ones, as removal generally damages seals.

When pressing in a seal which has manufacturer's marks, press it in with the marks facing out. Seals should be pressed into place using a suitable driver, which contacts evenly with the side of seal, until the face of the seal is even with the end of the hole. Before a shaft passes through a seal, apply a little high temperature grease on the lips to reduce rubber to metal friction.

## (14) Circlip, Retaining Ring, and Cotter Pin

Replace any circlips, retaining rings, and cotter pins that were removed with new ones, as removal weakens and deforms them. When installing circlips and retaining rings, take care to compress or expand them only enough to install them and no more.


## (15) Lubrication

Engine wear is generally at its maximum while the engine is warming up and before all the rubbing surfaces have an adequate lubricative film. During assembly, oil or grease (whichever is more suitable) should be applied to any rubbing surface which has lost its lubricative film. Old grease and dirty oil should be cleaned off. Deteriorated grease has lost its lubricative quality and may contain abrasive foreign particles.

Don't use just any oil or grease. Some oils and greases in particular should be used only in certain applications and may be harmful if used in an application for which they are not intended. This manual makes reference to molybdenum disulfide grease ( $\text{MoS}_2$ ) in the assembly of certain engine and chassis parts. Always check manufacturer recommendations before using such special lubricants.

## (16) Electrical Wires

All the electrical wires are either single-color or two-color and, with only a few exceptions, must be connected to wires of the same color. On any of the two-color wires there is a greater amount of one color and a lesser amount of a second color, so a two-color wire is identified by first the primary color and then the secondary color. For example, a yellow wire with thin red stripes is referred to as a "yellow/red" wire; it would be a "red/yellow" wire if the colors were reversed to make red the main color.

Wire (cross-section)	Name of Wire Color
 <p>Red Wire Strands Yellow Red</p>	Yellow/Red

## (17) Replacement Parts

When there is a replacement instruction, replace these parts with new ones every time they are removed. These replacement parts will be damaged or lose their original function once removed.

## (18) Inspection

When parts have been disassembled, visually inspect these parts for the following conditions or other damage. If there is any doubt as to the condition of them, replace them with new ones.

Abrasion	Crack	Hardening	Warp
Bent	Dent	Scratch	Wear
Color change	Deterioration	Seizure	

## (19) Specifications

Specification terms are defined as follows:

"Standards": show dimensions or performances which brand-new parts or systems have.

"Service Limits": indicate the usable limits. If the measurement shows excessive wear or deteriorated performance, replace the damaged parts.

## 1-4 GENERAL INFORMATION

---

### Model Identification

---

ZX600-G1 Left Side View:



ZX600-G1 Right Side View:



ZX600-H1 Left Side View:



ZX600-H1 Right Side View:



# 1-6 GENERAL INFORMATION

## General Specifications

Items	ZX600-G1	H1	
<b>Dimensions:</b>			
Overall length	2 025 mm, (FG)(GR)(NR)(SW) 2 055 mm	2 055 mm	
Overall width	715 mm	←	
Overall height	1 160 mm	←	
Wheelbase	1 400 mm	←	
Road clearance	140 mm	←	
Seat height	815 mm	←	
Dry mass	176 kg, (CA) 178 kg	177 kg	
Curb mass: Front	103 kg	←	
Rear	97 kg, (CA) 99 kg	98 kg	
Fuel tank capacity	18.0 L	←	
<b>Performance:</b>			
Minimum turning radius	3.2 m	←	
<b>Engine:</b>			
Type	4-stroke, DOHC, 4-cylinder	←	
Cooling system	Liquid-cooled	←	
Bore and stroke	66.0 x 43.8 mm	←	
Displacement	599 mL	←	
Compression ratio	11.8	←	
Maximum horsepower	79.4 kW (108 PS) @12 000 r/min (rpm), (AS) 78.4 kW (106.6 PS) @12 000 r/min (rpm), (FG) 72 kW (98 PS) @12 000 r/min (rpm), (FR) 78.2 kW (106.3 PS) @12 000 r/min (rpm) (UTAC's norm), (SW) 43 kW (58.5 PS) @10 500 r/min (rpm), (CN)(ML) 78.7 kW (107 PS) @12 000 r/min (rpm), (US) ---	(FG) 72 kW (98 PS) @12 000 r/min (rpm) (ST) 78.7 kW (107 PS) @12 000 r/min (rpm)	
Maximum torque	65.7 N-m(6.7 kg-m, 48 ft-lb) @10 000 r/min (rpm), (AS) 64.7 N-m (6.6 kg-m, 48 ft-lb) @9 000 r/min (rpm), (FG) 62 N-m (6.3 kg-m, 46 ft-lb) @10 000 r/min (rpm), (SW) 51 N-m (5.2 kg-m, 38 ft-lb) @6 000 r/min (rpm), (CN)(ML) 65 N-m (6.63 kg-m, 48 ft-lb) @10 000 r/min (rpm) (FR)(UK)(US) ---	(FG) 62 N-m (6.3 kg-m, 46 ft-lb) @6 000 r/min (rpm) (ST) 65 N-m (6.63 kg-m, 48 ft-lb) @10 000 r/min (rpm)	
Carburetion system	Carburetors, Mikuni BDSR 36R x 4	←	
Starting system	Electric starter	←	
Ignition system	Battery and coil (transistorized)	←	
Timing advance	Electronically advanced(digital igniter)	←	
Ignition timing	From 12.5° BTDC @1 300 r/min (rpm) to 35° BTDC @5 000 r/min (rpm)	←	
Spark plug	NGK CR9E or ND U27ESR-N	←	
Cylinder numbering method	Left to right, 1-2-3-4	←	
Firing order	1-2-4-3	←	
Valve timing:			
Inlet	Open	58° BTDC	←
	Close	78° ABDC	←
	Duration	316°	←
Exhaust	Open	66° BBDC	←
	Close	46° ATDC	←
	Duration	292°	←

Items	ZX600-G1	H1
Lubrication system	Forced lubrication (wet sump with cooler)	←
Engine oil:		
Grade	SE, SF or SG class	←
Viscosity	SAE10W-40, 10W-50, 20W-40, or 20W-50	←
Capacity	4.0 L	←
<b>Drive Train:</b>		
Primary reduction system:		
Type	Gear	←
Reduction ratio	2.022 (89/44)	←
Clutch type	Wet multi disc	←
Transmission:		
Type	6-speed, constant mesh, return shift	←
Gear ratios:		
1st	2.923 (38/13)	←
2nd	2.062 (33/16)	←
3rd	1.631 (31/19)	←
4th	1.380 (29/21)	←
5th	1.217 (28/23)	←
6th	1.083 (26/24)	←
Final drive system:		
Type	Chain drive	←
Reduction ratio	2.666 (40/15)	←
Overall drive ratio	5.843 @Top gear	←
<b>Frame:</b>		
Type	Tubular, diamond	←
Caster (rake angle)	23.5°	←
Trail	91 mm	←
Front tire: Type	Tubeless	←
Size	120/60 ZR17 (55W)	←
Rear tire: Type	Tubeless	←
Size	170/60 ZR17 (72W)	←
Front suspension:		
Type	Telescopic fork	←
Wheel travel	120 mm	←
Rear suspension:		
Type	Swingarm (uni-trak)	←
Wheel travel	135 mm	←
Brake type: Front	Dual disc	←
Rear	Single disc	←
<b>Electrical Equipment:</b>		
Battery	12 V 8 Ah	←
Headlight: Type	Semi-sealed beam	←
Bulb	12V60/55W (quartz-halogen),	←
Tail/brake light	12 V 5/21 W × 2, (CN)(US)(ML) 12 V 8/27 W × 2	12 V 5/21 W × 2
Alternator: Type	Three-phase AC	←
Rated output	20 A/ 14 V @5 000 r/min (rpm)	←

Specifications are subject to change without notice, and may not apply to every country.

(AS) : Australian Model  
 (CA) : California Model  
 (CN) : Canadian Model  
 (FG) : German Model  
 (FR) : French Model  
 (GR) : Greek Model

(KR) : Korean Model  
 (ML) : Malaysian Model  
 (NR) : Norwegian Model  
 (SW) : Swedish Model  
 (US) : U.S.A. Model  
 (UK) : U.K. Model

# 1-8 GENERAL INFORMATION

## Periodic Maintenance Chart

The scheduled maintenance must be done in accordance with this chart to keep the motorcycle in good running condition. **The initial maintenance is vitally important and must not be neglected.**

OPERATION	FREQUENCY	Whichever comes first		*ODOMETER READING															
		Every	1 000 km (600 mile)	6 000 km (4 000 mile)	12 000 km (7 500 mile)	18 000 km (12 000 mile)	24 000 km (15 000 mile)	30 000 km (20 000 mile)	36 000 km (24 000 mile)										
Spark plug – clean and gap †			•	•	•	•	•	•	•										
Valve clearance – check †				•	•	•	•	•	•										
Air suction valve – check †			•	•	•	•	•	•	•										
Air cleaner element and air vent filter – clean#				•	•	•	•	•	•										
Throttle grip play – check †		•		•	•	•	•	•	•										
Idle speed – check †		•		•	•	•	•	•	•										
Carburetor synchronization – check †				•	•	•	•	•	•										
Evaporative emission control system (CA) – check †		•	•	•	•	•	•	•	•										
Engine oil – change #	6 months	•	•	•	•	•	•	•	•										
Oil filter – replace		•		•	•	•	•	•	•										
Drive chain wear – check † #				•	•	•	•	•	•										
Brake pad wear – check † #				•	•	•	•	•	•										
Brake light switch – check †		•	•	•	•	•	•	•	•										
Steering – check †		•	•	•	•	•	•	•	•										
Front fork oil – change	2 years								•										
Rear shock absorber oil leak – check †					•	•	•	•	•										
Front fork oil leak – check †					•	•	•	•	•										
Tire wear – check †			•	•	•	•	•	•	•										
Swingarm pivot, Uni-trak linkage – lubricate					•	•	•	•	•										
General lubrication – perform					•	•	•	•	•										
Nuts, bolts, and fasteners tightness – check †		•		•	•	•	•	•	•										
Drive chain – lubricate #	600 km		•	•	•	•	•	•	•										
Drive chain slack – check † #	1000 km	•	•	•	•	•	•	•	•										
Brake fluid level – check †	month	•	•	•	•	•	•	•	•										
Clutch adjust – check †	month	•	•	•	•	•	•	•	•										
Radiator hoses, connection – check †		•																	
Brake fluid – change	2 years								•										
Brake master cylinder cup and dust seal – replace	4 years																		
Coolant – change	2 years								•										
Caliper piston seal and dust seal – replace	4 years																		
Steering stem bearing – lubricate	2 years								•										

- # : Service more frequently when operating in severe conditions; dusty, wet, muddy, high speed, or frequent starting/stopping.
- \* : For higher odometer readings, repeat at the frequency interval established here.
- † : Replace, add, adjust, clean, or torque if necessary.
- (CA): California Model only


## Technical Information - KLEEN (KAWASAKI LOW EXHAUST EMISSION)

The ZX600G (California), and the ZX600H (Germany and Switzerland) have catalytic converters.


The secondary air injection system [A] helps Kawasaki keep motorcycle exhaust gases below the established emission regulation limits. This system draws air into the exhaust ports, dilutes and burns harmful ingredients in the exhaust gas in order to reduce them. This allows the carburetor to be set at a reasonable setting position without adjusting it much leaner, so engine performance and actual riding performance are not spoiled.

But, under the trend that the emission regulation becomes more severe, Kawasaki has adopted two catalytic converters [B] in addition to the secondary air injection system. As a result, we can reduce the exhaust gas emission below the current standards without hurting the output performance and the actual riding feeling at all. The harmful ingredients in the exhaust gas under LA4 or EC-mode running performance were reduced considerably. As actual examples, carbon monoxide (CO) is reduced about 70%, hydrocarbons (HC) about 60%, nitrogen oxides (NOx) about 10%.

Moreover, in order to improve the reliability of the system, we install fuel cut valves [C] as a catalyst protection system.



### Kawasaki Low Exhaust Emission System




## 1. Exhaust Purification System

The burned gas, which goes out from the combustion chamber, is injected with secondary air (adding necessary oxygen), and is cleaned up while passing through the small precatalytic converter at the joint pipe and the main catalytic converter at the silencer, and then goes out to the atmosphere.

### 1) Secondary Air Injection System

In order to oxidize CO and HC by the catalysts, the proper amount of oxygen is necessary. As original combustion gas has little remaining oxygen, air is injected in the exhaust ports by the secondary air injection system in order to supply enough oxygen to the combustion gas to purify CO and HC to a certain extent as well as prepare for activation of the catalysts. As for NOx, as the carburetor is set at rich level [A], NOx is at lower level from the beginning as described in the figure.



### 2) Precatalytic Converter [A]


A small-size three-way catalytic converter (precatalytic converter) is installed in the pipe ahead at the joint [B] of the silencer. A precatalytic converter is made of a punched metal pipe [C] of stainless steel, and its surface is covered with alumina upon which platinum and rhodium as catalysts are applied. Generally, the temperature of the exhaust gas must be higher than the activation temperature, so we set this precatalytic converter at the upper portion of the main catalytic converter where the temperature of exhaust gas is high. Accordingly, the precatalytic converter will be activated even under low load conditions. Activation of the precatalytic converter makes the passed exhaust gas heated by the heat of reaction and makes its temperature to the main catalytic converter higher, which helps the main catalytic converter operate more efficiently. The precatalytic converter purifies CO, HC, and NOx to a certain extent.

### 3) Main Catalytic Converter [D]

The converter is a three-way catalytic converter upon which platinum and rhodium are applied, and has a cylindrical metallic honeycomb structure [E] made by bending a corrugated sheet and a flat sheet of stainless steel into a spiral of increasing diameter. The main catalytic converter is installed in the first expansion chamber of the silencer. When the exhaust gas passes through the upper portion of the secondary air injection system, the precatalytic converter, and the inside of the honeycomb, the main catalytic converter works efficiently to reduce CO, HC, and NOx. So, we can keep it within regulation.


The honeycomb structure is convenient for the catalytic converter because it has a large surface area but small size to react effectively and low exhaust resistance. In addition, its inherent strength helps resist vibration, and has simple structure welded directly on the silencer.

## Catalytic Converters



## 2. Catalyst Protection System

When excessive unburned gasoline flows more than the allowable amount into the exhaust gas during running, the temperature of the catalysts rises abnormally because the unburned gasoline reacts with catalysts heated (at the activation temperature or higher). In an excessive case, the problem such as melting-down occurs. Moreover, there is a possibility that the purification performance becomes poorer when it is cool (below the activation temperature). So, the fuel cut valve [A] as a catalyst protection system is installed on each carburetor float bowl [B]. It runs by the IC Igniter and opens and closes the fuel passage toward a main jet [C]. A catalyst protection system works in the following cases.



- 1) Prevention of unburned gasoline from flowing when overspeed limiter works.  
The limiter has fuel cut-off and ignition cut-off operations.
- 2) Prevention of unburned gasoline from flowing when the engine stop switch is turned off during running.  
When the engine stop switch is turned off while coasting the motorcycle, fuel is cut off. For example, fuel is cut off under the abnormal running condition that you go down the slope with the engine stop switch OFF.

## 1-12 GENERAL INFORMATION

- 3) Prevention of unburned gasoline from flowing when misfire occurs by cut-off of a primary coil of an ignition coil and its faulty connection.

Fuel is cut off when an electric current of a primary coil becomes abnormal because of cut-off or defective connection of the primary coil when the engine is running.

- 4) Prevention of solenoid valve lock

If a driver always runs the engine under the red zone in the tachometer, the IC igniter doesn't operate overspeed limiter and the catalyst protection system doesn't have a chance to work. The old fuel may gum up the fuel cut valves which remain seated in the float bowls. To cope with, the IC igniter test-operates the fuel cut valves when starting the engine and prevents lock of the valves.

- 5) Usage of leaded gasoline is prohibited completely.

Leaded gasoline harms the purification efficiency of the catalysts. In German model, the shape of the filler cap is modified so that a gas supply nozzle for unleaded gasoline can be installed but for leaded gasoline cannot.

The performance of the catalyst protection system is summed up as follows.

[Performance of Catalyst Protection System]

No	Running condition	Ignition switch	Engine stop switch	Protection system	Fuel cut valve	Remedy (Action)
1	Normal	ON	ON	OFF	OPEN	● Not necessary (Normal condition)
2	Overspeed performance	ON	ON	ON	CLOSE	● Not necessary
3	Abnormal (misfire) ● Defects at the ignition coil primary-side	ON	ON	ON	CLOSE	● Inspect the connection at the primary-side of the ignition coil.
4	Abnormal (misfire) ● Defects at the ignition coil secondary-side ● Battery is dead. ● Spark plug fouling  ● Defects of the pickup coil ● Defects of the IC igniter  ● Defects of the carburetor	ON	ON	OFF	OPEN	● Inspect the spark plug cap and spark plug lead. ● Charge the battery. ● Clean the spark plug and adjust the gap. ● Inspect and replace the pickup coil. ● Inspect and replace the IC igniter. ● Inspect and adjust the carburetor.
5	Abnormal (no spark) ● Short of the engine stop switch ● While coasting the motorcycle, do not turn the engine stop switch OFF.	ON	OFF	ON	CLOSE	● Inspect and repair the engine stop switch. ● Turn the engine stop switch ON, and run.
6	Abnormal (no spark) ● Short of the ignition switch ● While coasting the motorcycle, do not turn the ignition switch OFF.	OFF	ON or OFF	OFF	OPEN	● Inspect and replace the ignition switch. ● Turn the ignition switch and the engine stop switch ON, and run.

### 3. Maintenance

Special maintenance is not necessary except for the inspection of the air suction valve (which has been described in manuals).

#### 1) Replacement of Muffler Assy

It is impossible to replace only catalytic converters because they are welded in the muffler. So, in the following case, the replacement of the muffler assy is also necessary.

- In case of using not-appointed fuel (leaded gasoline, etc.):

Purification efficiency decreases in a very short period because lead poisons the catalytic converters. Although the appearance of the converter and engine performance are not effected, the replacement of a muffler assy is necessary to secure the purification efficiency of exhaust gas.

- In case catalytic converters melt down by over-heating:

Especially in the case that a lot of unburned gasoline flows into the catalytic converters under the extreme running condition far beyond common sense, there is a possibility that the catalysts overreact and that catalytic converters overheat severely. If they melt down, it causes poor engine performance, deterioration of emission noise level and purification efficiency. So, the muffler assy must be replaced.

#### 2) Durability

It has the same durability as a conventional muffler.

#### 3) Disposal to Waste

As any harmful toxic substance is not used especially, it can be disposed as usual industrial wastes. The body of the muffler is made of aluminum, steel, and stainless steel. The catalytic converter is made of stainless steel which has alumina on its surface, and the main ingredients of catalysts are platinum and rhodium.

### 4. Handling Precautions

Catalyst protection system against mishandling is applied to a vehicle with catalysts. But, we prohibit depending on the system too much when running.

#### 1) Use only unleaded gasoline:


Usage of leaded gasoline is prohibited completely. Only fuel and additives which are specified in the Owner's Manual can be used.

#### 2) Use specified engine oil which is described in the Owner's Manual:

In case of some ingredients which give bad effects to the catalysts (such as phosphorus "P", lead "Pb", sulfur "S") are included, the purification efficiency decreases.


#### 3) Coasting (such as cranking while going down a slope) is prohibited with the ignition system OFF:

The engine running without igniting causes a great flow of unburned gasoline and the decreasing of purification efficiency, and melting down of catalysts at the activation temperature or higher.



- When the ignition switch [A] is turned off, the fuel cut valves [B] do not work. So, avoid coasting with the ignition switch OFF.
- Do not run the engine nor coast the motorcycle under the misfire which occurs by defects such as a bad connection with the spark plug at the secondary wiring [D] of the ignition coil [C].
- Do not coast too much with the engine stop switch [E] OFF. (Under the condition that the engine stop switch is turned off during running, the IC igniter [F] closes the fuel cut valves to shut off fuel.)
- Do not run the engine nor coast the motorcycle too much under the condition that the primary wiring [G] of the ignition coil does not connect completely (misfire). (Incomplete connection or cut-off of the primary coil makes the fuel cut valves start to cut fuel. In this case, from the standpoint to protect the catalysts, the fuel for all cylinders is cut off even if one cylinder has been affected.)

**Kawasaki Low Exhaust Emission System**




- Do not run overspeed limiter too much from the standpoint to protect the engine. (Overspeed limiter has a protection system that applies ignition cut method and fuel cut method together. Conventional system applies fuel-on method.)
- Do not run the engine under the condition that even if only one cylinder has a misfire or has unstable running. In this case, request the nearest service facility to correct it. If you have no choice but running by yourself, keep engine rpm as low as possible and try to finish running at the shortest period.
- When the battery is dead, do not push-start. Connect another full-charged battery with jumper cables, and start the engine.

**5. Additional Information**

1) Secondary Air Injection System

The mechanism is simple and power loss is minimum because the system uses the vacuum pressure created by exhaust pulses.

The secondary injection air helps the fuel/air mixture burn more completely. (The primary air means air which flows through the inlet pipe.) As the exhaust valve opens, and the burned fuel passes the exhaust valve, a stream of fresh air is introduced through the air suction valve. This fresh air burns the unburned gas and converts the carbon monoxide (CO) and hydrocarbons (HC) into harmless carbon dioxide (CO<sub>2</sub>) and water (H<sub>2</sub>O).



The secondary air injection system consists of a vacuum switch valve, and two air suction valves. Without using an air pump, the air suction valve can draw fresh air into the exhaust passage near the exhaust valves by vacuum that exhaust pulses generate.

### Air Suction Valves


The air suction valve is a check valve which allows fresh air to flow only from the air cleaner via air hoses into the exhaust port and prevents return flow. Remove and inspect the air suction valves periodically (see Engine Top End chapter). Also, remove and inspect the air suction valves whenever the idle speed is unstable, engine power is greatly reduced, or there are abnormal engine noises.

### Vacuum Switch Valve

Although the vacuum switch valve usually permits secondary air flow, it closes when a high vacuum (low pressure) is developed at the inlet pipe during engine braking. This is to shut off secondary air flow and prevent explosions in the exhaust ports which might be caused by extra unburned fuel in the exhaust during deceleration. These explosions, or backfiring in the exhaust system could damage the air suction valves.

Regular inspection of the vacuum switch valve is not needed. If backfiring occurs frequently in the exhaust system during engine braking or if there are abnormal engine noises, check the vacuum switch valve as described in the text (see Engine Top End chapter).

### Secondary Air Injection System



1. Air Cleaner Housing  
2. Air Hose  
3. Inlet Silencer



4. Vacuum Switch Valve  
5. Air Suction Valve  
6. Exhaust Valve

7. Carburetors  
8. Inlet Pipe  
9. Inlet Valve


## 2) Operation of Three-way Catalytic Converter

The three-way catalysts are used for the pre-catalytic converter and the main catalytic converter. These converters can clean up carbon monoxide (CO), hydrocarbons (HC), and nitrogen oxides (NO<sub>x</sub>) at the same time.

CO and HC are oxidized (O is added) by platinum (Pt) and converted to harmless carbon dioxide gas (CO<sub>2</sub>) and water (H<sub>2</sub>O), and the exhaust gas is cleaned up:



NO<sub>x</sub> is reduced (O is removed) by rhodium (Rh) and converted to harmless nitrogen (N<sub>2</sub>) and oxygen (O<sub>2</sub>), and the exhaust gas is cleaned up.



## 3) Property of Catalyst




Most catalysts are powders of metal or of metallic compounds, and they increase the rate of a chemical reaction. Catalysts are supposed to act in some way to loosen the bonds of the reacting substances. In other words, they lower the energy of activation, thus allowing the reaction to proceed more rapidly. To activate catalysts, the temperature of the exhaust gas must be higher than the activation temperature that is 220° ~ 230°C for new catalysts, and 270° ~ 280°C for used catalysts (after 10000 ~ 20000 km ride).

The catalyst itself undergoes no permanent chemical change, or can be recovered when the chemical reaction is completed. So, the muffler with built-in catalyst has the same durability as the conventional muffler.

The mechanism of catalytic action is supposed to be a surface phenomenon in which reactants are adsorbed onto a small portion of the surface of the catalyst. The catalytic converter is made of stainless steel and the surface is applied by alumina (aluminum oxide Al<sub>2</sub>O<sub>3</sub>). The alumina adheres to the stainless steel wall and the catalyst adheres to the alumina very well. The alumina surface is not uniform and there are corners, edges, dislocations, and grain boundaries. Catalyst is applied on the alumina and this makes the catalyst surface rough.

The rougher the surface is, the more actively the catalyst adsorbs the reactants. If various impurities like lead are adsorbed, they block the small portion of the catalyst surface, preventing adsorption of CO, HC, and NO<sub>x</sub>. This is the reason why leaded fuel poisons the catalyst without any break on the surface and generation of heat.


Catalysts are generally efficient in small quantities. A catalyst can catalyze the reaction of several thousand to a million times its weight in reactants. The three-way catalyst is a blend of platinum (Pt) and rhodium (Rh) which are expensive. But a pre-catalytic converter uses only about 0.05 gram of Pt and 0.01 gram of Rh and a main catalytic converter uses only about 0.4 grams of Pt and 0.1 gram of Rh.





## 1-18 GENERAL INFORMATION

- In the internal system of the Hall IC, the switch is operated in accordance with the magnetic induction alternator. This makes the square wave equal to the pulse of the rotor nut output.
  - Amount of magnetic induction when large [A]
  - Amount of magnetic induction when small [B]
  - Operating point [C]
  - Returning point [D]
  - When high voltage [E]
  - When low voltage [F]
- The vehicle speed is indicated in the speedometer, altering the pulse of this square wave.



### *Speed Sensor Inspection*

- Refer to the chapter 15-48.

## Technical Information – Alternator Made from Rare Magnet


### **Rare Magnet Material:**

Sintered metal made from mainly neodymium (Nd), ferric magnet (Fe), and boron (B).

### **Main Characters:**

Rare magnet used and assembled in the alternator for the ZX600-G and H models has six (6) times higher performance than that of the traditional use ferrite magnet.

This allows the alternator to reduce its mass and weight to the large extent. In addition to above mentioned, there's no use to worry about the future lackage of rare magnetic resources such as samarium cobalt.



**Torque and Locking Agent**

The following tables list the tightening torque for the major fasteners requiring use of a non-permanent locking agent or liquid gasket.

Letters used in the "Remarks" column mean:

- L** : Apply a non-permanent locking agent to the threads.
- LG** : Apply liquid gasket to the threads.
- Lh** : Left-hand threads.
- M** : Apply molybdenum disulfide grease.
- O** : Apply an oil to the threads and seating surface.
- S** : Tighten the fasteners following the specified sequence.
- SS** : Apply silicone sealant.
- St** : Stake the fasteners to prevent loosening.
- R** : Replacement parts

The table below, relating tightening torque to thread diameter, lists the basic torque for the bolts and nuts. Use this table for only the bolts and nuts which do not require a specific torque value. All of the values are for use with dry solvent-cleaned threads.

**Basic Torque for General Fasteners**

Threads dia. (mm)	Torque		
	N-m	kg-m	ft-lb
5	3.4 ~ 4.9	0.35 ~ 0.50	30 ~ 43 in-lb
6	5.9 ~ 7.8	0.60 ~ 0.80	52 ~ 69 in-lb
8	14 ~ 19	1.4 ~ 1.9	10.0 ~ 13.5
10	25 ~ 34	2.6 ~ 3.5	19.0 ~ 25
12	44 ~ 61	4.5 ~ 6.2	33 ~ 45
14	73 ~ 98	7.4 ~ 10.0	54 ~ 72
16	115 ~ 155	11.5 ~ 16.0	83 ~ 115
18	165 ~ 225	17.0 ~ 23.0	125 ~ 165
20	225 ~ 325	23 ~ 33	165 ~ 240

Fastener	Torque			Remarks
	N-m	kg-m	ft-lb	
<b>Fuel System:</b>				
Vacuum Valve Drain Screw	1.0	0.10	9 in-lb	
<b>Cooling System:</b>				
Water Hose Clamp Screws	2.0	0.20	17 in-lb	
Coolant By-pass Fitting	9.8	1.0	87 in-lb	L
Coolant Plug	9.8	1.0	87 in-lb	
Coolant Drain Plug (Water Pump)	9.8	1.0	87 in-lb	
Coolant Drain Plugs (Cylinder)	9.8	1.0	87 in-lb	
Radiator Fan Switch	18	1.8	13.0	
Water Temperature Sensor	7.8	0.80	69 in-lb	SS
Impeller Bolt	9.8	1.0	87 in-lb	
Water Pump Cover Bolts	12	1.2	104 in-lb	L
Thermostat Housing Cover Bolts	5.9	0.60	52 in-lb	
Water Hose Fitting Bolts	11	1.1	95 in-lb	
<b>Engine Top End:</b>				
Spark Plugs	13	1.3	113 in-lb	
Air Suction Valve Cover Bolts	13	1.3	113 in-lb	
Cylinder Head Cover Bolts	9.8	1.0	87 in-lb	
Pickup Coil Cover Bolts	12	1.2	104 in-lb	L (1)
Camshaft Chain Tensioner Mounting Bolts	11	1.1	95 in-lb	
Camshaft Chain Tensioner Cap Bolt	5.4	0.55	48 in-lb	
Camshaft Cap Bolts	12	1.2	104 in-lb	
Camshaft Chain Guide Bolts (Upper)	12	1.2	104 in-lb	
Cylinder Head Bolts: $\phi$ 10	49	5.0	36	S, O (Washer)
$\phi$ 6	12	1.2	104 in-lb	S
Cylinder Head Jacket Plugs (Right)	15	1.5	11.0	L
Cylinder Head Jacket Plugs (Upper, Left)	20	2.0	14.5	L
Engine Side Cover Bolts	12	1.2	104 in-lb	
Camshaft Chain Guide Bolt (Crankcase)	25	2.5	18.0	
Carburetor Holder Bolts	12	1.2	104 in-lb	
Baffle Plate Bolts	5.9	0.60	52 in-lb	

# 1-20 GENERAL INFORMATION

Fastener	Torque			Remarks	
	N-m	kg-m	ft-lb		
Muffler and Exhaust Pipe Connection Nuts	34	3.5	25		
Exhaust Pipe Clamp Bolts	34	3.5	25		
<b>Clutch</b>					
Clutch Cover Bolts	12	1.2	104 in-lb	L (2, Front)	
Clutch Cover Damper Bolts	5.9	0.60	52 in-lb	L	
Clutch Spring Bolts	8.8	0.90	78 in-lb		
Clutch Hub Nut	130	13.5	98	R	
<b>Engine Lubrication System:</b>					
Oil Filler Plug	1.5 or Hand-Tight	0.15 or Hand-Tight	13 in-lb or Hand-Tight		
Engine Drain Plug	20	2.0	14.5		
Oil Filter (Cartridge type)	9.8	1.0	87 in-lb	R, O	
Oil Cooler Mounting Bolt	78	8.0	58	O	
Oil Pan Bolts	12	1.2	104 in-lb		
Oil Pipe Holder Bolts	13	1.3	113 in-lb		
Oil Pressure Relief Valve	15	1.5	11.0	L	
Oil Pressure Switch	15	1.5	11.0	SS	
Oil Pressure Switch Terminal Bolt	1.5	0.15	13 in-lb		
Impeller Bolt	9.8	1.0	87 in-lb		
Oil Passage Plug (Right)	15	1.5	11.0		
Oil Hose Banjo Bolts	25	2.5	18.0		
<b>Engine Removal/Installation:</b>					
Engine Mounting Bolts and Nuts	44	4.5	33		
Engine Mounting Bracket Bolts	23	2.3	16.5		
Engine Mounting Clamp Bolts	23	2.3	16.5		
<b>Crankshaft/Transmission:</b>					
Breather Plate Bolts	9.8	1.0	87 in-lb	L	
Breather Tube Bracket Bolts	11	1.1	95 in-lb		
Crankcase Bolts	φ 8	31	3.2	23	S
	φ 7	20	2.0	14.5	S
	φ 6, L38 (Front, 6)	18	1.8	13.0	S
	φ 6	12	1.2	104 in-lb	S
Oil Passage Plug (Left)	20	2.0	14.5	L	
Oil Passage Plug (Right)	15	1.5	11.0		
Connecting Rod Big End Nuts	in the text	←	←	←	
Engine Ground Lead Terminal Bolt	9.8	1.0	87 in-lb		
Timing Rotor Bolt	39	4.0	29		
Oil Pressure Switch	15	1.5	11.0	SS	
Gear Positioning Lever Bolt	13	1.3	113 in-lb		
Shift Shaft Return Spring Pin (Bolt)	28	2.9	21	L	
Neutral Switch	15	1.5	11.0		
Shift Drum Bearing Holder Bolt	13	1.3	113 in-lb		
Shift Drum Bearing Holder Screw	5.4	0.55	48 in-lb	L	
Shift Drum Cam Bolt	12	1.2	104 in-lb	L	
Oil Pipe Holder Bolts	12	1.2	104 in-lb		
Pickup Coil Cover Bolts	12	1.2	104 in-lb	L (1)	
Oil Nozzles	6.9	0.70	61 in-lb	L	
<b>Wheels/Tires:</b>					
Front Axle Clamp Bolts	20	2.0	14.5		
Front Axle Nut	110	11.0	80		
Rear Axle Nut	110	11.0	80		

Fastener	Torque			Remarks
	N-m	kg-m	ft-lb	
<b>Final Drive:</b>				
Engine Sprocket Nut	125	13.0	94	O
Engine Sprocket Cover Bolts	12	1.2	104 in-lb	
Speed Sensor Mounting Bolt	6.9	0.70	61 in-lb	L
Rear Sprocket Nuts	59	6.0	43	
Rear Sprocket Studs	-	-	-	L
<b>Brakes:</b>				
Bleed Valves	7.8	0.80	69 in-lb	
Brake Hose Banjo Bolts	25	2.5	18.0	
Brake Lever Pivot Bolt	1.0	0.10	9 in-lb	
Brake Lever Pivot Bolt Locknut	5.9	0.60	52 in-lb	
Front Brake Reservoir Cap Stopper Screws	1.5	0.15	13 in-lb	
Front Brake Reservoir Bracket Bolt	6.9	0.70	61 in-lb	
Front Brake Light Switch Screws	1.0	0.10	9 in-lb	
Front Master Cylinder Clamp Bolts	11	1.1	95 in-lb	S
Pad Spring Screws (Front Caliper)	2.9	0.30	26 in-lb	
Caliper Mounting Bolts (Front)	34	3.5	25	
Caliper Assembly Bolts (Front)	21	2.1	15.0	
Front Brake Disc Mounting Bolts	23	2.3	16.5	L
Rear Brake Disc Mounting Bolts	23	2.3	16.5	L
Caliper Mounting Bolts (Rear)	25	2.5	18.0	
Rear Master Cylinder Mounting Bolts	23	2.3	16.5	
Rear Master Cylinder Push Rod Locknut	18	1.8	13.0	
<b>Suspension:</b>				
Front Fork Clamp Bolts (Upper)	20	2.0	14.5	
Front Fork Clamp Bolts (Lower)	20	2.0	14.5	
Front Fork Top Plugs	23	2.3	16.5	
Piston Rod Nut	28	2.9	21	
Front Fork Bottom Allen Bolts	39	4.0	29	L
Front Axle Clamp Bolts	20	2.0	14.5	
Rear Shock Absorber Nuts (Upper and Lower)	34	3.5	25	
Rear Shock Absorber Upper Bracket Nut	59	6.0	43	
Swingarm Pivot Shaft Nut	110	11.0	80	
Uni-Trak				
Rocker Arm Nut	34	3.5	25	
Tie-Rod Nuts	59	6.0	43	
<b>Steering:</b>				
Steering Stem Head Nut	49	5.0	36	
Steering Stem Nut	4.9	0.50	43 in-lb	
Handlebar Bolts	34	3.5	25	L
Handlebar Holder Bolts	23	2.3	16.5	
Handlebar Holder Position Bolts	9.8	1.0	87 in-lb	L
Handlebar Weight Screws	-	-	-	L
Handlebar Switch Housing Screws	3.4	0.35	30 in-lb	
<b>Frame:</b>				
Footpeg Holder Bolts	34	3.5	25	L
Side Stand Bracket Bolts	49	5.0	36	
Rear Frame Bolts and Nuts	44	4.5	33	
Rear Shock Absorber Upper Bracket Nut	59	6.0	43	
<b>Electrical System:</b>				
Spark Plugs	13	1.3	113 in-lb	
Alternator Rotor Bolt	120	12.0	87	
Stator Coil Bolts	12	1.2	104 in-lb	L
Alternator Lead Holding Plate Bolts	8.3	0.85	74 in-lb	L

## 1-22 GENERAL INFORMATION


Fastener	Torque			Remarks
	N-m	kg-m	ft-lb	
Engine Ground Lead Terminal Bolt	9.8	1.0	87 in-lb	L (1)
Alternator Cover Bolts	12	1.2	104 in-lb	
Pickup Coil Cover Bolts	12	1.2	104 in-lb	
Pickup Coil Bolts	5.9	0.60	52 in-lb	
Timing Rotor Bolt	39	4.0	29	
Starter Motor Mounting Bolts	11	1.1	95 in-lb	L
Starter Motor Clutch Bolts	34	3.5	25	
Handlebar Switch Housing Screws	3.4	0.35	30 in-lb	
Radiator Fan Switch	18	1.8	13.0	SS
Water Temperature Sensor	7.8	0.80	69 in-lb	
Oil Pressure Switch	15	1.5	11.0	SS
Oil Pressure Switch Terminal Bolt	1.5	0.15	13 in-lb	
Neutral Switch	15	1.5	11.0	
Starter Lockout Switch Screws	1.0	0.10	9 in-lb	
Front Brake Light Switch Screws	1.0	0.10	9 in-lb	
Throttle Sensor Mounting Screws	3.4	0.35	30 in-lb	

Special Tools and Scales


Product: 1998-1999 Kawasaki ZX6R Motorcycle Service Repair Workshop Manual

Full Download: <https://www.arepairmanual.com/downloads/1998-1999-kawasaki-zx6r-motorcycle-service-repair-workshop-manual/>


Bearing Puller: 57001-135




Compression Gauge: 57001-221




Inside Circlip Pliers: 57001-143




Valve Spring Compressor Assembly: 57001-241




Outside Circlip Pliers: 57001-144




Bearing Puller Adapter: 57001-317




Circlip Pliers: 57001-154




Piston Pin Puller Assembly: 57001-910



Oil Pressure Gauge, 10 kg/cm<sup>2</sup>: 57001-164



Fuel Level Gauge: 57001-1017



Sample of manual. Download All 370 pages at:

<https://www.arepairmanual.com/downloads/1998-1999-kawasaki-zx6r-motorcycle-service-repair-workshop-manual/>