

Product: 2003 Suzuki SV650/S Motorcycle Service Repair Workshop Manual
Full Download: <https://www.arepairmanual.com/downloads/2003-suzuki-sv650s-motorcycle-service-repair-workshop-manual/>

SUZUKI

SV650/S

SERVICE MANUAL

Sample of manual. Download All 610 pages at:

<https://www.arepairmanual.com/downloads/2003-suzuki-sv650s-motorcycle-service-repair-workshop-manual/>



IMPORTANT

All street-legal Suzuki motorcycles with engine displacement of 50 cc or greater are subject to Environmental Protection agency emission regulations. These regulations set specific standards for exhaust emission output levels as well as particular servicing requirements. This manual includes specific information required to properly inspect and service SV650/S in accordance with all EPA regulations. It is strongly recommended that the chapter on Emission Control, Periodic Servicing and FUEL SYSTEM be thoroughly reviewed before any type of service work is performed. Further information concerning the EPA emission regulations and U.S. Suzuki's emission control program can be found in the U.S. SUZUKI EMISSION CONTROL PROGRAM MANUAL/SERVICE BULLETIN.

FOREWORD

This manual contains an introductory description on the SUZUKI SV650/S and procedures for its inspection/service and overhaul of its main components. Other information considered as generally known is not included.

Read the GENERAL INFORMATION section to familiarize yourself with the motorcycle and its maintenance. Use this section as well as other sections to use as a guide for proper inspection and service. This manual will help you know the motorcycle better so that you can assure your customers of fast and reliable service.

* This manual has been prepared on the basis of the latest specifications at the time of publication. If modifications have been made since then, differences may exist between the content of this manual and the actual motorcycle.

* Illustrations in this manual are used to show the basic principles of operation and work procedures. They may not represent the actual motorcycle exactly in detail.

* This manual is written for persons who have enough knowledge, skills and tools, including special tools, for servicing SUZUKI motorcycles. If you do not have the proper knowledge and tools, ask your authorized SUZUKI motorcycle dealer to help you.

▲ WARNING

Inexperienced mechanics or mechanics without the proper tools and equipment may not be able to properly perform the services described in this manual. Improper repair may result in injury to the mechanic and may render the motorcycle unsafe for the rider and passenger.

SUZUKI MOTOR CORPORATION


© COPYRIGHT SUZUKI MOTOR CORPORATION 2003

GROUP INDEX

| | |
|---------------------------------------|-----------|
| GENERAL INFORMATION | 1 |
| PERIODIC MAINTENANCE | 2 |
| ENGINE | 3 |
| FI SYSTEM DIAGNOSIS | 4 |
| FUEL SYSTEM AND THROTTLE BODY | 5 |
| COOLING AND LUBRICATION SYSTEM | 6 |
| CHASSIS | 7 |
| ELECTRICAL SYSTEM | 8 |
| SERVICING INFORMATION | 9 |
| EMISSION CONTROL INFORMATION | 10 |
| WIRING DIAGRAM | 11 |

HOW TO USE THIS MANUAL TO LOCATE WHAT YOU ARE LOOKING FOR:


1. The text of this manual is divided into sections.
2. The section titles are listed in the GROUP INDEX.
3. Holding the manual as shown at the right will allow you to find the first page of the section easily.
4. The contents are listed on the first page of each section to help you find the item and page you need.



COMPONENT PARTS AND WORK TO BE DONE





















Under the name of each system or unit, is its exploded view. Work instructions and other service information such as the tightening torque, lubricating points and locking agent points, are provided.

Example: Front wheel



SYMBOL

Listed in the table below are the symbols indicating instructions and other information necessary for servicing. The meaning of each symbol is also included in the table.

| SYMBOL | DEFINITION | SYMBOL | DEFINITION |
|---|---|---|--|
|  | Torque control required. Data beside it indicates specified torque. |  | Apply THREAD LOCK SUPER "1360". 99000-32130 |
|  | Apply oil. Use engine oil unless otherwise specified. |  | Use engine coolant. |
|  | Apply molybdenum oil solution. (Mixture of engine oil and SUZUKI MOLY PASTE in a ratio of 1:1) |  | Use fork oil. 99000-99001-SS8 |
|  | Apply SUZUKI SUPER GREASE "A". 99000-25030 (USA) 99000-25010 (Others) |  | Apply or use brake fluid. |
|  | Apply SUZUKI MOLY PASTE. 99000-25140 |  | Measure in voltage range. |
|  | Apply SUZUKI SILICONE GREASE. 99000-25100 |  | Measure in current range. |
|  | Apply SUZUKI BOND "1215". 99000-31110 (Except USA) |  | Measure in resistance range. |
|  | Apply SUZUKI BOND "1207B". 99104-31140 (USA) 99000-31140 (Others) |  | Measure in diode test range. |
|  | Apply THREAD LOCK SUPER "1303". 99000-32030 |  | Measure in continuity test range. |
|  | Apply THREAD LOCK SUPER "1322". 99000-32110 (Except USA) |  | Use special tool. |
|  | Apply THREAD LOCK "1342". 99000-32050 |  | Indication of service data. |

ABBREVIATIONS USED IN THIS MANUAL

SYMBOL

A

| | |
|--------------|--|
| ABDC | : After Bottom Dead Center |
| AC | : Alternating Current |
| ACL | : Air Cleaner, Air Cleaner Box |
| API | : American Petroleum Institute |
| ATDC | : After Top Dead Center |
| ATM Pressure | : Atmospheric Pressure Atmospheric Pressure Sensor (APS) |
| A/F | : Air Fuel Mixture |

B

| | |
|------|-----------------------------|
| BBDC | : Before Bottom Dead Center |
| BTDC | : Before Top Dead Center |
| B+ | : Battery Positive Voltage |

C

| | |
|------------|---|
| CKP Sensor | : Crankshaft Position Sensor (CKPS) |
| CKT | : Circuit |
| CLP Switch | : Clutch Lever Position Switch (Clutch Switch) |
| CMP Sensor | : Camshaft Position Sensor (CMPS) |
| CO | : Carbon Monoxide |
| CPU | : Central Processing Unit |

D

| | |
|------|-----------------------------|
| DC | : Direct Current |
| DMC | : Dealer Mode Coupler |
| DOHC | : Double Over Head Camshaft |
| DRL | : Daytime Running Light |

E

| | |
|---------------|--|
| ECM | : Engine Control Module Engine Control Unit (ECU) (FI Control Unit) |
| ECT Sensor | : Engine Coolant Temperature Sensor (ECTS), Water Temp. Sensor (WTS) |
| EVAP | : Evaporative Emission |
| EVAP Canister | : Evaporative Emission Canister (Canister) |

F

| | |
|----------|---------------------------------|
| FI | : Fuel Injection, Fuel Injector |
| FP | : Fuel Pump |
| FPR | : Fuel Pressure Regulator |
| FP Relay | : Fuel Pump Relay |

G

| | |
|-----------|------------------------|
| GEN | : Generator |
| GND | : Ground |
| GP Switch | : Gear Position Switch |

H

| | |
|----|----------------|
| HC | : Hydrocarbons |
|----|----------------|

I

| | |
|------------|---|
| IAP Sensor | : Intake Air Pressure Sensor (IAPS) |
| IAT Sensor | : Intake Air Temperature Sensor (IATS) |
| IG | : Ignition |

L

| | |
|-----|--|
| LCD | : Liquid Crystal Display |
| LED | : Light Emitting Diode (Malfunction Indicator Lamp) |
| LH | : Left Hand |

M

- MAL-Code : Malfunction Code
(Diagnostic Code)
- Max : Maximum
- MIL : Malfunction Indicator Lamp
(LED)
- Min : Minimum

N

- NOx : Nitrogen Oxides

O

- OHC : Over Head Camshaft
- OPS : Oil Pressure Switch

P

- PCV : Positive Crankcase
Ventilation (Crankcase Breather)

R

- RH : Right Hand
- ROM : Read Only Memory

S

- SAE : Society of Automotive Engineers
- STC System : Secondary Throttle Control
System (STCS)
- STP Sensor : Secondary Throttle Position
Sensor (STPS)
- ST Valve : Secondary Throttle Valve (STV)
- STV Actuator : Secondary Throttle Valve Actuator
(STVA)

T

- TO Sensor : Tip Over Sensor (TOS)
- TP Sensor : Throttle Position Sensor (TPS)

V

- VD : Vacuum Damper

SAE-TO-FORMER SUZUKI TERM

This table lists SAE (Society of Automotive Engineers) J1930 terms and abbreviations which may be used in this manual in compliance with SAE recommendations, as well as their former SUZUKI names.

| SAE TERM | | FORMER SUZUKI TERM |
|-------------------------------|---------------|---|
| FULL TERM | ABBREVIATION | |
| A | | |
| Air Cleaner | ACL | Air Cleaner, Air Cleaner Box |
| B | | |
| Barometric Pressure | BARO | Barometric Pressure, Atmospheric Pressure (APS, AP Sensor) |
| Battery Positive Voltage | B+ | Battery Voltage, +B |
| C | | |
| Camshaft Position Sensor | CMP Sensor | Camshaft Position Sensor (CMPS) |
| Crankshaft Position Sensor | CKP Sensor | Crankshaft Position Sensor (CKPS), Crank Angle |
| D | | |
| Data Link Connector | DLC | Dealer Mode Coupler |
| Diagnostic Test Mode | DTM | — |
| Diagnostic Trouble Code | DTC | Diagnostic Code, Malfunction Code |
| E | | |
| Electronic Ignition | EI | — |
| Engine Control Module | ECM | Engine Control Module (ECM) FI Control Unit, Engine Control Unit (ECU) |
| Engine Coolant Level | ECL | Coolant Level |
| Engine Coolant Temperature | ECT | Coolant Temperature, Engine Coolant Temperature Water Temperature |
| Engine Speed | RPM | Engine Speed (RPM) |
| Evaporative Emission | EVAP | Evaporative Emission |
| Evaporative Emission Canister | EVAP Canister | — (Canister) |
| F | | |
| Fan Control | FC | — |
| Fuel Level Sensor | — | Fuel Level Sensor, Fuel Level Gauge |
| Fuel Pump | FP | Fuel Pump (FP) |
| G | | |
| Generator | GEN | Generator |
| Ground | GND | Ground (GND, GRD) |

| SAE TERM | | FORMER SUZUKI TERM |
|-----------------------------------|--------------|---|
| FULL TERM | ABBREVIATION | |
| I | | |
| Idle Speed Control | ISC | — |
| Ignition Control | IC | Electronic Spark Advance (ESA) |
| Ignition Control Module | ICM | — |
| Intake Air Temperature | IAT | Intake Air Temperature (IAT), Air Temperature |
| M | | |
| Malfunction Indicator Lamp | MIL | LED Lamp Malfunction Indicator Lamp (MIL) |
| Manifold Absolute Pressure | MAP | Intake Air Pressure (IAP), Intake Vacuum |
| Mass Air Flow | MAF | Air Flow |
| O | | |
| On-Board Diagnostic | OBD | Self-Diagnosis Function Diagnostic |
| Open Loop | OL | — |
| P | | |
| Programmable Read Only Memory | PROM | — |
| Pulsed Secondary Air Injection | PAIR | Pulse Air Control (PAIR) |
| Purge Valve | Purge Valve | Purge Valve (SP Valve) |
| R | | |
| Random Access Memory | RAM | — |
| Read Only Memory | ROM | ROM |
| S | | |
| Secondary Air Injection | AIR | — |
| Secondary Throttle Control System | STCS | STC System (STCS) |
| Secondary Throttle Valve | STV | ST Valve (STV) |
| Secondary Throttle Valve Actuator | STVA | STV Actuator (STVA) |
| T | | |
| Throttle Body | TB | Throttle Body (TB) |
| Throttle Body Fuel Injection | TBI | Throttle Body Fuel Injection (TBI) |
| Throttle Position Sensor | TP Sensor | TP Sensor (TPS) |
| V | | |
| Voltage Regulator | VR | Voltage Regulator |
| Volume Air Flow | VAF | Air Flow |

WIRE COLOR

B : Black
Bl : Blue
Br : Brown
Dg : Dark green
G : Green

Gr : Gray
Lbl : Light blue
Lg : Light green
O : Orange
P : Pink

R : Red
W : White
Y : Yellow

B/Bl : Black with Blue tracer
B/G : Black with Green tracer
B/R : Black with Red tracer
B/Y : Black with Yellow tracer
Bl/G : Blue with Green tracer
Bl/W : Blue with White tracer
Br/B : Brown with Black tracer
G/B : Green with Black tracer
G/Y : Green with Yellow tracer
Gr/R : Gray with Red tracer
O/B : Orange with Black tracer
O/G : Orange with Green tracer
O/W : Orange with White tracer
P/W : Pink with White tracer
R/W : Red with White tracer
W/Bl : White with Blue tracer
Y/B : Yellow with Black tracer
Y/G : Yellow with Green tracer

B/Br : Black with Brown tracer
B/O : Black with Orange tracer
B/W : Black with White tracer
Bl/B : Blue with Black tracer
Bl/R : Blue with Red tracer
Bl/Y : Blue with Yellow tracer
Br/W : Brown with White tracer
G/R : Green with Red tracer
Gr/B : Gray with Black tracer
Gr/W : Gray with White tracer
O/Bl : Orange with Blue tracer
O/R : Orange with Red tracer
O/Y : Orange with Yellow tracer
R/B : Red with Black tracer
W/B : White with Black tracer
W/R : White with Red tracer
Y/Bl : Yellow with Blue tracer
Y/R : Yellow with Red tracer

GENERAL INFORMATION

1

CONTENTS

| | |
|---|-------------|
| WARNING/CAUTION/NOTE | 1- 2 |
| GENERAL PRECAUTIONS..... | 1- 2 |
| SUZUKI SV650 ('03-MODEL)..... | 1- 4 |
| SUZUKI SV650S ('03-MODEL) | 1- 4 |
| SERIAL NUMBER LOCATION..... | 1- 5 |
| FUEL, OIL AND ENGINE COOLANT RECOMMENDATION..... | 1- 5 |
| FUEL (FOR USA AND CANADA)..... | 1- 5 |
| FUEL (FOR OTHER COUNTRIES)..... | 1- 5 |
| ENGINE OIL (FOR USA)..... | 1- 5 |
| ENGINE OIL (FOR OTHER COUNTRIES) | 1- 5 |
| BRAKE FLUID..... | 1- 6 |
| FRONT FORK OIL | 1- 6 |
| ENGINE COOLANT | 1- 6 |
| WATER FOR MIXING | 1- 6 |
| ANTI-FREEZE/ENGINE COOLANT..... | 1- 6 |
| LIQUID AMOUNT OF WATER/ENGINE COOLANT | 1- 6 |
| BREAK-IN PROCEDURES | 1- 7 |
| CYLINDER IDENTIFICATION | 1- 7 |
| INFORMATION LABELS..... | 1- 8 |
| SPECIFICATIONS | 1- 9 |
| DIMENSIONS AND DRY MASS | 1- 9 |
| ENGINE | 1- 9 |
| DRIVE TRAIN..... | 1- 9 |
| CHASSIS..... | 1-10 |
| ELECTRICAL | 1-10 |
| CAPACITIES | 1-10 |
| COUNTRY AND AREA CODES..... | 1-11 |

WARNING/CAUTION/NOTE

Please read this manual and follow its instructions carefully. To emphasize special information, the symbol and the words WARNING, CAUTION and NOTE have special meanings. Pay special attention to the messages highlighted by these signal words.

▲ WARNING

Indicates a potential hazard that could result in death or injury.

CAUTION

Indicates a potential hazard that could result in motorcycle damage.

NOTE:

Indicates special information to make maintenance easier or instructions clearer.

Please note, however, that the warnings and cautions contained in this manual cannot possibly cover all potential hazards relating to the servicing, or lack of servicing, of the motorcycle. In addition to the WARNINGS and CAUTIONS stated, you must use good judgement and basic mechanical safety principles. If you are unsure about how to perform a particular service operation, ask a more experienced mechanic for advice.

GENERAL PRECAUTIONS

▲ WARNING

- * Proper service and repair procedures are important for the safety of the service mechanic and the safety and reliability of the motorcycle.
- * When 2 or more persons work together, pay attention to the safety of each other.
- * When it is necessary to run the engine indoors, make sure that exhaust gas is forced outdoors.
- * When working with toxic or flammable materials, make sure that the area you work in is well-ventilated and that you follow all of the material manufacturer's instructions.
- * Never use gasoline as a cleaning solvent.
- * To avoid getting burned, do not touch the engine, engine oil, radiator and exhaust system until they have cooled.
- * After servicing the fuel, oil, water, exhaust or brake systems, check all lines and fittings related to the system for leaks.

CAUTION

- * If parts replacement is necessary, replace the parts with Suzuki Genuine Parts or their equivalent.
 - * When removing parts that are to be reused, keep them arranged in an orderly manner so that they may be reinstalled in the proper order and orientation.
 - * Be sure to use special tools when instructed.
 - * Make sure that all parts used in reassembly are clean. Lubricate them when specified.
 - * Use the specified lubricant, bond, or sealant.
 - * When removing the battery, disconnect the negative cable first and then the positive cable.
 - * When reconnecting the battery, connect the positive cable first and then the negative cable, and replace the terminal cover on the positive terminal.
 - * When performing service to electrical parts, if the service procedures not require use of battery power, disconnect the negative cable the battery.
 - * When tightening the cylinder head and case bolts and nuts, tighten the larger sizes first. Always tighten the bolts and nuts diagonally from the inside toward outside and to the specified tightening torque.
 - * Whenever you remove oil seals, gaskets, packing, O-rings, locking washers, self-locking nuts, cotter pins, circlips and certain other parts as specified, be sure to replace them with new ones. Also, before installing these new parts, be sure to remove any left over material from the mating surfaces.
 - * Never reuse a circlip. When installing a new circlip, take care not to expand the end gap larger than required to slip the circlip over the shaft. After installing a circlip, always ensure that it is completely seated in its groove and securely fitted.
 - * Use a torque wrench to tighten fasteners to the specified torque. Wipe off grease and oil if a thread is smeared with them.
 - * After reassembling, check parts for tightness and proper operation.
-
- * To protect the environment, do not unlawfully dispose of used motor oil, engine coolant and other fluids: batteries, and tires.
 - * To protect Earth's natural resources, properly dispose of used motorcycle and parts.

SUZUKI SV650 ('03-MODEL)



RIGHT SIDE



LEFT SIDE

- Difference between photographs and actual motorcycles depends on the markets.

SUZUKI SV650S ('03-MODEL)



RIGHT SIDE



LEFT SIDE

- Difference between photographs and actual motorcycles depends on the markets.

BRAKE FLUID

Specification and classification: DOT 4

▲ WARNING

Since the brake system of this motorcycle is filled with a glycol-based brake fluid by the manufacturer, do not use or mix different types of fluid such as silicone-based and petroleum-based fluid for refilling the system, otherwise serious damage will result.
Do not use any brake fluid taken from old or used or unsealed containers.
Never re-use brake fluid left over from a previous servicing, which has been stored for a long period.

FRONT FORK OIL

Use fork oil SS8 or an equivalent fork oil.

ENGINE COOLANT

Use an anti-freeze/engine coolant compatible with an aluminum radiator, mixed with distilled water only.

WATER FOR MIXING

Use distilled water only. Water other than distilled water can corrode and clog the aluminum radiator.

ANTI-FREEZE/ENGINE COOLANT

The engine coolant perform as a corrosion and rust inhibitor as well as anti-freeze. Therefore, the engine coolant should be used at all times even though the atmospheric temperature in your area does not go down to freezing point.

Suzuki recommends the use of SUZUKI COOLANT anti-freeze/engine coolant. If this is not available, use an equivalent which is compatible with an aluminum radiator.

LIQUID AMOUNT OF WATER/ENGINE COOLANT

For engine coolant mixture information, refer to cooling system section, page 6-2

CAUTION

Mixing of anti-freeze/engine coolant should be limited to 60 %. Mixing beyond it would reduce its efficiency. If the anti-freeze/engine coolant mixing ratio is below 50 %, rust inhabiting performance is greatly reduced. Be sure to mix it above 50 % even though the atmospheric temperature does not go down to the freezing point.

BREAK-IN PROCEDURES

During manufacture only the best possible materials are used and all machined parts are finished to a very high standard but it is still necessary to allow the moving parts to "BREAK-IN" before subjecting the engine to maximum stresses. The future performance and reliability of the engine depends on the care and restraint exercised during its early life. The general rules are as follows.

- Keep to these break-in engine speed limits:

Initial 800 km (500 miles): Below 5 000 r/min


Up to 1 600 km (1 000 miles): Below 8 000 r/min

Over to 1 600 km (1 000 miles): Below 10 500 r/min

- Upon reaching an odometer reading of 1 600 km (1 000 miles) you can subject the motorcycle to full throttle operation. However, do not exceed 10 500 r/min at any time.






CYLINDER IDENTIFICATION

The two cylinders of this engine are identified as NO.1 and NO.2 cylinder, as viewed from front to rear (as viewed by the rider on the seat).



INFORMATION LABELS

| | |
|---|--------------------------------------|
| ① | Noise label (For E-03, 24, 33) |
| ② | Information label (For E-03, 28, 33) |
| ③ | Vacuum hose routing label (For E-33) |
| ④ | Fuel caution label (For E-02, 24) |
| ⑤ | Manual notice label (For E-03, 33) |
| ⑥ | Frame caution label |
| ⑦ | Screen warning label (SV650S) |
| ⑧ | Steering warning label (SV650S) |
| ⑨ | Tire information label |
| ⑩ | Warning safety label |
| ⑪ | ICES Canada label (For E-28) |
| ⑫ | ID plate (Except for E-03, 28, 33) |
| ⑬ | Safety plate (For E-03, 28, 33) |



SPECIFICATIONS

DIMENSIONS AND DRY MASS

| | |
|-----------------------|---------------------------------|
| Overall length | 2 125 mm (83.7 in) SV650 |
| | 2 130 mm (83.9 in) SV650S |
| Overall width | 745 mm (29.3 in) SV650 |
| | 730 mm (28.7 in) SV650S |
| Overall height | 1 085 mm (42.7 in) SV650 |
| | 1 175 mm (46.3 in) SV650S |
| Wheelbase | 1 440 mm (56.7 in) SV650 |
| | 1 430 mm (56.3 in) SV650S |
| Ground clearance..... | 150 mm (5.9 in) SV650 |
| | 155 mm (6.1 in) SV650S |
| Seat height..... | 800 mm (31.5 in) |
| Dry mass | 167 kg (368 lbs) SV650 |
| | 171 kg (376 lbs) SV650S |

ENGINE

| | |
|---------------------------|---|
| Type | 4-stroke, liquid-cooled, DOHC, 90 °-degree V-twin |
| Number of cylinders | 2 |
| Bore..... | 81.0 mm (3.189 in) |
| Stroke..... | 62.6 mm (2.465 in) |
| Displacement | 645 cm ³ (39.4 cu.in) |
| Compression ratio | 11.5 : 1 |
| Carburetion | Fuel injection |
| Air cleaner | Non-woven fabric element |
| Starter system..... | Electric |
| Lubrication system | Wet sump |
| Idle speed..... | 1 300 ± 100 r/min |

DRIVE TRAIN

| | |
|-------------------------------|------------------------------------|
| Clutch | Wet multi-plate type |
| Transmission..... | 6-speed constant mesh |
| Gearshift pattern | 1-down, 5-up |
| Primary reduction ratio | 2.088 (71/34) |
| Final reduction ratio..... | 3.000 (45/15) SV650 |
| | 2.933 (44/15) SV650S |
| Gear ratios, Low | 2.461 (32/13) |
| 2nd..... | 1.777 (32/18) |
| 3rd..... | 1.380 (29/21) |
| 4th..... | 1.125 (27/24) |
| 5th..... | 0.961 (25/26) |
| Top..... | 0.851 (23/27) |
| Drive chain | DID 525 V8, 110 links SV650 |
| | DID 525 V8, 108 links SV650S |

CHASSIS

| | |
|------------------------|---|
| Front suspension | Telescopic, coil spring, oil damped |
| Rear suspension | Link type, coil spring, oil damped |
| Front fork stroke..... | 130 mm (5.1 in) |
| Rear wheel travel..... | 134 mm (5.3 in) |
| Caster | 25 ° |
| Trail..... | 102 mm (4.02 in) SV650 100 mm (3.94 in) SV650S |
| Steering angle..... | 32 ° (right & left)..... SV650 30 ° (right & left)..... SV650S |
| Turning radius | 3.0 m (9.8 ft) SV650 3.2 m (10.5 ft) SV650S |
| Front brake..... | Disc brake, twin |
| Rear brake | Disc brake |
| Front tire size | 120/60 ZR17 MC (55 W), tubeless |
| Rear tire size..... | 160/60 ZR17 MC (69 W), tubeless |

ELECTRICAL

| | |
|--|---|
| Ignition type..... | Electronic ignition (Transistorized) |
| Ignition timing..... | 7 ° B.T.D.C. at 1 300 r/min |
| Spark plug..... | NGK CR8E, or DENSO U24ESR-N |
| Battery..... | 12V 36.0 kC (10 Ah)/10 HR |
| Generator..... | Three-phase A.C. generator |
| Main fuse | 30 A |
| Fuse | 15/10/10/10/10/10 A SV650 15/15/15/10/10/10 A SV650S |
| Headlight..... | 12 V 60/55 W (H4)..... SV650 12 V 60/55 W (H4) × 2.. SV650S |
| Position light..... | 12 V 5 W..... SV650 (Except E-03, 24, 33) 12 V 5 W × 2..... SV650S |
| Brake light/Taillight..... | LED |
| License plate light | 12 V 5 W |
| Turn signal light..... | 12 V 21 W |
| Speedometer light..... | LED |
| Turn signal indicator light..... | LED |
| Neutral indicator light | LED |
| High beam indicator light | LED |
| Oil pressure/Coolant temperature/ Fuel injection warning light..... | LED |
| Fuel injection light | LED |

CAPACITIES

| | |
|------------------------------------|--|
| Fuel tank, including reserve | 16 L (4.2/3.5 US/lmp gal) E-33 17 L (4.5/3.7 US/lmp gal) Others |
| Engine oil, oil change..... | 2 300 ml (2.4/2.0 US/lmp qt) |
| with filter change | 2 700 ml (2.9/2.4 US/lmp qt) |
| overhaul | 3 100 ml (3.3/2.7 US/lmp qt) |
| Coolant..... | 1.7 L (1.8/1.5 US/lmp qt) |

These specifications are subject to change without notice.

COUNTRY AND AREA CODES

The following codes stand for the applicable country (-ies) and area (-s).

| CODE | COUNTRY or AREA |
|------|--------------------------------|
| E-02 | U.K. |
| E-03 | U.S.A. (Except for california) |
| E-19 | EU |
| E-24 | Australia |
| E-28 | Canada |
| E-33 | California (U.S.A.) |

PERIODIC MAINTENANCE

CONTENTS

| | |
|--|------|
| PERIODIC MAINTENANCE SCHEDULE | 2- 2 |
| PERIODIC MAINTENANCE CHART | 2- 2 |
| LUBRICATION POINTS | 2- 4 |
| MAINTENANCE AND TUNE-UP PROCEDURES | 2- 5 |
| AIR CLEANER | 2- 5 |
| SPARK PLUG | 2- 6 |
| TAPPET CLEARANCE | 2- 9 |
| ENGINE OIL AND OIL FILTER | 2-14 |
| FUEL HOSE | 2-16 |
| ENGINE IDLE SPEED | 2-16 |
| THROTTLE VALVE SYNCHRONIZATION | 2-16 |
| EVAPORATIVE EMISSION CONTROL SYSTEM (E-33 ONLY) | 2-16 |
| PAIR (AIR SUPPLY) SYSTEM | 2-16 |
| THROTTLE CABLE PLAY | 2-17 |
| CLUTCH | 2-19 |
| ENGINE COOLANT | 2-20 |
| RADIATOR HOSES | 2-22 |
| DRIVE CHAIN | 2-22 |
| BRAKE | 2-26 |
| TIRE | 2-29 |
| STEERING | 2-30 |
| FRONT FORK | 2-31 |
| REAR SUSPENSION | 2-31 |
| EXHAUST PIPE BOLT AND NUT | 2-31 |
| CHASSIS BOLT AND NUT | 2-32 |
| COMPRESSION PRESSURE CHECK | 2-34 |
| COMPRESSION TEST PROCEDURE | 2-34 |
| OIL PRESSURE CHECK | 2-35 |

PERIODIC MAINTENANCE SCHEDULE

The chart below lists the recommended intervals for all the required periodic service work necessary to keep the motorcycle operating at peak performance and economy. Mileages are expressed in terms of kilometers, miles and time for your convenience.

IMPORTANT: The periodic maintenance intervals and service requirements have been established in accordance with EPA regulations. Following these instructions will ensure that the motorcycle will not exceed emission standards and it will also ensure the reliability and performance of the motorcycle.

NOTE:

More frequent servicing may be performed on motorcycles that are used under severe conditions.

PERIODIC MAINTENANCE CHART

| Item | Interval | km | 1 000 | 6 000 | 12 000 | 18 000 | 24 000 |
|---|----------|--------|---|-------|--------|--------|--------|
| | | miles | 600 | 4 000 | 7 500 | 11 000 | 14 500 |
| | | months | 1 | 6 | 12 | 18 | 24 |
| Air cleaner | | | — | | | R | |
| Spark plugs | | | — | | R | | R |
| Tappet clearance | | | — | — | — | — | |
| Engine oil | | | R | R | R | R | R |
| Engine oil filter | | | R | — | — | R | — |
| Fuel line | | | — | | | | |
| | | | Replace every 4 years. | | | | |
| Engine idle speed | | | | | | | |
| Throttle valve synchronization | | | E-33 only | — | | — | |
| Evaporative emission control system E-33 (California) model only | | | — | — | | — | |
| | | | Replace vapor hose every 4 years. | | | | |
| PAIR (air supply) system | | | — | — | | — | |
| Throttle cable play | | | | | | | |
| Clutch | | | — | | | | |
| Radiator hoses | | | — | | | | |
| | | | Replace every 4 years. | | | | |
| Engine coolant | | | Replace every 2 years. | | | | |
| Drive chain | | | | | | | |
| | | | Clean and lubricate every 1 000 km (600 miles). | | | | |
| Brakes | | | | | | | |
| Brake hose | | | — | | | | |
| | | | Replace every 4 years. | | | | |
| Brake fluid | | | — | | | | |
| | | | Replace every 2 years. | | | | |

| Item | Interval | km | 1 000 | 6 000 | 12 000 | 18 000 | 24 000 |
|-----------------------------|----------|--------|-------|-------|--------|--------|--------|
| | | miles | 600 | 4 000 | 7 500 | 11 000 | 14 500 |
| | | months | 1 | 6 | 12 | 18 | 24 |
| Tires | | — | I | I | I | I | I |
| Steering | | I | — | I | — | I | I |
| Front forks | | — | — | I | — | I | I |
| Rear suspension | | — | — | I | — | I | I |
| Exhaust pipe bolts and nuts | | T | — | T | — | T | T |
| Chassis bolts and nuts | | T | T | T | T | T | T |

NOTE:


I=Inspect and clean, adjust, replace or lubricate as necessary;

R=Replace; T=Tighten


LUBRICATION POINTS

Proper lubrication is important for smooth operation and long life of each working part of the motorcycle. Major lubrication points are indicated below.

SV650



SV650S



- ① Brake pedal pivot and footrest pivot
- ② Brake lever holder and throttle cables
- ③ Clutch lever holder and clutch cable

- ④ Side-stand pivot and spring hook
- ⑤ Footrest pivot
- ⑥ Drive chain

NOTE:

- * Before lubricating each part, clean off any rusty spots and wipe off any grease, oil, dirt or grime.
- * Lubricate exposed parts which are subject to rust, with a rust preventative spray whenever the motorcycle has been operated under wet or rainy conditions.

MAINTENANCE AND TUNE-UP PROCEDURES

This section describes the servicing procedures for each item of the Periodic Maintenance requirements.

AIR CLEANER



Inspect every 6 000 km (4 000 miles, 6 months) and replace every 18 000 km (11 000 miles, 18 months).

- Lift and support the fuel tank. (☞ 5-6)
- Remove the air cleaner box cap ①.
- Carefully use air hose to blow the dust from the cleaner element.

CAUTION

Always use air pressure on the throttle body side of the air cleaner element. If air pressure is used on the other side, dirt will be forced into the pores of the air cleaner element thus restricting air flow through the air cleaner element.


- Reinstall the cleaned or new air cleaner element in the reverse order of removal.



CAUTION

If driving under dusty conditions, clean the air cleaner element more frequently. The surest way to accelerate engine wear is to operate the engine without the element or to use a torn element. Make sure that the air cleaner is in good condition at all times. The life of the engine depends largely on this component!

- Remove the drain plugs ② from the air cleaner drain hose and air cleaner box to allow any water to drain out.



SPARK PLUG


Inspect every 6 000 km (4 000 miles, 6 months) and replace every 12 000 km (7 500 miles, 12 months).

▲ WARNING


The hot radiator and the hot engine can burn you. Wait until the radiator and the engine are cool enough to touch.

NO.1 (FRONT) SPARK PLUG REMOVAL

- Remove the radiator front cover ①. (SV650)




- Remove the radiator lower mounting bolt.



- Move the radiator lower side to forward.

NOTE:

- * Do not extract the radiator hoses.
- * Place a wooden block **(A)** between the radiator and the front cylinder to facilitate spark plug removal.




- Disconnect the spark plug cap and remove the spark plug.

TOOL 09930-10121: Spark plug socket wrench set

NOTE:

Be careful not to damage the radiator fins.



NO.2 (REAR) SPARK PLUG REMOVAL

- Lift and support the fuel tank. (☞ 5-6)



- Disconnect the spark plug cap.
- Remove the spark plug with a spark plug wrench.

TOOL 09930-10121: Spark plug socket wrench set




HEAT RANGE

Check to see the heat range of the plug.

| | Standard | Cold type | Hot type |
|-----|----------|-----------|----------|
| NGK | CR8E | CR9E | CR7E |
| ND | U24ESR-N | U27ESR-N | U22ESR-N |

CARBON DEPOSITS


Check to see if there are carbon deposits on the spark plug. If carbon is deposited, remove it with a spark plug cleaner machine or carefully use a tool with a pointed end.

**SPARK PLUG GAP**

Measure the spark plug gap with a thickness gauge. If out of specification, regap the spark plug.

DATA Spark plug gap
Standard: 0.7 – 0.8 mm (0.028 – 0.031 in)

TOOL 09900-20803: Thickness gauge

**ELECTRODE'S CONDITION**

Check to see the worn or burnt condition of the electrodes. If it is extremely worn or burnt, replace the spark plug. Replace the spark plug if it has a broken insulator, damaged thread, etc.

CAUTION

Confirm the thread size and reach when replacing the plug. If the reach is too short, carbon will be deposited on the screw portion of the plug hole and engine damage may result.

SPARK PLUG INSTALLATION**CAUTION**

Before tightening the spark plug to the specified torque, carefully turn the spark plug by finger into the threads of the cylinder head to prevent damage the aluminum threads.

- First, finger tighten the spark plugs, and then tighten them to the specified torque.


TOOL Spark plug: 11 N·m (1.1 kgf-m, 8.0 lb-ft)



Product: 2003 Suzuki SV650/S Motorcycle Service Repair Workshop Manual
 Full Download: <https://www.arepairmanual.com/downloads/2003-suzuki-sv650s-motorcycle-service-repair-workshop-manual/>


NOTE:

When fitting the spark plug caps, front and rear, face the triangle marks **A** on the water-proof covers to each cylinder exhaust side.

**TAPPET CLEARANCE**

Inspect every 24 000 km (14 500 miles, 24 months).

- Lift and support the fuel tank. (☞ 5-6)
- Remove the spark plugs, front and rear. (☞ 2-6)
- Remove the cylinder head covers, front and rear.




The tappet clearance specification is different for intake and exhaust valves.

Tappet clearance must be checked and adjusted, 1) at the time of periodic inspection, 2) when the valve mechanism is serviced, and 3) when the camshafts are disturbed by removing them for servicing.


DATA Tappet clearance (when cold):

IN. : 0.10 – 0.20 mm (0.004 – 0.008 in)

EX.: 0.20 – 0.30 mm (0.008 – 0.012 in)

**NOTE:**

- * The tappet clearance should be taken when each cylinder is at Top Dead Center (TDC) of compression stroke.
- * The cams (IN & EX) on the front cylinder at position **A** show the front cylinder at TDC of compression stroke.
- * The cams (IN & EX) on the rear cylinder at position **B** show the rear cylinder at TDC of compression stroke.
- * The clearance specification is for COLD state.
- * To turn the crankshaft for clearance checking, be sure to use a wrench, and rotate in the normal running direction. All spark plugs should be removed.



Sample of manual. Download All 610 pages at:

<https://www.arepairmanual.com/downloads/2003-suzuki-sv650s-motorcycle-service-repair-workshop-manual/>