

Product: Yanmar 6CX-ETE Marine Diesel Engine Service Repair Workshop Manual  
Full Download: <https://www.arepairmanual.com/downloads/yanmar-6cx-ete-marine-diesel-engine-service-repair-workshop-manual/>

# **YANMAR**

# **SERVICE MANUAL**

## **MARINE DIESEL ENGINE**

### **MODEL 6CX-ETE**

Sample of manual. Download All 119 pages at:  
<https://www.arepairmanual.com/downloads/yanmar-6cx-ete-marine-diesel-engine-service-repair-workshop-manual/>

## FOREWORD

This service manual outlines procedures for servicing and maintaining Yanmar 6CX-ETE engines to obtain maximum life and performance. It explains about the structure, performance, dis- and re-assembly procedures, important inspection points, servicing instructions and the wear limit of parts. For a full understanding of this manual, also refer to the Operation Manual and Parts Catalog. Besides reference use at your service shop, this manual can also be used as a text for your service engineers. You should understand the contents of this manual fully to offer accurate and efficient service to your customers.

For accurate and efficient work, the following preparations are necessary:

1. Check the service date of your customer

- ① When was the last service?
- ② How many months or hours has the engine been used since the last service?
- ③ What was the trouble and what parts were replaced in the last service?
- ④ What parts must be replaced in the present service?

2. Preparation of Parts

Check the inventory of parts that are necessary for servicing.

3. Preparation of Report Forms

Inspection and service check sheets, parts measurement record form, operation test record form.

4. Prepare the servicing tools, measuring devices, containers, etc.

# CONTENTS

<b>1. Specifications</b> .....	<b>1</b>
1-1. Major Specification .....	1
1-2. Marine Gear .....	2
<b>2. Disassembly and Reassembly</b> .....	<b>3</b>
2-1. Preparations before Disassembly and Reassembly .....	3
2-2. Disassembly and Reassembly Tools .....	4
2-3. Reassembly Procedures .....	9
<b>3. Inspection and Servicing of Major Engine Parts</b> .....	<b>32</b>
3-1. Cylinder Head .....	32
3-2. Piston and Piston Pin .....	37
3-3. Connecting Rod .....	41
3-4. Cylinder Sleeve .....	42
3-5. Cylinder Block .....	44
3-6. Crankshaft and Main Bearing .....	44
3-7. Camshaft and Valve Gear .....	49
3-8. Timing Gear .....	51
3-9. Lube Oil System .....	52
3-10. Cooling Water System .....	56
3-11. Fuel Oil System .....	60
3-12. Piping Diagram .....	75
3-13. Electrical Equipment .....	79
3-14. Reduction Reversing Gears .....	93
3-15. Turbocharger .....	104
3-16. Front Driving Equipment .....	109
<b>4. Periodic Inspection</b> .....	<b>110</b>
<b>5. Service Standard</b> .....	<b>112</b>
<b>6. Adjustment and Set Values</b> .....	<b>114</b>
<b>7. Tightening Torque of Major Bolts and Nuts</b> .....	<b>115</b>

# 1. Specifications

## 1-1. Major Specification

(Without marine gear)

ENGINE MODEL		UNIT	6CX-ETE				
Type			Vertical, water-cooling, 4-cycle diesel engine				
Combustion system			Direct injection				
Aspiration			Turbocharger with air cooler				
No. of cyl. - bore × Stroke		mm	6 - 110 × 125				
Displacement		ℓ	7.127				
Continuous rating	Output/Crankshaft speed	HP/rpm	375/2600				
	Brake mean effective pressure	kgf/cm <sup>2</sup>	18.21				
	Piston speed	m/sec	10.83				
Max. rating	Specifications		Flywheel end				
	Output/Crankshaft speed	HP/rpm	420/2700				
	Brake mean effective pressure	kgf/cm <sup>2</sup>	19.64				
	Piston speed	m/sec	11.25				
Non-load rotation speed (Max./Min)		rpm	3000 ± 25 / 700 ± 25				
Starting system			Electric starting, 12V-4KW				
Firing order			1-4-2-6-3-5-1				
Direction of rotation (viewed from stem)	Crankshaft		Counter-clockwise				
	Propeller shaft		Bi-rotation				
Lub. oil capacity	Max.	ℓ	23				
	Effect	ℓ	12				
Marine gear	Model		YX-70S				
	Type		Hydraulic wet multi-disk type				
	Reduction ratio(forward)		1.52	1.96	2.50		
	Propeller shaft speed(at cont. rating)	rpm	1716	1324	1040		
	Direction of rotation(propeller shaft)		Clockwise or counterclockwise viewed from stem				
	Dry weight	kg	160				
	Lubricating oil capacity	Max.	ℓ	5			
		Effective	ℓ	0.7			
Hydraulic oil pressure	kgf/cm <sup>2</sup>	24 ± 5					
Fuel system	Fuel injection pump		In-line type				
	Injection timing		b.T.D.C 12 ± 1				
	Type of injection nozzle degree		Hole type 5 - φ 0.34 × 150°				
	Injection pressure	kgf/cm <sup>2</sup>	240 ± 5				
	Applicable fuel		Diesel oil or light oil (Cetane value ≥ 45)				
	Fuel filter		Paper element				
Engine lub. oil system	Lubrication		Forced lubrication by geared pump				
	Lub. oil discharge volume	ℓ/hr./rpm	≥ 6720/2600				
	Lub. oil pressure	kgf/cm <sup>2</sup>	5 ± 0.5				
	Lub. oil		API Service grade CD				
	Lub. oil filter		(Suction side) Perforated steel plate	(Discharge side) Paper element			
Cooling water system	Sea water pump		Rubber impeller type, gear driving type				
	Freshwater pump		Center type, V-belt driving type				
	Cooling		Fresh water cooling				
	Pump discharge volume	ℓ/hr./rpm	Seawater : ≥ 9820/2600 Fresh water : ≥ 13000/2600				
	Fresh water capacity inside engine	ℓ	36				
	Fresh water capacity in sub-tank	ℓ	1.1				
Turbocharger	Type		Garret TW51				
	Cooling		Water cooling				
	Lubrication		Common with engine				
Air cooler	Type and capacity		Fin tube type 6.5m <sup>2</sup>				
	Cooling		Seawater cooling				
Engine dimension: Overall length × overall width × overall height		mm	1607 × 869 × 994				
Piston stroke height(from installation floor)			797				
Engine dry weight(inc. clutch)		kg	990				

△ NOTE Max. rating: Continuous operation hours at max. below 0.5 hours.



## 1-2. Marine Gear

Reduction and reversing gear	Model		YX-70S		
	Type		Constant mesh gear with multiple disc clutch		
	Reduction ratio(Ahead/Astern)		1.52/1.52	1.96/1.96	2.50/2.50
	Propeller speed(Ahead)(at continuous rating)	rpm	1716/1716	1324/1324	1040/1040
Direction of rotation	Crankshaft		Counterclockwise viewed from stern		
	Propeller shaft		Changeable(Clockwise/conter-clockwise)		
Hydraulic oil pressure			24kg/cm <sup>2</sup> ±0.5/2700rpm		
Lube oil pressure			2.5kg/cm <sup>2</sup> ±0.5/2700rpm		
API Service grade			CD		
Dry weight		kg	210		

## 2. Disassembly and Reassembly

### 2-1. Preparations before Disassembly and Reassembly

#### 2-1-1 Visual Mark List for Disassembly and Reassembly

Visual Mark		Visual Mark	
	See		※1 Apply liquid packing
	Caution		Safety
	Measure		Clean
	Oil supply		※2 Use torque wrench

※1 THREE BOND 3B-388-055

※2 The figure shows the widths across flat of the hexagonal part.

#### 2-1-2 Disassembly

- (1) Prepare the disassembly tools, measuring devices and record forms.
- (2) Prepare the cleaning machine and cleaning cans.
- (3) Prepare a place for putting parts and parts containers.
- (4) Extract cooling water and lube oil.
- (5) Put the disassembled parts in order.
- (6) Return bolts and nuts to their original positions temporarily to avoid confusion with different bolt and nut types.
- (7) Locate the cause of trouble accurately before disassembly, and do not remove or disassemble unnecessary parts.


#### 2-1-3 Reassembly

- (1) Clean and inspect the disassembled parts completely.
- (2) Apply clean engine oil to the sliding and rotational parts before installation.
- (3) Replace all gaskets and O-rings.
- (4) Apply liquid packing to the necessary parts to prevent water or oil leakage.
- (5) Check and ensure the correct oil and thrust clearance during reassembly.
- (6) Install the parts according to the alignment marks when they are provided. Take care of the combination of the parts with selective engagement.
- (7) Do not mix up bolts, nuts and washers. Tighten the major bolts and nuts to the specified tightening torque. Take special care when tightening aluminum alloy parts.
- (8) Apply engine oil to the threads and seat of the major bolts and tighten them to the specified tightening torque.





## 2-2. Disassembly and Reassembly Tools







### Standard tools




The following are the standard disassembly and reassembly tools:

Name of tool	Size	Shape
Double-headed wrench	8 × 10, 12 × 14, 13 × 17 19 × 22, 24 × 27	(for removing fuel valve)
Wrench	7, 26	
Monkey wrench	200	
Screw driver	⊕, ⊖ changeable	
Hexagon bar wrench	(for clutch emergency bolt)	
Double-head wrench	17 × 19	
Pliers		
Box wrench	19 × 12 (for cyl. head) 13 × 17 (for fuel oil pump)	
Extractor	(for fuel valve adiabatic packing) 127610-92910	
Extractor	(for removing fuel valve) 127616-92500	
Clearance gauge	(for adjusting intake/exhaust valve clearance)	
Hammar		
Filter wrench	(for removing filters) 127610-92750	
Oiler		
Turning handle		





### Tools (to be specially ordered)

Name of tool	Code No.	Shape
Socket (for rod bolt)	127610-92730	
Extractor for valve guide	127411-92160	
Extractor for fuel oil valve	127616-92500	
Piston insertion tool	122310-92140	
Piston rings fitting/removal tool	135410-92140	
Oil pan potitioning tool	1. Bolt (4pcs) 127610-92700 2. Spacers A 127610-92680 3. Spacers B 127610-92690	

Name of tool	Code No.	shape
Fresh water pump impeller (cam gear puller) (Press-fitting type)	1. Spacer 127610-92430 2. Bolt 124160-77511 3. Bolt (for impeller) × 2 26116-060302 4. Bolt (for cam gear) × 2 26116-080502	
Automatic timer tool (adiabatic material puller)	158591-54120 158591-54200	
Adiabatic material puller	127610-92910 (Standard)	
Protector pulier	127695-92910	
Stem seal insertion tool		
Valve guide puller		

Name of tool	Code No.	shape
Exhaust manifold puller		
Fuel valve puller tool 127616-92500		

Special tools for clutch

No.	Name of tool	Note	shape
1	Emergency bolt span	For tightening the emergency bolt on clutch failure	
2	Gear puller		
3	Bearing separator	For removing bearing; used together with the gear puller	
4	Hydraulic fitting tool	For disassembly of output shaft joint Output shaft joint and large gear	

Name	for using
Liquid packing (THREEBOND auxiliary packing):	<p>The silver grey semi-dry type viscoelastic liquid packing based on extreme heat-resisting synthetic rubber and synthetic resin. Apply the packing to the seal surface and join the part after several minutes when the packing has become semi-dry.</p> <p>The white liquid packing based on nylon resin. Brush the packing on the seal surface and join the part after several minutes when the packing has become semi-dry.</p> <p>Be sure to stir well before use.</p>
White paint	Coat the paint on the contact area with the cylinder body before inserting the cylinder liner to prevent rust and water leakage. (Use the oil type make-up paint.)

Name	quantity	Code No.	Note
Scale removing agent	UNICON 1 case (4kg × 4)	974100-01460	<p>The strong scaling agent removes scale quickly (1-10 hrs.).</p> <p>Dissolve the agent in 10 parts of water or seawater (by weight ratio) and stir it well.</p> <p>Scale can be removed by just immersing the disassembled parts. To speed up the treatment, stir the solution. When the cleaning performance drops, neutralize the solution and throw it away.</p>
	Counteragent (caustic soda) 1 case (2kg × 4)	974100-0200	
	PH test paper	974100-04200	
Anti-rust agent	21	974100-04200	Mix the agent in ten parts of fresh water and stir the solution by operating the engine for about 5 minutes. The anti-rust performance lasts for about 6 months.
Yanmar Super Freeze			<p>Can be used both as anti-freeze in winter and coolant in summer. The performance lasts for 2 years.</p> <p>The Super Freeze can safely be mixed with anti-rust agent.</p>








Temp.	-5°C	-10°C	-15°C	-20°C	-25°C	-30°C	-35°C	-40°C
Volume ratio	15%	25%	30%	35%	40%	45%	50%	55%





Name	quantity	Code No.	using
Metal Clean Y (cleaning agent)	1kg × 20	975600-02000	<p>Has strong performance to remove accumulated carbon.</p> <p>Can safely be heated to double the cleaning performance.</p> <p>Corrodes almost no metals, including iron. (Also has anti-rust effect.)</p> <p>To use, dissolve 1kg of the agent in 40 liters of water.</p> <p>When a cleaning machine is used, use 4-6% solution and heat in to 60-80°C.</p> <p>This will further raise the effect.</p>
Blower Clean (Special cleaning agent for turbocharger)	4 ℓ × 4	919200-10000	Special cleaning agent for turbocharger blower. Needs on water washing.
	18 ℓ × 1	919200-30000	
	1500cc × 6	919200-20000	

Measuring Device







Name	quantity	Code No.	using
Cap tester	RCT-2A	955000-055000	For testing the radiator and the cap.




## 2-3. Reassembly Procedures




No.	Item	Procedure	Tool & Caution	Illustration				
1	Cylinder Block	<p>Clean the bearing holes completely. Reverse the cylinder block before reassembly.</p> <table border="1" data-bbox="416 427 756 524"> <tr> <td>T-plug 1/8 tightening torque</td> <td>0.5kgf - m</td> </tr> </table>	T-plug 1/8 tightening torque	0.5kgf - m		 <p>Cylinder Block</p>		
T-plug 1/8 tightening torque	0.5kgf - m							
2	Piston Cooling Nozzle	<p>Install the nozzle correctly according to the positioning pin. Take care not to over-tighten the nozzle.</p> <table border="1" data-bbox="416 808 756 869"> <tr> <td>Tightening torque</td> <td>2.0kgf-m</td> </tr> </table> <p>Check carefully that there are no chips or dust in the oil holes of the nozzle body, nozzle installation hole and check nozzle. Check that the nozzle body does not touch the cylinder block.</p>	Tightening torque	2.0kgf-m	 	 <p>Piston Cooling Nozzle</p>		
Tightening torque	2.0kgf-m							
3	Cam Shaft	<p>Apply lube oil to the cam shaft journal. Insert the cam shaft. Install the thrust plate.</p> <table border="1" data-bbox="416 1267 756 1328"> <tr> <td>Tightening torque</td> <td><math>2.6 \pm 0.2</math> kgf-m</td> </tr> </table> <p>Measure the side clearance.</p> <table border="1" data-bbox="416 1402 756 1503"> <tr> <td>Side clearance</td> <td>0.10-0.25mm</td> </tr> </table> <p>Installation of cam shaft metal. Replace the cam shaft metal as follows:</p> <ol style="list-style-type: none"> <li>1. Apply lube oil to the outside circumference of the cam shaft metal and the inside bore of the block.</li> <li>2. Align the oil hole so that the joint of the winding metal comes to the upper side.</li> <li>3. Overlapping of not less than 2mm will suffice for the alignment of the oil holes of the block and cam shaft metal. (Check the alignment after knocking in the cam shaft metal.)</li> </ol> 	Tightening torque	$2.6 \pm 0.2$ kgf-m	Side clearance	0.10-0.25mm	 	 <p>Cam Shaft</p>  <p>Installation of the thrust metal</p>
Tightening torque	$2.6 \pm 0.2$ kgf-m							
Side clearance	0.10-0.25mm							

No.	Item	Procedure	Tool & Caution	Illustration						
4	Cooling Water Passage Cover	Install the cooling water passage cover.	 12							
5	Crankshaft and Main Bearing	<p>The upper bearing (block side) has an oil groove; no oil groove in the lower bearing. The standard bearing is at the flywheel side (with flange). Apply lube oil to the crank and assemble. Confirm the alignment number on the bearing cap and block. Assemble with the F-mark at the flywheel side. Apply lube oil to the bolt threads and seat face and tighten the bolt to the specified tightening torque. Turn manually to check that it turns lightly. Measure the side clearance.</p> <table border="1" data-bbox="395 846 794 1070"> <tr> <td>Cap bolt tightening torque</td> <td><math>28^{+1.0}</math> kgf-m</td> </tr> <tr> <td>Side clearance</td> <td>0.155 - 0.296mm</td> </tr> <tr> <td>Crankshaft bearing oil clearance</td> <td>0.04 - 0.108mm</td> </tr> </table>	Cap bolt tightening torque	$28^{+1.0}$ kgf-m	Side clearance	0.155 - 0.296mm	Crankshaft bearing oil clearance	0.04 - 0.108mm	   24	<p>Fitting the upper bearing</p>  <p>Fitting the crank shaft</p>  <p>Apply lube oil</p>  <p>Fitting the bearing cap</p>  <p>Fitting the cap bolt</p>  <p>Measure the side clearance</p>
Cap bolt tightening torque	$28^{+1.0}$ kgf-m									
Side clearance	0.155 - 0.296mm									
Crankshaft bearing oil clearance	0.04 - 0.108mm									






No.	Item	Procedure	Tool & Caution	Illustration						
6	Idle Gear (Lube Oil Pump)	<p>Check the gear side clearance.</p> <table border="1" data-bbox="408 331 762 432"> <tr> <td data-bbox="408 331 560 432">Gear side clearance</td> <td data-bbox="560 331 762 432">0.066–0.114mm</td> </tr> </table> <p>Check the gear backlash.</p> <table border="1" data-bbox="408 488 762 589"> <tr> <td data-bbox="408 488 560 589">Gear backlash</td> <td data-bbox="560 488 762 589">0.08–0.16mm</td> </tr> </table> <p>Install the idle gear to the cap.</p> <table border="1" data-bbox="408 645 762 701"> <tr> <td data-bbox="408 645 560 701">Tightening torque</td> <td data-bbox="560 645 762 701">1.5–2.0kgf-m</td> </tr> </table>	Gear side clearance	0.066–0.114mm	Gear backlash	0.08–0.16mm	Tightening torque	1.5–2.0kgf-m		 <p data-bbox="1098 667 1310 696">Fitting the idle gear</p>
Gear side clearance	0.066–0.114mm									
Gear backlash	0.08–0.16mm									
Tightening torque	1.5–2.0kgf-m									



No.	Item	Procedure	Tool & Caution	Illustration				
7	Lube Oil Pump	<p>Install the lube oil assembly. Install the suction and discharge pipes.</p> <table border="1" data-bbox="386 338 802 439"> <tr> <td>(Bolt head width 12) Tightening torque</td> <td><math>2.5 \pm 0.2</math> kgf-m</td> </tr> </table> <p>Check the gear backlash (to the crankshaft).</p> <table border="1" data-bbox="386 495 802 595"> <tr> <td>Backlash for crank gear</td> <td>0.12-0.22mm</td> </tr> </table>  <p>Fitting to the suction pipe</p>	(Bolt head width 12) Tightening torque	$2.5 \pm 0.2$ kgf-m	Backlash for crank gear	0.12-0.22mm	 12  14 	 <p>Fitting to the lube oil pump</p>  <p>Fitting to the Safety valve and discharger pipe</p>
(Bolt head width 12) Tightening torque	$2.5 \pm 0.2$ kgf-m							
Backlash for crank gear	0.12-0.22mm							
8	Gear Case	<p>Install the bolt for fixing the fuel pump and the stud bolt for fixing the seawater pump to the gear case in advance. Match up the mounting surfaces of the oil pan. Align the positioning pin to the block and install the gear case.</p> <table border="1" data-bbox="386 1373 802 1473"> <tr> <td>(Bolt head width 12) Tightening torque</td> <td><math>2.6 \pm 0.2</math> kgf-m</td> </tr> </table> <p>Cut off the protruding packing.</p>	(Bolt head width 12) Tightening torque	$2.6 \pm 0.2$ kgf-m	 12	 <p>Fitting the gear case</p>		
(Bolt head width 12) Tightening torque	$2.6 \pm 0.2$ kgf-m							
9	Oil Pan	<p>Bring the gear case level so that the packing will not break. (Use the fitting tool.)</p> <table border="1" data-bbox="386 1619 802 1720"> <tr> <td>(Bolt head width 12) Tightening torque</td> <td><math>2.6 \pm 0.2</math> kgf-m</td> </tr> </table> <p>After tightening, cut off the packing protruding on the wheel housing side.</p> <p><i>Note:</i></p> <p><i>Apply THREEBOND to both sides of the packing at the three-face joint of the gear case and flywheel side. Match up the installation faces of the wheel housing.</i></p> <table border="1" data-bbox="386 1977 802 2078"> <tr> <td>Step of the joint face at the flywheel housing side</td> <td>0.1mm</td> </tr> </table>	(Bolt head width 12) Tightening torque	$2.6 \pm 0.2$ kgf-m	Step of the joint face at the flywheel housing side	0.1mm	 12  	 <p>Fit the oil pan using the tool</p>
(Bolt head width 12) Tightening torque	$2.6 \pm 0.2$ kgf-m							
Step of the joint face at the flywheel housing side	0.1mm							





No.	Item	Procedure	Tool & Caution	Illustration						
10	Flywheel Housing	<p>Assemble the flywheel housing according to the positioning parallel pin.</p> <table border="1" data-bbox="400 342 810 443"> <tr> <td>Deviation at the oil seal insertion area</td> <td>0.2mm</td> </tr> </table> <table border="1" data-bbox="400 461 810 562"> <tr> <td>Face deviation from the crankshaft center</td> <td>0.3mm</td> </tr> </table> <table border="1" data-bbox="400 584 810 685"> <tr> <td>Flywheel housing tightening torque</td> <td><math>5 \pm 0.5</math> kgf-m</td> </tr> </table> <p>Install the lube oil piping (flywheel housing – oil filter).</p>	Deviation at the oil seal insertion area	0.2mm	Face deviation from the crankshaft center	0.3mm	Flywheel housing tightening torque	$5 \pm 0.5$ kgf-m		 <p>Assemble the Fly wheel housing</p>
Deviation at the oil seal insertion area	0.2mm									
Face deviation from the crankshaft center	0.3mm									
Flywheel housing tightening torque	$5 \pm 0.5$ kgf-m									
11	Oil Seal Case	<p>Press-fit the seal into the oil seal case (with the press-fitting tool).</p> <p><i>Note :</i></p> <table border="1" data-bbox="392 969 818 1037"> <tr> <td><i>(Apply lube oil to the outside lip of the oil seal before press-fitting.)</i></td> </tr> </table> <p>Install the oil seal case assembly to the flywheel side with its oil escape hole vertical.</p>	<i>(Apply lube oil to the outside lip of the oil seal before press-fitting.)</i>	 	 <p>Assemble the oil seal case</p>					
<i>(Apply lube oil to the outside lip of the oil seal before press-fitting.)</i>										
12	Engine Foot	Install the engine foot.		 <p>Install the engine foot</p>						
13	Reverse the cylinder block	Reverse the cylinder block.								






No.	Item	Procedure	Tool & Caution	Illustration				
14	Tappets and Tappets Case cover	<p>Insert the tappets into the cylinder block hole. (Apply engine oil to the tappets. Move the tappets manually to check that they are inserted smoothly.)</p> <table border="1" data-bbox="376 439 807 535"> <tr> <td>Tappet hole oil clearance</td> <td>0,04–0,082mm</td> </tr> </table> <p>Install the tappet case cover after inserting all tappets.</p> <table border="1" data-bbox="376 629 807 725"> <tr> <td>(Bolt head width 12) Tightening Torque</td> <td>1,2–1,7kgf-m</td> </tr> </table>	Tappet hole oil clearance	0,04–0,082mm	(Bolt head width 12) Tightening Torque	1,2–1,7kgf-m	  	 <p>Tappet</p>
Tappet hole oil clearance	0,04–0,082mm							
(Bolt head width 12) Tightening Torque	1,2–1,7kgf-m							
15	Cylinder Sleeve	<p>Clean the sleeve fitting area of the cylinder block completely. Clean the outside circumference of the cylinder sleeve completely and insert it manually into the cylinder block.</p> <p><i>Note :</i></p> <div data-bbox="376 1048 807 1525" style="border: 1px solid black; padding: 5px;"> <p><i>Before inserting the cylinder sleeve, check the cylinder number and the insertion direction. (Size code is for the cylinder sleeve) (Identical code for the cylinder block and sleeve) (Make a combination of A, B, C and D.) (Direct the code side to the anti-operation side.) (Marked in black paint at the anti-operation side.) Do not place on the cylinder head face after inserting the cylinder sleeve. Be sure to assemble the cylinder sleeve manually. (Do not use a hammer.)</i></p> </div> <p>Measure the protrusion of the cylinder liner.</p> <table border="1" data-bbox="408 1603 767 1664"> <tr> <td>Liner protrusion</td> <td>0,03–0,09mm</td> </tr> </table> <p>Measure the distortion of the cylinder liner.</p> <table border="1" data-bbox="408 1776 767 1836"> <tr> <td>Cylindricity</td> <td>≤0,03mm</td> </tr> </table> <p>(The mark at the cylinder block side is punched on the head joint face of the operation side.)</p>	Liner protrusion	0,03–0,09mm	Cylindricity	≤0,03mm		 <p>Cylinder sleeve</p> <p>Size code is for the cylinder sleeve. Marked in black paint at the anti-operation side.</p> <div data-bbox="1031 1574 1350 1888" style="text-align: center;"> <p>「BM」</p> <p>↑ ↑</p> <p>Piston fitting code</p> <p>↑</p> <p>Cylinder block fitting code</p> </div>
Liner protrusion	0,03–0,09mm							
Cylindricity	≤0,03mm							








No.	Item	Procedure	Tool & Caution	Illustration				
18	Piston and Connecting Rod	<p>Assemble the connecting rod to the piston. The size code, ML or MS, is provided on the piston head. Match up the code with the correctly code of the cylinder sleeve. Distribute the end gaps of the piston rings evenly on the piston. Insert the piston into the cylinder liner, placing the con. rod alignment mark on the operation side. Apply lube oil. Confirm the alignment marks on the connecting rod and cap, and install the cap. Apply lube oil to the thread seat face and tighten the rod bolt to the specified tightening torque. Tighten the bolts by turns evenly 3 times to avoid uneven tightening.</p> <table border="1" data-bbox="395 719 743 819"> <tr> <td>Tightening torque</td> <td><math>23 \pm 0.5</math> kgf-m</td> </tr> </table> <p>Measure the side clearance after tightening the bolts.</p> <table border="1" data-bbox="395 898 788 999"> <tr> <td>Rod large end side clearance</td> <td>0.15 - 0.35mm</td> </tr> </table> <p>Install the cylinder block side cover. (An alignment mark is provided on the rod bolt. This is because a torque wrench cannot be used in restricted engine room spaces.)</p> 	Tightening torque	$23 \pm 0.5$ kgf-m	Rod large end side clearance	0.15 - 0.35mm		 <p>Assemble the piston and con.rod.</p>  <p>alignment mark</p>  <p>Fitting the side cover</p>  <p>Fitting the gear case cover</p>
Tightening torque	$23 \pm 0.5$ kgf-m							
Rod large end side clearance	0.15 - 0.35mm							
19	Gear Case Cover	<p>Install the oil seal to the gear case.</p> <p><i>Note:</i></p> <p><i>Apply lube oil to the exterior and lip of the oil seal before press-fitting it.</i></p> <p>Install the gear case cover.</p> <p><i>Note:</i></p> <p><i>The positioning pin (spring pin) is provided at the joint face of the gear case and cylinder block.</i></p> <p>Measure the face deviation of the front drive installation.</p> <table border="1" data-bbox="373 1872 780 1973"> <tr> <td>Face deviation</td> <td>Less than 0.05mm for crank center</td> </tr> </table>	Face deviation	Less than 0.05mm for crank center		 <p>Fitting the gear case cover</p>		
Face deviation	Less than 0.05mm for crank center							




No.	Item	Procedure	Tool & Caution	Illustration			
20	Bearing Case	Install the sea water pump drive bearing case. Install the V-pulley. Bend the washer after tightening the nut. Install the breather.		 <p data-bbox="1061 638 1348 672">Assemble the bearing case</p>  <p data-bbox="1101 1041 1308 1075">Install the V-pulley</p>			
21	Flywheel	Install the flywheel. (Align the positioning parallel pin holes.) Tighten the bolts to the specified tightening torque. <table border="1" data-bbox="406 1220 758 1332" style="margin-left: 20px;"> <tr> <td style="padding: 5px;">Tightening torque</td> <td style="padding: 5px;"><math>29 \pm 1</math> kgf-m</td> </tr> </table> Measure and check the flywheel face deviation and centering location deviation. <table border="1" data-bbox="406 1433 790 1500" style="margin-left: 20px;"> <tr> <td style="padding: 5px;">Face deviation</td> <td style="padding: 5px;">less than 0.13mm</td> </tr> </table> Follow the instructions below when replacing the top indication plate: 1) Bring the No.1 piston at the flywheel side to the top position. (Check using the dial gauge.) 2) Install aligning the top punched line of the flywheel to the piston top position. 3) The alignment error between the top mark of the indication plate and the top punched line of the flywheel should be within +30 min.	Tightening torque	$29 \pm 1$ kgf-m	Face deviation	less than 0.13mm	 <p data-bbox="1085 1556 1324 1590">Assemble the flywheel</p>  <p data-bbox="1085 2016 1324 2049">Check the No1 cyl. top.</p>
Tightening torque	$29 \pm 1$ kgf-m						
Face deviation	less than 0.13mm						

No.	Item	Procedure	Tool & Caution	Illustration				
22		<p>Install the injection timing adjustment and turning window covers.</p> <p>1) Adjust the injection timing with the governor control lever at its max. position (pump rack's max. scale).</p> <p>2) After adjusting the fuel timing, punch an injection alignment mark aligned with the punched scale on the flange side mounting of the fuel pump.</p> <p>3) Install the turning window cover.</p> <table border="1" data-bbox="395 584 742 645"> <tr> <td>Tightening torque</td> <td><math>5 \pm 0.5</math> kgf-m</td> </tr> </table> <table border="1" data-bbox="395 669 746 730"> <tr> <td>Injection timing</td> <td><math>12 \pm 1^\circ</math></td> </tr> </table>	Tightening torque	$5 \pm 0.5$ kgf-m	Injection timing	$12 \pm 1^\circ$	 14  24	 Indication plate
Tightening torque	$5 \pm 0.5$ kgf-m							
Injection timing	$12 \pm 1^\circ$							
23	Breather	Install the breather.						
24	Cylinder Head	<p>Valve sink: Intake 0.2mm, Exhaust 0.2mm</p> <p>Install the head gasket according to the positioning pin.</p> <p>Lift the cylinder head level and install it according to the positioning pins (spring pins)(4 pcs.).</p> <p>Apply lube oil to the threads and seat of the head bolts and tighten them 3 times to the specified tightening torque in the proper tightening order.</p> <table border="1" data-bbox="395 1406 738 1467"> <tr> <td>Tightening torque</td> <td><math>25 \pm 0.5</math> kgf-m</td> </tr> </table> <p>procedures for the head bolts.) Measure the top clearance.</p> <table border="1" data-bbox="395 1570 790 1630"> <tr> <td>Top clearance</td> <td><math>0.95 \pm 0.09</math> mm</td> </tr> </table> <p>(Head gasket tightening torque and tightening order)</p> <div data-bbox="391 1821 858 1989" style="text-align: center;"> <p>cam shaft side</p>  <p>gear side</p> <p>Fly wheel side</p> <p>pump side</p> </div> <p>Install the fuel return pipe joint.</p>	Tightening torque	$25 \pm 0.5$ kgf-m	Top clearance	$0.95 \pm 0.09$ mm	   22	 Cylinder head   Tightening of the cyl. head
Tightening torque	$25 \pm 0.5$ kgf-m							
Top clearance	$0.95 \pm 0.09$ mm							


No	Item	Procedure	Tool & Caution	Illustration		
25	Fresh water Tank	Install the fresh water tank to the freshwater pump. <table border="1" data-bbox="400 360 746 421"> <tr> <td data-bbox="400 360 539 421">Tightening torque</td> <td data-bbox="539 360 746 421"><math>2.6 \pm 0.2</math> kgf-m</td> </tr> </table> Install the stay of the fresh water tank.	Tightening torque	$2.6 \pm 0.2$ kgf-m		 <p data-bbox="1066 741 1345 768">Install the freshwater tank</p>
Tightening torque	$2.6 \pm 0.2$ kgf-m					
26	Fresh water Pump	Install the fresh water pump assembly to the cylinder block. Install the thermostat to the fresh water pump body. Thermostat valve opening temperature:71°C Full-open lift test temperature:85°C	 	 <p data-bbox="1114 1178 1297 1205">freshwater pump</p>		
27	Starting Motor	Install the starting motor to the flywheel housing. <table border="1" data-bbox="400 1323 746 1424"> <tr> <td data-bbox="400 1323 539 1424">Tightening torque</td> <td data-bbox="539 1323 746 1424"><math>9 \pm 0.5</math> kgf-m</td> </tr> </table>	Tightening torque	$9 \pm 0.5$ kgf-m		 <p data-bbox="1070 1581 1334 1608">Install the starting motor</p>
Tightening torque	$9 \pm 0.5$ kgf-m					
28	Lube Oil Pipe and Lube Oil Filter	Install the lube oil filter mount to the cylinder block.		 <p data-bbox="1038 2029 1374 2056">Install the lube oil filter mount</p>		

No.	Item	Pocedure	Tool & Caution	Illustration
		Install the lube oil piping (Lube oil filter—flywheel housing). Install the lube oil piping (Lube oil filter—cylinder block). Install the filter.		 <p>(Lube oil filter—flywheel housing)</p>  <p>(Lube oil filter—cylinder block)</p>
29	Lube oil Cooler	Install the oil cooler assembly to the oil cooler mount. (Install the elbow of the Lube oil pipe filter and union Lube oil pipe to the filter in advance. )		 <p>(install the oil cooler assembly)</p>
30	Cooling Water Pipe	Install the cooling water piping (sea water pump—Lube oil cooler).		

No.	Item	Procedure	Tool & Caution	Illustration
		Install the cooling water piping (L.O. cooler-Marine gear cooler). Install the cooling water piping (Marine gear cooler-intercooler). Install the cooling water piping (intercooler-fresh water cooler). Install the cooling water piping (lube oil cooler-fresh water cooler).	Do not bend the piping.	
31	Engine Lift Fixture	Install the engine lift fixture..		 <p>Install the engine lift fixture</p>

No.	Item	Procedure	Tool & Caution	Illustration
32	Wire Harness	<p>Install the wire harness (engine side):</p> <p><i>Note:</i></p> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p>1) Beware of the heated area of the exhaust and bend pipes as well as the moving parts when wiring.</p> <p>2) Refer to the electrical wiring diagram and ensure correct terminal connections.</p> </div> <p>Install the remote control cable support mount. (To be installed to the installation seat at the top of the side cover on the operation side of the block.)</p> <p>Install the Marine gear remote control cable mount.</p>	 	 <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p><b>OPTION</b></p>  </div>

No.	Item	Procedure	Tool & Caution	Illustration
-----	------	-----------	----------------	--------------




for 6CX-E TE






No.	dia.	color	Note	No.	dia.	color	Note
①	5	White	Starting motor "s"	⑩	0.85	White,Black	CW meter "U"
②	0.85	Yellow, White	L0 "SW"	⑪	0.85	Yellow, Green	Clutch L0 "SW"
③	0.85	White,Blue	CW temp. "SW"	⑫	0.85	Green	L0 filter "SW"
④	0.85	White,Red	CW level "SW"	⑬	0.85	Yellow, Black	L0 press. meter "U"
⑤	0.85	Blue,Black	generator "L"	⑭	0.85	Green,Black	Boost meter "U"
⑥	5	Red	Starting motor "B"	⑮	0.85	Green,Red	WAIT "SW"
⑦	0.85	Black	⊖	⑯	5	Black	⊖
⑧	0.85	Blue,Red	Tachmeter "P" or "G"	⑰	0.85	Black	⊖
				⑱	5	Red	⊕



33 Direct Coupling of Reduction and Reversing Gear

Install the rubber block flange ring to the flywheel.  
 Install the rubber block flange to the input shaft joint of the reduction reversing gears.  
 Apply silicon oil to the rubber block, lift the reduction reversing gear (assembly) level, and insert it into the ring for direct coupling.





Install the reduction clutch

No.	Item	Procedure	Tool & Caution	Illustration			
34	Fuel Pump	<p>Install the fuel pump mount to the cylinder block.            (Axial deviation TIR within 0.3; deviation angle within 30 degrees)            (TIR:Total Indicator Reading)            Install the fuel injection pump.            Install the lube oil piping            (cylinder block-fuel pump).  <b>CAUTION:</b>  <i>(Do not overtighten the block or it may crack.)</i></p> <table border="1" data-bbox="384 528 815 584"> <tr> <td data-bbox="384 528 528 584">(Do not overtighten the block or it may crack.)</td> </tr> </table> <table border="1" data-bbox="384 607 732 685"> <tr> <td data-bbox="384 607 528 685">Union tightening torque</td> <td data-bbox="528 607 732 685">0.5- 1 kgf-m</td> </tr> </table>  <p>Tool for centering</p>  <p>Measure the center</p>  <p>Timer and Flexible coupling</p>	(Do not overtighten the block or it may crack.)	Union tightening torque	0.5- 1 kgf-m	<p>Wrench 12</p> <p>Wrench 17</p>	 <p>Fuel pump mount</p>  <p>Assemble the flexible coupling</p>  <p>Assemble the Fuel pump</p>  <p>Titrating the Lube oil pipe</p>
(Do not overtighten the block or it may crack.)							
Union tightening torque	0.5- 1 kgf-m						

No.	Item	Procedure	Tool & Caution	Illustration						
35	Fuel Injection Valve and Pipe	<p>Put in the protector and adiabatic material and install the fuel injection valve to the cylinder head.</p> <table border="1" data-bbox="384 412 727 510"> <tr> <td>Fuel valve retainer tightening torque</td> <td><math>3.2 \pm 0.2</math> kgf-m</td> </tr> </table> <p><i>Note</i></p> <table border="1" data-bbox="384 589 826 842"> <tr> <td colspan="2">           1) Provisionally tighten the fuel injection pipe joint until it contacts with the fuel valve seat to a tightening torque of 2.5–3.0kg-m. Then, the fuel injection valve and the fuel injection pipe joint.            2) Apply molybdenum disulfide to both the outside and the inside circumferences of the protector before inserting it.         </td> </tr> </table> <p>Install the fuel injection pipe.</p> <table border="1" data-bbox="384 904 727 965"> <tr> <td>Tightening torque</td> <td>3.5kgf-m</td> </tr> </table> <p>Install the fuel return pipe. Install the rocker arm case.</p>	Fuel valve retainer tightening torque	$3.2 \pm 0.2$ kgf-m	1) Provisionally tighten the fuel injection pipe joint until it contacts with the fuel valve seat to a tightening torque of 2.5–3.0kg-m. Then, the fuel injection valve and the fuel injection pipe joint. 2) Apply molybdenum disulfide to both the outside and the inside circumferences of the protector before inserting it.		Tightening torque	3.5kgf-m	<p>⚠</p> <p>12</p> <p>19</p>	<p>Fuel injection valve</p>   <p>Fuel injection pipe</p>
Fuel valve retainer tightening torque	$3.2 \pm 0.2$ kgf-m									
1) Provisionally tighten the fuel injection pipe joint until it contacts with the fuel valve seat to a tightening torque of 2.5–3.0kg-m. Then, the fuel injection valve and the fuel injection pipe joint. 2) Apply molybdenum disulfide to both the outside and the inside circumferences of the protector before inserting it.										
Tightening torque	3.5kgf-m									
36	Exhaust manifold	Install the exhaust manifold.		 <p>Install the exhaust manifold.</p>						
37	Viscous damper	Install the viscous damper.		 <p>Viscous damper</p>						

No.	Item	Procedure	Tool & Caution	Illustration													
38	Intake/ Exhaust Rocker Arm (Assembly)	<p>Install the valve bridge.</p> <p><i>Note</i></p> <div style="border: 1px solid black; padding: 5px;"> <p>1) The installation range of the rocker arm shaft mount is 180 degrees. If the mount is installed in reverse, the valve head position will be varied. (See fig. at the right.)</p> <p>2) Check the performance of the intake/ exhaust valve.</p> </div> <p>Fit the push rod to the dent in the tappet. Adjust the bridge valve head adjust bolt, and tighten the set nut.</p> <table border="1" data-bbox="376 696 812 891"> <tr> <td>Bridge valve head clearance</td> <td></td> </tr> <tr> <td>Intake</td> <td>0.25mm</td> </tr> <tr> <td>Exhaust</td> <td>0.4mm</td> </tr> <tr> <td>Tightening torque</td> <td>2.0kgf-m</td> </tr> </table> <p>Install the intake/exhaust rocker arm (assembly).</p> <table border="1" data-bbox="376 976 798 1095"> <tr> <td rowspan="2">Valve arm A'ssy Tightening Torque</td> <td>M8 bolt</td> <td><math>2.6 \pm 0.5</math> kgf-m</td> </tr> <tr> <td>M10 bolt</td> <td><math>4 \pm 0.5</math> kgf-m</td> </tr> </table> <p><i>Note</i></p> <div style="border: 1px solid black; padding: 5px;"> <p>When replacing the valve guide, note that the guide is lightly calked to the head. (Assemble the push rod, adjust the intake/ exhaust valve head clearance, and install the rocker arm assembly.)</p> </div>	Bridge valve head clearance		Intake	0.25mm	Exhaust	0.4mm	Tightening torque	2.0kgf-m	Valve arm A'ssy Tightening Torque	M8 bolt	$2.6 \pm 0.5$ kgf-m	M10 bolt	$4 \pm 0.5$ kgf-m	<p>?</p> <p>14</p> <p>17</p> <p>12</p> <p>14</p>	 <p>Adjust the bridge valve head</p>  <p>Assemble the push rod</p>  <p>Assemble the rocker arm a'ssy</p>  <p>Adjust the valve clearance</p>
Bridge valve head clearance																	
Intake	0.25mm																
Exhaust	0.4mm																
Tightening torque	2.0kgf-m																
Valve arm A'ssy Tightening Torque	M8 bolt	$2.6 \pm 0.5$ kgf-m															
	M10 bolt	$4 \pm 0.5$ kgf-m															

No.	Item	Procedure	Tool & Caution	Illustration
39	Cooling Water Pipe (Fresh Water)	Install the piping between the exhaust manifold and the fresh water tank. Install the piping between the head and the fresh water cooler.	 12	
40	Fuel Piping	Install the piping between the feed pump and the filter. Install the piping between the filter and the injection pump. Install the feed pump inlet piping.	 12	