

Contents

Introductory pages

About this manual	0-5
Introduction to the Yamaha FJ600, FZ600, XJ600 and YX600 Radian	0-5
Identification numbers	0-6
Buying parts	0-7
General specifications	0-7
Maintenance techniques, tools and working facilities	0-8
Safety first!	0-14
Motorcycle chemicals and lubricants	0-15
Troubleshooting	0-16

Chapter 1

Tune-up and routine maintenance	1-1	1
---------------------------------	-----	----------

Chapter 2

Engine, clutch and transmission	2-1	2
---------------------------------	-----	----------

Chapter 3

Fuel and exhaust systems	3-1	3
--------------------------	-----	----------

Chapter 4

Ignition system	4-1	4
-----------------	-----	----------

Chapter 5

Frame, suspension and final drive	5-1	5
-----------------------------------	-----	----------

Chapter 6

Brakes, wheels and tires	6-1	6
--------------------------	-----	----------

Chapter 7

Fairing and bodywork	7-1	7
----------------------	-----	----------

Chapter 8

Electrical system	8-1	8
-------------------	-----	----------

Wiring diagrams

8-23

Conversion factors

Product: 1984-1992 Yamaha FJ600/FZ600/XJ600/YX600 Motorcycle Service Repair Workshop Manual
Full Download: <https://www.aresairmanual.com/downloads/1984-1992-yamaha-fj600fz600xj600yx600-motorcycle-service-repair-workshop-manual/>



Right side view of the Yamaha FZ600



Right side view of the Yamaha YX600 Radian

Sample of manual. Download All 249 pages at: <https://www.aresairmanual.com/downloads/1984-1992-yamaha-fj600fz600xj600yx600-motorcycle-service-repair-workshop-manual/>

About this manual

Its purpose

The purpose of this manual is to help you get the best value from your motorcycle. It can do so in several ways. It can help you decide what work must be done, even if you choose to have it done by a dealer service department or a repair shop; it provides information and procedures for routine maintenance and servicing; and it offers diagnostic and repair procedures to follow when trouble occurs.

We hope you use the manual to tackle the work yourself. For many simpler jobs, doing it yourself may be quicker than arranging an appointment to get the vehicle into a shop and making the trips to leave it and pick it up. More importantly, a lot of money can be saved by avoiding the expense the shop must pass on to you to cover its labor and overhead costs. An added benefit is the sense of satisfaction and accomplishment that you feel after doing the job yourself.

Using the manual

The manual is divided into Chapters. Each Chapter is divided into numbered Sections, which are headed in bold type between horizontal lines. Each Section consists of consecutively numbered paragraphs.

At the beginning of each numbered Section you will be referred to any illustrations which apply to the procedures in that Section. The reference numbers used in illustration captions pinpoint the pertinent Section and the Step within that Section. That is, illustration 3.2 means the illustration refers to Section 3 and Step (or paragraph) 2 within that Section.

Procedures, once described in the text, are not normally repeated. When it is necessary to refer to another Chapter, the reference will be given as Chapter and Section number. Cross references given without use of the word "Chapter" apply to Sections and/or paragraphs in the same Chapter. For example, "see Section 80" means in the same Chapter.

References to the left or right side of the vehicle assume you are sitting on the seat, facing forward.

Motorcycle manufacturers continually make changes to specifications and recommendations, and these, when notified, are incorporated into our manuals at the earliest opportunity.

Even though we have prepared this manual with extreme care, neither the publisher nor the author can accept responsibility for any errors in, or omissions from, the information given.

NOTE

A **Note** provides information necessary to properly complete a procedure or information which will make the procedure easier to understand.

CAUTION

A **Caution** provides a special procedure or special steps which must be taken while completing the procedure where the Caution is found. Not heeding a Caution can result in damage to the assembly being worked on.

WARNING

A **Warning** provides a special procedure or special steps which must be taken while completing the procedure where the Warning is found. Not heeding a Warning can result in personal injury.

Introduction to the Yamaha FJ600, FZ600, XJ600 and YX600 Radian

The Yamaha FJ/XJ600, FZ600 and YX600 Radian are three different types of motorcycles developed around the same engine and transmission. The FJ600 and XJ600 are sport-touring bikes, the FZ600 is a sport bike and the YX600 Radian is a standard motorcycle.

The engine is an air-cooled, inline four with double overhead camshafts and two valves per cylinder. The design has remained essentially the same since its introduction in 1984.

absorber/spring units mounted from the frame to the swingarm. The rear suspension on the FJ600, FZ600 and XJ600 models uses the Yamaha Monocross design, which employs a shock absorber/spring unit mounted ahead of the swingarm. The suspension provides a progressive damping effect. Spring preload and shock absorber damping are adjustable.

The front brakes use dual discs and the rear brake uses a drum.

Identification numbers

The frame serial number is stamped into the right side of the frame and printed on a label affixed to the frame center brace. The engine number is stamped into the right upper side of the crankcase. Both of these numbers should be recorded and kept in a safe place so they can be furnished to law enforcement officials in the event of a theft.

The frame serial number, engine serial number and carburetor identification number should also be kept in a handy place (such as with your driver's license) so they are always available when purchasing or ordering parts for your machine.

The models covered by this manual are as follows:

FJ600, FZ600, XJ600 and YX600 Radian - 1984 through 1992

Identifying model years

The procedures in this manual identify the bikes by model year. To determine which model year a given machine is, look for the following identification codes in the engine and frame numbers. **Note:** UK models can be further identified by their initial engine/frame no. given in parentheses after the identification code in the table.

Model and Year	Code
FJ600	
1984 and 1985	49A (49 states), 51K (California)
FZ600	
1986 and 1987 US	2AX (49 states), 2AY (California)
1988 US	2XL (49 states), 3BW1 (California)
1987 UK	2HW (2HW-000101)
1988 UK	3BX (2HW-002101)
XJ600	
1984 through 1987	51J (51J-000101)
1989	3KM1 (51J-051101)
1990	3KM3 (51J-070101)
1991 and 1992	3KM5 (3KM-000101)
YX600 Radian	
1986 and 1987	1UJ (49 states), 1UL (California)
1988	2WY (49 states), 2XA (California)
1989	3LT1 (49 states), 3LT2 (California)
1990	3LT3 (49 states), 3LT4 (California)



The frame number is stamped in the right side of the steering head



The engine number is stamped into the right side of

Buying parts

Once you have found all the identification numbers, record them for reference when buying parts. Since the manufacturers change specifications, parts and vendors (companies that manufacture various components on the machine), providing the ID numbers is the only way to be reasonably sure that you are buying the correct parts.

Whenever possible, take the worn part to the dealer so direct comparison with the new component can be made. Along the trail from the manufacturer to the parts shelf, there are numerous places that the part can end up with the wrong number or be listed incorrectly.

The two places to purchase new parts for your motorcycle - the accessory store and the franchised dealer - differ in the type of parts

they carry. While dealers can obtain virtually every part for your motorcycle, the accessory dealer is usually limited to normal high wear items such as shock absorbers, tune-up parts, various engine gaskets, cables, chains, brake parts, etc. Rarely will an accessory outlet have major suspension components, cylinders, transmission gears, or cases.

Used parts can be obtained for roughly half the price of new ones, but you can't always be sure of what you're getting. Once again, take your worn part to the wrecking yard (breaker) for direct comparison.

Whether buying new, used or rebuilt parts, the best course is to deal directly with someone who specializes in parts for your particular make.

General specifications

Wheelbase	
FJ600	1425 mm (56.1 inches)
FZ600	1385 mm (54.5 inches)
XJ600	1430 mm (56.3 inches)
YX600 Radian	1385 mm (54 inches)
Overall length	
FJ600	2115 mm (83.3 inches)
FZ600 (US)	2040 mm (80.3 inches)
FZ600 (UK)	2025 mm (79.7 inches)
XJ600	2145 mm (84.4 inches)
YX600 Radian	2075 mm (81.7 inches)
Overall width	
FJ600	735 mm (28.9 inches)
FZ600	690 mm (27.2 inches)
XJ600	
1984 and 1985	735 mm (28.9 inches)
1989-on	745 mm (29.3 inches)
YX600 Radian	770 mm (30.3 inches)
Overall height	
FJ600	1225 mm (48.2 inches)
FZ600	1145 mm (45.1 inches)
XJ600	1225 mm (48.2 inches)
YX600 Radian	1095 mm (43.1 inches)
Seat height	
FJ600	790 mm (31.1 inches)
FZ600	785 mm (30.9 inches)
XJ600	790 mm (31.1 inches)
YX600 Radian	765 mm (30.1 inches)
Ground clearance (minimum)	
FJ600	140 mm (5.5 inches)
FZ600	135 mm (5.31 inches)
XJ600	140 mm (5.51 inches)
YX600 Radian	145 mm (5.7 inches)
Weight (with oil and full fuel tank)	
FJ600	213 kg (470 lbs)
FZ600	202 kg (409 lbs)
XJ600	208 kg (459 lbs)
YX600 Radian	197 kg (434 lbs)

Maintenance techniques, tools and working facilities

Basic maintenance techniques

There are a number of techniques involved in maintenance and repair that will be referred to throughout this manual. Application of these techniques will enable the amateur mechanic to be more efficient, better organized and capable of performing the various tasks properly, which will ensure that the repair job is thorough and complete.

Fastening systems

Fasteners, basically, are nuts, bolts and screws used to hold two or more parts together. There are a few things to keep in mind when working with fasteners. Almost all of them use a locking device of some type (either a lock washer, locknut, locking tab or thread adhesive). All threaded fasteners should be clean, straight, have undamaged threads and undamaged corners on the hex head where the wrench fits. Develop the habit of replacing all damaged nuts and bolts with new ones.

Rusted nuts and bolts should be treated with a penetrating oil to ease removal and prevent breakage. Some mechanics use turpentine in a spout type oil can, which works quite well. After applying the rust penetrant, let it work for a few minutes before trying to loosen the nut or bolt. Badly rusted fasteners may have to be chiseled off or removed with a special nut breaker, available at tool stores.

If a bolt or stud breaks off in an assembly, it can be drilled out and removed with a special tool called an E-Z out (or screw extractor). Most dealer service departments and motorcycle repair shops can perform this task, as well as others (such as the repair of threaded holes that have been stripped out).

Flat washers and lock washers, when removed from an assembly, should always be replaced exactly as removed. Replace any damaged washers with new ones. Always use a flat washer between a lock washer and any soft metal surface (such as aluminum), thin sheet metal or plastic. Special locknuts can only be used once or twice before they lose their locking ability and must be replaced.

Tightening sequences and procedures

When threaded fasteners are tightened, they are often tightened to a specific torque value (torque is basically a twisting force). Over-tightening the fastener can weaken it and cause it to break, while under-tightening can cause it to eventually come loose. Each bolt, depending on the material it's made of, the diameter of its shank and the material it is threaded into, has a specific torque value, which is noted in the Specifications. Be sure to follow the torque recommendations closely.

Fasteners laid out in a pattern (i.e. cylinder head bolts, engine case bolts, etc.) must be loosened or tightened in a sequence to avoid warping the component. Initially, the bolts/nuts should go on finger tight only. Next, they should be tightened one full turn each, in a criss-cross or diagonal pattern. After each one has been tightened one full turn, return to the first one tightened and tighten them all one half turn, following the same pattern. Finally, tighten each of them one quarter turn at a time until each fastener has been tightened to the proper torque. To loosen and remove the fasteners the procedure would be reversed.

Disassembly sequence

Component disassembly should be done with care and purpose to help ensure that the parts go back together properly during reassembly. Always keep track of the sequence in which parts are removed. Take note of special characteristics of parts that can be installed more than one way.

clean surface in the order that they were removed. It may also be helpful to make sketches or take instant photos of components before removal.

When removing fasteners from a component, keep track of the locations. Sometimes threading a bolt back in a part, or putting washers and nut back on a stud, can prevent mixups later. If nuts and bolts can't be returned to their original locations, they should be kept in a compartmented box or a series of small boxes. A cupcake or muffin tin is ideal for this purpose, since each cavity can hold the bolts and nuts from a particular area (i.e. engine case bolts, valve cover bolts, engine mount bolts, etc.). A pan of this type is especially helpful when working on assemblies with very small parts (such as the carburetors and the valve train). The cavities can be marked with paint or tape to identify the contents.

Whenever wiring looms, harnesses or connectors are separated, it's a good idea to identify the two halves with numbered pieces of masking tape so they can be easily reconnected.

Gasket sealing surfaces

Throughout any motorcycle, gaskets are used to seal the mating surfaces between components and keep lubricants, fluids, vacuum or pressure contained in an assembly.


Many times these gaskets are coated with a liquid or paste type gasket sealing compound before assembly. Age, heat and pressure can sometimes cause the two parts to stick together so tightly that they are very difficult to separate. In most cases, the part can be loosened by striking it with a soft-faced hammer near the mating surfaces. A regular hammer can be used if a block of wood is placed between the hammer and the part. Do not hammer on cast parts or parts that could be easily damaged. With any particularly stubborn part, always recheck to make sure that every fastener has been removed.

Avoid using a screwdriver or bar to pry apart components, as they can easily mar the gasket sealing surfaces of the parts (which must remain smooth). If prying is absolutely necessary, use a piece of wood, but keep in mind that extra clean-up will be necessary if the wood splinters.

After the parts are separated, the old gasket must be carefully scraped off and the gasket surfaces cleaned. Stubborn gasket material can be soaked with a gasket remover (available in aerosol cans) to soften it so it can be easily scraped off. A scraper can be fashioned from a piece of copper tubing by flattening and sharpening one end. Copper is recommended because it is usually softer than the surfaces to be scraped, which reduces the chance of gouging the part. Some gaskets can be removed with a wire brush, but regardless of the method used, the mating surfaces must be left clean and smooth. If for some reason the gasket surface is gouged, then a gasket sealer thick enough to fill scratches will have to be used during reassembly of the components. For most applications, a non-drying (or semi-drying) gasket sealer is best.

Hose removal tips

Hose removal precautions closely parallel gasket removal precautions. Avoid scratching or gouging the surface that the hose mates against or the connection may leak. Because of various chemical reactions, the rubber in hoses can bond itself to the metal spigot that the hose fits over. To remove a hose, first loosen the hose clamps that secure it to the spigot. Then, with slip joint pliers, grab the hose at the clamp and pull it away from the spigot.



Spark plug gap adjusting tool



Feeler gauge set



Control cable pressure luber



Hand impact screwdriver and bits

If a hose clamp is broken or damaged, do not reuse it. Also, do not reuse hoses that are cracked, split or torn.


Tools

A selection of good tools is a basic requirement for anyone who plans to maintain and repair a motorcycle. For the owner who has few tools, if any, the initial investment might seem high, but when compared to the spiraling costs of routine maintenance and repair, it is a wise one.

To help the owner decide which tools are needed to perform the tasks detailed in this manual, the following tool lists are offered: Maintenance and minor repair, Repair and overhaul and Special. The newcomer to practical mechanics should start off with the Maintenance and minor repair tool kit, which is adequate for the simpler jobs. Then, as confidence and experience grow, the owner can tackle more difficult tasks, buying additional tools as they are needed. Eventually the basic kit will be built into the Repair and overhaul tool set. Over a period of time, the experienced do-it-yourselfer will assemble a tool set complete enough for most repair and overhaul procedures and will add tools from the Special category when it is felt that the expense is justified by the frequency of use.



Torque wrenches (left - click type; right - beam type)



Snap-ring pliers (top - external; bottom - internal)



Allen wrenches (left) and Allen head sockets (right)




Valve spring compressor



Piston ring removal/installation tool



Piston pin puller





0-to-1-inch micrometer



Cylinder surfacing hone




Cylinder compression gauge



Dial indicator set



Multimeter (volt/ohm/ammeter)



Adjustable spanner

Maintenance and minor repair tool kit

The tools in this list should be considered the minimum required for performance of routine maintenance, servicing and minor repair work. We recommend the purchase of combination wrenches (box end and open end combined in one wrench); while more expensive than open-ended ones, they offer the advantages of both types of wrench.

- Combination wrench set (6 mm to 22 mm)
- Adjustable wrench - 8 in
- Spark plug socket (with rubber insert)
- Spark plug gap adjusting tool
- Feeler gauge set
- Standard screwdriver (5/16 in x 6 in)
- Phillips screwdriver (No. 2 x 6 in)
- Allen (hex) wrench set (4 mm to 12 mm)
- Combination (slip-joint) pliers - 6 in
- Hacksaw and assortment of blades
- Tire pressure gauge
- Control cable pressure luber
- Grease gun
- Oil can
- Fine emery cloth
- Wire brush
- Hand impact screwdriver and bits
- Funnel (medium size)
- Safety goggles
- Drain pan
- Work light with extension cord

Repair and overhaul tool set

These tools are essential for anyone who plans to perform major repairs and are intended to supplement those in the Maintenance and minor repair tool kit. Included is a comprehensive set of sockets which, though expensive, are invaluable because of their versatility (especially when various extensions and drives are available). We recommend the 3/8 inch drive over the 1/2 inch drive for general motorcycle maintenance and repair (ideally, the mechanic would have a 3/8 inch drive set and a 1/2 inch drive set).

- Socket set(s)
 - Reversible ratchet
 - Extension - 6 in
 - Universal joint
 - Torque wrench (same size drive as sockets)
 - Ball peen hammer - 8 oz
 - Soft-faced hammer (plastic/rubber)
 - Standard screwdriver (1/4 in x 6 in)
 - Standard screwdriver (stubby - 5/16 in)
 - Phillips screwdriver (No. 3 x 6 in)
 - Phillips screwdriver (stubby - No. 2)
 - Pliers - locking
 - Pliers - lineman's
 - Pliers - needle nose
 - Pliers - snap-ring (internal and external)
 - Cold chisel - 1/2 in
 - Scriber
 - Scraper (made from flattened copper tubing)
 - Center punch
 - Pin punches (1/16, 1/8, 3/16 in)
 - Steel rule/straightedge - 12 in
 - Pin-type spanner wrench
 - A selection of files
 - Wire brush (large)
- Note:** Another tool which is often useful is an electric drill with a chuck capacity of 3/8 inch (and a set of good quality drill bits).

Special tools

The tools in this list include those which are not used regularly, are expensive to buy, or which need to be used in accordance with their manufacturer's instructions. Unless used frequently, it is not

consideration would be to split the cost and use between yourself and a friend or friends (i.e. members of a motorcycle club).

This list primarily contains tools and instruments widely available to the public, as well as some special tools produced by the vehicle manufacturer for distribution to dealer service departments. As a result, references to the manufacturer's special tools are occasionally included in the text of this manual. Generally, an alternative method of doing the job without the special tool is offered. However, sometimes there is no alternative to their use. Where this is the case, and the tool can't be purchased or borrowed, the work should be turned over to the dealer service department or a motorcycle repair shop.

- Valve spring compressor
- Piston ring removal and installation tool
- Piston pin puller
- Telescoping gauges
- Split-ball gauges
- Micrometer(s) and/or dial/Vernier calipers
- Cylinder deglazing hone
- Cylinder compression gauge
- Dial indicator set with clamp and/or magnetic base
- Multimeter
- Adjustable spanner
- Manometer or vacuum gauge set
- Small air compressor with blow gun and tire chuck

Buying tools

For the do-it-yourselfer who is just starting to get involved in motorcycle maintenance and repair, there are a number of options available when purchasing tools. If maintenance and minor repair is the extent of the work to be done, the purchase of individual tools is satisfactory. If, on the other hand, extensive work is planned, it would be a good idea to purchase a modest tool set from one of the large retail chain stores. A set can usually be bought at a substantial saving over the individual tool prices (and they often come with a tool box). As additional tools are needed, add-on sets, individual tools and a large tool box can be purchased to expand the tool selection. Building a tool set gradually allows the cost of the tools to be spread over a longer period of time and gives the mechanic the freedom to choose only those tools that will actually be used.

Tool stores and motorcycle dealers will often be the only source of some of the special tools that are needed, but regardless of where tools are bought, try to avoid cheap ones (especially when buying screwdrivers and sockets) because they won't last very long. There are plenty of tools around at reasonable prices, but always aim to purchase items which meet the relevant national safety standards. The expense involved in replacing cheap tools will eventually be greater than the initial cost of quality tools.

It is obviously not possible to cover the subject of tools fully here. For those who wish to learn more about tools and their use, there is a book entitled *Motorcycle Workshop Practice Manual* (Book no. 166) available from the publishers of this manual. It also provides an introduction to basic workshop practice which will be of interest to the home mechanic working on any type of motorcycle.

Care and maintenance of tools

Good tools are expensive, so it makes sense to treat them with respect. Keep them clean and in usable condition and store them properly when not in use. Always wipe off any dirt, grease or metal chips before putting them away. Never leave tools lying around in the work area.

Some tools, such as screwdrivers, pliers, wrenches and sockets can be hung on a panel mounted on the garage or workshop wall, while others should be kept in a tool box or tray. Measuring instruments, gauges, meters, etc. must be carefully stored where they can't be damaged by weather or impact from other tools.

Working facilities

Not to be overlooked when discussing tools is the workshop. If anything more than routine maintenance is to be carried out, some sort of suitable work area is essential.

It is understood, and appreciated, that many home mechanics do not have a good workshop or garage available and end up removing an engine or doing major repairs outside (it is recommended, however, that the overhaul or repair be completed under the cover of a roof).

A clean, flat workbench or table of comfortable working height is an absolute necessity. The workbench should be equipped with a vise that has a jaw opening of at least four inches.

As mentioned previously, some clean, dry storage space is also required for tools, as well as the lubricants, fluids, cleaning solvents, etc. which soon become necessary.

Sometimes waste oil and fluids, drained from the engine or cooling system during normal maintenance or repairs, present a disposal problem. To avoid pouring them on the ground or into a sewage system, simply pour the used fluids into large containers, seal them with caps and take them to an authorized disposal site or service station. Plastic jugs (such as old antifreeze containers) are ideal for this purpose.

Always keep a supply of old newspapers and clean rags available. Old towels are excellent for mopping up spills. Many mechanics use rolls of paper towels for most work because they are readily available and disposable. To help keep the area under the motorcycle clean, a large cardboard box can be cut open and flattened to protect the garage or shop floor.

Whenever working over a painted surface (such as the fuel tank) cover it with an old blanket or bedspread to protect the finish.

Professional mechanics are trained in safe working procedures. However enthusiastic you may be about getting on with the job at hand, take the time to ensure that your safety is not put at risk. A moment's lack of attention can result in an accident, as can failure to observe simple precautions.

There will always be new ways of having accidents, and the following is not a comprehensive list of all dangers; it is intended rather to make you aware of the risks and to encourage a safe approach to all work you carry out on your bike.

Essential DOs and DON'Ts

- DON'T** start the engine without first ascertaining that the transmission is in neutral.
- DON'T** suddenly remove the filler cap from a hot cooling system - cover it with a cloth and release the pressure gradually first, or you may get scalded by escaping coolant.
- DON'T** attempt to drain oil until you are sure it has cooled sufficiently to avoid scalding you.
- DON'T** grasp any part of the engine or exhaust system without first ascertaining that it is cool enough not to burn you.
- DON'T** allow brake fluid or antifreeze to contact the machine's paint work or plastic components.
- DON'T** siphon toxic liquids such as fuel, hydraulic fluid or antifreeze by mouth, or allow them to remain on your skin.
- DON'T** inhale dust - it may be injurious to health (see Asbestos heading).
- DON'T** allow any spilled oil or grease to remain on the floor - wipe it up right away, before someone slips on it.
- DON'T** use ill fitting wrenches or other tools which may slip and cause injury.
- DON'T** attempt to lift a heavy component which may be beyond your capability - get assistance.
- DON'T** rush to finish a job or take unverified short cuts.
- DON'T** allow children or animals in or around an unattended vehicle.
- DON'T** inflate a tire to a pressure above the recommended maximum. Apart from over-stressing the carcass and wheel rim, in extreme cases the tire may blow off forcibly.
- DO** ensure that the machine is supported securely at all times. This is especially important when the machine is blocked up to aid wheel or fork removal.
- DO** take care when attempting to loosen a stubborn nut or bolt. It is generally better to pull on a wrench, rather than push, so that if you slip, you fall away from the machine rather than onto it.
- DO** wear eye protection when using power tools such as drill, sander, bench grinder etc.
- DO** use a barrier cream on your hands prior to undertaking dirty jobs - it will protect your skin from infection as well as making the dirt easier to remove afterwards; but make sure your hands aren't left slippery. Note that long-term contact with used engine oil can be a health hazard.
- DO** keep loose clothing (cuffs, ties etc. and long hair) well out of the way of moving mechanical parts.
- DO** remove rings, wristwatch etc., before working on the vehicle - especially the electrical system.
- DO** keep your work area tidy - it is only too easy to fall over articles left lying around.
- DO** exercise caution when compressing springs for removal or installation. Ensure that the tension is applied and released in a controlled manner, using suitable tools which preclude the possibility of the spring escaping violently.
- DO** ensure that any lifting tackle used has a safe working load rating adequate for the job.
- DO** get someone to check periodically that all is well, when working alone on the vehicle.
- DO** carry out work in a logical sequence and check that everything is correctly assembled and tightened afterwards.
- DO** remember that your vehicle's safety affects that of yourself and others. If in doubt on any point, get professional advice.

IF, in spite of following these precautions, you are unfortunate enough to injure yourself, seek medical attention as soon as possible.

Asbestos

Certain friction, insulating, sealing and other products - such as brake pads, clutch linings, gaskets, etc. - contain asbestos. Extreme care must be taken to avoid inhalation of dust from such products since it is hazardous to health. If in doubt, assume that they do contain asbestos.

Fire

Remember at all times that gasoline (petrol) is highly flammable. Never smoke or have any kind of naked flame around, when working on the vehicle. But the risk does not end there - a spark caused by an electrical short-circuit, by two metal surfaces contacting each other, by careless use of tools, or even by static electricity built up in your body under certain conditions, can ignite gasoline (petrol) vapor, which in a confined space is highly explosive. Never use gasoline (petrol) as a cleaning solvent. Use an approved safety solvent.

Always disconnect the battery ground (earth) terminal before working on any part of the fuel or electrical system, and never spill fuel on to a hot engine or exhaust.

It is recommended that a fire extinguisher of a type suitable for fuel and electrical fires is kept handy in the garage or workplace at all times. Never try to extinguish a fuel or electrical fire with water.

Fumes

Certain fumes are highly toxic and can quickly cause unconsciousness and even death if inhaled to any extent. Gasoline (petrol) vapor comes into this category, as do the vapors from certain solvents such as trichloroethylene. Any draining or pouring of such volatile fluids should be done in a well ventilated area.

When using cleaning fluids and solvents, read the instructions carefully. Never use materials from unmarked containers - they may give off poisonous vapors.

Never run the engine of a motor vehicle in an enclosed space such as a garage. Exhaust fumes contain carbon monoxide which is extremely poisonous; if you need to run the engine, always do so in the open air or at least have the rear of the vehicle outside the workplace.

The battery

Never cause a spark, or allow a naked light near the vehicle's battery. It will normally be giving off a certain amount of hydrogen gas which is highly explosive.

Always disconnect the battery ground (earth) terminal before working on the fuel or electrical systems (except where noted).

If possible, loosen the filler plugs or cover when charging the battery from an external source. Do not charge at an excessive rate or the battery may burst.

Take care when topping up, cleaning or carrying the battery. The acid electrolyte, even when diluted, is very corrosive and should not be allowed to contact the eyes or skin. Always wear rubber gloves and goggles or a face shield. If you ever need to prepare electrolyte yourself, always add the acid slowly to the water; never add the water to the acid.

Electricity

When using an electric power tool, inspection light etc., always ensure that the appliance is correctly connected to its plug and that, where necessary, it is properly grounded (earthed). Do not use such appliances in damp conditions and, again, beware of creating a spark or applying excessive heat in the vicinity of fuel or fuel vapor. Also ensure that the appliances meet national safety standards.

A severe electric shock can result from touching certain parts of the electrical system, such as the spark plug wires (HT leads), when the engine is running or being cranked, particularly if components are damp or the insulation is defective. Where an electronic ignition system is used, the secondary (HT) voltage is much higher and could prove fatal.

Motorcycle chemicals and lubricants

A number of chemicals and lubricants are available for use in motorcycle maintenance and repair. They include a wide variety of products ranging from cleaning solvents and degreasers to lubricants and protective sprays for rubber, plastic and vinyl.

Contact point/spark plug cleaner is a solvent used to clean oily film and dirt from points, grime from electrical connectors and oil deposits from spark plugs. It is oil free and leaves no residue. It can also be used to remove gum and varnish from carburetor jets and other orifices.

Carburetor cleaner is similar to contact point/spark plug cleaner but it usually has a stronger solvent and may leave a slight oily residue. It is not recommended for cleaning electrical components or connections.

Brake system cleaner is used to remove grease or brake fluid from brake system components (where clean surfaces are absolutely necessary and petroleum-based solvents cannot be used); it also leaves no residue.

Silicone-based lubricants are used to protect rubber parts such as hoses and grommets, and are used as lubricants for hinges and locks.

Multi-purpose grease is an all purpose lubricant used wherever grease is more practical than a liquid lubricant such as oil. Some multi-purpose grease is colored white and specially formulated to be more resistant to water than ordinary grease.

Gear oil (sometimes called gear lube) is a specially designed oil used in transmissions and final drive units, as well as other areas where high friction, high temperature lubrication is required. It is available in a number of viscosities (weights) for various applications.

Motor oil, of course, is the lubricant specially formulated for use in the engine. It normally contains a wide variety of additives to prevent corrosion and reduce foaming and wear. Motor oil comes in various weights (viscosity ratings) of from 5 to 80. The recommended weight of the oil depends on the seasonal temperature and the demands on the engine. Light oil is used in cold climates and under light load conditions, heavy oil is used in hot climates and where high loads are encountered. Multi-viscosity oils are designed to have characteristics of both light and heavy oils and are available in a number of weights from 5W-20 to 20W-50.

Gas (petrol) additives perform several functions, depending on their chemical makeup. They usually contain solvents that help dissolve gum and varnish that build up on carburetor and intake parts. They also serve to break down carbon deposits that form on the inside surfaces of the combustion chambers. Some additives contain upper

cylinder lubricants for valves and piston rings.

Brake fluid is a specially formulated hydraulic fluid that can withstand the heat and pressure encountered in brake systems. Care must be taken that this fluid does not come in contact with painted surfaces or plastics. An opened container should always be resealed to prevent contamination by water or dirt.

Chain lubricants are formulated especially for use on motorcycle final drive chains. A good chain lube should adhere well and have good penetrating qualities to be effective as a lubricant inside the chain and on the side plates, pins and rollers. Most chain lubes are either the foaming type or quick drying type and are usually marketed as sprays.

Degreasers are heavy duty solvents used to remove grease and grime that may accumulate on engine and frame components. They can be sprayed or brushed on and, depending on the type, are mixed with either water or solvent.

Solvents are used alone or in combination with degreasers to clean parts and assemblies during repair and overhaul. The home mechanic should use only solvents that are non-flammable and that do not produce irritating fumes.

Gasket sealing compounds may be used in conjunction with gaskets, to improve their sealing capabilities, or alone, to seal metal-to-metal joints. Many gasket sealers can withstand extreme heat, some are impervious to gasoline and lubricants, while others are capable of filling and sealing large cavities. Depending on the intended use, gasket sealers either dry hard or stay relatively soft and pliable. They are usually applied by hand, with a brush, or are sprayed on the gasket sealing surfaces.

Thread cement is an adhesive locking compound that prevents threaded fasteners from loosening because of vibration. It is available in a variety of types for different applications.

Moisture dispersants are usually sprays that can be used to dry out electrical components such as the fuse block and wiring connectors. Some types can also be used as treatment for rubber and as a lubricant for hinges, cables and locks.

Waxes and polishes are used to help protect painted and plated surfaces from the weather. Different types of paint may require the use of different types of wax polish. Some polishes utilize a chemical or abrasive cleaner to help remove the top layer of oxidized (stull) paint on older vehicles. In recent years, many non-wax polishes (that contain a wide variety of chemicals such as polymers and silicones) have been introduced. These non-wax polishes are usually easier to apply and last longer than conventional waxes and polishes.

Troubleshooting

Contents

Symptom	Section	Symptom	Section
Engine doesn't start or is difficult to start		Abnormal engine noise	
Starter motor doesn't rotate.....	1	Knocking or pinging.....	
Starter motor rotates but engine does not turn over.....	2	Piston slap or rattling.....	
Starter works but engine won't turn over (seized).....	3	Valve noise.....	
No fuel flow.....	4	Other noise.....	
Engine flooded.....	5	Abnormal driveline noise	
No spark or weak spark.....	6	Clutch noise.....	
Compression low.....	7	Transmission noise.....	
Stalls after starting.....	8	Final drive noise.....	
Rough idle.....	9	Abnormal frame and suspension noise	
Poor running at low speed		Front end noise.....	
Spark weak.....	10	Shock absorber noise.....	
Fuel/air mixture incorrect.....	11	Brake noise.....	
Compression low.....	12	Oil level indicator light comes on	
Poor acceleration.....	13	Engine lubrication system.....	
Poor running or no power at high speed		Electrical system.....	
Firing incorrect.....	14	Excessive exhaust smoke	
Fuel/air mixture incorrect.....	15	White smoke.....	
Compression low.....	16	Black smoke.....	
Knocking or pinging.....	17	Brown smoke.....	
Miscellaneous causes.....	18	Poor handling or stability	
Overheating		Handlebar hard to turn.....	
Engine overheats.....	19	Handlebar shakes or vibrates excessively.....	
Firing incorrect.....	20	Handlebar pulls to one side.....	
Fuel/air mixture incorrect.....	21	Poor shock absorbing qualities.....	
Compression too high.....	22	Braking problems	
Engine load excessive.....	23	Brakes are spongy, don't hold.....	
Lubrication inadequate.....	24	Brake lever or pedal pulsates.....	
Miscellaneous causes.....	25	Brakes drag.....	
Clutch problems		Electrical problems	
Clutch slipping.....	26	Battery dead or weak.....	
Clutch not disengaging completely.....	27	Battery overcharged.....	
Gear shifting problems			
Doesn't go into gear, or lever doesn't return.....	28		
Jumps out of gear.....	29		
Overshifts.....	30		

Engine doesn't start or is difficult to start

1 Starter motor does not rotate

- 1 Engine kill switch Off.
- 2 Fuse blown. Check fuse block (Chapter 8).
- 3 Battery voltage low. Check and recharge battery (Chapter 8).
- 4 Starter motor defective. Make sure the wiring to the starter is secure. Make sure the starter relay clicks when the start button is pushed. If the relay clicks, then the fault is in the wiring or motor.
- 5 Starter relay faulty. Check it according to the procedure in Chapter 8.
- 6 Starter button not contacting. The contacts could be wet, corroded or dirty. Disassemble and clean the switch (Chapter 8).
- 7 Wiring open or shorted. Check all wiring connections and harnesses to make sure that they are dry, tight and not corroded. Also check for broken or frayed wires that can cause a short to ground (see wiring diagrams, Chapter 8).
- 8 Ignition switch defective. Check the switch according to the procedure in Chapter 8. Replace the switch with a new one if it is defective.
- 9 Engine kill switch defective. Check for wet, dirty or corroded contacts. Clean or replace the switch as necessary (Chapter 8).
- 10 Faulty starter lockout switch (if equipped). Check the wiring to the switch and the switch itself according to the procedures in Chapter 8.

2 Starter motor rotates but engine does not turn over

- 1 Starter motor clutch defective. Inspect and repair or replace (Chapter 2).
- 2 Damaged idler or starter gears. Inspect and replace the damaged parts (Chapter 2).

3 Starter works but engine won't turn over (seized)

Seized engine caused by one or more internally damaged components. Failure due to wear, abuse or lack of lubrication. Damage can include seized valves, valve lifters, camshaft, pistons, crankshaft, connecting rod bearings, or transmission gears or bearings. Refer to Chapter 2 for engine disassembly.

4 No fuel flow

- 1 No fuel in tank.
- 2 Fuel tap vacuum hose broken or disconnected.
- 3 Tank cap air vent obstructed. Usually caused by dirt or water. Remove it and clean the cap vent hole.
- 4 Fuel tap clogged. Remove the tap and clean it and the filter (Chapter 1).
- 5 Fuel line clogged. Pull the fuel line loose and carefully blow through it.
- 6 Inlet needle valve clogged. For all of the valves to be clogged, either a very bad batch of fuel with an unusual additive has been used, or some other foreign material has entered the tank. Many times after a machine has been stored for many months without running, the fuel turns to a varnish-like liquid and forms deposits on the inlet needle valves and jets. The carburetors should be removed and overhauled if draining the float bowls doesn't solve the problem.

5 Engine flooded

- 1 Float level too high. Check and adjust as described in Chapter 3.
- 2 Inlet needle valve worn or stuck open. A piece of dirt, rust or other

debris can cause the inlet needle to seat improperly, causing excess fuel to be admitted to the float bowl. In this case, the float chamber should be cleaned and the needle and seat inspected. If the needle and seat are worn, then the leaking will persist and the parts should be replaced with new ones (Chapter 3).

3 Starting technique incorrect. Under normal circumstances (i.e., if all the carburetor functions are sound) the machine should start with little or no throttle. When the engine is cold, the choke should be operated and the engine started without opening the throttle. When the engine is at operating temperature, only a very slight amount of throttle should be necessary. If the engine is flooded, turn the fuel tap off and hold the throttle open while cranking the engine. This will allow additional air to reach the cylinders. Remember to turn the fuel tap back on after the engine starts.

6 No spark or weak spark

- 1 Ignition switch Off.
- 2 Engine kill switch turned to the Off position.
- 3 Battery voltage low. Check and recharge battery as necessary (Chapter 8).
- 4 Spark plug dirty, defective or worn out. Locate reason for fouled plug(s) using spark plug condition chart and follow the plug maintenance procedures in Chapter 1.
- 5 Spark plug cap or secondary (HT) wiring faulty. Check condition. Replace either or both components if cracks or deterioration are evident (Chapter 4).
- 6 Spark plug cap not making good contact. Make sure that the plug cap fits snugly over the plug end.
- 7 Igniter defective. Check the unit, referring to Chapter 4 for details.
- 8 Pickup coil(s) defective. Check the unit(s), referring to Chapter 4 for details.
- 9 Ignition coil(s) defective. Check the coils, referring to Chapter 4.
- 10 Ignition or kill switch shorted. This is usually caused by water, corrosion, damage or excessive wear. The switches can be disassembled and cleaned with electrical contact cleaner. If cleaning does not help, replace the switches (Chapter 8).
- 11 Wiring shorted or broken between:
 - a) Ignition switch and engine kill switch (or blown fuse)
 - b) Igniter and engine kill switch
 - c) Igniter and ignition coil
 - d) Ignition coil and plug
 - e) Igniter and pickup coil(s)

Make sure that all wiring connections are clean, dry and tight. Look for chafed and broken wires (Chapters 4 and 8).

7 Compression low

- 1 Spark plug loose. Remove the plug and inspect the threads. Reinstall and tighten to the specified torque (Chapter 1).
- 2 Cylinder head not sufficiently tightened down. If the cylinder head is suspected of being loose, then there's a chance that the gasket or head is damaged if the problem has persisted for any length of time. The head nuts should be tightened to the proper torque in the correct sequence (Chapter 2).
- 3 Improper valve clearance. This means that the valve is not closing completely and compression pressure is leaking past the valve. Check and adjust the valve clearances (Chapter 1).
- 4 Cylinder and/or piston worn. Excessive wear will cause compression pressure to leak past the rings. This is usually accompanied by worn rings as well. A top end overhaul is necessary (Chapter 2).
- 5 Piston rings worn, weak, broken, or sticking. Broken or sticking piston rings usually indicate a lubrication or carburetion problem that causes excess carbon deposits or seizures to form on the pistons and rings. Top end overhaul is necessary (Chapter 2).

6 Piston ring-to-groove clearance excessive. This is caused by excessive wear of the piston ring lands. Piston replacement is necessary (Chapter 2).

7 Cylinder head gasket damaged. If the head is allowed to become loose, or if excessive carbon build-up on the piston crown and combustion chamber causes extremely high compression, the head gasket may leak. Retorquing the head is not always sufficient to restore the seal, so gasket replacement is necessary (Chapter 2).

8 Cylinder head warped. This is caused by overheating or improperly tightened head bolts. Machine shop resurfacing or head replacement is necessary (Chapter 2).

9 Valve spring broken or weak. Caused by component failure or wear; the spring(s) must be replaced (Chapter 2).

10 Valve not seating properly. This is caused by a bent valve (from over-revving or improper valve adjustment), burned valve or seat (improper carburetion) or an accumulation of carbon deposits on the seat (from carburetion or lubrication problems). The valves must be cleaned and/or replaced and the seats serviced if possible (Chapter 2).

8 Stalls after starting

1 Improper choke action. Make sure the choke rod is getting a full stroke and staying in the out position.

2 Ignition malfunction. See Chapter 4.

3 Carburetor malfunction. See Chapter 3.

4 Fuel contaminated. The fuel can be contaminated with either dirt or water, or can change chemically if the machine is allowed to sit for several months or more. Drain the tank and float bowls (Chapter 3).

5 Intake air leak. Check for loose carburetor-to-intake manifold connections, loose or missing vacuum gauge access port cap or hose, or loose carburetor top (Chapter 3).

6 Engine idle speed incorrect. Turn throttle stop screw until the engine idles at the specified rpm (Chapters 1 and 3).

9 Rough idle

1 Ignition malfunction. See Chapter 4.

2 Idle speed incorrect. See Chapter 1.

3 Carburetors not synchronized. Adjust carburetors with vacuum gauge or manometer set as described in Chapter 1.

4 Carburetor malfunction. See Chapter 3.

5 Fuel contaminated. The fuel can be contaminated with either dirt or water, or can change chemically if the machine is allowed to sit for several months or more. Drain the tank and float bowls (Chapter 3).

6 Intake air leak. Check for loose carburetor-to-intake manifold connections, loose or missing vacuum gauge access port cap or hose, or loose carburetor top (Chapter 3).

7 Air cleaner clogged. Service or replace air filter element (Chapter 1).

Poor running at low speed

10 Spark weak

1 Battery voltage low. Check and recharge battery (Chapter 8).

2 Spark plug fouled, defective or worn out. Refer to Chapter 1 for spark plug maintenance.

3 Spark plug cap or high tension wiring defective. Refer to Chapters 1 and 5 for details on the ignition system.

4 Spark plug cap not making contact.

5 Incorrect spark plug. Wrong type, heat range or cap configuration. Check and install correct plugs listed in Chapter 1, or one with a recessed firing end.

without fouling.

6 Igniter defective. See Chapter 4.

7 Signal generator defective. See Chapter 4.

8 Ignition coil(s) defective. See Chapter 4.

11 Fuel/air mixture incorrect

1 Pilot screw(s) out of adjustment (Chapter 3).

2 Pilot jet or air passage clogged. Remove and overhaul the carburetors (Chapter 3).

3 Air bleed holes clogged. Remove carburetor and blow out all passages (Chapter 3).

4 Air cleaner clogged, poorly sealed or missing.

5 Air cleaner-to-carburetor boot poorly sealed. Look for cracks, holes or loose clamps and replace or repair defective parts.

6 Fuel level too high or too low. Adjust the floats (Chapter 3).

7 Fuel tank air vent obstructed. Make sure that the air vent passage in the filler cap is open.

8 Carburetor intake manifolds loose. Check for cracks, breaks, tears or loose clamps or bolts. Repair or replace the rubber boots.

12 Compression low

1 Spark plug loose. Remove the plug and inspect the threads. Reinstall and tighten to the specified torque (Chapter 1).

2 Cylinder head not sufficiently tightened down. If the cylinder head is suspected of being loose, then there's a chance that the gasket and head are damaged if the problem has persisted for any length of time. The head bolts should be tightened to the proper torque in the correct sequence (Chapter 2).

3 Improper valve clearance. This means that the valve is not closing completely and compression pressure is leaking past the valve. Check and adjust the valve clearances (Chapter 1).

4 Cylinder and/or piston worn. Excessive wear will cause compression pressure to leak past the rings. This is usually accompanied by worn rings as well. A top end overhaul is necessary (Chapter 2).

5 Piston rings worn, weak, broken, or sticking. Broken or sticking piston rings usually indicate a lubrication or carburetion problem that causes excess carbon deposits or seizures to form on the pistons and rings. Top end overhaul is necessary (Chapter 2).

6 Piston ring-to-groove clearance excessive. This is caused by excessive wear of the piston ring lands. Piston replacement is necessary (Chapter 2).

7 Cylinder head gasket damaged. If the head is allowed to become loose, or if excessive carbon build-up on the piston crown and combustion chamber causes extremely high compression, the head gasket may leak. Retorquing the head is not always sufficient to restore the seal, so gasket replacement is necessary (Chapter 2).

8 Cylinder head warped. This is caused by overheating or improperly tightened head bolts. Machine shop resurfacing or head replacement is necessary (Chapter 2).

9 Valve spring broken or weak. Caused by component failure or wear; the spring(s) must be replaced (Chapter 2).

10 Valve not seating properly. This is caused by a bent valve (from over-revving or improper valve adjustment), burned valve or seat (improper carburetion) or an accumulation of carbon deposits on the seat (from carburetion, lubrication problems). The valves must be cleaned and/or replaced and the seats serviced if possible (Chapter 2).

13 Poor acceleration

1 Carburetor...

- 3 Carburetors not synchronized. Adjust them with a vacuum gauge set or manometer (Chapter 1).
- 4 Engine oil viscosity too high. Using a heavier oil than that recommended in Chapter 1 can damage the oil pump or lubrication system and cause drag on the engine.
- 5 Brakes dragging. Usually caused by debris which has entered the brake piston sealing boot (disc brakes), weak springs (drum brakes), or from a warped disc or bent axle. Repair as necessary (Chapter 6).

Poor running or no power at high speed

14 Firing incorrect

- 1 Air filter restricted. Clean or replace filter (Chapter 1).
- 2 Spark plug fouled, defective or worn out. See Chapter 1 for spark plug maintenance.
- 3 Spark plug cap or secondary (HT) wiring defective. See Chapters 1 and 4 for details of the ignition system.
- 4 Spark plug cap not in good contact. See Chapter 4.
- 5 Incorrect spark plug. Wrong type, heat range or cap configuration. Check and install correct plugs listed in Chapter 1. A cold plug or one with a recessed firing electrode will not operate at low speeds without fouling.
- 6 Igniter defective. See Chapter 4.
- 7 Ignition coil(s) defective. See Chapter 4.

15 Fuel/air mixture incorrect

- 1 Main jet clogged. Dirt, water or other contaminants can clog the main jets. Clean the fuel tap filter, the float bowl area, and the jets and carburetor orifices (Chapter 3).
- 2 Main jet wrong size. The standard jetting is for sea level atmospheric pressure and oxygen content.
- 3 Throttle shaft-to-carburetor body clearance excessive. Refer to Chapter 3 for inspection and part replacement procedures.
- 4 Air bleed holes clogged. Remove and overhaul carburetors (Chapter 3).
- 5 Air cleaner clogged, poorly sealed, or missing.
- 6 Air cleaner-to-carburetor boot poorly sealed. Look for cracks, holes or loose clamps, and replace or repair defective parts.
- 7 Fuel level too high or too low. Adjust the float(s) (Chapter 3).
- 8 Fuel tank air vent obstructed. Make sure the air vent passage in the filler cap is open.
- 9 Carburetor intake manifolds loose. Check for cracks, breaks, tears or loose clamps or bolts. Repair or replace the rubber boots (Chapter 2).
- 10 Fuel tap clogged. Remove the tap and clean it and the filter (Chapter 1).
- 11 Fuel line clogged. Pull the fuel line loose and carefully blow through it.

16 Compression low

- 1 Spark plug loose. Remove the plug and inspect the threads. Reinstall and tighten to the specified torque (Chapter 1).
- 2 Cylinder head not sufficiently tightened down. If the cylinder head is suspected of being loose, then there's a chance that the gasket and head are damaged if the problem has persisted for any length of time. The head nuts should be tightened to the proper torque in the correct sequence (Chapter 2).
- 3 Improper valve clearance. This means that the valve is not closing completely and compression pressure is leaking past the valve. Check and adjust the valve clearances (Chapter 1).
- 4 Cylinder and/or piston worn. Excessive wear will cause

- compression pressure to leak past the rings. This is usually accompanied by worn rings as well. A top end overhaul is necessary (Chapter 2).
- 5 Piston rings worn, weak, broken, or sticking. Broken or sticking piston rings usually indicate a lubrication or carburetion problem that causes excess carbon deposits or seizures to form on the pistons and rings. Top end overhaul is necessary (Chapter 2).
- 6 Piston ring-to-groove clearance excessive. This is caused by excessive wear of the piston ring lands. Piston replacement is necessary (Chapter 2).
- 7 Cylinder head gasket damaged. If the head is allowed to become loose, or if excessive carbon build-up on the piston crown and combustion chamber causes extremely high compression, the head gasket may leak. Retorquing the head is not always sufficient to restore the seal, so gasket replacement is necessary (Chapter 2).
- 8 Cylinder head warped. This is caused by overheating or improperly tightened head bolts. Machine shop resurfacing or head replacement is necessary (Chapter 2).
- 9 Valve spring broken or weak. Caused by component failure or wear; the spring(s) must be replaced (Chapter 2).
- 10 Valve not seating properly. This is caused by a bent valve (from over-revving or improper valve adjustment), burned valve or seat (improper carburetion) or an accumulation of carbon deposits on the seat (from carburetion or lubrication problems). The valves must be cleaned and/or replaced and the seats serviced if possible (Chapter 2).

17 Knocking or pinging

- 1 Carbon build-up in combustion chamber. Use of a fuel additive that will dissolve the adhesive bonding the carbon particles to the crown and chamber is the easiest way to remove the build-up. Otherwise, the cylinder head will have to be removed and decarbonized (Chapter 2).
- 2 Incorrect or poor quality fuel. Old or improper grades of fuel can cause detonation. This causes the piston to rattle, thus the knocking or pinging sound. Drain old fuel and always use the recommended fuel grade.
- 3 Spark plug heat range incorrect. Uncontrolled detonation indicates the plug heat range is too hot. The plug in effect becomes a glow plug, raising cylinder temperatures. Install the proper heat range plug (Chapter 1).
- 4 Improper air/fuel mixture. This will cause the cylinder to run hot, which leads to detonation. Clogged jets or an air leak can cause this imbalance. See Chapter 3.

18 Miscellaneous causes

- 1 Throttle valve doesn't open fully. Adjust the cable slack (Chapter 1).
- 2 Clutch slipping. May be caused by loose or worn clutch components. Refer to Chapter 2 for clutch overhaul procedures.
- 3 Timing not advancing.
- 4 Engine oil viscosity too high. Using a heavier oil than the one recommended in Chapter 1 can damage the oil pump or lubrication system and cause drag on the engine.
- 5 Brakes dragging. Usually caused by debris which has entered the brake piston sealing boot, or from a warped disc or bent axle. Repair as necessary.

Overheating

19 Engine overheats

- 1 Engine oil level low. Check and add oil (Chapter 1).

- Wrong type of oil. If you're not sure what type of oil is in the engine, drain it and fill with the correct type (Chapter 1).
- Air leak at carburetor intake boots. Check and tighten or replace as necessary (Chapter 3).
- Float level low. Check and adjust if necessary (Chapter 3).
- Worn oil pump or clogged oil passages. Check oil pressure (Chapter 2). Replace pump or clean passages as necessary.
- Carbon build-up in combustion chambers. Use of a fuel additive that will dissolve the adhesive bonding the carbon particles to the piston crowns and chambers is the easiest way to remove the build-up. Otherwise, the cylinder head will have to be removed and decarbonized (Chapter 2).

20 Firing incorrect

- Spark plugs fouled, defective or worn out. See Chapter 1 for spark plug maintenance.
- Incorrect spark plugs.
- Faulty ignition coil(s) (Chapter 4).

21 Fuel/air mixture incorrect

- Main jet clogged. Dirt, water and other contaminants can clog the main jets. Clean the fuel tap filter, the float bowl area and the jets and carburetor orifices (Chapter 3).
- Main jet wrong size. The standard jetting is for sea level atmospheric pressure and oxygen content.
- Air cleaner poorly sealed or missing.
- Air cleaner-to-carburetor boot poorly sealed. Look for cracks, holes or loose clamps and replace or repair.
- Fuel level too low. Adjust the float(s) (Chapter 3).
- Fuel tank air vent obstructed. Make sure that the air vent passage in the filler cap is open.
- Carburetor intake manifolds loose. Check for cracks, breaks, tears or loose clamps or bolts. Repair or replace the rubber boots (Chapter 2).

22 Compression too high

- Carbon build-up in combustion chamber. Use of a fuel additive that will dissolve the adhesive bonding the carbon particles to the piston crown and chamber is the easiest way to remove the build-up. Otherwise, the cylinder head will have to be removed and decarbonized (Chapter 2).
- Improperly machined head surface or installation of incorrect gasket during engine assembly. Check Specifications (Chapter 2).

23 Engine load excessive

- Clutch slipping. Can be caused by damaged, loose or worn clutch components. Refer to Chapter 2 for overhaul procedures.
- Engine oil level too high. The addition of too much oil will cause pressurization of the crankcase and inefficient engine operation. Check Specifications and drain to proper level (Chapter 1).
- Engine oil viscosity too high. Using a heavier oil than the one recommended in Chapter 1 can damage the oil pump or lubrication system as well as cause drag on the engine.
- Brakes dragging. Usually caused by debris which has entered the brake piston sealing boot, or from a warped disc or bent axle. Repair as necessary.

24 Lubrication inadequate

- Engine oil level too low. Friction caused by intermittent lack of lubrication or from oil that is overworked can cause overheating. The oil provides a definite cooling function in the engine. Check the oil level (Chapter 1).
- Poor quality engine oil or incorrect viscosity or type. Oil is not only according to viscosity but also according to type. Some oils are not rated high enough for use in this engine. Check the Specifications section and change to the correct oil (Chapter 1).

25 Miscellaneous causes

Modification to exhaust system. Most aftermarket exhaust systems cause the engine to run leaner, which make them run hotter. When installing an accessory exhaust system, always refer to carburetors.

Clutch problems

26 Clutch slipping

- Friction plates worn or warped. Overhaul the clutch assembly (Chapter 2).
- Steel plates worn or warped (Chapter 2).
- Clutch springs broken or weak. Old or heat-damaged (from slipping clutch) springs should be replaced with new ones (Chapter 2).
- Worn or warped clutch plates. Replace (Chapter 2).
- Clutch release mechanism defective. Replace any defective parts (Chapter 2).
- Clutch hub or housing unevenly worn. This causes improper engagement of the discs. Replace the damaged or worn parts (Chapter 2).

27 Clutch not disengaging completely

- Sticking cable. Inspect and lubricate or replace (Chapter 2).
- Clutch plates warped or damaged. This will cause clutch drag which in turn will cause the machine to creep. Overhaul the clutch assembly (Chapter 2).
- Clutch spring tension uneven. Usually caused by a sagged or broken spring. Check and replace the spring (Chapter 2).
- Engine oil deteriorated. Old, thin, worn out oil will not provide proper lubrication for the discs, causing the clutch to drag. Replace the oil and filter (Chapter 1).
- Engine oil viscosity too high. Using a heavier oil than recommended in Chapter 1 can cause the plates to stick together putting a drag on the engine. Change to the correct weight oil (Chapter 1).
- Clutch housing seized on shaft. Lack of lubrication, severe wear or damage can cause the housing to seize on the shaft. Overhaul of the clutch, and perhaps transmission, may be necessary to repair the damage (Chapter 2).
- Clutch release mechanism defective. Worn or damaged release mechanism parts can stick and fail to apply force to the pressure plate. Overhaul the release mechanism components (Chapter 2).
- Loose clutch hub nut. Causes housing and hub misalignment putting a drag on the engine. Engagement adjustment continually varies. Overhaul (Chapter 2).

Gear shifting problems

28 Doesn't go into gear or lever doesn't return

- 1 Clutch not disengaging. See Section 27.
- 2 Shift fork(s) bent or seized. Often caused by dropping the machine or from lack of lubrication. Overhaul the transmission (Chapter 2).
- 3 Gear(s) stuck on shaft. Most often caused by a lack of lubrication or excessive wear in transmission bearings and bushings. Overhaul the transmission (Chapter 2).
- 4 Shift cam binding. Caused by lubrication failure or excessive wear. Replace the cam and bearings (Chapter 2).
- 5 Shift lever return spring weak or broken (Chapter 2).
- 6 Shift lever broken. Splines stripped out of lever or shaft, caused by allowing the lever to get loose or from dropping the machine. Replace necessary parts (Chapter 2).
- 7 Shift mechanism pawl broken or worn. Full engagement and rotary movement of shift cam results. Replace shaft assembly (Chapter 2).
- 8 Pawl spring broken. Allows pawl to float, causing sporadic shift operation. Replace spring (Chapter 2).

29 Jumps out of gear

- 1 Shift fork(s) worn. Overhaul the transmission (Chapter 2).
- 2 Gear groove(s) worn. Overhaul the transmission (Chapter 2).
- 3 Gear dogs or dog slots worn or damaged. The gears should be inspected and replaced. No attempt should be made to service the worn parts.

30 Overshifts

- 1 Pawl spring weak or broken (Chapter 2).
- 2 Shift cam stopper lever not functioning (Chapter 2).
- 3 Overshift limiter broken or distorted (Chapter 2).

Abnormal engine noise

31 Knocking or pinging

- 1 Carbon build-up in combustion chamber. Use of a fuel additive that will dissolve the adhesive bonding the carbon particles to the piston crown and chamber is the easiest way to remove the build-up. Otherwise, the cylinder head will have to be removed and decarbonized (Chapter 2).
- 2 Incorrect or poor quality fuel. Old or improper fuel can cause detonation. This causes the pistons to rattle, thus the knocking or pinging sound. Drain the old fuel and always use the recommended grade fuel (Chapter 3).
- 3 Spark plug heat range incorrect. Uncontrolled detonation indicates that the plug heat range is too hot. The plug in effect becomes a glow plug, raising cylinder temperatures. Install the proper heat range plug (Chapter 1).
- 4 Improper air/fuel mixture. This will cause the cylinders to run hot and lead to detonation. Clogged jets or an air leak can cause this imbalance. See Chapter 3.

32 Piston slap or rattling

- 1 Piston pin or piston pin bore worn or seized from wear or lack of lubrication. Replace damaged parts (Chapter 2).

- 2 Connecting rod bent. Caused by over-revving, trying to start a badly flooded engine or from ingesting a foreign object into the combustion chamber. Replace the damaged parts (Chapter 2).
- 3 Piston pin or piston pin bore worn or seized from wear or lack of lubrication. Replace damaged parts (Chapter 2).
- 4 Piston ring(s) worn, broken or sticking. Overhaul the top end (Chapter 2).
- 5 Piston seizure damage. Usually from lack of lubrication or overheating. Replace the pistons and bore the cylinders, as necessary (Chapter 2).
- 6 Connecting rod upper or lower end clearance excessive. Caused by excessive wear or lack of lubrication. Replace worn parts.

33 Valve noise

- 1 Incorrect valve clearances. Adjust the clearances by referring to Chapter 1.
- 2 Valve spring broken or weak. Check and replace weak valve springs (Chapter 2).
- 3 Camshaft or cylinder head worn or damaged. Lack of lubrication at high rpm is usually the cause of damage. Insufficient oil or failure to change the oil at the recommended intervals are the chief causes. Since there are no replaceable bearings in the head, the head itself will have to be replaced if there is excessive wear or damage (Chapter 2).

34 Other noise

- 1 Cylinder head gasket leaking.
- 2 Exhaust pipe leaking at cylinder head connection. Caused by improper fit of pipe(s) or loose exhaust flange. All exhaust fasteners should be tightened evenly and carefully. Failure to do this will lead to a leak.
- 3 Crankshaft runout excessive. Caused by a bent crankshaft (from over-revving) or damage from an upper cylinder component failure. Can also be attributed to dropping the machine on either of the crankshaft ends.
- 4 Engine mounting bolts loose. Tighten all engine mount bolts to the specified torque (Chapter 2).
- 5 Crankshaft bearings worn (Chapter 2).
- 6 Camshaft chain tensioner out of adjustment or defective. Adjust (Chapter 1) or replace (Chapter 2).
- 7 Camshaft chain, sprockets or guides worn (Chapter 2).

Abnormal driveline noise

35 Clutch noise

- 1 Clutch housing/friction plate clearance excessive (Chapter 2).
- 2 Loose or damaged clutch pressure plate and/or bolts (Chapter 2).

36 Transmission noise

- 1 Bearings worn. Also includes the possibility that the shafts are worn. Overhaul the transmission (Chapter 2).
- 2 Gears worn or chipped (Chapter 2).
- 3 Metal chips jammed in gear teeth. Probably pieces from a broken clutch, gear or shift mechanism that were picked up by the gears. This will cause early bearing failure (Chapter 2).
- 4 Engine oil level too low. Causes a howl from transmission. Also

37 Final drive noise

- 1 Chain not adjusted properly (Chapter 1).
- 2 Engine sprocket or rear sprocket loose. Tighten fasteners (Chapters 2 and 5).
- 3 Sprocket(s) worn. Replace sprocket(s). (Chapter 5).
- 4 Rear sprocket warped. Replace (Chapter 5).
- 5 Wheel coupling worn. Replace coupling (Chapter 5).

Abnormal frame and suspension noise

38 Front end noise

- 1 Low fluid level or improper viscosity oil in forks. This can sound like spurring and is usually accompanied by irregular fork action (Chapter 5).
- 2 Spring weak or broken. Makes a clicking or scraping sound. Fork oil, when drained, will have a lot of metal particles in it (Chapter 5).
- 3 Steering head bearings loose or damaged. Clicks when braking. Check and adjust or replace as necessary (Chapter 5).
- 4 Fork clamps loose. Make sure all fork clamp pinch bolts are tight (Chapter 5).
- 5 Fork tube bent. Good possibility if machine has been dropped. Replace tube with a new one (Chapter 5).
- 6 Front axle or axle clamp bolt loose. Tighten them to the specified torque (Chapter 6).

39 Shock absorber noise

- 1 Fluid level incorrect. Indicates a leak caused by defective seal. Shock will be covered with oil. Replace shock (Chapter 5).
- 2 Defective shock absorber with internal damage. This is in the body of the shock and can't be remedied. The shock must be replaced with a new one (Chapter 5).
- 3 Bent or damaged shock body. Replace the shock with a new one (Chapter 5).

40 Brake noise

- 1 Squeal caused by pad shim not installed or positioned correctly (Chapter 6).
- 2 Squeal caused by dust on brake pads or shoes. Usually found in combination with glazed pads. Clean using brake cleaning solvent (Chapter 6).
- 3 Contamination of brake pads or shoes. Oil, brake fluid or dirt causing brake to chatter or squeal. Clean or replace pads or shoes (Chapter 6).
- 4 Pads glazed. Caused by excessive heat from prolonged use or from contamination. Do not use sandpaper, emery cloth, carborundum cloth or any other abrasive to roughen the pad surfaces as abrasives will stay in the pad material and damage the disc. A very fine flat file can be used, but pad replacement is suggested as a cure (Chapter 6).
- 5 Disc warped. Can cause a chattering, clicking or intermittent squeal. Usually accompanied by a pulsating lever and uneven braking. Replace the disc (Chapter 6).
- 6 Drum out-of-round. Can cause chattering, clicking or intermittent squeal. Usually accompanied by a pulsating pedal and uneven braking. Refinish or replace drum (Chapter 6).
- 7 Loose or worn wheel bearings. Check and replace as needed (Chapter 6).

Oil level indicator light comes on

41 Engine lubrication system

- 1 These models use an oil level light rather than an oil pressure light.
- 2 Engine oil level low. Inspect for leak or other problem causing the oil level and add recommended oil (Chapters 1 and 2).

42 Electrical system

- 1 Oil level switch defective. Check the switch according to the procedure in Chapter 8. Replace it if it's defective.
- 2 Oil level indicator light circuit defective. Check for pinched, shorted, disconnected or damaged wiring (Chapter 8).

Excessive exhaust smoke

43 White smoke

- 1 Piston oil ring worn. The ring may be broken or damaged, causing oil from the crankcase to be pulled past the piston into the combustion chamber. Replace the rings with new ones (Chapter 2).
- 2 Cylinders worn, cracked, or scored. Caused by overheating or oil starvation. The cylinders will have to be rebored and new pistons installed.
- 3 Valve oil seal damaged or worn. Replace oil seals with new ones (Chapter 2).
- 4 Valve guide worn. Perform a complete valve job (Chapter 2).
- 5 Engine oil level too high, which causes the oil to be forced past the rings. Drain oil to the proper level (Chapter 1).
- 6 Head gasket broken between oil return and cylinder. Causes oil to be pulled into the combustion chamber. Replace the head gasket and check the head for warpage (Chapter 2).
- 7 Abnormal crankcase pressurization, which forces oil past the rings. Clogged breather or hoses usually the cause (Chapter 3).

44 Black smoke

- 1 Air cleaner clogged. Clean or replace the element (Chapter 1).
- 2 Main jet too large or loose. Compare the jet size to the Specifications (Chapter 3).
- 3 Choke stuck, causing fuel to be pulled through choke orifices (Chapter 3).
- 4 Fuel level too high. Check and adjust the float level as necessary (Chapter 3).
- 5 Inlet needle held off needle seat. Clean the float bowls and fuel line and replace the needles and seats if necessary (Chapter 3).

45 Brown smoke

- 1 Main jet too small or clogged. Lean condition caused by wrong size main jet or by a restricted orifice. Clean float bowl and jets and compare jet size to Specifications (Chapter 3).
- 2 Fuel flow insufficient. Fuel inlet needle valve stuck closed due to chemical reaction with old fuel. Float level incorrect. Restricted fuel line. Clean line and float bowl and adjust floats if necessary.
- 3 Carburetor intake manifolds loose (Chapter 3).
- 4 Air cleaner

Poor handling or stability

46 Handlebar hard to turn

- 1 Steering stem locknut too tight (Chapter 5).
- 2 Bearings damaged. Roughness can be felt as the bars are turned from side-to-side. Replace bearings and races (Chapter 5).
- 3 Races dented or worn. Denting results from wear in only one position (e.g., straight ahead), from a collision or hitting a pothole or from dropping the machine. Replace races and bearings (Chapter 5).
- 4 Steering stem lubrication inadequate. Causes are grease getting hard from age or being washed out by high pressure car washes. Disassemble steering head and repack bearings (Chapter 5).
- 5 Steering stem bent. Caused by a collision, hitting a pothole or by dropping the machine. Replace damaged part. Don't try to straighten the steering stem (Chapter 5).
- 6 Front tire air pressure too low (Chapter 1).

47 Handlebar shakes or vibrates excessively

- 1 Tires worn or out of balance (Chapter 6).
- 2 Swingarm bearings worn. Replace worn bearings by referring to Chapter 6.
- 3 Rim(s) warped or damaged. Inspect wheels for runout (Chapter 6).
- 4 Wheel bearings worn. Worn front or rear wheel bearings can cause poor tracking. Worn front bearings will cause wobble (Chapter 6).
- 5 Handlebar clamp bolts loose (Chapter 5).
- 6 Steering stem or fork clamps loose. Tighten them to the specified torque (Chapter 5).
- 7 Engine mounting bolts loose. Will cause excessive vibration with increased engine rpm (Chapter 2).

48 Handlebar pulls to one side

- 1 Frame bent. Definitely suspect this if the machine has been dropped. May or may not be accompanied by cracking near the bend. Replace the frame (Chapter 5).
- 2 Wheel out of alignment. Caused by improper location of axle spacers or from bent steering stem or frame (Chapter 5).
- 3 Swingarm bent or twisted. Caused by age (metal fatigue) or impact damage. Replace the arm (Chapter 5).
- 4 Steering stem bent. Caused by impact damage or by dropping the motorcycle. Replace the steering stem (Chapter 5).
- 5 Fork leg bent. Disassemble the forks and replace the damaged parts (Chapter 6).
- 6 Fork oil level uneven. Check and add or drain as necessary (Chapter 1).

49 Poor shock absorbing qualities

- 1 Too hard:
 - a) Fork oil level excessive (Chapter 5).
 - b) Fork oil viscosity too high. Use a lighter oil (see the Specifications in Chapter 1).
 - c) Fork tube bent. Causes a harsh, sticking feeling (Chapter 5).
 - d) Shock shaft or body bent or damaged (Chapter 5).
 - e) Fork internal damage (Chapter 5).
 - f) Shock internal damage.
 - g) Tire pressure too high (Chapters 1 and 6).

- b) Fork oil level too low (Chapter 5).
- c) Fork oil viscosity too light (Chapter 5).
- d) Fork springs weak or broken (Chapter 5).

Braking problems

50 Brakes are spongy, don't hold

- 1 Air in brake line. Caused by inattention to master cylinder fluid level or by leakage. Locate problem and bleed brakes (Chapter 6).
- 2 Pad or disc worn (Chapters 1 and 6).
- 3 Brake fluid leak. See paragraph 1.
- 4 Contaminated pads. Caused by contamination with oil, grease, brake fluid, etc. Clean or replace pads. Clean disc thoroughly with brake cleaner (Chapter 6).
- 5 Brake fluid deteriorated. Fluid is old or contaminated. Drain system, replenish with new fluid and bleed the system (Chapter 6).
- 6 Master cylinder internal parts worn or damaged causing fluid to bypass (Chapter 6).
- 7 Master cylinder bore scratched by foreign material or broken spring. Repair or replace master cylinder (Chapter 6).
- 8 Disc warped. Replace disc (Chapter 6).

51 Brake lever or pedal pulsates

- 1 Disc warped. Replace disc (Chapter 6).
- 2 Axle bent. Replace axle (Chapter 5).
- 3 Brake caliper bolts loose (Chapter 6).
- 4 Brake caliper shafts damaged or sticking, causing caliper to bind. Lube the shafts or replace them if they are corroded or bent (Chapter 6).
- 5 Wheel warped or otherwise damaged (Chapter 6).
- 6 Wheel bearings damaged or worn (Chapter 6).
- 7 Drum out-of-round (Radian models). Refinish or replace drum (Chapter 6).

52 Brakes drag

- 1 Master cylinder piston seized. Caused by wear or damage to piston or cylinder bore (Chapter 6).
- 2 Lever balky or stuck. Check pivot and lubricate (Chapter 6).
- 3 Brake caliper binds. Caused by inadequate lubrication or damage to caliper shafts (Chapter 6).
- 4 Brake caliper piston seized in bore. Caused by wear or ingestion of dirt past deteriorated seal (Chapter 6).
- 5 Brake pad damaged. Pad material separated from backing plate. Usually caused by faulty manufacturing process or from contact with chemicals. Replace pads (Chapter 6).
- 6 Pads or shoes improperly installed (Chapter 6).
- 7 Rear brake pedal free play insufficient (Chapter 1).
- 8 Rear brake springs weak (Chapter 6).

Electrical problems

53 Battery dead or weak

- 1 Battery faulty. Caused by sulfated plates which are shorted

- 3 Load excessive. Caused by addition of high wattage lights or other electrical accessories.
- 4 Ignition switch defective. Switch either grounds internally or fails to shut off system. Replace the switch (Chapter 8).
- 5 Regulator/rectifier defective (Chapter 8).
- 6 Stator coil open or shorted (Chapter 8).
- 7 Wiring faulty. Wiring grounded or connections loose in ignition, charging or lighting circuits (Chapter 8).

54 Battery overcharged

- 1 Regulator/rectifier defective. Overcharging is noticed when battery gets excessively warm or boils over (Chapter 8).
- 2 Battery defective. Replace battery with a new one (Chapter 8).
- 3 Battery amperage too low, wrong type or size. Install manufacturer's specified amp-hour battery to handle charging load (Chapter 8).

Chapter 1

Tune-up and routine maintenance

Contents

	<i>Section</i>		<i>Section</i>
Air filter element - servicing.....	14	Exhaust system - check.....	22
Battery electrolyte level/specific gravity - check.....	4	Fasteners - check.....	24
Brake lever play and pedal position - check and adjustment.....	8	Fluid levels - check.....	3
Brake pads - check.....	5	Fork oil - replacement.....	27
Brake shoes - check.....	6	Fuel system - check and filter cleaning.....	25
Brake system - general check.....	7	Idle speed - check and adjustment.....	19
Cam chain adjustment.....	28	Introduction to tune-up and routine maintenance.....	2
Carburetor synchronization - check and adjustment.....	20	Lubrication - general.....	17
Clutch - check.....	11	Routine maintenance intervals.....	1
Cylinder compression - check.....	15	Spark plugs - replacement.....	16
Drive chain and sprockets - check, adjustment and lubrication.....	12	Steering head bearings - check, adjustment and lubrication.....	23
Engine oil/filter - change.....	13	Suspension - check.....	26
Evaporative emission control system (California models only) - check.....	21	Throttle operation/grip freeplay - check and adjustment.....	10
		Tires/wheels - general check.....	9
		Valve clearances - check and adjustment.....	18

Engine

Spark plugs	
Type	NGK D8EA or ND X24ES-U NGK DR8ES-L or ND X24ESR-U 0.6 to 0.7 mm (0.024 to 0.028 inch)
US models	
UK models	
Gap	
Valve clearances (COLD engine)	
Intake.....	0.11 to 0.15 mm (0.004 to 0.005 inch)
Exhaust.....	0.16 to 0.20 mm (0.006 to 0.008 inch)
Engine idle speed	
YX600 Radian.....	1300 +/- 50 rpm
All others	1200 +/- 50 rpm
Cylinder compression pressure (at sea level)	
Standard.....	10.6 Bars (156 psi)
Maximum.....	11.2 Bars (164 psi)
Minimum.....	9.7 Bars (142 psi)
Carburetor synchronization	
Vacuum at idle speed.....	175 +/- 5 mm Hg (6.89 +/- 0.2 inch Hg)
Maximum vacuum difference between cylinders.....	10 mm Hg (0.39 inch Hg)
Cylinder numbering (from left side to right side of bike).....	1-2-3-4

Miscellaneous

Disc brake pad minimum thickness (front and rear).....	0.5 mm (.020 inch)
Drum brake shoe lining minimum thickness.....	2 mm (.080 inch)
Brake pedal position (below top of footpeg)	
FJ600.....	30 mm (1.20 inches)
FZ600	40 mm (1.6 inches)
XJ600	30 mm (1.2 inches)
YX600 Radian.....	15 mm (0.6 inch)
Freeplay adjustments	
Throttle grip	
FJ600	3 to 7 mm (0.12 to 0.28 inch)
FZ600	2 to 5 mm (0.08 to 0.20 inch)
XJ600	3 to 7 mm (0.12 to 0.28 inch)
YX600 Radian	2 to 5 mm (0.08 to 0.20 inch)
Clutch lever	
FJ600	2 to 3 mm (0.8 to 1.2 inch)
FZ600	8 to 12 mm (0.3 to 0.5 inch)
XJ600	2 to 3 mm (0.8 to 1.2 inch)
YX600 Radian	10 to 15 mm (0.4 to 0.6 inch)
Front brake lever	
FJ600	5 to 8 mm (0.2 to 0.3 inch)
FZ600	0 to 1 mm (0 to 0.04 inch)
XJ600	5 to 8 mm (0.2 to 0.3 inch)
YX600 Radian	2 to 5 mm (0.08 to 0.20 inch)
Brake pedal	
FJ600	20 to 30 mm (0.80 to 1.20 inch)
FZ600	13 to 15 mm (0.51 to 0.59 inch)
XJ600	20 to 30 mm (0.80 to 1.20 inch)
YX600 Radian	20 to 30 mm (0.80 to 1.20 inch)
Drive chain slack.....	20 to 30 mm (0.8 to 1.2 inch)
Battery electrolyte specific gravity.....	1.280 at 20-degrees C (68-degrees F)
Minimum tire tread depth*	1 mm (0.040 inch)
Tire pressures (cold)	
FJ600, XJ600	
Front	
Up to 90 kg (198 lbs)	1.77 Bars (26 psi)
Above 90 kg (198 lbs) or high speed riding	1.9 Bars (28 psi)
Rear	
Up to 90 kg (198 lbs)	1.9 Bars (28 psi)
Above 90 kg (198 lbs) or high speed riding	2.2 Bars (32 psi)
FZ600	
Front	
Up to 90 kg (198 lbs)	1.77 Bars (26 psi)
Above 90 kg (198 lbs) or high speed riding	1.9 Bars (28 psi)

Chapter 1 Tune-up and routine maintenance

Rear	
Up to 90 kg (198 lbs)	1.9 Bars (28 psi)
Above 90 kg (198 lbs)	2.48 Bars (36 psi)
High speed riding	2.2 Bars (32 psi)
YX600 Radian	
Front	
Up to 90 kg (198 lbs)	1.77 Bars (26 psi)
Above 90 kg (198 lbs) or high speed riding	1.9 Bars (28 psi)
Rear	
Up to 90 kg (198 lbs)	1.9 Bars (28 psi)
90 to 160 kg (198 to 353 lbs) or high speed riding	2.2 Bars (32 psi)
Above 160 kg (353 lbs)	2.48 Bars (36 psi)

Recommended lubricants and fluids

Engine/transmission oil

Type	API grade SE, SF or SG
Viscosity	
Up to 15 degrees C (60 degrees F)	SAE 10W30
Above 5 degrees C (40 degrees F)	SAE 20W40
Capacity	
With filter change	
FJ600, FZ600, XJ600	2.6 liters (2.7 US qts, 4.6 Imperial pts)
YX600 Radian	2.5 liters (2.6 US qts, 4.4 Imperial pts)
Oil change only	2.2 liters (2.3 US qts, 3.8 Imperial pts)
Brake fluid	DOT 4 (DOT 3 may be used if DOT 4 is unavailable)

Fork oil

Type	SAE 10W - fork oil
Capacity	
FJ600	287 cc (9.7 US fl oz, 10.1 Imperial fl oz)
FZ600	315 cc (10.7 US fl oz, 11.1 Imperial fl oz)
XJ600	269 cc (9.09 US fl oz, 9.47 Imperial fl oz)
YX600 Radian	320 cc (10.8 US oz, 11.3 Imperial oz)
Oil level**	
FJ600	Not specified
FZ600	117 mm (4.61 inches)
XJ600	
1984 and 1985	Not specified
1989-on	149 cc (5.87 inches)
YX600 Radian	not specified

Miscellaneous

Drive chain	SAE 30 to 50W engine oil
Wheel bearings	Medium weight, lithium-based multi-purpose grease
Swingarm pivot bearings	Medium weight, lithium-based waterproof wheel bearing grease
Cables and lever pivots	Chain and cable lubricant or 10W30 motor oil
Sidestand/centerstand pivots	Medium-weight, lithium-based multi-purpose grease
Brake pedal/shift lever pivots	Chain and cable lubricant or 10W30 motor oil
Throttle grip	Multi-purpose grease or dry film lubricant

Torque specifications

Oil drain plug	43 Nm (31 ft-lbs)
Oil filter bolt	15 Nm (11 ft-lbs)
Oil filter drain screw	7 Nm (5.1 ft-lbs)
Spark plugs	17.5 Nm (12.5 ft-lbs)
Steering head bearing ring nut	
Initial torque	38 Nm (27 ft-lbs)***
Final torque	See text
Valve cover bolts	See Chapter 2

*In the UK, tread depth must be at least 1 mm over 3/4 of the tread breadth all the way around the tire, with no bald patches.

**With the forks fully compressed and the spring removed.

***Using Yamaha ring nut wrench YU-33975 and a torque wrench placed at a right angle to the ring nut wrench.

1 Yamaha FJ, FZ, XJ, YX Radian 600

Routine maintenance intervals

Note: The pre-ride inspection outlined in the owner's manual covers checks and maintenance that should be carried out on a daily basis. It's condensed and included here to remind you of its importance. Always perform the pre-ride inspection at every maintenance interval (in

addition to the procedures listed). The intervals listed below are the shortest intervals recommended by the manufacturer for each particular operation during the model years covered in this manual. Your owner's manual may have different intervals for your model.

Daily or before riding

- Check the engine oil level
- Check the fuel level and inspect for leaks
- Check the operation of both brakes - also check the fluid level and look for leakage
- Check the tires for damage, the presence of foreign objects and correct air pressure
- Check the throttle for smooth operation and correct freeplay
- Check the operation of the clutch - make sure the freeplay is correct
- Make sure the steering operates smoothly, without looseness and without binding
- Check for proper operation of the headlight, taillight, brake light, turn signals, indicator lights, speedometer and horn
- Make sure the sidestand and centerstand (if equipped) return to their fully up positions and stay there under spring pressure
- Make sure the engine kill switch works properly

- Clean and gap the spark plugs
- Check/adjust the idle speed
- Check/adjust the carburetor synchronization
- Check the brake fluid level
- Lubricate brake pad edges and caliper cavities*
- Check the drum brake operation
- Check the brake discs and pads
- Check/adjust the brake pedal position
- Check the operation of the brake light
- Lubricate the clutch and brake lever pivots
- Lubricate the shift/brake lever pivots and the sidestand/centerstand pivots
- Check the steering
- Check the front forks for proper operation and fluid leaks
- Inspect and lubricate the rear suspension adjusting belt (if equipped)
- Check the tires and wheels
- Check the battery electrolyte level
- Check the exhaust system for leaks and check the tightness of the fasteners
- Check the cleanliness of the fuel system and the condition of the fuel lines and vacuum hoses
- Inspect the crankcase ventilation system
- Check the operation of the sidestand switch
- Lubricate the throttle cables

*Required in the UK and recommended wherever salt is used on the roads

After the initial 500 miles

Perform all of the daily checks plus:

- Check/adjust the idle speed and carburetor synchronization
- Check/adjust the drive chain slack
- Change the engine oil and oil filter
- Check the tightness of all fasteners
- Check/adjust the clutch lever position
- Check the brake fluid level
- Check/adjust the brake pedal position
- Check the operation of the brake light
- Check the operation of the sidestand switch
- Adjust cam chain tension
- Lubricate the throttle, clutch, speedometer and choke cables (if equipped)

Every 12,000 km/8,000 miles or 12 months

All of the items above plus:

- Change the engine oil and oil filter
- Replace the spark plugs
- Replace the alternator brushes (if equipped)
- Check/adjust the valve clearances

Every 18,000 km/12,000 miles or 18 months

All of the items above plus:

- Inspect the evaporative emission control system (if equipped)

Every 500 miles

- Check/adjust the drive chain slack
- Lubricate the drive chain

Every 6000 km/4000 miles or 6 months


- Change the engine oil
- Clean the air filter element and replace it if necessary

Every 24,000 km/16,000 miles or two years


- Change the brake fluid
- Clean and repack the steering head bearings
- Lubricate the swingarm bearings and rear suspension pivot points



2.3a Maintenance information printed on decals includes tune-up and lubrication data . . .



2.3b . . . battery vent tube location . . .



2.3c . . . and vacuum hose routing information



3.3 Check oil level at the inspection window; it should be between the Minimum and Maximum marks

2 Introduction to tune-up and routine maintenance

Refer to illustrations 2.3a, 2.3b and 2.3c

This Chapter covers in detail the checks and procedures necessary for the tune-up and routine maintenance of your motorcycle. Section 1 includes the routine maintenance schedule, which is designed to keep the machine in proper running condition and prevent possible problems. The remaining Sections contain detailed procedures for carrying out the items listed on the maintenance schedule, as well as additional maintenance information designed to increase reliability.

Since routine maintenance plays such an important role in the safe and efficient operation of your motorcycle, it is presented here as a comprehensive check list. For the rider who does all his/her own maintenance, these lists outline the procedures and checks that should be done on a routine basis.

Maintenance information is printed on decals attached to the motorcycle (see illustrations). If the information on the decals differs from that included here, use the information on the decal.

Deciding where to start or plug into the routine maintenance schedule depends on several factors. If you have a motorcycle whose warranty has recently expired, and if it has been maintained according to the warranty standards, you may want to pick up routine maintenance as it coincides with the next mileage or calendar interval. If you have owned the machine for some time but have never performed any maintenance on it, then you may want to start at the nearest interval and include some additional procedures to ensure that nothing important is overlooked. If you have just had a major engine overhaul, then you may want to start the maintenance routine from the beginning. If you have a used machine and have no knowledge of its

history or maintenance record, you may desire to combine all the checks into one large service initially and then settle into the maintenance schedule prescribed.

The Sections which outline the inspection and maintenance procedures are written as step-by-step comprehensive guides to the performance of the work. They explain in detail each of the routine inspections and maintenance procedures on the check list. References to additional information in applicable Chapters is also included and should not be overlooked.

Before beginning any maintenance or repair, the machine should be cleaned thoroughly, especially around the oil filter, spark plugs, cylinder head covers, side covers, carburetors, etc. Cleaning will help ensure that dirt does not contaminate the engine and will allow you to detect wear and damage that could otherwise easily go unnoticed.

3 Fluid levels - check

Engine oil

Refer to illustrations 3.3 and 3.4


1 Start the engine and allow it to reach normal operating temperature. **Warning:** Do not run the engine in an enclosed space such as a garage or shop.

2 Stop the engine and allow the machine to sit undisturbed in a level position for about five minutes. Place the bike on the centerstand (if equipped) or prop it securely in an upright position.


3 With the engine off, check the oil level in the window located at the lower part of the right crankcase cover. The oil level should be between the Maximum and Minimum level marks next to the window (see illustration).




3.4 The oil filler cap is located on the right side of the engine on the clutch cover (arrow)



3.7a With the front master cylinder in a level position, check fluid level in the inspection window (arrow)



3.7b The fluid level in the rear brake master cylinder can be checked by looking through the plastic reservoir - fluid must be above the lower mark (arrow)



3.9 To add fluid to the front brake reservoir, remove the master cylinder cover screws (arrows) and lift off the cover and diaphragm

4 If the level is below the Minimum mark, remove the oil filler cap from the right side of the crankcase (see illustration) and add enough oil of the recommended grade and type to bring the level up to the Maximum mark. Do not overfill.

Brake fluid

Refer to illustrations 3.7a, 3.7b and 3.9

5 In order to ensure proper operation of the hydraulic disc brakes, the fluid level in the master cylinder reservoir must be properly maintained.

6 With the motorcycle on the centerstand or held upright, turn the handlebars until the top of the front master cylinder is as level as possible. If necessary, tilt the motorcycle make it level.

7 Look closely at the inspection window in the master cylinder reservoir (front brakes) or at the level marks on the reservoir (rear brakes). Make sure that the fluid level is above the Lower mark on the reservoir (see illustrations).

8 If the level is low, the fluid must be replenished. Before removing the master cylinder cover or cap, cover the fuel tank to protect it from brake fluid spills (which will damage the paint) and remove all dust and dirt from the area around the cover or cap.

9 To top up front brake fluid, remove the screws (see illustration) and lift off the cover and rubber diaphragm. To top up rear brake fluid, unscrew the cap from the reservoir. **Note:** Do not operate the brakes with the cover or cap removed.

10 Add new, clean brake fluid of the recommended type until the level is above the inspection window in the front reservoir or the lower line in the rear reservoir. Do not mix different brands of brake fluid in the reservoir, as they may not be compatible.

11 On front brakes, install the rubber diaphragm and the cover.

Tighten the screws evenly, but do not overtighten them. On rear brakes, install the reservoir cap.

12 Wipe any spilled fluid off the reservoir body and reposition and tighten the brake lever and master cylinder assembly if it was moved.

13 If the brake fluid level was low, inspect the brake system for leaks.

4 Battery electrolyte level/specific gravity - check

Refer to illustrations 4.4, 4.7, 4.11a, 4.11b and 4.11c

Warning: Be extremely careful when handling or working around the battery. The electrolyte is very caustic and an explosive gas (hydrogen) is given off when the battery is charging. **Note:** The first Steps describe battery removal. If the electrolyte level is known to be sufficient it won't be necessary to remove the battery.

1 This procedure applies to original equipment batteries that have removable filler caps, which can be removed to add water to the battery. Sealed maintenance-free batteries can't be topped up.

2 Remove the seat (see Chapter 7).

3 If you're working on a Radian, remove the right side cover (see Chapter 7).

4 Remove the screws securing the battery cables to the battery terminals (remove the negative cable first, positive cable last) (see illustration). Remove the battery securing strap and pull the battery straight up to remove it. The electrolyte level will now be visible through the translucent battery case - it should be between the Upper and Lower level marks.


5 If the electrolyte is low, remove the cell caps and fill each cell to the upper level mark with distilled water only. Do not use tap water.




4.4 Detach the negative cable (right arrow) from the battery first, then detach the positive cable (left arrow); the plastic cap protects the positive terminal from accidental contact with metal



4.7 Check the specific gravity with a hydrometer



4.11a Be sure the battery vent tube is routed correctly, with no kinking or obstructions; this is an FJ/XJ600 ...



4.11b ... this is an FZ600 ...

(except in an emergency), and do not overfill. The cell holes are quite small, so it may help to use a plastic squeeze bottle with a small spout to add the water. If the level is within the marks on the case, additional water is not necessary.

6 Next, check the specific gravity of the electrolyte in each cell with a small hydrometer made especially for motorcycle batteries. These are available from most dealer parts departments or motorcycle accessory stores.


7 Remove the caps, draw some electrolyte from the first cell into the hydrometer (see illustration) and note the specific gravity. Compare the reading to the Specifications listed in this Chapter. **Note:** Add 0.004 points to the reading for every 10-degrees F above 20-degrees C (68-degrees F) - subtract 0.004 points from the reading for every 10-degrees below 20-degrees C (68-degrees F). Return the electrolyte to the appropriate cell and repeat the check for the remaining cells. When the check is complete, rinse the hydrometer thoroughly with clean water.

8 If the specific gravity of the electrolyte in each cell is as specified, the battery is in good condition and is apparently being charged by the machine's charging system.

9 If the specific gravity is low, the battery is not fully charged. This may be due to corroded battery terminals, a dirty battery case, a malfunctioning charging system, or loose or corroded wiring connections. On the other hand, it may be that the battery is worn out, especially if the machine is old, or that infrequent use of the motorcycle prevents normal charging from taking place.


10 Be sure to correct any problems and charge the battery if necessary. Refer to Chapter 8 for additional battery maintenance and charging procedures.

11 Install the battery cell caps, tightening them securely. Reconnect the cables to the battery, attaching the positive cable first and the negative cable last. Make sure to install the insulating boot over the




4.11c ... and this is a YX600 Radian

positive terminal. Install the fuel tank mount and the seat. Be very careful not to pinch or otherwise restrict the battery vent tube, as the battery may build up enough internal pressure during normal charging system operation to explode (see illustrations). Additionally, battery acid spilled onto the frame can cause accelerated corrosion and metal fatigue.



5.2a Lift off the front pad cover to expose the pads ...



5.2b ... and check to see if the raised corner of the pad backing metal (arrow) is close to the disc; if it is, the pad is worn and the full set of pads must be replaced (pad removed for clarity)

5 Brake pads - check

Refer to illustrations 5.2a, 5.2b and 5.4

- 1 The front and rear brake pads should be checked at the recommended intervals and replaced with new ones when worn beyond the limit described in this Section.
- 2 To check the front brake pads, remove the pad cover (see illustration). Reach up and operate the brake lever while you look at the back of the caliper. If the pad wear indicator is close to the disc (see illustration), the pads are worn excessively and must be replaced with new ones (see Chapter 6).
- 3 Repeat Step 2 to check the other front caliper.
- 4 To check the rear brake pads, have an assistant press the brake pedal firmly while you look at the pads through the back of the caliper (see illustration). Press the brake pedal firmly while you look at the wear indicators on the pads (see illustration 5.2b). If the indicators are close to the disc, replace the pads (see Chapter 6).
- 5 If the pads are in good condition, reinstall the covers (front brakes only). The words "Uncover for pad service" stamped in the covers may be upside down when the cover is installed. This doesn't mean the cover is upside down.
- 6 On UK models, remove the brake pads and lubricate the edges of the pad backing plates and the pad cavities in the calipers with special lubricants (see *Brake pads - replacement* in Chapter 6).

6 Brake shoes - check


Refer to illustration 6.1

- 1 Check rear brake shoe wear by pressing the brake pedal and observing the movement of the wear indicator pointer (see illustration).
- 2 If the arrow moves out of the safe range, replace the rear brake shoes (see Chapter 6).

7 Brake system - general check

Refer to illustration 7.7

- 1 A routine general check of the brakes will ensure that any problems are discovered and remedied before the rider's safety is jeopardized.
- 2 Check the brake lever and pedal for loose connections, excessive play, bends, and other damage. Replace any worn or damaged parts with new ones (see Chapter 6).



5.4 Look into the pad cavity from the rear of the caliper to inspect the rear pads (FZ600 shown; FJ600 and XJ600 similar)



6.1 If the rear brake shoe indicator pointer moves past the end of the "safe movement" area on the scale, the shoes are worn and should be replaced

- 3 Make sure all brake fasteners are tight. Check the brake pads (and rear shoes if equipped) for wear (see Section 5) and make sure the fluid level in the reservoirs is correct (see Section 3). Look for leaks at the hose connections and check for cracks in the hoses. If the