

Product: 1998 Yamaha XVS1100(L) Motorcycle Service Repair Workshop Manual
Full Download: <https://www.arepairmanual.com/downloads/1998-yamaha-xvs1100l-motorcycle-service-repair-workshop-manual/>



XVS1100(L) '99

5EL1-AE1

SERVICE MANUAL

Sample of manual. Download All 355 pages at:
<https://www.arepairmanual.com/downloads/1998-yamaha-xvs1100l-motorcycle-service-repair-workshop-manual/>

Product: 1998 Yamaha XVS1100(L) Motorcycle Service Repair Workshop Manual
Full Download: <https://www.arepairmanual.com/downloads/1998-yamaha-xvs1100l-motorcycle-service-repair-workshop-manual/>

EB000000

**XVS1100 (L)
SERVICE MANUAL**
©1998 by Yamaha Motor Co.,Ltd.
First edition, October 1998
All rights reserved. Any reproduction or
unauthorized use without the written
permission of Yamaha Motor Co., Ltd.
is expressly prohibited.

Sample of manual. Download All 355 pages at.

<https://www.arepairmanual.com/downloads/1998-yamaha-xvs1100l-motorcycle-service-repair-workshop-manual/>

NOTICE

This manual was produced by the Yamaha Motor Company primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual, so it is assumed that anyone who uses this book to perform maintenance and repairs on Yamaha motorcycles has a basic understanding of the mechanical ideas and the procedures of motorcycle repair. Repairs attempted by anyone without this knowledge are likely to render the motorcycle unsafe and unfit for use.

Yamaha Motor Company, Ltd. is continually striving to improve all its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

NOTE:

Designs and specifications are subject to change without notice.

IMPORTANT INFORMATION

Particularly important information is distinguished in this manual by the following notations.



The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!



Failure to follow WARNING instructions could result in severe injury or death to the motorcycle operator, a bystander or a person inspecting or repairing the motorcycle.

CAUTION:

A CAUTION indicates special precautions that must be taken to avoid damage to the motorcycle.

NOTE:

A NOTE provides key information to make procedures easier or clearer.

HOW TO USE THIS MANUAL

MANUAL ORGANIZATION

This manual consists of chapters for the main categories of subjects. (See “Illustrated symbols”)

- 1st title ①: This is the title of the chapter with its symbol in the upper right corner of each page.
- 2nd title ②: This title indicates the section of the chapter and only appears on the first page of each section. It is located in the upper right corner of the page.
- 3rd title ③: This title indicates a sub-section that is followed by step-by-step procedures accompanied by corresponding illustrations.

EXPLODED DIAGRAMS

To help identify parts and clarify procedure steps, there are exploded diagrams at the start of each removal and disassembly section.

- 1. An easy-to-see exploded diagram ④ is provided for removal and disassembly jobs.
- 2. Numbers ⑤ are given in the order of the jobs in the exploded diagram. A number that is enclosed by a circle indicates a disassembly step.
- 3. An explanation of jobs and notes is presented in an easy-to-read way by the use of symbol marks ⑥. The meanings of the symbol marks are given on the next page.
- 4. A job instruction chart ⑦ accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc.
- 5. For jobs requiring more information, the step-by-step format supplements ⑧ are given in addition to the exploded diagram and the job instruction chart.

CLUTCH ENG

CLUTCH CRANKCASE COVER (RIGHT)

⑤ → [Diagram part]

④ → [Diagram part]

⑦ → [Table]

| Order | Job name/Part name | Qty | Remarks |
|-------|---------------------------------|-----|--|
| | Crankcase cover (right) removal | | Remove the parts in the order below. Stand the motorcycle on a level surface. WARNING Securely support the motorcycle so there is no danger of it falling over. |
| | Engine oil | | Refer to "ENGINE OIL REPLACEMENT" in CHAPTER 3. |
| | Muffler assembly 1.2 | | Refer to "ENGINE REMOVAL". |
| 1 | Brake pedal link | 1 | |
| 2 | Oil filter cover plate | 1 | L=70 mm × 1, 65 mm × 1, 25 mm × 3 |
| 4 | Oil filter | 1 | |
| 5 | Crankcase cover (right) | 1 | L=65 mm × 1, 55 mm × 1, 45 mm × 4, 30 mm × 4 |

4-34

CLUTCH ENG

CLUTCH REMOVAL

- Straighten:
 - Lock washer tab
- Loosen:
 - Nut (clutch boss) ①

NOTE:
Loosen the nut (clutch boss) ① while holding the clutch boss ② with the clutch holding tool ③.

Clutch holding tool:
90890-04086

PRIMARY DRIVE GEAR REMOVAL

- Straighten:
 - Lock washer tab
- Loosen:
 - Nut (primary drive gear) ①

NOTE:
Place a copper plate ② between the teeth of the primary drive gear ③ and primary driven gear to lock them.

CLUTCH INSPECTION



- Inspect:
 - Friction plates
 - Wear/damage → Replace the friction plates as a set.
- Measure:
 - Friction plate thickness
 - Out of specification → Replace the friction plates as a set.
 - Measure at four places.

Thickness (friction plate):
2.9 – 3.1 mm
◀Wear limits▶ 2.6 mm

- Inspect:
 - Clutch plate
 - Damage → Replace the clutch plates as a set.
- Measure:
 - Clutch plate warpage
 - Out of specification → Replace the clutch plates as a set.
 - Use a surface plate and a feeler gauge ①.

Warp limit (clutch plate):
Less than 0.2 mm

4-38

| | | |
|--|--|---|
| ① GEN INFO  | ② SPEC  | |
| ③ INSP ADJ  | ④ ENG  | |
| ⑤ COOL  | ⑥ CARB  | |
| ⑦ CHAS  | ⑧ ELEC  | |
| ⑨ TRBL SHTG  | ⑩  | |
| ⑪  | ⑫  | |
| ⑬  | ⑭  | |
| ⑮  | ⑯  | ⑰  |
| ⑱  | ⑲  | ⑳  |
| ㉑  | ㉒  | ㉓  |
| ㉔  | ㉕ New | |

EB003000

ILLUSTRATED SYMBOLS

Illustrated symbols ① to ⑨ are printed on the top right of each page and indicate the subject of each chapter.

- ① General information
- ② Specifications
- ③ Periodic inspections and adjustments
- ④ Engine
- ⑤ Cooling system
- ⑥ Carburetion
- ⑦ Chassis
- ⑧ Electrical
- ⑨ Troubleshooting

Illustrated symbols ⑩ to ⑰ are used to identify the specifications appearing in the text.

- ⑩ Can be serviced with engine mounted
- ⑪ Filling fluid
- ⑫ Lubricant
- ⑬ Special tool
- ⑭ Torque
- ⑮ Wear limit, clearance
- ⑯ Engine speed
- ⑰ Ω, V, A

Illustrated symbols ⑱ to ㉓ in the exploded diagrams indicate the types of lubricants and lubrication points.


- ⑱ Apply engine oil
- ⑲ Apply gear oil
- ⑳ Apply molybdenum disulfide oil
- ㉑ Apply wheel bearing grease
- ㉒ Apply lightweight lithium-soap base grease
- ㉓ Apply molybdenum disulfide grease

Illustrated symbols ㉔ to ㉕ in the exploded diagrams indicate where to apply locking agent ㉔ and when to install new parts ㉕.

- ㉔ Apply locking agent (LOCTITE®)
- ㉕ Replace

CHAPTER TITLES

| | |
|--|---|
| GENERAL INFORMATION |  |
| | GEN INFO 1 |
| SPECIFICATIONS |  |
| | SPEC 2 |
| PERIODIC INSPECTION AND ADJUSTMENTS |  |
| | INSP ADJ 3 |
| ENGINE OVERHAUL |  |
| | ENG 4 |
| CARBURETION |  |
| | CARB 5 |
| CHASSIS |  |
| | CHAS 6 |
| ELECTRICAL |  |
| | ELEC 7 |
| TROUBLESHOOTING | ? |
| | TRBL SHTG 8 |




**GEN
INFO**

1

**CHAPTER 1.
GENERAL INFORMATION**

| | |
|---|-----|
| MOTORCYCLE IDENTIFICATION | 1-1 |
| VEHICLE IDENTIFICATION NUMBER | 1-1 |
| MODEL LABEL | 1-1 |
| | |
| IMPORTANT INFORMATION | 1-2 |
| PREPARATION FOR REMOVAL PROCEDURES | 1-2 |
| REPLACEMENT PARTS | 1-2 |
| GASKETS, OIL SEALS AND O-RINGS | 1-2 |
| LOCK WASHERS/PLATES AND COTTER PINS | 1-3 |
| BEARINGS AND OIL SEALS | 1-3 |
| CIRCLIPS | 1-3 |
| | |
| CHECKING OF CONNECTIONS | 1-4 |
| | |
| SPECIAL TOOLS | 1-5 |




EB100000

GENERAL INFORMATION MOTORCYCLE IDENTIFICATION

EB100010



VEHICLE IDENTIFICATION NUMBER

The vehicle identification number ① is stamped into the right side of the steering head.



MODEL LABEL


The model label ① is affixed to the frame. This information will be needed to order spare parts.



EB101000

IMPORTANT INFORMATION PREPARATION FOR REMOVAL PROCEDURES

1. Remove all dirt, mud, dust and foreign material before removal and disassembly.
2. Use proper tools and cleaning equipment. Refer to the "SPECIAL TOOLS" section.
3. When disassembling the machine, always keep mated parts together. This includes gears, cylinders, pistons and other parts that have been "mated" through normal wear. Mated parts must always be reused or replaced as an assembly.
4. During machine disassembly, clean all parts and place them in trays in the order of disassembly. This will speed up assembly and allow for the correct installation of all parts.
5. Keep all parts away from any source of fire.



EB101010


REPLACEMENT PARTS

1. Use only genuine Yamaha parts for all replacements. Use oil and grease recommended by Yamaha for all lubrication jobs. Other brands may be similar in function and appearance, but inferior in quality.

EB101020

GASKETS, OIL SEALS AND O-RINGS


1. Replace all gaskets, seals and O-rings when overhauling the engine. All gasket surfaces, oil seal lips and O-rings must be cleaned.
2. Properly oil all mating parts and bearings during reassembly. Apply grease to the oil seal lips.



EB101030

LOCK WASHERS/PLATES AND COTTER PINS

1. Replace all lock washers/plates ① and cotter pins after removal. Bend lock tabs along the bolt or nut flats after the bolt or nut has been tightened to specification.



EB101040


BEARINGS AND OIL SEALS

1. Install bearings and oil seals so that the manufacturer's marks or numbers are visible. When installing oil seals, apply a light coating of lightweight lithium base grease to the seal lips. Oil bearings liberally when installing, if appropriate.


- ① Oil seal

CAUTION: _____

Do not use compressed air to spin the bearings dry. This will damage the bearing surfaces.



- ① Bearing







EB101050

CIRCLIPS

1. Check all circlips carefully before reassembly. Always replace piston pin clips after one use. Replace distorted circlips. When installing a circlip ①, make sure that the sharp-edged corner ② is positioned opposite the thrust ③ it receives. See sectional view.

- ④ Shaft



EB801000

CHECKING OF CONNECTIONS

Check the connectors for stains, rust, moisture, etc.

1. Disconnect:
 - Connector
2. Check:
 - Connector
 - Moisture → Dry each terminal with an air blower.
 - Stains/rust → Connect and disconnect the terminals several times.
3. Check:
 - Connector leads
 - Looseness → Bend up the pin ① and connect the terminals.

4. Connect:
 - Connector terminals

NOTE: _____
 The two terminals “click” together.

5. Check:
 - Continuity (using a pocket tester)

NOTE: _____
 ◦ If there is no continuity, clean the terminals.
 ◦ When checking the wire harness be sure to perform steps 1 to 3.
 ◦ As a quick remedy, use a contact revitalizer available at most part stores.
 ◦ Check the connector with a pocket tester as shown.









EB102001

SPECIAL TOOLS

The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools; this will help prevent damage caused by the use of inappropriate tools or improvised techniques. Special tools may differ by shape and part number from country to country. In such a case, two types are provided.








When placing an order, refer to the list provided below to avoid any mistakes.

| Tool No. | Tool name/How to use | Illustration |
|--|--|---|
| Weight 90890-01084 Bolt 90890-01085 | Slide hammer bolt/weight These tools are used to remove the rocker arm shaft. |  |
| 90890-01135 | Crankcase separating tool This tool is used to remove the crankshaft. |  |
| 90890-01229 | Coupling gear/Middle shaft tool This tool is needed when removing or installing the final pinion shaft nut. |  |
| Final gear backlash band 90890-01230 Middle gear backlash band 90890-01231 | Final gear backlash band This tool is needed when measuring final gear /middle gear backlash. |  |
| Installer pot 90890-01274 Bolt 90890-01275 Adaptor 90890-04130 Spacer 90890-04060 | Crankshaft installer pot/bolt/adaptor/spacer These tools are used to install the crankshaft. |  |
| 90890-01304 | Piston pin puller This tool is used to remove the piston pin. |  |
| 90890-01312 | Fuel level gauge This gauge is used to measure the fuel level in the float chamber. |  |










SPECIAL TOOLS

**GEN
INFO**






| Tool No. | Tool name/How to use | Illustration |
|---|--|---|
| T-handle 90890-01326 Holder 90890-01460 | T-handle/damper rod holder These tools are needed to loosen and tighten the damper rod holding bolt. |  |
| Puller 90890-01362 Adapter 90890-04131 | Flywheel puller/adaptor These tools are needed to remove the rotor. |  |
| Weight 90890-01367 Adapter 90890-01381 | Fork seal driver weight/adaptor These tools are needed when installing the slide metal, oil seal and dust seal into the fork. |  |
| Ring nut wrench 90890-01403 Exhaust nut wrench 90890-01268 | Ring nut wrench/exhaust and steering nut wrench This tool is needed to loosen and tighten the steering stem ring nut. |  |
| 90890-01701 | Sheave holder This tool is needed to hold the rotor when removing or installing the rotor bolt. |  |
| 90890-03081 | Compression gauge set These tools are needed to measure engine compression. |  |
| 90890-03094 | Vacuum gauge This gauge is needed for carburetor synchronization. |  |
| 90890-03112 | Pocket tester This instrument is needed for checking the electrical system. |  |
| 90890-03113 | Engine tachometer This tool is needed for observing engine r/min. |  |



| Tool No. | Tool name/How to use | Illustration |
|--|--|---|
| 90890-03141 | <p>Timing light</p> <p>This tool is necessary for checking ignition timing.</p> |  |
| 90890-04014 | <p>Valve guide remover & installer</p> <p>This tool is needed to remove and install the valve guide.</p> |  |
| 90890-04019 | <p>Valve spring compressor</p> <p>This tool is needed to remove and install the valve assemblies.</p> |  |
| <p>Adapter 90890-01277 Shock puller 90890-01290 Weight 90890-01291</p> | <p>Crankshaft installer bolt adapter/armature shock puller/weight</p> <p>These tools are needed when removing the final pinion shaft.</p> |  |
| 90890-04137 | <p>Bearing retainer wrench</p> <p>This tool is needed when removing or installing the middle drive shaft assembly.</p> |  |
| <p>Wrench 90890-04138 Holder 90890-04055</p> | <p>Middle drive shaft nut wrench/Middle drive shaft holder</p> <p>These tools are needed when removing or installing the middle drive shaft bearing.</p> |  |
| 90890-04062 | <p>Universal joint holder</p> <p>This tool is needed when removing or installing the driven pinion gear nut.</p> |  |
| 90890-04077 | <p>Bearing retainer wrench</p> <p>This tool is needed when removing or installing the final drive pinion gear assembly.</p> |  |
| 90890-04086 | <p>Clutch holding tool</p> <p>This tool is needed to hold the clutch when removing or installing the clutch boss nut.</p> |  |

SPECIAL TOOLS



| Tool No. | Tool name/How to use | Illustration |
|-------------|---|---|
| 90890-04090 | <p>Damper spring compressor</p> <p>This tool is needed when removing or installing the damper spring.</p> |  |
| 90890-06754 | <p>Dynamic spark tester Ignition checker</p> <p>This instrument is necessary for checking the ignition system components.</p> |  |
| 90890-85505 | <p>Yamaha bond No.1215</p> <p>This sealant (bond) is used on crankcase mating surfaces, etc.</p> |  |



SPEC

2



CHAPTER 2. SPECIFICATIONS

| | |
|---|------|
| GENERAL SPECIFICATIONS | 2-1 |
| MAINTENANCE SPECIFICATIONS | 2-4 |
| ENGINE | 2-4 |
| CHASSIS | 2-14 |
| ELECTRICAL | 2-18 |
| GENERAL TORQUE SPECIFICATIONS | 2-20 |
| CONVERSION TABLE | 2-20 |
| LUBRICATION POINTS AND LUBRICANT TYPES | 2-21 |
| ENGINE | 2-21 |
| CHASSIS | 2-22 |
| LUBRICATION DIAGRAMS | 2-23 |
| CABLE ROUTING | 2-26 |



SPECIFICATIONS

GENERAL SPECIFICATIONS

| Item | Standard |
|---|--|
| Model code: | XVS1100: 5EL1 (For Europe) 5EL2 (For D, A, FIN) 5EL3 (For Australia) |
| Dimensions: Overall length Overall width Overall height Seat height Wheelbase Minimum ground clearance Minimum turning radius | 2,405 mm 895 mm 1,095 mm 690 mm 1,640 mm 145 mm 3,200 mm |
| Basic weight: With oil and a full fuel tank | 274 kg (5EL2 : 275kg) |
| Engine: Engine type Cylinder arrangement Displacement Bore × stroke Compression ratio Compression pressure (STD) Starting system | Air cooled 4-stroke, SOHC V-type 2-cylinder 1.063 L 95 × 75mm 8.3 : 1 1,000 kPa (10 kg/cm ² , 10 bar) at 400 r/min Electric starter |
| Lubrication system: | Wet sump |
| Oil type or grade: Engine oil Temp. °C -20 -10 0 10 20 30 40 10W/30 10W/40 20W/40 20W/50 | API standard: "SE" or higher grade ACEA standard: G4 or G5 |
| Final gear oil: | SAE80API "GL-4" Hypoid Gear Oil |
| Oil quantity: Engine oil Periodic oil change With oil filter replacement Total amount Final gear case oil Total amount | 3.0 L 3.1 L 3.6 L 0.2 L |
| Air filter: | Dry type element |
| Fuel: Type Fuel tank capacity Fuel reserve amount | Regular unleaded gasoline 17 L 4.5 L |

GENERAL SPECIFICATIONS

SPEC



| Item | Standard |
|---|---|
| Carburetor: Type/quantity Manufacturer | BSR37/2 MIKUNI |
| Spark plug: Type Manufacturer Spark plug gap | BPR7ES/W22EPR-U NGK/DENSO 0.7 ~ 0.8 mm |
| Clutch type: | Wet, multiple-disc |
| Transmission: Primary reduction system Primary reduction ratio Secondary reduction system Secondary reduction ratio Transmission type Operation Gear ratio 1st 2nd 3rd 4th 5th | Spur gear 78/47 (1.660) Shaft drive 44/47 × 19/18 × 32/11 (2.875) Constant mesh 5-speed Left foot operation 40/17 (2.353) 40/24 (1.667) 36/28 (1.286) 32/31 (1.032) 29/34 (0.853) |
| Chassis: Frame type Caster angle Trail | Double cradle 33° 136 mm |
| Tire: Type Size front rear Manufacturer front rear Type front rear | With tube 110/90-18 61S 170/80-15M/C 77S BRIDGESTONE/DUNLOP BRIDGESTONE/DUNLOP EXEDRA L309/K555F EXEDRA G546/K555 |
| Maximum load-except motorcycle: | 201 kg (5EL2 : 200kg) |
| Tire pressure (cold tire): 0 ~ 90 kg (0 ~ 198 lb) load * front rear 90 kg (198 lb) ~ Maximum load * front rear | 200 kPa (2.00 kg/cm ²) 225 kPa (2.25 kg/cm ²) 225 kPa (2.25 kg/cm ²) 250 kPa (2.50 kg/cm ²) * Load is the total weight of the cargo, rider, passenger and accessories. |
| Brake: Front brake type operation Rear brake type operation | Dual disc brake Right hand operation Single disc brake Right foot operation |

GENERAL SPECIFICATIONS





SPEC



| Item | Standard |
|--|--|
| Suspension: Front suspension Rear suspension | Telescopic fork Swingarm (link suspension) |
| Shock absorber: Front shock absorber Rear shock absorber | Coil spring/Oil damper Coil spring/Gas-oil damper |
| Wheel travel: Front wheel travel Rear wheel travel | 140 mm 113 mm |
| Electrical: Ignition system Generator system Battery type Battery capacity | T.C.I. (digital) A.C. magneto GT14B-4 12 V 12 AH |
| Headlight type: | Quartz bulb (halogen) |
| Bulb wattage × quantity: Headlight Auxiliary light Tail/brake light Turn signal Licence light Meter light Neutral indicator light High beam indicator light Turn indicator light Oil level caution light Engine warning light | 12 V 60 W/55 W × 1 12 V 4 W × 1 12 V 5 W/21 W × 1 12 V 21 W × 4 12 V 5 W × 1 14 V 1.4 W × 2 12 V 1.7 W × 1 12 V 1.7 W × 1 12 V 1.7 W × 1 12 V 1.7 W × 1 |

MAINTENANCE SPECIFICATIONS




SPEC


| Item | Standard | Limit | |
|---|---|--|---------|
| Timing chain: Timing chain type/No. of links Timing chain adjustment method | SILENT CHAIN/98L Automatic | | |
| Rocker arm/rocker arm shaft: Bearing inside diameter Shaft outside diameter Arm-to-shaft clearance | 14.000 mm ~ 14.018 mm 13.985 mm ~ 13.991 mm 0.009 mm ~ 0.033 mm | 14.036 mm 13.95 mm 0.086 mm | |
| Valve, valve seat, valve guide: Valve clearance (cold) IN EX | 0.07 ~ 0.12 mm 0.12 ~ 0.17 mm | | |
| Valve dimensions: | | | |
|  |  |  | |
| Head Dia | Face width | Seat Width | |
|  | | Margin Thickness | |
| "A" head diameter | IN | 47.0 ~ 47.2 mm | ... |
| | EX | 39.0 ~ 39.2 mm | ... |
| "B" face width | IN | 2.1 mm | ... |
| | EX | 2.1 mm | ... |
| "C" seat width | IN | 1.2 ~ 1.4 mm | 1.8 mm |
| | EX | 1.2 ~ 1.4 mm | 1.8 mm |
| "D" margin thickness | IN | 1.1 ~ 1.5 mm | 0.8 mm |
| | EX | 1.1 ~ 1.5 mm | 0.8 mm |
| Stem outside diameter | IN | 7.975 ~ 7.990 mm | ... |
| | EX | 7.960 ~ 7.975 mm | ... |
| Guide inside diameter | IN | 8.000 ~ 8.012 mm | ... |
| | EX | 8.000 ~ 8.012 mm | ... |
| Stem-to-guide clearance | IN | 0.010 ~ 0.037 mm | 0.08 mm |
| | EX | 0.025 ~ 0.052 mm | 0.10 mm |

MAINTENANCE SPECIFICATIONS

SPEC







| Item | Standard | Limit |
|--|--|--|
| Stem runout limit  | ••• | 0.03 mm |
| Valve seat width IN EX | 1.2 ~ 1.4 mm 1.2 ~ 1.4 mm | 2.0 mm 2.0 mm |
| Valve spring: Free length IN EX Set length (valve closed) IN EX Compressed pressure (installed) IN EX Tilt limit * IN EX  | 44.6 mm 44.6 mm 40 mm 40 mm 160.7 N (16.4 kg) 160.7 N (16.4 kg) ••• ••• | 43.5 mm 43.5 mm ••• ••• ••• ••• 2.5°/1.9mm 2.5°/1.9mm |
| Direction of winding (top view) IN EX | Clockwise Clockwise | ••• ••• |
| Piston: Piston to cylinder clearance Piston size "D"  | 0.025 ~ 0.050 mm 94.960 ~ 94.975 mm | 0.15 mm ••• |
| Measuring point "H" Piston off-set | 5 mm 0 mm | ••• ••• |

MAINTENANCE SPECIFICATIONS

SPEC



| Item | Standard | Limit |
|---|--|--------------------------------|
| Piston pin bore inside diameter Piston pin outside diameter | 22.004 ~ 22.015 mm 21.991 ~ 22.000 mm | |
| Piston rings: Top ring: <div style="text-align: center; margin: 5px 0;">  </div> Type Dimensions (B × T) End gap (installed) Side clearance (installed) | Plain 1.5 × 3.8 mm 0.3 ~ 0.5 mm 0.04 ~ 0.08 mm | 0.8 mm 0.1 mm |
| 2nd ring: <div style="text-align: center; margin: 5px 0;">  </div> Type Dimensions (B × T) End gap (installed) Side clearance | Taper 1.2 × 3.8 mm 0.30 ~ 0.45 mm 0.03 ~ 0.07 mm | 0.8 mm 0.1 mm |
| Oil ring: <div style="text-align: center; margin: 5px 0;">  </div> Dimensions (B × T) End gap (installed) | 2.5 × 3.4 mm 0.2 ~ 0.7 mm | |
| Connecting rod: Oil clearance Color code (corresponding size) | 0.044 ~ 0.073 mm ①Blue ② Black ③ Brown ④ Green ⑤ Yellow | |
| Crankshaft: <div style="text-align: center; margin: 5px 0;">  </div> Crank width "A" Runout limit "C" Big end side clearance "D" | 101.95 ~ 102.00 mm ... 0.320 ~ 0.474 mm | ... 0.02 mm ... |

MAINTENANCE SPECIFICATIONS

SPEC



| Item | Standard | Limit |
|---------------------------------|------------------------------------|---------|
| Clutch: | | |
| Friction plate thickness | 2.9 ~ 3.1 mm | 2.8 mm |
| Quantity | 8 | ••• |
| Clutch plate thickness | 2.5 ~ 2.7 mm | 0.1 mm |
| Quantity | 1 | ••• |
| Clutch plate thickness | 1.9 ~ 2.1 mm | 0.1 mm |
| Quantity | 7 | ••• |
| Clutch spring free length | 7.2 mm | 6.5 mm |
| Quantity | 1 | ••• |
| Clutch housing thrust clearance | 0.05 ~ 0.40 mm | ••• |
| Clutch housing radial clearance | 0.010 ~ 0.044 mm | ••• |
| Clutch release method | Inner push, screw push | ••• |
| Push rod bending limit | ••• | 0.5 mm |
| Transmission: | | |
| Main axle deflection limit | ••• | 0.08 mm |
| Drive axle deflection limit | ••• | 0.08 mm |
| Shifter: | | |
| Shifter type | Guide bar | ••• |
| Carburetor: | | |
| I. D. mark | 5EL1 00 | ••• |
| Main jet (M.J) | #1: #110, #2: #112.5 | ••• |
| Main air jet (M.A.J) | #55 | ••• |
| Jet needle (J.N) | #1: 5DL39-53-3/5, #2: 5DL40-53-3/5 | ••• |
| Needle jet (N.J) | P-0M | ••• |
| Pilot air jet (P.A.J.1) | #63.8 | ••• |
| (P.A.J.2) | #145 | ••• |
| Pilot outlet (P.O) | 1.0 | ••• |
| Pilot jet (P.J) | #17.5 | ••• |
| Bypass 1 (B.P.1) | 0.8 | ••• |
| Bypass 2 (B.P.2) | 0.8 | ••• |
| Bypass 3 (B.P.3) | 0.8 | ••• |
| Pilot screw (P.S) | 3 | ••• |
| Valve seat size (V.S) | 1.2 | ••• |
| Starter jet (G.S.1) | #42.5 | ••• |
| Starter jet (G.S.2) | 0.8 | ••• |
| Throttle valve size (Th.V) | #125 | ••• |
| Fuel level (F.L) | 4~5 mm | ••• |
| Engine idle speed | 950 ~ 1,050 r/min | ••• |
| Intake vacuum | 34.7 ~ 37.3 kPa (260 ~ 280 mmHg) | ••• |
| Engine oil temperature | 75 ~ 85°C | ••• |
| Fuel pump: | | |
| Type | Electrical type | ••• |
| Model/manufacturer | UC-Z6M/MITSUBISHI | ••• |
| Consumption amperage <max> | 0.8 A | ••• |
| Output pressure | 12 kPa (0.12 kg/cm ²) | ••• |

MAINTENANCE SPECIFICATIONS

SPEC




| Item | Standard | Limit |
|---------------------------------|---|---------|
| Lubrication system: | | |
| Oil filter type | Paper type | ••• |
| Oil pump type | Trochoid type | ••• |
| Tip clearance "A" or "B" | 0.03 ~ 0.09 mm | 0.15 mm |
| Side clearance | 0.03 ~ 0.08 mm | 0.15 mm |
| Relief valve operating pressure | 450 ~ 550 kPa (4.5 ~ 5.5 kg/cm ²) | ••• |
| Shaft drive: | | |
| Middle gear backlash | 0.1 ~ 0.2 mm | ••• |
| Final gear backlash | 0.1 ~ 0.2 mm | ••• |







Cylinder head tightening sequence:



Crankcase tightening sequence:



Left crankcase



Right crankcase

MAINTENANCE SPECIFICATIONS



Tightening torques

| Part to be tightened | Part name | Thread size | Q'ty | Tightening torque | | Remarks |
|---|------------|-------------|------|-------------------|------|--|
| | | | | Nm | m•kg | |
| Cylinder head | Nut | M12 | 8 | 50 | 5.0 |  Use lock washer |
| Cylinder head | Nut | M10 | 2 | 35 | 3.5 | |
| Plate | Bolt | M8 | 2 | 20 | 2.0 | |
| Cylinder head cover | Screw | M6 | 4 | 4 | 0.4 | |
| Cylinder head (exhaust pipe) | Stud bolt | M8 | 4 | 12.5 | 1.25 | |
| Rocker arm shaft | Union bolt | M16 | 2 | 37.5 | 3.75 | |
| Camshaft sprocket cover | Bolt | M6 | 4 | 10 | 1.0 | |
| Tappet cover | Bolt | M6 | 8 | 10 | 1.0 | |
| Rocker arm shaft (oil passage) | Bolt | M16 | 4 | 38 | 3.8 | |
| Stopper plate (camshaft) | Bolt | M8 | 4 | 20 | 2.0 | |
| Spark plug | — | M14 | 2 | 20 | 2.0 | |
| Cylinder | Bolt | M6 | 2 | 10 | 1.0 | |
| Lower cylinder head cover | Bolt | M6 | 6 | 10 | 1.0 | |
| Upper cylinder head cover | Screw | M6 | 8 | 5 | 0.5 |  Use lock washer |
| Connecting rod | Nut | M9 | 4 | 48 | 4.8 | |
| Rotor | Nut | M16 | 1 | 175 | 17.5 | |
| Valve adjusting locknut | Nut | M8 | 4 | 27 | 2.7 | |
| Camshaft sprocket | Bolt | M10 | 2 | 55 | 5.5 | |
| Timing chain tensioner | Bolt | M6 | 4 | 10 | 1.0 | |
| Timing chain tensioner cap | Bolt | M6 | 2 | 8 | 0.8 | |
| Timing chain guide | Bolt | M6 | 4 | 10 | 1.0 | |
| Oil pump | Bolt | M6 | 3 | 10 | 1.0 | |
| Oil strainer cover | Bolt | M6 | 3 | 10 | 1.0 | |
| Oil filter cover | Bolt | M6 | 5 | 10 | 1.0 | |
| Oil pump gear | Bolt | M6 | 1 | 12 | 1.2 | |
| Oil pump cap | Bolt | M6 | 1 | 10 | 1.0 | |
| Oil deliuey pipe (cylinder head) | Union bolt | M16 | 2 | 20 | 2.0 | |
| (crankcase) | Union bolt | M10 | 1 | 20 | 2.0 | |
| Drain bolt | — | M14 | 1 | 43 | 4.3 | |
| Carburetor cover | Bolt | M5 | 2 | 7 | 0.7 | |
| Air filter case stay | Bolt | M6 | 2 | 10 | 1.0 | |
| Air filter case assembly | Bolt | M5 | 3 | 2 | 0.2 | |
| Exhaust pipe joint and cylinder head | Nut | M8 | 4 | 20 | 2.0 | |
| Exhaust pipe joint and muffler assembly | Bolt | M8 | 2 | 20 | 2.0 | |
| Muffler | Bolt | M10 | 2 | 25 | 2.5 | |
| Crankcase (cylinder) | Stud bolt | M12 | 8 | 24 | 2.4 |  Use lock washer |
| Crankcase (cylinder) | Stud bolt | M10 | 2 | 20 | 2.0 | |
| Crankcase | Bolt | M10 | 3 | 38.5 | 3.85 | |
| Crankcase | Bolt | M6 | 10 | 10 | 1.0 | |
| Bearing retainer (middle drive pinion gear) | Bolt | M8 | 3 | 25 | 2.5 | |
| Crankcase cover (left) | Bolt | M6 | 13 | 10 | 1.0 | |
| Crankcase cover (right) | Bolt | M6 | 11 | 10 | 1.0 | |
| Clamp | Bolt | M6 | 1 | 10 | 1.0 | |
| One-way clutch | Bolt | M6 | 8 | 12 | 1.2 | |
| Primary drive gear | Nut | M20 | 1 | 110 | 11.0 | |