

# SERVICE MANUAL

## Crawler Dozer D350

Print No. 84568077A



Product: New Holland D350 Crawler Dozer  
Full Download: <https://www.arepairmanual.com/new-holland-d350-crawler-dozer-service-repair-workshop-manual>

# SERVICE MANUAL

## Crawler Dozer D350

Print No. 84568077A



**NEW HOLLAND**

**CONSTRUCTION**

Sample of manual. Download All 354 pages  
<https://www.arepairmanual.com/download>

---

# D350

## CRAWLER DOZER

# Service Manual

Print No. 84568077A English



THIS ALERT SYMBOL SIGNALS IMPORTANT MESSAGES INVOLVING YOUR SAFETY.

Read and heed carefully the safety instructions listed and follow the precautions recommended to avoid potential risks and to safeguard your health and your safety.

You will find this symbol in the text of this Manual referred to the following key words:

**WARNING** - Cautions directed to avoid improper repair interventions involving potential consequences for the safety of the personnel performing the repairs.

**DANGER** - These warnings qualify specifically potential dangers for the safety of the operator or other persons directly or indirectly involved.

### IMPORTANT NOTICE

All maintenance and repair interventions explained in this Manual **must be performed exclusively by the Service Organisation of the Manufacturer**, observing strictly the instructions explained using, whenever necessary, the recommended specific tools.

Whoever performs the operations reported without following exactly the precautions is responsible on his own, for the damages that may result.

Neither the Factory nor any Organisations in its Distribution Network, including but not limited to national, regional or local distributors, are responsible for any liability arising from any damage resulting from defects caused by parts and/or components not approved by the Factory for use in maintaining and/or repairing products manufactured or merchandised by the Factory.

In any case, no warranty of any kind is made or shall be imposed with respect to products manufactured or merchandised by the Factory, when failures are caused by the use of parts and/or components not approved by the Factory.

---

---

## AVOID ACCIDENTS

Most accidents, whether they occur in industry, on the farm, at home or on the road, are caused by the failure of some individuals to follow simple and fundamental safety rules and precautions. For this reason **MOST ACCIDENTS CAN BE PREVENTED** by recognising the real cause and doing something about it before the accident occurs.

Regardless of the care used in the design and construction of any type of equipment, there are many conditions that cannot be completely safeguarded against without interfering in the reasonable accessibility and efficient operation.

A careful operator is the best insurance against an accident. The complete observance of one simple rule would prevent many serious accidents.

The rule is simple: never attempt to clean, lubricate or maintain a machine while it is in motion.



### **WARNING**

**Prior to engaging in any maintenance, adjustment or repair operation on machines having hydraulically, mechanically, and/or cable controlled equipment (such as shovels, loaders, dozers, excavators etc.) be certain the equipment is lowered to the ground.**


**If it is necessary to have the equipment partially or fully raised to gain access to certain items, be sure the equipment is suitably supported by means other than the devices used for controlling the equipment.**

---

---

# SUMMARY

<b>GENERALITIES</b>	<b>SECT. 0</b>
<b>ENGINE</b>	<b>SECT. 1</b>
<b>TRANSMISSION</b>	<b>SECT. 2</b>
<b>FINAL DRIVES</b>	<b>SECT. 3</b>
<b>BRAKES AND STEERING DIFFERENTIAL</b>	<b>SECT. 4</b>
<b>UNDERCARRIAGE</b>	<b>SECT. 5</b>
<b>DOZING EQUIPMENT</b>	
<b>HYDRAULIC SYSTEM</b>	<b>SECT. 6</b>
<b>ELECTRICAL SYSTEM</b>	<b>SECT. 7</b>





**SECTION 0**  
**GENERALITIES**

**TABLE OF CONTENTS**

SUBJECT	PAGE
SAFETY RULES .....	III-X
TABLE OF TECHNICAL DATA .....	
Identification data .....	0-3
Table of capacities .....	0-4
Main dimensions D350 .....	0-5
Specifications D350 .....	0-6
CONTROL DATA ON THE MACHINE .....	0-19
LIST OF WEIGHTS FOR MAIN SERVICE COMPONENTS .....	0-20
STABILITY .....	0-21
GENERAL INSTRUCTIONS .....	0-22
TROUBLESHOOTING .....	0-26
UNITS OF MEASURE .....	0-27
TABLE OF TIGHTENING TORQUES .....	0-29



## **WARNING**

**Study carefully this Manual before starting, operating, maintaining, fuelling or servicing the machine.**

**Read and heed all safety rules before any intervention.**

### **SAFETY RULES**

- Do not allow unauthorised personnel to operate service or maintain this machine.
- Do not wear rings, wrist watches, jewellery, loose or hanging apparels, such as ties, torn clothing, scarves, unbuttoned or unzipped jackets that can catch on moving parts. Wear proper safety equipment as recommended for the job. Examples: hard hat, heavy gloves, ear protection, safety glasses or goggles, reflector vests, respirator. Consult your employer for specific safety equipment requirements.
- Keep operator's compartment, stepping points, grab-rails and handles clear of foreign objects, oil, grease, mud or snow accumulation to minimise the danger of slipping or stumbling. Clean mud or grease from shoes before attempting to mount or operate the machine.
- Do not jump on or off the machine. Keep two hands and one foot, or two feet and one hand in contact with step grab rails and handles at all times.
- Do not use controls or hoses as hand holds when climbing on or off machine. Hoses and controls are movable and do not provide a solid support. Also, controls may be inadvertently moved causing accidental machine or equipment movement.
- Never attempt to operate the machine or its tools from any position other than seated in the operator's seat.
- Keep head, body, limbs, hands and feet inside operator's compartment at all times, to reduce exposure to hazards outside the operator's compartment.
- Be careful of slippery conditions on stepping points, hand rails, and on the ground. Wear safety boots or shoes that have a high slip resistant sole material.
- Do not leave the machine until it is completely stopped.
- Check the seat safety belt at least twice a year. If there are signs of wear or fraying or other signs of weakness that could lead to failure, replace it.
- Check brakes, steering and attachment controls before moving. Advise the proper maintenance authority of any malfunctioning part or system.
- Be sure all protective guards or panels are in place, and all safety devices provided are in place and in good operating conditions.
- Be sure exposed personnel in the area of operation are clear of the machine before moving it or its attachments. **WALK COMPLETELY AROUND** the machine before mounting. Sound horn.
- Before starting machine, check, adjust and lock the operator's seat for maximum comfort and control of the machine.
- Fasten your seat belt (when provided).
- Obey all flag signals and signs.
- Due to the presence on the machine of flammable fluids, never check or fill fuel reservoirs or batteries near open flames, smoking materials or sparks.
- **REMEMBER THAT STARTING FLUID IS FLAMMABLE.** Follow strictly the recommendations printed on containers and in the Operation and Maintenance Manual.
- **DO NOT PUNCTURE OR BURN CONTAINERS.**
- Containers must be stored in fresh, well ventilated places, out of reach of unauthorised persons. Follow strictly the instructions provided by the Manufacturer.
- Never use these products near open flames, smoking materials or sparks.

### **STARTING**

- **NEVER START NOR OPERATE AN UNSAFE MACHINE.** Before operating a machine, always ensure that any unsafe condition has been satisfactorily remedied.

### **OPERATION**

- Do not run the engine of this machine in closed areas without proper ventilation to remove deadly exhaust gases.
- Roll Over Protective Structures are required on loaders, dozers, graders, excavators. **NEVER OPERATE** machines without ROPS.
- Make sure the Operator's compartment is free of foreign objects, especially if not firmly secured. Never use the machine to transport objects, unless proper securing points are provided.

## SAFETY RULES

- Check monitoring instruments at start-up and frequently during operations. In case the brake pressure gauge shows a pressure lower than the minimum operating pressure, stop immediately the machine .
- DO NOT CARRY RIDERS ON MACHINE
- Study and familiarise with escape routes alternate to normal exit routes.
- Seat belts are required by current regulations to be provided with Roll Over Protection Structures or cabs. Keep safety belts fastened around you during operation.
- For your personal protection, do not climb on or off machine while machine is in motion.
- Make sure that exposed persons in the area of operation are clear of the machine, before starting the engine and operating the equipment. Sound horn. Obey all indications provided by flags and signals.
- NEVER COAST the machine down grades and slopes with the transmission in neutral or neutralised.  
  
Choose and shift into the most appropriate gear to keep the speed required, thus preventing any loss of control.
- Do not operate machinery in a condition of extreme fatigue or illness. Be especially careful towards the end of working shift.
- Do not operate machine with brakes out of adjustment.
- Operate the machine at speeds slow enough to ensure complete control at all times.
- Travel slowly over rough terrain, on slopes or near drop-offs, in congested areas or on ice or slippery surfaces.
- When backing, always look to where the machine is to be moved. Be alert to the position of exposed personnel. DO NOT OPERATE if exposed personnel enter the immediate work area. STOP THE MACHINE.
- Maintain a safe distance from other machines. Provide sufficient clearance for ground and visibility conditions. Yield right-of-way to loaded machines.
- Maintain clear vision of areas of travel or work. Keep cab windows clean and repaired.
- When machines are operating in tandem, the pusher (rear) must be equipped with the appropriate deflectors to protect the unit in front from the air stream coming from the radiator.
- When pulling or towing through a cable or chain, do not start suddenly at full throttle; take-up slack carefully.  
  
Inspect carefully for flaws or troubles before using.
- Avoid kinking chains or cables. Do not pull through a kinked chain or cable to the high stresses and possibility of failure of the kinked area. Always wear heavy gloves when handling chains or cables.
- Be sure chains and cables are anchored and the anchor points are strong enough to handle the expected load. Keep exposed personnel clear of anchor points and cables or chains.
- DO NOT PULL UNLESS OPERATOR'S COMPARTMENT OF MACHINES INVOLVED ARE PROPERLY GUARDED AGAINST POTENTIAL CABLE OR CHAIN BACKLASH.
- Be alert to soft ground conditions close to newly constructed walls. The fill material and weight of the machine may cause the wall collapse under the machine.
- In darkness, check area of operation carefully before moving in with machine. Use all lights provided. Do not move into area of restricted visibility.
- If engine has a tendency to stall for any reason under load or idle, report this for adjustment to proper maintenance authority immediately. Do not continue to operate machine, until condition has been corrected.
- On machines supplied with suction radiator fans, be sure to periodically check engine exhaust parts for leaks, as exhaust fumes are dangerous to the operator.
- In case of closed type cabs, always keep an opening with the outside, to ensure a constant air circulation.
- Operators must know thoroughly the performances of the machine they are operating. When working on slopes or near sudden level drops of the terrain, avoid areas where ground is loose or soft since rolling-over or loss of control of machine could result.
- Where noise exposure exceeds 90 dBA for 8 hours, wear approved ear protection.
- When counterweights are provided, do not work machine if they have been removed.
- Overtaking manoeuvres must be performed only when absolutely necessary and unavoidable. Beware of possible uneven terrains, poor visibility conditions, the presence of other machinery or persons out of sight.
- Operate the machine at a speed adequate to the working conditions in the site and slow enough to ensure complete control at all times.
- Never use the machine as a work platform or scaffolding, nor other inappropriate operations (i.e. pushing railway cars, trucks or other machines).

## SAFETY RULES

- Be alert of people in the operating area of the machine.
- When operating a machine, know in advance what clearances will be encountered, overhead doors, cables, pipes, bearing load limitations of ground, bridges, floors or ramps.
- When roading, find-out what conditions are likely to be encountered, clearances, traffic congestion, type of road surfacing, etc. Beware of fog, smoke or dust elements that obscure visibility.
- When crossing gullies or ditches, move at an angle with reduced speed after ensuring ground conditions will permit a safe traverse.
- Explore the working area to identify potential risks such as: slopes, overhangs, pits, demolition rubble, fires, ravines, ditches, soft terrain, heavy traffic, crowded parking areas, closed ambients. In such conditions, proceed with extreme care.
- Whenever possible, avoid going over obstacles such as rough terrain, rocks, logs highly irregular ground, steps, ditches, railroad tracks. When obstructions must be crossed, do so with extreme care at an angle, if possible. Reduce speed, shift-down. Ease up to the break over point, pass the balance point slowly on the obstruction and ease down on the other side.
- In steep down-hill operation, do not allow engine to over-speed. Select proper gear before starting down grade.
- Avoid side hill travel, whenever possible. Drive up and down the slope. Should the machine slipping sideways, turn it immediately downhill.
- The grade of slope you should attempt will be limited by factors such as condition of the ground, load being handled, type of machine, speed of machine and visibility.
- There is no substitute for good judgement when working on slopes.
- Avoid operating equipment too close to an overhang or high wall, either above or below the machine. Be on the look-out for caving edges, falling objects and slides. Beware of concealment by brush and undergrowth of these danger.
- When pushing-over trees, the machine must be equipped with proper overhead guarding. Never allow a machine to climb up on the root structure particularly while the tree is being felled. Use extreme care when pushing over any tree with dead branches.
- When pushing trees with dead limbs, proceed with extreme care. Avoid brush piles, logs or rocks.
- NEVER DRIVE OVER THEM or other surface irregularities that brake traction with the ground, especially when on slopes or near drop-offs.
- Be alert to avoid changes in traction conditions that could cause loss of control. DO NOT DRIVE on ice or frozen ground conditions when working the machine on steep slopes or near drop-offs.
- Working in virgin and rough terrains is characterised by the presence of all the perils and risks listed above. In these conditions, it is emphasised the danger represented by large tree limbs (possibly falling on the machine), large roots (acting as a leverage under the machine when up-rooted causing the roll-over of the unit) etc.

## STOPPING

- When the machine is stopped for whatever reason, follow the instructions of chapters "**Stopping the machine**" and "**Stopping the engine**" of the Operation and Maintenance Instruction Manual.
- Always remember to position the transmission drive control in neutral and engage the control lock to secure the machine.
- The parking brake is automatically set, when the transmission safety lever is lowered.
- NEVER LEAVE THE MACHINE UNATTENDED with the engine running.
- Always, before leaving the operator's seat and after making sure all people are clear of the machine, slowly lower the attachments or tools flat to the ground in a positive ground support position.
- Return the controls to rest position. Place the gearshift lever in neutral. Disconnect the master switch and extract the key.
- Park in a non- operating and no-traffic area or as instructed. Park on firm level ground if possible. Where not possible, position machine at a right angle to the slope, making sure there is no danger of uncontrolled sliding movements.
- If parking in traffic lanes cannot be avoided, provide appropriate flags, barriers, flares and signals as required. Also provide advance warning signals in the traffic lane of approaching traffic.
- Keep head, body, limbs, feet, fingers or hands away from bucket, blade or ripper when in raised position.
- Always disconnect the master switch before any intervention (i.e. cleaning, repairing, maintaining, refuelling

## SAFETY RULES

etc.). Do the same when parking for prolonged periods of time to avoid accidental or unauthorised starting.

- Never lower attachments or tools other than seated in operator's seat. Sound horn. Make sure area near the attachment is clear. Lower the attachment slowly. DO NOT USE FLOAT POSITION of hydraulic system.
- Place master switch in **OFF**, securely block the machine and lock it every time you leave it unattended. Return keys to authorised security. Heed all shut-down operations of the Operation and Maintenance Instruction Manual are followed.

## MAINTENANCE

### GENERALITIES

- Before operating or performing any intervention on the machine:
  - read carefully all the rules contained by this Manual;
  - read and obey all safety related plates and instructions located on the machine.
- Do not allow unauthorised personnel to perform any maintenance operation. Do not perform maintenance operation without prior authorisation. Follow all recommended maintenance and service procedures.
- Keep operator's compartment free of all loose objects that are not properly secured.
- Do not wear rings, wrist watches, jewellery, loose or hanging apparels, such as ties, torn clothing, scarves, unbuttoned or unzipped jackets that can catch on moving parts. Wear proper safety equipment as recommended for the job. Examples: hard hat, heavy gloves, ear protection, safety glasses or goggles, reflector vests, respirator. Consult your employer for specific safety equipment requirements.
- Do not use controls or hoses as hand holds when climbing on or off machine. Hoses and controls are movable and do not provide a solid support. Also, controls may be inadvertently moved causing accidental machine or equipment movement.
- Do not jump on or off the machine. Keep two hands and one foot, or two feet and one hand in contact with step grab rails and handles at all times.
- Do not perform any service operation on the machine with a person seated in the operator's compartment, unless he is an authorised operator co-operating in the operation to be performed.

- Keep operator's compartment, stepping points, grab-rails and handles clear of foreign objects, oil, grease, mud or snow accumulation to minimise the danger of slipping or stumbling.

Clean mud or grease from shoes before attempting to mount or operate the machine.

- Keep shoes free of mud or grease before climbing or driving the machine.
  - Never attempt to operate the machine or its tools from any position other than seated in the operator's seat.
  - When maintenance operations require moving hydraulically operated attachments by means of machine's hydraulic system remember that all manoeuvres must be made only when seated in the operator's seat. Before starting machine or moving attachment or tools, set brakes, sound horn and call for an all clear. Raise attachment slowly.
  - Always block booms or parts of the machine which must be raised to perform interventions under them with external devices. Do not allow persons to move into the vicinities nor standing under equipment not being blocked. Unless you are totally sure about your safety, avoid staying under raised equipment, even in case it is blocked.
  - Do not place the body, limbs or fingers into sharp articulation uncontrolled openings of the machine and without proper protections, unless they are blocked in a safe manner.
  - Never perform interventions with engine running, except as called for in a Manual. Do not wear loose clothing or jewellery near moving parts.
  - When servicing or maintenance require access to areas that cannot be reached from the ground, use a ladder or step platform that meet local and national regulations, to reach the service point. If such ladder or platform are not available, use the machine hand holds and steps as provided. Perform all service or maintenance carefully.
  - Shop and/or field service platforms or ladders must be constructed and maintained in accordance with local and national regulations.
  - Disconnect batteries and tag all controls according to current regulations to warn that work is in progress. Block machine and all attachments that must be raised according to current regulations.
- Due to the presence of flammable fluids, never check or fill fuel tanks, batteries, nor use starting fluid near lighted smoking materials or open flames.
- **BRAKES ARE INOPERATIVE** when manually released for servicing. Provisions must be made to maintain control of the machine by blocking or other means.

## SAFETY RULES

- The fuel filling nose must be kept constantly inside the filling neck. Keep this contact from the beginning to the end of the fuelling operation to avoid the possibility that sparks due to static electricity are generated.
- Use only designated towing or attaching points. Use care in making attachments. Make sure pins and/or locks are secure before pulling. Stay clear of drawbars, cables or chains under load.
- To move a disabled machine, use a trailer or a low-boy, if available. In case towing is needed, use all necessary signals required by local and national regulations, and follow the directions provided in this Manual.
- To load/unload a machine from transporter, choose a level surface ensuring firm support to the wheels of truck or trailer. Use strong access ramps, with adequate height and angle. Keep surface free of mud, oil or slippery materials.
- Anchor the machine securely to the bed of truck or trailer and block wheels or tracks with appropriate wedges.
- Never align holes with fingers or hands; always use appropriate aligning tools.
- Eliminate all sharp edges and burrs from re-worked parts.
- Use only approved grounded auxiliary power sources for heaters, chargers, pumps and similar equipment to reduce the hazards of electrical shocks.
- Lift and handle heavy parts with a lifting device of proper capacity. Be sure parts are supported by proper slings and hooks. Use lifting eyes if provided. Watch-out for people in the vicinity.
- Never pour gasoline or diesel fuel into open, wide and low containers. Never use gasoline, solvent or other flammable fluid to clean parts. Use exclusively qualified, non-flammable, non-toxic commercial solvents.
- When using compressed air for cleaning parts, use safety glasses with side shields or goggles. Limit pressure to 2 bar (29 psi), in accordance with local and national regulations.
- Do not run the engine in closed areas without proper ventilation to remove deadly exhaust fumes.
- Do not smoke or permit any open flames or spark near when re-fuelling or handling flammable materials.
- Do not use an open flame as a light source to look for leaks or for inspection anywhere on the machine.
- Make sure that all mechanic's tools are in good conditions. NEVER USE tools with mushroomed heads or frayed. Always wear eye protections.
- Move with extreme care when working under the machine, its attachments and or on or near them. Always wear protective safety equipment as required, such as hard hat, goggles, safety shoes, ear plugs.
- When performing operations requiring running of the engine, have a qualified operator in the operator's seat at all times with the mechanic on sight. Place the transmission in neutral and set the brakes and safety lock.
- **KEEP HANDS AND CLOTHING AWAY FROM MOVING PARTS.**
- For field service, move machine to level ground, if possible, and block it. If work on an incline is absolutely necessary, first block machine and its attachments securely, than move it to level ground as soon as possible.
- Do not trust worn and /or kinked chains and cables: do not use them for lifting or pulling operations. To handle them, always use heavy gloves.
- Be sure chains and cables are anchored and the anchor points are strong enough to handle the expected load. Keep exposed personnel clear of anchor points and cables or chains.
- No bystanders are allowed near the hooking points, chains or cables.
- **DO NOT PULL UNLESS OPERATOR'S COMPARTMENT OF MACHINES INVOLVED ARE PROPERLY GUARDED AGAINST POTENTIAL CABLE OR CHAIN BACKLASH.**
- Keep the area where maintenance operations are performed CLEAN and DRY. Eliminate immediately all water and oil spillages.
- Do not pile oily or greasy rags; they represent a fire hazard. Store in closed metal container.
- Before starting machine, check, adjust and lock the operator's seat for maximum comfort and control of the machine. Be sure exposed personnel in the area of operation are clear of the machine before moving it or its attachments. Sound horn.
- Rust inhibitors are volatile and flammable Use only in well ventilated areas. Keep open flames away - **DO NOT SMOKE** - Store containers in a cool well ventilated place, secure against unauthorised personnel.
- Do not carry loose objects in pockets that might fall unnoticed into open compartments.
- Wear proper protective equipment such as safety goggles or safety glasses with side shields, hard hat, safety shoes, heavy gloves when metal or other particles are apt to fly or fall.

## SAFETY RULES

- Wear welders protective equipment such as dark safety glasses, helmets, protective clothing, gloves and safety shoes, when welding or burning. Wear dark safety glasses near welding zones.

**DO NOT LOOK AT ARC WITHOUT PROPER EYE PROTECTION.**

- Know your jacking equipment and its capacity. Be sure the jacking point used on the machine is appropriate for the load to be applied. Be sure the support of the jack at the machine and under jack is appropriate and stable.
- The load lifted by jacks is always dangerous: it is necessary to transfer loads to appropriate blocking as a safety measure, before proceeding with service or maintenance work, according to local or national regulations.
- Steel cables are frayed after prolonged use; always wear appropriate protections (heavy gloves, goggles etc.).
- Handle all parts carefully. Keep hands and fingers away from structures, gears or moving parts. Use and wear always the appropriate protections
- Compressed air systems can have water deposits created by moisture condensation due to changes of atmospheric conditions. If required, discharge deposits, as instructed.

### STARTING

- Do not run the engine in closed areas without proper ventilation to remove deadly exhaust fumes.
- Do not place head, body, limbs, feet, hands or fingers, near rotating fans or belts. Be especially alert near pusher fans.

### ENGINE

- Loosen the radiator cap very slowly, to release pressure from the system, before removing it. All coolant level top-ups must be performed with engine OFF.
- Avoid that flammable materials touch exhaust parts. Should this be possible, provide the necessary protections.

- Do not run engine when refuelling and use care if the engine is hot due to the increased possibility of a fire if fuel is spilled.
- Never attempt to check or adjust fan belts when engine is running.
- Do not adjust engine fuel pump when machine is moving.
- Do not lubricate the machine with engine running.
- Do not run the engine with air intakes, door or protections open.

### ELECTRICAL SYSTEM

- Disconnect batteries prior to any intervention on machine or electrical system (cleaning, repair, maintenance).
- Should booster batteries be used, remember to connect both ends of the booster cables in the proper manner (+) with (+) and (-) with (-). Avoid short-circuits of the terminals. Follow thoroughly the instructions of this Manual.
- Before any intervention, make sure that the main switch is OFF.
- **BATTERY GAS IS HIGHLY FLAMMABLE.** Leave battery box open to improve ventilation when recharging batteries. Never check charge by placing metal objects across the posts. Keep sparks or open flames away from batteries. Do not smoke near battery to guard against the possibility of causing an explosion.
- Before any intervention, make sure that there are no fuel or electrolyte leakages; eliminate them before proceeding with further work. When recharging batteries in closed ambients, make sure that there is appropriate ventilation to prevent possible accidental explosions due to the accumulation of gases generated during the recharge.

### HYDRAULIC SYSTEM

- Fluid escaping under pressure from a very small hole can be almost invisible and can have sufficient force to penetrate the skin. Use a piece of cardboard or wood to search for suspected pressure leaks. **DO NOT USE**

## SAFETY RULES

**HANDS.** If injured by escaping fluid, see a doctor at once. Serious infection or reaction can develop if proper medical treatment is not administered immediately.

- Stop the engine and release all pressures in the system before removing panels, housings, plugs or covers.
- In case pressures must be measured, use instruments of adequate capacity. Always follow the recommended procedures.

### TOOLS

- Keep head, body, limbs, feet, fingers or hands away from bucket, blade or ripper when in raised position.

Prior to any intervention, install all safety devices according to current rules and regulations.

- In case equipment on the machine must be operated by hydraulic systems, remember to proceed only after seating in the operator's compartment. Make sure that there are no persons in the operating area of the machine. Alert people before operating using the horn and by voice. Move the equipment very carefully.
- Do not use machine to transport loose objects, unless proper devices for this purpose are provided.
- Clutches and brakes of this machine and eventual auxiliary equipment and attachments (such as operating cylinder or winches control valves) must always be properly adjusted in accordance with the instructions provided by the Manuals of the Manufacturer.
- Never perform adjustments with engine running, except when called for by the above instructions.

When changing work shift, check that wheel or rim securing screws and brackets are not loosen; if necessary, retighten to the prescribed torque.

### **WARNING**

**On machines having hydraulically, mechanically, and/or cable controlled equipment (such as shovels, loaders, dozers, excavators etc.) be certain the equipment is lowered to the ground before servicing, adjusting and/or repairing. If it is necessary to have the hydraulically, mechanically, and/or cable controlled equipment partially or fully raised to gain access to certain items, be sure the equipment is suitably supported by means other than the hydraulic lift cylinders, cable and/or mechanical devices used for controlling the equipment.**

## SAFETY RULES

### SAFETY RULES FOR SEALS

#### VITON SEALS (FLUOROELASTOMER)

Seals, especially VITON O-Rings, (normally coloured red) are used in systems operating at high temperatures, since this material resists the effects of heat. However, in the event this material is subject to heat exceeding 315 °C (599 °F) (in practice, only in case of fire or when using welding flames) fluoridic acid is generated. **This acid is highly corrosive and could cause severe burns**, if in contact with the skin.


Every time it is necessary to intervene on components equipped with VITON rings, for which an exposure to excessive temperatures is suspected, the following procedures must be applied:

1) inspect visually, without touching them, all seals showing signs of damage due to high temperature. They look

black and tacky;

- 2) identify the type of material of the seals, if they are VITON, performing the test illustrated below, on the spare parts;
- 3) in case it is verified, or there is a reasonable doubt that the components are made of VITON, the contaminated area **MUST** be decontaminated before proceeding with further operations;
- 4) wear neoprene rubber or PVC gloves and protection goggles or face screen, and wash accurately the contaminated zone with a solution of hydraulic lime (found at building stores) and water, so that a milky liquid is obtained. Rinse carefully with steam or running water;
- 5) dispose of the materials removed and the protective gloves in a safe manner, without burning them.

#### TEST FOR THE DISCRIMINATION OF RUBBER (BUNA N) MATERIALS AND "VITON" (FLUOROELASTOMER) MATERIAL



# **D350**

**CRAWLER DOZERS**

**TABLE OF TECHNICAL DATA**




**IDENTIFICATION DATA**

**A. Engine data plate**

The data plate can be seen opening the left side panel of the engine compartment, containing the identification data and other important information on the engine.

1. Serial number of the engine (E.S.N. Engine Serial Number Cummins)



Engine No. 35048946	Advert. Power HP/KW 330/246 <sup>st</sup> 2100	RPM	Idle Speed RPM 650 - 1000	NOx FEL	IMPORTANT ENGINE INFORMATION: This engine conforms to: 2004 U.S. EPA and California Tier 2 and EU Stage II regulations for heavy duty nonroad compression ignition diesel cycle engines as applicable.  THIS ENGINE IS CERTIFIED TO OPERATE ON DIESEL FUEL. Warranty Start Date: _____  WARNING: Injury may result and warranty is voided if fuel rate, RPM or altitude exceed published maximum values for this model and application.
Family 1CEXLO661AAC	Fuel rate at Advert. Power 155	CID/L 661/10.8	Inj. Timing KV	PM FEL	
Date of Mfg. 11/01	Inj. Set IN/mm .025 LASH	CPL 2828	Int. 027/686	Est. 4060483	
Model OSM11-C	Valve Lash Cold IN/mm .025 / .356				
Ref. No. S052008					

D350M002


D350R0411

**B. Machine identification plate**

The identification plate contains the main data of the machine and it is visible under the operator's seat.



D350R0464




D350M0134

**C. Marking and serial number of frame**

The MARKING of the machine is seen on the left side of the transmission housing.

In the lower side it is readable:

- manufacturer code (the first 3 digits) FNH;
- the machine code 35000;
- check letter "N";
- year of production "5" for 2005;
- manufacturing plant H (Lecce Plant);
- product line "C" (Dozer);
- the serial number (last 5 digits).



D350M0005

MODEL	MARKING
D350	FNH35000N5HC30001

TABLE OF CAPACITIES

ITEM	Q. TY Litres (gal.)	Fluids and lubricants 	VISCOSITY GRADE	Ambient temperature of reference	International classification
<b>Cooling system</b>	37 (9.8)	AMBRA - Agriflù	Agriflù mixed 50% with water ensures anti-freezing down to -35 °C (-31 °F)	Down to -35 °C (-31 °F)	50 -50 mixture of water and anti- freeze. The mixture has anti-oxida- tion, anti-corrosion, anti-scaling, anti-foaming properties and anti- freezing down to -35 °C (-31 °F).
<b>Fuel tank</b>	675 (178.3)	—	—	—	DIESEL FUEL ASTM No. 2D Grade TT of reputable quality and make
<b>Engine</b>	35 (9.2)	AMBRA - Super Gold	SAE 15W - 40	-15 to 40° C (5 to 104 °F)	API CF-4/SG or CCMC D4 or MIL-L-2104E
			SAE 10W - 30	-25 to 20° C (-13 to 68 °F)	
<b>Torque converter - Transmiss.</b>	70 (18.5)	AMBRA - Hydropower	SAE 10W	All season	ATF Type A Suffix A
<b>Steering / brakes transmission housing</b>	175 (46.2)	AMBRA - Super Gold	SAE 15W - 40	-15 to 40 °C (5 to 104 °F)	API CF-4/SG or CCMC D4 or MIL-L-2104E
			SAE 10W - 30	-25 to 20 °C (-13 to 68° F)	
<b>Hydraulic system</b>	145 (38.3)	HI-TECH46	ISO 46	-20 to 50 °C (5 to 104 °F)	DIN 51524 PART - 1 DIN 51524 PART - 2 ISO VG 46
<b>Final drives (each)</b>	38 (10.0)	AMBRA - Hypoide 90	SAE 80W - 90	All season	API GL5 or MIL-L-2105
<b>Various grease fittings</b>	-	AMBRA - MG2	NLGI2 Consistency	All season	—


**Note:** - Oil quantities indicated are those required for periodical changes.

- In case of a lower classification of CH4 engine oil, the change must be done every 250 hours.
- The change interval must be reduced when present sulfur in the fuel exceed to 0,5% or the ambient temperature exceed to 38 °C.

If the content of sulphur exceeds 0.5%, change the engine oil as follows:

Up to 0.5 % S	Periodic change
from 0.5 to 1 %	Half the normal interval
Over 1 %	One quarter the normal interval

## MAIN DIMENSIONS D350



BLADE TYPE	Blade width mm (in)	Blade height mm (in)	Blade capacity m <sup>3</sup> (ft <sup>3</sup> )	Tilt mm (in)	Pitch	Digging depth mm (in)	Blade lifting from ground mm (in)
Semi-U (HSU)	3975 (156.5)	1700 (66.9)	9.1 (321.3)	900 (35.4)	13°	600 (23.6)	1220 (48)
Angolable (HA) •	4620 (181.9)	1145 (45.1)	4.5 (158.9)	470 (18.5)	10°	685 (26.9)	1140 (44.9)
Full-U (HU)	4295 (169.1)	1650 (64.9)	11.4 (402.6)	975 (38.4)	13°	600 (23.6)	1220 (48)

• Maximum angle: ± 25°.

## SPECIFICATIONS D350

SPECIFICATIONS	DATA		
<b>PERFORMANCES</b>	<b>Max. speeds</b> FORWARD		
	1 <sup>st</sup>	Km/h (mph)	3.8 (2.4)
	2 <sup>nd</sup>	Km/h (mph)	6.1 (3.8)
	3 <sup>rd</sup>	Km/h (mph)	10.3 (6.4)
	REVERSE		
	1 <sup>st</sup>	Km/h (mph)	4.4 (2.7)
	2 <sup>nd</sup>	Km/h (mph)	7.0 (4.3)
	3 <sup>rd</sup>	Km/h (mph)	11.4 (7.0)
	<b>Max Trazione alla Barra</b> FORWARD		
	1 <sup>st</sup>	daN	58172
	2 <sup>nd</sup>	daN	33144
	3 <sup>rd</sup>	daN	16300
	REVERSE		
1 <sup>st</sup>	Km (mile)	48590 (30192.4)	
2 <sup>nd</sup>	Km (mile)	27515 (17097.0)	
3 <sup>rd</sup>	Km (mile)	13332 (8284.1)	
<b>Bearing pressure on ground</b>			
Under work conditions	bar (psi)	0.90 (13.0)	
Under work conditions + single shank ripper	bar (psi)	0.98 (14.2)	
<b>Climbing capacity (FWD)</b>		<b>Maximum speed</b>	
3 <sup>rd</sup> 10%	Km/h (mph)	8.5 (5.3)	
2 <sup>nd</sup> 30%	Km/h (mph)	4.4 (2.7)	
1 <sup>st</sup> 60%	km/h (mph)	2.7 (1.7)	
<b>Front equipment cycle times (ref. semi-U blade)</b>			
Raising time (from ground to max. height)	sec	2.7	
Controlled lowering	sec	1.6	
Floating	sec	1	
<b>Noise</b>			
Inner LwA	dB(A)	83	
Outer LwA	dB(A)	118	
Outer with sound suppression option	dB(A)	113	
<b>SAFETY DEVICES</b>	Back-up alarm. Left safety lever. It blocks the equipment, cuts-off the transmission and engages the parking brake. Right safety lever. It blocks the equipment, cuts-off the transmission and engages the parking brake.		

## cont.ed SPECIFICATIONS D350

<b>ENGINE AND ACCESSORIES</b>	Engine manufacturer	-	Cummins		
	Engine model	-	QSM11-330/365 HP		
	Engine type: direct injection, turbocharged, after-cooled, 4-stroke diesel.				
	Bore and stroke	mm (in)	125 x 147 (4.9 x 5.8)		
	Total displacement	lt (gal.)	10.82 (2.8)		
	Number of cylinders	-	6		
	<b>D350</b>	kW		HP	
	Net power	nom. @ 2100 rpm	max. @1800 rpm	nom. @ 2100 rpm	max. @1800 rpm
	DIN 6270	224	257	300	345
	SAE J1349	221	253	296	339
	ISO9249	223	255	299	342
	EEC 80/1269	224	257	300	345
	Max. torque			daNm (lb.ft.)	167.4 (1234.2)
	Fuel consumption (MAX. POWER)			KG/h (lb/h)	50 (110.2)
	<b>Starting capacity</b>				
Standard configuration			°C (°F)	-12 (10)	
With cold starting system			°C (°F)	-17 (1.4)	
<b>Electrical system</b>					
System voltage			Volt	24	
Capacity of starter motor			kW (HP)	9.5 (12.7)	
Capacity of alternator			Amp	70	
<b>Radiator</b>					
Dimension of transmission heat exchanger			-	-	
Dimension of core (water)	dm <sup>2</sup> 64.4 (6.9 ft <sup>2</sup> )	mm (in)	114 x 1180 x 540 (4.5 x 46.4 x 21.2)		
Material of core			brass		
No of tube rows			-	6	
Fin pitch			mm (in)	3.5 (0.1)	
Cap pressure			bar (psi)	1.0 (14.5)	
<b>Air/air radiator</b>					
Fan diameter			mm (in)	600 (23.6)	
No. of tubes			-	37	
Pitch			mm (in)	2.8 (0.1)	
Radiator surface			dm <sup>2</sup> (ft <sup>2</sup> )	42.5 (4.6)	
Operating pressure			bar (psi)	2 (29)	
Water pump flow (at normal speed)			lt/min (gpm)	438 (115.7)	
<b>Water / oil radiator "Landfill" version (optional)</b>					
Fin pitch			mm (in)	3.5 (0.13)	
Material of core			-	CU	
Tubes dimension sect.			mm (in)	15x2.5 (0.6x0.10)	
Material			-	OT	
No. of tubes			-	282	
Radiator surface			dm <sup>2</sup> (ft <sup>2</sup> )	64.4 (6.93)	
Operating pressure			bar (psi)	1 (14.5)	
Test pressure			bar (psi)	2 (29)	

## cont.ed SPECIFICATIONS D350

<b>ENGINE AND ACCESSORIES</b>	<b>Sound suppressed fan (blowing)/fan (sucking)</b>	<b>TRUFLO</b>	<b>TECNOVENT</b>
	Fan diameter	mm (in)	1066.8 (42) 1067 (42)
	Blade angle pitch	deg	45° 30°
	Number of blades	-	8 12
	Dimension of blade	mm (in)	203 x 2.3 x 375 (7.9 x 0.1 x 14.8)
	Drive ratio (fan/engine)	-	0.67 : 1 0.57 : 1
	<b>Air cleaner</b>		
	Brand	Donaldson	
	Type	FRG15-0092	
	Dry type, two stages with safety element and centrifugal separator.		
	Setting of clogging indicator	bar (in H <sub>2</sub> O)	0.06 (25)
	Initial clogging (@ 15 cum /min, 529.7 ft <sup>3</sup> /min) - Cummins limit: 0.04 bar (15 in H <sub>2</sub> O)	bar (in H <sub>2</sub> O)	0.02 (10.8)
	Dust containment capacity (@ 13 cum /min, 459.1 ft <sup>3</sup> /min) - Cummins limit : 25 gr./CFM	gr/CFM	19.2
	Dimensions	mm (in)	381 (15)
	<b>Rain protected pre-filter</b>		Donaldson
	<b>Silencer</b>		Donaldson
	Horizontal type. Under hood.		
	Dimensions	mm (in)	275 x 813 (10.8 x 32)
	Max. counter-pressure (Cummins limit: 76 mmHg, 1.5 psi)	mmHg (psi)	40 (0.8)
<b>FUEL TANK</b>	Total volume	lt (gal.)	675 (178.3)
	Specifications of filler cap	lt (gal.)	670 (176.9)
<b>TORQUE CONVERTER AND HOUSING</b>	Brand: Twin disc		
	Model: 8F-1600 MS-480		
	Type: Single stage, dual phase.		
	Stall ratio	-	2.3 : 1
	Nominal diameter	mm (in)	406.4 (16.0)
	Setting of pressure relief valve delivery @ 10 lt/min (2.6 gpm)	bar (psi)	10 to 11 (0.19 to 0.21)
	Transmission pump nominal flow @ 16 bar	lt/min (gpm)	101 (26.7)
	Transmission scavenge @ 1 bar (14.5 psi)	lt/min (gpm)	194 (51.2)
	Tc pump nominal flow @ 3.5 bar (50.8 psi)	lt/min (gpm)	89 (23.5)
	Tc scavenge pump @ 1 bar (14.5 psi)	lt/min (gpm)	37 (9.8)
<b>TRANSMISSION</b>	Type: POWER SHIFT		
	Model: TM400		
	Brand: CNH		
	Specifications: 3+3 speeds, speed and direction modulating valves Electronic control + automatic mode Integrated CPU and TM control.		

## cont.ed SPECIFICATIONS D350

<b>TRANSMISSION</b>	<b>PTO capacity</b>		
	Max. torque @ 0 rpm	daNm (lb.ft.)	294.3 (17326.5)
	Max. speed @0 torque	rpm	2350
	<b>Specifications</b>	Clockwise rotation (from rear of machine) driven by Torque Converter.	
	<b>Shaft specifications</b>		
	Number of teeth	-	24
	Module	mm (in)	2.58 (0.1)
	Outer diameter	mm (in)	63.68 (2.5)
<b>Filters</b>	Intake:		
	Metal mesh + magnetic rod (Q.ty 2)	mesh	100
	<b>In-line</b>		
	Spin-on	Micron	30 abs.
	By-pass valve setting	bar (psi)	2 (29)
Transmission pressure relief valve setting @ 10 lt/min (2.6 gpm) bar (psi)			10 to 11 (145 to 159.5)
Aluminium made oil radiator core		mm (in)	500 x 1170 x 150 (19.7 x 46 x 5.9)
<b>Controls</b>			
Fingertip type, FNR pivoting control, neutral switch. Safety lever.			
<b>Description of auto mode</b>			
AS Allows the operator to pre-select the 1 <sup>st</sup> speed in froward and the 2 <sup>nd</sup> in reverse at direction changes.			
<b>PROPELLER SHAFT</b>	Dimension of shaft		
	Mechanical 8.5 °C (47.3°F) Nominal length	mm (in)	452.2 (17.8)
<b>BEVEL GEAR GROUP</b>	Gleason type, modular pinion assembly. Forced lube pinion bearings.		
	Ratio:		23/35
	Module:	M	10
<b>STEERING SYSTEM D350</b>	The machine uses a differential steering system; this consists of a hydraulic pump, a hydraulic motor, controls, two planetary modules and a steering gear train. The rear transmission has two power inlets. One from the bevel gear for the speed and Forward reverse, the other from the motor, to turn. The steering system is actuated by two "finger tip" potentiometric levers, located on the left side of the operator's seat.		
	The levers send an electric signal to the microprocessor controlling the two proportional solenoid valves; these valves convert the electric signal into a hydraulic one, piloting the steering section of the main valve. This section controls the pump flow to the hydraulic motor that through the steering gear train, actuates the two planetary modules and the right track chain.		

## cont.ed SPECIFICATIONS D350

<b>STEERING SYSTEM D350</b>	<p>The open hydrostatic circuit includes:</p> <ul style="list-style-type: none"> <li>- Main pump The same of the equipment (see hydraulic system) <span style="float: right;">cm<sup>3</sup>/rev (in<sup>3</sup>/rev)</span></li> <li>- Hydraulic motor Bent axis design, axial pistons, fixed displacement motor (with bolt-on movement control valve)</li> </ul>	190 (11.6)
	<p>Displacement <span style="float: right;">cm<sup>3</sup>/rev (in<sup>3</sup>/rev)</span></p> <p>Max. operating pressure <span style="float: right;">bar (psi)</span></p> <ul style="list-style-type: none"> <li>- Steering control valve. Closed centre. This section is included in the implement control valve.</li> <li>- Steering control. Electro-Hydraulic control with two proportional valves. Integrated CPU for steering and TM control.</li> <li>- Priority valve. It provides priority to the steering over the equipment control.</li> <li>- Make-up valve. It provides pressure to both equipment control pilot valves and to the proportional solenoid valves <span style="float: right;">bar (psi)</span></li> <li>- Oil radiator Aluminium body <span style="float: right;">mm (in)</span> By-pass setting <span style="float: right;">bar (psi)</span></li> </ul>	180 (10.9) 350 (5076.3)
	<p><b>Planetary modules</b></p> <p>See "power train" diagram</p> <p>Gear ratio straight travel conditions <span style="float: right;">-</span></p>	1.52
	<p><b>Steering line</b></p> <p>See "power train" diagram.</p> <p>Gear ratio.</p> <p>Hydraulic motor to sprocket <span style="float: right;">-</span></p>	244
	<p><b>Performance</b></p> <p>Min. steering radius <span style="float: right;">m (ft)</span></p> <p>Max. differ. track chain speed, no load condition <span style="float: right;">Km/h (mph)</span></p> <p>Max. differ. track chain torque at 350 bar (5076.3) <span style="float: right;">KNm</span></p>	2.0 (6.6) 2.8 (1.7) 124
	<p>The steering system is controlled by two levers installed on the left side of the operator's seat. When the lever is moved, a modular pressure is forwarded through the controller and the proportional solenoid valves to the steering control valve.</p> <p>The service brakes system is negatively controlled by the brake pedal or when pulling the two levers at the same time.</p> <p>The actuation of the pedal cuts with a modulation the backpressure of the brake piston so that the springs apply a braking load.</p>	

**cont.ed SPECIFICATIONS D350**

<b>BRAKES</b>	<b>Steering/brakes filters</b>		
	Suction, spin-on	Micron	150
	<b>In-line filters</b>		
	Spin-on	Micron	25
	By-pass valve setting	bar (psi)	3.44 (49.9)
	Multiple-disc, spring actuated, released by oil, oil-cooled		
	No. of clutch discs	-	8
	Outer diameter	mm (in)	407.98 (16.1)
	Inner diameter	mm (in)	320.92 (12.6)
	Total friction area	cm <sup>2</sup> (in <sup>2</sup> )	8046 (1247.1)
	Friction material	-	-
	No. of springs	-	16
	Max. braking torque	daN	2116
	Steering pump flow	lt/min (gpm)	-
System pressure	bar (psi)	350 (5076.3)	
<b>STEERING/BRAKES COMPARTMENT</b>	Welded housing.		
<b>FINAL DRIVE</b>	Countershaft single reduction, plus one planetary reduction.		
	Total ratio	-	15.6
<b>SPROCKET</b>	Segments. 3 Elements		
	No. of teeth	-	27
	Pitch diameter	mm (in)	936.25 (36.9)
<b>TRACK FRAME</b>	Tubular, torsion and flexion resistant fabricated structure. Sealed track tensioner compartment.		
<b>UNDERCARRIAGE</b>	Link pitch	mm (in)	215.9 (8.5)
	No. of links	-	44
	Link height	mm (in)	150 (5.9)
	Shoe height	mm (in)	84 (3.3)
	Weight of shoes per metre	Kg/m (lb/m)	28.4 (62.6)
	Width of standard shoe	mm (in)	610 (24)
	Width of optional shoes	mm (in)	711 (28)
	No. of track rollers (2 twin rim and 5 single rim)	-	7
	Sequence from sprocket	-	SF-DF-SF-SF -DF-SF-SF
	Diameter of rollers	mm (in)	242 (9.5)
	No. of support rollers	-	2
	Roller diameter (support)	mm (in)	191 (7.5)
	Idler diameter	mm (in)	813 (32)

*cont.ed* SPECIFICATIONS D350

<b>TRACK TENSION SYSTEM</b>	Sliding idler guides with replaceable wear strips. Grease piston to track adjuster. Single spring.		
	Nominal load of spring assembly	daN	28910
	Outside diameter of spring	mm (in)	285 (11.2)
	Diameter of wire	mm (in)	63.5 (2.5)
	Diameter of grease piston	mm (in)	101.5 (4.0)
	Setting of relief valve	KPa (psi)	68.95 (10.0)
<b>TRACK SUSPENSION SYSTEM</b>	Pivot shaft (near sprocket) and fixed frond cross-member.		
	All joints permanently lubricated		
	Pivot shaft diameter	mm (in)	Ø 189 (7.4) - Ø 149 (5.9)
	Thickness of crossbar	mm (in)	125 (4.9)
	Oscillation stroke (track)	deg	10°30'
Stroke of idler (total)	mm (in)	480 (18.9)	
<b>MAIN FRAME</b>	Fabricated structure with two boxed beams, centrally connected by the suspension cross-member support, frontally to the radiator and hood support and at the rear to the transmission housing.		
	Frame length	mm (in)	1314 (51.7)
	Width of beam	mm (in)	114.3 (4.5)
<b>TOWING HOOK</b>	Bolted to rear transmission housing.		
	Pin diameter	mm (in)	50.8 (2.0)
	Fork opening	mm (in)	95 (3.7)
<b>HYDRAULIC SYSTEM</b>	Load sensing system, flow partition with piloted variable displacement pump.		
	<b>System pressure</b>		
	Setting of dual pressure relief valve (equipment/steering)	bar (psi)	200/350 (2900.7/5076.3)
	Pressure of piloting line	bar (psi)	30 to 32 (435.1 to 464.1)
	<b>Main pump: axial pistons</b>		
	Regulators: variable displacement		
	Constant power control	kW (HP)	90 kW@ 1950 rpm (120.7 HP@ 1950 rpm)
	CUT-OFF pressure	bar (psi)	350 (5076.3)
	Load sensing	bar (psi)	20 to 21 (290.1 to 304.6)
	Brand		Rexroth
Model		A11VL0 190 LRS/11	
max. displacement	cc/rev	192.7	
Pump speed at engine max. speed	rpm	2003	
Max. pump flow	l/min (gpm)	386 (101.9)	

*cont.ed* SPECIFICATIONS D350

<b>HYDRAULIC SYSTEM</b>	Min displacement	cc/rev	15
	Stand-by pressure	bar (psi)	33 to 37 (478.6 to 536.6)
	<b>Equipment control valve:</b> Piloted, Closed centre, flow partition, with discharge valve		4-spool
	Brand		Rexroth
	Model		4M7 - 22
	Nominal dimensions	mm (in)	22 (0.8)
	1 <sup>st</sup> spool Ripper (lift, lowering) at max. flow	l/min (gpm)	350 (92.5)
	2 <sup>nd</sup> spool Blade tilt (left, right) at max. flow	l/min (gpm)	100 (26.4)
3 <sup>rd</sup> spool Blade (lift, lowering, floating w/detent)	l/min (gpm)	350 (92.5)	
4 <sup>th</sup> spool Steering motor			
<b>Pilot valve</b> Blade and tilt			
Brand		Rexroth	
Model		5THF6Z97	
<b>Auxiliary lever</b> Single lever for ripper spool			
Brand		Rexroth	
Model		2TH6-L97	
<b>Cylinders:</b>			
<b>Blade q.ty 2 cylinders</b>			
Bore	mm (in)	120 (4.7)	
Rod diameter	mm (in)	70 (2.8)	
Stroke	mm (in)	1255 (49.4)	
<b>Tilt (bulldozer blade)</b>			
Bore	mm (in)	180 (7.1)	
Rod diameter	mm (in)	90 (3.5)	
Stroke	mm (in)	180 (7.1)	
<b>Ripper (lift) q.ty 2 cylinders</b>			
Bore	mm (in)	180 (7.1)	
Rod diameter	mm (in)	90 (3.5)	
Stroke	mm (in)	533 (20.9)	

<b>HYDRAULIC SYSTEM</b>	<b>Ripper (pitch) q.ty 2 cylinders</b>		
	Bore	mm (in)	160 (6.3)
	Rod diameter	mm (in)	80 (3.1)
	Stroke	mm (in)	622 (24.5)
	<b>Hydraulic tank</b>		
	Total capacity of tank	l (gal.)	205 (54.1)
	Oil tank volume	l (gal.)	145 (38.3)
	Capacity of oil circuit	l (gal.)	310 (81.9)
	<b>Return filter</b>		
	Filtering capacity	micron (absolute)	25
By-pass valve setting	mPa (psi)	200 to 15 (29007 to 2175.6)	
Surface	cm <sup>2</sup> (in <sup>2</sup> )	7392 (1145.8)	
<b>DRIVER'S COMPARTMENT</b>	<b>Canopy rops fops:</b> Standard with 2-beam rigid structure.		
	<b>Cab:</b> Fully enclosed, modular, fops cab. Two doors, two side windows, 4 resilient supports.		
	<b>Description of cab arrangement</b>		
	Left console: With fully adjustable armrest (satellite) including the Steering and Transmission controls. The console holds: Auto T/M switches, left safety lever, Conditioning dashboard.		
	Right console: Support for hydraulic pilot valve and 3 <sup>rd</sup> function lever, adjustable armrest, starter key, horn, ashtray.		
	Front control module: Monitor, control switches, manual throttle (RH).		
	Pedal support: Brake central pedal, decelerator pedal (RH) footrest (2).		
	Cab accessories: Rear mirror. Front wiper, door window wipers. Rear window wiper. Ashtray and cigarette lighter. Ceiling light (2). Radio FM-AM (12 Volt). Drink holder. Fridge 12 Volt socket.		
	No. of air ducts	-	8
	<b>Seat</b>		
Brand		Bostrom	

Carefully read personal and machine SAFETY PRECAUTIONS at the beginning of this Manual

Sample of manual. Download All 354 pages at:

<https://www.aresairmanual.com/downloads/new-holland-d350-crawler-dozer-service-repair-workshop-manual/>