

Product: New Holland Fiat F100/F110/F120/F130 Turbo Tractors Service Repair Manual

Full Download: <https://www.arepairmanual.com/downloads/new-holland-fiat-f10>

[0-f110-f120-f130-turbo-tractors-service-repair-manual/](https://www.arepairmanual.com/downloads/new-holland-fiat-f10-f110-f120-f130-turbo-tractors-service-repair-manual/)



WINNER

FIAT

F100 F110

F120 F130 Turbo

WORKSHOP MANUAL

06910101

Sample of manual. Download All 370 pages at:
<https://www.arepairmanual.com/downloads/new-holland-fiat-f100-f110-f120-f130-turbo-tractors-service-repair-manual/>
SERVIZI TECNICI DI ASSISTENZA
Reprinted

Product: New Holland Fiat F100/F110/F120/F130 Turbo Tractors Service Repair Manual

Full Download: [https://www.arepairmanual.com/downloads/new-holland-fiat-f10](https://www.arepairmanual.com/downloads/new-holland-fiat-f100-f110-f120-f130-turbo-tractors-service-repair-manual/)

[0-f110-f120-f130-turbo-tractors-service-repair-manual/](https://www.arepairmanual.com/downloads/new-holland-fiat-f100-f110-f120-f130-turbo-tractors-service-repair-manual/)

Sample of manual. Download All 320 pages at:

<https://www.arepairmanual.com/downloads/new-holland-fiat-f100-f110-f120-f130-turbo-tractors-service-repair-manual/>

WORKSHOP MANUAL

SECTIONS

GENERAL – MAINTENANCE	00
CLUTCH	18
TRANSMISSION	21
FRONT-WHEEL DRIVE LINES	23
FRONT-WHEEL DRIVE	25
MECHANICAL REAR WHEEL DRIVE	27
POWER TAKE-OFF	31
BRAKES	33
HYDRAULIC SYSTEMS	35
STEERING	41
FRONT AXLE AND WHEELS	44
AUXILIARY UNITS	50
ELECTRICAL SYSTEM	55
BODY AND OPERATOR'S CAB	90

S E R V I Z I T E C N I C I D I A S S I S T E N Z A

FOREWORD

- ◇ *This Manual is subdivided into Sections, each identified by a two-digit number and with separately numbered pages.
For ready reference, these Sections maintain the same identification number and group description of the corresponding Flat Time Rate Manual.*
- ◇ *Topics and information can be easily retrieved by consulting the Index on the following pages.*
- ◇ *Manual Print no. and respective edition/updating date appear on the bottom of each page.*
- ◇ *Revised sheets will carry the same print number followed by a 2-digit number (e.g. first revision 603.54.276.01; second revision 603.54.276.02 etc.) and date of issue.
These pages will be accompanied by a specifically revised and updated index.*
- ◇ *Information contained in this Manual are updated to the date reported on the print. As FIATAGRI maintains a constant improvement program for its product range, some information may not result updated because of modifications motivated by reasons of a technical or marketing nature as well as by the legal requirements of different Countries. In case of discordance, consult FIATAGRI Sales and Service Organizations.*
- ◇ *The imperial weights and measures are given for operators' convenience and though the closest approximation is sought, they are normally rounded off for practical reasons. In case of discrepancies only the metric units should be considered.*

IMPORTANT NOTICES

- ◇ *All maintenance and repair work reported and described in this Manual is the exclusive responsibility of the FIATAGRI Service Network, which must carry it out by strictly following directions and using, wherever necessary, the specific service tools specified therein.*
- ◇ *Anybody carrying out service operations dealt with in this manual without abiding strictly to its prescriptions makes himself personally responsible for of any ensuing damage.*
- ◇ *The Manufacturer and all of the Organizations associated with its distribution network, including but not limited to national, regional or local distributors, decline any and all responsibility for damages that may derive from the abnormal behaviour of parts and/or components not specifically authorized by the Manufacturer, including those utilized in maintenance and/or repair work on its products, manufactured or commercialized by the same.
In no case, warranties of any kind may be issued or forced on the products fabricated or distributed by the Manufacturer for damages deriving from any abnormal behaviour of parts and/or components unauthorized by the Manufacturer itself.*

COPYRIGHT BY FIATGEOTECH S.p.A.

●
Reproduction of text and illustrations
is not permitted in any form.

PRINTED IN ITALY

FIATGEOTECH S.p.A. – Viale delle Nazioni, 55 – 41100 MODENA – Italia
FIATAGRI – POST VENDITA – Servizi Tecnici di Assistenza – Pubblicazioni Tecniche
Print No. 603.54.276.00 – 01 – 1992 – 800

CONTENTS

	Page	Date		Page	Date
00 – GENERAL – MAINTENANCE					
General instructions	7-8	01-92			
Safety rules	9-10-11	01-92			
18 – CLUTCH					
Specifications	1	01-92			
Torque data – Service tools – Longitudinal sectional view ..	2	01-92			
Trouble-shooting	2-3	01-92			
LUK clutch					
Removal-installation	4-5-6-7-8 -9-10	01-92			
Clutch hydrostatic control					
Removal-installation	10-11	01-92			
Sectional views	12	01-92			
Disassembly-assembly	12-13	01-92			
Air bleeding – hydraulic clutch control	13	01-92			
21 – TRANSMISSION					
Specifications	1-2-3-4	01-92			
Torque data	5	01-92			
Service tools	6-7-8	01-92			
Sectional views	9-10	01-92			
Trouble-shooting	11-12	01-92			
Clutch-transmission case					
Removal-installation	13-14-15- 16-17-18- 19-20-21- 22-23-24- 25	01-92			
Disassembly-assembly	25-26-27- 28-29-30- 31-32-33	01-92			
Adjusting the reverser gear bearings	34	01-92			
Adjusting the range drive and driven shaft roller bearings ..	35	01-92			
Disassembly-assembly of 5 th speed gear	36-37-38- 39	01-92			
Transmission with HI-LO					
Removal-installation	39-40-41- 42-43	01-92			
Disassembly-assembly	43-44-45- 46	01-92			
Transmission control electro- valve replacement	46	01-92			
Sectional views	47	01-92			
Creep speed unit					
Gear disassembly-assembly ..	47-48	01-92			
Outside control lever travel ad- justment	48	01-92			
Transmission longitudinal section view	49	01-92			
Transmission cross-section- al view	50	01-92			
23 – FRONT – WHEEL DRIVE LINES					
Specifications	1-2	01-92			
Torque data	2	01-92			
Service tools	3	01-92			
Trouble-shooting	4	01-92			
Prop shaft guard – Removal – Installation	5	01-92			
Prop shaft and support – Di- sassembly – Assembly	5-6	01-92			
Drive shaft oil seal – Replace- ment	6	01-92			
Electro-hydraulic engage- ment – Removal – Installation	7-8-9-10- 11-12	01-92			
Mechanical engagement – Di- sassembly – Assembly	13-14-15- 16	01-92			
25 – FRONT – WHEEL DRIVE					
Specifications	1-2	01-92			
Torque data	3	01-92			
Sectional view of front axle and pivot mounting	4-5	01-92			
Service tools	6	01-92			
Trouble-shooting	7	01-92			
Live front axle – Removal – In- stallation	8-9	01-92			
Front epicyclic-gear final drive – Disassembly – Assembly ..	9-10-11	01-92			
Wheel hub and steering knuckle – Disassembly – Assembly	11-12-13	01-92			
Bevel gear drive and differen- tial housing – Removal – Instal- lation	13-14-15	01-92			
Front differential lock clutch – Overhauling	15-16-17	01-92			
Front axle bevel gear and pi- nion – Overhauling	17-18	01-92			
Bevel gear and pinion adjust- ments	19-20-21- 22-23	01-92			
Front axle differential – Over- hauling	23-24	01-92			
Steering knuckle kingpins and bearings – Replacement	24	01-92			
Drive-steering wheels toe-in check	25	01-92			

GENERAL – MAINTENANCE

00 – 4

	Page	Date
27 – MECHANICAL REAR WHEEL DRIVE		
Specifications	1-2	01-92
Torque data	2	01-92
Sectional views	3	01-92
Trouble-shooting	4-5	01-92
Service tools	6	01-92
Rear drive case, assy.		
Removal-installation	6-7-8-9- 10-11-12- 13-14-15	01-92
Replacement	15-16-17- 18-19-20- 21	01-92
Bevel gear and pinion adjust- ments	21-22-23- 24-25-26- 27	01-92
Differential with hydraulic lock – Disassembly – Assembly ..	27-28-29	01-92
Differential lock hydraulic control – Disassembly – Assembly ..	30	01-92
Replacement of the control electro-valve	31	01-92
Final drive RH or LH assy.		
Removal-installation	31-32-33	01-92
Drive wheel shaft disassem- bly – assembly	34-35-36	01-92
Planetary gear unit disassem- bly – assembly	36	01-92
31 – POWER TAKE-OFF		
Specifications	1-2	01-92
Torque data	2	01-92
Service tools	2	01-92
Sectional views	3	01-92
Trouble-shooting	4	01-92
Removal-installation	5-6-7	01-92
540 – 750 – 1000 rpm PTO – Disassembly – Assembly	7-8-9-10- 11-12-13	01-92
Sectional view of ground- speed PTO	13	01-92
Replacement of PTO brake engagement electro-valve ..	14	01-92
Replacement of PTO engage- ment electro-valve	14	01-92
33 – BRAKES		
Specifications – Torque data ..	1	01-92
Service tools – Sectional views	2	01-92

	Page	Date
Trouble-shooting	3	01-92
Removal-installation of brake unit, RH or LH	4-5-6-7	01-92
Removal-installation of brake hydraulic pump	7-8-9	01-92
Brake pedal adjustment	9	01-92
Air bleeding brake hydraulic system	10	01-92
Disassembly-assembly of hand brake sector plate sup- port	11-12-13- 14-15	01-92
Travel adjustment of parking brake hand control lever	16	01-92

35 – HYDRAULIC SYSTEMS

Specifications	1-2-3-4-5- 6-7	01-92
Torque data	8	01-92
Service tools	8-9	01-92
Trouble-shooting	10-11	01-92
Rear-mounted hydraulic lift – Removal – Installation	12-13-14	01-92
Rear lift external controls – Disassembly – Assembly	14-15	01-92
Rear lift inside controls – Di- sassembly – Assembly – Ad- justments	15-16-17- 18-19-20	01-92
Rear lift linkage adjustment ..	21-22	01-92
Rockshaft and hydraulic cylin- der – Disassembly – Assem- bly	22-23	01-92
Lift control valve – Removal – Installation	24	01-92
Lift control valve removed – Disassembly – Assembly	24-25-26- 27	01-92
Lift adjustments	28	01-92
Oil filter replacement	28	01-92
Lift safety valve – Removal – Installation	29	01-92
Auxiliary rams – Removal – Installation	30	01-92
Lift oil pump – Removal – In- stallation	31	01-92
Lift and power steering pump mounting support – Removal – Installation	31-32	01-92

41 – STEERING

Specifications	1-2	01-92
Sectional view of the hydro- static steering control valve ..	3	01-92
Trouble-shooting	4-5	01-92

	Page	Date
Service tools	5	01-92
Power steering cylinder – Removal – Installation	6-7	01-92
Power steering control valve – Removal – Installation	7-8-9	01-92

44 – FRONT AXLE AND WHEELS

Specifications	1	01-92
Torque data	2	01-92
Service tools	2	01-92
Trouble-shooting	2	01-92
Front axle – Removal – Installation	3-4	01-92
Front axle wheel hub – Disassembly – Assembly	4-5	01-92
Steering knuckle – Overhauling	6-7	01-92
Front steering wheel alignment check	7-8	01-92

50 – AUXILIARY UNITS

Cab air conditioning system

Safety rules	1	01-92
Cab versions	2	01-92
Special service tools for air conditioning system	3	01-92
Heated and ventilated cab controls	4	01-92
Air conditioned cab controls ..	5	01-92
Specifications	6	01-92
Operation	6-7	01-92
Main components	8-9-10-11	01-92
Repair notes	11	01-92

Cab air conditioning system charging and discharging

Charging station	12-13	01-92
System filling	13-14-15-16-17	01-92
Operation checks	17-18	01-92
Summary of charging operations	18	01-92
Leakage search (refrigerant fluid)	19	01-92
Fault search	20	01-92

	Page	Date
Air conditioning system trouble-shooting guide	21-22-23-24	01-92
Maintenance	25	01-92
Discharging the system	25	01-92
Plant lay-out and flow chart	25	01-92

Servicing and repair procedures

Evaporator – Replacement ..	26	01-92
System hoses upstream of compressor – Replacement ..	27-28-29-30-31	01-92
System hoses downstream of quick-connect couplings – Replacement	31-32	01-92
Receiver-drier filter – Replacement	32	01-92
System hoses downstream of compressor – Replacement ..	33	01-92
Condenser – Replacement ..	34	01-92
Compressor – Removal-Installation	34-35-36	01-92

Compressor overhauling and maintenance

Filling and checking lube oil level	36	01-92
Electro-magnetic clutch replacement	37-38-39-40	01-92
Drive shaft oil seal replacement	40-41-42	01-92
Valve plate and head replacement	42-43-44	01-92
Drive belt installation and tension check	44	01-92

Heater and electric fan overhauling

Electric fan, disassembly – assembly with conditioner and heater units installed	45	01-92
Cab heater, disassembly – assembly with conditioner and heater units installed	46-47-48	01-92

GENERAL – MAINTENANCE

00 – 6

	Page	Date		Page	Date
Heater delivery and return hoses – Replacement	49–50–51	01–92	Door handle and lock, RH or LH side – Replacement	5	01–92
Engine piping connecting hoses, delivery and return – Replacement	51–52	01–92	Cab door glass – Replacement with door removed	6	01–92
55 – ELECTRICAL SYSTEM					
Windshield wiper motor _ Removal – Installation	1	01–92	Cab door weatherstrip, RH or LH side – Replacement	7	01–92
Windshield washer fluid line connecting check valve and jet spray – Replacement	2	01–92	Cab door alignment and closing – Adjustment	8	01–92
Windshield washer jet spray nozzle – Replacement	2	01–92	Cab rear side window glasses – Replacement	9	01–92
Rear window glass wiper motor – Removal – Installation ..	3	01–92	Cab rear window glass – Replacement and adjustment ...	10–11–12	01–92
Rear window glass fluid line connecting check valve and jet spray – Replacement	3–4–5–6	01–92	Rear window glass seal – Replacement	13	01–92
Rear window glass jet spray nozzle – Replacement	7	01–92	Lower rear window glass	13	01–92
90 – BODY AND OPERATOR'S CAB					
Paints	1	01–92	Cab roof safety hatch – Removal – Installation	14	01–92
Cab windshield glass – Replacement	2–3–4	01–92	Side pillar trim – Replacement	15	01–92
Cab door, RH or LH side – Removal – Installation	4–5	01–92	Rear cab headliner – Replacement	16	01–92
			Cab front left–hand side headliner – Disassembly – Assembly	17–18–19	01–92
			Cab front right–hand side headliner – Disassembly – Assembly	19	01–92
			Cab central headliner – Disassembly – Assembly	20–21	01–92

GENERAL INSTRUCTIONS

IMPORTANT NOTICE

All service interventions dealt with in this Manual are intended to be the exclusive competence of the FIATAGRI Service world network organization and must be carried out in the absolute respect of the indications given hereafter, using, whenever necessary, the envisaged special service tools and equipment.

Anyone attempting to or carrying out work and operations included in this Manual without following full instructions and specifications makes himself personally and directly responsible for resulting damages.

ADJUSTMENTS

At each adjustment operation, select shim packs by measuring shims one by one with a micrometer gauge and summing up readings obtained: do not preventively rely on shim pack thickness or on nominal values of shims.

ROTARY SHAFT OIL SEALS

When installing oil seals on rotary shafts, pay attention to the following:

- prior to fitting, keep seals dipped for at least half an hour in the very fluid which is to be retained at work;
- thoroughly clean the shaft and make sure working surfaces are free from damages or faults of any kind;
- place seal with the lip facing the fluid; if the seal is of the thrower-lip type, grooves must be so oriented that during shaft rotation the fluid tends to be thrown back towards the inside of the machine part or component containing it.
- coat the sealing lip with a thin film of lubricant (possibly oil instead of grease) and pack the space between sealing lip and dust shield with grease;
- fit the seal in place pressing it or driving it with a flat-head tool or ram of the right diameter: on no account strike it with a hammer or mallet;
- when being pressed or driven in place, make sure that the seal is introduced perpendicularly to the seat surface and, once fitted, check that the seal is fully home and seated properly;
- to prevent seal lip damage during fitting, use some sort of protection interposed between mating surfaces of seal and shaft.

TOROIDAL “O-RING” OIL SEALS

Lubricate O-ring seals prior to installation to prevent their rolling over themselves and remain twisted during fitting.

JOINT SEALING COMPOUNDS

Upon joining mating surfaces indicated by an “X”, apply one of the following sealing compounds: RTV SILMATE, RHO-DORSIL CALF 1 or LOCTITE PLASTIC GASKET.

Prior to sealing compound application, prepare the joint surfaces as follows:

- remove scales or encrusted matter using a wirebrush;
- thoroughly degrease surfaces using one of the following detergents: solvent (trichloroethylene), kerosene or water/soda solution.

BEARINGS

Suggested bearing preparation procedure prior to installation:

- heat to 80 to 90°C (176 to 194°F);
- cool them off before force fitting in place.

ROLL PINS

When fitting split pins make sure the cut is facing in the direction of force in order to put the pin under stress. Instead, spiral pins do not require any particular way of fitting.

SPARE PARTS INFORMATION

Use exclusively FIATAGRI genuine spare parts identified with the trademark shown below.



FIATAGRI Parts



These are the same and only spares assuring the standards of quality, safety and service life of the original parts fitted at the Factory.

Only the FIATAGRI original spare parts can offer this guarantee.

When ordering spare parts make sure to state:

- tractor model (marketing denomination) and chassis serial number;
- engine type and serial number;
- part number, found on microfish or printed Spare Parts Catalogue.

SERVICE TOOL INFORMATION

The service tools that FIATAGRI proposes and illustrates in this Manual are:

- studied and designed specifically for the FIAT tractor range;
- essential for technically reliable repairs and service work;
- manufactured and tested conforming to strict quality standards to offer efficient and long lasting service.

Service workshops and staff are also reminded that being equipped with the right tools means:

- operating in optimum working conditions;
- obtaining the best results;
- saving time and fatigue;
- working in more safety.

NOTE

Permissible wear limits suggested in this Manual for some of the parts or components are to be considered indicative only and absolutely not binding.

"Front", "rear", "right" and "left" indications given throughout this Manual are referred to the tractor operator seated on board and facing the direction of forward travel.

WHEN PUTTING IN MOTION A TRACTOR WITHOUT BATTERY

Outside feeder cables must be connected exclusively to the respective positive and negative cable terminals of the tractor using efficient clamps ensuring an adequate and stable electric contact.

Disconnect all user circuits (lights, windshield wipers, etc.) prior to starting the tractor.

Should it be necessary to make functional checks of the tractor electrical system, make sure the feeder is connected; upon completion of check, disconnect all user circuits and put off the feeder before disconnecting the cables.

SAFETY RULES

PAY ATTENTION TO THIS WARNING SIGN



This symbol alerts you for important messages involving your safety. Read messages attentively and strictly follow suggested precautions designed to avoid potential dangers and safeguard your health and personal safety. You will find, throughout this manual, this sign associated with the following keywords:



ATTENTION – Warning intended to prevent unsuitable repair procedures with potential consequences to repairman's safety.

DANGER – Associated with warnings of specific potential dangers for the repairman and any other people directly or indirectly involved.

AVOID ACCIDENTS

Most accidents occurring in the workshop are a consequence of the failure to follow some simple and prudential safety rule. For this reason **MOST ACCIDENTS CAN BE AVOIDED**: it is enough to recognize possible causes and act consequently, using the necessary attention and precautions.

Handling any type of machine, regardless of how well it has been designed and manufactured, cannot exclude the possibility that an accident may occur.

A cautious and alert repairman is the best guarantee against accidents.

Scrupulous observance of a single elementary safety rule would already be sufficient to avoid many serious accidents.

DANGER. Never attempt to clean, lubricate or service a tractor with engine running.

- ◇ Never attempt to operate the machine or any attached implement or equipment in any position other than the operator's seat.
- ◇ Never attempt any intervention of any kind on the machine when engine is running, unless the case is conforming to instructions
- ◇ Shut the engine off and check that hydraulic fluid is no longer under pressure before removing caps, covers, valves, etc.
- ◇ All servicing operations deserve best care and attention.
- ◇ Shop or field ladders and service stands should conform to present accident prevention regulations.
- ◇ Disconnect batteries and put signs on all controls to warn that the machine is being repaired or serviced. Block the machine and any attached implement or equipment to be lifted.
- ◇ Never check or fill fuel tanks and batteries, or use preheating fluid, while smoking or when there are open flame sources in the vicinity, as fluids involved are highly inflammable.
- ◇ Brakes are inactive when manually released for servicing: in such cases the machine should be secured with blocks or similar devices.
- ◇ The fuel gun must be steadily kept in contact with the filler cap while re-fuelling: the contact must be maintained until fuelling is completed to avoid the possibility of sparks consequent to accumulation of static electricity.

SAFETY RULES

GENERAL

- ◇ Pay your best attention to given maintenance and repair procedures.
- ◇ Do not wear rings, wrist watches, jewelry, loose or hanging apparel such as ties, torn clothing, scarves, unbuttoned or unzipped jackets that can catch on moving or rotating mechanical parts. Wear instead safety prevention clothing, for example: anti-skid shoes, gloves, safety glasses, helmets, ect.
- ◇ Do not carry on any work on the machine with anyone on the operator' seat unless recognized as a qualified operator called to assist with the work at hand.

GENERAL – MAINTENANCE

00 – 10

- ◇ When towing use exclusively the prescribed towing or pulling points. Take care in making attachments: be sure pins and locks are sure before pulling. Stay clear of drawbars, cables or chains under load.
- ◇ To move a disabled machine, use a trailer or low-body truck if available.
- ◇ Load or unload the machine on level grounds affording full support to the trailer or truck wheels. Fix the machine securely to the trailer or truck platform and block wheels as required for transport.
- ◇ Use exclusively grounded auxiliary power sources to feed electric heaters, battery-chargers and similar equipment in order to avoid the hazards of electric shocks.
- ◇ If necessity arises to handle or transport heavy parts and components, make sure to use hoists or similar equipment of appropriate lifting capacity.
- ◇ Always watch out for presence of people in the vicinity.
- ◇ Never pour gasoline or diesel fuel into open or wide and low containers.
- ◇ Never use gasoline, diesel fuel or other flammable liquids detergents: use, instead, non-flammable and non-toxic solvents available in commerce.
- ◇ When using compressed air to clean parts, wear safety glasses with side protections.
- ◇ Limit the pressure within a maximum of 2.1 bar, conforming to local or national legislation.
- ◇ Do not run engines in closed premises not adequately ventilated.
- ◇ Do not smoke and neither use or allow open flames or sparking in the vicinity, when re-fuelling or handling easily flammable materials.
- ◇ Do not use flames for lighting purposes when searching for sources of fluid leaks on the machine.
- ◇ Move very carefully when working under the machine and also on it or in the vicinity of the same. Wear the prescribed safety equipment: helmets, glasses and special shoes.
- ◇ When carrying on checks requiring engine running, call for the help of a qualified assistant remaining in the operator seat at all times with the repairman in sight.
- ◇ For field service, bring the machine possibly on level grounds and block it. If the job must be necessarily carried out on a gradient, preventively block the machine and move it on a level area as soon as feasible and affording adequate safety.
- ◇ Beware of kinky or bent chains and cables, do not use them for lifting or towing. To handle them, wear thick gloves.
- ◇ Chains should always be anchored securely: check that anchoring point is robust enough to carry the load. Keep people clear of anchor point, chains or towing cables.
- ◇ Keep maintenance and servicing areas always CLEAN and DRY. Remove any water or oil puddles immediately.
- ◇ Do not pile up grease or oil-impregnated rags: they are a fire hazard. Always tear them in a closed metal container. Before moving the machine or attached implement, check, adjust and block the operator seat. Also make sure no people are in the immediate vicinity within operating area of machine or implements.
- ◇ Do not hold in your pockets objects that may fall, unseen, inside the machine.
- ◇ Where metal particles or objects are apt to fly or fall, wear protective equipment such as goggles or safety glasses with side shields, hard hats or helmets, safety shoes and heavy gloves.
- ◇ When welding is required, wear the specific protective accident-prevention equipment: dark glasses, helmets, overalls, special gloves and shoes. Dark glasses must be worn also by anyone standing by while welding is in progress. **DO NOT LOOK AT ARK WITHOUT ADEQUATE EYE PROTECTION.**
- ◇ Wire ropes develop metallic sleeves with use: protect yourself by wearing adequate safety equipment (heavy gloves, glasses ect.).
- ◇ Handle all parts with extreme care. Keep hands and fingers off rotating parts, closed parts and open joints and similar. Always use the authorized accident prevention clothing items, such as safety glasses, heavy gloves and safety shoes.

STARTING

- ◇ Do not run engines inside closed premises without adequate ventilation or equipped with suitable means for removal of exhaust gases.
- ◇ Never bring head, body, arms and legs, feet, hands and fingers close to running fans or drive belts.

ENGINE

- ◇ Before removing the radiator cap, turn it very slowly in order to remove inside pressure. Add coolant only with engine stopped or idling, if warm.
- ◇ Do not let the engine run when re-fuelling, particularly if still hot, owing to the possibility of fire hazard if fuel is spilled over.
- ◇ Never attempt to check or adjust fan belts when engine is running. Do not adjust the engine fuel pump when the machine is in motion.
- ◇ Never lubricate the machine when the engine is running.

ELECTRIC SYSTEM

- ◇ When using auxiliary batteries, remember that cables must be connected at both ends following the prescribed procedure: (+) with (+) and (-) with (-). Avoid short-circuiting battery posts. **BATTERY GAS IS HIGHLY INFLAMMABLE.** When re-charging, let the battery compartment open, thus affording a better ventilation. Never check battery charge by "bridging" across posts with metal objects. Avoid sparks or flames in the battery area. Do not smoke, to prevent explosions.
- ◇ Prior to servicing interventions of any sort, make sure there are no fuel or electrical leaks or losses: remove and rectify them before proceeding with work.
- ◇ Do not re-charge batteries inside closed premises: make sure ventilation is adequate to prevent the possibility of accidental explosions caused by the accumulation of battery gas produced during the charging process.
- ◇ Always disconnect batteries prior to interventions of any kind involving the electric system.

HYDRAULICS

- ◇ Fluid escaping under pressure through a small hole can be almost invisible and can develop sufficient striking force to penetrate the skin; in these cases, should it be necessary to verify the leak, protect yourself using a cardboard or a piece of wood. **NEVER DO IT WITH YOUR BARE HANDS:** if the fluid spray penetrates the skin, see a doctor immediately. In fact, without qualified medical assistance, a serious infection or reaction may develop.
- ◇ When measuring fluid pressure, use a gauge compatible with expected values.

WHEELS AND TYRES

- ◇ Make sure tyres are inflated correctly to the pressure specified by the Manufacturer. Periodically check for damages at wheel rims and tyres.
- ◇ Stand to one side when correcting pressure or inflating tyres.
- ◇ Check tyre pressure on unloaded machines and with cold tyres only in order to avoid erroneous readings with resulting overinflation. Do not use recovered wheel parts because improper welding, brazing or heating may have weakened them and caused failures.
- ◇ Never cut or weld on the rim of mounted and inflated tyre.
- ◇ To remove wheels, block front the machine at front and rear on all wheels. After lifting the machine, place supports underneath to prevent it from falling, according to present regulations.
- ◇ Deflate the tyre before attempting to remove objects caught in the threads.
- ◇ Never inflate tyres using an inflammable gas: explosions with injuries to nearby people may occur.

REMOVAL – INSTALLATION WORK

- ◇ Lift and handle all heavy parts using means and equipment of adequate capacity. Make sure appropriate hooks and slings are used. Use the lifting eyes specifically provided. Watch out for people in the vicinity of the load to be lifted.
- ◇ Handle all parts with extreme care. Keep hands and fingers away from open joints between parts components. Wear homologated accident-prevention safety clothing such as goggles, gloves and special shoes.
- ◇ Guard against twisted and kinking chains and cables. Always wear safety gloves to handle chains or cables.

GENERAL – MAINTENANCE
00 – 12

LUK 13"/13" CLUTCH (F100–F110–F120)

Type	single, dry-plate with torsion springs
Control	hydrostatically operated, pedal control
Release mechanism	diaphragm spring
Clutch plate friction material	cerametallic buttons
Clutch plate total thickness under a load of 8800 N – 897 kg or 2280 lb)	9.6 to 10.4 mm (.38 to .41 in)
Spline backlash on gearbox drive shaft	0.076 to 0.136 mm (.003 to .005 in)
Clearance fit of throw-out collar	0.060 to 0.136 mm (.002 to .005 in)
Clutch pedal mounting adjustment	see page 18–10

LUK 14"/14" CLUTCH (F130)

Type	single, dry-plate with torsion springs
Control	hydrostatically operated, pedal control
Release mechanism	diaphragm spring
Clutch plate friction material	cerametallic buttons
Clutch plate total thickness under a load of 8800 N – 897 kg or 2280 lb)	10.1 to 10.9 mm (.40 to .43 in)
Spline backlash on gearbox drive shaft	0.076 to 0.136 mm (.003 to .005 in)
Clearance fit of throw-out collar	0.060 to 0.136 mm (.002 to .005 in)
Clutch pedal mounting adjustment	see page 18–10

CLUTCH

18 - 2

TORQUE DATA

DESCRIPTION	Thread size	Torque		
		Nm	kgm	ft.lb
Capscrews and nuts, clutch case to engine (C ₁)	M 12 x 1.25	88	9	65
Capscrews, clutch to engine flywheel (C ₂)	M 8 x 1.25	23	2.4	17.5
Screws, shift forks (C ₃)	M 16 x 1.5	157	16	116


SERVICE TOOLS

ATTENTION – Operations included in this section of the Manual must be performed using the **ESSENTIAL** tools further evidenced by the identification code (X).

Besides, to work safely and achieve the best technical results, with additional savings of time and fatigue, these mandatory tools should be used in conjunction with the suggested special tools listed below and further integrated with the self-made ones for which you will find the necessary working drawings and specifications directly on this manual.

List of the special tools necessary to perform service operations covered by this section of the Manual:

- 292320 Workshop stand, tractor disassembly
- X 293974 Spigot, clutch centering (on tractor)
- 292888 Pilot pins, transmission housing/engine alignment



Longitudinal sectional view of LUK 13" and 14" clutches

a. LUK 13" clutch – b. LUK 14" clutch – C₁. Capscrew, clutch case to engine – C₂. Capscrew, clutch to engine flywheel – C₃. Lockscrew, clutch release levers – 1. Diaphragm spring – 2. Master clutch plate – 3. Splined hub, PTO oil clutch shaft control – 4. Throw-out collar and thrust bearing – 5. Throw-out collar (4) shift fork – 6. Clutch cover – 7. Fixed collar cover.

ENGINE CLUTCH TROUBLE-SHOOTING CHART

Fault	Diagnosis	Correction
Clutch slips	<ol style="list-style-type: none"> 1. Lack of clearance (G, page 18-12) between rod and hydraulic pump piston. 2. Disk (2) and/or pressure plate and flywheel wear. 3. Weak or unserviceable diaphragm spring (1). 4. Oil or grease on clutch disk (2) facings. 	<p>Replace pump.</p> <p>Replace disk and the clutch, if necessary, and grind the flywheel.</p> <p>Replace clutch.</p> <p>Replace disk, eliminate the cause for the presence of lubricants inside the clutch compartment and thoroughly clean friction surfaces.</p>

ENGINE CLUTCH TROUBLE-SHOOTING CHART

(cont.)

Fault	Diagnosis	Correction
Clutch grabs or chatters	<ol style="list-style-type: none"> 1. Tight external control linkage. 2. Bent or warped clutch disk (2, page 18-2). 3. Disk (2) hub tight on clutch shaft. 4. Disk (2) with damaged torsion damper springs or loose at hub (loose rivets). 5. Oil or grease on clutch disk (2) facings. 6. Diaphragm spring (1) with broken elements. 	<p>Check linkage pivot points and lubricate.</p> <p>Replace disk.</p> <p>Remove clutch and check meshing: if necessary, replace defective parts.</p> <p>Replace disk.</p> <p>Replace disk, eliminate the cause of the presence of lubricants inside the clutch compartment and thoroughly clean disk facings.</p> <p>Replace clutch.</p>
Clutch fails to disconnect and drags	<ol style="list-style-type: none"> 1. Bent or warped clutch disk (2). 2. Seizure of external controls. 3. Inefficient hydraulic pump and/or lower cylinder. 4. Disk (2) hub tight on clutch shaft. 5. Controls out of adjustment. 6. Presence of air inside the clutch hydraulic control system. 7. Diaphragm spring (1) with broken elements and/or damaged throw-out bearing. 	<p>Replace disk.</p> <p>Check, replace defective parts and lubricate.</p> <p>Overhaul or replace hydraulic pump and/or cylinder.</p> <p>Free disk and, if necessary, replace disk or clutch shaft.</p> <p>Adjust controls (see page 18-11).</p> <p>Bleed hydraulic system (see page 18-13) and, if necessary, replace pump and/or lower cylinder seals.</p> <p>Replace clutch and/or throw-out bearing.</p>
Clutch noise at engagement or disengagement	<ol style="list-style-type: none"> 1. Bent or warped clutch disk. 2. Clutch disk (2) with defective torsion damper springs. 3. Excessive backlash on clutch shaft and disk (2) hub meshing splines. 	<p>Replace disk.</p> <p>Replace disk.</p> <p>Replace disk and, if necessary, the clutch shaft.</p>
Clutch noise at disengagement	<ol style="list-style-type: none"> 1. Worn throw-out bearing. 	<p>Replace bearing</p>
Clutch control pedal hardness	<ol style="list-style-type: none"> 1. Broken or disconnected clutch return spring. 2. Seized pump plunger. 3. Tight external control linkage. 4. Hard pedal. 	<p>Replace or hook-up the return spring.</p> <p>Overhaul or replace hydraulic pump.</p> <p>Check linkage points and lubricate.</p> <p>Check linkage and lubricate.</p>

CLUTCH

18 - 4

LUK CLUTCH

Removal-Installation (Op. 18 110 10)

To gain access to the clutch, separate the engine with attached front axle or live axle from the transmission.




DANGER




Lift and handle all heavy components using lifting equipment of appropriate capacity. Ensure that units or parts are supported by suitable slings or hooks. Ensure that no one is in the vicinity of the load to be lifted.

Proceed as follows:




19603




19605

2. Disconnect the battery positive cable (3) and insulate properly.




19606

3. Remove the engine cooling radiator filler plug (4).



19604


1. Remove panels (1 and 2) on both sides.




19607

19608


4. Remove the radiator cooler drain pipe plug (5).




5. Remove the retaining screws (12) and tractor tool box (13).




8. Remove retaining screws and supporting bracket (6) of the previously disconnected lines (4 and 5).




6. Shut off the cock (3) on the line connecting main and auxiliary tanks.



9. Unscrew clamps (7 and 8) securing the heater-to-engine connecting lines (9).




7. If the cabin is air-conditioned, remove both refrigerant lines (4 and 5).




10. Remove the retaining screws of the supporting clamps (10 and 11) and subsequently the lines (9) from the engine.

CLUTCH


18 - 6




11. Slacken the engine accelerator cable supporting clamp (1) screw.




14. Loosen the feed line securing band clamp (6) and withdraw the former from its connection.




12. Snap off the stop spring (3), free the terminal section of cable (2) and finally withdraw the latter from the bracket (11).




15. Drain out approx. 2 liters or 1/2 gallon of fuel by removing plug (6, page 21-14), loosen band clamp (7) securing hose (8) and finally withdraw the latter from pipe (9).




13. Unscrew the fastenings of the brake oil lines supporting bracket (5) and remove the latter from the engine.




16. Pull out the windscreen washer fluid tubelet (10).




17. Loosen the breather line (2) clamp.




20. Unscrew the connections of the power steering cylinders oil lines (7) and remove them.




18. Back off the retaining clamp (3) screw and the tractor meter gauge (4) cable connection, then remove the instrument from the engine.



21. Unscrew the connections of the power steering hydrostatic unit oil lines (8) and remove them.




19. Disconnect electric leads (5 and 6).



22. Block the engine with respect to front axle or live front axle by installing two wood supporting blocks (9), one on each side, as shown in the figure.


CLUTCH

18 - 8




19631

23. Disconnect hose (2) from pipe (1) leading to the live front axle differential lock.




19635

26. Snap the retaining ring (7) open and move back sleeve (8) to free it from the front axle splined connection.




19632

24. Remove hose (3) from live front axle.



19636


27. Snap the retaining ring (9) open and move sleeve (10) forward to free it from the drive box splined connection.



19633


19634

25. Unscrew the fastenings, front (4), central (5) and rear screws securing the live front axle transmission and drive shafts guard (6).




19637

28. Back off the cap screws of the front axle transmission drive shafts mounting bracket (11).




29. Retrieve shafts (1) and respective supports.


Note – Operations 23 to 29 apply in case of 4WD tractors only.




32. Block rear wheels by pulling the hand brake or through wedge blocks suitably installed and then unscrew cap screws (C₁).




30. Support the rear end of the tractor through a stationary stand (2) positioned underneath the rear transmission case.



33. Split the tractor by separating engine and clutch case, move the former forward making sure that there no parts still connected or any undue resistance.




31. Place the tool 292320 (3) under the tractor positioning the stationary support underneath the clutch case and the two mobile parts under the tractor weights and engine oil sump, respectively.



34. Unscrew the clutch to engine flywheel fastening cap screws (C₂) and remove the clutch with the aid of the centralizer spigot tool no. 293974 (4).

CLUTCH

18 - 10



19644

35. Check the clutch disk (1) for wear and replace it if rivets are near to or flush with the cerametallic button friction surface.

36. When installing the clutch pay attention to the following:

- a. proceed by reversing the removal sequence of operations starting from no. 35 back to no. 1;
- b. torque tighten fastenings to specifications data of page 18-2;
- c. apply grease (**grassofiat TUTELA G9**) on the clutch disk splined drive;
- d. use special tool **293794** (4, page 18-9) to join clutch and flywheel correctly;
- e. screw on two centering dowels **292888** to ease installation, paying attention to avoid interferences;
- f. thoroughly clean and degrease mating surfaces prior to assembly.

CLUTCH HYDROSTATIC CONTROL

Pump removal-installation (Op. 18 104 15 - 18 104 30)

CAUTION

Handle all parts with great care. Do not put hands or fingers between parts.

Wear safety equipment such as goggles, gloves and special shoes.


CAUTION

Use suitable tools to align holes. DO NOT USE FINGERS OR HANDS.

Proceed as follows:

1. Remove body panels (1 and 2, page 18-4) on both sides.
2. Disconnect the battery positive cable (3, page 18-4) and insulate properly.


Print No. 603.54.276.00 - 01 - 1992



19645


19646

3. Remove the three side screws, the rear one (2) and finally the LH side protection (3).



19647


4. Disconnect the reservoir oil level gauge electric connecting (4).




19648

19649


5. Unscrew the oil delivery line (5) between pump and lower cylinder.




6. Remove the spring stops (1) and withdraw the pin (3) from fork (2).



7. Unscrew the fastenings (4) and retrieve the hydraulic pump (5) from engine side.




8. Slacken the band clamp (6) and retrieve it from the lever, remove screws (7).




9. Retrieve the hydraulic cylinder (8).
10. Install the clutch control assembly by reversing the removal sequence of operations and, in addition, adjust the pedal position as follows:

Height clutch pedal adjustment.

11. Adjust distance (D, page 12) prior to refitting the pump.




12. With clutch pedal (9) connected to fork (2) check that height (H) from center of pedal to the top surface of the mat is approx. 190 mm or 7-1/2 in.



13. If correction is needed, slacken the jam nut and turn the screw clockwise on the fork (2) until obtaining the desired height (H), then check that the free travel (A) of pedal (9) is 170 mm (6.69 in).

CLUTCH

18 - 12



Clutch hydrostatic control assembly

a. Operating pump - b. Lower cylinder - $G = .1$ to 1.4 mm (.004 to .055 in). Pin (6) clearance with clutch pedal at rest - $D = 137.5$ to 138 mm (5.41 to 5.43 in). Distance measured from center of fork (8) to the mounting flange on pump body - 1. Reservoir - 2. Pump body - 3. Spring - 4. Seal - 5. Plunger - 6. Pin - 7. Jam nut - 8. Fork - 9. Clutch control cylinder - 10. Spring - 11. Plunger - 12. Pin.

HYDROSTATIC CLUTCH CONTROL

Disassembly-Assembly (Op. 18 104 18 - 18 104 33)



CAUTION


Handle all parts with great care. Do not put hands or fingers between parts.

Wear safety equipment such as goggles, gloves and special shoes.




CAUTION

Use suitable tools to align holes. DO NOT USE FINGERS OR HANDS.




19658

Proceed as follows:




19657

1. Hold the pump in a workbench vise and withdraw the reservoir (1) from pump body (2).




19659

3. Retrieve plunger (5) and its spring (3).



4. Hold the lower hydraulic cylinder (1) in a workbench vise, slacken the band clamp (2) and remove hose (3).




5. Use compressed air to extract the plunger (4) and spring.
6. At re-assembly of the hydraulic pump and clutch control lower hydraulic cylinder pay attention to the following:
 - a. proceed by reversing the sdequence of operations starting from no. 5 back to no. 1;
 - b. inspect seals and replace them if necessary;
 - c. check sliding surfaces of pistons and seats.

HYDROSTATIC CLUTCH CONTROL

Air bleeding of the clutch control hydraulic system (Op. 18 104 05).

Air bleeding is necessary after any intervention on the hydraulic system.
Proceed as follows:


1. Accurately clean external surfaces in correspondance of the bleeding screw (6) and oil reservoir (5) cover.



2. Make sure that the reservoir (5) is filled to level before and after air bleeding.

Note – Previously drained oil must be thoroughly filtered before re-use.

3. Depress the clutch pedal **slowly and over its full travel run**, so to pressurize the system.



4. Hold the pedal depressed, loosen the bleed screw (6) half a turn and then let oil and air bubbles flow out.
5. Turn the screw (6) back on and repeat these operations until the oil flows out clean and free from air bubbles.
6. Operate the pedal again to pressurize the system; this condition exists when pedal operation is normal again.
7. Once the operation is completed top up the oil level in the reservoir (5).


CLUTCH

18 - 14

SYNCHRO-RANGE TRANSMISSION

Transmission	4-speed w/ constant-mesh, fully synchronized gears helical-tooth
Gear type	cascade scheme, 4 forward plus 4 reverse ranges for a total of 16 forward and 16 reverse speeds
Range gears	helical-tooth
– gear type	
– reduction ratios:	
low range	$(24 \times 15) : (46 \times 55) = 1 : 7.03$
medium range	$(24 \times 26) : (46 \times 40) = 1 : 2.95$
normal range	$(24 \times 29) : (46 \times 37) = 1 : 2.45$
high range	1
Transmission and range shift controls	separate, w/ two hand levers located on the RH side of the operator.
Lubrication	forced-feed, w/ gear-type pump (the same of power steering)
I.D. of transmission driven gears (1)	60.060 to 60.090 mm (2.3645 to 2.3657 in)
O.D. of respective bushings (2)	59.981 to 60.000 mm (2.3614 to 2.3622 in)
Radial clearance of gears and bushings	0.060 to 0.109 mm (.0024 to .0043 in)
Dia. of transmission driven shaft (3)	49.375 to 49.391 mm (1.9439 to 1.9445 in)
I.D. of bushings (2)	49.400 to 49.430 mm (1.9449 to 1.9445 in)
Radial clearance of shaft in bushings	0.009 to 0.055 mm (.0003 to .0022 in)
I.D. of range driven gears (4)	60.060 to 60.090 (2.3645 to 2.3657 in)
O.D. of respective bushings (5)	59.981 to 60.000 (2.3614 to 2.3622 in)
Radial clearance of gears and bushings	0.060 to 0.109 mm (.0024 to .0043 in)
Dia. of range driven shaft (6)	49.375 to 49.391 mm (1.9439 to 1.9445 in)
I.D. of bushings (5)	49.400 to 49.430 mm (1.9449 to 1.9460 in)
Radial clearance of shaft in bushings	0.009 to 0.055 mm (.0003 to .0022 in)

(follows)



20347

TRANSMISSION

Product: New Holland Fiat F100/F110/F120/F130 Turbo Tractors Service Repair Manual

File Download: <https://www.aresairmanual.com/downloads/new-holland-fiat-f100-f110-f120-f130-turbo-tractors-service-repair-manual/>


0-f110-f120-f130-turbo-tractors-service-repair-manual/

SYNCHRO-RANGE TRANSMISSION

(cont.)

Dia. of power take-off drive shaft (1), at bushing location	31.950 to 31.975 mm (1.2579 to 1.2588 in)
I.D. of force-fitted bushings (2)	31.990 to 32.085 ^(°) mm (1.2594 to 1.2632 in)
Radial clearance of shaft in bushings	0.015 to 0.135 mm (.0006 to .0053 in)
Thickness of transmission drive shaft (3) rear bearing thrust washer ...	2.950 to 3.000 mm (.1161 to .1181 in)
Adjustment of range-gear drive shaft bearings	see page 21-35
Thickness of range-gear drive shaft (4) bearing shims	1.70 - 1.80 - 1.90 - 2.00 - 2.05 2.10 - 2.15 - 2.20 - 2.25 - 2.30 - 2.35 2.40 - 2.45 - 2.50 - 2.55 - 2.60 2.65 - 2.70 - 2.75 - 2.80 - 2.85 - 2.90 2.95 - 3.00 - 3.10 - 3.20 - 3.30 mm (.067 - .070 - .074 - .078 - .080 - .082 .084 - .086 - .088 - .090 - .092 - .094 -.096 - .098 - .100 - .102 - .104 - .106 - .108 - .110 - .112 - .114 - .116 .118 - .122 - .126 - .130 in)
Adjustment of range-gear driven shaft bearings	see page 21-35
Thickness of range-gear driven shaft (5) bearing shims	1.70 - 1.80 - 1.90 - 2.00 - 2.05 2.10 - 2.15 - 2.20 - 2.25 - 2.30 - 2.35 2.40 - 2.45 - 2.50 - 2.55 - 2.60 2.65 - 2.70 - 2.75 - 2.80 - 2.85 - 2.90 2.95 - 3.00 - 3.10 - 3.20 - 3.30 mm (.067 - .070 - .074 - .078 - .080 - .082 .084 - .086 - .088 - .090 - .092 - .094 -.096 - .098 - .100 - .102 - .104 - .106 - .108 - .110 - .112 - .114 - .116 .118 - .122 - .126 - .130 in)
Pressure-relief valve spring (1, page 21-10):	
- free length	127 mm (5.0 in)
- length under load of 278 to 304 N (28.4 to 31 kg = 72.1 to 78.7 lb) ...	102.5 mm (4.03 in)
Working pressure	16 bar (16.3 kg/cm ²) = (232 psi)
Lubrication pressure-relief valve (2, page 21-10):	
- free length	35.5 mm (1.40 in)
- length under load of 37 to 41 N (3.8 to 4.2 kg = 9.6 to 10.7 lb)	25.5 mm (1.0 in)
Lubrication pressure	6.5 to 7 bar (6.6 to 7.1 kg/cm ²) = (94.2 to 101.5 psi)

(°) Final dimension without reaming.



Sample of manual. Download All 320 pages at:

<https://www.aresairmanual.com/downloads/new-holland-fiat-f100-f110-f120-f130-turbo-tractors-service-repair-manual/>

Print No. 603.54.276.00 - 01 - 1992