



# FIAT 86 Series Tractors

**3-cylinder engine models: 50V 55V 55F 60V 60F 62F**

**4-cylinder engine models: 70V 72F 72LP 82F 82LP**

## WORKSHOP MANUAL

### SECTIONS

<b>INDEX .....</b>	<b>A</b>
<b>GENERAL – MAINTENANCE .....</b>	<b>00</b>
<b>ENGINE .....</b>	<b>10</b>
<b>CLUTCH .....</b>	<b>18</b>
<b>TRANSMISSION .....</b>	<b>21</b>
<b>LIVE AXLE DRIVE .....</b>	<b>23</b>
<b>FRONT DRIVE AXLE .....</b>	<b>25</b>
<b>REAR DRIVE .....</b>	<b>27</b>
<b>POWER TAKE-OFF .....</b>	<b>31</b>
<b>BRAKES .....</b>	<b>33</b>
<b>HYDRAULIC SYSTEMS .....</b>	<b>35</b>
<b>STEERING .....</b>	<b>41</b>
<b>FRONT AXLE .....</b>	<b>44</b>
<b>ACCESSORIES .....</b>	<b>50</b>
<b>ELECTRICAL SYSTEM .....</b>	<b>55</b>
<b>CAB AND DRIVE STATION .....</b>	<b>90</b>

Product: New Holland Fiat 86 Series Tractors Service Repair Manual

Full Download: <https://www.arepairmanual.com/downloads/new-holland-fiat-86-series-tractors-service-repair-manual/>

## FOREWORD

◊ *This Manual is subdivided into separately numbered (two-digits) Sections, each with independently numbered pages.*

*For quick cross-reference, these Sections have the same identification number and denomination of the units appearing on the Repair Time Manual.*

◊ *Topics and information contained herein can be easily traced by consulting the index pages that follow.*

◊ *Each page is identified at the bottom with the print number of the manual and the date of first issue or updating edition.*

◊ *Pages of future revised/updated editions will be identified with the same print number of the original edition, followed by a two-digit number (ex.: 1st updated edition 603.54.283.01; 2nd updated edition 603.54.283.02, etc.) and by the respective date of issue.*

*These pages will be accompanied by a reprint of the index, updated.*

◊ *All information herein are updated at the date appearing on the Manual. As NEW HOLLAND is constantly committed to product improvement, some information may not be to-date as a consequence of modifications implemented on the machines for technical or commercial reasons or for compliance to local legal requirements, differing in the various Countries.*

*In case of discrepancies, please contact our nearest Sales and Service point.*

## IMPORTANT NOTICES

◊ *All maintenance and repair operations appearing on this manual must be performed exclusively by the FIATGRI Service network, which is committed to strictly follow the instructions and indications therein and to use, whenever necessary, the envisaged special tools.*

◊ *Whomever should carry out any operation or service work herein included without strictly following our indications and prescriptions will be held personally responsible for any ensuing damage.*

◊ *The Company and all of its Distributors, including but not limited to national, regional or local distributors, decline any and all responsibilities for any damage which may ensue from the abnormal behaviour of parts and/or components not duly authorized by the Company, including any of these used in carrying on maintenance and repair work on the product manufactured or distributed by the Company.*

*In any case, no warranty coverage of any kind will be issued or prescribed regarding the product manufactured or distributed by the Company for damages consequent to an abnormal behaviour of parts or components which have not been duly authorized by the Company.*

COPYRIGHT BY NEW HOLLAND FIAT S.p.A.



Reproduction of text and illustrations, in whole  
or in part, is strictly prohibited.

PRINTED IN ITALY

NEW HOLLAND FIAT S.p.A. – Viale delle Nazioni, 55 – 41100 MODENA – Italy  
Sample of manual Download All 443 pages at  
AFTER SALES SERVICE – Technical Publication & Tools  
<https://www.arepairmanual.com/downloads/new-holland-fiat-86-series-tractors-service-repair-manual/>  
Print No. 603.54.283.00 – 09 – 1994 – 500

	Page	Date		Page	Date
<b>A – INDEX</b>					
Index .....	1÷10	09-94	Engine crankcase main data – Checks, dimensions, repairs .....	63-64	09-94
<b>00 – GENERAL – MAINTENANCE</b>					
General instructions .....	1-2	09-94	Crankshaft, bearings and flywheel main data – Checks, dimensions, repairs .....	65÷68	09-94
Safety .....	3-4-5	09-94	Connecting rod, piston main data – Checks, dimensions, repairs .....	69÷72	09-94
<b>10 – ENGINE</b>					
General specifications .....	1	09-94	Valve timing gear, tappets, rocker arm main data – Checks, dimensions, repairs .....	73÷75	09-94
Lubrication and cooling main data .....	2	09-94	Valve timing diagram – Valve/rocker arm clearance adjustment .....	76	09-94
Timing and fuel system main data .....	3	09-94	Cylinder head main data – Checks, dimensions, repairs .....	77÷82	09-94
Longitudinal section of 3-cyl. engine, 50V 55V 60V 55F 60F 62F models .....	4	09-94	Flyweight type dynamic balancer main data – Checks, dimensions, repairs .....	83	09-94
Cross-section of 3-cyl. engine, 50V 55V 60V 55F 60F 62F models .....	5	09-94	Lubrication system main data – Checks, dimensions, repairs .....	84÷86	09-94
Longitudinal section of 4-cyl. engine, 70V 72F 82F 72LP 82LP models .....	6	09-94	Cooling system data – Checks, dimensions, repairs .....	87÷89	09-94
Cross-section of 4-cyl. engine, 70V 72F 82F 72LP 82LP models .....	7	09-94	Water pump/alternator belt tension adjustment .....	89	09-94
Torque wrench data .....	8	09-94	Crankshaft front end seal replacement .....	90÷92	09-94
Fuel injection system data, with BOSCH and C.A.V. pump calibration charts .....	9÷28	09-94	BOSCH injection pump Removal–Installation, timing check and air bleeding .....	93÷95	09-94
Fuel transfer pump main data .....	29	09-94	C.A.V. injection pump Removal–Installation, timing check and air bleeding .....	96÷98	09-94
Compression test .....	30	09-94	Cooling system thermostat replacement .....	99	09-94
Troubleshooting guide .....	31÷34	09-94	Radiator Removal–Installation .....	100-101	09-94
Service tools .....	35-36	09-94			
Engine removal–installation ..	37÷44	09-94			
Engine disassembly .....	45÷54	09-94			
General notes .....	55	09-94			
Engine assembly main operations .....	56÷62	09-94			

# INDEX

## A-2

---

	Page	Date		Page	Date
<b>18 – CLUTCH</b>					
10"/10" and 11"/11" LUK clutch main data .....	1	09-94	Transmission–creeper speed–reverser unit installed on model 50V 55V 60V 70V 55F 60F tractors. Specifications and data ..	2	09-94
10"/10" and 11"/11" VALEO clutch main data .....	2	09-94	Transmissions on model 50V 55V 60V 55F 60F tractors. Troubleshooting guide and service tools .....	3	09-94
11"/11" O.M.G. clutch main data – Service tools .....	3	09-94	12+4 transmission speed chart for model 50V 55V 60V tractors (30 km/h) .....	4	09-94
Torque wrench data – Longitudinal section of 10"/10" VALEO and LUK clutches ..	4	09-94	12+4 transmis. speed chart for mod. 55F 60F tractors (30 km/h) .....	5	09-94
Longitudinal section of 11"/11" VALEO clutch .....	5	09-94	12+4 transmission speed chart for mod. 70V tractors (30 km/h) .....	6	09-94
Longitudinal section of 11"/11" LUK clutch .....	6	09-94	<b>12+4 transmission torque data and sections for model 50V 55V 60V 70V 55F 60F tractors .....</b>	7	09-94
Longitudinal section of the 11"/11" O.M.G. clutch .....	7	09-94	20+8 transmission speed chart for model 50V 55V 60V (30 km/h) tractors .....	8	09-94
Clutch troubleshooting guide .....	8	09-94	20+8 transmis. speed chart for mod. 55F 60F (30 km/h) tractors .....	9	09-94
Removal–installation of 10"/10" LUK and VALEO, or of 11"/11" LUK, VALEO, O.M.G. clutches .....	9 ÷ 10	09-94	20+8 transmission speed chart for model 70V (30 km/h) tractors .....	10	09-94
Overhauling the 10"/10" LUK or VALEO clutch .....	11 ÷ 14	09-94	<b>Sectional views of 20+8 creeper speed for model 50V 55V 60V 70V 55F 60F tractors .....</b>	11	09-94
Adjusting the 10"/10" LUK or VALEO clutch .....	14 ÷ 16	09-94	12+12 transmission speed chart for model 50V 55V 60V (30 km/h) tractors .....	12	09-94
Adjusting the 10"/10" LUK or VALEO main and PTO clutch controls .....	16	09-94	12+12 transmission speed chart for model 55F 60F (30 km/h) tractors .....	13	09-94
Overhauling the 11"/11" LUK, O.M.G or VALEO clutch .....	17 ÷ 20	09-94	12+12 transmission speed chart for model 70V (30 km/h) tractors .....	14	09-94
Adjusting the 11"/11" LUK, O.M.G. or VALEO clutch .....	20 ÷ 22	09-94	<b>Sectional views of the 12+12 synchromesh mechanical reverser for model 50V 55V 60V 70V 55F 60F tractors .....</b>	15	09-94
Adjusting the 11"/11" LUK, O.M.G. or VALEO main and PTO clutch controls .....	23	09-94	Cross–sectional view of transmission installed on model 50V 60V 70V 55F 60F tractors .....	16	09-94
<b>21 – TRANSMISSION</b>					
Description and identification data for transmissions installed on model 50V 55V 60V 70V 55F 60F tractors ..	1	09-94	Longitudinal section of transmission installed on 50V 55V 60V 70V 55F 60F tractors .....	17	09-94

Page	Date	Page	Date		
Transmission-rear drive case Removal-installation .....	18	09-94	Lay-out scheme of 12+4 transmission for model 62F 72F 82F 72LP 82LP tractors (30 and 40 km/h versions) .....	32	09-94
Transmission-rear drive parts for model 50V 55V 60V 70V 55F 60F tractors – Disassembly–assembly with case removed .....	19÷22	09-94	12+4 transmission speed chart for model 62F 72F 82F tractors (30 and 40 km/h version) ...	33	09-94
Replacing rear bearing and splitter medium speed drive gear with bevel gear–differential unit installed (model 50V 55V 60V 70V 55F 60F (tractors) .....	23	09-94	12+4 transmission speed chart for model 72LP 82LP tractors (30 and 40 km/h versions) ...	34	09-94
Disassembly–Assembly of transmission drive shaft with bevel drive pinion shaft installed (model 50V 55V 60V 70V 55F 60F tractors). .....	24	09-94	<b>Torque data and sections of 12+4 transmissions for model 62F 72F 82F 72LP 82LP tractors .....</b>	35	09-94
Creeper speed–synchromesh reverser for model 50V 55V 60V 70V 55F 60F tractors. Description and Removal–Installation .....	24÷25	09-94	Lay-out scheme of 20+12 transmission for model 62F 72F 82F 72LP 82LP tractors (30 and 40 km/h versions) ...	36	09-94
Creeper speed gears, shaft and bearings for model 50V 55V 60V 70V 55F 60F tractors. Disassembly–Assembly with clutch–transmission case removed from tractor .....	25÷26	09-94	20+12 transmission speed chart for model 62F 72F 82F tractors (30 and 40 km/h versions) .....	37	09-94
Reverser gears, shafts and bearings for model 50V 55V 60V 70V 55F 60F tractors. Disassembly–Assembly with clutch – transmission case removed from tractor .....	27÷28	09-94	20+12 transmission speed chart for model 72LP 82LP tractors (30 and 40 km/h versions) .....	38	09-94
Transmission description and identification data (model 62F 72F 82F 72LP 82LP tractors)	29	09-94	<b>Sections of 20+12 creeper speed unit installed on model 62F 72F 82F 72LP 82LP tractors .....</b>	39	09-94
Transmission–creeper speed–reverser for model 62F 72F 82F 72LP 82LP tractors. Specifications and features .	30 ÷ 31	09-94	Lay-out scheme of 20+12 transmission for model 62F 72F 82F 72LP 82LP tractors (30 and 40 km/h versions) ...	40	09-94
Transmissions installed on model 62F 72F 82F 72LP 82LP tractors. Troubleshooting guide and service tools .....	31	09-94	12+12 transmission speed chart for model 62F 72F 82F tractors (30 and 40 km/h version) .....	41	09-94
			12+12 transmission speed chart for model 72LP 82LP tractors (30 and 40 km/h versions) .....	42	09-94

Page	Date	Page	Date		
<b>23 – LIVE AXLE DRIVE</b>					
Sections of 12+12 transmission reverser installed on model 62F 72F 82F 72LP 82LP tractors .....	43	09-94	4WD mecanical engagement and drive shaft. Main data .....	1	09-94
Cross-section of transmission installed on model 62F 72F 82F tractors .....	44	09-94	Service tools .....	1	09-94
Cross-section of transmission installed on model 72LP 82LP tractors .....	45	09-94	Torque data .....	2	09-94
Longitudinal section of transmission installed on model 62F 72F 82F 72LP 82LP tractors .	46	09-94	Drive shaft guard (model 50VDT 55VDT 60VDT tractors). Removal–Installation .....	2	09-94
Transmission–rear drive case installed on model 62F 72F 82F 72LP 82LP tractors. Removal–Installation .....	47	09-94	Drive shaft (model 50VDT 55VDT 60VDT tractors). Disassembly–Assembly .....	2	09-94
Inside components of transmission installed on model 62F 72F 82F 72LP 82LP tractors. Disassembly–Assembly with case removed .....	47 ÷ 52	09-94	Drive shaft guard (model 55FDT 60FDT 770VDT 62FDT 72FDT 82FDT 72LPDT 82LPDT tractors). Removal–Installation .....	3	09-94
Replacing rear bearing and medium speed range drive gear with bevel drive–differential installed (model 62F 72F 82F 72LP 82LP tractors) ....	53	09-94	Drive shaft and bearing (model 55FDT 60FDT 70VDT 62FDT 72FDT 82FDT 72LPDT 82LPDT tractors). Disassembly–Assembly .....	3	09-94
Creeper speed–reverser units installed on model 62F 72F 82F 72LP 82LP tractors. Description and Removal–Installation .....	54	09-94	Drive box shaft oil seal. Replacement .....	4	09-94
Creeper speed gears, shafts and bearings for model 62F 72F 82F 72LP 82LP tractors. Disassembly–assembly with clutch–transmission case removed .....	54 ÷ 55	09-94	Drive box. Removal–Installation .....	4	09-94
Reverser gears, shafts and bearings for model 62F 72F 82F 72LP 82LP tractors – Disassembly–Assembly with clutch transmission case removed .....	56 ÷ 57	09-94	Drive box. Disassembly–Assembly .....	5	09-94
<b>25 – FRONT DRIVE AXLE</b>					
Creeper speed gears, shafts and bearings for model 62F 72F 82F 72LP 82LP tractors. Disassembly–assembly with clutch–transmission case removed .....	54 ÷ 55	09-94	Drive box gear layout .....	6	09-94
Reverser gears, shafts and bearings for model 62F 72F 82F 72LP 82LP tractors – Disassembly–Assembly with clutch transmission case removed .....	56 ÷ 57	09-94	Torque wrench data .....	2–3	09-94
Reverser gears, shafts and bearings for model 62F 72F 82F 72LP 82LP tractors – Disassembly–Assembly with clutch transmission case removed .....	56 ÷ 57	09-94	Service tools .....	3	09-94
Reverser gears, shafts and bearings for model 62F 72F 82F 72LP 82LP tractors – Disassembly–Assembly with clutch transmission case removed .....	56 ÷ 57	09-94	Live axle and central pivot sections of model 50VDT 55VDT 60VDT tractors .....	4–5	09-94

Page	Date	Page	Date		
Live axle and central pivot sections of model 55FDT 60FDT 70VDT tractors .....	6-7	09-94	Live axle of model 55FDT 60FDT 70VDT 62FDT 72FDT 82FDT 72LPDT 82LPDT tractors. Removal-Installation .....	17	09-94
Live axle and central pivot sections of model 62FDT 72FDT 82FDT tractors .....	8-9	09-94	Live axle planetary-gear final drives of model 55FDT 60FDT 70VDT 62FDT 72FDT 82FDT of model 55FDT 60FDT 70VDT 62FDT 72FDT 82FDT Disassembly-Assembly .....	18	09-94
Live axle and central pivot sections of model 72LPDT 82LPDT tractors .....	9-10	09-94	Wheel hub and steering knuckle of model 55FDT 60FDT 70VDT 62FDT 72FDT 82FDT 72LPDT 82LPDT tractors. Disassembly-Assembly .....	19-20	09-94
NO-SPIN differential of model 50VDT 55VDT 60VDT - Operation and sections .....	11	09-94	Live axle bevel drive-differential unit of model 55FDT 60FDT 70VDT 62FDT 72FDT 82FDT 72LPDT 82LPDT tractors. Removal-Installation .....	20-21	09-94
Live axle assembly of model 50VDT 55VDT 60VDT tractors. Removal-Installation .....	12	09-94	Live axle bevel drive unit of model 55FDT 60FDT 70VDT 62FDT 72FDT 82FDT 72LPDT 82LPDT tractors. Overhauling .....	21-22	09-94
Wheel hub and steering knuckle of model 50VDT 55VDT 60VDT tractors. Disassembly-assembly .....	12-13	09-94	Bevel pinion bearing adjustment and shim (S1) thickness finding using the 293438/2 special tool (model 55FDT 60FDT 70VDT 62FDT 72FDT 82FDT 72LPDT 82LPDT tractors .....	22	09-94
Live axle bevel drive pinion cone point adjustment and shim (S2) thickness finding using the 293510 universal gauge (model 50VDT 55VDT 60VDT tractors) .....	14	09-94	Bevel pinion bearing adjustment and shim (S1) thickness finding using the 293510 universal gauge (model 55FDT 60FDT 70VDT 62FDT 72FDT 82FDT 72LPDT 82LPDT tractors .....	23	09-94
Bevel pinion bearing adjustment and shim (S1) thickness finding using the 293510 universal gauge (model 50VDT 55VDT 60VDT tractors) .....	15	09-94	Bevel pinion cone point adjustment and shim (S2) thickness finding using the 293400/1 special tool and 293510 universal gauge, (or 293400/1 and 293438/2 special tools). Model 55FDT 60FDT 70VDT 62FDT 72FDT 82FDT 72LPDT 82LPDT tractors .....	24	09-94
Bevel pinion bearing adjustment and and shim (S1) and (S2) thicknesses finding using the 293752 special tool (model 50VDT 55VDT 60VDT tractors) .....	15-16	09-94			
Differential bearing and bevel drive tooth backlash adjustments (model 50VDT 55VDT 60VDT tractors) .....	16	09-94			
Live axle central pivot installation on model 50VDT 55VDT 60VDT tractors .....	17	09-94			

# INDEX

## A-6

	Page	Date		Page	Date
Ring gear bearing adjustment and bevel drive tooth backlash check on model 55FDT 60FDT 70VDT 62FDT 72FDT 82FDT 72LPDT 82LPDT tractors ...	25-26	09-94	R.H. final drive section .....	15	09-94
Live axle differential of model 55FDT 60FDT 70VDT 62FDT 72FDT 82FDT 72LPDT 82LPDT tractors.			R.H. or L.H. final drive case.		
Overhauling .....	27	09-94	Removal-Installation .....	16	09-94
LIM-SLIP differential of model 55FDT 60FDT 70VDT 62FDT 72FDT 82FDT 72LPDT 82LPDT tractors.			R.H. or L.H. final drive.		
Overhauling .....	28-29	09-94	Disassembly-Assembly .....	16 17	09-94
Front wheels (all models)			<b>31 – POWER TAKE OFF</b>		
Toe-in adjustment .....	30	09-94	Main data .....	1-2	09-94
			Torque wrench data .....	2	09-94
			Service tools .....	3	09-94
			Sections .....	3 – 4	09-94
			540, 540/750 and 540/1000 rpm PTO's of model 50V 55V 60V 70V 55F 60F tractors.		
			Disassembly-Assembly .....	4-6	09-94
<b>27 – REAR DRIVE</b>			540, 540/750 and 540/1000 rpm PTO's of model 62F 72F 82F 72LP 82LP tractors.		
Bevel drive, differential and final drives.			Removal-Installation .....	6	09-94
Main data .....	1	09-94			
Torque wrench data .....	2	09-94	540, 540/750 and 540/1000 rpm PTO's of model 62F 72F 82F 72LP 82LP tractors.		
Bevel drive-differential sections .....	3	09-94	Disassembly-Assembly .....	7-8	09-94
Bevel drive, differential, final drive and differential lock troubleshooting guide .....	4-5	09-94	<b>33 – BRAKES</b>		
Service tools .....	5-6	09-94	Brakes and trailer brake control valve.		
Rear drive axle case.			Main data .....	1	09-94
Removal-Installation .....	7	09-94	Brake and control operation and sectional view .....	2	09-94
Bevel pinion shaft.			Brake unit torque wrench data and sections .....	3	09-94
Disassembly-Assembly .....	7	09-94	Service tools – Brake and trailer brake valve troubleshooting guide .....	4	09-94
Bevel drive adjustments .....	8 12	09-94	R.H. and L.H. brake.		
Differential lock.			Removal-Installation .....	5	09-94
Assembly-adjustment .....	13	09-94			
Application scheme of case-cover mating surface sealing compound .....	14	09-94			

	Page	Date		Page	Date
Brake drive plates removed. Disassembly–assembly .....	5	09–94	Neutral mode .....	16	09–94
Foot brake pedal travel and alignment adjustments .....	5	09–94	Arm lowering operation .....	17	09–94
Parking brake lever free travel adjustment .....	6	09–94	Rear–mounted hydraulic lift. Description and oil flow dia- grams .....	18–21	09–94
Trailer brake remote control valve – Operation and oil flow diagrams .....	7–8–9	09–94	Rear–mounted hydraulic lift. Removal–Installation .....	22	09–94
Trailer brake remote control valve – control linkage adjust- ment .....	10	09–94	Lift external control linkage. Disassembly–Assembly .....	23	09–94
			Lift internal control linkage. Disassembly–Assembly–Ad- justments .....	24–34	09–94
<b>35 – HYDRAULIC SYSTEMS</b>					
Rear–mounted hydraulic lift. Main data .....	1–2	09–94	Lift control linkage and LIFT– O–MATIC device. Adjustments .....	35–36	09–94
Rear–mounted hydraulic lift. Sections .....	3	09–94	Lift rocker shaft and power cylinder. Disassembly–Assembly .....	37–38	09–94
Hydraulic lift control valve. Sections .....	4	09–94	Lift control valve. Removal–installation .....	38	09–94
Hydraulic lift oil pump. Main data .....	5 – 6	09–94	Lift control valve. Sections .....	39	09–94
Implement carrier. Main data .....	7	09–94	Lift control valve removed. Disassembly–Assembly Checks– Adjustments .....	40–41	09–94
Remote control valves. Main data .....	8	09–94	Lift oil filter replacement .....	41	09–94
Lift – Implement carrier and drawing attachments – Oil pump and remote control valves. Torque wrench data .....	9–10	09–94	Lift hydraulic relief valve. Pressure setting adjustment ..	42–43	09–94
Service tools .....	11–12	09–94	Lift oil pump. Disassembly–Assembly .....	44–45	09–94
Lift troubleshooting guide ..	13	09–94	Draft control mechanism (model 62F 72F 82F 72LP 82LP tractors). Removal–Installation–Disas- sembly–Assembly .....	46–47	09–94
Lift oil flow diagram .....	14	09–94	Draft control mechanism (model 50V 55V 60V 70V 55F 60F tractors). Flexion bar replacement ..	48	09–94
Lift control valve perspective view .....	14	09–94			
Arm lifting operation .....	15	09–94			

# INDEX

## A-8

---

	Page	Date		Page	Date
Adjustable rod.			Pressure relief valve check		
Disassembly–Assembly . . . . .	49	09–94	with control valve installed . . . . .	24	09–94
KONTAK remote control valves.					
Description and operation . . . . .	50÷52	09–94			
KONTAK remote control valves.			<b>44 – FRONT AXLE AND WHEELS</b>		
Disassembly–Assembly . . . . .	53	09–94	Front axle.		
KONTAK remote control valves.			Main data . . . . .	1–2	09–94
Bench tests . . . . .	54–55	09–94	Torque wrench data . . . . .	2–3	09–94
SALAMI remote control valves.			Service tools . . . . .	3	09–94
Description and operation . . . . .	56÷58	09–94	Troubleshooting guide . . . . .	3	09–94
SALAMI remote control valves. Flow divider description and operation . . . . .	59	09–94	Front axle sections . . . . .	4	09–94
SALAMI remote control valves.			Front axle.		
Disassembly–Assembly . . . . .	60	09–94	Removal–Installation . . . . .	5	09–94
SALAMI remote control valves.			Wheel hub.		
Bench tests . . . . .	61	09–94	Disassembly–Assembly . . . . .	5–6	09–94
			Steering knuckle overhaul . . . . .	6	09–94
			Checking the front wheel asset . . . . .	7	09–94
<b>41 – STEERING</b>			<b>50 – ACCESSORIES</b>		
Hydraulic steering and oil pump.			<b>Cab air conditioning system</b>		
Main data . . . . .	1–2	09–94	Safety . . . . .	1	09–94
Torque wrench data . . . . .	2	09–94	Cab versions . . . . .	2	09–94
Hydraulic steering control valve. Sections . . . . .	3	09–94	Service tools . . . . .	3	09–94
Troubleshooting guide . . . . .	4–5	09–94	Heated and ventilated cab controls . . . . .	4	09–94
Service tools . . . . .	6	09–94	Air conditioned cab controls . . . . .	5	09–94
Control valve.			Specifications . . . . .	6	09–94
Removal–Installation . . . . .	6–7	09–94	Operation . . . . .	7–8	09–94
Control valve. Disassembly–assembly after removal . . . . .	8÷16	09–94	Main components . . . . .	9÷12	09–94
Control valve.			Servicing notes and precautions . . . . .	12	09–94
Bench test and safety/relief valve pressure setting . . . . .	17–18	09–94			
Hydraulic steering description of operation and working diagrams . . . . .	19÷21	09–94	<b>Refrigerant recovery–reclaiming and evacuation charge stations</b>		
Hydraulic pump.			Description and technical features . . . . .	13–14	09–94
Disassembly–Assembly after removal . . . . .	22–23	09–94			

	Page	Date		Page	Date
Recovering the refrigerant through the recovery-reclaiming station .....	15÷17	09-94	Conditioner thermostatic switch. Replacement .....	39	09-94
Evacuating and charging the system through the evacuation-charge station .....	18-19	09-94	<b>Electric fans and air cleaners for heated/ventilated or air conditioned cabs</b>		
Cab air conditioning system operation checks .....	20	09-94	Electric fan Disassembly-Assembly with conditioner heater or evaporator removed .....	39	09-94
Summary of system charging operations .....	21	09-94	Air cleaner, air conditioned or heated/ventilated cab. Replacement .....	40	09-94
Checking air outlet temperature inside the cab .....	22	09-94	<b>Heater/ventilation unit overhauling</b>		
Refrigerant fluid leakage search using the electronic leak detector .....	22-23	09-94	Cab heater/ventilation unit. Removal-Installation .....	40	09-94
Summary of the cab air conditioning system possible problems and their causes .....	23-24	09-94	Cab heater water delivery and return hoses. Replacement .....	41-42	09-94
Troubleshooting guide .....	25÷28	09-94			
Maintenance .....	29	09-94			

### **Servicing and repairs**

Air conditioner evaporator. Replacement .....	30-31	09-94
Fluid hoses placed down-stream of compressor. Replacement .....	31÷33	09-94
Fluid hoses placed up-stream of compressor. Replacement .....	34-35	09-94
Receiver-drier filter. Replacement .....	35	09-94
Condenser. Replacement .....	36	09-94
Compressor. Removal-Installation .....	36÷37	09-94

### **Compressor maintenance and overhauling**

Compressor lube oil, types and level .....	37	09-94
Compressor drive belt installation and tension check .....	38	09-94

### **55 – ELECTRICAL SYSTEM**

Battery charging system .....	1	09-94
Starting motors .....	2÷9	09-94
Batteries and fuses .....	10	09-94
Lights-Indicators-Accessories .....	11	09-94
Control boards and switches. Description and operation ..	12-13	09-94
Instrument panel, indicator and warning lights .....	14	09-94
Windshield wiper motor. Removal-Installation .....	15	09-94
Flex line, check valve/windshield washer spray. Replacement .....	15÷16	09-94
Windshield washer spray. Replacement .....	16	09-94

# INDEX

## A-10

---

	Page	Date		Page	Date
Models 50V 55V 60V 70V 55F 60F.			Front glass, right or left. Replacement .....	6	09-94
Wiring diagram .....	17	09-94	Cab door, right or left. Removal-Installation .....	6	09-94
Models 62F 72F 82F 72LP 82LP.			Handle with lock, right or left door. Replacement .....	7	09-94
Wiring diagram .....	18	09-94	Cab door glass, right or left. Replacement on door removed from cab .....	7	09-94
Models 62F 72F 82F with cab.			Glass sealing strip, right or left door. Replacement on door removed from cab .....	7	09-94
Wiring diagram .....	19-20	09-94	Cab door alignment and clo- sure. Adjustment .....	8	09-94
Models 50V 55V 60V 70V 55F 60F.			Cab rear window glass. Replacement .....	8	09-94
Power take-off safety switch .	21	09-94	Rear window glass sealing strip. Replacement .....	9	09-94
Models 62F 72F 82F 72LP 82LP.			Left door frame lining strip Replacement .....	9	09-94
Power take-off safety switch .	22	09-94			
<b>90 – CAB AND DRIVE STATION</b>					
Paint .....	1	09-94			
Cab removal-installation ....	2÷4	09-94			
Windshield glass. Replacement .....	4-5	09-94			
Windshield glass seal strip. Replacement .....	5	09-94			

## **GENERAL INSTRUCTIONS**

### **IMPORTANT NOTICE**

All maintenance and repair operations appearing on this manual must be performed exclusively by the Company's official Service network, which is committed to strictly follow the instructions and indications therein and to use, whenever necessary, the envisaged special tools.

Whomever should carry out any operation or service work herein included without strictly following our indications and prescriptions will be held personally responsible for any ensuing damage.

### **SHIMS**

At each adjustment, select appropriate shim by measuring them one by one with a micrometer gauge and subsequently summing up the single thickness readings: do not rely on wrong overall reading of shim pack thickness or on the nominal value indicated for each shim.

### **ROTARY SHAFT SEALS**

Install seals on rotary shaft correctly, as follows:

- prior to fitting, soak the seals for at least half an hour in the fluid to be retained;
- clean the shaft thoroughly and make sure that working surfaces are free from any damage;
- install the seal with the sealing lip side facing the fluid; in case of a thrower lip type seal, the grooves must be oriented so as to throw the fluid back in when the shaft is rotating;
- smear the sealing lip with a very thin coating of lubricant (oil is better than grease) and pack the space between sealing lip and dust shield with grease on double-lip type seals;
- fit seals into their housings by pressure or using a punch with a flat contact surface; under no circumstances hit the seal directly with a hammer or mallet;
- at assembly, make sure the seal is not entering the housing in tilted position and once fitted ensure that the seal is pressed fully home;
- to prevent that the sealing lip may be damaged by the shaft at installation, use some sort of protection when sliding it over the shaft.

### **O-RING SEALS**

Lubricate each seal prior to fitting to prevent twisting at assembly and consequent loss of fluid tightness.

### **SEALING COMPOUNDS**

On the mating surfaces indicated by a X apply one of the following sealing compounds: RTV SILMATE, RHODORSIL CAF 1 or LOCTITE PLASTIC GASKET.

Before applying the sealing compounds, treat mating surfaces as follows:

- using a wire brush, remove all metallic particles;
- thoroughly degrease surfaces using one of the following detergents: solvent, kerosene or a water/soda solution.

### **BEARINGS**

When fitting bearings, it is recommended:

- pre-heating them 80°C to 90°C before installation on shafts;
- cooling them before force-fitting into their respective seats.

### **ROLL PINS**

When fitting straight roll pins make sure the cut faces towards direction of work, to stress the pin.  
Coil roll pins, instead, do not require any particular orientation at assembly.

### SPARE PARTS

Use exclusively **NEW HOLLAND genuine spare parts**, the only ones that can be identified by this exclusive trademark.



New Holland  
Original  
Controlled  
Quality



New Holland  
Original  
Controlled  
Quality

These are the only ones that guarantee the same quality, durability and safety of the original Factory parts, being the same ones installed on the assembly line.

Only the **genuine NEW HOLLAND spare parts** offer this guarantee.

When ordering spare parts please state:

- tractor model (marketing code) and chassis serial number;
- engine type and serial number;
- part number, (given on "Microfiches" or "Spare Parts Catalogue").

### SERVICE TOOLS

The service tools proposed and illustrated in this Manual are:

- envisaged and designed specifically for use on tractors of the FIATAGRI range;
- necessary for reliable service work;
- accurately made and thoroughly tested to offer efficient and durable working tools.

We should like to remind to Service operators that being in possess of the right tools means:

- working under optimum technical conditions;
- obtaining the best possible results;
- save time and fatigue;
- working under better safety conditions.

### NOTICES

Wear limits given in this manual for some of the parts and components are to be considered indicative only, for guidance purposes, and are not binding.

Indications such as "front", "rear", "right" and "left" referred to different components are intended for the tractor operator sitting in the driver's seat and facing the direction of normal tractor travel.

### HOW TO START AND MOVE A TRACTOR WITHOUT BATTERY

Cables of the outside energizer must be connected exclusively to their respective positive and negative posts on the tractor, using clean and efficient clamps assuring adequate and stable contacts.

Disconnect all users (lights, windshield wiper, etc.) prior to starting the tractor.

Should it be necessary to verify the tractor electrical system operation, do it only with the outside energizer connected; Ultimated the check, disconnect all electrical accessories and de-activate the energizer before disconnecting its cables.

## SAFETY

### PAY ATTENTION TO THIS SYMBOL



*This warning symbol calls your attention on important messages involving your personal safety.*

*Read the precautionary statements attentively and strictly comply with the recommended precautions in order to avoid any potential risk and safeguard your personal health and wellbeing.*

*Throughout this manual you will find this symbol associated with the following keywords:*

**CAUTION** – For warnings intended to make you avoid wrong or inadequate repair practices which may potentially involve the repairman personal safety.

**DANGER** – In the presence of warnings that specifically alert of potential physical danger for the safety of the repairman or of other persons directly or indirectly involved.



## AVOID ACCIDENTS !

Most accidents occurring in the workshop are caused by the failure of following some basic and simple safety rules and precautions.

For this reason MOST ACCIDENTS CAN BE PREVENTED by paying attention in advance to avoid the possible causes and act accordingly, being careful and cautious.

No matter what the type of machine, and no matter how well this has been designed and manufactured, it will be impossible to absolutely exclude the possibility of an accident.

A careful and cautious mechanic is the best guarantee against accidents.

Just the compliance to this one only simple safety rule would prevent the occurrence of a good many serious accidents:

**DANGER** – Never attempt to clean, lubricate or service the tractor with the engine started.

## PRECAUTIONARY STATEMENTS

### GENERAL

- ◊ Strictly follow all maintenance and servicing directions.
- ◊ Do not wear rings, wrist watches, jewelry and loose or hanging apparel such as, for example: ties, torn clothing, scarves, unbuttoned or unzipped jackets that can be caught in moving parts. We recommend, instead, to wear proper safety clothing and accessories, such as, for example: anti-skid shoes, gloves, safety goggles, helmets, etc.
- ◊ Do not carry on service work on the machine with persons sitting in the driver's seat, with the exception of operators abilitated to cooperate with you for the work at hand.
- ◊ Carry on all performance tests from the operator's seat.
- ◊ Unless otherwise specified, do not do any work on the machine while the engine is running.
- ◊ Before taking off caps, covers, valves, etc., stop the engine and relieve pressure from hydraulic circuit involved.
- ◊ All service work and operations must be carried on by constantly using maximum care and paying best attention.
- ◊ Shop and field platforms and ladders should be constructed and maintained in accordance with accident prevention regulations.
- ◊ Disconnect batteries and label all controls to warn that work is in progress. Restrain machine and any implement to be lifted.
- ◊ Never check levels or fill fuel tanks and storage batteries while smoking or near open flames as fluids involved are flammable.
- ◊ Brakes are inactive when disconnected for servicing the machine, it will therefore be necessary to make provisions to securely restrain it by means of wedge blocks in order to prevent any movement that might be physically dangerous for the operator.
- ◊ Make sure that the fuel filler gun is and remains in contact with the tank filler cap during refuelling to prevent sparks due to static electricity.

## GENERAL – MAINTENANCE

### 00 – 4

---

- ◊ Use only designated towing or pulling attachment points. Use great care in connecting: make sure pins and locks are secure before attempting to pull. Stay clear of drabars, chains and cables under load.
- ◊ To move a disabled machine use a trailer or low body truck, if available.
- ◊ Load or unload the machine from transporter on level grounds affording full support to the trailer or truck wheels. Anchor tractor to load or trailer platform for transport and fit wedge blocks under the wheels as requested by the carrier.
- ◊ Use only grounded auxiliary power sources for heaters, chargers, pumps and similar equipment to avoid potential electrical shocks.
- ◊ Lift and handle all heavy parts with lifting tackle of adequate capacity.
- ◊ Watch out for people in the vicinities.
- ◊ Never pour gasoline or diesel fuel in open, large and low containers.
- ◊ Never use gasoline, diesel fuel or other flammable liquids as detergents: use, instead, commercial solvents, non flammable and non toxic.
- ◊ When cleaning parts with compressed air wear safety goggles with side protection.
- ◊ Limit the pressure to 2.1 bar (30 psi) in accordance to local safety regulations.
- ◊ Do not keep the engine running inside closed premises without adequate ventilation.
- ◊ Do not smoke, do not use open flames and do not cause sparks in the vicinity when refuelling or handling easily inflammable materials.
- ◊ Do not use open flames as light sources with work in progress or when searching for "leaks" on the machine.
- ◊ Move carefully when working under/on the machine or near the same and wear the envisaged safety clothing and accessories: helmets, goggles and safety shoes.
- ◊ When carrying on inspection or checks requiring that the engine be running, call on the assistance of an operator remaining seated in the driver seat while watching the mechanic at work at all times.
- ◊ For field service, drive the machine on level grounds and make provisions to block it securely in place. If working on sloping grounds cannot be avoided, first move the machine, if possible, to the best available level grounds and block machine and its attachment securely to avoid accidents.
- ◊ Guard against kinking chains or cables: do not use them to lift or pull. Always wear heavy gloves when handling them.
- ◊ Be sure chains are anchored securely: check that the anchor point is strong enough for the expected load. Nobody should be near the anchor point, chain or pull cable and ropes.
- ◊ Keep maintenance floor area always CLEAN and DRY. Remove water or oil puddles immediately.
- ◊ Do not let oily, greasy wrags to pile up: they are a serious fire hazard. Always store them in a closed metal container. Before starting the machine or moving equipment check and inspect the driver's seat setting and locking. Also make sure no one else is present within the operating radius of the machine or equipment.
- ◊ Do not carry loose objects in your pockets that might fall inside disassembled parts and components.
- ◊ When in the presence of a potential hazard of being hit by flying metal particles or similar, wear goggles or glasses with side protection, helmets, special safety shoes and heavy gloves.
- ◊ Wear welders' protective accessories such as dark glasses, helmets, protective clothing, gloves and safety shoes when welding. Dark safety glasses must be worn also by anyone standing by when welding is in progress. DO NOT LOOK AT ARC WITHOUT PROPER EYE PROTECTION.
- ◊ Wire ropes develop steel slivers in time. When handling them, always use adequate protection (heavy gloves, safety glasses, etc.).
- ◊ Handle all parts with extreme care. Do not put hands and fingers in between parts. Always wear proper, designated clothing and accessories such as safety glasses, heavy gloves and safety shoes.

## STARTING

- ◊ Do not run the engine inside closed premises without proper ventilation capable of eliminating exhaust gases.
- ◊ Never place head, body, legs and arms, feet, hands and fingers near rotating fans or belts.

## ENGINE

- ◊ Turn radiator cap slowly to release cooling system pressure before removing it. Add coolant only when the engine is shut off or idling, if warm.
- ◊ Do not refuel with engine running, particularly if warm, to avoid the possibility of spilled fuel taking fire.
- ◊ Never attempt to verify or adjust fan belt tension when the engine is running. Do not adjust the fuel injection pump when the tractor is moving.
- ◊ Never lubricate a machine with the engine running.

## ELECTRICAL SYSTEM

- ◊ When auxiliary batteries are used, be sure to connect both cable ends correctly: (+) with (+) and (–) with (–) and do not short-circuit terminals.  
**BATTERY GAS IS HIGHLY INFLAMMABLE.**  
 Leave battery box open for better ventilation when charging batteries. Never check charge by placing metal objects across the posts. Keep sparks and open flames away from battery area and avoid smoking to prevent explosions.
- ◊ Check for fuel or battery electrolyte leaks before starting service or maintenance work: eliminate leaks, if any, before proceeding.
- ◊ Do not charge batteries inside closed premises or areas: make sure ventilation is adequate to prevent accidental explosions due to accumulation of explosive gas given off during the charging process.
- ◊ Always disconnect batteries before working on the electrical system.

## HYDRAULICS

- ◊ Fluid escaping under pressure from a very small hole can almost be invisible but can have sufficient force to penetrate the skin.  
 Use a piece of cardboard or wood when searching for suspected pressure leaks. NEVER USE HANDS: if the fluid jet has penetrated under the skin, see a doctor at once as serious infection or skin reactions may develop if proper medical treatment is not administered immediately.
- ◊ When checking hydraulic system pressure use accident prevention provisions and the proper instruments and gauges.

## WHEELS AND TYRES

- ◊ Make sure tyres are properly inflated to manufacturers specifications. Inspect rims and tyres periodically for damage.
- ◊ Stand sideways when checking tyre pressures.
- ◊ Check pressure only under unloaded machine and cold tyres conditions to avoid getting a wrong, overinflated pressure value.  
 Do not use reworked wheel parts as improper welding, brazing or heating may have weakened them and cause failures.
- ◊ Never cut or weld a wheel rim with the tyre installed and inflated.
- ◊ When removing or installing one or two wheels, restrain all the others by means of wedge blocks in order to prevent accidental movements potentially dangerous for the operator.  
 After jacking up the tractor in correspondence of the wheel or wheels to be removed, place the designated floor stands for proper supporting and safety.
- ◊ Deflate tyres before foreign objects from treads.
- ◊ Never inflate tyres with a flammable gas: explosion and personal injuries could be the result.

## REMOVAL AND INSTALLATION WORK

- ◊ Lift and handle all heavy parts using lifting tackle of proper capacity. Keep people away from the load being lifted and make sure that parts and components are securely supported by proper hooks and chains and use the specific steel eyes for attachment.
- ◊ Handle all parts with extreme care, keep hands and fingers from between parts and wear the approved safety clothing and accessories such as goggles and glasses, gloves and shoes.
- ◊ Guard against kinking chains or steel wire ropes and always wear safety gloves when handling them.

**GENERAL – MAINTENANCE**

**00 – 6**

---

GENERAL SPECIFICATIONS	3-cylinder	4-cylinder
<b>Engine.:</b>		
– 50V model – type 8035.06.220 (BOSCH pump) .....	See data on p.10-9	–
– 50V model – type 8035.06.321 (C.A.V. pump) .....	See data on p.10-11	–
– 55V and 55F models – type 8035.06.222 (BOSCH pump) .....	See data on p.10-13	–
– 55V and 55F models – type 8035.06.323 (C.A.V. pump) .....	See data on p.10-15	–
– 60V, 60F and 62F models – type 8035.05.208 (BOSCH pump)	See data on p.10-17	–
– 60V, 60F and 62F models – type 8035.05.309 (C.A.V. pump) ..	See data on p.10-19	–
– 70V, 72F and 72LP models – type 8045.06.208 (BOSCH pump)	–	See data on p.10-21
– 70V, 72F and 72LP models – type 8045.06.309 (C.A.V. pump)	–	See data on p.10-23
– 82F and 82LP models – type 8045.05.208 (BOSCH pump) .....	–	See data on p.10-25
– 82F and 82LP models – type 8045.05.309 (C.A.V. pump) .....	–	See data on p.10-27
Cycle .....		diesel, 4-cycle, aspirated
Injection .....		direct
Number of in-line cylinders .....	3	4
Cylinder sleeves .....		dry, force-fitted in crankcase
Piston diameter:		
– 50V model .....	100 mm (3.94 in)	–
– 55V and 55F models .....	100 mm (3.94 in)	–
– 60V, 60F and 62F models .....	104 mm (4.10 in)	–
– 70V, 72F and 72LP models .....	–	100 mm (3.94 in)
– 82F and 82LP models .....	–	104 mm (4.10 in)
Piston stroke .....		115 mm (4.53 in)
Engine displacement:		
– 50V model .....	2710 cm <sup>3</sup> (165.31 in <sup>3</sup> )	–
– 55V and 55F models .....	2710 cm <sup>3</sup> (165.31 in <sup>3</sup> )	–
– 60V, 60F and 62F models .....	2931 cm <sup>3</sup> (178.79 in <sup>3</sup> )	–
– 70V, 72F and 72LP models .....	–	3613 cm <sup>3</sup> (220.40 in <sup>3</sup> )
– 82F and 82LP models .....	–	3908 cm <sup>3</sup> (238.39 in <sup>3</sup> )
Compression ratio .....		17:1
Max. power:		
– 50V model .....	33,1 kW (45 HP)	–
– 55V and 55F models .....	40,4 kW (55 HP)	–
– 60V, 60F and 62F models .....	44,1 kW (60 HP)	–
– 70V, 72F and 72LP models .....	–	51,5 kW (70 HP)
– 82F and 82LP models .....	–	58,8 kW (80 HP)
Max. output speed .....		2500 rpm
Max. torque speed: 50V model .....	1300 rpm	–
Max. torque speed: 55V and 55F models .....	1400 rpm	–
Max. torque speed: 60V, 60F and 62F models .....	1500 rpm	–
Max. torque speed: 70V, 72F and 72LP models .....	–	1500 rpm
Max. torque speed: 82F and 82LP models .....	–	1400 rpm
Main bearings .....	4	5
Oil sump .....		cast-iron

(continued)

## ENGINE


### 10 – 2

(follows)		
GENERAL SPECIFICATIONS	3-cylinder	4-cylinder
<b>Lubrication</b> .....	forced, w/gear-type pump	
Pump drive .....	camshaft	
Engine/oil pump speed ratio .....	2:1	
Oil cleaning .....	through wire filter on intake and cartridge on delivery	
Normal oil pressure, warm engine running at max. speed : .....	2,9 ÷ 3,9 bar (3 ÷ 4 kg/cm <sup>2</sup> – 42,6 ÷ 56,9 psi)	
Pressure relief valve .....	inside pump housing	
Valve crack-off pressure .....	3,5 bar (3,6 Kg/cm <sup>2</sup> – 50,8 psi)	
For further lubrication data .....	See page 10-84	
<b>Cooling</b> .....	water circulation	
Radiator, 50V, 55V, 55F, 60V, 60F, 62F and 70V models .....	3-row vertical copper tubes	
Radiator, 72F, 72L, 82F and 82LP models .....	4-row vertical copper tubes	
Fan, attached to water pump pulley .....	suction, sheet metal, six blades	
Water pump .....	vane-type	
Engine/water pump speed ratio .....	1:1,403	
Temperature regulation .....	through thermostat	
Water temperature gauge .....	3-colour sector scale	
Temperature gauge dial sector temperatures:		
– starting white sector .....	30° ÷ 65° C (86° ÷ 149° F)	
– central green sector (normal operating temperature) .....	65° ÷ 105° C (86° ÷ 221° F)	
– final red sector .....	105° ÷ 115° C (221° ÷ 239° F)	
For further cooling system data .....	See page 10-87	
<b>Tractor meter</b> .....	on instrument panel	
Drive .....	through camshaft gear	
Hourmeter/engine speed setting .....	1800 rpm	


(continued)

(follows)


GENERAL SPECIFICATIONS	3-cylinder	4-cylinder
<b>Timing</b>	overhead type valves driven by the timing camshaft, located in the engine crankcase, through the push rod and rocker arm mechanism; the camshaft is driven by the engine crankshaft through helical-tooth gears.	
Intake:		
- commencement: before T.D.C. ....	12°	
- end: after B.D.C. ....	31°	
Exhaust:		
- commencement: before B.D.C. ....	50°	
- end: after T.D.C. ....	16°	
Valve clearance for timing check ....	0,45 mm (.018 in)	
Normal operating valve clearance, measured on cold engine:		
- intake ....	0,30 ± 0,05 mm (.012 ± .002 in)	
- exhaust ....	0,30 ± 0,05 mm (.012 ± .002 in)	
For further timing data ....	See page 10-73	
<b>Fuel system</b>		
Air cleaning ....	through a dual-cartridge dry air cleaner, with clogged filter warning light, centrifugal pre-cleaner and automatic dust ejector	
Fuel transfer pump ....	double-diaphragm	
Fuel filtering ....	through wire filter in fuel transfer pump and a replaceable, cartridge-type filter in pump output	
Min. fuel output with drive shaft rotating at 1600 rpm ....	100 l/h (22 UK or 26 US gal)	
Cam drive ....	actuated by the engine timing mechanism	
BOSCH or C.A.V. fuel injection pump ....	distributor type	
All-speed, built-in speed governor:		
BOSCH and C.A.V. ....	mechanical flyweights	
Automatic, built-in advance variator:		
BOSCH and C.A.V. ....	hydraulic	
For further fuel system data ....	See prospect below	
For information concerning fixed advance (pump setting on engine for commencement of delivery, before T.D.C.) – Pressure setting – Firing order and others completing BOSCH and C.A.V. pump data, refer to the pages indicated hereafter in relation to the type of engine:		
- 50V model – type 8035.06.220 (BOSCH pump) ....	See data on p. 10-9	–
- 50V model – type 8035.06.321 (C.A.V. pump) ....	See data on p.10-11	–
- 55V and 55F models – type 8035.06.222 (BOSCH pump) ....	See data on p.10-13	–
- 55V and 55F models – type 8035.06.323 (C.A.V. pump) ....	See data on p.10-15	–
- 60V, 60F and 62F models – type 8035.05.208 (BOSCH pump)	See data on p.10-17	–
- 60V, 60F and 62F models – type 8035.05.309 (C.A.V. pump) ..	See data on p.10-19	–
- 70V, 72F and 72LP models – type 8045.06.208 (BOSCH pump)	–	See data on p.10-21
- 70V, 72F and 72LP models – type 8045.06.309 (C.A.V. pump)	–	See data on p.10-23
- 82F and 82LP models – type 8045.05.208 (BOSCH pump) ...	–	See data on p.10-25
- 82F and 82LP models – type 8045.05.309 (C.A.V. pump) ....	–	See data on p.10-27




**Longitudinal section of the 3-cylinder engine installed on the 50V – 55V – 55F – 60V – 60F – 62F model tractors**



Cross-section of the 3-cylinder engine installed on the 50V - 55V - 55F - 60V - 60F - 62F model tractors



Longitudinal section of the 4-cylinder engine installed on the 70V – 72F – 72LP – 82F – 82LP model tractors



Cross-section of the 4-cylinder engine installed on the 70V - 72F - 72LP - 82F - 82LP model tractors

**ENGINE****10 – 8****ANGULAR TORQUE WRENCH DATA**

DESCRIPTION	Thread size	Torque		Angle
		Nm	kgm/ft-lb	
Cap screws, cylinder head ( <b>C<sub>1</sub></b> , page 10–4, or page 10–6) .....	M 12 x 1.25	60	6,1/44	90° + 90°
Cap screws, main bearing caps ( <b>C<sub>2</sub></b> ) .....	M 14 x 1.5	80	8,2/59	90°
Cap screws, connecting rod caps ( <b>C<sub>3</sub></b> ) .....	M 11 x 1.5	40	4,1/30	60°
Cap screws, engine flywheel ( <b>C<sub>4</sub></b> ) .....	M 12 x 1.25	40	4,1/30	60°

**TORQUE WRENCH DATA**

DESCRIPTION	Thread size	Torque	
		Nm	kgm/ft-lb
Cap screws, rocker arm shaft bracket ( <b>C<sub>5</sub></b> , page 10–4, or page 10–6) ..	M 8	25	2.5/18
Nut, crankshaft hub ( <b>C<sub>6</sub></b> ) .....	M 30 x 1.5	294	30/217
Cap screws, fan and alternator drive pulley ( <b>C<sub>7</sub></b> ) .....	M 10 x 1.25	55	5.6/40.5
Cap screws, balancer weights ( <b>C<sub>8</sub></b> , page 10–7) for 70 – 72 – 82 models	M 12 x 1.25	110	11.2/81
Cap screws, inlet manifold ( <b>C<sub>9</sub></b> , page 10–48) .....	M 8	25	2.6/19
Nut, alternator and belt stretcher ( <b>C<sub>10</sub></b> , page 10–45) .....	M 10 x 1.25	55	5.6/40.5
Cap screws, engine coolant pump ( <b>C<sub>11</sub></b> , page 10–46) .....	M 10 x 1.25	55	5.6/40.5
Nuts, injector stud ( <b>C<sub>12</sub></b> , page 10–62) .....	M 8	25 (*)	2.6 (*)/19
Nuts, valve tappet cover ( <b>C<sub>13</sub></b> ) .....	M 8	15	1.5/11
Cap screws, rocker arm shaft brackets ( <b>C<sub>14</sub></b> ) .....	M 8	25	2.5/18
Cap screws, oil pump and cover ( <b>C<sub>15</sub></b> , page 10–51) .....	M 8	25	2.6/19
Cap screws, timing box and cover ( <b>C<sub>16</sub></b> , page 10–52) .....	M 8	25	2.6/19
Cap screws, intermediate flanged axle ( <b>C<sub>17</sub></b> ) .....	M 10 x 1,25	55	5.6/40.5
Cap screws, camshaft thrust plate ( <b>C<sub>18</sub></b> ) .....	M 8	35	3.6/26
Cap screws, crankcase rear cover ( <b>C<sub>19</sub></b> , page 10–58) .....	M 8	25	2.6/19
Nuts, valve tappet adjustment setscrews ( <b>C<sub>20</sub></b> , page 10–62) .....	M 8	22	2.2/16
Cap screws, exhaust manifold ( <b>C<sub>21</sub></b> , page 10–46) .....	M 8	25	2.6/19
Cap screws, injection pump ( <b>C<sub>22</sub></b> , page 10–93, or page 10–96) .....	M 8	25	2.6/19
Cap screws, engine oil sump ( <b>C<sub>23</sub></b> , page 10–50) .....	M 12x1.25	69	7/51

(\*) Tighten nuts at two subsequent stages, see page 10–62

FUEL SYSTEM MAIN DATA

<b>BOSCH INJECTION SYSTEM</b>		VE 3/11 F 1250 L 163-2 – 4804867
Engine .....		8035.06.220
Tractor .....		50V
Power output .....		45 HP
Cylinders .....		3
Stroke .....		115 mm (4.53 in)
Bore .....		100 mm (3.94 in)
Displacement .....		2710 cm <sup>3</sup> (165.31 in <sup>3</sup> )
Max. power torque .....		2500 rpm
<b>Injector types :</b>		
– W ALTECNA .....		4802391
– BOSCH .....		4792442
– C.A.V. .....		–
– OMAP .....		4800032
<b>Nozzle holder types :</b>		
– W ALTECNA .....		KBEL 83S 1W200–4802392
– BOSCH .....		KBEL 83S 35–4791124
– C.A.V. .....		–
– OMAP .....		OKLL 83S 3392–4796644
<b>Spray nozzle types :</b>		
– W ALTECNA .....		DDL124S 500W–4802393
– BOSCH .....		DLLA 124S 1001–4792443
– C.A.V. .....		–
– OMAP .....		OOL124S 3990–4792447
Spray orifice diameter .....		0.31 mm (.012 in)
Number of spray holes .....		4
Pressure setting .....		230 ÷ 238 bar (235 ÷ 243 kg/cm <sup>2</sup> – 3407 ÷ 3523 psi)
Delivery pipes .....		4797506
Pipe size .....		6 x 1.5 x 475 mm (.24 x .06 x 19 in)
<b>Assembly data</b>		
Sense of pump rotation (drive end) .....		counterclockwise
Firing order .....		1–2–3
Pumping element pre-lifting from B.D.C. .....		0,2 ± 0,05 mm (.008 ± .002 in)
Pump setting on engine: commencement of delivery before T.D.C. at cylinder 1 in the compression phase (*) .....		6° ± 1
Pump delivery connection to cylinder 1 .....		designated by the letter A.
<b>Calibration test conditions</b>		
Test bench complying with ISO 4008/1./2 standard .....		–
Injectors complying with ISO 7440 A 11 standard .....		1688901020 (°)
Test fluid ISO 4113 .....		at the temperature of 40° + 2° (104° ± 4°F)
Test glasses emptying time .....		30'
<b>Note (*)</b> Pumping element pre-lifting from B.D.C. for timing on engine (with 291754 and 291755 tools) .....		1 mm (.039 in)
<b>Note (°)</b> With button .....		1680103096

(continued)

# ENGINE

## 10 – 10

(follows)

BOSCH INJECTION SYSTEM		VE 3/11 F 1250 L 163-2 – 4804867
Fuel transfer pressure: bar (kg/cm <sup>2</sup> – psi)	.....	0.2 (0.2 – 2.9)
Injector pressure setting	.....	172 ÷ 175 bar (175 ÷ 178 kg/cm <sup>2</sup> – 2537 ÷ 2581 psi)
Pipes (complying with ISO 4093 std.)	.....	6 x 2 x 840 mm (.24 x .08 x 33.6 in)

ADJUSTMENT DATA						
Operation description	rpm	Advance piston stroke mm	Fuel pressure bar(kg/cm <sup>2</sup> )	Unit delivery cm <sup>3</sup> /1000 shots	Transfer bar (kg/cm <sup>2</sup> )	Spread cm <sup>3</sup> /1000 shots
Full load delivery	800	2.8 ÷ 3.2	4.2 ÷ 4.8	56.5 ÷ 57.5	0.2	3.5
Idle speed limit	350	–	–	10 ÷ 14	0.2	3
Starting delivery	150	–	–	100 ÷ 120	0.2	–
Full throttle limit	1350	–	–	39 ÷ 45	0.2	–

TEST DATA							
Advance device check	rpm	mm	Fuel pressure check	rpm	bar (Kg/cm <sup>2</sup> )	Back leakage	rpm
	600	0.6 ÷ 1.4	–	600	3.2 ÷ 3.8	–	–
	800	2.8 ÷ 3.2	–	800	4.2 ÷ 4.8	–	–
	1200	4.6 ÷ 5.4	–	1200	6.4 ÷ 7.0	–	–

DELIVERY CHECK							
Full throttle stop	rpm	Delivery cm <sup>3</sup> /1000 shots	Transfer pressure bar (kg/cm <sup>2</sup> )	Idle speed shut-off	rpm	Delivery cm <sup>3</sup> /1000 shots	Transfer pressure bar (kg/cm <sup>2</sup> )
	1400 ÷ 1460	≤ 2	0.2	–	350	10 ÷ 14	0.2
	1350	39 ÷ 45	0.2	–	400	≤ 2	0.2
	1250	50.5 ÷ 53.5	0.2	–	–	–	–
	800	56.5 ÷ 57.5	0.2	–	–	–	–
	500	52.5 ÷ 55.5	0.2	–	–	–	–
	250	≤ 47	0.2	–	–	–	–
	150	100 ÷ 120	0.2	–	–	–	–

BENCH TEST PERFORMANCE DATA							
Test conditions				Performance data			
Fixed injection advance before T.D.C. at cylinder 1 in compression phase: (see page before).				Relative humidity: 70% + 5			
Engine without fan, air cleaner and exhaust silencer.				Ambient temperature 20 ± 3° C (68 ± 3° F)			
Barometric pressure 740 ± 5 mm Hg (at Turin altitude: 239 meters – 785 ft above sea level).				Fuel specific weight 830 ± 10 g/liter.			
Throttle	Brake load	Engine speed rpm	Power output with engine run-in time of			Fuel consumption kg/h	
			2-hour total kW (metric HP)	50-hour total kW (metric HP)			
Maximum	For max power output	2500	≥ 32.4 (44)	33.1 ÷ 35 (45 ÷ 47.6)		7.8 ÷ 8.2	
Maximum	For max torque	1500	≥ 22.8 (31)	23.5 ÷ 25 (32 ÷ 34)		5.1 ÷ 5.6	
Maximum	None (idling)	2750 ÷ 2790	–	–		–	
Minimum	None (idling)	625 ÷ 675	–	–		–	

FULE SYSTEM MAIN DATA

C.A.V. INJECTION SYSTEM	DPS 8522 A 170 A – 98404118
Engine .....	8035.06.321
Tractor .....	50V
Power output .....	45 (metric HP)
Cylinders .....	3
Stroke .....	115 mm (4.53 in)
Bore .....	100 mm (3.94 in)
Displacement .....	2710 cm <sup>3</sup> (165.31 in <sup>3</sup> )
Max. power speed .....	2500 rpm
<b>Injector type :</b>	
– BOSCH .....	4824164
<b>Nozzle holder type :</b>	
– BOSCH .....	KBEL 83S 35–4791124
<b>Nozzle type :</b>	
– BOSCH .....	DLLA 134S 1113–4824165
Spray orifice diameter .....	0.31 mm (.012 in)
Number of spray holes .....	4
Pressure setting .....	260 ÷ 268 bar (265 ÷ 273 kg/cm <sup>2</sup> – 3842 ÷ 3958 psi)
Delivery pipes .....	–
Pipe size .....	6 x 2 x 475 (.24 x .08 x 19 in)
<b>Assembly data</b>	
Sense of pump rotation (drive end): counterclockwise	
Firing order : 1–2–3	
Distance between governor bracket and metering pin: 40.45 ÷ 41.05 mm (1.618 ÷ 1.642 in)	
Pump timing on engine: commencement of delivery before T.D.C. at cylinder 1 in compression phase 0° ± 1°	
Flange centering guide diameter : 50mm	
Pump delivery connection corresponding to cylinder 1: designated by letter <b>U</b>	
<b>Calibration test conditions</b>	
Test bench complying with ISO 4008/1..2 standard .....	–
Injectors complying with ISO 7440 A 11 standard .....	–
Test fluid ISO 4113 .....	at 40° ± 2° C (104° ± 4° F)
Test glass emptying time .....	30'
Fuel transfer pressure: bar (kg/cm <sup>2</sup> – psi) .....	0.1 (1.45 psi)
Injector pressure setting .....	172 ÷ 175 bar (175 ÷ 178 kg/cm <sup>2</sup> – 3842 ÷ 3958 psi)
Pipes complying with ISO 4093/1 standards .....	6 x 2 x 845 mm (.24 x .08 x 33.8 in)
Projecting height of maximum delivery setscrew above its locknut surface .....	9 mm (.35 in)
Back off completely the transfer pressure set screw and then screw it in .....	3.5 revs
Position the release valve set screw just below its locknut surface .....	–
Back off completely the maximum, minimum and shut-off exclusion screws .....	–
The advance device, spring end, fits a 2 mm (.08) shim .....	no others required

(continued)

(follows)

C.A.V. INJECTION SYSTEM			DPS 8522 A 170 A - 98404118				
Test n.	Throttle lever position	Speed rpm	Advance degrees	Transfer pressure bar (kg/cm <sup>2</sup> )	Unit delivery	Spread	Back leakage
					cm <sup>3</sup> /200 shots	cm <sup>3</sup> /200 shots	cm <sup>3</sup> /100 shots
1 (1)	max	200	—	—	—	—	—
2 (2)		1000	—	—	—	—	—
3		100	—	0.3	—	—	—
4 (+)		950	—	—	—	—	—
5 (3) - 6		950	2.75÷3.00 (15)	4.5÷5.6	—	—	—
7 (4)		1250	3.75÷4.75 (16)	—	—	—	—
8 - 9		750	—	—	8.6÷8.8(*)	≤1	40÷90(°)
10 (5)		1250	—	—	—	—	—
11 (6)		1420	—	—	1.5÷2.0	—	—
12 (x)		1520	—	—	≤1.4	—	—
13 (7)		1250	—	—	—	—	—
14 (8)		250	0.75÷1.75(17)	—	—	—	—
15 (9)		200	0	—	≥16.0	—	—
16 (11)	min	325	—	—	2.0÷2.5	—	—
17 (10)		850	—	—	—	—	—
18 (12)		325	—	—	≤0.8	—	—
19 (13)		325	—	—	≤0.5	—	—
20 (14)		—	—	—	—	—	—

<sup>1)</sup> Delivery to all injectors.  
<sup>2)</sup> Run pump for 3'.  
<sup>3)</sup> Set pressure adjusting screw for specified advance and check that pressure corresponds.  
<sup>4)</sup> Stop test machine, disconnect transfer pressure gauge and install shut-off device. Activate the latter and re-start test machine.  
<sup>5)</sup> Record average delivery.  
<sup>6)</sup> Adjust max. speed screw and lock it in position.  
<sup>7)</sup> Delivery shall not be less than in test 10 by more than 0.4 cm<sup>3</sup>/200 shots.  
<sup>8)</sup> Prior to test, bring machine speed to 100 revs then stop it. Fully tighten release valve adjusting screw, start machine and slacken screw until reaching specified values.  
<sup>9)</sup> Prior to test, bring machine speed to 100 revs then stop it and re-start it.  
<sup>10)</sup> Adjust anti-stall screw for a delivery of 2 to 3 cm<sup>3</sup>/200 shots and then lock it in position.

<sup>11)</sup> Adjust idling speed screw.  
<sup>12)</sup> Shut-off lever closed.  
<sup>13)</sup> With shut-off device deactivated and shut-off lever open, await 5" before performing test.  
<sup>14)</sup> Connect delivery fitting "U" to injector tester and maintain 54 bar (757 psi) pressure. Using timing tool, bring about hydraulic lock-up, then position pump timing plate at 11.25°.  
<sup>15)</sup> 2.2÷2.4 mm (.088÷.096 in)  
<sup>16)</sup> 3.0÷3.8 mm (.12÷.15 in)  
<sup>17)</sup> 0.6÷1.4 mm (.024÷.056 in)  
<sup>x)</sup> If delivery is more, adjust rod length at minimum (see above).  
<sup>+</sup> Inside pressure in pump housing, measured with a pressure gauge connected to the ori-fice in the drain screw, should read 0.1÷0.3 bar (kg/cm<sup>2</sup> - 1.45÷4.35 psi).  
<sup>\*</sup> Take reading after 15". ° Flow 300÷675 cm<sup>3</sup>/min. (18÷40.5 in<sup>3</sup>/min).

BENCH TEST PERFORMANCE DATA					
Fixed injection advance before T.D.C. at cylinder 1 in compression phase : (see page before).			Relative humidity: 70% ± 5. Ambient temperature 20 ± 3° C. Fuel specific weight: 830 ± 10 g/liter.		
Engine without fan, air cleaner and exhaust silencer. Barometric pressure 740 ± 5 mm of Hg (at Turin altitude: 239 m - 785 ft. above sea level).					
Throttel	Brake load	Engine speed rpm	Power output with engine run-in time of:		Fuel consumption kg/h
Maximum	For max power output	2500	2-hour total kW (metric HP)	50-hour total kW (metric HP)	
Maximum	For max torque	1500	≥ 22.8 (31)	23.5 ÷ 25 (32 ÷ 34)	5.1 ÷ 5.6
Maximum	None (idling)	2750÷2790	—	—	—
Minimum	None (idling)	625÷675	—	—	—

Sample of manual. Download All 443 pages at:

<https://www.arepairmanual.com/downloads/new-holland-fiat-86-series-tractors-service-repair-manual/>