

Product: New Holland Ford 700/750/800/825/850/900/950 Tractors Service Repair Manual

Full Download: <https://www.aresairmanual.com/downloads/new-holland-ford-700>


[-750-800-825-850-900-950-tractors-service-repair-manual/](https://www.aresairmanual.com/downloads/new-holland-ford-700-750-800-825-850-900-950-tractors-service-repair-manual/)

VERSATILE

Service Manual



Series 2 Tractors
700, 750, 800, 825, 850,
900 & 950



Sample of manual. Download All 348 pages at:

<https://www.aresairmanual.com/downloads/new-holland-ford-700-750-800-825-850-900-950-tractors-service-repair-manual/>

40070060

Reprinted

Product: New Holland Ford 700/750/800/825/850/900/950 Tractors Service Repair Manual

Full Download: <https://www.arepairmanual.com/downloads/new-holland-ford-700>

[-750-800-825-850-900-950-tractors-service-repair-manual/](https://www.arepairmanual.com/downloads/new-holland-ford-700-750-800-825-850-900-950-tractors-service-repair-manual/)

Sample of manual. Download All 348 pages at:

<https://www.arepairmanual.com/downloads/new-holland-ford-700-750-800-825-850-900-950-tractors-service-repair-manual/>

service manual

SERIES 2 FOUR-WHEEL DRIVE TRACTORS

APPLICABILITY: For 1977 Model Year Tractors.

Certain sections of this manual will also be applicable, in whole or in part, to preceding model years. The serviceman should read the table of contents to determine specific applicability.

APPLICABILITY: FOR 1977 MODEL YEAR TRACTORS.

CERTAIN SECTIONS OF THIS MANUAL WILL ALSO BE APPLICABLE, IN WHOLE OR IN PART, TO PRECEDING MODEL YEARS. THE SERVICEMAN SHOULD READ THE TABLE OF CONTENTS TO DETERMINE SPECIFIC APPLICABILITY.

Date of Issue, First Edition: 5 JUNE 1978

PU4001

FOREWORD

This Service Manual is issued to provide sufficient instructions for a qualified service mechanic to carry out Basic Servicing, Troubleshooting, Maintenance (removal, inspection and replacement of component assemblies,) and Overhaul (disassembly, inspection, repair and replacement of sub-assemblies).

A summary of the contents of each Section is provided in the main Table of Contents and a detailed coverage will be found in the Table of Contents preceding each Section.

The Service Manual should be used in conjunction with the Parts Manual for the specific Model year of Tractor. For the Serviceman's convenience and for reference to engine data and service, a list of Cummins Distributors is provided as Appendix 1 following Section 8: Structures.

REVISIONS AND ADDITIONS TO THE MANUAL

When changes are made in the unit covered in this service manual, pages will be marked to indicate whether they are replacement, or added pages. Replacement pages will show the revision number and carry the same page number as the original issue. Discard the original page and insert the replacement page in its place. Added pages will carry the revision number, an existing page number, and an alphabetical suffix (for example A, B, etc.). Insert these pages after the existing page.

A new revision record page will also be issued with every update as a check sheet so that the reader can determine if the manual is complete. The purpose of a loose-leaf Service Manual is to enable us to keep the book updated, and to revise it if it is found necessary to provide additional information. This purpose will be defeated if additional or revised pages are supplied. Please insert them immediately.

A 'feed-back' page has been inserted at the back of this Service Manual. After using this book, it would be appreciated if the user fills in this form and returns it to Versatile Manufacturing Limited. Such information will help us to improve our manuals if required, and give the user better manuals in the future.

**SECTION 1:
SERVICING**

SECTION 1: SERVICING
Table of Contents

1	INTRODUCTION	
2	TOWING/TRANSPORTING	
2.1	General	1-3
2.2	Towing	1-3
2.3	Transporting	1-3
3	HOISTS AND JACKS	
3.1	General	1-3
3.2	Jacks	1-4
3.3	Hoists	1-4
4	SPECIFICATIONS AND CAPACITIES	
4.1	General	1-4
4.2	Dimensions	1-4
4.3	Tire Size and Tractor Width	1-5
4.4	Tire Inflation	1-5
4.5	Weights	1-5
4.6	Engines	1-5
4.7	Cooling System	1-7
4.8	Air Cleaner	1-7
4.9	Exhaust System	1-7
4.10	Cold Start Aid	1-7
4.11	Clutch	1-7
4.12	Brakes	1-7
4.13	Transmission	1-7
4.14	Drivelines	1-7
4.15	Axles	1-8
4.16	Steering	1-8
4.17	Hydraulic System	1-8
4.18	Electrical System	1-8
4.19	Frames	1-8
4.20	Drawbar	1-8
4.21	Cab	1-8
4.22	Instrument Panel	1-9
4.23	Environmental Control Roof Unit	1-9
4.24	Radio	1-9
4.25	Options	1-9
5	FUELS, FLUIDS AND LUBRICANTS	
5.1	General	1-9
5.2	Fuel	1-9
5.3	Fluids	1-10

5.4	Lubricants	1-10
6	LUBRICATION	
6.1	General	1-11
7	BELTS AND FILTERS	
7.1	General	1-15
7.2	Belts-Replacement.....	1-15
7.3	Filters.....	1-15
8	STORAGE	
8.1	General	1-15
8.2	Preparation of Tractor for Storage	1-15
8.3	Preparation of Engine for Storage	1-16
8.4	Storing Batteries.....	1-16
8.5	Preparation after Storage.....	1-19
8.6	Startup of Engine after Storage.....	1-19
9	TROUBLESHOOTING	
9.1	General	1-19
9.2	Troubleshooting Guide	1-20
9.3	Troubleshooting Drive Train	1-22
9.4	Hydraulics.....	1-24
9.5	Troubleshooting Electrical System	1-26
9.6	Troubleshooting Environmental System	1-29

SECTION 1: SERVICING

1 Introduction

This section contains general information about specifications, capacities, lubricants, fluids and fuels for the tractor as a whole rather than having the information scattered throughout the other sections. A troubleshooting subsection will make reference to other service sections in the manual, which cover the tractor in greater detail.

2 Towing/Transporting

2.1 GENERAL

Towing or transporting a large four wheel drive tractor is a big job. Below are listed some recommendations to follow.

2.2 TOWING

Use the following recommendations when towing is necessary:

1. Use a strong chain, cable or towbar and attach securely to the front plate or drawbar of tractor.
2. Let engine run, if possible, so full use is made of hydrostatic steering.
3. Tow tractor slowly to allow operator to properly control towed unit.

NOTE

If engine can not be started, pull tractor in a gradual arc across the field. Steering tractor will be difficult.

— CAUTION —

DO NOT TOW TRACTOR FASTER THAN 10 MPH (17 km/hr.)

DO NOT SLIDE TRACTOR FROM SIDE TO SIDE TO MANEUVER INTO PLACE FOR REPAIR, DAMAGE TO DRIVE-TRAIN WILL RESULT.



BE ALERT

4. Use a strong front end loader to pick up either front or rear of tractor and push (and articulate) into the service area.
5. Disconnect drivelines when transmission or axles need repair or overhaul.
6. When axle is broken, remove side covers from the planetary hubs and pull planetaries out.
7. Cover the exhaust stack on all turbocharged tractors to prevent the turbocharger seizing. This applies when engine can not be started.

2.3 TRANSPORTING

For long distances, hauling the tractor on a trailer is best. Use the following Procedures when hauling the tractor:

1. Check with local authorities as to laws, permits required and other information required to transport large machinery.
2. Use a trailer having the carrying capacity (30,000 lbs.) to haul tractors and other large machinery.
3. Use "wide load" signs and equip trailer with clearance lights to indicate to passersby of load.
4. Equip the trailer with a winch (minimum 10-ton capacity) to pull tractor on to the trailer.
5. Securely chain tractor to trailer to prevent tractor movement or tipping.
6. Block wheels and/or engage park brake to prevent tractor movement.
7. Inspect chains regularly looking for cracks, gouges, wear, bent links, worn or bent hooks. Repair any damaged links and hooks.
8. Cover the exhaust pipe on all turbocharged tractors to prevent the turbocharger seizing.

3 Hoist and Jacks

3.1 GENERAL

Hoist and jacks are most useful in properly servicing the tractor. Use the following recommendations to aid in safely working on the tractor or any other equipment.

3.2 JACKS

Improper use of jacks or lifting devices results in serious accidents. Use the following recommendations when raising tractor using a jack:

1. Select a jack strong enough to carry the load. The minimum jack required is five ton capacity.
2. Use jack carefully. Dropping or tossing distorts or cracks the jack housing causing jack to fail.
3. Take proper care of jack by using proper lubricants as specified in the operating instructions. Do not use leaky jacks to lift heavy equipment.
4. Stabilize tractor by placing transmission into gear; engaging park brake; chocking or blocking wheels securely.
5. Brace up the center pivot frame by applying a strong wedge on the frame pivot to prevent jackknifing of tractor.
6. Use a level ground or floor surface so jack will lift straight up and down.
7. Place jack securely under axle tube, frame, or drawbar where it is strong enough to support the lifted weight.
8. Use a heavy block as a base for the jack if working on ground. It should be long and wide enough to keep jack from tipping, sinking or shifting. Any additional blocking should be under the jack.
9. Jack up front and/or rear frame just enough to install steel safety stands under axle tubes or frame.
10. Check jack position after it has started to lift. Lower jack immediately if it starts to lean. Reset jack; block tractor more securely and lift again.
11. Keep tractor stable by not raising so high it will slide off jack saddle.
12. Remove jack handle from mechanical jacks, when not in use, to prevent being stuck by handle.
13. Hold handle of mechanical jack firmly to prevent kicking as tractor is being raised or lowered.
14. Place support stands under tractor. Lower jack and let tractor rest on stands. This provides a solid support for the tractor when jack is removed.

3.3 HOISTS

Improper hoisting equipment can create accidents

and injuries. These accidents are caused by overloading the hoist or rigging the lift chains so they slip. Practice the following:

1. Use a proper chain hoist and frame to properly lift tractor. The minimum capacity required for the hoist is ten tons; for the A-frame or overhead support is seven and one-half tons; and for the support stands is three tons.
2. Never overload a hoist or frame beyond its carrying capacity.
3. Inspect chains regularly looking for cracks, gouges, wear, or bent links. Repair any damaged links.
4. Inspect hooks regularly and replace any that are bent, cracked, spring or worn. If in doubt, compare the dimensions of a new hook with the old one. Replace if there are any differences in the size or shape.
5. Select suitable, balanced lift point on tractor frame. Place hook and frame directly over the point of lift.
6. Set chain to prevent the pull point from slipping.
7. Protect yourself from injury as tractor is being raised by doing the following:
 - a) Do not stand on tractor as you are lifting.
 - b) Keep hands away from pinch points where chain links tighten or chain is against tractor frame.
 - c) Do not let tractor swing and strike personnel or fame as it leaves the ground.
 - d) Keep support stands nearby and place under tractor when proper height is reached.
 - e) Do not go under tractor supported by a chain hoist. Place support stands under tractor before working under tractor.

4 Specifications and Capacities

4.1 GENERAL

The specifications and capacities apply to the Models 700, 750, 800, 825, 850, 900, 950 Series 2 tractors.

4.2 DIMENSIONS

Wheel Base - 130 in.

Tread, with 20.8 x 38 single tires - 72 in. between centers.

Overall length - 253 in. without three-point hitch

Overall width - 93 in. with 20.8 x 38 single tires

Cab height - with 20.8 x 38 single tires

Models 700, 750, 800, 825: 125 in.

Models 850, 900, 950: 126-3/4 in.

Maximum allowable height - (Clearance for Bridges, Overpasses, etc.) - with 20.8 x 38 Single Tires, and with antenna vertical and adjusted to 30 in. height:

Models 700, 750, 800, 825: 156 in.
 Models 850, 900, 950: 156-3/4 in.

Turning Radius:

236 in. with 18.4 x 38 Dual tires
 239 in. with 20.8 Dual tires
 216 in. with 24.5 x 32 Single tires
 222 in. with 30.5 x 32 Single tires
 Nominal - 203.5 in. measured to center line of 72 in. tread.

4.3 TIRE SIZE AND TRACTOR WIDTH

Tractor width

(Outside of tires): Inner tires - 91.5 in.
 Outer tires - 137.5 in.

20.8 x 38 Dual tires

Between tread centers: Inner tires - 72 in.
 Outer tires - 112 in.

(Outside of tires):

Inner tires - 93 in.
 Outer tires - 143.5 in.

24.5 x 32 Dual tires

Between tread centers: 72 in.

Tractor Width

(Outside of tires): 97.5 in.

24.5 x 32 Single tires

Between tread centers: 72 in.

Tractor width

(Outside of tires): 97.5 in.

30.5 x 32 Single tires

Between tread centers: 79.12 in.

Tractor width

(Outside of tires): 109 in.

4.4 TIRE INFLATION

For proper tire inflation, follow the recommendations listed (Ref. Table 1-1).

IMPORTANT

Outside tires (duals) should have 2 psi less pressure than the inside tires.

4.5 WEIGHTS

Table 1-2 lists the weights of Series 2 tractors in shipping weight, maximum operating and recommended range.

4.6 ENGINES

Model 700

Cummins V-555-C210 V8 diesel

Maximum brake horsepower - 210 @ 2850 rpm (per SAE Standard J816a)

Maximum torque - 425 lb ft @ 1800 rpm

Full load governed speed - 2850 rpm

Full throttle no load speed - 3100 to 3135 rpm

Idle speed - 1000 rpm

Bore - 4.625 in.

Stroke - 4.125 in.

Displacement - 555 cu. in.

Compression ratio - 17.0:1

Lubrication system - 26 U.S. qts., 21.7 Imp. qts. Full flow oil filter with by-pass oil conditioner, filter and oil to water cooler

30° angular capability oil pan

Mounts - VERSATILE design, fully rubber mounted.

TABLE 1-1: Tire Inflation Chart

TIRE SIZE	PLY RATING	LITTLE OR NO BALLAST	MAX BALLAST OR HEAVY LOAD
18.4 x 38 *	6	16 psi	16 psi
20.8 x 38 *	8	16 psi	20 psi
24.5 x 32	10	18 psi	20 psi
30.5 x 32	10	16 psi	16 psi

* When used as duals, minimum tire pressure is 12 psi. Use ballast on duals only.

TABLE 1-2: Operating Weights

	700	750	800	825	850	900	950
Maximum Operating Weight (lbs.)	28,000	28,000	28,000	28,000	28,000	29,000	32,500
Recommended Range of Operating Weights (lbs.)	22,500 to 25,000	23,000 to 25,000	24,000 to 26,000	24,000 to 26,000	26,000 to 27,500	27,000 to 28,500	29,300 to 31,000
Shipping Weight with 20.8 x 38 Tires (lbs.)	16,920	18,020	18,100	18,100	18,380	17,920	18,045

For detailed recommendations of operating weights, consult Specifications Section of Operator's Manual for each Model.

Model 750

Cummins N-855-C220 (in-line six cylinder) diesel
 Maximum brake horsepower - 220 @ 2100 rpm (per SAE Standard J-816a)
 Maximum torque - 644 lb ft @ 1500 rpm
 Compression ratio - 15.8:1

Model 800

Cummins N-855-C235 (in-line six cylinder)
 Maximum brake horsepower - 235 @ 2100 rpm (per SAE Standard J-816a)
 Maximum torque - 660 lb ft @ 1500 rpm
 Compression ratio - 15.8:1

Model 825

Cummins NT-855-C250 (in-line six cylinder)
 Maximum brake horsepower - 250 @ 2100 rpm (per SAE Standard J-816a)
 Maximum torque 750 lb ft @ 1500 rpm
 Compression ratio - 15.8:1

Model 850

Cummins NT-855-C280 (in-line six cylinder)
 Maximum brake horsepower - 280 @ 2100 rpm (per SAE Standard J-816a)
 Maximum torque - 806 lb ft @ 1500 rpm
 Compression ratio - 14.0:1

Common Specifications for 855 Engine (Models 750, 800, 825, 850 Tractors)
 Full load governed speed - 2100 rpm

Full throttle no load speed - 2250 rpm to 2300 rpm
 Idle speed - 1000 rpm
 Bore - 5.50 in.
 Stroke - 6.00 in.
 Displacement - 855 cu. in.
 Lubrication system - 41 U.S. qts., 34.6 Imp. qts. Full flow oil filter with by-pass oil conditioner filter and oil to water cooler
 30° angularity capability oil pan
 Mounts - VERSATILE design, fully isolated

Model 900

Cummins V-903-C-295 V8 diesel
 Maximum brake horsepower - 295 @ 2400 rpm (per SAE Standard J-816a)
 Maximum torque - 706 lb ft @ 1800 rpm
 Compression ratio - 16.5:1

Model 950

Cummins VT-903 V8 diesel Turbocharged
 Maximum brake horsepower - 348 @ 2400 rpm (per SAE Standard J-816a)
 Maximum torque - 848 lb ft @ 1800 rpm
 Compression ratio - 15.5:1

Common Specifications for V-8 engine (Models 900 and 950 Tractors)

Full load governed speed - 2400 rpm
 Full throttle no load speed - 2550 rpm to 2640 rpm
 Idle speed - 1000 rpm

Bore - 5.50 in.

Stroke - 4.75 in.

Displacement - 903 cu. in.

Lubrication system - 34 U.S. qts., 28.3 Imp. qts. Full flow oil filter with by-pass oil conditioner and oil to water cooler.

30° angular capability oil pan

Mounts - VERSATILE design, fully isolated

4.7 COOLING SYSTEM

Capacity: Model 700 - 48 U.S. qts., 40 Imp. qts. Models 750, 800, 825, 850 - 49 U.S. qts., 41 Imp. qts. Models 900, 950, - 53 U.S. qts., 42 Imp. qts.

Radiator (4-row core) rubber mounted. Model 700 - 750 sq. in. All others - 930 sq. in.

Independent surge tank.

Quickly removable perforated metal grill screen fan (6-blade sucker type).

Model 700 - 24 in. diameter.

Models 750, 800 - 26 in. diameter.

Models 825, 850, 900, 950 - 28 in. diameter.

4.8 AIR CLEANER

Models 700, 750, 800 and 900:

United-Triphase (700 Model E112D18; 750, 800, 900-Model 114D10)

Models 825, 850, 950:

Donaldson Strata System STB14-0019

Both United and Donaldson systems:

Dual element, dry type with safety element

Restriction indication gauge on instrument panel

4.9 EXHAUST SYSTEM

Model 700 - One 8.5 in. diameter x 36 in. muffler

Models 750, 800, 825, 850, 950 - One 8.25 in. x 11.5 in. elliptical x 40 in. muffler.

Models 750, 800, 825, 850, 950 - One 8.25 in. x 11.5 in. elliptical x 40 in. muffler.

Model 900 - Two 8.5 in. diameter x 35.3 in. mufflers.

Mufflers are rubber-mounted.

Built-in vacuum aspirator for air cleaner.

Built-in spark arrestor (where mandatory).

4.10 COLD START AID

Make - KBI

Type - Ether, operated from instrument panel

4.11 CLUTCH

Dana Spicer - 14 in. two plate dry type, self-adjusting

Model AS-1402 (Model AS2-1402SD, Model 950 only) pull type with angle spring

Spring loaded, cushion hub discs

Ceramic button linings

Greaseable shaft bearing with slinger and sealed release bearing

Foot operated, mechanically actuated

Integral disc type, torque limiting transmission brake

Static torque rating - 16.40 lb ft

4.12 BRAKES

Road Brake - driveline mounted, 15 in. disc and self-adjusting caliper, hydraulically actuated by a single foot pedal.

Park Brake - same disc with caliper mechanically actuated by over center lever.

4.13 TRANSMISSION

VERSATILE design, completely rubber mounted

12 speed constant mesh with sliding collar shifting

4 shafts vertically arranged, 3.0 in. diameter, drilled for lubrication.

Independent lubrication system with pump, 10 micron filter, cooler, steel lines and wire braid hose, dash mounted oil pressure warning light.

Oil capacity - 21.5 U.S. qts., 16.8 Imp. qts.

Dipstick oil level check and filler point

Timken tapered roller bearings

Helical forward gears with straight cut (spur) reverse gears

One dash mounted, in-line shift, range lever

One floor mounted gear shift lever

Each model has five field speeds between:

- Model 700 - 4.1 and 7.5 mph
- Models 750, 800 & 825 - 4.1 and 7.3 mph
- Model 850 - 4.1 and 7.3 mph
- Models 900 & 950 - 4.0 and 7.2 mph

4.14 DRIVELINES

Engine to transmission - Spicer 1550 Series (Model 950 - Spicer 1600 Series)

Transmission to axles - Spicer 1600 Series

TABLE 1-3: Speeds in Miles per Hour

MODEL	700 2850 rpm				750, 800, 825 2100 rpm				850 2100 rpm				900 & 950 2400 rpm			
	1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4
Range																
Low Gear	2.6	3.1	3.5	4.1	2.6	3.0	3.5	4.1	2.6	3.0	3.5	4.1	2.5	3.0	3.3	4.0
Second Gear	4.7	5.6	6.3	7.5	4.7	5.5	6.3	7.3	4.7	5.5	6.3	7.3	4.5	5.4	6.0	7.2
High Gear	9.1	10.8	12.2	14.5	9.2	10.7	12.3	14.3	9.2	10.7	12.3	14.3	8.8	10.5	11.7	14.1
Reverse	3.4	4.0	4.5	5.3	3.4	3.9	4.5	5.2	3.4	3.9	4.5	5.2	3.3	3.9	4.3	5.2

NOTE: All speeds are with 24.5 x 32 tires (31.5 in. loaded radius tires).

Spicer Glidecote telescoping action
 Driveline carrier bearing on center swing frame

4.15 AXLES

VERSATILE design

Spiral bevel (and planetaries, on Models 850, 900, 950) differential with outboard planetary floating ring gear final drive.

Eaton differential - (Models 700, 750, 800, 825 - Series 17103. Models 850, 900, 950 - Series 23120)

Differential housing and axle tubes - Ductile iron

Oil Capacity -
 Models 700, 750, 800, 825 - 38 U.S. qts., 31.6 Imp. qts.,
 Models 850, 900, 950 - 40.4 U.S. qts., 34.0 Imp. qts.

Lubrication - SAE 90 MIL 2105 B gear oil

Axle seals - Unitized (combined neoprene seal and wear sleeve), prelubricated labyrinth-type guard.

Wheel mounting bolts - Twelve, 0.75 in. diameter

4.16 STEERING

Articulated frame - 42 degrees in each direction

Fully hydrostatic actuation

Two 3 in. I.D. x 16.5 in. stroke actuators mounted with 1.25 in. self-aligning ball bushings.

4.17 HYDRAULIC SYSTEM

Pump gear type. Flow: Model 700 - 25 U.S. gpm. Models 750, 800, 825, 850 - 23.5 U.S. gpm, Models 900, 950 - 26.9 U.S. gpm.

Drive - engine mounted gear driven

Relief valve - set at 2300 - 50 psi

Two-way spools which self-cancel at 2100 - 0 to 100 psi

One four-way spool with float position

Reservoir - vented, 74.5 U.S. qts., (62 Imp. qts.) capacity

Dipstick oil level check and low level sight glass

4.18 ELECTRICAL SYSTEM

12 volt - negative ground system

12 volt - 75 amp Delco-Remy alternator

Two 8D-900 amp 12 volt batteries, connected in parallel inside clean compartment

AWG 00 starting cables

Circuit breakers - automatic resetting type

Fuses - accessible and identified

Six 60 watt working lights (exceeds ASAE 279.6)

Two red tail lamps for highway (ASAE 279.6)

4.19 FRAME

Articulated frame 4-wheel drive

Oscillates to 15 degrees in both directions

Front frame - 3/8 in. formed side plates with 1/2 in. rear end plate. Reinforcement near axle mounting pads

Rear frame - 1/2 in. formed plate

4.20 DRAWBAR

Swinging clevis type - 1.75 in. x 5.0 in. steel with wear block, 1.5 in. hardened steel pin with locking lever.

Replaceable hardened bushings

Height - 18 in. to top of main member

4.21 CAB

VERSATILE design - independent module type with rollover protective structure (ASAE S336.1)

Fully isolated on rubber mounts

Acoustically insulated interior

tinted safety glass, side windows open for emergency exit

Height - 63 in. outside

Width - 56 in. outside

Lap type seat belt, easily adjustable

Bostrom seat, fully adjustable. Some '76 models have swivel seat.

Self-cleaning cab air filter allows for longer periods between manual servicing. The filter is removable (without the use of tools) from outside the cab.

4.22 INSTRUMENT PANEL

Gauges - engine tachometer with hour meter; engine oil pressure; engine temperature; battery condition voltmeter; fuel level

Warning lights - transmission oil pressure; park brake; alternator

Key ignition

Manual override button for automatic shut down system

Hazard warning-signal flasher combination

Light switch

Ether cold start aid control

International identification symbols on gauges and warning lights (ASAE S303.4)

4.23 ENVIRONMENTAL CONTROL ROOF UNIT

VERSATILE design

Operator controlled recirculation door - provides cool inside air recirculation to reduce heat load on air conditioning system, without losing cab pressurization

24,000 BTU/hr. air conditioning evaporator core to cool cab air and remove humidity

Large heater to warm cab and defrost windshield

Automatic shut down of compressor if refrigeration system becomes low on freon, or if pressure becomes too high

Indicator lights to indicate reasons for shut down

Pressurization and recirculation fan, 3-speed selection

Fan automatically comes on when ignition key is turned on to prevent operation of tractor without cab pressurization

4.24 RADIO

(1977 Models)

AM-FM (stereo) - 2 speakers

Make - automatic radio

Solid state circuitry

Five push button station selection

Volume and tone controls

Telescoping antenna, spring mounted

(1976 Models)

AM Solid state Radio

Five push button station selection

Volume and tone controls

Telescoping antenna, spring mounted

4.25 OPTIONS

No-spin differential - front axle only or front and rear axles.

Rear fenders

Three-point hitch (category III) - lift capacity of 12,370 lbs. at 24 in. to the rear of the lower link points throughout the working range. Maximum lift is 18,270 lbs. at the lift points.

Quick-attach coupler for three-point hitch

Tires - singles - 24.5 x 32, 30.5 x 32
duals - 18.4 x 38, 20.8 x 38

Rice and Cane Tires - 24.5 x 32 singles (Goodyear and Firestone)

30.5 x 32 singles (Goodyear and Firestone)

Dual wheel spacer - 14 in. for 18.4 x 38 tires

Engine block heater

5 Fuels, Fluids and Lubricants

5.1 GENERAL

The following information lists fuels, fluids and lubricants used on the Series 2 Tractors. Also lubricant capacities for the various models are listed.

5.2 FUEL

No. 2 diesel fuel is recommended. No. 1 diesel fuel is also satisfactory. Any other fuel should meet the following specifications:

Sulfur content less than one per cent.

Sediment and water content less than 0.1 per cent

Cetane number 40 or greater. A higher Cetane number fuel may be required at low temperatures or high altitudes.

Pour point below the lowest expected temperature

Ash content less than 0.02 per cent

Viscosity range 0.021 - 0.089 sq. in./sec. at 100° F.

Fuel capacity - 185 U.S. gal., 154 Imp. gal.

REFUELING

Observe all cautions and warnings in the Operator's Manual. Refer to "Tractor Safety" (or "Safety Rules") and "Operation" section of Operator's Manual for more information on refuelling.

5.3 FLUIDS

Coolant Mixture

Water: Clean and preferably soft. Water suitable for drinking is adequate as a coolant.

— CAUTION —



DO NOT USE DOW CHEMICAL THERM 209 BRAND ANTIFREEZE. IT IS NOT COMPATIBLE WITH THE CORROSION INHIBITOR.

Antifreeze: Commercial grade, ethylene glycol base, used in proportions recommended by the manufacturer.

Coolant Conditioner Filter: (Dry Chemical Additive) used when coolant is replaced.

Engine Coolant Capacities -

Model 700 - 48 U.S. qts., 40 Imp. qts.

Models 750, 800, 825, 850 - 49 U.S. qts., 40.8 Imp. qts.

Models 900, 950 - 53 U.S. qts., 44.1 Imp. qts.

Brake Fluid

SAE specification 70R3.

Hydraulic Fluid

Temperatures above 40° F - Esso Hydraul 56 or SAE 20 MS Motor Oil

Temperatures below 40° F - Dexron or 5W-20 MS Motor Oil

Liquid Ballast

The tire ballast consists of commercial Type 1 Calcium Chloride Flake (77 per cent CaCl₂) mixed with water (Ref. Table 1-4). If Type 2 Flake (94 per cent CaCl₂) is used, the weights given can be reduced by 25 per cent.

The 3-1/2 lb./gal. Calcium Chloride Solution is slush-free to -12° F (-24.4° C) and freezes solid at -52° F. The 5 lb./gal. solution is slush-free to -52° F and will freeze solid at -62° F.

5.4 LUBRICANTS

Table 1-5 lists the recommended lubricants for the tractor used for varying temperature conditions.

TABLE 1-4: Liquid Ballast Calculations

TIRE SIZE	WATER ONLY			3-1/2 LB. CaCl ₂ SOLUTION PER GAL				5 LB. CaCl ₂ SOLUTION PER GAL			
	US GAL	IMP GAL	WT LBS	US GAL	IMP GAL	LBS CaCl ₂	TOTAL WEIGHT	US GAL	IMP GAL	LBS CaCl ₂	TOTAL WEIGHT
18.4 x 36	110	92	917	94	78	329 lb.	1113 lb.	89	74	445 lb.	1190 lb.
20.8 x 36	140	117	1168	120	100	420 lb.	1420 lb.	114	95	470 lb.	1521 lb.
24.5 x 32	170	142	1418	146	122	511 lb.	1729 lb.	138	115	690 lb.	1841 lb.
30.5 x 32	217	181	1810	186	155	651 lb.	2202 lb.	175	146	875 lb.	2335 lb.

NOTE

The amount of liquid required will have to be determined as outlined in the calculation of wheel slippage given in the Operator's Manual.

TABLE 1-5: Lubricant Chart

LOCATION	CONDITIONS	TYPE	GRADE
Oils			
Engine Crankcase	Above 40° F (-4° C)	SAE 30	CC/CD
	20° F to 60° F (-7° C to 16° C)	SAE 20 - 20W	CC/CD
	-10° F to 30° F (-23° C to -1° C)	10W	CC/CD
	Below -10° F (-23° C)	See 'Arctic Oil Recommendations' in Cummins Manual	
Transmission and Hydraulic System	Above 40° F (4° C) Below 40° F (4° C)	Hydraul 56 or equivalent SD SAE 5W-20	
Differentials and Axle Planetary Gears	Above 90° F (32° C) Below 90° F (32° C)	SAE 140 SAE 90	GL5 (MIL2105B)* or GL5 (MIL2105C)*
Grease			
Pressure Grease Fittings	All	SAE High-Temperature Multi-Purpose	

* No Zinc Additives

American Petroleum Institute Lubricant Grades

Models 750, 800, 825, 850 - 41 U.S. qts., 34.1 Imp. qts.

Models 900, 950 - 34 U.S. qts., 28.3 Imp. qts.

CC - Service typical of lightly supercharged diesel engines operating in moderate to severe duty. These oils provide protection from high temperature deposits.

Hydraulic System - 74.5 U.S. qts., 28.3 Imp. qts.

Transmission - 21.5 U.S. qts., 17.9 Imp. qts.

Differential (each)

CD - Service typical of supercharged diesel engines in high output, high speed duty. These oils provide protection from bearing corrosion and high temperature deposits in supercharged engines using fuels of a wide quality range.

Axle and two planetaries -

1976 All Models - 38 U.S. qts., 31.6 Imp. qts.,

1977 Models 700, 750, 800, 825 - 38 U.S. qts., 31.6 Imp. qts.;

1977 Models 850, 900, 950 - 41 U.S. qts., 32.8 Imp. qts.

Each planetary housing - 4 U.S. qts., 3.2 Imp. qts.

NOTE

Turbo-charged tractors require oil with the 'CD' classification.

GL5(MIL2105B) or (MIL2105C) - Gear Lubricant for service 'GL5 (Hypoid Gears) meeting specification MIL2105B and MIL2105C with no zinc additives.

Lubricant Capacities

Engine Oil - Model 700 - 26 U.S. qts., 21.7 Imp. qts.

6 Lubrication

6.1 GENERAL

Table 1-6 lists the lube points on the Series 2 tractors. Along with the table are lube point illustrations (Ref. Figure 1-1).

Refer to subsection 5 for capacities and requirements.




FIGURE 1-1 Lube Points Sheet 1




FIGURE 1-1 Lube Points for Series 2 Tractors Sheet 2

TABLE 1-6: Lubrication Points

LUBE POINT (Ref. Fig. 1-1)	DESCRIPTION	SERVICE POINTS	LUBRICANT
1	Check Engine Oil Level	1	Ref. Table 1-5
2	Drain Engine Oil	1	Ref. Table 1-5
3	Clutch Cross Shaft ²	2	SAE Multi-Purpose Grease
4	Clutch Shaft Support ² Bearing	1	SAE Multi-Purpose Grease
5	Upper Driveline U-joint	3	SAE Multi-Purpose Grease
6	Lower Driveline U-joint	8	SAE Multi-Purpose Grease
7	Driveline Steady Bearing ³	1	SAE Multi-Purpose Grease
8	Check Transmission Oil		Ref. Table 1-5
9	Drain Transmisison Oil	1	Ref. Table 1-5
10	Check Differential Oil (front and rear diff.)	2	Ref. Table 1-5
11	Drain Differential Oil ² (front and fear diff.)	2	Ref Table 1-5
12	Check Axle Planetary Gear Oil	4	Ref. Table 1-5
13	Drain Axle Planetary ² Gear Oil	4	Ref. Table 1-5
14 *	Axle Seals ('76 Models only)	4	SAE Multi-Purpose Grease
15	Steering Cylinder Pivots	4	SAE Multi-Purpose Grease
16	Upper and Lower Main Frame Pivots	2	SAE Multi-Purpose Grease
17	Drag Link Pivot Bearings	4	Ref. Table 1-5
18	Main Frame Pivot	1	SAE Multi-Purpose Grease
19	Three-Point Hitch (Option)	10	SAE Multi-Purpose Grease
20	Three-Point Hitch (Option) (oil metal-to-metal parts)		SAE 30
21	Grease Three-Point Hitch Draft Arm Pins ⁴	-	SAE Multi-Purpose Grease
22	Seat	9	SAE Multi-Purpose Grease
23	Door and Window Hinge Pins (oil metal-to-metal parts)	5	SAE 30

NOTES

- 1. PLANETARIES AND DIFFERENTIALS**
To check a planetary hub, the drain plug on the hub is to be at the four o'clock or eight o'clock position. Remove filler plug and check fluid level. The axle differential level plugs are located on the input shaft side of the differential housings. When changing differential and planetary oil, flush before installing new oil.
- 2. CLUTCH SHAFT SUPPORT BEARING LUBRICATION**
Apply four strokes of grease gun to the shaft support bearing; and two strokes to the release bearing.

NOTE

Too frequent greasing could rupture the bearing seal and allow lubricant to enter the clutch assembly or dirt to enter housing.

- 3. DRIVE LINE STEADY BEARING**
The bearing is located in the swing frame between the transmission and rear differential. It is to be greased with three grease gun strokes of multi-purpose grease. The grease fitting is in the bearing housing and can be reached from under the rear frame section.
- 4. THREE POINT HITCH (OPTIONAL)**
The three point hitch requires regular service. Oil metal-to-metal parts of the hitch regularly and to grease the lube points. Annually, or every 400 hours, the draft arm pins (at the tractor frame) must be removed, cleaned and greased.

7 Belts and Filters

7.1 GENERAL

Refer to Tables 1-7 and 1-8 for correct replacement belts and filters. Refer to Figures 1-2, 1-3, 1-4, and 1-5 for location of filters on the tractors.

7.2 BELTS - REPLACEMENT

Table 1-7 lists the belts used on all the Series 2 tractors. Purchase and replace belts as sets to ensure proper matching and avoid overloading the new belt.

7.3 FILTERS

Table 1-8 lists the filters used on the Series 2 Tractors. Check serial number of your tractor when replacing the return hydraulic filters.

TABLE 1-7 Belt Replacement

MODEL 700	PART NUMBER
Alternator (2 per set)	17623
Compressor (2 per set)	20974
Fan and water pump (3 per set)	17622
MODEL 750, 800, 825, 850	
Alternator (2 per set)	31885
Compressor	22925
Fan belt (2 per set)	23265
Water pump (2 per set)	23266
MODEL 900, 950	
Alternator (2 per set)	19508
Compressor	20472
Fan and water pump (3 per set)	19507

8 Storage

8.1 GENERAL

When your tractor is not going to be used for several months, it must be prepared for storage to prevent damage to components. Prepare a kit for the long period of storage. Include plastic bags and tape to seal off openings; paint for scratched and chipped surfaces; grease and rust preventative; cleaning cloths and various fluids to refill all systems to proper level.

8.2 PREPARATION OF TRACTOR FOR STORAGE

After warming the engine, proceed as follows:

1. Drain the crankcase.
2. Install new engine oil filters.
3. Fill the crankcase with new oil.
4. Drain and flush the cooling system, refill it with a correct mixture of water and glycol base antifreeze.
5. Drain oil from axle housing. Refill with recommended lubricant (Ref. Table 1-5).
6. Drain oil from hydraulic circuit reservoir. Refill with recommended fluid. (Ref. Table 1-5).
7. Drain oil from transmission circuit. Refill with recommended lubricant (Ref. Table 1-5). Run engine to circulate coolant.
8. Operate transmission, hydraulic system, steering and brakes to distribute oil to all components.

TABLE 1-8: Filters - Series 2 Tractors

	700	750	800	825	850	900	950
AIR CLEANER ELEMENT - INNER	17444	17444	17444	17444	30927	17444	30927
AIR CLEANER ELEMENT - OUTER	15803	22930	22930	22930	30924	22930	30924
CAB PRESSURIZER ELEMENT - INNER	30988	30988	30988	30988	30988	30988	30988
CAB PRESSURIZER ELEMENT - OUTER	30986	30986	30986	30986	30986	30986	30986
CORROSION ELEMENT	25881	25881	25881	25881	25881	25881	25881
ENGINE BY-PASS OIL FILTER	711T106	19567	19567	19567	19567	19567	19567
ENGINE CRANKCASE OIL FILTER	31133	31133	31133	31133	31133	31133	31133
FUEL FILTER	608T118						
HYDRAULIC FILTER STEERING SIDE (RETURN) UP TO SERIAL NUMBER 26344	76011800	76090300	76032330		76051580	76071100	
HYDRAULIC FILTER STEERING SIDE (RETURN) FROM SERIAL NUMBER 36169	76011861	76090301	76032331	77150001	76051581	76071101	77110301
HYDRAULIC FILTER IMPLEMENT SIDE (SUCTION)	15799	15799	15799	15799	15799	15799	15799
TRANSMISSION FILTER	SW2854						

9. Relieve tension of drive belts; e.g. alternator, air conditioner, compressor.
10. Remove both batteries, charge them fully. Store in a cool, dry place. Keep batteries fully charged. Bring them to a full charge monthly.
11. Clean tractor entirely of all dirt, grease and other foreign matter. Touch up all painted surfaces which are scratched or chipped.
12. Jack up tractor and block up axles to remove weight from tires. Cover tires if they are exposed to heat and sunlight.
13. Coat all exposed hydraulic cylinder shafts with grease or rust preventative.
14. Using plastic bags or tape, seal the following tractor openings: air cleaner inlet, exhaust muffler, fuel tank breather tube and cap, radiator inlet hose, and air conditioning air intake screens.

15. Store tractor in dry, protected place. If tractor is to be stored outside, cover with a waterproof canvas or protective material to protect components.

8.3 PREPARATION OF ENGINE FOR STORAGE

Before storing the tractor, start the engine and run it until coolant temperature is up to at least 160° F (70° C). (Shielding the radiator may be necessary to achieve this temperature under no load). Shutting the engine down while the temperature is up, helps to prevent condensation from forming during storage.

8.4 STORING BATTERIES

NOTE

Every 30 days the battery is in storage, charge to a full charge state.




FIGURE 1-2: Internal Filter Locations - Model 700




FIGURE 1-3: Internal Filter Locations - Models 750, 800, 825 and 850




FIGURE 1-4: Internal Filter Location - Model 900




FIGURE 1-5: Internal Filter Location - Model 950

If the tractor is to be stored for more than 30 days, do the following:

1. Remove batteries from tractor.
2. Check electrolyte level to make sure it is at bottom of cell filler necks.
3. Charge battery before storing it.
4. Store batteries in as cool and dry a place as possible so long as the electrolyte does not freeze.
5. Clean battery tops and keep batteries dry to reduce self-discharge.

8.5 PREPARATION AFTER STORAGE

When tractors are taken out of storage, the following steps are to be taken:

1. Inflate the tires to recommended pressure.
2. Check the cooling system level.
3. Check the oil levels in the crankcase, axles, hydraulic and transmission reservoir.
4. Install the batteries.

8.6 STARTUP OF ENGINE AFTER STORAGE

WARNING

**BEFORE STARTING ENGINE
ENSURE ALL OPERATING
CONTROLS ARE IN THE
NEUTRAL POSITION.**

**OPERATE ALL CONTROLS
ONLY FROM THE OPERATORS
SEAT.**



BE ALERT

**STOP ENGINE BEFORE PER-
FORMING ANY WORK OR
MAINTENANCE ON TRACTOR.**

KEEP ALL SHIELDS IN PLACE.

Initial startup can place abnormal loads on the engine cranking system. To reduce cranking loads, the following steps should be taken:

1. Electrical cables must be clean, tight and in good condition. They should be cleaned at all connection points, (including the battery terminals) before any attempt is made to start the unit.
2. If the fuel filter has been changed prior to startup, prime the filter lines.
3. Never crank the engine for longer than a 30 second period. Allow two minutes for the starting motor to cool between cranking cycles.

4. The battery must be fully charged (1.254 hydrometer reading). This reading should not be taken immediately after charging or discharging the battery.
5. Use cold start equipment if the temperature is below 50° F (10° C).
6. Avoid high rpm after engine starts. Bearings are dry after storage and can be damaged by high rpm. Pressure priming the engine oil system is highly recommended if an external source of oil pressure is available. Make certain oil is clean. Towing the tractor slowly in 3rd gear and 4th range and with the key switch OFF will pre-lube the engine satisfactorily.
7. If new batteries are installed they must be of equivalent or higher capacity than the original batteries.
8. Tighten all V-belts. The alternator belt must be tight and in good condition to keep the battery charged.
9. If the engine does not start within 30 seconds (assuming starting aids are used as necessary and cranking speed is ample) the engine is most likely not receiving fuel.
10. If white smoke is coming from the exhaust, the engine is receiving fuel but more starting aid is needed.
11. If the exhaust is clear, the fuel system is not delivering fuel to the combustion chambers and the following checks should be made:
 - Check that the fuel system is primed adequately.
 - Check operation of electric solenoid switch. This switch has a manual opening knob that overrides the fuel solenoid.
 - Check fuel pump delivery by loosening the ferrule nut on the line between the fuel pump and engine. Clear, solid fuel should flow from the fitting when the engine is cranked.
 - Check for a water freeze blockage at a low point in the fuel line.

9 Troubleshooting

9.1 GENERAL

A troubleshooting subsection at the system level is included with each section in the service manual. Troubleshooting information is in the chart form to help identify the problem so that a possible remedy can be found. The sections are arranged as follows:

1. Engine System - Section 2
2. Drive Train - Section 3
3. Controls and Ancillary Systems - Section 4
4. Hydraulic system - Section 5
5. Electrical System - Section 6
6. Environmental Systems - Section 7
7. Structures - Section 8

Each of the above sections generally is divided into five parts:

1. Introduction
2. Description and Operation
3. Troubleshooting
4. Maintenance
5. Repair and Overhaul

9.2 TROUBLESHOOTING GUIDE

Table 1-9 troubleshoots simple problems and remedies concerning the engines. Further information is in Section 2 - Engines and/or Cummins Maintenance and Operation Manual.

TABLE 1-9: Engine (Section 2)

TROUBLE	PROBABLE CAUSE	REMEDY	REFERENCE
Difficult to start or will not start	No fuel in tank. Improper fuel Dirty or watery fuel. Air in fuel system. Improper timing. Dirty injector nozzles.	Fill tanks with proper fuel. Drain wrong fuel and refill. Drain tanks, bleed system and fill with clean fuel. Bleed fuel system. Check injector pump by skilled serviceman. Clean and repair by skilled serviceman.	Cummins Operation and Maintenance Manual.
Start, but runs improperly.	Dirty or watery fuel, clogged filters, air in fuel system.	Check fuel, replace filters and bleed fuel system.	Cummins Operation and Maintenance Manual.
Lack of power.	Dirty air cleaner Clogged fuel filters. Improper fuel. Vent in fuel tank plugged. Low engine operating temperature. Incorrect injector timing. Incorrect valve clearance. Valves leaking in engine head.	Clean air cleaner. Replace filters. Use recommended cetane number. Clean fuel tank cap. Replace if necessary. Replace thermostat. Check injector pump by skilled serviceman. Correct to proper valve clearance. Adjust and repair if necessary.	Section 2. Cummins Operation and Maintenance Manual. Cummins Operation and Maintenance Manual. Cummins Operation and Maintenance Manual.

TABLE 1-9: Engine (Section 2) Continued

TROUBLE	PROBABLE CAUSE	REMEDY	REFERENCE
Overheating	<p>Defective radiator cap.</p> <p>Radiator plugged with debris and dirt.</p> <p>Defective thermostat.</p> <p>Loose or broken fan belt.</p> <p>Overloading engine.</p> <p>Low oil level or improper viscosity in engine.</p> <p>Low coolant level.</p> <p>Scale build-up in cooling system.</p>	<p>Replace radiator cap.</p> <p>Clean radiator core.</p> <p>Replace thermostat.</p> <p>Tighten or replace belt.</p> <p>Downshift into lower gear. Reduce engine load.</p> <p>Replace to proper oil level. Change oil to proper viscosity.</p> <p>Check for leaks, radiator cap, hoses.</p> <p>Remove scales using cooling system cleaner.</p>	Section 2.
Uses too much fuel.	<p>Overloaded engine.</p> <p>Improper fuel.</p> <p>Dirty air cleaner.</p> <p>Engine not at proper operating temperature.</p> <p>Incorrect valve clearance.</p> <p>Improper timing.</p>	<p>Downshift into lower gear. Reduce engine load.</p> <p>Use recommended diesel fuel.</p> <p>Clean air cleaner.</p> <p>Check thermostat</p> <p>Correct to proper valve clearance.</p> <p>Check injector pump by skilled serviceman.</p>	<p>Section 2.</p> <p>Cummins Operation and Maintenance Manual.</p>
Uses too much oil or low oil pressure.	<p>Oil is improper viscosity and weight.</p> <p>Restriction in air intake system.</p> <p>External oil leaks on engine.</p> <p>Worn valve guides and/or seals.</p> <p>Worn rings and/or pistons.</p>	<p>Change to the recommended oils.</p> <p>Clean air intake system.</p> <p>Stop external leakage.</p> <p>Replace.</p> <p>Overhaul and replace.</p>	<p>Section 2.</p> <p>Section 2 and Cummins Operation and Maintenance Manual.</p> <p>Cummins Operation and Maintenance Manual.</p>

TABLE 1-9: Engine (Section 2) Continued

TROUBLE	PROBABLE CAUSE	REMEDY	REFERENCE
White smoke from engine.	Low engine temperature.	Warm up engine to normal temperatures before operating under load.	refer to para 5.2 Section 2. Cummins Operation and Maintenance Manual.
	Improper fuel.	Change to recommended diesel fuel.	
	Defective thermostat.	Replace thermostat.	
	Incorrect timing of engine.	Injectors and / or pump require service.	
Gray or black smoke from engine.	Overloading engine.	Downshift into lower gear. Reduce engine load.	Refer to para 5.2. Section 2. Cummins Operation and Maintenance Manual.
	Dirty air cleaner.	Clean and / or replace filter.	
	Improper fuel.	Change to recommended diesel fuel.	
	Defective muffler.	Replace.	
	Improper timing and / or faulty injection system.	Determine cause and repair.	

9.3 TROUBLESHOOTING DRIVE TRAIN

Table 1-10 troubleshoots simple problems and remedies of the drive train. Refer to Section 3 - Drive Train for further service information.

TABLE 1-10 Drive Train

TROUBLE	PROBABLE CAUSE	REMEDY	REFERENCE
---------	----------------	--------	-----------

Clutch

Clutch squeaks	Dry clutch cross shaft and / or release shaft bearing.	Lubricate cross shaft and / or release shaft bearing.	Section 3.
Clutch slips	Operator riding the clutch pedal.	Avoid riding the clutch pedal.	Section 4. Section 3.
	Too little clutch pedal free play.	Adjust clutch pedal free travel.	
	Worn clutch.	Replace.	
Clutch grabs, chatters, rattles, and / or vibration.	Any of these indicate service, repair, adjustment of clutch.	Service clutch. Repair or adjust.	Section 3.

Sample of manual. Download All 348 pages at:

<https://www.arepairmanual.com/downloads/new-holland-ford-700-750-800-825-850-900-950-tractors-service-repair-manual/>