

Product: New Holland Ford 1150 Tractor Service Repair Manual

Full Download: <https://www.arepairmanual.com/downloads/new-holland-ford-1150-tractor-service-repair-manual/>

VERSATILE

Service Manual



Tractor
1150



Sample **Reprinted** Download All 290 pages at:

<https://www.arepairmanual.com/downloads/new-holland-ford-1150-tractor-service-repair-manual/>

40115010

Product: New Holland Ford 1150 Tractor Service Repair Manual

Full Download: <https://www.arepairmanual.com/downloads/new-holland-ford-1150-tractor-service-repair-manual/>

Sample of manual. Download All 290 pages at:

<https://www.arepairmanual.com/downloads/new-holland-ford-1150-tractor-service-repair-manual/>

1150 TRACTOR SERVICE MANUAL



VERSATILE FARM EQUIPMENT COMPANY

A division of Versatile Corporation

1260 CLARENCE AVENUE, WINNIPEG

MANITOBA, CANADA, P3T 1T3/(204) 284-6100

VERSATILE® is a registered trademark of Versatile Corporation
Copyright® 1984 Versatile Corporation

74801
JUNE 1984
PRINTED IN CANADA/8C/LG

FOREWORD

This service manual provides instructions for troubleshooting, removal, inspection, replacement and overhaul of 1981, 1982 and 1983 Model 1150 VERSATILE® Tractor components.

The service manual should be used in conjunction with the parts manual for the specific model year.

A table of contents precedes each section providing detailed coverage of the information contained within that section. The index at the end of the book should ease location of specific information.

REVISIONS AND ADDITIONS

The purpose of a loose leaf service manual is to enable us to keep the book updated.

When changes are made, pages will be forwarded to you marked either as replacement or additional pages.

Replacement pages will carry the same page number as the original. Discard the original page and insert the replacement page in its place. Added pages will carry the original page number plus an alphabetical suffix. Insert these pages after the existing page.

Please complete the feedback page at the back of the manual and return it to Versatile Farm Equipment Company. Such information will help us improve our service manuals in the future.

Safety

This section contains general safety precautions which should be thoroughly studied and practised by all service personnel.

GENERAL SAFETY

1. Mount a fire extinguisher in the service area. Maintain it according to manufacturer's recommendations.
2. Never operate tractor in a closed building. If it is absolutely necessary to do so, ensure building is well ventilated and use ducting to channel exhaust fumes outside.
3. Always keep clothing relatively tight and belted. Remove jewelry or any objects that might catch in moving parts.
4. Use steps and handholds when entering or leaving tractor.
5. Park tractor on a clear, level area before servicing. Center steering, put all controls in neutral, set parkbrake, shut down engine and remove key. Engage articulation lock and chock wheels.
6. Operate all tractor controls from operator's seat.
7. Clear personnel before moving tractor.

TRANSPORT SAFETY

1. Use a strong chain, cable or tow bar and attach securely to front frame or drawbar of tractor. Do not tow tractor faster than 25 km/h (15 mph).
2. Use a trailer of at least 22 680 kg (25 ton) capacity to haul tractor.
3. Chain tractor securely to trailer, block wheels, set parkbrake and engage articulation lock to limit tractor movement.

JACKING SAFETY

1. Ensure jacks meet or exceed capacities listed in Special Tools and Equipment sections throughout this manual.
2. Ensure parkbrake and articulation lock are engaged and appropriate wheels are chocked or blocked.
3. Brace swing frame with strong wedge on frame pivot and engage articulation lock to prevent jackknifing.
4. Ensure jack is solid against component to be raised.
5. Use heavy block as base for jack. Block should be long enough to prevent jack sinking, tipping or shifting. Any additional blocks should be under jack.
6. Jack only high enough to install appropriate capacity safety stands.
7. Check jack immediately after starting lift. Lower jack immediately if jack slips or tilts.
8. Do not raise tractor or component higher than jack's limit.
9. Place safety stands under tractor or component and lower jack so that stands take the weight. Do not trust jack to support the weight while working.

HOIST SAFETY

1. Use a chain hoist and frame to lift tractor or components. Follow capacities recommended in Special Tools and Equipment sections throughout the manual.
2. Protect yourself from injury while raising tractor or components by observing the following precautions:
 - a. Do not stand on tractor when lifting.
 - b. Keep hands away from pinch points where parts pivot or where hoist chains or cables tighten against frame.

- c. Do not let tractor or component swing and strike personnel or hoist frame as it leaves ground.
- d. Keep support stands nearby and place under lifted item when the necessary height is reached.
- e. Do not go under tractor or component supported by hoist. Place support stands of recommended capacity under item before working on it.

- 8. Do not remove engine radiator pressure cap while engine is hot. Allow it to cool to 74° C (165° F) before removing pressure cap.
- 9. Shut down engine and remove key before making any linkage adjustment.
- 10. Welding fuel tanks is dangerous and not recommended.
- 11. Repair adhesive is very flammable. Keep adhesive and its vapors away from heat, sparks or flame.
- 12. During adhesive use and until vapor is dissipated, avoid using spark producing electrical equipment. Keep container closed when not in use.
- 13. Use adhesive only in a well ventilated area.

MAINTENANCE SAFETY

- 1. Shut down engine before repairing tractor.
- 2. Be alert when approaching tractor while it is running, especially around the articulation joint.
- 3. Engage articulation lock during tractor overhaul operations.
- 4. Never service, lubricate, clean or adjust tractor while it is running.
- 5. Before working on any hydraulic system component, shut down engine, set parkbrake, turn steering wheel and move implement control levers backwards and forwards several times to relieve system pressure. Disconnect any component that may be connected to the remote couplers.
- 6. Wear a face shield or goggles to protect your eyes and heavy gloves to protect your hands when searching for hydraulic leaks or charging the air conditioning system.
- 7. Escaping hydraulic oil under pressure can penetrate the skin, causing severe personal injury. Use a piece of cardboard or wood as a backstop when searching for leaks. If injured by escaping hydraulic oil, get immediate medical attention.

FUEL AND FLUID SAFETY

- 1. Do not smoke and avoid open flames when:
 - a. Filling fuel tanks.
 - b. Filling batteries.
 - c. Working on air conditioning systems. Refrigerant vapor and flame combine to form a lethal gas.
- 2. Never use an open pail or can to transport fuel. Use only an approved container manufactured for that purpose.
- 3. If clothing is splashed with fuel, change immediately. Fuel soaked clothes are an extreme fire hazard.
- 4. Dispose of all fuel soaked rags. Do not leave them lying around work area where they may be exposed to flame, spark or cigarette smoking.

SECTION 1: SPECIFICATIONS AND DATA

Table of Contents

| | | |
|----------|------------------------------------|------|
| 1 | Introduction | 1-2 |
| 2 | Hoists and Jacks | 1-2 |
| 3 | Specifications | 1-2 |
| 3.1 | Air Cleaner | 1-2 |
| 3.2 | Air Conditioner | 1-2 |
| 3.3 | Axles | 1-2 |
| 3.4 | Brakes | 1-2 |
| 3.5 | Cab | 1-2 |
| 3.6 | Clutch | 1-2 |
| 3.7 | Cooling System | 1-2 |
| 3.8 | Dimensions | 1-3 |
| 3.9 | Drawbar | 1-3 |
| 3.10 | Electrical | 1-3 |
| 3.11 | Engine | 1-3 |
| 3.12 | Exhaust System | 1-3 |
| 3.13 | Frame | 1-3 |
| 3.14 | Fuel Tanks | 1-3 |
| 3.15 | Hydraulics | 1-3 |
| 3.15.1 | Steering Valve | 1-4 |
| 3.15.2 | Implement Control Valve | 1-4 |
| 3.16 | Options | 1-4 |
| 3.17 | Radio | 1-4 |
| 3.18 | Steering | 1-4 |
| 3.19 | Tires | 1-4 |
| 3.20 | Transmission | 1-4 |
| 4 | Fuel, Fluids and Lubricants | 1-5 |
| 4.1 | Fuels | 1-5 |
| 4.2 | Fluids | 1-5 |
| 4.2.1 | Brakes | 1-5 |
| 4.2.2 | Coolant | 1-5 |
| 4.3 | Lubricants | 1-5 |
| 4.3.1 | Grades | 1-5 |
| 4.3.2 | Engine Oil | 1-5 |
| 4.3.3 | Differential and Planetaries | 1-6 |
| 4.3.4 | Hydraulic and Transmission Oil | 1-6 |
| 4.3.5 | Grease | 1-6 |
| 5 | Lubrication | 1-7 |
| 5.1 | General | 1-7 |
| 6 | Belts and Filters | 1-7 |
| 6.1 | General | 1-7 |
| 7 | Storage | 1-9 |
| 7.1 | Storing the Tractor | 1-9 |
| 7.2 | Storing the Batteries | 1-9 |
| 7.3 | Removal from Storage | 1-10 |
| 7.4 | Initial Engine Start-Up | 1-11 |

SECTION 1: SPECIFICATIONS AND DATA

1 Introduction

This section contains general information on specifications, capacities, lubricants, fluids and fuels for the tractor.

2 Hoists and Jacks

Refer to Safety Section at beginning of manual.

3 Specifications

3.1 AIR CLEANER

Type Dual element, dry type with safety element, precleaner, exhaust aspirated, air intake restriction warning light

3.2 AIR CONDITIONER

Charge 3 (3.5 lb)

Oil Level 200 mL (7 oz)

3.3 AXLES

Type Spiral bevel differential unit, outboard planetary, floating ring gear final drive

Differential Ratio 4.63:1

Lubrication SAE 85W140

Oil Capacity 42 L (11.1 gal US)

Planetary Ratio 5.625:1

Final Ratio 26.04:1

3.4 BRAKES

Type

Mechanical Twin disc, twin caliper

Powershift Single disc, twin caliper

Disc

Mechanical 430 mm (17 in.) driveline mounted on each side of transmission

Powershift 510 mm (20 in.) driveline mounted on each side of transmission

Caliper Twin piston, non-floating, hydraulically actuated by foot pedal

Parkbrake Integral with hydraulic brake, self-adjusting, actuated by overcenter lever

3.5 CAB

Type Independent module type with rollover protective structures (ROPS ASAE S336.1)

Seatbelt SAE J141, SAE J385

3.6 CLUTCH

Type

Mechanical 394 mm (15.5 in.) dia, three plate dry-type, safety start switch

Powershift 394 mm (15.5 in.) dia twin torsional damper, safety start switch

3.7 COOLING SYSTEM

Capacity 80.4 L (85 qt US)

Radiator Core Area (Frontal) 1.25 m² (1 935 in.²)

Fan 915 mm (36 in.) sucker-type, geardriven

Pressure Cap 48 kPa (7 psi)

3.8 DIMENSIONS

Wheelbase 3 560 mm (140 in.)
Overall Length 6 890 mm (271 in.)
Nominal Turning Radius 4 630 mm (182 in.)
to centerline of drawbar
Turning Radius
(measure to outside of outer tire) 6 475 mm
(255 in.) with 20.8 x 42 duals
Maximum Operating Weight 20 800 kg (46 500 lb)

3.9 DRAWBAR

Type Swinging clevis of 50 x 150 mm
(2 x 7 in.) steel with wear block.
Replaceable hardened bushing
Height 455 mm (18 in.) to top
of main member

3.10 ELECTRICAL

System Voltage 12 V negative ground
Starting System 24 V negative ground
Batteries Two low maintenance,
8D 29 plates per cell
Alternator 90A, two charge lines
Lamps Two 60W headlights,
eight 50W halogen work lamps,
two red taillights and four flashers
Trailer Connector Cable SAE J560B

3.11 ENGINE

Type Cummins Big Cam III
KTA-1150-C470 inline 6 cylinder
turbocharged, aftercooled diesel
Maximum Torque 2 130 N·m (1 570 lbf ft)
at 1 500 r/min
Maximum Brake Horsepower ... 350 kW (470 hp)
at 2 100 r/min

Full Load Governed Speed 2 100 r/min
Full Throttle (No load) Speed 2 250-
2 300 r/min
Idle Speed 1 000 r/min
Crankcase Capacity 38 L (40 qt US)
Full flow oil filter with bypass oil conditioner
filter and oil to water cooler, 30° angular capaci-
ty oil pan.

3.12 EXHAUST SYSTEM

Muffler One 254 x 381 mm
(10 x 15 in.) dual
Inlet Diameter 127 mm (5 in.)
Outlet Diameter 152 mm (6 in.)

3.13 FRAME

Type 42° angled articulated frame
Oscillation ± 15°
Articulation Lock Bar-type

3.14 FUEL TANKS

Total Capacity 1 515 L (400 gal US)
Type 63.5 mm (2.5 in.) filler neck
on both tanks. Remote breather is 610
mm (24 in.) above tanks

3.15 HYDRAULICS

Tank Capacity
Mechanical 95 L
(25 gal US)
Powershift 83 L
(22 gal US)

Type Closed center; load sensing steering
Pump Two variable displacement
pressure and flow
compensated piston pumps

3.15.1 STEERING VALVE

Displacement 1.2 L (75 in.³)
Max Flow 147.5 L/min (39 gpm)
Revolutions lock-to-lock 5.3

3.15.2 IMPLEMENT CONTROL VALVE

Type 5 spool; individual flow on each spool adjustable 0° to 156° approx on all spools with detented positions; No. 1 includes float position

Pressure Release 15 MPa ± 517 kPa (2 175 psi ± 75psi)

System Filtration 100 mesh reusable screen filter on suction line; 25 micron replacement element on return line

Temperature Sensor Alarm light set for 93° C (200° F)

3.16 OPTIONS

Engine Block Coolant Heater
Cold Start Aid
Differential Lock
Clutch Decelerator

3.17 RADIO

Type AM/FM stereo cassette player

3.18 STEERING

Type Hydrostatic, two 101.6 x 460 mm
(4 x 18 in.) cylinders

3.19 TIRES

Inflation See Table 1,
outside tires (duals or triples)
should have 14 kPa (2 psi) less
pressure than inside tires

3.20 TRANSMISSION

Capacity
Mechanical 18.5 L (19 qt US)
Powershift 68.2 L (18 gal US)

| | |
|------------|---|
| Type | |
| Mechanical | 8 forward, 4 reverse; constant mesh with sliding shift collars |
| Powershift | 12 forward, 2 reverse; constant mesh with hydraulic master clutch |

Lubrication Independent system with
pump, filter, cooler and
low pressure sensor

TABLE 1-1: Tire Inflation Chart

| SIZE | PLY | NO BALLAST | MAX BALLAST |
|-----------|-----|------------------|------------------|
| 20.8 x 42 | 10 | 110 kPa (16 psi) | 138 kPa (20 psi) |
| 20.8 x 38 | 8 | 110 kPa (16 psi) | 143 kPa (20 psi) |
| 24.5 x 32 | 10 | 124 kPa (18 psi) | 138 kPa (20 psi) |
| 30.5 x 32 | 10 | 110 kPa (16 psi) | 110 kPa (16 psi) |

4 Fuel, Fluids and Lubricants

4.1 FUELS

The tractors operate on No. 2 diesel fuel, although they will also operate satisfactorily on other fuels within these specifications:

1. Less than one percent sulphur content.
2. Sediment and water less than 0.1 percent.
3. Cetane number of at least 40. A higher cetane number fuel may be necessary at low temperatures or high altitudes.
4. Pour point below the lowest expected temperature.
5. Less than 0.02 percent ash content.
6. Viscosity of 1.4 to 5.8 mm²/s at 37.8° C (100° F).

Refer to Cummins Manual for further details.

4.2 FLUIDS

SAE J1703 Super Duty Fluid is recommended for all temperature usage.

4.2.2 Coolant

WATER: Clean and preferably soft

ANTIFREEZE: Use a good commercial grade glycol base antifreeze in the proportions recommended by its manufacturer. Do not use oil base or alcohol base antifreezes. Foaming and jelling could result and damage the cooling system.

IMPORTANT

Do not use calcium chloride solution. It is harmful to the cooling system.

IMPORTANT

Do not use Dow Chemical Dowtherm 209 brand antifreeze in the tractor. It is not compatible with the corrosion inhibitor.

Check engine coolant level daily and keep within 50 mm (2 in.) of surge tank filler neck. When adding coolant due to leakage, add one unit DCA to 3.75 L (1 gal US) water then mix at a 1:1 ratio with antifreeze.

4.3 LUBRICANTS

4.3.1 Grades

CD (Commercial grade) used in turbocharged diesel engines. It provides protection from bearing corrosion, engine wear and high temperature deposits.

SF (Service grade) provides increased oxidation stability and improved anti-wear. It also protects against rust, engine deposits and corrosion.

4.3.2 Engine Oil

Check engine oil daily. Do not mix brands or grades of oil. If it is necessary to change brands of oil, completely drain the engine and replace both filters before filling. Oil consumption may vary between 1 and 3 L (1 to 3 qt US) per day depending on loads and operating conditions.

RECOMMENDED OIL

| Viscosity | Ambient Temp |
|-----------|-------------------------------------|
| 10W30 | – 25° to 35° C (– 13° to 95° F) |
| 15W40 | – 10° C and above (14° F and above) |
| 20W40 | 0° C and above (32° F and above) |

ALTERNATE OILS

| Viscosity | Ambient Temp |
|-----------|-----------------------------------|
| 10W | – 25° to 0° C (– 13° to 32° F) |
| 20W20 | – 5° to 20° C (23° to 68° F) |
| 30 | 4° C and above (39° F and above) |
| 40 | 10° C and above (50° F and above) |

Below – 23° C (– 10° F), refer to Arctic Oil Recommendations in the Cummins Manual.

4.3.3 Differentials and Planetaries

Use SAE 85W140GL5 for temperatures above 32° C (90° F).

Use SAE 80W90GL5 for temperatures below 32° C (90° F)

4.3.4 Hydraulic and Transmission Oil

Use VERSATILE® HyGear 23 for temperatures above 4° C (40° F)

Use VERSATILE® HyGear 24 for temperatures below 4° C (40° F)

4.3.5 Grease

Use lithium complex grease for extreme pressure conditions. Use SAE high temperature, multi-purpose grease for all other fittings.

TABLE 1-2: Fuels, Fluids and Lubrication Schedule

| | AS REQUIRED | DAILY 10 HOURS | WEEKLY 50 HOURS | MONTHLY 200 HOURS | 400 HOURS | ANNUALLY | LUBRICANT ⁴ | NUMBER OF POINTS | SERVICE POINTS ⁵ |
|--|----------------|----------------|-----------------|-------------------|-----------|----------|------------------------|------------------|-----------------------------|
| Change fuel system filter | | | | | • | • | | 1 | 27 |
| Check brake fluid level | | | • | • | • | • | D | 1 | |
| Change coolant/install precharge element | | | | | | • | | 1 | |
| Change coolant filter (DCA) | | | • | • | | | | 1 | 25 |
| Change engine oil and filters | • ¹ | | • | • | • | • | A | 2 | 26,31 |
| Lubricate differentials | | | • | • | • | • | C | 9,19 | |
| Change planetary/differential oil | • ² | | | • | • | • | C | 6 | 8 |
| Change hydraulic oil | | | | • | • | • | B | 1 | |
| Change hydraulic suction filter | | | | • | • | • | | 1 | 33 |
| Change hydraulic return filter | | | • | • | • | • | | 1 | 32 |
| Change trans oil, wash filter screen | | | | • | • | • | B | 1 | 29,30 |
| Change trans return filter | • ³ | | • | • | • | • | | 1 | 28 |
| Lubricate driveline | | | • | • | • | • | E | 11 | |
| Lubricate driveline steady bearing | | • | • | • | • | • | E | 1 | 11 |
| Lubricate main pivot frame | | • | • | • | • | • | E | 1 | 20 |
| Lubricate upper and lower pivots frame | | • | • | • | • | • | E | 2 | 21,24 |
| Lubricate drag link pivot bearings | | • | • | • | • | • | E | 4 | 22 |
| Lubricate steering cylinder pivots | | • | • | • | • | • | E | 4 | 23 |
| Lubricate clutch cross shaft | | • | • | • | • | • | F | 2 | 2 |
| Lubricate clutch shaft support bearing | | • | • | • | • | • | F | 1 | 1 |
| Lubricate clutch release bearing | • | • | • | • | • | • | F | 1 | 1 |
| Lubricate door and window hinge pins | | | | | | • | A | 4 | |

1. Change oil after the first 50 hours of operation and every 200 hours thereafter.

2. Change oil after the first 30 hours of operation and every 400 hours thereafter.

3. Change filter after the first 50 hours of operation and every 200 hours thereafter.

4. See Table 1-3, Lubricant Brand Equivalency Chart.

5. See Figure 1-1, 1-2 or 1-3 for service point locations.

5 Lubrication

5.1 GENERAL

Service intervals recommended in this manual are based on operation under average conditions. Service the tractor more frequently when operating tractor in conditions of severe heat, cold, dust or humidity. Table 1-2 lists the points and frequency of lubrication. Refer to Table 1-3 for the lubricant brands meeting the required specifications. Figures 1-1 and 1-2 show the tractor lubrication points.

1. Check battery charge every 90 days. If not 1.270 specific gravity, charge batteries. See Electrical System, Section 3, LUBRICATION AND MAINTENANCE.

6 Belts and Filters

6.1 GENERAL

Refer to Table 1-4 for correct replacement belts and filters. Refer to Figure 1-3 for filter locations.




FIGURE 1-1: Driveline Lubrication Points

TABLE 1-3: Lubricant Brands

| | | VERSATILE | IMPERIAL | SHELL | TEXACO | GULF | CLASSIFICATION |
|---|------------------------------|------------------------|----------------------------|------------------------------|-----------------|--------------------------|---|
| A | Engine | | Essolube XD3 | Rotella T | Ursa Super Plus | Low Ash Super Duty 15W40 | Factory fill is SAE 10W30 SF/CD above 4° C (40° F) |
| B | Trans Hyd Oil | HyGear 23 HyGear 24 | Hydraul 56 Hydraul 50 | Donax TD Donax TDL | Texamatic TDH | Duratran | SAE 20 SF/CD above 4° C (40° F) SAE 5W20 below 4° C (40° F) |
| C | Differential/Planetary | | Gear Oil GX | Spirax HD | Multigear EP | Gearlube | SAE 85W140 GL5 above 32°C (90°F) SAE 80W90 below 32° C (90° F) |
| D | Brake Fluid | | Atlas Extra Heavy Duty 450 | Super Heavy Duty Brake Fluid | | H.D. Brake Fluid | SAE J 1703F All weather conditions |
| E | Grease | | Unitol | Alvania EP2 | Marfak AP | Super Crown E.P.2 | SAE Multipurpose grease, high temp, all weather cond |
| F | Clutch Shaft Support Bearing | | Unirex EP2 | | | | Extreme pressure conditions, lithium complex grease |




FIGURE 1-2: Steering Cylinder and Articulated Frame Lubrication Points

TABLE 1-4: Belts and Filters

| Component | Part Numbers | | | | |
|-------------------------------|---------------------|----------------|------------------|----------------|------------------|
| | Year | Year | Year | Year | |
| | 1981 (Mech) | 1982 (Mech) | 1982 (Power.) | 1983 (Mech) | 1983 (Power.) |
| Engine Crankcase Filter | 31133 | 31133 | 31133 | 31133 | 31133 |
| Engine Bypass Filter | 57124 | 57124 | 57124 | 57124 | 57124 |
| Fuel Filter Element | 61559 | 61559 | 61559 | 61559 | 61559 |
| Air Cleaner Primary Element | 63971 | 63971 | 63971 | 63971 | 63971 |
| Air Cleaner Safety Element | 63972 | 63972 | 63972 | 63972 | 63972 |
| Water Filter | 25881 | 25881 | 25881 | 25881 | 25881 |
| Water Filter Precharged | 26206 | 26206 | 26206 | 26206 | 26206 |
| Transmission Circuit Element | 63304 | 63304 | 68256 | 63304 | 68256 |
| Hydraulic Suction Element | 63290 | 63290 | 61071 | 63290 | 61070 |
| Hydraulic Return Element | 63297 | 63297 | 61070 | 63297 | 61070 |
| Cab Pressurizer Panel Element | 63218 | 63218 | 63218 | 63218 | 63218 |
| Cab Recirculation Element | 63077 | 63077 | 63077 | 63077 | 63077 |

7 Storage

7.1 STORING THE TRACTOR

1. Change hydraulic oil.
2. Change transmission oil.
3. Change engine coolant.
4. Drain and flush gear oil from differentials and planetary gear housings. Fill with new oil.
5. Change engine oil and filters.
6. Start engine. While engine is warming up, operate the transmission, hydraulic system, steering and differentials to distribute the new lubricants to components. Warm engine to at least 70° C (160° F); it may be necessary to shield the radiator to achieve this temperature. Stop engine.
7. Clean tractor of all debris, dirt and accumulated grease.
8. Drive tractor to storage location.
9. Relieve tension on alternator, air conditioner compressor and fan belts.

10. Coat all exposed hydraulic cylinder shaft areas with grease or a rust preventative.
11. Using plastic bags or tape, seal the following openings: air cleaner inlet, exhaust muffler, fuel tank breather and air conditioner air intake screens.
12. Touch up all scratches or chips with VERSATILE® paint.
13. Block up tractor to remove weight from tires. Remove dual tires.
14. Cover tires if they will be exposed to heat and/or direct sunlight.
15. If tractor is to be stored outside, cover with a waterproof canvas or other protective material.

7.2 STORING BATTERIES

1. Low maintenance batteries do not require charging before or during storage. Under normal conditions, storage life will be 12 months before recharging.
2. Check battery charge. If not 1.270 specific gravity, charge batteries. See Electrical




FIGURE 1-3: Filter Locations

System, Section 3, LUBRICATION AND MAINTENANCE.

3. Remove batteries from tractor and store in a dry, weatherproof area.

WARNING



BE ALERT

AVOID SMOKING OR OPEN FLAMES IN OR NEAR BATTERY CHARGING AREA DURING OR FOR TWO HOURS FOLLOWING CHARGING

7.3 REMOVAL FROM STORGE

1. Remove protective covering from tractor tires and seals from air cleaner inlet, exhaust muffler, fuel tank breather and air conditioner air intake screens.
2. Remove blocks. Lower tractor onto tires.
3. Correct any leaks.

4. Inflate tires to recommended pressure.
5. Install fully charged batteries. Tighten cable clamps at both ends of cables.
6. Tension alternator, air conditioner compressor and fan belts.
7. Check fluid level of engine crankcase, axles and planetaries, transmission, hydraulic reservoir, master brake cylinder reservoir and engine coolant radiator.
8. If fuel filters were changed during or after storage, ensure filters, pump and lines are primed.
3. Press on clutch and put transmission in neutral. Hold clutch pedal to floor.
4. Turn keyswitch ON.
5. When engine starts, observe above IMPORTANT. Alternator warning light should go out. Release clutch slowly and transmission oil pressure warning light should go out within 30 seconds.
6. Warm engine to at least 50° C (120° F) before putting it under load.

If engine does not start after 30 seconds cranking cycle, repeat above starting procedures.

7.4 INITIAL ENGINE START-UP

Initial start-up can place abnormal loads on the cranking system. Do not crank the engine longer than 30 seconds. Allow at least 2 min between cranking cycles to permit starting motor to cool and batteries to recover.

1. Set parkbrake.
2. Set throttle to idle.

IMPORTANT

On initial start-up of engine, do not increase speed above 1 000 r/min, unless necessary to prevent stalling, until engine oil pressure is normal.

If engine still does not start, observe exhaust during cranking. If exhaust is clear, the engine is not receiving fuel. Check the following:

1. Dip check fuel tank level by inserting a clean stick (broom handle) through the fuel tank filler neck.
2. Fuel line obstruction or loose union connection.
3. Operation of fuel solenoid valve.
4. Fuel system for adequate priming.
5. Fuel pump operation for delivery of fuel.

SECTION 2: ENGINE SYSTEMS

Table of Contents

| | | |
|----------|----------------------------------|------|
| 1 | Introduction | 2-3 |
| 1.1 | Specifications | 2-3 |
| 1.1.1 | Fluids and Capacities | 2-3 |
| 1.1.2 | Torque Values | 2-3 |
| 1.1.3 | Filters | 2-3 |
| 1.2 | Troubleshooting | 2-3 |
| 1.3 | Engine Replacement | 2-3 |
| 1.3.1 | Special Tools and Equipment | 2-3 |
| 1.3.2 | Removal | 2-3 |
| 1.3.3 | Installation | 2-9 |
| 1.4 | Engine Mount Replacement | 2-12 |
| 1.4.1 | Special Tools and Equipment | 2-12 |
| 1.4.2 | Front Mounts | 2-12 |
| 1.4.3 | Rear Mounts | 2-13 |
| 2 | Fuel System | 2-13 |
| 2.1 | General | 2-13 |
| 2.2 | Troubleshooting | 2-13 |
| 2.2.1 | Inspection Procedures | 2-14 |
| 2.2.2 | Throttle Linkage Adjustment | 2-14 |
| 2.2.3 | Fuel Shutoff Solenoid Check | 2-14 |
| 2.2.4 | Purging Fuel Lines and Hoses | 2-14 |
| 2.2.5 | Priming Fuel System | 2-15 |
| 2.3 | Replacement of Fuel Hoses | 2-15 |
| 2.3.1 | Suction, Supply and Return Hoses | 2-15 |
| 2.3.2 | Breather Hose | 2-15 |
| 2.3.3 | Crossover Hose | 2-15 |
| 2.4 | Fuel Tank Replacement | 2-15 |
| 2.4.1 | Removal | 2-15 |
| 2.4.2 | Installation | 2-16 |
| 2.5 | Fuel Gauge Sender Replacement | 2-17 |
| 2.6 | Cold Start | 2-17 |
| 2.6.1 | Inspection Procedures | 2-18 |
| 2.6.2 | Ether Cylinder Replacement | 2-18 |
| 3 | Cooling System | 2-19 |
| 3.1 | General | 2-19 |
| 3.2 | Troubleshooting | 2-19 |
| 3.2.1 | Inspection Procedures | 2-19 |
| 3.2.2 | Coolant Level/Temperature Sender | 2-19 |
| 3.3 | Coolant Hose Replacement | 2-19 |
| 3.3.1 | Bottom Radiator Hoses | 2-19 |
| 3.3.2 | Top Radiator Hoses | 2-20 |
| 3.3.3 | Deaerating Hose | 2-20 |
| 3.3.4 | Radiator Bleeder Hose | 2-20 |

| | | |
|----------|--|-------------|
| 3.4 | Radiator Replacement | 2-21 |
| 3.4.1 | Special Tools and Equipment | 2-21 |
| 3.4.2 | Removal | 2-21 |
| 3.4.3 | Disassembly | 2-22 |
| 3.4.4 | Assembly | 2-22 |
| 3.4.5 | Installation | 2-22 |
| 3.5 | Flushing of Cooling System | 2-22 |
| 3.5.1 | Special Tools and Equipment | 2-22 |
| 3.5.2 | Procedure | 2-22 |
| 3.6 | Reverse Flushing of Engine Cooling System | 2-22 |
| 3.6.1 | Special Tools and Equipment | 2-22 |
| 3.6.2 | Procedure | 2-23 |
| 4 | Air Intake and Exhaust System | 2-24 |
| 4.1 | General | 2-24 |
| 4.2 | Troubleshooting | 2-24 |
| 4.2.1 | Inspection Procedures | 2-24 |
| 4.2.2 | Precleaner | 2-24 |
| 4.2.3 | Aspirator System | 2-25 |
| 4.2.4 | Exhaust Temperature Sender | 2-25 |
| 4.2.5 | Air Cleaner Restriction Sender | 2-25 |
| 4.3 | Air Cleaner Replacement | 2-25 |
| 4.3.1 | Removal | 2-25 |
| 4.3.2 | Installation | 2-26 |
| 4.4 | Muffler Replacement | 2-26 |
| 4.4.1 | Removal | 2-26 |
| 4.4.2 | Installation | 2-26 |
| 5 | Lubrication System | 2-26 |
| 5.1 | General | 2-26 |
| 5.2 | Troubleshooting | 2-26 |
| 5.2.1 | Inspection Procedures | 2-27 |
| 5.2.2 | Oil Pressure/Temperature Senders | 2-72 |
| 5.3 | Hose Replacement | 2-27 |
| 5.3.1 | Bypass Filter Supply Hose | 2-27 |
| 5.3.2 | Bypass Filter Drain Hose | 2-27 |
| 5.4 | Engine Oil and Filter Change | 2-27 |
| 5.5 | Priming Lubrication System | 2-28 |
| 6 | Cold Start Aid | 2-29 |
| 6.1 | General | 2-29 |
| 6.2 | Troubleshooting | 2-29 |
| 6.2.1 | Troubleshooting Procedure | 2-30 |
| 6.2.2 | Troubleshooting Checklist | 2-31 |
| 6.3 | Replacement of Cold Start Cylinder | 2-31 |
| 6.4 | Removal and Installation of Cold Start Valve | 2-32 |

SECTION 2: ENGINE SYSTEMS

1 Introduction

The Versatile 1150 tractor uses a Cummins Big Cam III six cylinder KTA-1150-C470 engine. This section contains service procedures for the engine-related subsystems. For service procedures and engine overhaul information not covered in this manual, refer to the Cummins operation and maintenance or engine shop manuals available from any Cummins dealer.

1.1 SPECIFICATIONS

1.1.1 Fluids and Capacities

Refer to Table 2-1.

TABLE 2-1: Fluids and Capacities

| SYSTEM | FLUID | CAPACITY |
|----------------------|--------------------------------|---------------------|
| Engine Oil | 10W30 SF/CD | 58.7 L (62 qt US) |
| Coolant Glycol/Water | 1:1 Ratio of 80.4 L (85 qt US) | |
| Fuel Oil | No. 2 Diesel | 1515 L (400 gal US) |

Cooling System Pressure 48 kPa (7 psi)
Engine Oil Pressure 200-410 kPa (30-60 psi)

1.1.2 Torque Values

Engine Mounts 95 N·m (70 lbf ft)
Starter Mounting Bolts 90 N·m (65 lbf ft)
Hydraulic Pump Mounting Bolts 90 N·m (65 lbf ft)
Fan Bolts 144 N·m (106 lbf ft)
Alternator Pulley Nut 108 N·m (80 lbf ft)

NOTE

For capscrews and nuts not specified in this section refer to Table 2-2.

1.1.3 Filters

Refer to Table 2-3.

1-2 TROUBLESHOOTING

Refer to Table 2-4, Troubleshooting Engine Systems. The troubleshooting chart lists most problems related to the engine systems. For more detailed troubleshooting information, refer to Cummins Service Bulletin No. 983643-CE "Tuneup Troubleshooting".

1.3 ENGINE REPLACEMENT

1.3.1 Special Tools and Equipment

1. Hoist, 2 700 kg (3 ton) capacity
2. Lifting fixture (Cummins Part ST-1258)
3. Two lift hooks (Cummins Part ST-1286)
4. Engine stand
5. Hose plugs

1.3.2 Removal

- CAUTION

SET PARKBRAKE, CHOCK WHEELS AND ENGAGE ARTICULATION LOCK BEFORE SERVICING TRACTOR.



DISCONNECT BATTERY CABLES FIRST, TO PREVENT ELECTRICAL DAMAGE FROM OCCURRING.

1. Drain engine oil from pan. Allow 10 min to drain completely and install drain plug. Torque to 90 N·m (65 lbf ft).
2. Drain cooling system through stopcock ports. Allow 15 min to drain system and tighten stopcocks.

TABLE 2-2: General Recommended Capscrew Torque Values

| CAPSCREW SIZE | CLASS 9.8 (METRIC)*ARE CLASS 8.8 | | CLASS 10.9 (METRIC) | |
|------------------|----------------------------------|-----------------------|-----------------------|----------------------|
| | PLAIN | PLATED | PLAIN | PLATED |
| M6 x 1.0 | 10 N·m (7 lbf ft) | 10 N·m (7 lbf ft) | 15 N·m (10 lbf ft) | 10 N·m (7 lbf ft) |
| M8 x 1.25 | 30 N·m (20 lbf ft) | 20 N·m (15 lbf ft) | 35 N·m (25 lbf ft) | 25 N·m (18 lbf ft) |
| M10 x 1.5 | 55 N·m (40 lbf ft) | 40 N·m (30 lbf ft) | 70 N·m (50 lbf ft) | 55 N·m (40 lbf ft) |
| M12 x 1.75 | 100 N·m (75 lbf ft) | 75 N·m (55 lbf ft) | 125 N·m (95 lbf ft) | 95 N·m (70 lbf ft) |
| M14 x 2.0 | 155 N·m (115 lbf ft) | 120 N·m (90 lbf ft) | 200 N·m (150 lbf ft) | 150 N·m (105 lbf ft) |
| M16 x 2.0 | *255 N·m (170 lbf ft) | *170 N·m (120 lbf ft) | 315 N·m (235 lbf ft) | 235 N·m (175 lbf ft) |
| M20 x 2.5 | *440 N·m (330 lbf ft) | *330 N·m (220 lbf ft) | 610 N·m (450 lbf ft) | 460 N·m (340 lbf ft) |
| M24 x 3.0 | *765 N·m (570 lbf ft) | 510 N·m (420 lbf ft) | 1055 N·m (780 lbf ft) | 790 N·m (580 lbf ft) |

| CAPSCREW SIZE | GRADE 5 (IMPERIAL) | | GRADE 8 (IMPERIAL) | |
|------------------|-----------------------|----------------------|------------------------|-----------------------|
| | PLAIN | PLATED | PLAIN | PLATED |
| 3/8-16 | 40 N·m (30 lbf ft) | 35 N·m (25 lbf ft) | 65 N·m (45 lbf ft) | 50 N·m (35 lbf ft) |
| 3/8-24 | 50 N·m (35 lbf ft) | 35 N·m (25 lbf ft) | 70 N·m (50 lbf ft) | 50 N·m (35 lbf ft) |
| 7/16-14 | 70 N·m (50 lbf ft) | 50 N·m (35 lbf ft) | 95 N·m (70 lbf ft) | 72 N·m (55 lbf ft) |
| 7/16-20 | 75 N·m (55 lbf ft) | 55 N·m (40 lbf ft) | 105 N·m (80 lbf ft) | 80 N·m (60 lbf ft) |
| 1/2-13 | 100 N·m (75 lbf ft) | 75 N·m (55 lbf ft) | 140 N·m (105 lbf ft) | 105 N·m (80 lbf ft) |
| 1/2-20 | 115 N·m (85 lbf ft) | 90 N·m (65 lbf ft) | 165 N·m (200 lbf ft) | 120 N·m (90 lbf ft) |
| 9/16-12 | 7115 N·m (110 lbf ft) | 105 N·m (80 lbf ft) | 210 N·m (155 lbf ft) | 155 N·m (115 lbf ft) |
| 9/16-18 | 165 N·m (120 lbf ft) | 120 N·m (90 lbf ft) | 230 N·m (170 lbf ft) | 175 N·m (130 lbf ft) |
| 5/8-11 | 205 N·m (150 lbf ft) | 155 N·m (115 lbf ft) | 285 N·m (210 lbf ft) | 215 N·m (160 lbf ft) |
| 5/8-18 | 230 N·m (170 lbf ft) | 175 N·m (130 lbf ft) | 325 N·m (240 lbf ft) | 240 N·m (180 lbf ft) |
| 3/4-10 | 360 N·m (265 lbf ft) | 270 N·m (200 lbf ft) | 510 N·m (375 lbf ft) | 380 N·m (280 lbf ft) |
| 3/4-16 | 400 N·m (295 lbf ft) | 300 N·m (225 lbf ft) | 510 N·m (420 lbf ft) | 430 N·m (315 lbf ft) |
| 7/8-9 | 580 N·m (430 lbf ft) | 440 N·m (320 lbf ft) | 820 N·m (605 lbf ft) | 615 N·m (455 lbf ft) |
| 7/8-14 | 640 N·m (475 lbf ft) | 480 N·m (355 lbf ft) | 905 N·m (670 lbf ft) | 680 N·m (500 lbf ft) |
| 1-8 | 875 N·m (645 lbf ft) | 655 N·m (485 lbf ft) | 1230 N·m (910 lbf ft) | 925 N·m (680 lbf ft) |
| 1-14 | 975 N·m (720 lbf ft) | 735 N·m (540 lbf ft) | 1380 N·m (1020 lbf ft) | 1040 N·m (765 lbf ft) |

TABLE 2-3: Replacement Filter Part Numbers

| Component | Part Number |
|--------------------------|-------------|
| Engine Crankcase Filters | 31133 |
| Engine Bypass Filter | 57124 |
| Primary Air Filter | 63971 |
| Safety Air Filter | 63972 |
| Fuel Filter | 61559 |
| Water Filter | 25881 |
| Water Filter - Precharge | 26206 |

- Remove exhaust temperature and air intake vacuum sender connectors from engine harness (Figure 2-1).
- Release clamps at both ends of exhaust pipe. Remove exhaust pipe and cover turbocharger and muffler openings.

- Cut tie straps from aspirator hose and remove hose from muffler and air cleaner.
- Release clamps at both ends of air intake tube. Remove intake tube and cover air cleaner and turbocharger openings.
- Remove fan guards from tractor frame hinges.
- Remove heater return hose from water pump housing.
- Loosen clamps and remove water pump inlet hose.
- Loosen radiator hose clamps at thermostat housing and remove hose.

TABLE 2-4: Troubleshooting Engine Systems




FIGURE 2-1: Tractor Right Side




FIGURE 2-2: Engine Right Side




FIGURE 2-3: Starter Wiring

NOTE

Label all sender wires to ensure proper installation.

11. Disconnect coolant temperature sender from the engine harness (Figure 2-2).
12. Remove heater supply hose from thermostat housing.

13. Remove engine oil bypass filter supply hose from engine adaptor and return hose from drain pan.
14. Remove 12 volt battery cable from alternator. Disconnect charge sender wire.
15. Label and remove battery cable from starter, and secure cables away from engine (Figure 2-3).

16. Disconnect magnetic start switch harness from starter. Label each wire.
17. Disconnect thermoguard from engine harness (Figure 2-4).

- CAUTION



BE ALERT

DO NOT DISCONNECT AIR CONDITIONING HOSES. SYSTEM MUST REMAIN CLOSED TO PREVENT CONTAMINATING LINES OR DISCHARGING REFRIGERANT.




FIGURE 2-4: Cold Start

18. Remove cold start hose from valve. Secure hose behind retainer clip on engine.
19. Label and disconnect oil pressure sender wire from oil filter.
20. Remove air conditioning hoses mounting clamp from engine (Figure 2-5).
21. Loosen three capscrews and remove compressor pulley dust shield.
22. Relieve compressor belt tension and remove belts.
23. Disconnect compressor connector from engine harness.
24. Remove four capscrews, plainwashers and nuts from compressor and remove compressor from mounting bracket. Secure compressor to frame.
25. Disconnect tachometer sender from engine harness.
26. Disconnect fuel pump D.C. solenoid and decelerator from engine harness.

- WARNING



BE ALERT

IF CLOTHES ARE SPLASHED WITH FUEL, CHANGE IMMEDIATELY. FUEL-SOAKED CLOTHES ARE AN EXTREME FIRE HAZARD.

27. Remove fuel pump supply and injector return lines from engine.
28. Remove throttle cable from mounting bracket. Thread nuts back on cable.
29. Remove hydraulic pump mounting capscrews. Ease each pump from engine and secure to tractor frame.

NOTE

Do not remove hydraulic hoses from pumps to eliminate risk of contaminating hydraulic system.




FIGURE 2-5: Engine Left Side

30. Remove clutch bearing lubrication hoses from clutch housing fittings (Figure 2-6).
31. Remove clevis pin from yoke end of clutch control rod.
32. Scribe first universal joint and cap (to ensure proper assembly). Disconnect driveline at universal joint.
33. Remove four capscrews from front and rear hood supports.
34. Using a hoist remove hood from tractor.
35. Remove one capscrew from steering valve shaft (Figure 2-7). Loosen four capscrews and remove steering valve from bracket. Tie valve to frame away from engine.
36. Secure lifting hooks to No. 1 and No. 5 cylinder head lift points (Figure 2-8). Attach lifting fixture.
37. Remove front and rear engine mount capscrews and upper isolator hardware. Remove ground cable from left rear engine mount.




FIGURE 2-6: Clutch and Driveline




FIGURE 2-7: Steering Valve Removal

IMPORTANT

Raise engine slowly to prevent damage.

38. Raise engine out of tractor and mount on engine stand (See Cummins shop repair manual).
39. Remove lower isolator pads from tractor frame.

1.3.3 Installation

1. Put lower isolator pads over tractor frame mounting holes.
2. Position engine over tractor and lower into frame. Maintain sufficient clearance from firewall components while lowering engine.




FIGURE 2-8: Engine Lift System

IMPORTANT

Lower engine cautiously to prevent damage.

3. Ensure engine mounts, isolator pads and tractor frame holes are properly aligned.

- CAUTION



DO NOT PUT FINGERS BETWEEN FRAME AND ENGINE MOUNTS. USE A TOOL TO POSITION ISOLATOR PADS.

BE ALERT

4. Install one upper isolator pad, washer, capscrew, flatwasher and locknut on each mount. Torque locknut to 95 N·m (70 lbf ft).
5. Secure ground cable to left rear engine mount with one capscrew and nut. Torque to 55 N·m (40 lbf ft).
6. Remove lifting fixture and hooks from engine.
7. Use hoist to position hood over tractor and lower into place.
8. Secure hood to frame with four capscrews.
9. Align universal joint scribe marks and connect the driveline. Install universal joint to yoke with a soft hammer. Torque capscrews to 100 N·m (75 lbf ft).
10. Secure clutch control rod to linkage with a clevis pin and a cotterpin. Connect lubrication hoses to clutch housing fittings.
11. Install steering valve to shaft with a capscrew. Secure valve to the mounting bracket with four capscrews, bushings and eight plainwashers.
12. Install hydraulic pumps to engine with four capscrews and lockwashers. Torque to 90 N·m (60 lbf ft).

13. Install throttle cable to mounting bracket with two hex nuts and lockwashers (Figure 2-9).
14. Secure cable plate to end of cable with two hex nuts and lockwashers.
15. Fasten decelerator connector and DC solenoid terminal to engine harness.
16. Connect tachometer sender to wire connector on engine harness.
17. Install air conditioner compressor to bracket with four capscrews, plainwashers and locknuts. Attach belt and set tension to 40 kg (90 lbs).
18. Fasten air conditioner compressor wire to engine harness.
19. Secure air conditioner compressor hose clamp to engine with one flange screw. Torque to 10 N·m (7 lbf ft).
20. Install fuel supply line to injector pump. Install fuel return line to engine adaptor.
21. Connect oil pressure sender to engine harness.
22. Install cold start hose and nut to valve. Secure thermoguard harness to connector.




FIGURE 2-9: Throttle Cable Installation

Sample of manual. Download All 290 pages at:

<https://www.arepairmanual.com/downloads/new-holland-ford-1150-tractor-service-repair-manual/>